

ENGINE LUBRICATION & COOLING SYSTEMS

SECTION LC

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

CONTENTS

ENGINE LUBRICATION SYSTEM	2	CHECKING RADIATOR CAP	10
Precautions	2	Water Pump	10
LIQUID GASKET APPLICATION PROCEDURE.....	2	REMOVAL.....	10
Preparation	2	INSPECTION.....	11
SPECIAL SERVICE TOOLS	2	INSTALLATION.....	11
Lubrication Circuit.....	3	Thermostat.....	12
Oil Pressure Check.....	4	REMOVAL AND INSTALLATION.....	12
Oil Pump.....	4	INSPECTION.....	13
REMOVAL.....	4	Water Outlet.....	13
DISASSEMBLY AND ASSEMBLY.....	5	INSPECTION.....	13
INSPECTION.....	5	INSTALLATION.....	13
REGULATOR VALVE INSPECTION	6	Radiator	14
INSTALLATION.....	7	COMPONENTS	14
Oil Filter	7	Cooling Fan Control System	14
ENGINE COOLING SYSTEM	8	Refilling Engine Coolant	15
Precautions	8	Overheating Cause Analysis	15
LIQUID GASKET APPLICATION PROCEDURE.....	8	SERVICE DATA AND SPECIFICATIONS (SDS)	17
Preparation	8	Oil Pressure Check.....	17
SPECIAL SERVICE TOOLS	8	Regulator Valve Inspection.....	17
Cooling Circuit	9	Oil Pump Inspection	17
System Check.....	9	Thermostat.....	17
CHECKING COOLING SYSTEM HOSES.....	9	Radiator	17
CHECKING COOLING SYSTEM FOR LEAKS.....	9		
CHECKING RADIATOR.....	10		

ENGINE LUBRICATION SYSTEM

Precautions



Precautions

LIQUID GASKET APPLICATION PROCEDURE

NCLC0001




1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. **(Use Genuine RTV silicone sealant part No. 999MP-A7007 or equivalent.)**
 - For oil pan, be sure liquid gasket diameter is 4.0 to 5.0 mm (0.157 to 0.197 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.

Preparation

SPECIAL SERVICE TOOLS


NCLC0002

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J34301-C) Oil pressure gauge set 1 (J34301-1) Oil Pressure gauge 2 (J34301-2) Hoses 3 (J34298) Adapter 4 (J34282-1) Adapter 5 (790-301-1230-A) 60° adapter 6 (J34301-15) Square socket	 <p>Measuring oil pressure Maximum measuring range: 1,379 kPa (14 kg/cm², 200 psi)</p> <p>AAT896</p>
ST25052000 (J25695-2) Hose	 <p>Adapting oil pressure gauge to cylinder block</p> <p>NT559</p>
KV10115801 (J38956) Oil filter wrench	 <p>Removing oil filter</p> <p>14 faces, inner span: 64.3 mm (2.531 in) (Face to opposite face)</p> <p>NT362</p>

ENGINE LUBRICATION SYSTEM

Preparation (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description
WS39930000 (—) Tube presser	 <p>Pressing the tube of liquid gasket</p> <p>NT052</p>

GI


MA

EM

LC

Lubrication Circuit

NCLC0003



EC

FE

CL


MT

AT

AX

SU

BR



ST

RS

BT

HA



SC

EL

IDX

ENGINE LUBRICATION SYSTEM

Oil Pressure Check



Oil Pressure Check

NCLC0004

WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- For M/T models, put gearshift lever in Neutral "N" position. For A/T models, put selector lever in Park "P" position.

1. Check oil level.
2. Remove oil pressure switch.

3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 78 (0.8, 11)
3,200	314 - 392 (3.2 - 4.0, 46 - 57)

- If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.

Oil Pump

REMOVAL

NCLC0005


1. Remove drive belts.
2. Remove cylinder head. Refer to EM section ("Removal", "CYLINDER HEAD").
3. Remove oil pans. Refer to EM section ("Removal", "OIL PAN").
4. Remove oil strainer and baffle plate.
5. Remove front cover assembly.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)

DISASSEMBLY AND ASSEMBLY

NCLC0006



1. Oil pump cover
2. Front cover
3. Inner gear
4. Outer gear

5. Regulator valve
6. Spring
7. Shim

8. Plug
9. Regulator valve assembly
10. Oil strainer

INSPECTION

Using a feeler gauge, check the following clearances:

Standard clearance:




Unit: mm (in)

Body to outer gear radial clearance 1	0.114 - 0.200 (0.0045 - 0.0079)
Inner gear to outer gear tip clearance 2	Below 0.18 (0.0071)
Body to inner gear clearance 3	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer gear axial clearance 4	0.05 - 0.11 (0.0020 - 0.0043)
Inner gear to brazed portion of housing clearance 5	0.045 - 0.091 (0.0018 - 0.0036)


- If the tip clearance (2) exceeds the limit, replace gear set.
- If body to gear clearances (1, 3, 4, 5) exceed the limit, replace front cover assembly.

ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)



SLC854A




REGULATOR VALVE INSPECTION


NCLC0008

1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.
 - If damaged, replace regulator valve set or oil pump assembly.
4. Check regulator valve to oil pump cover clearance.

Clearance:
6: 0.040 - 0.097 mm (0.0016 - 0.0038 in)

 - If it exceeds the limit, replace oil pump cover.





INSTALLATION

NCLC0009


- Always replace oil seal and O-ring with new ones. Refer to EM section ("OIL SEAL REPLACEMENT").
- When installing oil pump, apply engine oil to gears.
- Be sure that O-rings are properly fitted.
- Use a scraper to remove old liquid gasket from mating surface of front cover.
- Also remove traces of liquid gasket from mating surface of cylinder block.

GI

MA

EM

LC




1. Apply a continuous bead of liquid gasket to mating surface of front cover assembly.
- Use Genuine RTV silicone sealant part No. 999MP-A7007 or equivalent.
2. Installation is the reverse order of removal.

EC

FE

CL

MT



Oil Filter

NCLC0010

The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- The new and previous oil filter designs differ from each other and are not interchangeable.
- Use Tool KV10115801 (J38956) for removing oil filter.

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

ENGINE COOLING SYSTEM

Precautions



Precautions

LIQUID GASKET APPLICATION PROCEDURE

NCLC0014


1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. **(Use Genuine RTV silicone sealant part No. 999MP-A7007 or equivalent.)**
 - For oil pan, be sure liquid gasket diameter is 4.0 to 5.0 mm (0.157 to 0.197 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.

Preparation

SPECIAL SERVICE TOOLS


NCLC0015

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
EG17650301 (J33984-A) Radiator cap tester adapter	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Adapting radiator cap tester to radiator filler neck</p> <p>a: 28 (1.10) dia.</p> <p>b: 31.4 (1.236) dia.</p> <p>c: 41.3 (1.626) dia.</p> <p>Unit: mm (in)</p> </div> </div> <p style="margin-top: 10px;">NT564</p>

ENGINE COOLING SYSTEM

Cooling Circuit



System Check

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

CHECKING COOLING SYSTEM HOSES

Check hoses for the following:

- Improper attachment
- Leaks
- Cracks
- Damage
- Chafing
- Deterioration

CHECKING COOLING SYSTEM FOR LEAKS


To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure:

157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher pressure than specified may cause radiator damage.



ENGINE COOLING SYSTEM


System Check (Cont'd)

CHECKING RADIATOR

NCLC0017S04

Check radiator for mud or clogging. If necessary, clean radiator as follows.

- Be careful not to bend or damage the radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns. Then tape the harness and connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downward.
 2. Apply water again to all radiator core surfaces once per minute.
 3. Stop washing if any stains no longer flow out from the radiator.
 4. Blow air into the back side of radiator core vertically downward.
 - Use compressed air lower than 490 kPa (5 kg/cm², 71 psi) and keep distance more than 30 cm (11.8 in).
 5. Blow air again into all the radiator core surfaces once per minute until no water sprays out.



CHECKING RADIATOR CAP

NCLC0017S03

To check radiator cap, apply pressure to cap with a tester.


Radiator cap relief pressure:

Standard


78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)



Pull the negative pressure valve to open it.
Check that it closes completely when released.




Water Pump

REMOVAL

NCLC0018

1. Drain coolant from radiator.
2. Remove cylinder block drain plug located at left front of cylinder block and drain coolant.
3. Remove front RH wheel and engine side cover.
4. Remove drive belts. Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").
5. Remove RH engine mounting. Refer to EM section ("ENGINE REMOVAL").



6. Remove water pump.

CAUTION:


- When removing water pump assembly, be careful not to get coolant on drive belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.

GI

MA

EM

LC



INSPECTION

- Check body assembly for rust or corrosion.
- Check for rough operation due to excessive end play.


NCLG0019

EC

FE

CL

MT



INSTALLATION

1. Use a scraper to remove liquid gasket from water pump.
 - Also remove traces of liquid gasket from mating surface of cylinder block.


NCLC0020

AT

AX

SU

BR



2. Apply a continuous bead of liquid gasket to mating surface of water pump.

- Use Genuine RTV silicone sealant part No. 999MP-A7007 or equivalent.

When filling radiator with coolant, refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
When installing drive belts, refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").

ST

RS

BT

HA

SC

EL

IDX


ENGINE COOLING SYSTEM

Thermostat

Thermostat REMOVAL AND INSTALLATION

NCLC0021


SEC. 210



ALC085

Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.


1. Drain engine coolant.
2. Remove lower radiator hose.
3. Remove water inlet, then take out thermostat.



4. Install thermostat with jiggle valve or air bleeder at upper side.
 - **Apply a continuous bead of liquid gasket to mating surface of water inlet.**
 - **After installation, run engine for a few minutes, and check for leaks.**

ENGINE COOLING SYSTEM

Thermostat (Cont'd)




INSPECTION

NCLC0022

1. Check for valve seating condition at normal room temperature. It should seat tightly.
2. Check valve opening temperature and valve lift.

Valve opening temperature °C (°F)	76.5 (170)
Valve lift mm/°C (in/°F)	More than 8/90 (0.31/194)

3. Then check if valve closes at 5°C (9°F) below valve opening temperature.




Water Outlet

INSPECTION

NCLC0023

Visually inspect for water leaks. If there is leakage, apply liquid gasket.



INSTALLATION

NCLC0024

1. Use a scraper to remove old liquid gasket from water outlet.
 - Also remove traces of liquid gasket from mating surface of cylinder head.
2. Apply a continuous bead of liquid gasket to mating surface of water outlet.
 - Use Genuine RTV silicone sealant part No. 999MP-A7007 or equivalent.
 - When installing, tighten water outlet bolts to the specified torque.

: 6.3 - 8.3 N·m (0.64 - 0.85 kg·m, 55.6 - 73.8 in·lb)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ENGINE COOLING SYSTEM

Radiator

Radiator COMPONENTS

NCLC0025



- | | | |
|---------------------|---------------------------------|-------------------------|
| 1. Reservoir tank | 5. Washer | 9. Cooling fan assembly |
| 2. Mounting bracket | 6. Oil cooler hose (A/T models) | 10. Upper hose |
| 3. Mounting rubber | 7. Lower hose | 11. Radiator cap |
| 4. Radiator | 8. Air guide plate | |

Cooling Fan Control System

Cooling fans are controlled by the ECM. For details, refer to EC section ("Cooling Fan", "TROUBLE DIAGNOSIS FOR DTC P1900").

NCLC0026

ENGINE COOLING SYSTEM

Refilling Engine Coolant

Refilling Engine Coolant

For details on refilling engine coolant, refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").

NCLC0027

GI

MA

EM

LC

Overheating Cause Analysis

NCLC0028

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

		Symptom	Check items	
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—
		Thermostat stuck closed	—	
		Damaged fins	Dust contamination or paper clogging	
			Mechanical damage	
	Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)		
	Reduced air flow	Cooling fan does not operate	—	—
		High resistance to fan rotation		
		Damaged fan blades		
	Damaged radiator shroud	—	—	—
	Improper coolant mixture ratio	—	—	—
	Poor coolant quality	—	—	—
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp
				Cracked hose
			Water pump	Poor sealing
			Radiator cap	Loose
Poor sealing				
Radiator			O-ring for damage, deterioration or improper fitting	
		Cracked radiator tank		
	Cracked radiator core			
Reservoir tank	Cracked reservoir tank			
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration		
		Cylinder head gasket deterioration		

ENGINE COOLING SYSTEM

Overheating Cause Analysis (Cont'd)

		Symptom		Check items	
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load	—
				Driving in low gear for extended time	
				Driving at extremely high speed	
			Powertrain system malfunction		
			Installed improper size wheels and tires		
				Dragging brakes	
				Improper ignition timing	
	Blocked or restricted air flow		Blocked bumper	---	—
		Blocked radiator grille		Installed car brassiere	
				Mud contamination or paper clogging	
		Blocked radiator	—		
		Blocked condenser	---		
	Installed large fog lamp	---			

SERVICE DATA AND SPECIFICATIONS (SDS)

Oil Pressure Check

Oil Pressure Check

NCLC0011

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)	GI
Idle speed	More than 78 (0.8, 11)	MA
3,200	314 - 392 (3.2 - 4.0, 46 - 57)	

Regulator Valve Inspection

NCLC0012
Unit: mm (in)

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)	LC
---	---------------------------------	----

Oil Pump Inspection

NCLC0013
Unit: mm (in)

Body to outer gear radial clearance	0.114 - 0.200 (0.0045 - 0.0079)	EC
Inner gear to outer gear tip clearance	Below 0.18 (0.0071)	FE
Body to inner gear clearance	0.05 - 0.09 (0.0020 - 0.0035)	
Body to outer gear axial clearance	0.05 - 0.11 (0.0020 - 0.0043)	CL
Inner gear to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)	MT

Thermostat

NCLC0029

Valve opening temperature °C (°F)	76.5 (170)	AT
Valve lift mm/°C (in/°F)	More than 8/90 (0.31/194)	

Radiator

NCLC0030
Unit: kPa (kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)	SU
	Limit	59 - 98 (0.6 - 1.0, 9 - 14)	
Leakage test pressure		157 (1.6, 23)	BR

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX