

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

PRECAUTIONS	3	Component Parts and Harness Connector Location..	33
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	Schematic	34
Precautions For Trouble Diagnosis	3	Wiring Diagram - CAN -	35
CAN SYSTEM	3	Work Flow	38
Precautions For Harness Repair	3	CHECK SHEET	39
CAN SYSTEM	3	CHECK SHEET RESULTS (EXAMPLE)	40
CAN COMMUNICATION	4	Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit	47
System Description	4	ECM Circuit Check	48
CAN Communication Unit	4	Combination Meter Circuit Check	49
TYPE 1/TYPE 3	4	BCM Circuit Check	49
TYPE 2	6	Steering Angle Sensor Circuit Check	50
CAN SYSTEM (TYPE 1)	8	VDC/TCS/ABS Control Unit Circuit Check	50
System Description	8	IPDM E/R Circuit Check	51
Component Parts and Harness Connector Location..	8	CAN Communication Circuit Check	52
Schematic	9	IPDM E/R Ignition Relay Circuit Check	54
Wiring Diagram - CAN -	10	Component Inspection	54
Work Flow	13	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	54
CHECK SHEET	14	CAN SYSTEM (TYPE 3)	55
CHECK SHEET RESULTS (EXAMPLE)	15	System Description	55
Circuit Check Between TCM and Data Link Connector	24	Component Parts and Harness Connector Location..	55
Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit	25	Schematic	56
ECM Circuit Check	26	Wiring Diagram - CAN -	57
TCM Circuit Check	26	Work Flow	60
Combination Meter Circuit Check	27	CHECK SHEET	61
BCM Circuit Check	27	CHECK SHEET RESULTS (EXAMPLE)	62
Steering Angle Sensor Circuit Check	28	Circuit Check Between TCM and Data Link Connector	71
VDC/TCS/ABS Control Unit Circuit Check	28	Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit	72
IPDM E/R Circuit Check	29	ECM Circuit Check	73
CAN Communication Circuit Check	30	TCM Circuit Check	73
IPDM E/R Ignition Relay Circuit Check	32	Combination Meter Circuit Check	74
Component Inspection	32	BCM Circuit Check	74
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	32	Steering Angle Sensor Circuit Check	75
CAN SYSTEM (TYPE 2)	33	VDC/TCS/ABS Control Unit Circuit Check	75
System Description	33	IPDM E/R Circuit Check	76
		CAN Communication Circuit Check	77

F
G
H
I
J
LAN
L
M

IPDM E/R Ignition Relay Circuit Check	79	IGNITION	79
Component Inspection	79		
ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-			

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS000LU

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions For Trouble Diagnosis
CAN SYSTEM**


AKS000BF

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


**Precautions For Harness Repair
CAN SYSTEM**

AKS000BG

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION

PFP:23710

System Description

AKS000D9

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS000DA


Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan		
Axle	2WD		
Engine	VQ35DE		
Transmission	A/T	M/T	
Brake control	VDC		
CAN system type	1	3	2
CAN system trouble diagnosis	LAN-8 (Up to serial 329287*)	LAN-55 (From serial 329288*)	LAN-33

*: For further information, refer to [GI-47, "IDENTIFICATION NUMBER"](#) .

TYPE 1/TYPE 3

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
Engine torque signal	T	R					
Engine speed signal	T	R	R			R	
Engine coolant temperature signal	T	R	R				
Accelerator pedal position signal	T	R				R	
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
Stop lamp switch signal		R	T				
Fuel consumption monitor signal	T		R				
A/T self-diagnosis signal	R	T					
A/T CHECK indicator lamp signal		T	R				
A/T position indicator signal		T	R			R	
ABS operation signal		R				T	
A/T shift schedule change demand signal		R				T	
A/C switch signal	R			T			
A/C compressor request signal	T						R
A/C compressor feedback signal	T		R				
Blower fan motor switch signal	R			T			
Cooling fan motor operation signal	T						R
Position lights request signal			R	T			R
Low beam request signal				T			R
Low beam status signal	R						T
High beam request signal			R	T			R
High beam status signal	R						T
Front fog lights request signal				T			R
Vehicle speed signal			R			T	
	R	R	T	R			
Sleep request 1 signal			R	T			
Sleep request 2 signal				T			R
Wake up request 1 signal			R	T			R
Wake up request 2 signal			R	T			R
Door switch signal (without naviga- tion system)			R	T			R
Door switch signal (with navigation system)			T	R			
Turn indicator signal			R	T			
Seat belt buckle switch signal			T	R			
Oil pressure switch signal			R				T
Buzzer output signal			R	T			
ASCD SET lamp signal	T		R				
ASCD CRUISE lamp signal	T		R				
ASCD OD cancel request signal	T	R					
ASCD operation signal	T	R					
Output shaft revolution signal	R	T					
Front wiper request signal				T			R
Front wiper stop position signal				R			T
Rear window defogger switch signal				T			R
Rear window defogger control sig- nal	R						T
Manual mode signal		R	T				

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
Not manual mode signal		R	T				
Manual mode shift up signal		R	T				
Manual mode shift down signal		R	T				
Manual mode indicator signal		T	R				
Hood switch signal				R			T
Theft warning horn request signal				T			R
Horn chirp signal				T			R
Steering angle sensor signal					T	R	
Malfunction indicator lamp signal (Type 3 only: From serial 329288*)	T		R				
Fuel level sensor signal (Type 3 only: From serial 329288*)	R		T				
Turbine revolution signal (Type 3 only: From serial 329288*)	R	T					

*: For further information, refer to [GI-47, "IDENTIFICATION NUMBER"](#) .

TYPE 2

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
Engine speed signal	T	R			R	
Engine coolant temperature signal	T	R				
Accelerator pedal position signal	T				R	
Fuel consumption monitor signal	T	R				
A/C switch signal	R		T			
A/C compressor request signal	T					R
A/C compressor feedback signal	T	R				
Blower fan motor switch signal	R		T			
Cooling fan motor operation signal	T					R

CAN COMMUNICATION

[CAN]

Signals	ECM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R	
Position lights request signal		R	T			R	A
Low beam request signal			T			R	B
Low beam status signal	R		R			T	
High beam request signal		R	T			R	C
High beam status signal	R		R			T	
Front fog lights request signal			T			R	
Vehicle speed signal		R			T		D
	R	T	R				
Sleep request 1 signal		R	T				E
Sleep request 2 signal			T			R	
Wake up request 1 signal		R	T				
Wake up request 2 signal		R	T				F
Door switch signal (without navigation system)		R	T			R	
Door switch signal (with navigation system)		T	R				G
Turn indicator signal		R	T				
Seat belt buckle switch signal		T	R				
Oil pressure switch signal		R				T	H
Buzzer output signal		R	T				
Malfunction indicator lamp signal	T	R					I
ASCD SET lamp signal	T	R					
ASCD CRUISE lamp signal	T	R					
Fuel level sensor signal	R	T					J
Front wiper request signal			T			R	
Front wiper stop position signal			R			T	
Rear window defogger switch signal			T			R	LAN
Rear window defogger control signal	R		R			T	
Hood switch signal			R			T	
Theft warning horn request signal			T			R	L
Horn chirp signal			T			R	
Steering angle sensor signal				T	R		M

CAN SYSTEM (TYPE 1)


System Description

AKS009BH

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS009BI




CAN SYSTEM (TYPE 1)

[CAN]

Schematic

AKS009BJ



A
B
C
D
E
F
G
H
I
J
LAN
L
M

TKWT0385E

CAN SYSTEM (TYPE 1)


[CAN]

Wiring Diagram - CAN -

AKS009BK

LAN-CAN-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(F101), (F103) -ELECTRICAL UNITS



TKWT0954E

CAN SYSTEM (TYPE 1)


[CAN]

LAN-CAN-02


▬ : DATA LINE



(M8)
W



(M20)
W





(M22)
W

REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS

TKWT0955E

LAN-CAN-03

▬ : DATA LINE



E9
W



REFER TO THE FOLLOWING.

E108 -SUPER MULTIPLE JUNCTION (SMJ)

E118 -ELECTRICAL UNITS

TKWT0956E

Work Flow

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM" and "ABS" displayed on CONSULT-II.

(Example)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT DIAG MODE</td></tr> <tr><td style="text-align: center;">WORK SUPPORT</td></tr> <tr><td style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DATA MONITOR</td></tr> <tr><td style="text-align: center;">DATA MONITOR (SPEC)</td></tr> <tr><td style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;">Scroll Down</td></tr> <tr><td style="text-align: center;">BACK LIGHT COPY</td></tr> </table>	SELECT DIAG MODE	WORK SUPPORT	SELF-DIAG RESULTS	DATA MONITOR	DATA MONITOR (SPEC)	CAN DIAG SUPPORT MNTR	ACTIVE TEST		Scroll Down	BACK LIGHT COPY		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DTC RESULTS</td><td style="text-align: center;">TIME</td></tr> <tr><td style="text-align: center;">CAN COMM CIRCUIT [U1000]</td><td style="text-align: center;">0</td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> <tr><td colspan="2" style="text-align: center;">F.F.DATA</td></tr> <tr><td style="text-align: center;">ERASE</td><td style="text-align: center;">PRINT</td></tr> <tr><td style="text-align: center;">MODE BACK LIGHT COPY</td></tr> </table>	SELF-DIAG RESULTS		DTC RESULTS	TIME	CAN COMM CIRCUIT [U1000]	0					F.F.DATA		ERASE	PRINT	MODE BACK LIGHT COPY
SELECT DIAG MODE																											
WORK SUPPORT																											
SELF-DIAG RESULTS																											
DATA MONITOR																											
DATA MONITOR (SPEC)																											
CAN DIAG SUPPORT MNTR																											
ACTIVE TEST																											
Scroll Down																											
BACK LIGHT COPY																											
SELF-DIAG RESULTS																											
DTC RESULTS	TIME																										
CAN COMM CIRCUIT [U1000]	0																										
F.F.DATA																											
ERASE	PRINT																										
MODE BACK LIGHT COPY																											

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM" and "ABS" displayed on CONSULT-II.

(Example)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT DIAG MODE</td></tr> <tr><td style="text-align: center;">WORK SUPPORT</td></tr> <tr><td style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DATA MONITOR</td></tr> <tr><td style="text-align: center;">DATA MONITOR (SPEC)</td></tr> <tr><td style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;">Scroll Down</td></tr> <tr><td style="text-align: center;">BACK LIGHT COPY</td></tr> </table>	SELECT DIAG MODE	WORK SUPPORT	SELF-DIAG RESULTS	DATA MONITOR	DATA MONITOR (SPEC)	CAN DIAG SUPPORT MNTR	ACTIVE TEST		Scroll Down	BACK LIGHT COPY		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2" style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;">PRSNT</td></tr> <tr><td style="text-align: center;">INITIAL DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">TRANSMIT DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">TCM</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">VDC/TCS/ABS</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">METER/M&A</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">ICC</td><td style="text-align: center;">UNKWN</td></tr> <tr><td style="text-align: center;">BCM/SEC</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">IPDM E/R</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">AWD/4WD/e4WD</td><td style="text-align: center;">UNKWN</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Down</td></tr> <tr><td style="text-align: center;">MODE BACK LIGHT COPY</td></tr> </table>	CAN DIAG SUPPORT MNTR		ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE BACK LIGHT COPY
SELECT DIAG MODE																																							
WORK SUPPORT																																							
SELF-DIAG RESULTS																																							
DATA MONITOR																																							
DATA MONITOR (SPEC)																																							
CAN DIAG SUPPORT MNTR																																							
ACTIVE TEST																																							
Scroll Down																																							
BACK LIGHT COPY																																							
CAN DIAG SUPPORT MNTR																																							
ENGINE																																							
	PRSNT																																						
INITIAL DIAG	OK																																						
TRANSMIT DIAG	OK																																						
TCM	OK																																						
VDC/TCS/ABS	OK																																						
METER/M&A	OK																																						
ICC	UNKWN																																						
BCM/SEC	OK																																						
IPDM E/R	OK																																						
AWD/4WD/e4WD	UNKWN																																						
PRINT	Scroll Down																																						
MODE BACK LIGHT COPY																																							

PKIA8343E

- Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-14, "CHECK SHEET"](#).
- Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG", or "UNKWN" in the check sheet table. Refer to [LAN-14, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-15, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

Symptoms :

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
---	--	--	--

Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR
--	---	---	---

PKIB0278E

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-24, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN	—	UNKWN	—	—

PKIB0280E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-25, "Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0281E



CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-26. "ECM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UN ✓ KN	—	UN ✓ KN	UN ✓ KN	UN ✓ KN	—	UN ✓ KN	UN ✓ KN
A/T	NG	UNKWN	UN ✓ KN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UN ✓ KN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UN ✓ KN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0282E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-26, "TCM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	—	—

PKIB0283E



CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-27, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—

PKIB0284E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-27, "BCM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R	
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—

PKIB0285E



CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check steering angle sensor circuit. Refer to [LAN-28. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0286E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-28, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0287E



CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-29, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0288E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Case 10

Check CAN communication circuit. Refer to [LAN-30, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N
A/T	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—
BCM	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N
ABS	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	—

PKIB0289E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-32, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N
A/T	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—
BCM	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N
ABS	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	—

PKIB0291E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-32, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N
A/T	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—
BCM	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N
ABS	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	—

PKIB0290E

Circuit Check Between TCM and Data Link Connector

AKS009BM

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector and harness connector F102.
2. Check continuity between TCM harness connector F103 terminals 6 (L), 7 (R) and harness connector F102 terminals 35H (L), 34H (R).

6 (L) - 35H (L) : Continuity should exist.

7 (R) - 34H (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


- Check continuity between harness connector M72 terminals 35H (L), 34H (R) and data link connector M8 terminals 6 (L), 3 (R).

35H (L) - 6 (L) : Continuity should exist.

34H (R) - 3 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-13, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit

AKS009BN

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 3 (R) and harness connector M15 terminals 9G (L), 8G (R).

6 (L) - 9G (L) : Continuity should exist.

3 (R) - 8G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 9G (L), 8G (R) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (R).

9G (L) - 61 (L) : Continuity should exist.

8G (R) - 63 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-13, "Work Flow"](#) .
- NG >> Repair harness.



AKS009B0

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 109 (L) and 113 (R).

109 (L) - 113 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between harness connector F102 and ECM.



AKS009BP

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F103 terminals 6 (L) and 7 (R).

6 (L) - 7 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between harness connector F102 and TCM.



AKS009BQ

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M20 terminals 28 (L) and 27 (R).

28 (L) - 27 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between data link connector and combination meter.



AKS009BR

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) - 71 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-23, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between data link connector and steering angle sensor.



VDC/TCS/ABS Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (R).

61 (L) - 63 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between harness connector E108 and VDC/TCS/ABS control unit.



AKS009BU

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between harness connector E108 and IPDM E/R.



LKIA0030E

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, sensor side and harness side).
 - ECM
 - TCM
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect following connectors.
 - ECM connector
 - TCM connector
 - Harness connector F102
2. Check continuity between ECM harness connector F101 terminals 109 (L) and 113 (R).

109 (L) - 113 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

- NG >> ● Repair harness between ECM and harness connector F102.
- Repair harness between TCM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F101 terminals 109 (L), 113 (R) and ground.


109 (L) - Ground : Continuity should not exist.

113 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

- NG >> ● Repair harness between ECM and harness connector F102.
- Repair harness between TCM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 3 (R).


6 (L) - 3 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> ● Repair harness between harness connector M72 and harness connector M15.

- Repair harness between harness connector M72 and combination meter.
- Repair harness between harness connector M72 and data link connector.
- Repair harness between harness connector M72 and BCM.
- Repair harness between harness connector M72 and steering angle sensor.



5. CHECK HARNESS FOR SHORT CIRCUIT

- Check continuity between data link connector M8 terminals 6 (L), 3 (R) and ground.

6 (L) - Ground : Continuity should not exist.


3 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> ● Repair harness between harness connector M72 and harness connector M15.

- Repair harness between harness connector M72 and combination meter.
- Repair harness between harness connector M72 and data link connector.
- Repair harness between harness connector M72 and BCM.
- Repair harness between harness connector M72 and steering angle sensor.



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> ● Repair harness between harness connector E108 and VDC/TCS/ABS control unit.

- Repair harness between harness connector E108 and IPDM E/R.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) - Ground : Continuity should not exist.


49 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> ● Repair harness between harness connector E108 and VDC/TCS/ABS control unit.

- Repair harness between harness connector E108 and IPDM E/R.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-32, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-13, "Work Flow"](#) .

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS009BW

Replace IPDM E/R if there is no malfunction after checking the following.

- IPDM E/R power circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#) .


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS009BX

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 109 and 113.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	109 - 113	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 2)


System Description

AKS007V0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS007V1



A

B

C

D

E

F

G

H

I

J

LAN

L


M

CAN SYSTEM (TYPE 2)

[CAN]

Schematic

AKS007V2



TKWT0957E

CAN SYSTEM (TYPE 2)


[CAN]

Wiring Diagram - CAN -

AKS007V3

LAN-CAN-04

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M

LAN

REFER TO THE FOLLOWING.


(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(F108) -ELECTRICAL UNITS

TKWT0958E

LAN-CAN-05

▬ : DATA LINE



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M8)
W

25	26	27	28	29	30	31	32	33	34	35		
36	37	38	39	40	41	42	43	44	45	46	47	48

(M20)
W

3	2	1		
8	7	6	5	4

(M22)
W

REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS



TKWT0959E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-06

▬ : DATA LINE



(E9)
W



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E118) -ELECTRICAL UNITS

TKWT0960E

Work Flow

- Print all the data of “SELF-DIAG RESULTS” for “ENGINE”, “BCM” and “ABS” displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
			F.F.DATA
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

- Print all the data of “CAN DIAG SUPPORT MNTR” for “ENGINE”, “BCM” and “ABS” displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSN	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
TCM	OK		
VDC/TCS/ABS	OK		
METER/M&A	OK		
ICC	UNKWN		
BCM/SEC	OK		
IPDM E/R	OK		
AWD/4WD/e4WD	UNKWN		
PRINT			Scroll Down
MODE	BACK	LIGHT	COPY

PKIA8343E

- Attach the printed sheet of “SELF-DIAG RESULTS” and “CAN DIAG SUPPORT MNTR” onto the check sheet. Refer to [LAN-39, "CHECK SHEET"](#).
- Based on the “CAN DIAG SUPPORT MNTR” results, put marks “v” onto the items with “NG” or “UNKWN” in the check sheet table. Refer to [LAN-39, "CHECK SHEET"](#).

NOTE:

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 - The “CAN DIAG SUPPORT MNTR” items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
- According to the check sheet results (example), start inspection. Refer to [LAN-40, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
BCM	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

Symptoms :

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.


Case 1

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-47, "Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓
BCM	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—

PKIB0292E

//// : Malfunctioning part



SKIA7102E

CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-48, "ECM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N
BCM	NG	UNKWN	UNKW [✓] N	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKW [✓] N	UNKWN	—	UNKWN	—	—

PKIB0293E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 3

Check combination meter circuit. Refer to [LAN-49, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
BCM	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—

PKIB0294E

▨ : Malfunctioning part



SKIA7104E

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check BCM circuit. Refer to [LAN-49, "BCM Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
BCM	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0295E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 5

Check steering angle sensor circuit. Refer to [LAN-50, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN
BCM	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	—

PKIB0296E

▨ : Malfunctioning part



SKIA7106E

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-50, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	UNKWN
BCM	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—

PKIB0297E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 7

Check IPDM E/R circuit. Refer to [LAN-51, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
BCM	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0298E

▨ : Malfunctioning part



SKIA7108E

Case 8

Check CAN communication circuit. Refer to [LAN-52, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
BCM	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N
ABS	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—

PKIB0299E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-54, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
BCM	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N
ABS	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—

PKIB0301E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-54, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
BCM	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N
ABS	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—

PKIB0300E

Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit

AKS007V5

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 3 (R) and harness connector M15 terminals 9G (L), 8G (R).

6 (L) - 9G (L) : Continuity should exist.

3 (R) - 8G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 9G (L), 8G (R) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (R).

9G (L) - 61 (L) : Continuity should exist.

8G (R) - 63 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-38, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F108 terminals 94 (L) and 86 (R).

94 (L) - 86 (R)

: Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between data link connector and ECM.



PKIA0816E

AKS007V7

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M20 terminals 28 (L) and 27 (R).

28 (L) - 27 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between data link connector and combination meter.



SKIA1971E

AKS007V8

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) - 71 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-23, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (R).

4 (L) - 5 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between data link connector and steering angle sensor.



VDC/TCS/ABS Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (R).

61 (L) - 63 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between harness connector E108 and VDC/TCS/ABS control unit.



AKS007VB

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between harness connector E108 and IPDM E/R.



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Check

AKS007VC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, sensor side and harness side).
 - ECM
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - Harness connector F102
2. Check continuity between ECM harness connector F108 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F108 terminals 94 (L), 86 (R) and ground.

94 (L) - Ground : Continuity should not exist.

86 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 3 (R).


6 (L) - 3 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> ● Repair harness between harness connector M72 and harness connector M15.

- Repair harness between harness connector M72 and combination meter.
- Repair harness between harness connector M72 and data link connector.
- Repair harness between harness connector M72 and BCM.
- Repair harness between harness connector M72 and steering angle sensor.



5. CHECK HARNESS FOR SHORT CIRCUIT

- Check continuity between data link connector M8 terminals 6 (L), 3 (R) and ground.

6 (L) - Ground : Continuity should not exist.


3 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> ● Repair harness between harness connector M72 and harness connector M15.

- Repair harness between harness connector M72 and combination meter.
- Repair harness between harness connector M72 and data link connector.
- Repair harness between harness connector M72 and BCM.
- Repair harness between harness connector M72 and steering angle sensor.



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> ● Repair harness between harness connector E108 and VDC/TCS/ABS control unit.

- Repair harness between harness connector E108 and IPDM E/R.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) - Ground : Continuity should not exist.


49 (R) -Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> ● Repair harness between harness connector E108 and VDC/TCS/ABS control unit.

- Repair harness between harness connector E108 and IPDM E/R.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-54, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#)

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-38, "Work Flow"](#) .

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS007VD

Replace IPDM E/R if there is no malfunction after checking the following.

- IPDM E/R power circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#) .


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS007VE

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



CAN SYSTEM (TYPE 3)

PFP:23710


System Description

AKS009BY

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS009BZ



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

AKS009C0



TKWT1022E

CAN SYSTEM (TYPE 3)


[CAN]

Wiring Diagram - CAN -

AKS009C1

LAN-CAN-07

▬ : DATA LINE



REFER TO THE FOLLOWING.


(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(F103), (F108) -ELECTRICAL UNITS

TKWT1023E

LAN-CAN-08

▬ : DATA LINE



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M8)
W

25	26	27	28	29	30	31	32	33	34	35		
36	37	38	39	40	41	42	43	44	45	46	47	48

(M20)
W

3	2	1		
8	7	6	5	4

(M22)
W

REFER TO THE FOLLOWING.
(M3) -ELECTRICAL UNITS



TKWT1024E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-09

▬ : DATA LINE



E9
W



REFER TO THE FOLLOWING.

E108 -SUPER MULTIPLE JUNCTION (SMJ)

E118 -ELECTRICAL UNITS

TKWT1025E

Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
			F.F.DATA
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
TCM	OK		
VDC/TCS/ABS	OK		
METER/M&A	OK		
ICC	UNKWN		
BCM/SEC	OK		
IPDM E/R	OK		
AWD/4WD/e4WD	UNKWN		
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-61, "CHECK SHEET"](#).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-61, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
 - The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.
5. According to the check sheet results (example), start inspection. Refer to [LAN-62, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

Symptoms :

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
---	--	--	--

Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR
--	---	---	---

PKIB0278E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-71, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN	—	UNKWN	—	—

PKIB0280E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-72, "Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0281E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-73, "ECM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UN KN WN	—	UN KN WN	UN KN WN	UN KN WN	—	UN KN WN	UN KN WN
A/T	NG	UNKWN	UN KN WN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UN KN WN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UN KN WN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0282E



CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-73. "TCM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0283E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-74, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—

PKIB0284E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-74, "BCM Circuit Check"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0285E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check steering angle sensor circuit. Refer to [LAN-75, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0286E



CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-75, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0287E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 3)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-76, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0288E



Case 10

Check CAN communication circuit. Refer to [LAN-77, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0289E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-79, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0291E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-79, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—

PKIB0290E

Circuit Check Between TCM and Data Link Connector

AKS009C3

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector and harness connector F102.
2. Check continuity between TCM harness connector F103 terminals 6 (L), 7 (R) and harness connector F102 terminals 24H (L), 25H (R).

6 (L) - 24H (L) : Continuity should exist.

7 (R) - 25H (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M72 terminals 24H (L), 25H (R) and data link connector M8 terminals 6 (L), 3 (R).

24H (L) - 6 (L) : Continuity should exist.

25H (R) - 3 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-60, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and VDC/TCS/ABS Control Unit

AKS009C4

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M15.
2. Check continuity between data link connector M8 terminals 6 (L), 3 (R) and harness connector M15 terminals 9G (L), 8G (R).

6 (L) - 9G (L) : Continuity should exist.

3 (R) - 8G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect VDC/TCS/ABS control unit connector.
2. Check continuity between harness connector E108 terminals 9G (L), 8G (R) and VDC/TCS/ABS control unit harness connector E118 terminals 61 (L), 63 (R).

9G (L) - 61 (L) : Continuity should exist.

8G (R) - 63 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-60, "Work Flow"](#).
- NG >> Repair harness.



AKS009C5

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F108 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between harness connector F102 and ECM.



AKS009C6

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F103 terminals 6 (L) and 7 (R).

6 (L) - 7 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between harness connector F102 and TCM.



AKS009C7

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M20 terminals 28 (L) and 27 (R).

28 (L) - 27 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between data link connector and combination meter.



AKS009C8

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) - 71 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-23, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (R).

4 (L) - 5 (R)

: Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between data link connector and steering angle sensor.



VDC/TCS/ABS Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E118 terminals 61 (L) and 63 (R).

61 (L) - 63 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between harness connector E108 and VDC/TCS/ABS control unit.



AKS009CB

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) - 49 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between harness connector E108 and IPDM E/R.



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, sensor side and harness side).
 - ECM
 - TCM
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - TCM connector
 - Harness connector F102
2. Check continuity between ECM harness connector F108 terminals 94 (L) and 86 (R).

94 (L) - 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> ● Repair harness between ECM and harness connector F102.
 ● Repair harness between TCM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between ECM harness connector F108 terminals 94 (L), 86 (R) and ground.

94 (L) - Ground : Continuity should not exist.

86 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> ● Repair harness between ECM and harness connector F102.
 ● Repair harness between TCM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 3 (R).


6 (L) - 3 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> ● Repair harness between harness connector M72 and harness connector M15.

- Repair harness between harness connector M72 and combination meter.
- Repair harness between harness connector M72 and data link connector.
- Repair harness between harness connector M72 and BCM.
- Repair harness between harness connector M72 and steering angle sensor.



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 3 (R) and ground.

6 (L) - Ground : Continuity should not exist.


3 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> ● Repair harness between harness connector M72 and harness connector M15.

- Repair harness between harness connector M72 and combination meter.
- Repair harness between harness connector M72 and data link connector.
- Repair harness between harness connector M72 and BCM.
- Repair harness between harness connector M72 and steering angle sensor.



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect VDC/TCS/ABS control unit connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) - 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> ● Repair harness between harness connector E108 and VDC/TCS/ABS control unit.

- Repair harness between harness connector E108 and IPDM E/R.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) - Ground : Continuity should not exist.


49 (R) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> ● Repair harness between harness connector E108 and VDC/TCS/ABS control unit.

● Repair harness between harness connector E108 and IPDM E/R.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-79, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#)

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-60, "Work Flow"](#) .

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS009CD

Replace IPDM E/R if there is no malfunction after checking the following.

- IPDM E/R power circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" "](#) .


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS009CE

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

