

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

IDX

ALPHABETICAL INDEX

Brake master cylinder [BR-13](#)
 Brake pedal [BR-6](#)
 Brake switch [EC-572](#)
 BRK/SW - Wiring diagram [EC-573](#)
 Bulb specifications [LT-197](#)
 Bumper, front [EI-14](#)
 Bumper, rear [EI-17](#)

C

Camshaft [EM-84](#)
 Camshaft inspection [EM-86](#)
 Camshaft position sensor (PHASE) [EC-269](#)
 CAN - Wiring diagram [EC-139](#), [LAN-13](#), [LAN-41](#),
[LAN-66](#)
 CAN (Controller Area Network) [BL-22](#), [BL-54](#), [BL-110](#),
[LAN-5](#), [LAN-11](#), [LAN-39](#), [LAN-64](#)
 CAN communication . [EC-29](#), [EC-138](#), [AT-31](#), [AT-101](#),
[TF-13](#), [TF-34](#), [WT-9](#), [BL-22](#), [BL-54](#), [BL-110](#), [LT-42](#),
[WW-10](#), [LAN-5](#), [LAN-11](#), [LAN-39](#), [LAN-64](#)
 Canister-See EVAP canister [EC-666](#)
 Center bearing assembly (propeller shaft) [PR-8](#)
 Center bearing disassembly (propeller shaft) [PR-7](#)
 CHARGE - Wiring diagram [SC-23](#)
 Charging system [SC-22](#)
 Chassis and body maintenance [MA-21](#)
 CHIME - Wiring diagram [DI-39](#)
 CIGAR - Wiring diagram [WW-41](#)
 Cigarette lighter [WW-41](#)
 Cigarette lighter illumination [LT-163](#)
 Circuit breaker [PG-15](#)
 Clock [DI-52](#)
 CLOCK - Wiring diagram [DI-52](#)
 Closed loop control [EC-26](#)
 Clutch master cylinder [CL-8](#)
 Clutch operating cylinder [CL-11](#)
 Clutch pedal [CL-5](#)
 Clutch release bearing [CL-13](#)
 Clutch release mechanism [CL-13](#)
 Clutch withdrawal lever [CL-13](#)
 Coil spring (front) [FSU-10](#), [FSU-27](#)
 Collision diagnosis [SRS-58](#)
 Combination lamp, front, removal and installation
[LT-35](#)
 Combination lamp, rear, removal and installation
[LT-154](#)
 Combination meter [DI-4](#)
 Combination meter removal and installation - See
 Instrument panel [IP-11](#)
 Combination switch [LT-125](#)
 COMM - Wiring diagram [AV-66](#)
 COMPAS - Wiring diagram [DI-19](#)
 Compass [DI-18](#)
 Component Location (auto A/C) [ATC-42](#)
 Compression pressure [EM-99](#)
 Compressor clutch removal and installation .. [ATC-142](#)
 Compressor special service tool [ATC-16](#)
 Condenser [ATC-152](#)
 Console box - See Instrument panel [IP-10](#)

Control units (terminal arrangement) [PG-70](#)
 Control valve (A/T) [AT-36](#)
 Controller Area Network (CAN) [BL-22](#), [BL-54](#), [BL-110](#),
[LAN-5](#), [LAN-11](#), [LAN-39](#), [LAN-64](#)
 Converter housing installation [AT-266](#)
 COOL/F - Wiring diagram [EC-439](#)
 Cooling circuit (engine) [CO-8](#)
 Cooling fan [CO-20](#)
 Cooling fan motor [EC-446](#)
 Cowl top [EI-21](#)
 Cowl top cover [EI-21](#)
 Crankcase ventilation system - See Positive crankcase
 ventilation [EC-676](#)
 Crankshaft position sensor (POS) [EC-261](#)
 Crash zone sensor [SRS-47](#)
 Cylinder head [EM-99](#)

D

D/LOCK - Wiring diagram [BL-24](#)
 Daytime light system [LT-38](#)
 Daytime running light - See Daytime light system [LT-38](#)
 Diagnosis sensor unit [SRS-50](#)
 Diagnostic trouble code (DTC) for OBD system .. [EC-8](#)
 Differential carrier assembly [RFD-13](#)
 Differential carrier disassembly [RFD-18](#)
 Direct clutch solenoid valve [AT-153](#), [AT-155](#)
 Display and amp.assembly [ATC-50](#), [ATC-64](#)
 Door glass [GW-88](#), [GW-91](#)
 Door glass Fitting Adjustment(Front) [GW-90](#)
 Door glass Fitting Adjustment(Rear) [GW-93](#)
 Door lock [BL-84](#)
 Door mirror [GW-118](#)
 Door trim [EI-37](#)
 Door, front [BL-80](#), [GW-88](#)
 Door, rear [BL-80](#), [GW-91](#)
 Drive belt [EM-14](#)
 Drive pinion diff. inspection [RFD-16](#)
 Drive pinion height [RFD-23](#), [RFD-26](#)
 Drive shaft [MA-29](#)
 Drive shaft (rear) [RAX-10](#)
 Driver air bag [SRS-37](#)
 DTRL - Wiring diagram [LT-44](#)
 Duct and grilles [ATC-136](#)

E

ECM power supply [EC-130](#), [EC-375](#)
 ECM/PW - Wiring diagram [EC-376](#)
 ECTS - Wiring diagram [EC-174](#)
 Electric sunroof [RF-10](#)
 Electric throttle control actuator [EC-386](#), [EC-388](#)
 Electrical load signal circuit [EC-637](#)
 Electrical unit [PG-70](#)
 Electrical units location [PG-64](#)
 Electronic ignition (EI) system [EC-27](#)
 Engine control module (ECM) [EC-365](#)
 Engine control system diagram and chart [EC-22](#)
 Engine coolant [CO-10](#)

ALPHABETICAL INDEX

Engine coolant temperature sensor (ECTS) ... [EC-172](#),
[EC-186](#)
Engine oil [LU-6](#)
Engine oil filter replacement [MA-18](#)
Engine oil precautions [GI-7](#)
Engine oil replacement [MA-17](#)
Engine removal [EM-111](#)
ETC1 - Wiring diagram [EC-389](#)
ETC2 - Wiring diagram [EC-398](#)
ETC3 - Wiring diagram [EC-404](#)
EVAP canister [EC-666](#)
EVAP canister purge volume control solenoid valve
[EC-299](#), [EC-523](#)
EVAP canister vent control valve [EC-306](#), [EC-531](#)
EVAP control system (small leak) diagnosis .. [EC-290](#),
[EC-330](#)
EVAP control system pressure sensor [EC-313](#),
[EC-316](#), [EC-322](#)
EVAP control system purge flow monitoring diagnosis
[EC-285](#)
EVAP vapor lines inspection [MA-20](#)
Evaporative emission (EVAP) system [EC-663](#)
Evaporator [ATC-154](#)
Exhaust manifold [EM-26](#)
Exhaust system [EX-3](#)
Exhaust system inspection [EX-3](#), [MA-21](#)
Expansion valve [ATC-155](#)

F

F/FOG - Wiring diagram [LT-92](#)
F/PUMP - Wiring diagram [EC-627](#)
Final drive disassembly [RFD-18](#)
Final drive pre-inspection [RFD-16](#)
Final drive removal and installation .. [RFD-11](#), [FFD-10](#)
Floor trim [EI-43](#)
Flow charts [GI-26](#)
Fluid temperature sensor (A/T) [AT-131](#)
Fluorescent leak detector [ATC-156](#)
Flywheel runout(QR) [EM-148](#)
Fog lamp, front [LT-89](#)
Front axle [FAX-4](#), [FAX-12](#)
Front brake solenoid valve [AT-149](#), [AT-151](#)
Front bumper [EI-14](#)
Front combination lamp removal and installation [LT-35](#)
Front disc brake [BR-22](#)
Front door [BL-80](#), [BL-84](#), [GW-88](#)
Front fog lamp [LT-89](#)
Front passenger air bag [SRS-41](#)
Front seat [SE-64](#)
Front seat belt [SB-4](#)
Front seat belt pre-tensioner [SB-2](#), [SRS-3](#), [SRS-49](#)
Front side air bag [SRS-43](#)
Front suspension [FSU-6](#), [FSU-23](#)
Front washer [WW-4](#)
Front wiper [WW-4](#)
FTTS - Wiring diagram [EC-233](#), [EC-237](#)
Fuel cut control (at no load high engine speed) . [EC-28](#)
Fuel filter replacement [FL-4](#)

Fuel gauge [DI-4](#)
Fuel level sensor [EC-348](#), [EC-350](#), [EC-352](#)
Fuel line inspection [FL-3](#), [MA-17](#)
Fuel pressure check [EC-45](#)
Fuel pressure release [EC-45](#)
Fuel pump [EC-626](#)
Fuel pump and gauge [FL-4](#)
Fuel system [FL-3](#)
Fuel tank [FL-11](#)
Fuel tank temperature sensor [EC-231](#), [EC-236](#)
Fuel tank vacuum relief valve [EC-666](#)
FUELB1 - Wiring diagram [EC-216](#), [EC-225](#)
FUELB2 - Wiring diagram [EC-217](#), [EC-226](#)
Fuse [PG-15](#)
Fuse and fusible link box [PG-76](#)
Fusible link [PG-15](#)

G

Gauges [DI-4](#)
Glass [GW-13](#), [GW-15](#), [GW-88](#), [GW-91](#)
Glove box lamp [LT-161](#), [LT-196](#)
Grille - See Exterior [EI-20](#)
Ground distribution [PG-29](#)

H

H/LAMP - Wiring diagram [LT-12](#)
Harness connector [PG-68](#)
Harness layout [PG-40](#)
Hazard warning lamp [LT-107](#)
Headlamp [LT-7](#)
Headlamp removal and installation [LT-35](#)
Headlining - See Roof trim [EI-45](#)
Heated oxygen sensor 2 (bank 1) [EC-194](#), [EC-203](#),
[EC-410](#), [EC-421](#)
Heated oxygen sensor 2 (bank 2) [EC-194](#), [EC-203](#),
[EC-410](#), [EC-421](#)
Heated oxygen sensor 2 heater (bank 1) [EC-144](#)
Heated oxygen sensor 2 heater (bank 2) [EC-144](#)
Heated seat [SE-56](#)
Heater and cooling unit (Heater core) [ATC-130](#)
HFC134a (R134a) system precaution [ATC-5](#)
HFC134a (R134a) system service procedure [ATC-139](#)
HFC134a (R134a) system service tools [ATC-17](#)
HFC134a system service equipment precaution
[ATC-12](#)
High & low reverse clutch solenoid valve [AT-157](#),
[AT-159](#)
Hood [BL-12](#)
Hood lock system [BL-15](#)
Horn [WW-45](#)
HORN - Wiring diagram [WW-45](#)
HSEAT - Wiring diagram [SE-58](#), [SE-61](#)

I

IATS - Wiring diagram [EC-169](#)
Idle air volume learning [EC-43](#)

ALPHABETICAL INDEX

Idle mixture ratio	EC-31
Idle speed	EC-31
Idle speed control (ISC)	EC-356 , EC-358
Ignition coil	EM-43 , EC-608
Ignition control system	EC-608
Ignition key hole illumination	LT-160
Ignition timing	EC-31
IGNSYS - Wiring diagram	EC-609
In vehicle sensor	ATC-109 , ATC-122
INJECT - Wiring diagram	EC-621
Injector	EC-620
Input clutch solenoid valve	AT-145 , AT-147
Instrument panel	IP-10
Intake air temperature sensor	EC-167 , EC-189
Intake door control linkage adjustment	ATC-79
Intake door motor	ATC-77 , ATC-128
Intake manifold	EM-24
Intake manifold collector	EM-19
Intake sensor	ATC-115 , ATC-124
Intake valve timing control (Bank 1)	EC-141
Intake valve timing control (Bank 2)	EC-141
Intake valve timing control solenoid valve (Bank 1)	EC-379
Intake valve timing control solenoid valve (Bank 2)	EC-379
Integrated homelink transmitter	BL-154
Interior	EI-39
Interior lamp	LT-164
IPDM (Intelligent power distribution module engine room)	PG-16
IVCB1 - Wiring diagram	EC-380
IVCB2 - Wiring diagram	EC-382
IVIS (Infiniti vehicle immobilizer system) precautions ...	GI-3

K

Knock sensor (KS)	EC-256
KS - Wiring diagram	EC-257

L

LAN system circuit	ATC-67
Latch (lower anchors and tether for children) system ...	SB-9
Line pressure solenoid valve	AT-124
Line pressure test (A/T)	AT-51
Liquid gasket application	LU-2 , CO-2
Location of electrical units	PG-64
Low coast brake solenoid valve	AT-161 , AT-163
Low tire pressure warning system	WT-7
Lubricant (R134a) A/C	ATC-6 , ATC-26
Lubrication circuit (engine)	LU-4
Lubrication oil A/C	ATC-160
Luggage compartment trim	EI-47

M

M/T oil replacement	MT-10
---------------------------	-----------------------

MAFS - Wiring diagram	EC-155 , EC-162
Magnet clutch	ATC-86 , ATC-142
MAIN - Wiring diagram	EC-130
Maintenance (engine)	MA-13
Major overhaul (Transfer)	TF-52
Mass air flow sensor (MAFS)	EC-152 , EC-160
Master cylinder (brake)	BR-13
Master cylinder (clutch)	CL-8
Meter	DI-4
METER - Wiring diagram	DI-8
MIL data link connectors circuit	EC-661
MIL/DL - Wiring diagram	EC-661
Mirror, door	GW-118
Mirror, out side	GW-118
Misfire	EC-249
Mode door control linkage adjustment	ATC-73
Mode door motor	ATC-71 , ATC-134
Molding - See Exterior EI-23 , EI-24 , EI-27 , EI-30 , EI-32 , EI-36	
Mud guard - See Exterior	EI-28 , EI-29
Multiplex communication	ATC-117
Multiport fuel injection (MFI) system	EC-25
Multiport fuel injection precautions	GI-6

N

NATS - Wiring diagram	BL-138
NAVI - Wiring diagram	AV-62
Navigation system	AV-43
NVH troubleshooting (BR)	BR-5
NVH troubleshooting (Transfer)	TF-8
NVIS (Nissan vehicle immobilizer system) precautions	GI-3

O

O2H2B1 - Wiring diagram	EC-146
O2H2B2 - Wiring diagram	EC-148
O2S2B1 - Wiring diagram ..	EC-196 , EC-206 , EC-413 , EC-424
O2S2B2 - Wiring diagram ..	EC-198 , EC-208 , EC-415 , EC-426
Oil cooler (engine)	LU-14
Oil filter	LU-10
Oil pan (engine)	EM-30
Oil pressure (engine)	LU-7
Oil pump (engine)	LU-17
Oil pump regulator valve (engine)	LU-17
Oil seal replacement (front of final drive) RFD-7 , FFD-7	
Oil seal replacement (side of final drive) RFD-9 , FFD-9	
Operating cylinder (clutch)	CL-11
ORVR (On-board Refueling Vapor Recovery) .	EC-670
Out side mirror	GW-118
Overheat	EC-435

P

P/SCKT - Wiring diagram	WW-43
Park/Neutral position switch	EC-564

A
B
C
D
E
F
G
H
I
J
K
L
IDX

ALPHABETICAL INDEX

Park/neutral position switch (A/T)	AT-109	ATC-153	
Parking brake control	PB-5	Refrigeration cycle	ATC-20
Parking drum brake	PB-7	Release bearing (clutch)	CL-13
PCV (positive crankcase ventilation)	EC-676	Removal and installation (A/T)	AT-263
Personal lamp	LT-159	Removal and installation (Transfer)	TF-51
PGC/V - Wiring diagram	EC-301 , EC-525	Reverse lamp switch (M/T) - See Back-up lamp switch (M/T)	MT-12
PHSB1 - Wiring diagram	EC-270 , EC-274	Revolution sensor (A/T)	AT-113
PHSB2 - Wiring diagram	EC-272 , EC-276	Ring gear diff. inspection	RFD-16
Pinion bearing preload diff.	RFD-32	Rocker cover	EM-52
Pinion gear height diff.	RFD-26	Room lamp - See Interior lamp	LT-164
PNP/SW - Wiring diagram	EC-566	ROOM/L - Wiring diagram	LT-170
POS - Wiring diagram	EC-262	RP/SEN - Wiring diagram	EC-633
POWER - Wiring diagram	PG-4		
Power door mirror	BL-19		
Power seat	SE-53		
Power socket	WW-43		
Power steering fluid level	PS-6 , MA-28		
Power steering gear	PS-14		
Power steering hydraulic pressure	PS-25		
Power steering oil pump	PS-25		
Power steering system bleeding	PS-6		
Power supply routing	PG-3		
Power window	GW-17		
PRE/SE - Wiring diagram	EC-318 , EC-324		
Precautions for Leak detection dye	ATC-15		
Precautions (General)	GI-4		
Pressure switch 1	AT-151 , AT-170		
Pressure switch 2	AT-163		
Pressure switch 3	AT-147 , AT-172		
Pressure switch 5	AT-155 , AT-174		
Pressure switch 6	AT-159 , AT-176		
Pressure test (A/T)	AT-51		
Propeller shaft	PR-4 , PR-16		
Propeller shaft on vehicle service	PR-4 , PR-16		
Propeller shaft vibration	PR-4 , PR-16		
PS/SEN - Wiring diagram	EC-361		

R

Radiator	CO-13
Radio - See Audio	AV-5
Rear axle	RAX-6
Rear bumper	EI-17
Rear combination lamp removal and installation	LT-154
Rear cover packing replacement diff.	RFD-34
Rear disc brake	BR-29
Rear door	BL-80 , GW-91
Rear parcel shelf finisher	EI-41
Rear seat	SE-71
Rear seat belt	SB-5
Rear suspension	RSU-5
Rear window	GW-15
Rear window defogger	GW-96
Refrigerant connection precaution	ATC-7
Refrigerant discharging evacuating charging	ATC-139
Refrigerant general precaution	ATC-6
Refrigerant lines	ATC-139
Refrigerant pressure sensor	EC-632 , ATC-92 ,

S

Seal - See Exterior	EI-26
SEAT - Wiring diagram	SE-53
Seat belt inspection	SB-6
Seat belt pre-tensioner disposal	SRS-51
Seat belt, front	SB-4
Seat belt, rear	SB-5
Seat, front	SE-64
Seat, rear	SE-71
Self-diagnosis (Transfer)	TF-22
SEN/PW - Wiring diagram	EC-452
SHIFT - Wiring diagram	AT-230
Shift lock system	AT-229
Shift schedule	AT-338
Shock absorber (front)	FSU-10 , FSU-27
Shock absorber (rear)	RSU-9
Side air bag (satellite) sensor	SRS-48
Side bearing preload diff.	RFD-25
Side curtain air bag	SRS-45
Side flange installation diff.	RFD-9
Side trim	EI-39
SMJ (super multiple junction)	PG-71
Spark plug	EM-44
Spark plug replacement	MA-19
Specification value	EC-125
Speedometer	DI-4
Spiral cable	SRS-39
Spot lamp	LT-184
SROOF - Wiring diagram	RF-13
SRS - See Supplemental Restraint System	SRS-6
SRS - Wiring diagram	SRS-12
SRS Trouble diagnoses	SRS-8
Stabilizer bar (rear)	RSU-16
Stall test (A/T)	AT-50
Standardized relay	PG-73
START - Wiring diagram	SC-11
Starter	SC-9
Starting system	SC-9
Steering gear and linkage inspection	MA-28
Steering linkage	PS-14
Steering wheel and column	PS-8 , PS-10
Steering wheel play	PS-8
Steering wheel turning force	PS-8
Step lamp	LT-134

ALPHABETICAL INDEX

Stop lamp [LT-131](#)
 Stop lamp switch [EC-572](#)
 STOP/L - Wiring diagram [LT-132](#)
 Sun roof, electric [RF-10](#)
 Sunload sensor [ATC-111](#), [ATC-123](#)
 Sunroof [RF-10](#)
 Supplemental Restraint System [SRS-6](#)
 Supplemental restraint system - Wiring diagram
[SRS-12](#)
 Suspension [MA-29](#)
 Symbols and abbreviations [GI-9](#), [GI-22](#)

T

Tachometer [DI-4](#)
 TCM circuit diagram [AT-49](#)
 TCM inspection table [AT-86](#)
 Three way catalyst [EM-26](#)
 Three way catalyst function (Bank 1) [EC-281](#)
 Three way catalyst function (Bank 2) [EC-281](#)
 Three way catalyst precautions [GI-5](#)
 Throttle body [EM-23](#)
 Throttle control motor [EC-403](#)
 Throttle control motor relay [EC-396](#)
 Throttle position sensor (TPS) [EC-177](#), [EC-240](#),
[EC-447](#), [EC-449](#), [EC-591](#)
 Throwout bearing - See Clutch release bearing [CL-13](#)
 Thrust washer selection diff. [RFD-24](#)
 Tie-rod [PS-14](#)
 Timing chain [EM-64](#)
 Tire rotation [MA-26](#)
 TLID - Wiring diagram [BL-97](#)
 Tooth contact diff. [RFD-30](#)
 Top tether strap child restraint [SB-10](#)
 Torque converter installation [AT-266](#)
 Torque convertor clutch solenoid valve [AT-120](#), [AT-122](#)
 TPS1 - Wiring diagram [EC-242](#)
 TPS2 - Wiring diagram [EC-179](#)
 TPS3 - Wiring diagram [EC-593](#)
 Transfer control unit inspection table [TF-20](#)
 Transverse link (front) [FSU-12](#), [FSU-29](#)
 TRNSCV - Wiring diagram [BL-154](#)
 Trouble diagnoses [GI-10](#)
 Trunk lid [BL-90](#)
 Trunk lid opener - See Trunk lid [BL-95](#)
 Trunk lid trim [EI-47](#)
 Trunk room trim [EI-47](#)
 Turbine revolution sensor [AT-136](#)
 TURN - Wiring diagram [LT-111](#)
 Turn signal lamp [LT-107](#)
 Tyre pressure monitoring system - trouble diagnoses ..
[WT-10](#)
 Tyre pressure monitoring system - wiring diagram
[WT-10](#)

U

Upper link (front susp.) [FSU-13](#), [FSU-30](#)

V

Vacuum hose (brake system) [BR-20](#)
 Vacuum hose drawing (Engine control) [EC-23](#)
 Valve clearance [EM-91](#)
 Valve guide [EM-106](#)
 Valve lifter [EM-88](#)
 Valve seat [EM-108](#)
 Valve spring [EM-109](#)
 Vanity mirror lamp [LT-156](#)
 VDC -Wiring diagram [BRC-15](#)
 Vehicle security (theft warning) system [BL-106](#)
 Vehicle speed sensor (VSS) [EC-354](#)
 VEHSEC - Wiring diagram [BL-112](#)
 VENT/V - Wiring diagram [EC-308](#), [EC-533](#)
 VIN registration [EC-42](#)

W

W/ANT - Wiring diagram [AV-39](#)
 WARN - Wiring diagram [DI-26](#)
 Warning chime [DI-36](#)
 Warning lamps [DI-25](#)
 Washer, front [WW-4](#)
 Water pump [CO-22](#)
 Water temperature gauge [DI-4](#)
 Wheel alignment (front) [FSU-7](#), [FSU-24](#)
 Wheel alignment (rear) [RSU-5](#)
 Wheel balance [WT-5](#), [MA-25](#)
 Wheel bearing (front) [FAX-4](#)
 Wheel bearing (rear) [RAX-6](#)
 Wheel hub (front) [FAX-4](#), [FAX-12](#)
 Wheel hub (rear) [RAX-6](#)
 Wheel sensor (VDC) [BRC-65](#)
 WINDOW - Wiring diagram [GW-26](#)
 Window antenna [AV-38](#)
 Window, door [GW-88](#), [GW-91](#)
 Window, rear [GW-15](#)
 Windshield [GW-13](#)
 WIPER - Wiring diagram [WW-12](#)
 Wiper, front [WW-4](#)
 Wiring Diagram (Cell code) list [PG-61](#)
 Wiring diagrams [GI-14](#)
 Withdrawal lever (clutch) [CL-13](#)
 WT-T/WARN - Wiring diagram [WT-10](#)

A
B
C
D
E
F
G
H
I
J
K
L

IDX