

# PG

## SECTION

# POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

## CONTENTS

<b>POWER SUPPLY ROUTING CIRCUIT .....</b>	<b>3</b>	<b>GROUND .....</b>	<b>29</b>
Schematic .....	3	Ground Distribution .....	29
Wiring Diagram - POWER - .....	4	MAIN HARNESS .....	29
BATTERY POWER SUPPLY - IGNITION SW. IN ANY POSITION .....	4	ENGINE ROOM HARNESS .....	33
ACCESSORYPOWER SUPPLY-IGNITIONSW. IN "ACC" OR "ON" .....	9	ENGINE CONTROL HARNESS .....	36
IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" .....	10	BODY HARNESS .....	37
Fuse .....	15	<b>HARNESS .....</b>	<b>40</b>
Fusible Link .....	15	Harness Layout .....	40
Circuit Breaker .....	15	HOW TO READ HARNESS LAYOUT .....	40
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....</b>	<b>16</b>	OUTLINE .....	41
System Description .....	16	MAIN HARNESS .....	42
SYSTEMS CONTROLLED BY IPDM E/R .....	16	ENGINE ROOM HARNESS .....	45
CAN COMMUNICATION LINE CONTROL .....	16	ENGINE CONTROL HARNESS .....	49
IPDM E/R STATUS CONTROL .....	17	BODY HARNESS .....	51
CAN Communication System Description .....	17	BODY NO.2 HARNESS .....	54
CAN Communication Unit .....	17	ROOM LAMP HARNESS .....	55
Function of Detecting Ignition Relay Malfunction .....	17	FRONT DOOR HARNESS .....	56
CONSULT-II .....	18	REAR DOOR HARNESS .....	57
CONSULT-II BASIC OPERATION .....	18	Wiring Diagram Codes (Cell Codes) .....	58
SELF-DIAG RESULTS .....	19	<b>ELECTRICAL UNITS LOCATION .....</b>	<b>61</b>
DATA MONITOR .....	20	Electrical Units Location .....	61
ACTIVE TEST .....	20	ENGINE COMPARTMENT .....	61
Auto Active Test .....	22	PASSENGER COMPARTMENT .....	62
DESCRIPTION .....	22	LUGGAGE COMPARTMENT .....	64
OPERATION PROCEDURE .....	22	<b>HARNESS CONNECTOR .....</b>	<b>65</b>
INSPECTION IN AUTO ACTIVE TEST MODE... .....	22	Description .....	65
Schematic .....	24	HARNESS CONNECTOR (TAB-LOCKING TYPE) .....	65
IPDM E/R Terminal Arrangement .....	25	HARNESS CONNECTOR (SLIDE-LOCKING TYPE) .....	66
IPDM E/R Power/Ground Circuit Inspection .....	26	<b>ELECTRICAL UNITS .....</b>	<b>67</b>
Inspection With CONSULT-II (Self-Diagnosis) .....	27	Terminal Arrangement .....	67
Removal and Installation of IPDM E/R .....	28	<b>SMJ (SUPER MULTIPLE JUNCTION) .....</b>	<b>68</b>
REMOVAL .....	28	Terminal Arrangement .....	68
INSTALLATION .....	28	<b>STANDARDIZED RELAY .....</b>	<b>70</b>
		Description .....	70
		NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS .....	70
		TYPE OF STANDARDIZED RELAYS .....	70

---

<b>FUSE BLOCK - JUNCTION BOX (J/B) .....</b>	<b>72</b>	<b>FUSE, FUSIBLE LINK AND RELAY BOX .....</b>	<b>73</b>
Terminal Arrangement .....	72	Terminal Arrangement .....	73


# POWER SUPPLY ROUTING CIRCUIT

## POWER SUPPLY ROUTING CIRCUIT

### Schematic

PFP:24110

AKS000CM





(M) : With M/T

\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).


# POWER SUPPLY ROUTING CIRCUIT

## Wiring Diagram - POWER - BATTERY POWER SUPPLY - IGNITION SW. IN ANY POSITION

AKS000CN







REFER TO THE FOLLOWING.  
 (E108) -SUPER MULTIPLE JUNCTION (SMJ)



TKWT1567E

# POWER SUPPLY ROUTING CIRCUIT



PG-POWER-02



TKWT1568E

# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-03



TKWT1569E

# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-04

A

B

C

D

E

F

G


H

J

PG

L

M





TKWT1570E

# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-05

: DATA LINE





TKWT1571E

# POWER SUPPLY ROUTING CIRCUIT

## ACCESSORY POWER SUPPLY - IGNITION SW. IN "ACC" OR "ON"

PG-POWER-06



REFER TO THE FOLLOWING.



(M4, M5, E101, E102, E103) - FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWT1572E

# POWER SUPPLY ROUTING CIRCUIT

## IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START"



REFER TO THE FOLLOWING.


(B1) -SUPER MULTIPLE JUNCTION (SMJ)

(M4, E101, E102, E104) -FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-08



A

B

C

D

E

F

G

H

I

J

PG

L





M

REFER TO THE FOLLOWING.										
<b>(M4) -FUSE BLOCK- JUNCTION BOX (J/B)</b>										
1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWT1574E

# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-09



REFER TO THE FOLLOWING.


(M5 , E101) -FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWT1575E




# POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10



TKWT1576E

# POWER SUPPLY ROUTING CIRCUIT



REFER TO THE FOLLOWING.

**(M5 , E101 ) -FUSE BLOCK-JUNCTION BOX (J/B)**


1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

# POWER SUPPLY ROUTING CIRCUIT

## Fuse

AKS00018

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




## Fusible Link

AKS00019

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

### CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



## Circuit Breaker

AKS0001A

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PG  
L  
M

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

### System Description

AKS00010

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relay via IPDM E/R control circuit.
- IPDM E/R-integrated control circuit performs ON-OFF operation of relay, CAN communication control, oil pressure switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

#### CAUTION:

None of the IPDM E/R-integrated relays can be removed.

### SYSTEMS CONTROLLED BY IPDM E/R

1. Lamp control  
Using CAN communication line, it receives signal from BCM and controls the following lamps:
  - Head lamps (Hi, Lo)
  - Parking lamps
  - Tail lamps
  - Front fog lamps
2. Wiper control  
Using CAN communication line, it receives signals from BCM and controls the front wipers.
3. Rear window defogger relay control  
Using CAN communication line, it receives signals from BCM and controls the rear window defogger relay.
4. A/C compressor control  
Using CAN communication line, it receives signals from ECM and controls the A/C relay.
5. Cooling fan control  
Using CAN communication line, it receives signals from ECM and controls cooling fan relay.
6. Horn control  
Using CAN communication line, it receives signals from BCM and controls horn relay.

### CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L-line, CAN H-line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

1. Fail-safe control
  - When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
  - Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none"><li>With the ignition switch ON, the headlamp (low) is ON.</li><li>With the ignition switch OFF, the headlamp (low) is OFF.</li></ul>
Tail and parking lamps	<ul style="list-style-type: none"><li>With the ignition switch ON, the tail and parking lamps is ON.</li><li>With the ignition switch OFF, the tail and parking lamps is OFF.</li></ul>
Cooling fan	<ul style="list-style-type: none"><li>With the ignition switch ON, the cooling fan HI operates.</li><li>With the ignition switch OFF, the cooling fan stops.</li></ul>
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C compressor OFF
Front fog lamps	Front fog lamp relay OFF

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
  - CAN communication is normally performed with other control units.
  - Individual unit control by IPDM E/R is normally performed.
  - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
  - Process to stop CAN communication is activated.
  - All systems controlled by IPDM E/R are stopped. When 1 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
3. Sleep status
  - IPDM E/R operates in low current-consumption mode.
  - CAN communication is stopped.
  - When a change in CAN communication line is detected, mode switches to CAN communication status.
  - When a change hood switch or ignition switch signal is detected, mode switches to CAN communication status.

## CAN Communication System Description

AKS00A1L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

AKS0092W

Refer to [LAN-4, "CAN Communication Unit"](#).

## Function of Detecting Ignition Relay Malfunction

AKS009HN

- When contact point of integrated ignition relay is stuck and cannot be turned OFF, IPDM E/R turns ON tail and parking lamps for 10 minutes to indicate IPDM E/R malfunction.
- When a state of ignition relay having built-in does not agree with a state of Ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

### NOTE:

When the ignition switch is turned ON, the tail lamp is OFF.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## CONSULT-II

AKS009HO

CONSULT-II performs the following functions with combination of data receiving, command and transmission using the CAN communication line from the IPDM E/R.


Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.




- Touch "START (NISSAN BASED VHCL)".




- Touch "IPDM E/R" on "SELECT SYSTEM" screen.

- If "IPDM E/R" is not displayed, print "SELECT SYSTEM" screen, then refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

4. Select the desired part to be diagnosed on “SELECT DIAG MODE” screen.



## SELF-DIAG RESULTS

### Operation Procedure

1. Touch “SELF-DIAG RESULTS” on “SELECT DIAG MODE” screen.
2. Check display content in self-diagnostic results.

### Display Item List

Display Items	CONSULT-II display code	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.	-	-	-	-	-
CAN COMM CIRC	U1000	<ul style="list-style-type: none"> <li>• If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed.</li> <li>• When the data in CAN communication is not received before the specified time</li> </ul>	×	×	Any of or several items below have errors. • TRANSMIT DIAG • ECM • BCM/SEC

### NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

A  
B  
C  
D  
E

F  
G  
H  
I  
J

PG  
L  
M

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## DATA MONITOR

### Operation Procedure

1. Touch “DATA MONITOR” on “SELECT MONITOR ITEM ” screen.
2. Touch “ALL SIGNALS”, “MAIN SIGNALS” or “SELECTION FROM MENU” on “DATA MONITOR” screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

3. Touch “START”.
4. Touch the required monitoring item on “SELECTION FROM MENU”. In “ALL SIGNALS”, all items are monitored. In “MAIN SIGNALS”, predetermined items are monitored.
5. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

### All Signals, Main Signals, Select Item Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
Tail & clear request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L LO request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L HI request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR fog request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L washer request	HL WASHER REQ <sup>NOTE</sup>	OFF	×		×	—
FR wiper request	FR WIP REQ	STOP/1LOW/LOW/HI	×	×	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	×	×	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/Block	×	×	×	Control status of IPDM E/R
Starter request	ST RLY REQ	ON/OFF	×		×	Status of input signal <sup>NOTE</sup>
Ignition relay status	IGN RLY	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
Oil pressure switch	OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
DTLR request	DTLR REQ <sup>NOTE</sup>	ON/OFF	×		×	—
Hood switch	HOOD SW	ON/OFF	×		×	Input signal status
Theft warning horn request	THFT HRN REQ	ON/OFF	×		×	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	×		×	Output status of IPDM E/R

### NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- This item is displayed, but cannot monitor it.

## ACTIVE TEST

### Operation Procedure

1. Touch “ACTIVE TEST” on “SELECT DIAG MODE” screen.
2. Touch item to be tested, and check operation.

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

3. Touch "START".
4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Tail lamp output	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger output	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) output	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan output	MOTOR FAN	With a certain operation (1,2,3,4), the cooling fan can be operated.
Headlamp washer output	HEAD LAMP WASHER <sup>NOTE</sup>	—
Lamp (HI, LO, FOG) output	LAMPS	With a certain operation (OFF, HI ON, LO ON, FOG ON), the lamp relay (Lo, Hi, Fog) can be operated.
Horn output	HORN	Push "ON" button, horn relay operates 20ms.

**NOTE:**

This items are displayed, but they cannot be tested.

A

B

C

D

E

F

G

H

I

J

PG

L

M

## Auto Active Test

### DESCRIPTION

AKS009HP

- In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:
  - Rear window defogger
  - Front wipers
  - Tail and parking lamps
  - Front fog lamps
  - Headlamps (Hi, Lo)
  - A/C compressor (magnetic clutch)
  - Cooling fan

### OPERATION PROCEDURE

1. Close hood front door RH and lift wiper arms away from windshield (to prevent glass damage by wiper operation).

#### NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON and, within 20 seconds, press front door switch LH 10 times. Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once.
6. After a series of operations is repeated three times, auto active test is completed.

#### NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

#### CAUTION:

**Be sure to inspect [BL-36, "Check Door Switch / With Navigation System"](#) or [BL-37, "Check Door Switch / Without Navigation System"](#) when the auto active test cannot be performed.**

### INSPECTION IN AUTO ACTIVE TEST MODE

- When auto active test mode is actuated, the following eight steps are repeated three times.



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.


Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	<ul style="list-style-type: none"> <li>BCM signal input circuit</li> </ul>
		NO	<ul style="list-style-type: none"> <li>Rear window defogger relay</li> <li>Harness/connector malfunction between IPDM E/R and rear window defogger</li> <li>Open circuit of rear window defogger</li> <li>IPDM E/R malfunction</li> </ul>
Any of front wipers, tail and parking lamps, front fog lamps, and head lamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	<ul style="list-style-type: none"> <li>BCM signal input system</li> </ul>
		NO	<ul style="list-style-type: none"> <li>Lamp/wiper motor malfunction</li> <li>Lamp/wiper motor ground circuit malfunction</li> <li>Harness/connector malfunction between IPDM E/R and system in question</li> <li>IPDM E/R (integrated relay) malfunction</li> </ul>
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> <li>BCM signal input circuit</li> <li>CAN communication signal between BCM and ECM.</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>Magnetic clutch malfunction</li> <li>Harness/connector malfunction between IPDM E/R and magnetic clutch</li> <li>IPDM E/R (integrated relay) malfunction</li> </ul>
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	<ul style="list-style-type: none"> <li>ECM signal input circuit</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>Cooling fan motor malfunction</li> <li>Harness/connector malfunction between IPDM E/R and cooling fan motor</li> <li>IPDM E/R (integrated relay) malfunction</li> </ul>
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> <li>Harness/connector malfunction between IPDM E/R and oil pressure switch</li> <li>Oil pressure switch malfunction</li> <li>IPDM E/R malfunction</li> </ul>
		NO	<ul style="list-style-type: none"> <li>CAN communication signal between IPDM E/R and combination meter</li> <li>Combination meter</li> </ul>

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## Schematic

AKS009HQ



TKWT1578E


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## IPDM E/R Terminal Arrangement

AKS009HR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PG  
L  
M



CKIT0439E

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## IPDM E/R Power/Ground Circuit Inspection

AKS009HV

### 1. CHECK FUSE AND FUSIBLE LINK

- Make sure the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Signal name	Fuse, fusible link No.
1, 2	Battery power	F/L-C, F/L-E, Fuse No. 71,78

OK or NG

OK >> GO TO 2.

NG >> Replace fuse or fusible link.

### 2. CHECK POWER SUPPLY CIRCUIT


- Turn ignition switch OFF.
- Disconnect IPDM E/R harness connector E3.
- Check voltage between IPDM E/R harness connector E3 terminals 1 (W/R), 2 (W/L) and ground.

**1 (W/R), 2 (W/L) – : Battery voltage should exist  
Ground**

OK or NG

OK >> GO TO 3.

NG >> Replace IPDM E/R power supply circuit harness.



### 3. CHECK GROUND CIRCUIT


- Disconnect IPDM E/R harness connectors E8 and E9.
- Check continuity between IPDM E/R harness connectors E8 terminal 38 (B), E9 terminal 50 (B/W), 60 (B/W) and ground.

**38 (B), 50 (B/W), 60 (B/W) – : Continuity should exist  
Ground**

OK or NG

OK >> INSPECTION END

NG >> Replace ground circuit harness of IPDM E/R.



**Inspection With CONSULT-II (Self-Diagnosis)**

AKS009HW

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

**1. CHECK SELF DIAGNOSTIC RESULT**

1. Connect CONSULT-II and select "IPDM E/R" on the Diagnosis System Selection screen.
2. Select "SELF-DIAG RESULTS" on the "SELECT DIAG MODE" screen.
3. Check display content in self diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	-	-	-	No malfunction
CAN COMM CIRC	U1000	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> <li>● TRANSMIT DIAG</li> <li>● ECM</li> <li>● BCM/SEC</li> </ul>

**NOTE:**

The Details for Display of the Period Are as Follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END  
 CAN COMM CIRC>>After print-out of the monitor items, refer to [LAN-2. "Precautions When Using CONSULT-II"](#).


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## Removal and Installation of IPDM E/R


### REMOVAL

AKS009HX


1. Remove battery. Refer to [SC-8, "Removal and Installation"](#) in "Starting and Charging System (SC)" section.



2. Remove IPDM E/R cover A. While pushing pawl on backside of IPDM E/R cover B toward vehicle front to unlock, lift up IPDM E/R.



3. While pushing tabs on right and left side of IPDM E/R, remove IPDM E/R cover B from IPDM E/R.
4. Remove harness connector from IPDM E/R.



## INSTALLATION

Install in the reverse order of removal.


# GROUND

## GROUND

### Ground Distribution MAIN HARNESS

PFP:00011

AKS000IB




Next page

CKIT0440E

# GROUND

Preceding page





Next page

CKIT0441E

# GROUND

Preceding page



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PG  
L  
M

CONNECTOR NUMBER	CONNECT TO
(M8)	Data link connector (Terminal No. 5)
(M17)	Air mix door motor (Driver side)
(M32)	Display and A/C auto amp. (Terminal No. 24)
(M35)	Display unit (Terminal No. 22)
(M35)	Display unit (Terminal No. 24)
(M47)	A/T device (Terminal No. 1) • Park position switch • Shift lock solenoid
(M47)	A/T device (Terminal No. 9) • Mode select switch
(M49)	Ashtray illumination
(M53)	Heated seat switch (Passenger side) (With A/T)
(M54)	Heated seat switch (Driver side) (With A/T)
(M55)	Air bag diagnosis sensor unit
(M57)	NAVI control unit (Terminal No. 1)
(M57)	NAVI control unit (Terminal No. 4)
(M62)	Blow motor
(M64)	Glove box lamp
(M67)	Intake door motor
(M68)	Upper glove box lamp
(M154)	Heated seat switch (Driver side) (With M/T)
(M155)	Heated seat switch (Passenger side) (With M/T)
(M252)	Mode door motor
(M253)	Air mix door motor (Passenger side)




Next page

CKIT0442E


# GROUND

Preceding page



# GROUND

## ENGINE ROOM HARNESS



E/


Next page

CKIT0444E


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
**PG**  
L  
M

# GROUND

Preceding page




CON-NECTOR NUMBER	CONNECT TO
(M22)	Steering angle sensor
(M31)	Display and A/C auto amp. (Terminal No. 14)
(E24)	Front combination lamp RH(Terminal No.5) • Headlamp (Low)
(E24)	Front combination lamp RH (Terminal No. 8) • Headlamp (High) • Fog lamp
(E33)	Horn (Low)
(E39)	Cooling fan motor (Terminal No.3) (With A/T)
(E39)	Cooling fan motor (Terminal No.4) (With A/T)
(E39)	Cooling fan motor-1 (With M/T)
(E41)	Front combination lamp LH (Terminal No. 4) • Turn signal • Parking
(E44)	Brake fluid level switch
(E52)	Front wiper motor
(E53)	Cooling fan motor-2 (With M/T)
(E118)	VDC/TCS/ABS control unit (Terminal No. 28)
(E118)	VDC/TCS/ABS control unit (Terminal No. 29)




CKIT0445E

## GROUND

A  
B  
C  
D  
E  
F  
G  
H  
I  
J



CONNECTOR NUMBER	CONNECT TO
(E37)	Shield wire (Crash zone sensor)



CONNECTOR NUMBER	CONNECT TO
(E211)	Alternator (E)

PG


L

M

CKIT0446E

# GROUND


## ENGINE CONTROL HARNESS



CKIT0250E

# GROUND

## BODY HARNESS



\*: This sub-harness is not shown in "HARNESS LAYOUT".

F/


Next page

CKIT0447E

# GROUND


Preceding page

F




CON-NECTOR NUMBER	CONNECT TO
(B26)	Condenser
(B27)	Fuel level sensor unit and fuel pump (Terminal No. 3) • Fuel pump
(B102)	Back-up lamp LH
(B104)	License plate lamp
(B105)	Trunk room lamp switch
(B106)	Trunk lid opener actuator
(B112)	Back-up lamp RH
(B116)	High-mounted stop lamp (On the rear parcel shelf)
(B123)	Bose speaker amp.
(B222)	High-mounted stop lamp (In the rear air spoiler)

B29  
Body ground



B18  
Body ground






CON-NECTOR NUMBER	CONNECT TO
(B15)	Shield wire [LH side air bag (Satellite) sensor]

\*: This sub-harness is not shown in "HARNESS LAYOUT".

CKIT0448E

# GROUND

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
**PG**  
L  
M



# HARNESS

## HARNESS

PFP:00011

### Harness Layout

#### HOW TO READ HARNESS LAYOUT

AKS000IC

The following Harness Layouts use a map style grid to help locate connectors on the drawings:


- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness (Passenger Compartment)

#### To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

#### CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.




Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			

CKIT0108E

# HARNESS

## OUTLINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J


PG

L

M

# HARNESS

## MAIN HARNESS



TKIT0180E


# HARNESS

A4	(M1)	W/40	: BCM (Body control module)	D3	(M41)	W/6	: Audio unit	F2 ★ (M72)	SMJ	: To (F102)
A4	(M2)	B/15	: BCM (Body control module)	D2	(M42)	W/2	: In-vehicle sensor	F2 (M74)	SMJ	: To (D31)
A4 ★	(M4)	W/16	: Fuse block (J/B)	D3	(M43)	W/2	: Cigarette lighter illumination	E3 (M77)	W/2	: Diode
A3	(M5)	W/8	: Fuse block (J/B)	D3	(M44)	B/2	: Cigarette lighter socket	F1 (M78)	W/4	: Remote keyless entry receiver
B3	(M7)	W/3	: Illumination control switch	F3	(M45)	BR/2	: Antenna amp. (Via sub-harness)	C1 (M79)	W/2	: Diode
B4	(M8)	W/16	: Data link connector	E4 ★ (M47)	W/10	: A/T device (With A/T)	C1 (M80)	W/2	: Diode	
B3	(M9)	GY/6	: VDC off switch	E3 (M48)	BR/2	: A/T illumination (With A/T)	C2 (M81)	W/4	: Compass	
A3	(M11)	SMJ	: To (D1)	E4 (M49)	W/2	: Ashtray illumination	E3 (M82)	W/4	: To (M83)	
B3 ★	(M12)	SMJ	: To (B1)	E4 (M50)	W/8	: Hazard switch			: (With navigation system)	
B2	(M14)	W/2	: Circuit breaker (With M/T or automatic drive positioner)	F4 (M51)	B/6	: Yaw rate / side G sensor	E2 (M83)	W/4	: To (M82)	
B2 ★	(M15)	SMJ	: To (E103)	G3 (M52)	B/2	: Power socket (Floor console box) (With A/T)	C3 (M84)	B/2	: Trunk lid opener switch	
C3	(M16)	Y/4	: To (E109)	F3 (M53)	BR/6	: Heated seat switch (Passenger side)	B2 (M85)	L/4	: Heated seat relay (With M/T)	
B2	(M17)	W/3	: Air mix door motor (Driver side)			: (With A/T and heated seat)	F2 (M87)	SMJ	: To (B40) (For U.S.A.)	
B2	(M18)	B/2	: Sunload sensor	F4 (M54)	W/6	: Heated seat switch (Driver side)	F2 (M88)	B/2	: Power socket (Instrument side panel RH)	
C1 ★	(M19)	BR/24	: Combination meter			: (With A/T and heated seat)	F3 (M89)	W/12	: To (M158) (With M/T)	
C1 ★	(M20)	W/24	: Combination meter			: Air bag diagnosis sensor unit	D3 (M90)	W/12	: Option connector for audio unit (For U.S.A.)	
D2	(M22)	W/8	: Steering angle sensor	G4 (M55)	Y/28	: Trunk lid opener cancel switch	B4 (M91)	W/2	: Tire pressure warning check connector	
C3 ★	(M23)	GY/8	: Combination switch (Spiral cable)	F2 (M56)	W/2	: NAVI control unit (With navigation system)				
C3	(M24)	Y/6	: Combination switch (Spiral cable)	F1 (M57)	W/24					
C2	(M25)	BR/2	: Key switch							
D3	(M26)	W/2	: Ignition key hole illumination	F1 (M58)	GY/24					
D3	(M27)	W/8	: NATS antenna amp.							
C3	(M28)	W/10	: Door mirror remote control switch	F1 (M59)	GY/2					
D2	(M29)	W/16	: Combination switch							
C1 ★	(M30)	—	: Body ground	E2 (M60)	W/3					
D1	(M31)	GY/20	: Display and A/C auto amp.							
D1	(M32)	GY/16	: Display and A/C auto amp.	E1 (M61)	W/4					
D1	(M33)	W/4	: Clock	E1 (M62)	W/6					
D2	(M34)	W/2	: Security indicator lamp	E1 (M63)	W/3					
D2	(M35)	W/24	: Display unit (With navigation system)	F2 (M64)	W/2					
D3	(M37)	W/8	: NAVI switch (With navigation system)	E1 (M65)	Y/4					
E3	(M38)	W/12	: A/C and audio controller	E1 (M66)	—					
D4	(M39)	W/16	: Audio unit	E1 (M67)	W/3					
D4	(M40)	W/10	: Audio unit	F2 (M68)	Bulb					
				E1 (M70)	W/18	: To (R2)				

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.  
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIT0181E


# HARNESS



TKIT0182E

# HARNESS

## ENGINE ROOM HARNESS Engine Compartment



★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.  
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

For detail ground distribution information,  
refer to "GROUND DISTRIBUTION".

PG


# HARNESS

D2	<b>C1</b>	B/2	: Fusible link holder	F4	<b>E42</b>	B/2	: Front wheel sensor LH
D1	<b>E2</b>	GY/2	: Fusible link holder	E3	<b>*</b> <b>E43</b>	-	: Body ground
C2	<b>E3</b>	B/2	: IPDM E/R (Intelligent power distribution module engine room)	E2	<b>E44</b>	GY/2	: Brake fluid level switch
D1	<b>E4</b>	W/4	: IPDM E/R (Intelligent power distribution module engine room)	F3	<b>E47</b>	B/8	: VDC relay box
C2	<b>*</b> <b>E5</b>	B/4	: IPDM E/R (Intelligent power distribution module engine room)	F3	<b>E48</b>	B/2	: VDC relay box
D2	<b>*</b> <b>E6</b>	W/6	: IPDM E/R (Intelligent power distribution module engine room)	F2	<b>E49</b>	GY/8	: VDC actuator
D1	<b>*</b> <b>E7</b>	GY/16	: IPDM E/R (Intelligent power distribution module engine room)	F2	<b>E50</b>	B/8	: VDC actuator
D1	<b>*</b> <b>E8</b>	W/12	: IPDM E/R (Intelligent power distribution module engine room)	F2	<b>E52</b>	GY/5	: Front wiper motor
D1	<b>*</b> <b>E9</b>	W/16	: IPDM E/R (Intelligent power distribution module engine room)	B4	<b>*</b> <b>E53</b>	GY/4	: Cooling fan motor-2 (With M/T)
C1	<b>*</b> <b>E10</b>	GY/9	: To <b>F1</b>	E4	<b>E54</b>	GY/2	: To <b>(E55)</b>
C1	<b>*</b> <b>E11</b>	GY/10	: To <b>F2</b>	E4	<b>E55</b>	GY/2	: To <b>(E54)</b>
C1	<b>*</b> <b>E12</b>	B/8	: To <b>F3</b>				
C1	<b>E13</b>	-	: Relay box (For Canada)				
E1	<b>E14</b>	L/4	: Daytime light relay-1 (For Canada)				
E1	<b>E16</b>	L/4	: Daytime light relay-2 (For Canada)				
B1	<b>*</b> <b>E17</b>	-	: Body ground				
C2	<b>E18</b>	-	: Fuse, fusible link and relay box				
F1	<b>E19</b>	L/4	: Back-up lamp relay (With A/T)				
F1	<b>E20</b>	W/3	: Horn relay				
G1	<b>E21</b>	-	: Fuse and fusible link block				
B2	<b>E22</b>	-	: Body ground				
A2	<b>E23</b>	GY/2	: Hood switch				
A2	<b>E24</b>	B/8	: Front combination lamp RH				
B3	<b>E25</b>	GY/6	: Daytime light control unit (For Canada)				
B3	<b>E26</b>	GY/8	: Daytime light control unit (For Canada)				
A4	<b>E27</b>	GY/2	: Front wheel sensor RH				
A3	<b>E28</b>	GY/2	: Front side marker lamp RH				
A4	<b>E29</b>	GY/2	: Front washer motor				
A4	<b>E30</b>	BR/2	: Washer level sensor				
B3	<b>E31</b>	B/3	: Refrigerant pressure sensor				
A5	<b>E32</b>	B/1	: Horn (Low)				
B5	<b>E33</b>	B/1	: Horn (Low)				
B3	<b>E34</b>	B/2	: Ambient sensor				
C3	<b>E35</b>	B/1	: Horn (High)				
C3	<b>E36</b>	B/1	: Horn (High)				
C4	<b>E37</b>	Y/2	: Crash zone sensor				
B4,C4	<b>*</b> <b>E39</b>	GY/4	: Cooling fan motor-1				
E4	<b>E40</b>	GY/2	: Front side marker lamp LH				
E3	<b>E41</b>	B/8	: Front combination lamp LH				

★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.  
**Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.**

# HARNESS


## Passenger Compartment



TKIT0185E

# HARNESS


## Battery Cable



TKIT0031E

# HARNESS

## ENGINE CONTROL HARNESS



TKIT0186E


# HARNESS

Passenger compartment			
C1 ★ (F1)	GY/9	: To (E10)	F2 ★ (F33) GY/8 : To (F221)
C1 ★ (F2)	GY/10	: To (E11)	E4 (F34) B/2 : Compressor
B1 ★ (F3)	B/8	: To (E12)	F1 ★ (F35) B/2 : Park/Neutral position switch
D1 ★ (F4)	G/3	: Camshaft position sensor (PHASE) (Bank 1)	F1 (F36) B/2 : Back-up lamp switch (With M/T)
E1 ★ (F5)	L/2	: EVAP canister purge volume control solenoid valve	D1 ★ (F37) SB/2 : To (F229)
E1 ★ (F6)	GY/10	: A/T assembly (With A/T)	C1 (F38) GY/2 : Condenser
F1 ★ (F7)	GY/8	: A/T assembly (With A/T)	F3 ★ (F39) B/6 : Mass air flow sensor
E1 ★ (F8)	B/8	: A/T assembly (With A/T)	
B2 (F9)	GY/1	: Starter motor	
F2 ★ (F10)	B/3	: Crankshaft position sensor (POS)	D3 ★ (F201) L/6 : To (F18)
E1,F1 ★ (F11)	B/4	: Heated oxygen sensor 2 (Bank 1)	C2 (F202) GY/3 : Ignition coil No. 3 (With power transistor)
F1,F2 ★ (F12)	GY/4	: Heated oxygen sensor 2 (Bank 2)	B3 (F203) GY/3 : Ignition coil No. 1 (With power transistor)
D1 ★ (F13)	GY/2	: Engine coolant temperature sensor	
C1 (F15)	GY/3	: Ignition coil No. 5 (With power transistor)	B3 ★ (F204) G/2 : Intake valve timing control solenoid valve (Bank 1)
C2 ★ (F17)	GY/4	: Heated oxygen sensor 1 (Bank 1)	
C2 ★ (F18)	L/6	: To (F201)	
C3 ★ (F19)	B/3	: Power steering pressure sensor	F3 ★ (F221) G/8 : To (F33)
C3 (F20)	GY/2	: Alternator (S, L)	D3 ★ (F222) GY/2 : Injector No. 1
C3 (F21)	GY/1	: Oil pressure switch	C4 ★ (F223) GY/2 : Injector No. 3
C4 ★ (F22)	-	: Engine ground (With A/T)	D4 ★ (F224) GY/2 : Injector No. 5
C4 ★ (F23)	-	: Engine ground	D4 ★ (F225) GY/2 : Injector No. 2
E4 (F24)	B/1	: Compressor	D4 ★ (F226) GY/2 : Injector No. 4
E4 ★ (F26)	GY/2	: Intake valve timing control solenoid valve (Bank 2)	E4 ★ (F227) GY/2 : Injector No. 6
E3 (F27)	GY/3	: Ignition coil No. 2 (With power transistor)	D4 ★ (F228) L/2 : Knock sensor
E3 (F28)	GY/3	: Ignition coil No. 4 (With power transistor)	B1 ★ (F229) SB/2 : To (F37)
E3 (F29)	GY/3	: Ignition coil No. 6 (With power transistor)	
F3 ★ (F30)	GY/4	: Heated oxygen sensor 1 (Bank 2)	* (F104) GY/24 : TCM (Transmission control module) (With A/T)
F2 ★ (F31)	GY/6	: Electric throttle control actuator	* (F105) L/4 : A/T PV IGN relay (With A/T)
F3 ★ (F32)	B/3	: Camshaft position sensor (PHASE) (Bank 2)	(F106) L/20 : Joint connector-3
			(F107) P/20 : Joint connector-4
			* (F108) SMU : ECM

★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.  
**Do not disconnect these connectors except in the case of working AT sections.**

# HARNESS

## BODY HARNESS Passenger Compartment



# HARNESS

B2 ★ (B1)	SMJ	: To (M12)
A2 ★ (B2)	W/18	: To (E106)
A3 (B4)	W/15	: BCM (Body control module)
B3 (B5)	-	: Body ground
C2 (B6)	W/12	: Front power seat (Driver side) (With drive positioner)
C3 (B7)	W/4	: Front power seat (Driver side) (Without drive positioner)
C2 (B8)	W/3	: Seat belt buckle switch (Driver side)
B4 (B9)	Y/2	: Front LH side air bag module
D3 (B10)	Y/2	: Front RH side air bag module
D3 (B11)	W/3	: Seat belt buckle switch (Passenger side)
D3 (B12)	W/4	: Front power seat (Passenger side)
C4 (B13)	Y/12	: Air bag diagnosis sensor unit
D4 (B14)	Y/12	: Air bag diagnosis sensor unit
B3 (B15)	Y/2	: LH side air bag (Satellite) sensor
B3 (B16)	Y/2	: Front LH seat belt pre-tensioner
B3 (B17)	W/3	: Front door switch driver side
B2 (B18)	-	: Body ground
B3 (B19)	W/18	: To (D51)
C2 (B20)	W/3	: Rear door switch LH
E3 (B21)	Y/2	: RH side air bag (Satellite) sensor
E3 (B22)	Y/2	: Front RH seat belt pre-tensioner
D2 (B23)	W/3	: Front door switch passenger side
D2 (B24)	-	: Body ground
E2 (B25)	W/18	: To (D71)
C4 (B26)	W/2	: Condenser
E4 ★ (B27)	GY/5	: Fuel level sensor unit and fuel pump
C4 (B28)	GY/2	: Fuel level sensor unit (Sub)
C1 (B29)	-	: Body ground
D2 (B30)	Y/2	: LH side curtain air bag module
E3 (B32)	W/3	: Rear door switch RH
E2 (B33)	Y/2	: RH side curtain air bag module
F2 (B34)	W/1	: Condenser
A2 (B35)	W/2	: To (E120)
C2 (B37)	B/1	: Parking brake switch (With M/T)
D2 (B241)	B/1	: Rear window defogger (-)
D2 (B242)	-	: Body ground

★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.  
**Do not disconnect these connectors except in the case of working  
according to WORK FLOW of TROUBLE DIAGNOSES in EC and  
AT sections.**


TKIT0189E

## Body sub-harness

D2	B/1	: Rear window defogger (-)
D2	-	: Body ground

# HARNESS

## Trunk Room



★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.  
**Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.**


For detail ground distribution information,  
refer to "GROUND DISTRIBUTION".

TKIT0190E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

# HARNESS

## BODY NO.2 HARNESS




(B401) SMJ : To (M87)  
(B423) W/16 : Option connector for satellite radio receiver

TKIT0098E

# HARNESS

## ROOM LAMP HARNESS




TKIT0191E

# HARNESS


## FRONT DOOR HARNESS

LH Side



TKIT0192E

RH Side




(D31)	SMJ	: To (M74)
(D32)	W/8	: Door mirror (Passenger side)
(D33)	BR/2	: Tweeter RH
(D34)	W/2	: Front door speaker RH (Without BOSE system)
(D35)	BR/2	: Front door speaker RH (With BOSE system)
(D36)	W/12	: Power window sub-switch (Front passenger side)
(D37)	W/8	: Power window sub-switch (Front passenger side)
(D38)	W/6	: Power window motor (Front passenger side)
(D39)	W/2	: Step lamp (Passenger side)
(D40)	SB/4	: Front door lock actuator passenger side

TKIT0193E

# HARNESS


## REAR DOOR HARNESS

LH Side



TKIT0194E

RH Side



PG

- (D71) W/18 : To (B25)
- (D72) GY/6 : Power window motor (Rear RH)  
(With anti-pinch system)
- (D73) B/2 : Power window motor (Rear RH)  
(Without anti-pinch system)
- (D74) W/8 : Power window sub-switch (Rear RH)
- (D75) W/12 : Power window sub-switch (Rear RH)  
(With anti-pinch system)
- (D76) W/2 : Rear door speaker RH (Without BOSE system)
- (D77) BR/2 : Rear door speaker RH (With BOSE system)
- (D78) SB/4 : Rear door lock actuator RH

TKIT0195E

# HARNESS

## Wiring Diagram Codes (Cell Codes)

AKS000ID

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASCBOF	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
AUT/DP	SE	Automatic Drive Positioner
AUTO/L	LT	Automatic Light System
BACK/L	LT	Back-Up Lamp
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
CLOCK	DI	Clock
COMBSW	LT	Combination Switch
COMM	AV	Audio Visual Communication Line
COMPAS	DI	Compass and Thermometer
COOL/F	EC	Cooling Fan Control
D/C	AT	Direct Clutch Solenoid Valve
D/CF	AT	Direct Clutch Solenoid Valve Function
DEF	GW	Rear Window Defogger
D/LOCK	BL	Power Door Lock
DTRL	LT	Headlamp - With Daytime Light System
E/BRE	AT	A/T 1st Engine Braking
ECM/PW	EC	ECM Power Supply For Back-Up
ECTS	EC	Engine Coolant Temperature Sensor
ETC1	EC	Electric Throttle Control Function
ETC2	EC	Throttle Control Motor Relay
ETC3	EC	Throttle Control Motor
F/FOG	LT	Front Fog Lamp
FPSW1	AT	ATF Pressure Switch 1
FPSW3	AT	ATF Pressure Switch 3
FPSW5	AT	ATF Pressure Switch 5
FPSW6	AT	ATF Pressure Switch 6

# HARNESS

Code	Section	Wiring Diagram Name
F/PUMP	EC	Fuel Pump
FR/B	AT	Front Brake Solenoid Valve
FR/BF	AT	Front Brake Solenoid Valve Function
FTS	AT	A/T Fluid Temperature Sensor Circuit
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/LAMP	LT	Headlamp
HLR/C	AT	High and Low Reverse Clutch Solenoid Valve
HLR/CF	AT	High and Low Reverse Clutch Solenoid Valve Function
HORN	WW	Horn
HSEAT	SE	Heated Seat
IATS	EC	Intake Air Temperature Sensor
I/C	AT	Input Clutch Solenoid Valve
I/CF	AT	Input Clutch Solenoid Valve Function
IGNSYS	EC	Ignition System
ILL	LT	Illumination
I/LOCK	AT	A/T Interlock
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
INJECT	EC	Injector
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
KEYLES	BL	Remote Keyless Entry System
KS	EC	Knock Sensor
LC/B	AT	Low Coast Brake Solenoid Valve
LC/BF	AT	Low Coast Brake Solenoid Valve Function
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply and Ground Circuit
METER	DI	Speedometer, Tachometer, Temp., and Fuel Gauges
MIL/DL	EC	Mil & Data Link Connectors
MIRROR	GW	Power Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	Nissan Anti-Theft System
NAVI	AV	Navigation System
NONDTC	AT	Non-Detective Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater Bank 1
O2H1B2	EC	Heated Oxygen Sensor 1 Heater Bank 2
O2H2B1	EC	Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Heated Oxygen Sensor 2 Heater Bank 2
O2S1B1	EC	Heated Oxygen Sensor 1 Bank 1
O2S1B2	EC	Heated Oxygen Sensor 1 Bank 2
O2S2B1	EC	Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Heated Oxygen Sensor 2 Bank 2

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PG  
L  
M

# HARNESS

Code	Section	Wiring Diagram Name
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHSB1	EC	Camshaft Position Sensor (PHASE) (Bank 1)
PHSB2	EC	Camshaft Position Sensor (PHASE) (Bank 2)
PNP/SW	AT	Park / Neutral Position Switch
PNP/SW	EC	Park / Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	AT	Transmission Control Module Power Supply
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
P/SCKT	WW	Power Socket
PS/SEN	EC	Power Steering Pressure Sensor
ROOM/L	LT	Interior Room Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
SEAT	SE	Power Seat
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STOP/L	LT	Stop Lamp
STSIG	AT	Start Signal Circuit
TAIL/L	LT	Parking, License and Tail Lamps
TCCSIG	AT	A/T Tcc S/V Function (Lock-Up)
TCV	AT	Torque Converter Clutch Solenoid Valve
TLID	BL	Trunk Lid Opener
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TRNSCV	BL	Homelink Universal Transceiver
TRSA/T	AT	Turbine Revolution Sensor
TURN	LT	Turn Signal and Hazard Warning Lamp
T/WARN	WT	Tire Pressure Warning System
VDC	BRC	Vehicle Dynamics Control System
VEHSEC	BL	Vehicle Security System
VENT/V	EC	EVAP Canister Vent Control Valve
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
W/ANT	AV	Audio Antenna
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIPER	WW	Front Wiper and Washer


# ELECTRICAL UNITS LOCATION

## ELECTRICAL UNITS LOCATION

PFP:25230


### Electrical Units Location ENGINE COMPARTMENT

AKS000IE



Relay box **(E13)** (For Canada)  
Built-in daytime light relay-1 **(E14)** (For Canada)  
Built-in daytime light relay-2 **(E16)** (For Canada)


IPDM E/R (Intelligent power distribution module engine room)  
**(E3 , E4 , E5 , E6 ,  
E7 , E8 , E9)**



CKIT0315E


# ELECTRICAL UNITS LOCATION

## PASSENGER COMPARTMENT




**A** Behind the dash side lower LH finisher

Fuse block (J/B) rear view



CKIT0430E

# ELECTRICAL UNITS LOCATION



A  
B  
C  
D  
E  
F  
G  
H  
I  
J



PG

L  
M

CKIT0431E

# ELECTRICAL UNITS LOCATION

## LUGGAGE COMPARTMENT



# HARNESS CONNECTOR

## HARNESS CONNECTOR

PFP:00011

### Description

AKS0001F

#### HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

#### CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

# HARNESS CONNECTOR


## HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

### CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]




# ELECTRICAL UNITS

## ELECTRICAL UNITS


PFP:00011

### Terminal Arrangement


AKS000II




TCM (TRANSMISSION CONTROL MODULE)




VDC/TCS/ABS CONTROL UNIT



DISPLAY AND A/C AUTO AMP.



BCM (BODY CONTROL MODULE)



CKIT0449E

# SMJ (SUPER MULTIPLE JUNCTION)

## SMJ (SUPER MULTIPLE JUNCTION)

PFP:B4341


### Terminal Arrangement

AKS0001U


MAIN HARNESS




**M15** (White)




**M12** (White)




**M87** (White)




**E108** (White)



**B1** (White)



**B401** (White)




ENGINE ROOM HARNESS

BODY HARNESS

BODY NO.2 HARNESS

CKIT0260E

# SMJ (SUPER MULTIPLE JUNCTION)



CKIT0158E

# STANDARDIZED RELAY

## STANDARDIZED RELAY


PFP:00011

### Description

#### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

AKS000IK

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.




SEL881H

### TYPE OF STANDARDIZED RELAYS















1M ..... 1 Make  
1T ..... 1 Transfer

2M ..... 2 Make  
1M-1B ..... 1 Make 1 Break



SEL882H

# STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M	 		 	BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

PG  
L  
M



# FUSE BLOCK - JUNCTION BOX (J/B)

## FUSE BLOCK - JUNCTION BOX (J/B)

PFP:24350

### Terminal Arrangement

AKS000D7





# FUSE, FUSIBLE LINK AND RELAY BOX

## FUSE, FUSIBLE LINK AND RELAY BOX

PFP:24382

### Terminal Arrangement

AKS0001L



CKIT0302E

## **FUSE, FUSIBLE LINK AND RELAY BOX**

---