

SECTION **LAN**
LAN SYSTEM

CONTENTS

CAN		
PRECAUTIONS	3	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	
Precautions When Using CONSULT-II	3	
CHECK POINTS FOR USING CONSULT-II	3	
Precautions For Trouble Diagnosis	3	
CAN SYSTEM	3	
Precautions For Harness Repair	4	
CAN SYSTEM	4	
TROUBLE DIAGNOSES WORK FLOW	5	
When Displaying CAN Communication System Errors	5	
WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM	5	
WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM	5	
TROUBLE DIAGNOSIS FLOW CHART	6	
Diagnosis Procedure	7	
SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)	7	
ACQUISITION OF DATA BY CONSULT-II	8	
HOW TO USE CHECK SHEET TABLE	9	
CAN Diagnostic Support Monitor	15	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM	15	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM	16	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR AWD CONTROL UNIT... ..	16	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM	17	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR INTELLIGENT KEY UNIT..	18	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR VDC/TCS/ABS CONTROL UNIT	19	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DRIVER SEAT CON-		
TROL UNIT	19	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R	20	
CAN COMMUNICATION	21	
System Description	21	
CAN Communication Unit	21	
TYPE 1	21	
TYPE 2	23	
TYPE 3	25	
TYPE 4	27	
CAN SYSTEM (TYPE 1)	30	
System Description	30	
Component Parts and Harness Connector Location..	30	
Schematic-	31	
Wiring Diagram - CAN -	32	
CHECK SHEET	35	
CHECK SHEET RESULTS (EXAMPLE)	37	
Inspection Between TCM and Data Link Connector Circuit	47	
Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit	48	
ECM Circuit Inspection	49	
TCM Circuit Inspection	49	
Data Link Connector Circuit Inspection	50	
Combination Meter Circuit Inspection	50	
BCM Circuit Inspection	51	
Steering Angle Sensor Circuit Inspection	51	
VDC/TCS/ABS Control Unit Circuit Inspection	52	
IPDM E/R Circuit Inspection	52	
CAN Communication Circuit Inspection	53	
IPDM E/R Ignition Relay Circuit Inspection	56	
CAN SYSTEM (TYPE 2)	57	
System Description	57	
Component Parts and Harness Connector Location..	57	
Schematic	58	
Wiring Diagram - CAN -	59	
CHECK SHEET	62	
CHECK SHEET RESULTS (EXAMPLE)	64	
Inspection Between TCM and Data Link Connector Circuit	77	

Inspection Between Data Link Connector and Intelligent Key Unit Circuit	78	BCM Circuit Inspection	112
Inspection Between Intelligent Key Unit and Driver Seat Control Unit Circuit	79	Steering Angle Sensor Circuit Inspection	113
ECM Circuit Inspection	79	VDC/TCS/ABS Control Unit Circuit Inspection	113
TCM Circuit Inspection	80	IPDM E/R Circuit Inspection	114
Data Link Connector Circuit Inspection	80	CAN Communication Circuit Inspection	114
Combination Meter Circuit Inspection	81	IPDM E/R Ignition Relay Circuit Inspection	118
BCM Circuit Inspection	81	CAN SYSTEM (TYPE 4)	119
Steering Angle Sensor Circuit Inspection	82	System Description	119
Intelligent Key Unit Circuit Inspection	82	Component Parts and Harness Connector Location	119
VDC/TCS/ABS Control Unit Circuit Inspection	83	Schematic	120
Driver Seat Control Unit Circuit Inspection	83	Wiring Diagram - CAN -	121
IPDM E/R Circuit Inspection	84	CHECK SHEET	124
CAN Communication Circuit Inspection	85	CHECK SHEET RESULTS (EXAMPLE)	126
IPDM E/R Ignition Relay Circuit Inspection	89	Inspection Between TCM and Data Link Connector Circuit	140
CAN SYSTEM (TYPE 3)	90	Inspection Between Data Link Connector and Intelligent Key Unit Circuit	141
System Description	90	Inspection Between Intelligent Key Unit and Driver Seat Control Unit Circuit	142
Component Parts and Harness Connector Location..	90	ECM Circuit Inspection	142
Schematic	91	TCM Circuit Inspection	143
Wiring Diagram - CAN -	92	AWD Control Unit Circuit Inspection	143
CHECK SHEET	95	Data Link Connector Circuit Inspection	144
CHECK SHEET RESULTS (EXAMPLE)	97	Combination Meter Circuit Inspection	144
Inspection Between TCM and Data Link Connector Circuit	108	BCM Circuit Inspection	145
Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit	109	Steering Angle Sensor Circuit Inspection	145
ECM Circuit Inspection	110	Intelligent Key Unit Circuit Inspection	146
TCM Circuit Inspection	110	VDC/TCS/ABS Control Unit Circuit Inspection	146
AWD Control Unit Circuit Inspection	111	Driver Seat Control Unit Circuit Inspection	147
Data Link Connector Circuit Inspection	111	IPDM E/R Circuit Inspection	148
Combination Meter Circuit Inspection	112	CAN Communication Circuit Inspection	148
		IPDM E/R Ignition Relay Circuit Inspection	153

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS00CG9

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

AKS00ABN

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-21, "CAN Communication Unit"](#) .

**Precautions For Trouble Diagnosis
CAN SYSTEM**

AKS000BF


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J
L
M


LAN

Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



TROUBLE DIAGNOSES WORK FLOW

PPF:00004

When Displaying CAN Communication System Errors

AKS00CBK

WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts : When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage : If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

A

B

C

D

E

F

G

H

I

J


LAN

L

M

TROUBLE DIAGNOSIS FLOW CHART

Depending on the control unit which performs CAN communication, "U1010" may be indicated as the result of self-diagnosis. Replace the control unit if "U1010" is indicated.



- Step 1 : Refer to [LAN-7, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2 : Refer to [LAN-8, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3 : Refer to [LAN-9, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4 : Refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5 : Check and repair according to system diagnosis.

Diagnosis Procedure

SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

(Example) Sedan/4WD/VQ35DE/AT/VDC/Without Intelligent Key system/Without automatic drive positioner

CAN Communication Unit
Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan			
Axle	2WD	4WD		
Engine	VQ35DE			
Transmission	A/T			
Brake control	VDC			
Intelligent Key system		x		x
Automatic drive positioner		x		x
CAN system type	1	2	3	4
CAN system trouble diagnosis	XX-XX	XX-XX	XX-XX	XX-XX

× : Applicable

Check basic specification of the vehicle.

→ Select "x" if it is model with Intelligent Key system.
→ Select "x" if it is model with Automatic drive positioner system.

Which number is selected when sequentially selecting from the top of the specification table?
The number is "CAN system type" of the applicable vehicle.

In the case of this example:
It corresponds to type 3.

PKIB4940E

TROUBLE DIAGNOSES WORK FLOW

[CAN]

ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type.

Copy "SELECT SYSTEM" screen of CONSULT-II.

SELECT SYSTEM		SELECT SYSTEM	
ENGINE		ABS	
A/T		AIR BAG	
ABS		ALL MODE AWD/4WD	
AIR BAG		IPDM E/R	
ALL MODE AWD/4WD		INTELLIGENT KEY	
IPDM E/R		AUTO DRIVE POS	
Page Down		Page Up	
BACK	LIGHT COPY	BACK	LIGHT COPY

Check sheet table

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS				
			ECM	TCM	AWD/4WD	METER/M&A	BCM/SEC	STRG	VDC/TCS/ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)		
ENGINE	-	NG	UNKNW	-	UNKNW	UNKNW	UNKNW	-	UNKNW	-	UNKNW	-	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	-	NG	UNKNW	UNKNW	-	UNKNW	-	-	UNKNW	-	UNKNW	-	CAN COMM CIRCUIT (U1000)	-
ALL MODE AWD/4WD	-	NG	UNKNW	UNKNW	-	UNKNW	-	-	UNKNW	-	UNKNW	-	CAN COMM CIRCUIT (U1000)	-
BCM	No indicator	NG	UNKNW	UNKNW	-	UNKNW	-	-	UNKNW	-	UNKNW	-	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	-	UNKNW	-	UNKNW	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indicator	-	UNKNW	UNKNW	-	-	-	UNKNW	-	-	-	-	CAN COMM CIRCUIT (U1000)	-

Symptoms :

Attach copy of SELECT SYSTEM

Attach copy of SELECT SYSTEM

Copy "SELF-DIAG RESULTS" screen of CONSULT-II.

SELF-DIAG RESULTS	
DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE	PRINT
MODE BACK	LIGHT COPY

Attach copy of ENGINE SELF-DIAG RESULTS

Attach copy of A/T SELF-DIAG RESULTS

Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS

Attach copy of BCM SELF-DIAG RESULTS

Attach copy of ABS SELF-DIAG RESULTS

SELF-DIAG RESULTS	
DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE	PRINT
MODE BACK	LIGHT COPY

CAN DIAG SUPPORT MNTR	
A/T	
INITIAL DIAG	OK
TRANSFER DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICM/4WD	UNKNW
AWD/4WD	OK
PRINT	
MODE BACK	LIGHT COPY

Attach copy of ENGINE CAN DIAG SUPPORT MNTR

Attach copy of BCM CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

Copy "CAN DIAG SUPPORT MNTR" screen of CONSULT-II.

CAN DIAG SUPPORT MNTR		CAN DIAG SUPPORT MNTR	
ENGINE		ENGINE	
INITIAL DIAG	OK	TRANSMIT DIAG	OK
TRANSFER DIAG	OK	TCM	OK
VDC/TCS/ABS	OK	VDC/TCS/ABS	OK
METER/M&A	OK	METER/M&A	OK
ICM	UNKNW	ICM	UNKNW
BCM/SEC	UNKNW	BCM/SEC	UNKNW
IPDM E/R	OK	IPDM E/R	OK
AWD/4WD/e4WD	OK	AWD/4WD/e4WD	OK
EPS	UNKNW	EPS	UNKNW
PRINT		PRINT	
MODE BACK	Scroll Down LIGHT COPY	MODE BACK	Scroll Up LIGHT COPY

CAN DIAG SUPPORT MNTR	
ABS	
INITIAL DIAG	OK
TRANSFER DIAG	OK
ECM	OK
TCM	OK
METER/M&A	OK
STRG	OK
AWD/4WD	OK
PRINT	
MODE BACK	LIGHT COPY

PKIB4941E

HOW TO USE CHECK SHEET TABLE

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB4942E

1. Unit names displayed on CONSULT-II
2. “No indication” : Put a check mark to it if the unit name described in step 1 is not displayed on “SELECT SYSTEM” screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)
“—” : Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. “NG” : Display “NG” when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if “NG” is displayed.
“—” : Column not used (Initial diagnosis is not performed.)
4. “UNKWN” : Display “UNKWN” when the diagnosed unit does not transmit the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (Transmit diagnosis is not performed.)
5. “UNKWN” : Display “UNKWN” when the diagnosed unit does not receive the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (It is not necessary for CAN communication trouble diagnosis.)

NOTE:

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced. Refer to [LAN-10, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced. Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Reproduced

CAN DIAG SUPPORT MNTR	
ENGINE	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	OK
AWD/4WD/e4WD	OK
PRINT	Scroll Down
MODE	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR	
ENGINE	
	PRSNT
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	OK
AWD/4WD/e4WD	OK
EPS	UNKWN
PRINT	Scroll Up
MODE	BACK LIGHT COPY

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
			ECM	TCM	AWD/4WD/e4WD	METER/M&A	BCM/SEC	STRG	VDC/TCS/ABS	IPDM E/R		CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-
ALL MODE AWD/4WD	-	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-	-	-

SELECT SYSTEM	
ENGINE	
A/T	
ABS	
AIR BAG	
ALL MODE AWD/4WD	
IPDM E/R	
Page Down	
BACK LIGHT COPY	

SELECT SYSTEM	
ABS	
AIR BAG	
ALL MODE AWD/4WD	
IPDM E/R	
INTELLIGENT KEY	
AUTO DRIVE POS	
Page Up	
BACK LIGHT COPY	

PKIB4943E

- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

NOTE:

Put a check mark to "No indication" of BCM because BCM is not displayed on "SELECT SYSTEM" screen.


- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

NOTE:

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "ICC", "BCM/SEC" and "EPS". But put a check mark to "BCM/SEC" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

TROUBLE DIAGNOSES WORK FLOW

[CAN]



3. Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "A/T", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" as well as "ENGINE". And then, put a check mark to the check sheet table.

NOTE:

- For "A/T", "UNKWN" is displayed on "ICC/e4WD". But, do not put a check mark to their columns of reception diagnosis of the check sheet table because "UNKWN" is not listed.
- For "ALL MODE AWD/4WD", "UNKWN" is displayed on "TCM". But, do not put a check mark to their columns of reception diagnosis of the check sheet table because "UNKWN" is not listed.
- For "ABS", "UNKWN" is not displayed. Do not put a check to it.
- For "IPDM E/R", "UNKWN" is displayed on "BCM/SEC". Put a check mark to it.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—


Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 8
Check BCM circuit.

Check sheet results (example)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

/////: Malfunctioning part



PKIB4945E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT(U1000)" in "Check sheet results (example)" change to "—". Then, ignore check marks on the Check sheet table.

4. Perform system diagnosis for possible causes identified.
5. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-21, "CAN Communication Unit"](#).

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SYSTEM ENGINE

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1001] 1t

SYSTEM A/T

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM ALL MODE AWD/4WD

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM BCM

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM ABS

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM IPDM E/R

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1000] PAST

PKIB4946E

- See "SELF-DIAG RESULTS" of all units attached to the check sheet. If "CAN COMM CIRCUIT", "CAN COMM CIRCUIT [U1000]" or "CAN COMM CIRCUIT [U1001]" is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

NOTE:

- For "ENGINE", "CAN COMM CIRCUIT [U1001]" are displayed. Put a check mark to it.
- For "A/T", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "ALL MODE AWD/4WD", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "BCM", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "ABS", "NO DTC IS DETECTED" is displayed. Do not put a check mark to it.
- For "IPDM E/R", "CAN COMM CIRCUIT [U1000]" is displayed. Put a check mark to it.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


The arranged results of self-diagnosis

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD (4WD)	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	-	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
ALL MODE 4WD/4WD	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-	

When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.


Case 8
Check BCM circuit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD (4WD)	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	-	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
ALL MODE 4WD/4WD	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-	



Case 11
Check IPDM E/R circuit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD (4WD)	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
AT	-	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
ALL MODE 4WD/4WD	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-	



PKIB4947E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT(U1000)" in "Check sheet results (example)" change to "-". Then, ignore check marks on the Check sheet table.

- For the selected possible causes, it is expected that malfunctions have been found in the past.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

AKS00CBM

CAN Diagnostic Support Monitor

DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td> </td><td style="text-align: center;">PRSNT</td></tr> <tr><td>INITIAL DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td>TCM</td><td style="text-align: center;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: center;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: center;">OK</td></tr> <tr><td>ICC</td><td style="text-align: center;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: center;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: center;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Down</td></tr> <tr><td>MODE</td><td>BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	OK	PRINT	Scroll Down	MODE	BACK LIGHT COPY	CAN DIAG SUPPORT MNTR <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td> </td><td style="text-align: center;">PRSNT</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td>TCM</td><td style="text-align: center;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: center;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: center;">OK</td></tr> <tr><td>ICC</td><td style="text-align: center;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: center;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: center;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Up</td></tr> <tr><td>MODE</td><td>BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	OK	PRINT	Scroll Up	MODE	BACK LIGHT COPY
ENGINE																																																				
	PRSNT																																																			
INITIAL DIAG	OK																																																			
TRANSMIT DIAG	OK																																																			
TCM	OK																																																			
VDC/TCS/ABS	OK																																																			
METER/M&A	OK																																																			
ICC	UNKWN																																																			
BCM/SEC	OK																																																			
IPDM E/R	OK																																																			
AWD/4WD/e4WD	OK																																																			
PRINT	Scroll Down																																																			
MODE	BACK LIGHT COPY																																																			
ENGINE																																																				
	PRSNT																																																			
TRANSMIT DIAG	OK																																																			
TCM	OK																																																			
VDC/TCS/ABS	OK																																																			
METER/M&A	OK																																																			
ICC	UNKWN																																																			
BCM/SEC	OK																																																			
IPDM E/R	OK																																																			
AWD/4WD/e4WD	OK																																																			
PRINT	Scroll Up																																																			
MODE	BACK LIGHT COPY																																																			

SKIB2334E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from VDC/TCS/ABS control unit.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	Make sure of normal reception from AWD control unit.	OK/UNKWN
EPS	EPS is not diagnosed.	UNKWN	

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example)

CAN DIAG SUPPORT MNTR			
A/T			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC/e4WD		UNKWN	
AWD/4WD		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB2335E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from VDC/TCS/ABS control unit.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKWN
	AWD/4WD	Make sure of normal reception from AWD control unit.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR AWD CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
ALL MODE AWD/4WD			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
VDC/TCS/ABS		OK	
ECM		OK	
TCM		UNKWN	
METER/M&A		OK	
PRINT			
MODE	BACK	LIGHT	COPY

PKIA8948E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ALL MODE AWD/4WD	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from VDC/TCS/ABS control unit.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	TCM	TCM is not diagnosed.	UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN

Display Results (Present)

- OK: Normal
- NG: Malfunction
- UNKWN: The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example)

CAN DIAG SUPPORT MNTR			
BCM			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
IPDM E/R		OK	
METER/M&A		OK	
I-KEY		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB1625E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	I-KEY	Make sure of normal reception from Intelligent Key unit.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR INTELLIGENT KEY UNIT

(Example)

CAN DIAG SUPPORT MNTR			
INTELLIGENT KEY			
	PRSNT	PAST	
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
METER/M&A	OK	OK	
BCM/SEC	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB2359E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	past
INTELLIGENT KEY	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN	OK/0/1~39/-
	ECM	Make sure of normal reception from ECM.	OK/UNKWN	
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN	

Display Results (Present)

- OK : Normal
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

Display Results (Past)

- OK : Normal
- 0 : There is malfunction now.
- 1 ~ 39 : Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- - : Undiagnosed

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR VDC/TCS/ABS CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
TCM		OK	
STRG		OK	
METER/M&A		OK	
AWD/4WD		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB2336E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	STRG	Make sure of normal reception from steering angle sensor.	OK/UNKWN
	AWD/4WD	Make sure of normal reception from AWD control unit.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DRIVER SEAT CONTROL UNIT

(Example)

CAN DIAG SUPPORT MNTR			
AUTO DRIVE POS.			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
BCM/SEC		OK	
METER/M&A		OK	
TCM		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB2360E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
AUTO DRIVE POS.	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

PFP:23710

System Description

AKS000D9

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS000DA


Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan			
Axle	2WD	4WD		
Engine	VQ35DE			
Transmission	A/T			
Brake control	VDC			
Intelligent Key system		×		×
Automatic drive positioner		×		×
CAN system type	1	2	3	4
CAN system trouble diagnosis	LAN-30	LAN-57	LAN-90	LAN-119

×:Applicable

TYPE 1

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
A/C compressor request signal	T						R
A/C switch signal	R			T			
A/T CHECK indicator lamp signal		T	R				
A/T position indicator signal		T	R			R	
A/T self-diagnosis signal	R	T					
Accelerator pedal position signal	T	R				R	

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
ASCD CRUISE lamp signal	T		R				
ASCD OD cancel request signal	T	R					
ASCD operation signal	T	R					
ASCD SET lamp signal	T		R				
Battery voltage signal	T	R					
Blower fan motor switch signal	R			T			
Buzzer output signal			R	T			
Closed throttle position signal	T	R					
Cooling fan motor operation signal	T						R
Door switch signal			R	T			R
Engine coolant temperature signal	T		R				
Engine speed signal	T	R	R			R	
Front fog lights request signal				T			R
Front wiper request signal				T			R
Front wiper stop position signal				R			T
Fuel level sensor signal	R		T				
High beam request signal			R	T			R
High beam status signal	R						T
Hood switch signal				R			T
Horn chirp signal				T			R
Low beam request signal				T			R
Low beam status signal	R						T
Malfunction indicator lamp signal	T		R				
Manual mode indicator signal		T	R				
Manual mode shift down signal		R	T				
Manual mode shift up signal		R	T				
Manual mode signal		R	T				
Not manual mode signal		R	T				
Oil pressure switch signal			R				T
Output shaft revolution signal	R	T					
Position lights request signal			R	T			R
Rear window defogger control sig- nal	R						T
Rear window defogger switch sig- nal				T			R
Seat belt buckle switch signal			T	R			
Sleep request 1 signal			R	T			
Sleep request 2 signal				T			R
Snow mode switch signal	R		T				
Steering angle sensor signal					T	R	
Stop lamp switch signal		R	T				
Theft warning horn request signal				T			R
Tire pressure signal			R	T			
Turbine revolution signal	R	T					


CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Combina- tion meter	BCM	Steering angle sensor	VDC/TCS/ ABS control unit	IPDM E/R
Turn indicator signal			R	T			
Vehicle speed signal			R			T	
	R	R	T	R			
Wake up request 1 signal				T			R
Wake up request 2 signal				T			R
Wide open throttle position signal	T	R					

TYPE 2

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	Combina- tion meter	BCM	Steer- ing angle sensor	Intelli- gent Key unit	VDC/ TCS/ ABS control unit	Driver seat control unit	IPDM E/ R
A/C compressor request signal	T								R
A/C switch signal	R			T					
A/T CHECK indicator lamp signal		T	R						
A/T position indicator signal		T	R				R	R*	
A/T self-diagnosis signal	R	T							
Accelerator pedal position signal	T	R					R		
ASCD CRUISE lamp signal	T		R						
ASCD OD cancel request signal	T	R							
ASCD operation signal	T	R							
ASCD SET lamp signal	T		R						
Battery voltage signal	T	R							
Blower fan motor switch signal	R			T					
Buzzer output signal			R	T					
Closed throttle position signal	T	R							
Cooling fan motor operation signal	T								R
Door lock/unlock status signal				T		R			

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Combination meter	BCM	Steering angle sensor	Intelligent Key unit	VDC/TCS/ABS control unit	Driver seat control unit	IPDM E/R
Door lock/unlock/trunk open request signal				R		T			
Door switch signal			R	T		R		R	R
Engine coolant temperature signal	T		R						
Engine speed signal	T	R	R			R	R		
Front fog lights request signal				T					R
Front wiper request signal				T					R
Front wiper stop position signal				R					T
Fuel level sensor signal	R		T						
Hazard and horn request signal				R		T			
High beam request signal			R	T					R
High beam status signal	R								T
Hood switch signal				R					T
Horn chirp signal				T					R
Key fob door unlock signal				T				R	
Key switch signal				T				R	
Low beam request signal				T					R
Low beam status signal	R								T
Malfunction indicator lamp signal	T		R						
Manual mode indicator signal		T	R						
Manual mode shift down signal		R	T						
Manual mode shift up signal		R	T						
Manual mode signal		R	T						
Not manual mode signal		R	T						
Oil pressure switch signal			R						T
Output shaft revolution signal	R	T							
Panic alarm request signal				R		T			
Position lights request signal			R	T					R
Power window open request signal				R		T			
Rear window defogger control signal	R								T
Rear window defogger switch signal				T					R
Seat belt buckle switch signal			T	R					
Sleep request 1 signal			R	T					
Sleep request 2 signal				T					R
Snow mode switch signal	R		T						
Starter permission signal				R		T			
Steering angle sensor signal					T		R		
Stop lamp switch signal		R	T						
Theft warning horn request signal				T					R
Tire pressure signal			R	T					
Turbine revolution signal	R	T							


CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Combination meter	BCM	Steering angle sensor	Intelligent Key unit	VDC/TCS/ABS control unit	Driver seat control unit	IPDM E/R
Turn indicator signal			R	T					
Vehicle speed signal			R				T		
Wake up request 1 signal	R	R	T	R		R		R	
Wake up request 2 signal				T					R
Wide open throttle position signal	T	R							

*: P range and R range only

TYPE 3 System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	AWD control unit	Combination meter	BCM	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
A/C compressor request signal	T							R
A/C switch signal	R				T			
A/T CHECK indicator lamp signal		T		R				
A/T position indicator signal		T		R			R	
A/T self-diagnosis signal	R	T						
Accelerator pedal position signal	T	R	R				R	
ASCD CRUISE lamp signal	T			R				
ASCD OD cancel request signal	T	R						
ASCD operation signal	T	R						
ASCD SET lamp signal	T			R				
AWD warning lamp signal			T	R				
Battery voltage signal	T	R						
Blower fan motor switch signal	R				T			
Buzzer output signal				R	T			

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	AWD control unit	Combination meter	BCM	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
Closed throttle position signal	T	R						
Cooling fan motor operation signal	T							R
Door switch signal				R	T			R
Engine coolant temperature signal	T			R				
Engine speed signal	T	R	R	R			R	
Front fog lights request signal					T			R
Front wiper request signal					T			R
Front wiper stop position signal					R			T
Fuel level sensor signal	R			T				
High beam request signal				R	T			R
High beam status signal	R							T
Hood switch signal					R			T
Horn chirp signal					T			R
Low beam request signal					T			R
Low beam status signal	R							T
Malfunction indicator lamp signal	T			R				
Manual mode indicator signal		T		R				
Manual mode shift down signal		R		T				
Manual mode shift up signal		R		T				
Manual mode signal		R		T				
Not manual mode signal		R		T				
Oil pressure switch signal				R				T
Output shaft revolution signal	R	T						
Parking brake switch signal			R	T				
Position lights request signal				R	T			R
Rear window defogger control signal	R							T
Rear window defogger switch signal					T			R
Seat belt buckle switch signal				T	R			
Sleep request 1 signal				R	T			
Sleep request 2 signal					T			R
SNOW mode switch signal	R		R	T				
Steering angle sensor signal						T	R	
Stop lamp switch signal		R		T				
			R				T	
Theft warning horn request signal					T			R
Tire pressure signal				R	T			
Turbine revolution signal	R	T						
Turn indicator signal				R	T			
Vehicle speed signal			R	R			T	
	R	R		T	R			
Wake up request 1 signal					T			R


CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	AWD control unit	Combination meter	BCM	Steering angle sensor	VDC/TCS/ABS control unit	IPDM E/R
Wake up request 2 signal					T			R
Wide open throttle position signal	T	R						

TYPE 4

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	AWD control unit	Combination meter	BCM	Steering angle sensor	Intelligent Key unit	VDC/TCS/ABS control unit	Driver seat control unit	IPDM E/R
A/C compressor request signal	T									R
A/C switch signal	R				T					
A/T CHECK indicator lamp signal		T		R						
A/T position indicator signal		T		R				R	R*	
A/T self-diagnosis signal	R	T								
Accelerator pedal position signal	T	R	R					R		
ASCD CRUISE lamp signal	T			R						
ASCD OD cancel request signal	T	R								
ASCD operation signal	T	R								
ASCD SET lamp signal	T			R						
AWD warning lamp signal			T	R						
Battery voltage signal	T	R								
Blower fan motor switch signal	R				T					
Buzzer output signal				R	T					
Closed throttle position signal	T	R								

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	AWD control unit	Combination meter	BCM	Steering angle sensor	Intelligent Key unit	VDC/TCS/ABS control unit	Driver seat control unit	IPDME/R
Cooling fan motor operation signal	T									R
Door lock/unlock status signal					T		R			
Door lock/unlock/trunk open request signal					R		T			
Door switch signal				R	T		R	R	R	R
Engine coolant temperature signal	T			R						
Engine speed signal	T	R	R	R			R	R		
Front fog lights request signal					T					R
Front wiper request signal					T					R
Front wiper stop position signal					R					T
Fuel level sensor signal	R			T						
Hazard and horn request signal					R		T			
High beam request signal				R	T					R
High beam status signal	R									T
Hood switch signal					R					T
Horn chirp signal					T					R
Key fob door unlock signal					T				R	
Key switch signal					T				R	
Low beam request signal					T					R
Low beam status signal	R									T
Malfunction indicator lamp signal	T			R						
Manual mode indicator signal		T		R						
Manual mode shift down signal		R		T						
Manual mode shift up signal		R		T						
Manual mode signal		R		T						
Not manual mode signal		R		T						
Oil pressure switch signal				R						T
Output shaft revolution signal	R	T								
Panic alarm request signal					R		T			
Parking brake switch signal			R	T						
Position lights request signal				R	T					R
Power window open request signal					R		T			
Rear window defogger control signal	R									T
Rear window defogger switch signal					T					R
Seat belt buckle switch signal				T	R					
Sleep request 1 signal				R	T					

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	AWD control unit	Combination meter	BCM	Steering angle sensor	Intelligent Key unit	VDC/TCS/ABS control unit	Driver seat control unit	IPDM E/R
Sleep request 2 signal					T					R
SNOW mode switch signal	R		R	T						
Starter permission signal					R		T			
Steering angle sensor signal						T		R		
Stop lamp switch signal		R		T						
			R					T		
Theft warning horn request signal					T					R
Tire pressure signal				R	T					
Turbine revolution signal	R	T								
Turn indicator signal				R	T					
Vehicle speed signal			R	R				T		
	R	R		T	R		R		R	
Wake up request 1 signal					T					R
Wake up request 2 signal					T					R
Wide open throttle position signal	T	R								

*: P range and R range only

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

AKS0092B

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS0092C




CAN SYSTEM (TYPE 1)

[CAN]

Schematic-

AKS0092D



A
B
C
D
E
F
G
H
I
J
LAN
L
M

TKWM2111E

CAN SYSTEM (TYPE 1)




[CAN]

Wiring Diagram - CAN -

AKS0092E

LAN-CAN-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)



(F108) -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.


TKWM2112E

A
B
C
D
E
F
G
H
I
J
LAN
L
M


▬ : DATA LINE



(M8)
W



(M19)
W





(M22)
W

REFER TO THE FOLLOWING.


(M1) -ELECTRICAL UNITS

LAN-CAN-03

▬ : DATA LINE



E9
W



B2
W

REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

(M93) -ELECTRICAL UNITS

TKWM2114E

CAN SYSTEM (TYPE 1)

[CAN]

AKS0092F

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB3892E

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA7899E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-47, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	—	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	✓	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB3893E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-48. "Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG					
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—	

PKIB3894E



PKIB4030E

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-49, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG					
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U [✓] 00)	CAN COMM CIRCUIT (U [✓] 01)	
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	UNKW [✓] N	—	CAN COMM CIRCUIT (U [✓] 00)	—	
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	CAN COMM CIRCUIT (U [✓] 00)	—	
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	CAN COMM CIRCUIT (U [✓] 00)	—	

PKIB3895E



PKIB4031E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-49, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3896E



PKIB4032E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-50, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						STRG			VDC/TCS /ABS	IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC							
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)		
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—		
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—		
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—		
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—		

PKIB3897E



PKIB4033E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check combination meter circuit. Refer to [LAN-50, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3898E



PKIB4034E

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-51, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG					
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3899E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-51, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						STRG			VDC/TCS /ABS	IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC							
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)		
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—		
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—		
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—		
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—		

PKIB3900E



PKIB4036E

CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-52, "VDC/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						VDC/TCS /ABS			IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG					
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3901E



PKIB4037E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-52, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3902E



PKIB4038E

Case 11

Check CAN communication circuit. Refer to [LAN-53, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3903E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-56, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	—	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3904E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-56, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3905E

Inspection Between TCM and Data Link Connector Circuit

AKS0092G

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F42 terminals 3 (L), 8 (R) and harness connector F102 terminals 24H (L), 25H (P).

3 (L) – 24H (L) : Continuity should exist.
8 (R) – 25H (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 24H (L), 25H (P) and data link connector M8 terminals 6 (L), 14 (P).

24H (L) – 6 (L) : Continuity should exist.
25H (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit

AKS0092H


1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and VDC/TCS/ABS control unit connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and VDC/TCS/ABS control unit harness connector M93 terminals 61 (L), 63 (P).

6 (L) – 61 (L) : Continuity should exist.
14 (P) – 63 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



ECM Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F108 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



AKS0092J

TCM Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F42 terminals 3 (L) and 8 (R).

3 (L) – 8 (R) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F102.



SKIA6866E

A

B

C

D

E

F

G

H

I

J

LAN

L

M

Data Link Connector Circuit Inspection

AKS00AAH

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and combination meter.



Combination Meter Circuit Inspection

AKS0092K

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M19 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



BCM Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M1 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.

**Steering Angle Sensor Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



VDC/TCS/ABS Control Unit Circuit Inspection

AKS0092N

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector M93 terminals 61 (L) and 63 (P).

61 (L) – 63 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
NG >> Repair harness between VDC/TCS/ABS control unit and harness connector M12.



AKS0092O

IPDM E/R Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector B2
 - Harness connector E106
 - Harness connector M12
 - Harness connector B1

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
NG >> Repair harness between IPDM E/R and VDC/TCS/ABS control unit.



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, sensor side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
2. Check continuity between ECM harness connector F108 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F108 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - VDC/TCS/ABS control unit connector
 - Harness connector M12
- Check continuity between data link connector M8 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B2.
2. Check continuity between harness connector B1 terminals 52J (L) and 51J (P).

52J (L) – 51J (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
- NG >> Repair harness between harness connector B1 and harness connector B2.



7. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B1 terminals 52J (L), 51J (P) and ground.

52J (L) – Ground : Continuity should not exist.

51J (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
- NG >> Repair harness between harness connector B1 and harness connector B2.




8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
- NG >> Repair harness between IPDM E/R and harness connector B2.



9. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.

49 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 10.
- NG >> Repair harness between IPDM E/R and harness connector B2.



10. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

94 – 86 : **Approx. 108 – 132 Ω**

48 – 49 : **Approx. 108 – 132 Ω**

OK or NG

- OK >> GO TO 11.
 NG >> Replace ECM and/or IPDM E/R.



11. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 12.
 NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

12. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduce.
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - ECM
 - IPDM E/R

Check results

- Reproduced>>Install removed unit, and then check the other unit.
 Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS0092Q

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" .](#)

CAN SYSTEM (TYPE 2)


System Description

AKS00C9L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00C9M



PKIB5333E

A
B
C
D
E
F
G
H
I
J
LAN
L
M


LAN

CAN SYSTEM (TYPE 2)

[CAN]

Schematic

AKS00C9N



TKWM2465E

CAN SYSTEM (TYPE 2)




[CAN]

Wiring Diagram - CAN -

AKS00C90

LAN-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.

F102 -SUPER MULTIPLE JUNCTION (SMJ)



F108 -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


TKWM2466E

LAN-CAN-05


▬ : DATA LINE



(M8)
W



(M19)
W



(M22)
W

REFER TO THE FOLLOWING.

(M1) -ELECTRICAL UNITS



TKWM2467E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-06

A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M75), (M93) -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2468E

CAN SYSTEM (TYPE 2)

[CAN]

AKS00C9P

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB3940E

CAN SYSTEM (TYPE 2)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
INTELLIGENT KEY
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
INTELLIGENT KEY
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB3907E

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-77, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	✓	✓	—	—	—	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKW	UNKW	—	✓	—	—	—	—	✓	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKW	✓	—	UNKW	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKW	✓	—	UNKW	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKW	✓	✓	UNKW	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	✓	UNKW	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKW	✓	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB3908E



CAN SYSTEM (TYPE 2)

[CAN]


Case 2

Check harness between data link connector and Intelligent Key unit. Refer to [LAN-78, "Inspection Between Data Link Connector and Intelligent Key Unit Circuit"](#) .

A
B
C
D
E
F
G
H
I
J
LAN
L
M

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB3909E



PKIB4040E

CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check harness between Intelligent Key unit and driver seat control unit. Refer to [LAN-79, "Inspection Between Intelligent Key Unit and Driver Seat Control Unit Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3910E



CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-79, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U600) ✓	CAN COMM CIRCUIT (U601) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U600) ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U600) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U600) ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U600) ✓	—

PKIB3911E



LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-80, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	✓	—	✓	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	✓	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3912E



CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-80, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3913E



LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-81, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3914E



PKIB4045E

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-81, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB3915E



LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check steering angle sensor circuit. Refer to [LAN-82, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3916E




PKIB4047E

Case 10

Check Intelligent Key unit circuit. Refer to [LAN-82, "Intelligent Key Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3917E




A
B
C
D
E
F
G
H
I
J
LAN
L
M

Case 11

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-83, "VDC/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3918E




Case 12

Check driver seat control unit circuit. Refer to [LAN-83, "Driver Seat Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3919E



LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 13

Check IPDM E/R circuit. Refer to [LAN-84, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB3920E



Case 14

Check CAN communication circuit. Refer to [LAN-85, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U000) ✓	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB3921E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-89, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	✓UNKWN	UNKWN	UNKWN	—	—	—	✓UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3922E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-89, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3923E

Inspection Between TCM and Data Link Connector Circuit

AKS00C9Q

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F42 terminals 3 (L), 8 (R) and harness connector F102 terminals 24H (L), 25H (P).

3 (L) – 24H (L) : Continuity should exist.
8 (R) – 25H (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 24H (L), 25H (P) and data link connector M8 terminals 6 (L), 14 (P).

24H (L) – 6 (L) : Continuity should exist.
25H (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and Intelligent Key Unit Circuit

AKS00C9R


1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and Intelligent Key unit connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and Intelligent Key unit harness connector M75 terminals 2 (L), 3 (P).

6 (L) – 2 (L) : Continuity should exist.
14 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Intelligent Key Unit and Driver Seat Control Unit Circuit

AKS00CAM

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M12
 - Harness connector B1

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector and harness connector M12.
2. Check continuity between Intelligent Key unit harness connector M75 terminals 2 (L), 3 (P) and harness connector M12 terminals 52J (L), 51J (P).

2 (L) – 52J (L) : Continuity should exist.
3 (P) – 51J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B6.
2. Check continuity between harness connector B1 terminals 52J (L), 51J (P) and harness connector B6 terminals 3 (L), 19 (P).

52J (L) – 3 (L) : Continuity should exist.
51J (P) – 19 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



LAN

L

M

ECM Circuit Inspection

AKS00C9S

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F108 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
NG >> Repair harness between ECM and A/T assembly.



TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F42 terminals 3 (L) and 8 (R).

3 (L) – 8 (R) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
NG >> Repair harness between A/T assembly and harness connector F102.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and combination meter.



AKS00C9V

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M19 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



AKS00C9W

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M1 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
- NG >> Repair harness between steering angle sensor and data link connector.



Intelligent Key Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M75 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace Intelligent Key unit.
 NG >> Repair harness between Intelligent Key unit and VDC/TCS/ABS control unit.



AKS00C9Y

VDC/TCS/ABS Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector M93 terminals 61 (L) and 63 (P).

61 (L) – 63 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and harness connector M12.



AKS00CA0

Driver Seat Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side, connector side and harness side).
 - Driver seat control unit connector
 - Harness connector B6
 - Harness connector B321

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B324 terminals 3 (OR) and 19 (LG).

3 (OR) – 19 (LG) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B2.



AKS00C9Z

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R connector
 - Harness connector B2
 - Harness connector E106

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector B6.



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, sensor side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - Intelligent Key unit
 - VDC/TCS/ABS control unit
 - Driver seat control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
2. Check continuity between ECM harness connector F108 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F108 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
 - Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - Intelligent Key unit connector
 - VDC/TCS/ABS control unit connector
 - Harness connector M12
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B6 and harness connector B2.
2. Check continuity between harness connector B1 terminals 52J (L) and 51J (P).


52J (L) – 51J (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B1 and harness B6
- Harness between harness connector B1 and harness connector B2



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B1 terminals 52J (L), 51J (P) and ground.

52J (L) – Ground : Continuity should not exist.


51J (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B1 and harness B6
- Harness between harness connector B1 and harness connector B2



8. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B324 terminals 3 (OR) and 19 (LG).

3 (OR) – 19 (LG) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Repair harness between driver seat control unit and harness connector B321.



A
B
C
D
E
F
G
H
I
J
LAN
L
M


9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B324 terminals 3 (OR), 19 (LG) and ground.

- 3 (OR) – Ground : Continuity should not exist.**
- 19 (LG) – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 10.
- NG >> Repair harness between driver seat control unit and harness connector B321.




10. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

- 48 (L) – 49 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 11.
- NG >> Repair harness between IPDM E/R and harness connector E106.




11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

- 48 (L) – Ground : Continuity should not exist.**
- 49 (P) – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 12.
- NG >> Repair harness between IPDM E/R and harness connector E106.



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.


- 94 – 86 : Approx. 108 – 132 Ω**

- Check resistance between IPDM E/R terminals 48 and 49.

- 48 – 49 : Approx. 108 – 132 Ω**

OK or NG

- OK >> GO TO 13.
- NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduce.
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - Intelligent Key unit
 - VDC/TCS/ABS control unit
 - Driver seat control unit
 - ECM
 - IPDM E/R

Check results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00CA1

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" .](#)

CAN SYSTEM (TYPE 3)


System Description

AKS00AU3

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00AU4




CAN SYSTEM (TYPE 3)

[CAN]

Schematic

AKS00AU5



A
B
C
D
E
F
G
H
I
J
LAN
L
M

TKWM2469E

CAN SYSTEM (TYPE 3)




[CAN]

Wiring Diagram - CAN -

AKS00AU6

LAN-CAN-07

▬ : DATA LINE



REFER TO THE FOLLOWING.

F102 -SUPER MULTIPLE JUNCTION (SMJ)






F108 -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2470E

LAN-CAN-08

▬ : DATA LINE





REFER TO THE FOLLOWING.


(M1) -ELECTRICAL UNITS

TKWM2471E

▬ : DATA LINE



(E9) W



(B2) W

REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M93) -ELECTRICAL UNITS

TKWM2472E

CAN SYSTEM (TYPE 3)

[CAN]

AKS00AU7

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB3924E

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB3925E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-108, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	✓	—	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	✓	✓	—	—	✓	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3926E




A
B
C
D
E
F
G
H
I
J
LAN
L
M

Case 2

Check harness between data link connector and VDC/TCS/ABS control unit. Refer to [LAN-109, "Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										VDC/TCS /ABS	IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG						
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3927E



PKIB4053E

CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-110, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS				
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	CAN COMM CIRCUIT (U000) ✓	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	UNKW N	—	—	—	UNKW N	—	CAN COMM CIRCUIT (U000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	—	—	UNKW N	—	—	—	UNKW N	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication	NG	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	UNKW N	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB3928E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-110, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓	
A/T	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U100) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3929E



PKIB4055E

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check AWD control unit circuit. Refer to [LAN-111, "AWD Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS				
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
A/T	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKW	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3930E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-111, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3931E



PKIB4057E

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-112, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3932E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-112, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3933E



PKIB4059E

CAN SYSTEM (TYPE 3)


[CAN]

Case 9

Check steering angle sensor circuit. Refer to [LAN-113, "Steering Angle Sensor Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3934E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 10

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-113, "VDC/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										VDC/TCS /ABS	IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG						
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3935E



PKIB4061E

CAN SYSTEM (TYPE 3)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-114, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS				
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication ✓	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3936E



Case 12

Check CAN communication circuit. Refer to [LAN-114, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS				
ENGINE	—	NG	UNKW ✓	—	UNKW ✓	UNKW ✓	UNKW ✓	UNKW ✓	—	UNKW ✓	UNKW ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKW	UNKW ✓	—	UNKW ✓	UNKW ✓	—	—	UNKW ✓	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKW ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication ✓	NG	UNKW	UNKW	—	—	UNKW	—	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG ✓	UNKW ✓	UNKW ✓	UNKW ✓	UNKW ✓	UNKW ✓	—	UNKW ✓	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication ✓	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3937E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-118, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3938E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-118, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3939E

Inspection Between TCM and Data Link Connector Circuit

AKS00AUB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F42 terminals 3 (L), 8 (R) and harness connector F102 terminals 24H (L), 25H (P).

3 (L) – 24H (L) : Continuity should exist.
8 (R) – 25H (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 24H (L), 25H (P) and data link connector M8 terminals 6 (L), 14 (P).

24H (L) – 6 (L) : Continuity should exist.
25H (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



Inspection Between Data Link Connector and VDC/TCS/ABS Control Unit Circuit

AKS00AU9


1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and VDC/TCS/ABS control unit connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and VDC/TCS/ABS control unit harness connector M93 terminals 61 (L), 63 (P).

6 (L) – 61 (L) : Continuity should exist.
14 (P) – 63 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

ECM Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F108 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F42 terminals 3 (L) and 8 (R).

3 (L) – 8 (R) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
NG >> Repair harness between A/T assembly and harness connector F102.



AWD Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M10 terminals 8 (L) and 16 (P).

8 (L) – 16 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace AWD control unit.
 NG >> Repair harness between AWD control unit and data link connector.



Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and combination meter.



A
B
C
D
E
F
G
H
I
J
LAN
L
M

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M19 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M1 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



AKS00AUG

VDC/TCS/ABS Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector M93 terminals 61 (L) and 63 (P).

61 (L) – 63 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and harness connector M12.

A
B
C
D
E
F
G
H
I
J
LAN
L
M

IPDM E/R Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R
 - Harness connector B2
 - Harness connector E106
 - Harness connector M12
 - Harness connector B1

OK or NG


- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P)**: Approx. 108 – 132 Ω****OK or NG**

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and VDC/TCS/ABS control unit.

**CAN Communication Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, sensor side and harness side).
 - ECM
 - A/T assembly
 - AWD control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
- Check continuity between ECM harness connector F108 terminals 94 (L) and 86 (P).


94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and A/T assembly
- Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F108 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.


86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and A/T assembly
- Harness between ECM and harness connector F102



A
B
C
D
E
F
G
H
I
J

LAN

L

M

4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - AWD control unit connector
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - VDC/TCS/ABS control unit connector
 - Harness connector M12
2. Check continuity between data link connector M8 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and AWD control unit
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and AWD control unit
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B2.
2. Check continuity between harness connector B1 terminals 52J (L) and 51J (P).

52J (L) – 51J (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector B1 and harness connector B2.



7. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between harness connector B1 terminals 52J (L), 51J (P) and ground.

52J (L) – Ground : Continuity should not exist.

51J (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector B1 and harness connector B2.




8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Repair harness between IPDM E/R and harness connector E106.



9. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

48 (L) – Ground : Continuity should not exist.

49 (P) – Ground : Continuity should not exist.


OK or NG

- OK >> GO TO 10.
 NG >> Repair harness between IPDM E/R and harness connector E106.



10. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
3. Check resistance between IPDM E/R terminals 48 and 49.
48 – 49 : Approx. 108 – 132 Ω



OK or NG

- OK >> GO TO 11.
NG >> Replace ECM and/or IPDM E/R.

11. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 12.
NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

12. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduce.
 - A/T assembly
 - AWD control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - ECM
 - IPDM E/R

Check results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00AUJ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" ."](#)

CAN SYSTEM (TYPE 4)


System Description

AKS00CA3

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00CA4



PKIB5335E

A
B
C
D
E
F
G
H
I
J
K
L
M


LAN

CAN SYSTEM (TYPE 4)

[CAN]

AKS00CA5

Schematic



TKWM2473E

CAN SYSTEM (TYPE 4)




[CAN]

Wiring Diagram - CAN -

AKS00CA6

LAN-CAN-10

▬ : DATA LINE



REFER TO THE FOLLOWING.

F102 -SUPER MULTIPLE JUNCTION (SMJ)






F108 -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2474E

LAN-CAN-11

▬ : DATA LINE



REFER TO THE FOLLOWING.


(M1) -ELECTRICAL UNITS

TKWM2475E





CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-12



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M75), (M93) -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

TKWM2476E

CAN SYSTEM (TYPE 4)

[CAN]

AKS00CA7

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB3906E

CAN SYSTEM (TYPE 4)

[CAN]

A
B
C
D
E
F
G
H
I
J
K
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
INTELLIGENT KEY
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
INTELLIGENT KEY
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

LAN

PKIB3941E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-140, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	✓	—	—	—	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	✓	✓	—	—	—	✓	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	✓	✓	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3942E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between data link connector and Intelligent Key unit. Refer to [LAN-141, "Inspection Between Data Link Connector and Intelligent Key Unit Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3943E



PKIB4064E

CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check harness between Intelligent Key unit and driver seat control unit. Refer to [LAN-142, "Inspection Between Intelligent Key Unit and Driver Seat Control Unit Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—	

PKIB3944E



PKIB4065E

CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-142. "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB3945E



LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-143, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3946E



PKIB4067E

CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check AWD control unit circuit. Refer to [LAN-143, "AWD Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3947E



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-144, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD/e4WD	METER/M&A	BCM/SEC	STRG	I-KEY	VDC/TCS/ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3948E



CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-144, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD/e4WD	METER/M&A	BCM/SEC	STRG	I-KEY	VDC/TCS/ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3949E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-145, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3950E



CAN SYSTEM (TYPE 4)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-145, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3951E



PKIB4072E

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 11

Check Intelligent Key unit circuit. Refer to [LAN-146, "Intelligent Key Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	AWD/4WD/e4WD	METER/M&A	BCM/SEC	STRG	I-KEY	VDC/TCS/ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3952E



PKIB4073E

CAN SYSTEM (TYPE 4)


[CAN]

Case 12

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-146, "VDC/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB3953E




LAN

Case 13

Check driver seat control unit circuit. Refer to [LAN-147, "Driver Seat Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	AWD/4WD/e4WD	METER/M&A	BCM/SEC	STRG	I-KEY	VDC/TCS/ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3954E



CAN SYSTEM (TYPE 4)


[CAN]

Case 14

Check IPDM E/R circuit. Refer to [LAN-148, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	—	—	UNKW	—	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKW	UNKW	—	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB3955E



Case 15

Check CAN communication circuit. Refer to [LAN-148, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKW	UNKW	—	UNKW	UNKW	—	—	—	UNKW	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKW	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	—
INTELLIGENT KEY	No indication	—	UNKW	UNKW	—	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	UNKW	—	—	—	CAN COMM CIRCUIT (U000)	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	—	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB3956E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-153. "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3957E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-153. "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	AWD/4WD /e4WD	METER /M&A	BCM /SEC	STRG	I-KEY	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
INTELLIGENT KEY	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB3958E

Inspection Between TCM and Data Link Connector Circuit

AKS00CA8

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F42 terminals 3 (L), 8 (R) and harness connector F102 terminals 24H (L), 25H (P).

3 (L) – 24H (L) : Continuity should exist.
8 (R) – 25H (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 24H (L), 25H (P) and data link connector M8 terminals 6 (L), 14 (P).

24H (L) – 6 (L) : Continuity should exist.
25H (P) – 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



Inspection Between Data Link Connector and Intelligent Key Unit Circuit

AKS00CAP


1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect ECM connector and Intelligent Key unit connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (P) and Intelligent Key unit harness connector M75 terminals 2 (L), 3 (P).

6 (L) – 2 (L) : Continuity should exist.
14 (P) – 3 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

Inspection Between Intelligent Key Unit and Driver Seat Control Unit Circuit

AKS00CAQ

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M12
 - Harness connector B1

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector and harness connector M12.
2. Check continuity between Intelligent Key unit harness connector M75 terminals 2 (L), 3 (P) and harness connector M12 terminals 52J (L), 51J (P).


2 (L) – 52J (L) : Continuity should exist.

3 (P) – 51J (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B6.
2. Check continuity between harness connector B1 terminals 52J (L), 51J (P) and harness connector B6 terminals 3 (L), 19 (P).


52J (L) – 3 (L) : Continuity should exist.

51J (P) – 19 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

AKS00CAA

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F108 terminals 94 (L) and 86 (P).

94 (L) – 86 (P)

: Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



AKS00CAC

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F42 terminals 3 (L) and 8 (R).

3 (L) – 8 (R)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F102.



AKS00CAB

AWD Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of AWD control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect AWD control unit connector.
2. Check resistance between AWD control unit harness connector M10 terminals 8 (L) and 16 (P).

8 (L) – 16 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace AWD control unit.
 NG >> Repair harness between AWD control unit and data link connector.



AKS00CAD

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-5, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and combination meter.



AKS00CAE

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M19 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



AKS00CAF

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M1 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
 NG >> Repair harness between BCM and data link connector.



AKS00CAG

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M22 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Intelligent Key Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M75 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace Intelligent Key unit.
 NG >> Repair harness between Intelligent Key unit and VDC/TCS/ABS control unit.



VDC/TCS/ABS Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector M93 terminals 61 (L) and 63 (P).

61 (L) – 63 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between VDC/TCS/ABS control unit and harness connector M12.



AKS00CAS

Driver Seat Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control unit side, connector side and harness side).
 - Driver seat control unit connector
 - Harness connector B6
 - Harness connector B321

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector B324 terminals 3 (OR) and 19 (LG).

3 (OR) – 19 (LG) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B2.



A
B
C
D
E
F
G
H
I
J
LAN
L
M

IPDM E/R Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - IPDM E/R
 - Harness connector B2
 - Harness connector E106

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

48 (L) – 49 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector B6.

**CAN Communication Circuit Inspection****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, sensor side and harness side).
 - ECM
 - A/T assembly
 - AWD control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - Intelligent Key unit
 - VDC/TCS/ABS control unit
 - Driver seat control unit
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
- Check continuity between ECM harness connector F108 terminals 94 (L) and 86 (P).


94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and A/T assembly
- Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F108 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.


86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and A/T assembly
- Harness between ECM and harness connector F102



A
B
C
D
E
F
G
H
I
J
LAN
L
M

4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - AWD control unit
 - Combination meter connector
 - BCM connector
 - Steering angle sensor connector
 - Intelligent Key unit
 - VDC/TCS/ABS control unit
 - Harness connector M12
- Check continuity between data link connector M8 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and AWD control unit
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and AWD control unit
- Harness between data link connector and combination meter
- Harness between data link connector and BCM
- Harness between data link connector and steering angle sensor
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and VDC/TCS/ABS control unit
- Harness between data link connector and harness connector M12



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B6 and harness connector B2.
2. Check continuity between harness connector B1 terminals 52J (L) and 51J (P).


52J (L) – 51J (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B1 and harness connector B6
- Harness between harness connector B1 and harness connector B2



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B1 terminals 52J (L), 51J (P) and ground.

52J (L) – Ground : Continuity should not exist.


51J (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B1 and harness connector B6
- Harness between harness connector B1 and harness connector B2



8. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect driver seat control unit connector.
2. Check continuity between driver seat control unit harness connector B324 terminals 3 (OR) and 19 (LG).

3 (OR) – 19 (LG) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Repair harness between Driver seat control unit and harness connector B321.



A
B
C
D
E
F
G
H
I
J
LAN
L
M


9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between driver seat control unit harness connector B324 terminals 3 (OR), 19 (LG) and ground.

- 3 (OR) – Ground : Continuity should not exist.**
- 19 (LG) – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 10.
- NG >> Repair harness between Driver seat control unit and harness connector B321.




10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (P).

- 48 (L) – 49 (P) : Continuity should not exist.**

OK or NG

- OK >> GO TO 11.
- NG >> Repair harness between IPDM E/R harness connector E106.




11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (P) and ground.

- 48 (L) – Ground : Continuity should not exist.**
- 49 (P) – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 12.
- NG >> Repair harness between IPDM E/R harness connector E106.



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.


- 94 – 86 : Approx. 108 – 132 Ω**

3. Check resistance between IPDM E/R terminals 48 and 49.

- 48 – 49 : Approx. 108 – 132 Ω**

OK or NG

- OK >> GO TO 13.
- NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all the connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-13, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduce.
 - A/T assembly
 - AWD control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - Intelligent Key unit
 - VDC/TCS/ABS control unit
 - Driver seat control unit
 - ECM
 - IPDM E/R

Check results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

AKS00CAK

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-10, "IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START" .](#)

