

**SECTION** **LT**  
**LIGHTING SYSTEM**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

**CONTENTS**

<b>PRECAUTIONS</b> .....	<b>5</b>	Headlamp Low Beam Does Not Illuminate (Both Sides) .....	26
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	5	Headlamp Low Beam Does Not Illuminate (One Side) .....	29
General Precautions for Service Operations .....	5	Headlamps Does Not Turn OFF .....	30
Wiring Diagrams and Trouble Diagnosis .....	6	General Information for Xenon Headlamp Trouble Diagnosis .....	32
<b>HEADLAMP (FOR USA)</b> .....	<b>7</b>	Caution: .....	32
Component Parts and Harness Connector Location .....	7	Xenon Headlamp Trouble Diagnosis .....	32
System Description .....	7	Aiming Adjustment .....	33
OUTLINE .....	7	PREPARATION BEFORE ADJUSTING .....	33
HEADLAMP OPERATION .....	8	LOW BEAM AND HIGH BEAM .....	33
COMBINATION SWITCH READING FUNCTION .....	9	ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE) .....	34
EXTERIOR LAMP BATTERY SAVER CONTROL .....	9	Bulb Replacement .....	34
AUTO LIGHT OPERATION (IF EQUIPPED) .....	9	HEADLAMP (UPPER) LOW BEAM .....	34
VEHICLE SECURITY SYSTEM .....	9	HEADLAMP (LOWER) HIGH BEAM/FOG LAMP .....	35
XENON HEADLAMP .....	9	FRONT TURN SIGNAL/PARKING LAMP .....	35
CAN Communication System Description .....	9	Removal and Installation .....	35
CAN Communication Unit .....	9	REMOVAL .....	35
Schematic .....	10	INSTALLATION .....	35
Wiring Diagram — H/LAMP — .....	11	Disassembly .....	36
Terminals and Reference Values for BCM .....	15	Assembly .....	37
Terminals and Reference Values for IPDM E/R .....	15	Servicing to Replace Headlamps When Damaged .....	37
How to Proceed With Trouble Diagnosis .....	16	REMOVAL AND INSTALLATION .....	37
Preliminary Check .....	16	<b>HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM</b> .....	<b>38</b>
CHECK POWER SUPPLY AND GROUND CIRCUIT .....	16	Component Parts and Harness Connector Location .....	38
CONSULT-II Functions (BCM) .....	18	System Description .....	38
CONSULT-II BASIC OPERATION .....	18	OUTLINE .....	38
WORK SUPPORT .....	19	HEADLAMP OPERATION .....	39
DATA MONITOR .....	19	DAYTIME LIGHT OPERATION .....	41
ACTIVE TEST .....	20	OPERATION .....	41
CONSULT-II Functions (IPDM E/R) .....	21	COMBINATION SWITCH READING FUNCTION .....	41
CONSULT-II OPERATION .....	21	EXTERIOR LAMP BATTERY SAVER CONTROL .....	41
DATA MONITOR .....	22	AUTO LIGHT OPERATION (IF EQUIPPED) .....	41
ACTIVE TEST .....	22	VEHICLE SECURITY SYSTEM .....	42
Headlamp High Beam Does Not Illuminate (Both Sides) .....	23	XENON HEADLAMP .....	42
Headlamp High Beam Does Not Illuminate (One Side) .....	25	CAN Communication System Description .....	42
High Beam Indicator Lamp Does Not Illuminate .....	26	CAN Communication Unit .....	42

Schematic .....	43	CAN Communication System Description .....	78
Wiring Diagram — DTRL — .....	44	CAN Communication Unit .....	78
Terminals and Reference Values for Daytime Light Control Unit .....	50	Major Components and Functions .....	78
Terminals and Reference Values for BCM .....	51	Schematic .....	79
Terminals and Reference Values for IPDM E/R .....	51	Wiring Diagram — AUTO/L — .....	80
How to Proceed With Trouble Diagnosis .....	52	Terminals and Reference Values for BCM .....	83
Preliminary Check .....	52	Terminals and Reference Values for IPDM E/R .....	84
CHECK POWER SUPPLY AND GROUND CIRCUIT .....	52	How to Proceed With Trouble Diagnosis .....	84
CONSULT-II Functions (BCM) .....	54	Preliminary Check .....	85
CONSULT-II BASIC OPERATION .....	54	SETTING CHANGE FUNCTIONS .....	85
WORK SUPPORT .....	55	CHECK POWER SUPPLY AND GROUND CIRCUIT .....	85
DATA MONITOR .....	55	CONSULT-II Functions (BCM) .....	86
ACTIVE TEST .....	56	CONSULT-II BASIC OPERATION .....	86
CONSULT-II Functions (IPDM E/R) .....	57	WORK SUPPORT .....	87
CONSULT-II OPERATION .....	57	DATA MONITOR .....	87
DATA MONITOR .....	58	ACTIVE TEST .....	88
ACTIVE TEST .....	58	CONSULT-II Functions (IPDM E/R) .....	89
Daytime Light Control Does Not Operate Properly .....	59	CONSULT-II OPERATION .....	89
Headlamp High Beam Does Not Illuminate (Both Sides) .....	61	DATA MONITOR .....	90
RH High Beam Does Not Illuminate But RH Low Beam Illuminates .....	63	ACTIVE TEST .....	90
LH High Beam Does Not Illuminate But LH Low Beam Illuminates .....	65	Symptom Chart .....	91
Headlamp Low Beam Does Not Illuminate (Both Sides) .....	67	Lighting Switch Inspection .....	91
RH Low Beam Does Not Illuminate But RH High Beam Illuminates .....	69	Optical sensor System Inspection .....	92
LH Low Beam Does Not Illuminate But LH High Beam Illuminates .....	70	Removal and Installation for Optical Sensor .....	94
General Information for Xenon Headlamp Trouble Diagnosis .....	71	REMOVAL .....	94
Caution: .....	71	INSTALLATION .....	94
Xenon Headlamp Trouble Diagnosis .....	71	<b>FRONT FOG LAMP .....</b>	<b>95</b>
Aiming Adjustment .....	72	Component Parts and Harness Connector Location .....	95
PREPARATION BEFORE ADJUSTING .....	72	System Description .....	95
LOW BEAM AND HIGH BEAM .....	72	OUTLINE .....	95
ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE) .....	73	FOG LAMP OPERATION (FOR USA) .....	96
Bulb Replacement .....	73	FOG LAMP OPERATION (FOR CANADA) .....	96
HEADLAMP (UPPER) LOW BEAM .....	73	COMBINATION SWITCH READING FUNCTION .....	97
HEADLAMP (LOWER) HIGH BEAM/FOG LAMP .....	74	EXTERIOR LAMP BATTERY SAVER CONTROL .....	97
FRONT TURN SIGNAL/PARKING LAMP .....	74	CAN Communication System Description .....	97
Removal and Installation .....	74	CAN Communication Unit .....	97
REMOVAL .....	74	Wiring Diagram — F/FOG — .....	98
INSTALLATION .....	74	FOR USA .....	98
Disassembly .....	75	FOR CANADA .....	100
Assembly .....	76	Terminals and Reference Values for BCM .....	102
Servicing to Replace Headlamps When Damaged .....	76	Terminals and Reference Values for IPDM E/R .....	102
REMOVAL AND INSTALLATION .....	76	How to Proceed With Trouble Diagnosis .....	103
<b>AUTO LIGHT SYSTEM .....</b>	<b>77</b>	Preliminary Check .....	103
Component Parts and Harness Connector Location .....	77	CHECK POWER SUPPLY AND GROUND CIRCUIT .....	103
System Description .....	77	CONSULT-II Functions (BCM) .....	104
OUTLINE .....	77	CONSULT-II Functions (IPDM E/R) .....	104
COMBINATION SWITCH READING FUNCTION .....	78	Front Fog lamps Does Not Illuminate (Both Sides) (FOR USA) .....	105
EXTERIOR LAMP BATTERY SAVER CONTROL .....	78	Front Fog Lamp Does Not Illuminate (One Side) (FOR USA) .....	107
DELAY TIMER FUNCTION .....	78	Front Fog lamps Does Not Illuminate (Both Sides) (FOR CANADA) .....	108
		LH Front Fog Lamp Does Not Illuminate (FOR CANADA) .....	109
		RH Front Fog Lamp Does Not Illuminate (FOR CANADA) .....	112
		Bulb Replacement .....	112

<b>TURN SIGNAL AND HAZARD WARNING LAMPS. 113</b>	INSTALLATION .....	138	
Component Parts and Harness Connector Location	REMOVAL (WITHOUT REAR SPOILER) .....	138	A
System Description .....	INSTALLATION .....	138	
TURN SIGNAL OPERATION .....	Removal and Installation of Rear Combination		
HAZARD LAMP OPERATION .....	Lamp (Stop Lamp) .....	138	B
REMOTE KEYLESS ENTRY SYSTEM OPERA-	<b>STEP LAMP .....</b>	<b>139</b>	
TION .....	Bulb Replacement .....	139	
COMBINATION SWITCH READING FUNCTION	Removal and Installation .....	139	C
CAN Communication System Description .....	REMOVAL .....	139	
CAN Communication Unit .....	INSTALLATION .....	139	
Schematic .....	<b>BACK-UP LAMP .....</b>	<b>140</b>	D
Wiring Diagram — TURN — .....	Wiring Diagram — BACK/L — .....	140	
Terminals and Reference Values for BCM .....	A/T MODELS .....	140	
How to Proceed With Trouble Diagnosis .....	M/T MODELS .....	141	
Preliminary Check .....	<b>PARKING, LICENSE PLATE AND TAIL LAMPS ..</b>	<b>142</b>	E
CHECK POWER SUPPLY AND GROUND CIR-	Component Parts and Harness Connector Location	142	
CUIT .....	System Description .....	142	
CONSULT-II Functions (BCM) .....	OPERATION BY LIGHTING SWITCH .....	143	F
CONSULT-II BASIC OPERATION .....	COMBINATION SWITCH READING FUNCTION	143	
DATA MONITOR .....	EXTERIOR LAMP BATTERY SAVER CONTROL	143	
ACTIVE TEST .....	CAN Communication System Description .....	144	G
Turn Signal Lamp Does Not Operate .....	CAN Communication Unit .....	144	
Hazard Warning Lamp Does Not Operate But Turn	Schematic .....	145	
Signal Lamp Operate .....	Wiring Diagram — TAIL/L — .....	146	H
Turn Signal Indicator Lamp Does Not Operate ...	Terminals and Reference Values for BCM .....	149	
Bulb Replacement (Front Turn Signal Lamp) .....	Terminals and Reference Values for IPDM E/R ...	149	
Bulb Replacement (Rear Turn Signal Lamp) .....	How to Proceed With Trouble Diagnosis .....	150	I
Removal and Installation of Front Turn Signal Lamp	Preliminary Check .....	150	
Removal and Installation of Rear Turn Signal Lamp	CHECK POWER SUPPLY AND GROUND CIR-		
<b>LIGHTING AND TURN SIGNAL SWITCH .....</b>	CUIT .....	150	J
Removal and Installation .....	CONSULT-II Functions (BCM) .....	151	
REMOVAL .....	CONSULT-II Functions (IPDM E/R) .....	151	
INSTALLATION .....	Parking, License Plate and Tail Lamps Do Not Illu-		
<b>HAZARD SWITCH .....</b>	minate .....	151	
Removal and Installation (M/T) .....	Parking, License Plate, Side marker and Tail Lamps		
REMOVAL .....	Do Not Turn OFF (After Approx. 10 Minutes) .....	157	LT
INSTALLATION .....	Bulb Replacement .....	157	
Removal and Installation (A/T) .....	FRONT SIDE MARKER LAMP .....	157	L
REMOVAL .....	LICENSE PLATE LAMP .....	157	
INSTALLATION .....	FRONT TURN SIGNAL (PARKING) LAMP .....	157	M
<b>COMBINATION SWITCH .....</b>	TAIL LAMP .....	157	
Wiring Diagram — COMBSW — .....	Removal and Installation .....	157	
Combination Switch Reading Function .....	FRONT SIDE MARKER LAMP .....	157	
CONSULT-II Function (BCM) .....	LICENSE PLATE LAMP .....	158	
CONSULT-II BASIC OPERATION .....	FRONT TURN SIGNAL (PARKING) LAMP .....	158	
DATA MONITOR .....	TAIL LAMP .....	158	
Combination Switch Inspection .....	<b>REAR COMBINATION LAMP .....</b>	<b>159</b>	
Removal and Installation .....	Bulb Replacement .....	159	
<b>STOP LAMP .....</b>	REAR FENDER SIDE (REAR TURN SIGNAL		
Wiring Diagram — STOP/L — .....	LAMP BULB) .....	159	
Bulb Replacement of High-Mounted Stop Lamp .	TRUNK LID SIDE (BACK-UP LAMP) .....	159	
WITH REAR SPOILER .....	Removal and Installation .....	159	
WITHOUT REAR SPOILER .....	REMOVAL .....	159	
Bulb Replacement of Rear Combination Lamp (Stop	INSTALLATION .....	160	
Lamp) .....	<b>VANITY MIRROR LAMP .....</b>	<b>161</b>	
Removal and Installation of High-Mounted Stop	Bulb Replacement .....	161	
Lamp .....	<b>MAP LAMP .....</b>	<b>162</b>	
REMOVAL (WITH REAR SPOILER) .....			

Bulb Replacement .....	162	Schematic .....	174
Removal and Installation .....	162	Wiring Diagram — ROOM/L — .....	176
REMOVAL .....	162	Terminals and Reference Values for BCM .....	183
INSTALLATION .....	162	How to Proceed With Trouble Diagnosis .....	184
<b>TRUNK ROOM LAMP .....</b>	<b>163</b>	Preliminary Check .....	184
Bulb Replacement, Removal and Installation .....	163	CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	184
REMOVAL .....	163	CONSULT-II Functions (BCM) .....	185
INSTALLATION .....	163	CONSULT-II BASIC OPERATION .....	185
<b>PERSONAL LAMP .....</b>	<b>164</b>	WORK SUPPORT .....	186
Bulb Replacement .....	164	DATA MONITOR .....	186
Removal and Installation .....	164	ACTIVE TEST .....	187
REMOVAL .....	164	Map Lamp Control Does Not Operate .....	188
INSTALLATION .....	164	Ignition key Hole illumination Control Does Not Operate .....	189
<b>IGNITION KEY HOLE ILLUMINATION .....</b>	<b>165</b>	All Step Lamps Does Not Operate .....	191
Removal and Installation .....	165	All Interior Room Lamps Does Not Operate .....	192
REMOVAL (WITHOUT INTELLIGENT KEY SYS- TEM) .....	165	Bulb Replacement .....	192
REMOVAL (WITH INTELLIGENT KEY SYSTEM) .....	165	MAP LAMP .....	192
INSTALLATION .....	165	STEP LMP .....	192
<b>GLOVE BOX LAMP .....</b>	<b>166</b>	Removal and Installation .....	192
Bulb Replacement, Removal and Installation .....	166	MAP LAMP .....	192
REMOVAL .....	166	STEP LAMP .....	192
INSTALLATION .....	166	<b>ILLUMINATION .....</b>	<b>193</b>
<b>ASHTRAY ILLUMINATION .....</b>	<b>167</b>	System Description .....	193
Bulb Replacement, Removal and Installation .....	167	ILLUMINATION OPERATION BY LIGHTING SWITCH .....	193
REMOVAL .....	167	EXTERIOR LAMP BATTERY SAVER CONTROL .....	194
INSTALLATION .....	167	CAN Communication System Description .....	195
<b>CIGARETTE LIGHTER ILLUMINATION .....</b>	<b>168</b>	CAN Communication Unit .....	195
Bulb Replacement, Removal and Installation .....	168	Schematic .....	196
REMOVAL .....	168	Wiring Diagram — ILL — .....	197
INSTALLATION .....	168	Removal and Installation .....	206
<b>INTERIOR ROOM LAMP .....</b>	<b>169</b>	GLOVE BOX LAMP .....	206
Component Parts and Harness Connector Location .....	169	<b>BULB SPECIFICATIONS .....</b>	<b>207</b>
System Description .....	170	Headlamp .....	207
POWER SUPPLY AND GROUND .....	170	Exterior Lamp .....	207
SWITCH OPERATION .....	171	Interior Lamp/Illumination .....	207
ROOM LAMP TIMER OPERATION .....	172		
INTERIOR LAMP BATTERY SAVER CONTROL .....	173		

# PRECAUTIONS

## PRECAUTIONS

PPF:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS00AW4

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.



#### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### General Precautions for Service Operations

AKS00AW6

- Never work with wet hands.
- Xenon headlamp includes high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, never touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector, and housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. (If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.)
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.



# PRECAUTIONS

---

## Wiring Diagrams and Trouble Diagnosis

AKS00AW7

When you read wiring diagrams, refer to the following:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) in GI section.
- Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution in PG section.

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section.
- Refer to [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section.


# HEADLAMP (FOR USA)

## HEADLAMP (FOR USA)

PPF:26010

### Component Parts and Harness Connector Location

AKS009IE



## System Description

AKS009IF

Control of headlamp system operation is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the 2ND position, BCM (body control module) receives input signal requesting the headlamps (and tail lamps) illuminate. This input signal is communicated to IPDM E/R (intelligent power distribution module engine room) across CAN communication lines. The CPU (central processing unit) of IPDM E/R controls headlamp high and headlamp low relay coils. These relays, when energized, direct power to the respective headlamps, which then illuminate.

## OUTLINE

Power is supplied at all times

- to headlamp high relay, located in IPDM E/R and
- to headlamp low relay, located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 19, located in fuse block (J/B)]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

---

- to combination meter terminal 21.

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 22 and 23.

With ignition switch in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

## HEADLAMP OPERATION

### Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input signal requesting headlamps to illuminate. This input signal is communicated to IPDM E/R across CAN communication lines. The CPU located in the IPDM E/R controls headlamp low relay coil, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 3,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 3.

Ground is supplied

- to front combination lamp RH terminal 4
- through grounds E17 and E43,
- to front combination lamp LH terminal 4
- through grounds E17 and E43.

With power and ground supplied, low beam headlamps illuminate.

### High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input signal requesting the headlamp high beams to illuminate. This input signal is communicated to IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls headlamp high relay coil and low relay coil, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 3,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 3,
- through 10A fuse (No. 72, located in IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 2,
- through 10A fuse (No. 74, located in IPDM E/R)
- through IPDM E/R terminal 28



# HEADLAMP (FOR USA)

- to front combination lamp LH terminal 2.

Ground is supplied

- to front combination lamp RH terminals 4 and 8
- through grounds E17 and E43,
- to front combination lamp LH terminals 4 and 8
- through grounds E17 and E43.

With power and ground supplied, the high beam and low beam headlamps illuminate.

High beam indicator illuminates when combination meter receives input signal requesting high beam indicator to illuminate. This is communicated to BCM across the CAN communication lines.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, then the headlamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## AUTO LIGHT OPERATION (IF EQUIPPED)

Refer to [LT-77, "System Description"](#) in "AUTO LIGHT SYSTEM".

## VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-199, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .

## XENON HEADLAMP

Xenon type lamps are used for to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to strong lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Followings are some advantages of the xenon type headlamp.

- The light produced by the headlamps is white color similar to sunlight that is easy to the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- Counter-reflected luminance increases and the contrast enhances on the wet road in the rain. That makes visibility go up more than the increase of the light volume.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.

## CAN Communication System Description

AKS009IG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS009IH

Refer to [LAN-21, "CAN Communication Unit"](#) .

# HEADLAMP (FOR USA)

## Schematic

AKS009II



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).




TKWM2241E

# HEADLAMP (FOR USA)

AKS009J

## Wiring Diagram — H/LAMP —

LT-H/LAMP-01





REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2242E

# HEADLAMP (FOR USA)



## LT-H/LAMP-02



TKWM2243E

# HEADLAMP (FOR USA)

LT-H/LAMP-03





TKWM2244E

# HEADLAMP (FOR USA)

LT-H/LAMP-04

▬ : DATA LINE



REFER TO THE FOLLOWING.





(M4) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2245E

# HEADLAMP (FOR USA)

## Terminals and Reference Values for BCM

AKS009IK

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	W/L	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3468E</p>
3	G	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3469E</p>
4	G/R	Combination switch input 3			
5	W/G	Combination switch input 2			
6	W/R	Combination switch input 1			
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3470E</p>
33	L	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3471E</p>
34	PU	Combination switch output 3			
35	Y/R	Combination switch output 2			
36	Y	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	P	CAN - L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0V
55	W/R	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS009IL

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
20	R	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
27	BR	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage
28	R/Y	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage

# HEADLAMP (FOR USA)

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
30	R/B	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0V	
48	L	CAN – H	—	—	—	
49	P	CAN – L	—	—	—	
60	B/W	Ground	ON	—	Approx. 0V	

## How to Proceed With Trouble Diagnosis

AKS009IM

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-7, "System Description"](#).
3. Perform the preliminary check. Refer to [LT-16, "Preliminary Check"](#).
4. Check symptom and repair or replace the malfunctioning parts.
5. Does headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS009IN

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	72
		74
		76
		86

Refer to [LT-11, "Wiring Diagram — H/LAMP —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).



# HEADLAMP (FOR USA)

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M1	11 (LG)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M2	42 (GY)		Battery voltage	Battery voltage	Battery voltage
	55 (W/R)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminal		Continuity	
Connector	Terminal (Wire color)	Ground	Yes
M2	52 (B)		

OK or NG

OK >> INSPECTION END

NG >> Check ground circuit harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## CONSULT-II Functions (BCM)

AKS009/O

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# HEADLAMP (FOR USA)

4. Touch "HEAD LAMP" on "SELECT DIAG MODE" screen.



A  
B  
C  
D

## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

E  
F  
G

### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF.	ON	×
		OFF	—

H  
I

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

LT

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

L  
M

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.

# HEADLAMP (FOR USA)

Monitor item		Contents
AUTO LIGHT SW	"ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW	"ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW - DR	"ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF"	Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF"	Displays status of the rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW <sup>NOTE 1</sup>	"OFF"	—
TURN SIGNAL R	"ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE 1</sup>	"OFF"	—
OPTICAL SENSOR <sup>NOTE 2</sup>	"0 - 5V"	Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

1. This item is displayed, but cannot be monitored.
2. Vehicles without auto light system display this item, but cannot be monitored.

## ACTIVE TEST

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE</sup>	—

**NOTE:**

This item is displayed, but cannot be tested.

# HEADLAMP (FOR USA)

## CONSULT-II Functions (IPDM E/R)

AKS009IP

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19. "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not indicated, refer to [GI-38. "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



# HEADLAMP (FOR USA)

- Select desired part to be diagnosed on "SELECT DIAG MODE" screen.



## DATA MONITOR

### Operation Procedure

- Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

- Touch required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
- Touch "START".
- Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with ignition switch ON. When ignition switch is at ACC, display may not be correct.

## ACTIVE TEST

### Operation Procedure

- Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Touch item to be tested, and check operation.
- Touch "START".
- Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option.
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

# HEADLAMP (FOR USA)

## Headlamp High Beam Does Not Illuminate (Both Sides)

AKS0091Q

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is : HI BEAM SW ON  
HIGH position**

⊗ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HI BEAM SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7585E

### 2. HEADLAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-I, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operates.

**Headlamp high beam should operate.  
(Headlamp high beam repeats ON-OFF every 1 second).**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS		OFF	
		HI	
LO		FOG	
MODE	BACK	LIGHT	COPY

SKIA5774E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HI position.

**When lighting switch is : HL LO REQ ON  
HIGH position : HL HI REQ ON**

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
HL LO REQ	ON		
HL HI REQ	ON		
		RECORD	
MODE	BACK	LIGHT	COPY


PKIA7638E

# HEADLAMP (FOR USA)

## 4. CHECK HEADLAMP INPUT SIGNAL

④ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "HI" screen.
6. When headlamp high beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.



Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	2 (BR)	Ground	Battery voltage
LH	E41	2 (R/Y)		

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When headlamp high beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	2 (BR)	Ground	Battery voltage
LH	E41	2 (R/Y)		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and front combination lamp RH harness connector E24 terminal 2 (BR).

**27 (BR) – 2 (BR) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 (R/Y) and front combination lamp LH harness connector E41 terminal 2 (R/Y).

**28 (R/Y) – 2 (R/Y) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness or connector.



# HEADLAMP (FOR USA)

## 6. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.


**8 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp bulb.
- NG >> Repair harness or connector.



## Headlamp High Beam Does Not Illuminate (One Side)

AKS009/R

### 1. CHECK BULB

Check bulbs of lamps which does not illuminate.

OK or NG

- OK >> GO TO 2.
- NG >> Replace headlamp bulb.


### 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connector.
3. Turn ignition switch ON.
4. Lighting switch is turned HIGH position.
5. Check voltage between front combination lamp RH or LH harness connector and ground.

Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	2 (BR)	Ground	Battery voltage
LH	E41	2 (R/Y)		

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)


## 3. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and front combination lamp RH harness connector E24 terminal 2 (BR).

**27 (BR) – 2 (BR) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 (R/Y) and front combination lamp LH harness connector E41 terminal 2 (R/Y).

**28 (R/Y) – 2 (R/Y) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.


## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**



OK or NG

- OK >> Check headlamp harness and connector.
- NG >> Repair harness or connector.

## High Beam Indicator Lamp Does Not Illuminate

AKS009IS

### 1. CHECK BULB

Check bulb of high beam indicator lamp which does not illuminate.

OK or NG

- OK >> Replace combination meter.
- NG >> Replace indicator bulb.

## Headlamp Low Beam Does Not Illuminate (Both Sides)

AKS009IT

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓜ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 2ND position : HEAD LAMP SW 1 ON  
: HEAD LAMP SW 2 ON**

ⓧ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	ON		
HEAD LAMP SW2	ON		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7586E

# HEADLAMP (FOR USA)

## 2. HEADLAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST" ITEM screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

⊗ With out CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#) .
2. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

OK or NG

- OK >> GO TO 3.  
NG >> GO TO 4.



## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is 2ND position : HL LO REQ ON**

OK or NG

- OK >> Replace IPDM E/R.  
NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## 4. CHECK HEADLAMP INPUT SIGNAL

☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.



Terminal (+)			(-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	3 (R)	Ground	Battery voltage
LH	E41	3 (R/B)		

☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When headlamp low beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal (+)			(-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	3 (R)	Ground	Battery voltage
LH	E41	3 (R/B)		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 (R) and front combination lamp RH harness connector E24 terminal 3 (R).

**20 (R) – 3 (R) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 (R/B) and front combination lamp LH harness connector E41 terminal 3 (R/B).

**30 (R/B) – 3 (R/B) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness or connector.

# HEADLAMP (FOR USA)

## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front combination lamp RH harness connector E24 terminal 4 (B/W) and ground.


**4 (B/W) – Ground : Continuity should exist.**

3. Check continuity between front combination lamp LH harness connector E41 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**

### OK or NG

- OK >> Check headlamp harness and connectors, ballasts (HID control unit), and xenon bulbs. Refer to [LT-32, "Xenon Headlamp Trouble Diagnosis"](#) .
- NG >> Repair harness or connector.



## Headlamp Low Beam Does Not Illuminate (One Side)

AKS009IU

### 1. CHECK BULB

Check ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-32, "Xenon Headlamp Trouble Diagnosis"](#) .

### OK or NG

- OK >> GO TO 2.
- NG >> Replace malfunctioning part.


### 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connector.
3. Turn ignition switch ON.
4. Lighting switch is turned 2ND position.
5. Check voltage between front combination lamp RH or LH harness connector and ground.

Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	3 (R)	Ground	Battery voltage
LH	E41	3 (R/B)		

### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# HEADLAMP (FOR USA)


## 3. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 (R) and front combination lamp RH harness connector E24 terminal 3 (R).

**20 (R) – 3 (R) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 (R/B) and front combination lamp LH harness connector E41 terminal 3 (R/B).

**30 (R/B) – 3 (R/B) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.


## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**



OK or NG

- OK >> Check headlamp harness and connectors.
- NG >> Repair harness or connector.

## Headlamps Does Not Turn OFF

### 1. CHECK HEADLAMP TURN OFF

Make sure that lighting switch is OFF. And make sure is headlamp turns off when ignition switch is turned OFF.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is OFF : HEAD LAMP SW 1 OFF position : HEAD LAMP SW 2 OFF**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	ON		
HEAD LAMP SW2	ON		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7586E

# HEADLAMP (FOR USA)

## 3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" on CONSULT-II, and perform self-diagnosis for "BCM".

### Display of self-diagnosis results

NO DTC>> Replace IPDM E/R.

CAN COMM CIRCUIT>> Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT (U1000)			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## General Information for Xenon Headlamp Trouble Diagnosis

AKS00CMT

In most cases, malfunction of xenon headlamp - "does not illuminate", "flickers" or "dark" - is caused by a malfunctioning xenon bulb. A malfunctioning HID control unit or lamp housing, however, may be a cause. Be sure to perform trouble diagnosis following the steps described below.

### Caution:

AKS00CMU

- Installation or removal of connector must be done with lighting switch OFF.
- Disconnect the battery cable from the negative terminal or remove power fuse.
- When the lamp is illuminated (when lighting switch is ON), never touch harness, HID control unit, inside of lamp, or lamp metal parts.
- To check illumination, temporarily install lamp in vehicle. Be sure to connect power at vehicle side connector.
- If error can be traced directly to electrical system, first check for items such as blown fuses and fusible links, broken wires or loose connectors, dislocated terminals, and improper connections.
- Never work with wet hands.
- Using a tester for HID control unit circuit trouble diagnosis is prohibited.
- Disassembling HID control unit or harnesses (bulb socket harness, ECM harness) is prohibited.
- Immediately after illumination, light intensity and color will fluctuate, but there is nothing wrong.
- When bulb has come to end of its life, brightness will drop significantly, it will flash repeatedly, or light color will turn reddish.

## Xenon Headlamp Trouble Diagnosis

AKS00CMV

### 1. CHECK 1: XENON HEADLAMP LIGHTING

Install normal xenon bulb to corresponding xenon bulb headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace xenon bulb.
- NG >> GO TO 2.

### 2. CHECK 2: XENON HEADLAMP LIGHTING

Install normal HID control unit to corresponding xenon headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace HID control unit.
- NG >> GO TO 3.

### 3. CHECK 3: XENON HEADLAMP LIGHTING

Install normal xenon lamp housing assembly to corresponding xenon headlamp, and check if lamp lights up.

#### OK or NG


- OK >> Replace xenon headlamp housing assembly. [Malfunction in starter (boosting circuit) in xenon headlamp housing]
- NG >> INSPECTION END



# HEADLAMP (FOR USA)

## Aiming Adjustment

AKS00517



### PREPARATION BEFORE ADJUSTING

**For Details, Refer to the Regulations in Your Own Country.**

Before performing aiming adjustment, check the following.

1. Keep all tires inflated to correct pressures.
2. Place vehicle on flat surface.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.


### LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam ON.
2. Use adjusting screws to perform aiming adjustment.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

## ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)




If vehicle front body has been repaired and/or headlamp assembly has been replaced, check aiming. Use aiming chart shown in the figure.

- Basic illumination area for adjustment should be within the range shown on the aiming chart. Adjust headlamp accordingly.

## Bulb Replacement HEADLAMP (UPPER) LOW BEAM

1. Turn lighting switch OFF.
2. Disconnect the battery cable from the negative terminal or remove power fuse.
3. Remove headlamp. Refer to [LT-35, "Removal and Installation"](#).
4. Turn plastic cap counterclockwise and unlock it.
5. Turn bulb socket counterclockwise and unlock it.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.



# HEADLAMP (FOR USA)

## HEADLAMP (LOWER) HIGH BEAM/FOG LAMP

1. Turn lighting switch OFF.
2. Disconnect the battery cable from the negative terminal or remove power fuse.
3. Remove fender protector (front). Refer to [EI-22, "FENDER PROTECTOR"](#) in "EI" section.
4. Turn plastic cap counterclockwise and unlock it.
5. Disconnect bulb socket.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.

## FRONT TURN SIGNAL/PARKING LAMP

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-22, "FENDER PROTECTOR"](#) in "EI" section.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.
5. Installation is the reverse order of removal.

**Headlamp (upper) low beam** : 12V - 35W (D2R)

**Headlamp (lower) high beam/Fog lamp** : 12V - 60/55W (HB2)

**Front turn signal/Parking lamp** : 12V - 21/5W

### CAUTION:

After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.

## Removal and Installation

### REMOVAL

1. Disconnect the battery cable from the negative terminal or remove power fuse.
2. Remove front grille. Refer to [EI-20, "FRONT GRILLE"](#) in "EI" section.
3. Remove front undercover and fender protector. Refer to [EI-22, "FENDER PROTECTOR"](#) in "EI" section.
4. Remove mounting clip on top of front bumper and screws on side of front bumper. Refer to [EI-14, "FRONT BUMPER"](#) in "EI" section.
5. Pull side of front bumper toward the vehicle front and disengage it from clips on the body.
6. Remove headlamp mounting bolts.
7. Pull headlamp toward the vehicle front, disconnect connector, and remove headlamp.



### CAUTION:

When removing headlamps, put a shop cloth or something similar between headlamps and bumper to protect bumper.

## INSTALLATION

Installation is the reverse order of removal.


**Headlamp mounting bolt**  : 5.0 N·m (0.51 kg·m, 44 in·lb)



# HEADLAMP (FOR USA)

## Disassembly

AKS0051A



- |   |                            |   |
|---|----------------------------|---|
| 1. Retaining spring                     | 2. Xenon bulb (low)        | 3. Seal rubber                                |
| 4. Plastic cap (low)                    | 5. Xenon bulb socket (low) | 6. Halogen bulb (high/fog)                    |
| 7. Halogen bulb (high/fog) socket       | 8. Plastic cap (high/fog)  | 9. Front turn signal/Parking lamp bulb socket |
| 10. Front turn signal/Parking lamp bulb | 11. HID control unit       | 12. Headlamp housing assembly                 |


1. Turn plastic cap (low) counterclockwise and unlock it.
2. Turn xenon bulb (low) socket counterclockwise, and unlock it.
3. Unlock retaining spring, and remove xenon bulb (low).
4. Disconnect HID control unit connector, and remove HID control unit screws. (Xenon)
5. Turn plastic cap (high/fog) counterclockwise, and unlock it.
6. Disconnect the terminal connected to the halogen bulb (high/fog).
7. Unlock retaining spring, and remove halogen bulb (high/fog).
8. Turn front turn signal lamp/parking bulb socket counterclockwise and unlock it.
9. Remove front turn signal/parking lamp bulb from its socket.

# HEADLAMP (FOR USA)

## Assembly

AKS0051B

Assembly is the reverse order of disassembly.

HID control unit  : 3.2 N·m ( 0.33 kg·m, 28 in·lb)


### CAUTION:

- When HID control unit is removed, reinstall it securely and avoid any looseness.
- After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.

## Servicing to Replace Headlamps When Damaged


AKS0051C

If only installation part as shown in the figure is damaged, and headlamp housing itself is not damaged, repair can be completed easily by installing correction brackets.



## REMOVAL AND INSTALLATION

1. Remove headlamps. Refer to [LT-35, "Removal and Installation"](#).
2. Cut damaged section of installation part, then shape with sandpaper.
3. Attach each correction bracket to headlamp housing boss with 2 screws.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

PFP:26010

### Component Parts and Harness Connector Location

AKS004Q2



PKIB6099E

## System Description

AKS0091Y

The headlamp system for Canada vehicles is equipped with a daytime light control unit that activates high beam headlamps at approximately half illumination whenever engine is running. If parking brake is applied before engine is started daytime lights will not be illuminated. The daytime lights will illuminate once parking brake is released. Thereafter, daytime lights will continue to operate when parking brake is applied. And battery saver system is controlled by BCM (body control module).

## OUTLINE

Power is supplied at all times

- to headlamp high relay, located in IPDM E/R (intelligent power distribution module engine room) and
- to headlamp low relay, located in IPDM E/R, from battery direct,

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay, located in IPDM E/R,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21,
- through 10A fuse [No. 21, located in fuse block (J/B)]
- to daytime light control unit terminals 2 and 3,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42.

With ignition switch in ON or START position, power is supplied

- to CPU located in IPDM E/R, from battery direct,
- through 10A fuse (No. 82, located in IPDM E/R)
- to daytime light control unit terminal 12,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminals 22 and 23.

With ignition switch in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11,

With ignition switch in START position, power is supplied

- through 10A fuse [No. 9, located in fuse block (J/B)]
- to daytime light control unit terminal 1.

Ground is supplied

- to daytime light control unit terminal 9
- through grounds E17 and E43,
- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

## HEADLAMP OPERATION

### Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input signal requesting the headlamps to illuminate. This input signal is communicated to IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls the headlamp low relay coil, which when energized, directs power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 3,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 3.

Ground is supplied at all times

A

B

C

D

E

F

G

H

I

J

LT

L

M

## HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

---

- to front combination lamp RH terminal 4
- through grounds E17 and E43,
- to front combination lamp LH terminal 4
- through grounds E17 and E43.

With power and ground supplied, low beam headlamps illuminate.

### **High Beam Operation (When Daytime Light Does Not Operate)/Flash-to-Pass Operation**

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input signal requesting headlamp high beams to illuminate. High beam request signal is communicated to the IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls headlamp high relay coil and daytime light relay-2 turned ON, which when energized, directs power

- through 10A fuse (No. 74, located in IPDM E/R)
- through IPDM E/R terminal 28
- to daytime light control unit terminal 5
- through daytime light control unit terminal 6
- to front combination lamp LH terminal 2,
- through 10A fuse (No. 72, located in IPDM E/R)
- through IPDM E/R terminal 27
- to daytime light relay-2 terminal 2 and 5, and
- to daytime light control unit terminal 1,
- through daytime light relay-2 terminal 3
- to front combination lamp RH terminal 2,
- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 3, and
- to daytime light control unit terminal 1,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 3, and
- to daytime light control unit terminal 4.

Ground is supplied

- to daytime light relay-2 terminal 1
- through grounds E17 and E43,
- to front combination lamp RH terminal 8
- through grounds E17 and E43,
- to front combination lamp RH terminal 4
- through grounds E17 and E43,
- to front combination lamp LH terminal 4
- through grounds E17 and E43,
- to front combination lamp LH terminal 8
- through daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through grounds E17 and E43.

With the power and ground supplied, the headlamp high beam and low headlamp illuminate.

High beam indicator illuminates when combination meter receives input signal requesting high beam indicator to illuminate. This is communicated to BCM across the CAN communication lines.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## DAYTIME LIGHT OPERATION

With engine running, lighting switch in OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal 6
- to front combination lamp LH terminal 2
- through front combination lamp LH terminal 8
- to daytime light control unit terminal 7
- through daytime light control unit terminal 8
- to front combination lamp RH terminal 2.

Ground is supplied

- to front combination lamp RH terminal 8
- through grounds E17 and E43.

Because high beam headlamps are now wired in series, they operate at half illumination.

If lighting switch is in HIGH position, daytime light operation is canceled. On this occasion, power is supplied

- through IPDM E/R terminal 27
- to daytime light control unit terminal 1.

Daytime light control unit is canceled power supplying from front combination lamp RH terminal 8 to terminal 2 (series power supplying is canceled). And then high beam is ON.

## OPERATION

After starting engine with lighting switch in the OFF or 1ST position, headlamp high beam automatically turns on. Lighting switch operations other than above are same as conventional light systems.

Engine		With engine stopped												With engine running											
		OFF				1ST				2ND				OFF				1ST				2ND			
		Hi	Lo	P	F	Hi	Lo	P	F	Hi	Lo	P	F	Hi	Lo	P	F	Hi	Lo	P	F	Hi	Lo	P	F
Head-lamp	High beam	-	-	x	-	-	-	x	-	x	-	x	-	●*	●*	x	-	●*	●*	x	-	x	-	x	-
	Low beam	-	-	x	-	-	-	x	-	x	x	x	x	-	-	x	-	-	-	x	-	x	x	x	x
Tail lamp		-	-	-	-	x	x	x	x	x	x	x	x	-	-	-	-	x	x	x	x	x	x	x	x
License plate and instrument illumination lamp		-	-	-	-	x	x	x	x	x	x	x	x	-	-	-	-	x	x	x	x	x	x	x	x

- Hi: "HIGH BEAM" position
- Lo: "LOW BEAM" position
- P: "FLASH TO PASS" position
- F: "FOG LAMP" SW is ON
- x: Lamp "ON"
- -: Lamp "OFF"
- ●: Lamp dims. (Added functions)
- \*: When starting the engine with the parking brake released, the daytime light will come ON.  
When starting the engine with the parking brake pulled, the daytime light will not come ON.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3. "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, then the headlamps are turned off. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## AUTO LIGHT OPERATION (IF EQUIPPED)

For auto light operation, refer to [LT-77. "System Description"](#) in "AUTO LIGHT SYSTEM".

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

---

## VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-199, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .

## XENON HEADLAMP

Xenon type lamps are used for to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to strong lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Followings are some advantages of the xenon type headlamp.

- The light produced by the headlamps is white color similar to sunlight that is easy to the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- Counter-reflected luminance increases and the contrast enhances on the wet road in the rain. That makes visibility go up more than the increase of the light volume.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.

## CAN Communication System Description

AKS004Q4

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS0093K

Refer to [LAN-21, "CAN Communication Unit"](#) .

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Schematic

AKS004Q6



TKWM2246E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M




LT

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

AKS0091T

## Wiring Diagram — DTRL —

LT-DTRL-01



REFER TO THE FOLLOWING.


- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2247E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-02


▬ : DATA LINE



REFER TO PG-POWER.

TO LT-DTRL-04  
TO LT-DTRL-05  
NEXT PAGE

PRECEDING PAGE



REFER TO THE FOLLOWING.



(B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2248E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -




LT-DTRL-03



TKWM2249E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-04







REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M5) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2250E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-05



REFER TO THE FOLLOWING.  
 (E108), (F102), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (E102) -FUSE BLOCK-JUNCTION  
 BOX (J/B)



TKWM2251E



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-06

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M4) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2252E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Terminals and Reference Values for Daytime Light Control Unit





AKS00AAV

Terminal No.	Wire color	Item	Condition	Reference value
1	L/W	Start signal	When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "ON" from "START"	Approx.0V
			When turning ignition switch to "OFF"	Approx.0V
2	OR	RH light fuse	—	Battery voltage
3	OR	LH light fuse	—	Battery voltage
4	R/B	Lighting switch (Low beam)	When turning lighting switch is turned 2ND position "LOW BEAM" position.	Battery voltage
5	R/Y	Lighting switch (Hi beam)	When turning lighting switch is turned 2ND position "HI BEAM" position	Battery voltage
6	L	LH Hi beam	When lighting switch is turned to 2ND position with "HI BEAM" or "FLASH TO PASS" position	Battery voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Battery voltage
7	Y/G	LH Hi beam (Ground)	When turning lighting switch to 2ND position with "HI BEAM" or "FLASH TO PASS" position	Approx.0V
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Approx.6V
8	LG	RH Hi beam	When lighting switch is turned to 2ND position with "HI BEAM" or "FLASH TO PASS" position	Battery voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Approx.6V
9	B	Ground	—	—
10	PU/R	Parking brake switch	When parking brake is released	Battery voltage
			When parking brake is applied	Approx.0V
11	W/R	Alternator	When turning ignition switch to "ON"	Approx.0V
			When engine is running	Battery voltage
			When turning ignition switch to "OFF"	Approx.0V
12	G/R	Ignition switch (ON)	When turning ignition switch to "ON"	Battery voltage

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Terminals and Reference Values for BCM

AKS009IZ

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	W/L	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3468E</p>
3	G	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3469E</p>
4	G/R	Combination switch input 3			
5	W/G	Combination switch input 2			
6	W/R	Combination switch input 1			
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3470E</p>
33	L	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3471E</p>
34	PU	Combination switch output 3			
35	Y/R	Combination switch output 2			
36	Y	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	P	CAN - L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0V
55	W/R	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS00AAW

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
20	R	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
27	BR	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0V
					ON	Battery voltage
28	R/Y	Headlamp high (LH)			OFF	Approx. 0V
					ON	Battery voltage

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
30	R/B	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0V
					ON	Battery voltage
36	W/G	Front fog lamp (RH)	ON	Lighting switch must be in 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON	OFF	Approx. 0V
					ON	Battery voltage
37	SB	Front fog lamp (LH)	ON	Lighting switch must be in 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON	OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0V	
43	G/R	Ignition switch (ON)	ON	—	Battery voltage	
48	L	CAN – H	—	—	—	
49	P	CAN – L	—	—	—	
60	B/W	Ground	ON	—	Approx. 0V	

## How to Proceed With Trouble Diagnosis

AKS009J0

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-38, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-52, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS009J1

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

- Check fuses for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	72
		74
		76
		86
	Ignition switch ON or START position	82
DAYTIME LIGHT CONTROL UNIT	Battery	21
	Ignition switch START position	9

Refer to [LT-44, "Wiring Diagram — DTRL —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal (+)		Terminal (-)	Ignition switch position		
Connector	Terminal (Wire color)		OFF	ACC	ON
M1	11 (LG)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M2	42 (GY)		Battery voltage	Battery voltage	Battery voltage
	55 (W/R)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		Yes
M2	52 (B)		Yes

OK or NG

OK >> INSPECTION END

NG >> Check ground circuit harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## CONSULT-II Functions (BCM)

AKS00CN7

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

4. Touch "HEAD LAMP" on "SELECT DIAG MODE" screen.



A  
B  
C  
D

## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

E  
F  
G

### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF.	ON	×
		OFF	—

H  
I

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

LT

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

L  
M

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.

## HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Monitor item	Contents
AUTO LIGHT SW "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW - DR "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR "ON/OFF"	Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL "ON/OFF"	Displays status of the rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW <sup>NOTE 1</sup> "OFF"	—
TURN SIGNAL R "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE 1</sup> "OFF"	—
OPTICAL SENSOR <sup>NOTE 2</sup> "0 - 5V"	Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

1. This item is displayed, but cannot be monitored.
2. Vehicles without auto light system display this item, but cannot be monitored.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE</sup>	—

**NOTE:**

This item is displayed, but cannot be tested.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## CONSULT-II Functions (IPDM E/R)

AKS00CN8

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


Check Item, Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19. "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not indicated, refer to [GI-38. "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

- Select desired part to be diagnosed on "SELECT DIAG MODE" screen.



## DATA MONITOR

### Operation Procedure

- Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

- Touch required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
- Touch "START".
- Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

### NOTE:

Perform monitoring of IPDM E/R data with ignition switch ON. When ignition switch is at ACC, display may not be correct.

## ACTIVE TEST

### Operation Procedure

- Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Touch item to be tested, and check operation.
- Touch "START".
- Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option.
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


AKS004QE

## Daytime Light Control Does Not Operate Properly

### 1. CHECK DAYTIME LIGHT CONTROL UNIT

1. Turn ignition switch OFF.
2. Disconnect daytime light control unit connector.
3. Check voltage between daytime light control unit harness connector and ground.

Terminal (+)		Terminal (-)	Voltage
Connector	Terminal (Wire color)		
E25	2 (OR)	Ground	Battery voltage
E26	3 (OR)		



OK or NG

OK >> GO TO 2.

NG >> Repair or replace daytime light control unit power supply circuit harness.

### 2. CHECK GROUND FOR DAYTIME LIGHT CONTROL UNIT


Check continuity between daytime light control unit harness connector E26 terminal 9 (B) and ground.

**9 (B) – Ground : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect parking brake switch connector.
2. Check continuity between daytime light control unit harness connector E25 terminal 10 (PU/R) and parking brake switch harness connector B37\*1 or E110\*2 terminal 1 (PU/R\*1, R/W\*2).


**10 (PU/R) – 1 (PU/R\*1, R/W\*2) : Continuity should exist.**

\*1: M/T, \*2: A/T

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 4. CHECK PARKING BRAKE SWITCH

1. Connect daytime light control unit connector and parking brake switch connector.
2. Turn ignition switch ON.
3. Check voltage between parking brake switch harness connector B37\*1 or E110\*2 terminal 1 (PU/R\*1 , R/W\*2 ) and ground, when parking brake is released.


**1 (PU/R\*1 , R/W\*2) – Ground : Battery voltage.**

\*1: M/T, \*2: A/T

OK or NG

OK >> GO TO 5.

NG >> Replace parking brake switch.



## 5. CHECK ALTERNATOR CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect daytime light control unit connector.
3. Start engine running.
4. Check voltage between daytime light control unit harness connector E25 terminal 11 (W/R) and ground.

**11 (W/R) – Ground : Battery voltage.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



## 6. CHECK POWER CIRCUIT BETWEEN DAYTIME LIGHT CONTROL UNIT AND HEADLAMP LH


1. Turn ignition switch OFF.
2. Disconnect daytime light control unit connector and LH front combination lamp connector.
3. Check continuity between daytime light control unit harness connector E26 terminal 6 (L) and front combination lamp LH harness connector E41 terminal 2 (L).

**6 (L) – 2 (L) : Continuity should exist.**

OK or NG

OK >> GO TO 7.

NG >> Repair harness or connector.



## 7. CHECK GROUND CIRCUIT BETWEEN DAYTIME LIGHT CONTROL UNIT AND HEADLAMP LH


Check continuity between daytime light control unit harness connector E26 terminal 7 (Y/G) and front combination lamp LH harness connector E41 terminal 8 (Y/G).

**7 (Y/G) – 8 (Y/G) : Continuity should exist.**

OK or NG

OK >> GO TO 8.

NG >> Repair harness or connector.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


## 8. CHECK POWER CIRCUIT BETWEEN DAYTIME LIGHT CONTROL UNIT AND HEADLAMP RH

1. Disconnect front combination lamp RH connector.
2. Check continuity between daytime light control unit harness connector E26 terminal 8 (LG) and front combination lamp RH harness connector E24 terminal 2 (LG).

**8 (LG) – 2 (LG) : Continuity should exist.**

OK or NG

- OK >> GO TO 9.  
 NG >> Repair harness or connector.




## 9. CHECK DAYTIME LIGHT CONTROL UNIT

1. Connect daytime light control unit connector.
2. Check voltage between front combination lamp LH harness connector E41 terminal 2 (L) and ground, when releasing parking brake with engine running and turning lighting switch to OFF.

**2 (L) – Ground : Battery voltage.**

OK or NG

- OK >> ● Check connector for connection, bend and loose fit and repair.  
 ● Check headlamp bulb.
- NG >> Replace daytime light control unit.



## Headlamp High Beam Does Not Illuminate (Both Sides)

AKS004QF

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓟ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.


**When lighting switch is : HI BEAM SW ON HIGH position**

ⓧ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 2.  
 NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 2. HEADLAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operates.

**Headlamp high beam should operate.  
(Headlamp high beam repeats ON-OFF every 1 second).**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#) .
2. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

- OK >> GO TO 3.  
NG >> GO TO 4.

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HI position.

**When lighting switch is HIGH position : HL LO REQ ON  
: HL HI REQ ON**

OK or NG

- OK >> Replace IPDM E/R.  
NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

ACTIVE TEST			
LAMPS		HI	
OFF			
LO		FOG	
MODE	BACK	LIGHT	COPY

PKIA7741E

DATA MONITOR			
MONITOR			
HL LO REQ		ON	
HL HI REQ		ON	
RECORD			
MODE	BACK	LIGHT	COPY


PKIA7638E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 4. CHECK HEADLAMP INPUT SIGNAL

 With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. When headlamp high beam is operating, check voltage between front combination lamp RH and LH harness connector and ground (Headlamp high beam repeats ON-OFF every 1 second).



Terminal (+)		Terminal (-)	Voltage
Connector	Terminal (Wire color)		
E7	20 (R)	Ground	Battery voltage
	30 (R/B)		

 Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. When headlamp high beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal (+)		Terminal (-)	Voltage
Connector	Terminal (Wire color)		
E7	20 (R)	Ground	Battery voltage
	30 (R/B)		

OK or NG

- OK >> Check connector for connection, bend and loose fit and repair.  
 NG >> Replace IPDM E/R.

## RH High Beam Does Not Illuminate But RH Low Beam Illuminates

AKS004QG

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.  
 NG >> Replace bulb of lamp.

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 2. CHECK CIRCUIT BETWEEN IPDM E/R AND DAYTIME LIGHT RELAY-2

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Remove daytime light relay-2.
4. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and daytime light relay-2 harness connector E16 terminal 2 (BR).


**27 (BR) – 2 (BR) : Continuity should exist.**

5. Check continuity between IPDM E/R harness connector E7 terminal 27 (BR) and daytime light relay-2 harness connector E16 terminal 5 (BR).

**27 (BR) – 5 (BR) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.




## 3. CHECK DAYTIME LIGHT RELAY-2 GROUND

Check continuity between daytime light relay-2 harness connector E16 terminal 1 (B) and ground.

**1 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.




## 4. CHECK CIRCUIT BETWEEN DAYTIME LIGHT RELAY-2 AND HEADLAMP RH

1. Disconnect front combination lamp RH connector.
2. Check continuity between daytime light relay-2 harness connector E16 terminal 3 (LG) and front combination lamp RH harness connector E24 terminal 2 (LG).

**3 (LG) – 2 (LG) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Repair harness or connector.





# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 5. CHECK HEADLAMP RH GROUND CIRCUIT


Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



## 6. CHECK IPDM E/R

1. Connect IPDM E/R connector.
2. Turn ignition switch ON.
3. Lighting switch is turned HIGH position.
4. Check voltage between daytime light relay-2 harness connector E16 terminal 2 (BR) and ground.

**2 (BR) – Ground : Battery voltage.**


5. Check voltage between daytime light relay-2 harness connector E16 terminal 5 (BR) and ground.

**5 (BR) – Ground : Battery voltage.**

OK or NG

OK >> Replace daytime light relay-2.

NG >> Replace IPDM E/R.



## LH High Beam Does Not Illuminate But LH Low Beam Illuminates

AKS004QH

### 1. CHECK CIRCUIT BETWEEN IPDM E/R AND DAYTIME LIGHT CONTROL UNIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and daytime light control unit connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 28 (R/Y) and daytime light control unit harness connector E26 terminal 5 (R/Y).

**28 (R/Y) – 5 (R/Y) : Continuity should exist.**

OK or NG

OK >> GO TO 2.

NG >> Repair harness or connector.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


## 2. CHECK IPDM E/R

1. Connect IPDM E/R connector.
2. Turn ignition switch ON.
3. Lighting switch is turned HIGH position.
4. Check voltage between daytime light control unit harness connector E26 terminal 5 (R/Y) and ground.

**5 (R/Y) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 3.  
NG >> Replace IPDM E/R.




## 3. CHECK POWER CIRCUIT BETWEEN DAYTIME LIGHT CONTROL UNIT AND HEADLAMP LH

1. Turn ignition switch OFF.
2. Disconnect front combination lamp LH connector.
3. Check continuity between daytime light control unit harness connector E26 terminal 6 (L) and front combination lamp LH harness connector E41 terminal 2 (L).

**6 (L) – 2 (L) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.




## 4. CHECK CIRCUIT BETWEEN DAYTIME LIGHT CONTROL UNIT AND HEADLAMP LH

Check continuity between daytime light control unit harness connector E26 terminal 7 (Y/G) and front combination lamp LH harness connector E41 terminal 8 (Y/G).

**7 (Y/G) – 8 (Y/G) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Repair harness or connector.




## 5. CHECK DAYTIME LIGHT CONTROL UNIT AND GROUND

Check continuity between daytime light control unit harness connector E26 terminal 9 (B) and ground.

**9 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 6.  
NG >> Repair harness or connector.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 6. CHECK DAYTIME LIGHT CONTROL UNIT


1. Connect daytime light control unit connector.
2. Turn ignition switch ON.
3. Lighting switch is turned HIGH position.
4. Check voltage between front combination lamp LH harness connector E41 terminal 2 (L) and ground.

**2 (L) – Ground : Battery voltage.**

### OK or NG

- OK >> ● Check connector for connection, bend and loose fit and repair.  
● Check headlamp bulb.

NG >> Replace daytime light control unit.



## Headlamp Low Beam Does Not Illuminate (Both Sides)

AKS00AB1

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 2ND position : HEAD LAMP SW 1 ON  
: HEAD LAMP SW 2 ON**

☒ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#).

### OK or NG

OK >> GO TO 2.

NG >> Check combination switch lighting switch. Refer to [LT-134, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	ON		
HEAD LAMP SW2	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7586E

## 2. HEADLAMP ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST" ITEM screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

### OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS		LO	
OFF	HI		
		FOG	
MODE	BACK	LIGHT	COPY

PKIA7742E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is 2ND position : HL LO REQ ON**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .


DATA MONITOR			
MONITOR			
HL LO REQ		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7644E

## 4. CHECK HEADLAMP INPUT SIGNAL

Ⓜ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.



Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	3 (R)	Ground	Battery voltage
LH	E41	3 (R/B)		

ⓧ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#) .
4. When headlamp low beam is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal (+)			Terminal (-)	Voltage
Connector	Terminal (Wire color)			
RH	E24	3 (R)	Ground	Battery voltage
LH	E41	3 (R/B)		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 (R) and front combination lamp RH harness connector E24 terminal 3 (R).

**20 (R) – 3 (R) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 (R/B) and front combination lamp LH harness connector E41 terminal 3 (R/B).

**30 (R/B) – 3 (R/B) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.


## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front combination lamp RH harness connector E24 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**

3. Check continuity between front combination lamp LH harness connector E41 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**



OK or NG

- OK >> Check headlamp harness and connectors, ballasts (HID control unit), and xenon bulbs. Refer to [LT-71, "Xenon Headlamp Trouble Diagnosis"](#).
- NG >> Repair harness or connector.

## RH Low Beam Does Not Illuminate But RH High Beam Illuminates

AKS004QJ

### 1. CHECK BULB

Check ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-71, "Xenon Headlamp Trouble Diagnosis"](#).


OK or NG

- OK >> GO TO 2.
- NG >> Replace malfunctioning part.

### 2. CHECK CIRCUIT BETWEEN IPDM E/R AND HEADLAMP RH

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp RH connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 (R) and front combination lamp RH harness connector E24 terminal 3 (R).

**20 (R) – 3 (R) : Continuity should exist.**



OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -


## 3. CHECK HEADLAMP RH GROUND CIRCUIT

Check continuity between front combination lamp RH harness connector E24 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.



## LH Low Beam Does Not Illuminate But LH High Beam Illuminates

AKS004QK

### 1. CHECK BULB

Check ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-71, "Xenon Headlamp Trouble Diagnosis"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Replace malfunctioning part.


### 2. CHECK CIRCUIT BETWEEN IPDM E/R AND HEADLAMP LH

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp LH connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 30 (R/B) and front combination lamp LH harness connector E41 terminal 3 (R/B).

**30 (R/B) – 3 (R/B) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.




### 3. CHECK HEADLAMP AND GROUND

Check continuity between front combination lamp LH harness connector E41 terminal 4 (B/W) and ground.

**4 (B/W) – Ground : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## General Information for Xenon Headlamp Trouble Diagnosis

AKS00CMY

In most cases, malfunction of xenon headlamp - "does not illuminate", "flickers" or "dark" - is caused by a malfunctioning xenon bulb. A malfunctioning HID control unit or lamp housing, however, may be a cause. Be sure to perform trouble diagnosis following the steps described below.

### Caution:

AKS00CMZ

- Installation or removal of connector must be done with lighting switch OFF.
- Disconnect the battery cable from the negative terminal or remove power fuse.
- When the lamp is illuminated (when lighting switch is ON), never touch harness, HID control unit, inside of lamp, or lamp metal parts.
- To check illumination, temporarily install lamp in vehicle. Be sure to connect power at vehicle side connector.
- If error can be traced directly to electrical system, first check for items such as blown fuses and fusible links, broken wires or loose connectors, dislocated terminals, and improper connections.
- Never work with wet hands.
- Using a tester for HID control unit circuit trouble diagnosis is prohibited.
- Disassembling HID control unit or harnesses (bulb socket harness, ECM harness) is prohibited.
- Immediately after illumination, light intensity and color will fluctuate, but there is nothing wrong.
- When bulb has come to end of its life, brightness will drop significantly, it will flash repeatedly, or light color will turn reddish.

## Xenon Headlamp Trouble Diagnosis

AKS00CND

### 1. CHECK 1: XENON HEADLAMP LIGHTING

Install normal xenon bulb to corresponding xenon bulb headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace xenon bulb.
- NG >> GO TO 2.

### 2. CHECK 2: XENON HEADLAMP LIGHTING

Install normal HID control unit to corresponding xenon headlamp, and check if lamp lights up.

#### OK or NG

- OK >> Replace HID control unit.
- NG >> GO TO 3.

### 3. CHECK 3: XENON HEADLAMP LIGHTING

Install normal xenon lamp housing assembly to corresponding xenon headlamp, and check if lamp lights up.


#### OK or NG

- OK >> Replace xenon headlamp housing assembly. [Malfunction in starter (boosting circuit) in xenon headlamp housing]
- NG >> INSPECTION END

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Aiming Adjustment

AKS00CN1



PKIB6495E

### PREPARATION BEFORE ADJUSTING

**For Details, Refer to the Regulations in Your Own Country.**

Before performing aiming adjustment, check the following.

1. Keep all tires inflated to correct pressures.
2. Place vehicle on flat surface.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.


### LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam ON.
2. Use adjusting screws to perform aiming adjustment.



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)



A  
B  
C  
D  
E  
F  
G  
H  
I

If vehicle front body has been repaired and/or headlamp assembly has been replaced, check aiming. Use aiming chart shown in the figure.


- Basic illumination area for adjustment should be within the range shown on the aiming chart. Adjust headlamp accordingly.

### Bulb Replacement HEADLAMP (UPPER) LOW BEAM

AKS00CN2

LT

1. Turn lighting switch OFF.
2. Disconnect the battery cable from the negative terminal or remove power fuse.
3. Remove headlamp. Refer to [LT-74, "Removal and Installation"](#).
4. Turn plastic cap counterclockwise and unlock it.
5. Turn bulb socket counterclockwise and unlock it.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.



L  
M

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## HEADLAMP (LOWER) HIGH BEAM/FOG LAMP

1. Turn lighting switch OFF.
2. Disconnect the battery cable from the negative terminal or remove power fuse.
3. Remove fender protector (front). Refer to [EI-22, "FENDER PROTECTOR"](#) in "EI" section.
4. Turn plastic cap counterclockwise and unlock it.
5. Disconnect bulb socket.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.

## FRONT TURN SIGNAL/PARKING LAMP

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-22, "FENDER PROTECTOR"](#) in "EI" section.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.
5. Installation is the reverse order of removal.

**Headlamp (upper) low beam** : 12V - 35W (D2R)

**Headlamp (lower) high beam/Fog lamp** : 12V - 60/55W (HB2)

**Front turn signal/Parking lamp** : 12V - 21/5W

### CAUTION:

After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.

## Removal and Installation

### REMOVAL

1. Disconnect the battery cable from the negative terminal or remove power fuse.
2. Remove front grille. Refer to [EI-20, "FRONT GRILLE"](#) in "EI" section.
3. Remove front undercover and fender protector. Refer to [EI-22, "FENDER PROTECTOR"](#) in "EI" section.
4. Remove mounting clip on top of front bumper and screws on side of front bumper. Refer to [EI-14, "FRONT BUMPER"](#) in "EI" section.
5. Pull side of front bumper toward the vehicle front and disengage it from clips on the body.
6. Remove headlamp mounting bolts.
7. Pull headlamp toward the vehicle front, disconnect connector, and remove headlamp.

### CAUTION:



When removing headlamps, put a shop cloth or something similar between headlamps and bumper to protect bumper.

### INSTALLATION

Installation is the reverse order of removal.

**Headlamp mounting bolt**  : 5.0 N·m (0.51 kg·m, 44 in·lb)


AKS00CN3



# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Disassembly

AKS00C04



- |   |                            |   |
|---|----------------------------|---|
| 1. Retaining spring                     | 2. Xenon bulb (low)        | 3. Seal rubber                                |
| 4. Plastic cap (low)                    | 5. Xenon bulb socket (low) | 6. Halogen bulb (high/fog)                    |
| 7. Halogen bulb (high/fog) socket       | 8. Plastic cap (high/fog)  | 9. Front turn signal/Parking lamp bulb socket |
| 10. Front turn signal/Parking lamp bulb | 11. HID control unit       | 12. Headlamp housing assembly                 |

1. Turn plastic cap (low) counterclockwise and unlock it.
2. Turn xenon bulb (low) socket counterclockwise, and unlock it.
3. Unlock retaining spring, and remove xenon bulb (low).
4. Disconnect HID control unit connector, and remove HID control unit screws. (Xenon)
5. Turn plastic cap (high/fog) counterclockwise, and unlock it.
6. Disconnect the terminal connected to the halogen bulb (high/fog).
7. Unlock retaining spring, and remove halogen bulb (high/fog).
8. Turn front turn signal lamp/parking bulb socket counterclockwise and unlock it.
9. Remove front turn signal/parking lamp bulb from its socket.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Assembly

AKS00CN5

Assembly is the reverse order of disassembly.

HID control unit  : 3.2 N-m ( 0.33 kg-m, 28 in-lb)


### CAUTION:

- When HID control unit is removed, reinstall it securely and avoid any looseness.
- After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.

## Servicing to Replace Headlamps When Damaged


AKS00CN6

If only installation part as shown in the figure is damaged, and headlamp housing itself is not damaged, repair can be completed easily by installing correction brackets.



## REMOVAL AND INSTALLATION

1. Remove headlamps. Refer to [LT-74, "Removal and Installation"](#).
2. Cut damaged section of installation part, then shape with sandpaper.
3. Attach each correction bracket to headlamp housing boss with 2 screws.




# AUTO LIGHT SYSTEM

## AUTO LIGHT SYSTEM

PPF:28491

### Component Parts and Harness Connector Location

AKS009LA



PKIB6100E

## System Description

AKS009LB

Automatically turns ON/OFF the parking lamps and the headlamps in accordance with ambient light. Timing for when lamps turn ON/OFF can be selected using four modes.

### OUTLINE

The auto light control system has an optical sensor inside it that detects outside brightness. When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking lamps and the headlamps in accordance with ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, Refer to [LT-85. "SETTING CHANGE FUNCTIONS"](#).

Optical sensor, power is supplied

- from BCM (body control module) terminal 17
- to optical sensor terminal 1.

Optical sensor, ground is supplied

- to optical sensor terminal 3
- through BCM terminal 18.

When ignition switch is turn to "ON" position, and

# AUTO LIGHT SYSTEM

When outside brightness is darker than prescribed level, input is supplied

- from optical sensor terminal 2
- to BCM terminal 14.

The headlamps will then illuminate. For a description of headlamp operation, Refer to [LT-77, "System Description"](#).

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, then the headlamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## DELAY TIMER FUNCTION

Delay timer function carries out a function that BCM activates the timer and controls lights out of headlamps by door switch signal and lightning switch signal when turning the Ignition switch OFF while it is ON and headlamps are ON by the auto light function.

Timer types are a 5-minute timer and a 45-second timer

- When opening any door (door switch is ON), the 5-minute timer starts and then headlamps go out five minutes later
- When all the doors are closed (from door switch ON to OFF), the 45-second timer starts and then headlamps go out forty-five seconds later. If any door is opened (door switch ON) while the 45-second timer is in operation, the 5-minute timer starts again
- The timer stops when turning on the ignition switch or turning off the auto light switch under the above conditions.

Delay timer control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

AKS009LC

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing the high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

AKS009LD

Refer to [LAN-21, "CAN Communication Unit"](#).

## Major Components and Functions


AKS009LE

Components	Functions
BCM	● Turns on/off circuits of tail light and headlamp according to signals from light sensor, lighting switch (AUTO), driver door switch, passenger door switch, rear door switch, and ignition switch (ON, OFF).
Optical sensor	● Converts outside brightness (lux) to voltage, and sends it to BCM. (Detects brightness of 50 to 1,300 lux)

# AUTO LIGHT SYSTEM

## Schematic

AKS009LF



\* : This relay is built into the IPDME/R (Intelligent power distribution module engine room).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM

AKS009LG

## Wiring Diagram — AUTO/L —

LT-AUTO/L-01



REFER TO THE FOLLOWING.



- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWT1416E



# AUTO LIGHT SYSTEM

LT-AUTO/L-02





REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (B4) -ELECTRICAL UNITS

TKWM2254E

# AUTO LIGHT SYSTEM

LT-AUTO/L-03







REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2255E

# AUTO LIGHT SYSTEM

## Terminals and Reference Values for BCM

AKS009LH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
2	W/L	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3468E</p>	
3	G	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3469E</p>	
4	G/R	Combination switch input 3				
5	W/G	Combination switch input 2				
6	W/R	Combination switch input 1				
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage	
12	P	Front door switch passenger side signal	OFF	Front door switch passenger side	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
13	P	Rear door switch RH signal	OFF	Rear door switch RH	ON (open)	Approx. 0V
					OFF (closed)	Battery voltage
14	Y/PU	Optical sensor signal	ON	When optical sensor is illuminated		3.1 V or more <sup>Note</sup>
				When optical sensor is not illuminated		0.6 V or less
17	P	Optical sensor power supply	ON	—	Approx. 5V	
18	B	Sensor ground	ON	—	Approx. 0V	
32	GY	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3470E</p>	
33	L	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">PKIB3471E</p>	
34	PU	Combination switch output 3				
35	Y/R	Combination switch output 2				
36	Y	Combination switch output 1				
38	W/L	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN - H	—	—	—	
40	P	CAN - L	—	—	—	
42	GY	Battery power supply	OFF	—	Battery voltage	
52	B	Ground	ON	—	Approx. 0V	
55	W/R	Battery power supply	OFF	—	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
62	W	Front door switch driver side signal	OFF	Front door switch driver side	ON (open) Approx. 0V
					OFF (closed) Battery voltage
63	P	Rear door switch LH signal	OFF	Rear door switch LH	ON (open) Approx. 0V
					OFF (closed) Battery voltage

**NOTE:**

Optical sensor must be securely subjected to work lamp light. If the optical sensor is insufficiently illuminated, the measured value may not satisfy standard.

## Terminals and Reference Values for IPDM E/R

AKS009LI

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
20	R	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF Approx. 0V
					ON Battery voltage
22	R/L	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF Approx. 0V
					ON Battery voltage
27	BR	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF Approx. 0V
					ON Battery voltage
28	R/Y	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF Approx. 0V
					ON Battery voltage
30	R/B	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF Approx. 0V
					ON Battery voltage
38	B	Ground	ON	—	Approx. 0V
48	L	CAN – H	—	—	—
49	P	CAN – L	—	—	—
60	B/W	Ground	ON	—	Approx. 0V

## How to Proceed With Trouble Diagnosis

AKS009LJ

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-77, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-85, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts. Refer to [LT-91, "Symptom Chart"](#) .
5. Does the auto light system operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END.

# AUTO LIGHT SYSTEM

AKS009LK

## Preliminary Check SETTING CHANGE FUNCTIONS

- Sensitivity of auto light system can be adjusted using CONSULT-II. Refer to [LT-87, "WORK SUPPORT"](#).

## CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71
		72
		74
		76
		86

Refer to [LT-80, "Wiring Diagram — AUTO/L —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal (+)		Terminal (-)	Ignition switch position		
Connector	Terminal (Wire color)		OFF	ACC	ON
M1	11 (LG)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M4	42 (GY)		Battery voltage	Battery voltage	Battery voltage
	55 (W/R)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



# AUTO LIGHT SYSTEM


## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		Yes
M2	52 (B)		

OK or NG

- OK >> INSPECTION END
- NG >> Check ground circuit harness.



## CONSULT-II Functions (BCM)

AKS009LL

- CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.




2. Touch "START (NISSAN BASED VHCL)".




# AUTO LIGHT SYSTEM

3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



4. Touch "HEAD LAMP" on "SELECT DIAG MODE" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "CUSTOM A/LIGHT SETTING" or "ILL DELAY SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "NORMAL" or "MODE 2 - 4" of setting to be changed (CUSTOM A/LIGHT SETTING), Touch "MODE1-8" of setting to be changed (ILL DELAY SET).
6. Touch "SETTING CHANGE".
7. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
8. Touch "END".

### Work Support Setting Item

- Sensitivity of auto light can be selected and set from four modes.

Work item	Description
CUSTOM A/LIGHT SETTING	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. ● MODE 1 (Normal)/ MODE 2 (sensitive)/MODE 3 (Desensitized)/MODE4 (Insensitive)
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/MODE 5 (90 sec.)/MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

# AUTO LIGHT SYSTEM

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

## Display Item List

Monitor item	Contents
IGN ON SW	"ON/OFF" Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
ACC ON SW	"ON/OFF" Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW	"ON/OFF" Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1	"ON/OFF" Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2	"ON/OFF" Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST	"ON/OFF" Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW	"ON/OFF" Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW	"ON/OFF" Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF" Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW - DR	"ON/OFF" Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF" Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF" Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF" Displays status of the rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW <sup>NOTE 1</sup>	—
TURN SIGNAL R	"ON/OFF" Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF" Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE 1</sup>	—
OPTICAL SENSOR <sup>NOTE 2</sup>	"0 - 5V" Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

### NOTE:

1. This item is displayed, but cannot be monitored.
2. Vehicles without auto light system display this item, but cannot be monitored.

## ACTIVE TEST

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

## Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.



# AUTO LIGHT SYSTEM

Test item	Description
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <small>NOTE</small>	—

**NOTE:**

This item is displayed, but cannot be tested.

## CONSULT-II Functions (IPDM E/R)

AKS00CNA

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


Check Item, Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II OPERATION


**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM

- Select desired part to be diagnosed on "SELECT DIAG MODE" screen.



## DATA MONITOR

### Operation Procedure

- Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

- Touch required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
- Touch "START".
- Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with ignition switch ON. When ignition switch is at ACC, display may not be correct.

## ACTIVE TEST

### Operation Procedure

- Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Touch item to be tested, and check operation.
- Touch "START".
- Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option.
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option

# AUTO LIGHT SYSTEM

## Symptom Chart

AKS009LN

Phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> <li>● Parking lamps and headlamps will not illuminate when outside of vehicle becomes dark. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Parking lamps and headlamp will not go out when outside of vehicle becomes light. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Headlamps go out when outside of vehicle becomes light, but parking lamps stay on.</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-87, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-91, "Lighting Switch Inspection"</a> .</li> <li>● Refer to <a href="#">LT-92, "Optical sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM.</p>
<p>Parking lamps illuminate when outside of vehicle becomes dark, but headlamps stay off. (Lighting switch 1ST position and 2ND position operate normally.)</p>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-87, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-92, "Optical sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM.</p>
<p>Auto light adjustment system will not operate. (Lighting switch AUTO, 1ST position and 2ND position operate normally.)</p>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-92, "Optical sensor System Inspection"</a> .</li> </ul> <p>If above system is normal, replace BCM.</p>
<p>Auto light adjustment system of combination meter will not operate.</p>	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-15, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> </ul>
<p>Shut off delay feature will not operate.</p>	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-15, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> <li>● Refer to <a href="#">BL-41, "Check Door Switch"</a> .</li> </ul> <p>If above system is normal, replace BCM.</p>

## Lighting Switch Inspection

AKS009LO

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

Ⓟ With CONSULT-II  
 Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "AUTO LIGHT SW" turns ON-OFF linked with operation of lighting switch.


**When lighting switch is AUTO : AUTO LIGHT SW ON position**

ⓧ Without CONSULT-II  
 Refer to [LT-134, "Combination Switch Inspection"](#) .

OK or NG

OK >> INSPECTION END

NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#) .



# AUTO LIGHT SYSTEM

AKS009LP

## Optical sensor System Inspection

### 1. CHECK OPTICAL SENSOR INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "OPTICAL SENSOR", check difference in voltage when the optical sensor is illuminated and not illuminated.

**Illuminated**


**OPTICAL SENSOR : 3.1V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6V or less**

**CAUTION:**

**Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.**



DATA MONITOR			
MONITOR			
OPTICAL SENSOR		0.75V	
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7596E

⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector M1 terminal 14 (Y/PU) and ground.

**Illuminated**


**OPTICAL SENSOR : 3.1V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6V or less**

**CAUTION:**

**Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.**



OK or NG

OK >> INSPECTION END

NG >> GO TO 2.


### 2. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and optical sensor connector.
3. Check continuity (open circuit) between BCM harness connector M1 terminal 17 (P) and optical sensor harness connector M63 terminal 1 (P).

**17 (P) – 1 (P) : Continuity should exist.**

4. Check continuity (short circuit) between BCM harness connector M3 terminal 17 (P) and ground.

**17 (P) – Ground : Continuity should not exist.**



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

# AUTO LIGHT SYSTEM

## 3. CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M1 terminal 14 (Y/PU) and optical sensor harness connector M63 terminal 2 (Y/PU).

**14 (Y/PU) – 2 (Y/PU) : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M1 terminal 14 (Y/PU) and ground.

**14 (Y/PU) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



## 4. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M1 terminal 18 (B) and optical sensor harness connector M63 terminal 3 (B).

**18 (B) – 3 (B) : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M1 terminal 18 (B) and ground.

**18 (B) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



## 5. CHECK OPTICAL SENSOR VOLTAGE


1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M1 terminal 17 (P) and ground.

**17 (P) – Ground : Approx. 5V**

OK or NG

OK >> Replace optical sensor.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# AUTO LIGHT SYSTEM

## Removal and Installation for Optical Sensor

AKS009LQ

### REMOVAL

1. Insert a screwdriver or similar tool and remove front defroster grill (LH). Refer to [IP-15, "\(Aa\) Front Defroster Grille \(RH/LH\)"](#) in "IP" section.
2. Disconnect optical sensor connector.
3. Remove optical sensor.



### INSTALLATION

Installation is the reverse order of removal.


# FRONT FOG LAMP

## FRONT FOG LAMP

PPF:26150

### Component Parts and Harness Connector Location

AKS009KJ



PKIB6101E

## System Description

AKS009KK

Control of the fog lamps is dependent upon the position of the combination switch (lighting switch). The lighting switch must be in the 2ND position or AUTO position (headlamp is ON) for front fog lamp operation. When the lighting switch is placed in fog lamp position the BCM (body control module) receives input signal requesting the fog lamps to illuminate. When the headlamps are illuminated, this input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls the front fog lamp relay coil. When activated, this relay directs power to the front fog lamps.

## OUTLINE

Power is supplied at all times

- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay, located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42.

A

B

C

D

E

F

G

H

I

J

LT

L

M

# FRONT FOG LAMP

---

When ignition switch is in ON or START position, power is supplied

- to CPU located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

When ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43.

## FOG LAMP OPERATION (FOR USA)

The fog lamp switch is built in combination switch. The lighting switch must be in 2ND position or AUTO position (headlamp is ON) and fog lamp switch must be ON for fog lamp operation.

With the fog lamp switch in the ON position, CPU located in IPDM E/R grounds coil side of the fog lamp relay. Fog lamp relay then directs power

- through IPDM E/R terminal 37
- to front fog lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front fog lamp RH terminal 1.

Ground is supplied

- to front fog lamp LH terminal 8
- through grounds E17 and E43,
- to front fog lamp RH terminal 8
- through grounds E17 and E43.

With power and grounds supplied, front fog lamps illuminate.

## FOG LAMP OPERATION (FOR CANADA)

The fog lamp switch is built in combination switch. The lighting switch must be in 2ND position or AUTO position (headlamp is ON) and fog lamp switch must be ON for fog lamp operation.

With the fog lamp switch in the ON position, CPU located in IPDM E/R grounds coil side of the fog lamp relay. Fog lamp relay then directs power

- through IPDM E/R terminal 37
- to daytime light relay-1 terminals 2 and 5
- through daytime light relay-1 terminal 3
- to front combination lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front combination lamp RH terminal 1.

Ground is supplied

- to daytime light relay-1 terminal 1
- through grounds E17 and E43,
- to front combination lamp LH terminal 8
- through daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through grounds E17 and E43,
- to front combination lamp RH terminal 8
- through grounds E17 and E43.

With power and grounds supplied, front fog lamps illuminate.



# FRONT FOG LAMP

---

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

A

## EXTERIOR LAMP BATTERY SAVER CONTROL

When combination switch (lighting switch) is in the 2ND position (ON), fog lamp switch is ON, and ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

B

Under this condition, fog lamps (and headlamps) remain illuminated for 5 minutes, then fog lamps (and headlamps) are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

C

## CAN Communication System Description

AKS009KL

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

D

E

## CAN Communication Unit

AKS009KM

Refer to [LAN-21, "CAN Communication Unit"](#) .

F

G

H

I

J

LT

L





M

# FRONT FOG LAMP

## Wiring Diagram — F/FOG — FOR USA

AKS009KN

LT-F/FOG-01



REFER TO THE FOLLOWING.

(E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)




(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

(M1), (M2) -ELECTRICAL UNITS

TKWM2256E

# FRONT FOG LAMP

LT-F/FOG-02





TKWM2257E


# FRONT FOG LAMP

FOR CANADA


LT-F/FOG-03



M8  
W



M29  
W



B2  
W

REFER TO THE FOLLOWING.






(E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

(M1), (M2) -ELECTRICAL UNITS

TKWM2258E

# FRONT FOG LAMP



A

B

C

D

E

F

G

H

I

J

LT

L





M

TKWM2259E

# FRONT FOG LAMP

## Terminals and Reference Values for BCM

AKS009KO

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	W/L	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3468E</p>
3	G	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3469E</p>
4	G/R	Combination switch input 3			
5	W/G	Combination switch input 2			
6	W/R	Combination switch input 1			
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3470E</p>
33	L	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3471E</p>
34	PU	Combination switch output 3			
35	Y/R	Combination switch output 2			
36	Y	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN – H	—	—	—
40	P	CAN – L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0V
55	W/R	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS009KP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
36	W/G	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON) and the front fog lamp switch must be ON	OFF	Approx. 0V
					ON	Battery voltage
37	SB	Front fog lamp (LH)			OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0V	
48	L	CAN – H	—	—	—	

# FRONT FOG LAMP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
49	P	CAN – L	—	—	—
60	B/W	Ground	ON	—	Approx. 0V

## How to Proceed With Trouble Diagnosis

AKS009KQ

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-95, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-103, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS009KR

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	88

Refer to [LT-98, "Wiring Diagram — F/FOG —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# FRONT FOG LAMP

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal (+)		(-)	Ignition switch position		
Connector	Terminal (Wire color)		OFF	ACC	ON
M1	11 (LG)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M2	42 (GY)		Battery voltage	Battery voltage	Battery voltage
	55 (W/R)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		Yes
M2	52 (B)		Yes

OK or NG

OK >> INSPECTION END

NG >> Check ground circuit harness.



## CONSULT-II Functions (BCM)

Refer to [LT-18, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP (FOR USA).

Refer to [LT-54, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP (FOR CANADA).

## CONSULT-II Functions (IPDM E/R)

Refer to [LT-21, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP (FOR USA).

Refer to [LT-57, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP (FOR CANADA).

AKS009KS

AKS00CND



# FRONT FOG LAMP

## Front Fog lamps Does Not Illuminate (Both Sides) (FOR USA)

AKS009KT

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is FOG : FR FOG SW ON position**

⊗ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
FR FOG SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7598E

### 2. FOG LAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure fog lamp operates.

**Fog lamp should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure fog lamp operates.

**Fog lamp should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS		FOG	
OFF	HI		
LO			
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7748E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when lighting switch is in FOG position.

**When lighting switch is FOG : FR FOG REQ ON position**

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
FR FOG REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY


SKIA5898E

# FRONT FOG LAMP

## 4. CHECK FOG LAMP INPUT SIGNAL

☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
5. Touch "FOG" screen.
6. When fog lamp is operating, check voltage between front combination lamp RH and LH harness connector and ground.



Terminal (+)			Terminal (-)	Voltage
Connector		Terminal (Wire color)		
RH	E24	1 (W/G)	Ground	Battery voltage
LH	E41	1 (SB)		

☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When fog lamp is operating, check voltage between front combination lamp RH and LH harness connector and ground.

Terminal (+)			Terminal (-)	Voltage
Connector		Terminal (Wire color)		
RH	E24	1 (W/G)	Ground	Battery voltage
LH	E41	1 (SB)		

OK or NG

- OK >> GO TO 6.  
NG >> GO TO 5.


## 5. CHECK FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 (W/G) and front combination lamp RH harness connector E24 terminal 1 (W/G).

**36 (W/G) – 1 (W/G) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 (SB) and front combination lamp LH harness connector E41 terminal 1 (SB).

**37 (SB) – 1(SB) : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R.  
NG >> Repair harness or connector.

# FRONT FOG LAMP

## 6. CHECK FOG LAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.


**8 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> Check front fog lamp bulbs.  
NG >> Repair harness or connector.



## Front Fog Lamp Does Not Illuminate (One Side) (FOR USA)

AKS009KU

### 1. CHECK BULB

Check bulb of lamp with does not illuminate which does not illuminate.

OK or NG

- OK >> GO TO 2.  
NG >> Replace front fog lamp bulb.

### 2. CHECK FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp RH or LH connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 (W/G) and front combination lamp RH harness connector E24 terminal 1 (W/G).


**36 (W/G) – 1 (W/G) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 (SB) and front combination lamp LH harness connector E41 terminal 1 (SB).

**37 (SB) – 1 (SB) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.



### 3. CHECK FOG LAMP GROUND

1. Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.


**8 (B) – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E41 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R.  
NG >> Repair harness or connector.



# FRONT FOG LAMP

## Front Fog lamps Does Not Illuminate (Both Sides) (FOR CANADA)

AKS009KV

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is FOG : FR FOG SW ON position**

⊗ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
FR FOG SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7598E

### 2. FOG LAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure fog lamp operates.

**Fog lamp should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#) .
2. Make sure fog lamp operates.

**Fog lamp should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS	OFF		
		HI	
LO	FOG		
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5774E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when lighting switch is in FOG position.

**When lighting switch is FOG : FR FOG REQ ON position**

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .

DATA MONITOR			
MONITOR			
FR FOG REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY


SKIA5898E

# FRONT FOG LAMP

## 4. CHECK IPDM E/R

 With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. When fog lamp is operating, check voltage between IPDM E/R harness connector and ground.



Terminal			(-)	Voltage
(+)				
Connector		Terminal (Wire color)	Ground	Battery voltage
RH	E8	36 (W/G)		
LH		37 (SB)		

 Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. When fog lamp is operating, check voltage between IPDM E/R harness connector and ground.

Terminal			(-)	Voltage
(+)				
Connector		Terminal (Wire color)	Ground	Battery voltage
RH	E8	36 (W/G)		
LH		37 (SB)		

OK or NG

- OK >> Check front fog lamp bulbs.
- NG >> Replace IPDM E/R.

## LH Front Fog Lamp Does Not Illuminate (FOR CANADA)

AKS009KW

LT

### 1. CHECK BULB

Check bulb of lamp which does not illuminate .

OK or NG


- OK >> GO TO 2.
- NG >> Replace front fog lamp bulb.

# FRONT FOG LAMP

## 2. CHECK CIRCUIT BETWEEN IPDM E/R AND DAYTIME LIGHT RELAY-1

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Remove daytime light relay-1.
4. Check continuity between IPDM E/R harness connector and daytime light relay-1 harness connector.

Terminal				Continuity
IPDM E/R		Daytime light relay-1		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
E8	37 (SB)	E14	2 (SB)	Yes
			5 (SB)	



OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness or connector.


## 3. CHECK DAYTIME LIGHT RELAY-1 AND GROUND

Check continuity between daytime light relay-1 harness connector E14 terminal 1 (B) and ground.

**1 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness or connector.




## 4. CHECK CIRCUIT DAYTIME LIGHT RELAY-1 AND HEADLAMP

1. Disconnect front combination lamp LH connector.
2. Check continuity between daytime light relay-1 harness connector E14 terminal 3 (LG) and front combination lamp LH harness connector E41 terminal 1 (LG).

**3 (LG) – 1 (LG) : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness or connector.



# FRONT FOG LAMP


## 5. CHECK IPDM E/R

1. Connect IPDM E/R connector.
2. Turn ignition switch ON.
3. Lighting switch is turned FOG ON position.
4. Check voltage between daytime light relay-1 harness connector E14 terminal 2 (SB), 5 (SB) and ground.

**2 (SB), 5 (SB) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 6.  
NG >> Replace IPDM E/R.




## 6. CHECK DAYTIME LIGHT RELAY-1

1. Turn ignition switch OFF.
2. Connect daytime light relay-1.
3. Turn ignition switch ON.
4. Lighting switch is turned FOG ON position.
5. Check voltage between front combination lamp LH harness connector E41 terminal 1 (LG) and ground.

**1 (LG) – Ground : Battery voltage.**

OK or NG

- OK >> GO TO 7.  
NG >> Replace daytime light relay-1.




## 7. CHECK CIRCUIT BETWEEN HEADLAMP AND DAYTIME LIGHT CONTROL UNIT

1. Turn ignition switch OFF.
2. Disconnect daytime light control unit connector.
3. Check continuity between front combination lamp LH harness connector E41 terminal 8 (Y/G) and daytime light control unit harness connector E26 terminal 7 (Y/G).

**8 (Y/G) – 7 (Y/G) : Continuity should exist.**

OK or NG

- OK >> GO TO 8.  
NG >> Repair harness or connector.




## 8. CHECK CIRCUIT BETWEEN HEADLAMP AND DAYTIME LIGHT CONTROL UNIT

Check continuity between daytime light control unit harness connector E26 terminal 9 (B) and ground.

**9 (B) – Ground : Continuity should exist.**

OK or NG

- OK >> Replace daytime light control unit.  
NG >> Repair harness or connector.



# FRONT FOG LAMP

## RH Front Fog Lamp Does Not Illuminate (FOR CANADA)

AKS00AB2

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

OK >> GO TO 2.

NG >> Replace front fog lamp bulb.

### 2. CHECK CIRCUIT BETWEEN IPDM E/R AND FRONT FOG LAMP


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp RH connector.
3. Check continuity between harness IPDM E/R harness connector E8 terminal 36 (W/G) and front combination lamp RH harness connector E24 terminal 1 (W/G).

**36 (W/G) – 1 (W/G) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK FRONT FOG LAMP GROUND


Check continuity between front combination lamp RH harness connector E24 terminal 8 (B) and ground.

**8 (B) – Ground : Continuity should exist.**

OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness or connector.



## Bulb Replacement

Refer to [LT-34, "Bulb Replacement"](#) in "HEADLAMP".

AKS009KX




# TURN SIGNAL AND HAZARD WARNING LAMPS

## TURN SIGNAL AND HAZARD WARNING LAMPS

PPF:26120

### Component Parts and Harness Connector Location

AKS009MF



PKIB6496E

### System Description TURN SIGNAL OPERATION

AKS005KK

When ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM (body control module) terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminals 22 and 23.

Ground is supplied

- to BCM (body control module) terminal 52
- through grounds M30 and M66,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

### LH Turn Signal Lamp

When turn signal switch is moved to left position, BCM receives input signal requesting left turn signals to flash. BCM then supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 6, and
- to rear combination lamp LH terminal 3.

Ground is supplied

- to front combination lamp LH terminal 4

A

B

C

D

E

F

G

H

I

J

LT

L

M

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

- through grounds E17 and E43,
- to rear combination lamp LH terminal 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 across CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left turn signal indicator lamp.

With power and input supplied, BCM controls flashing of LH turn signal lamps.

## RH Turn Signal Lamp

When turn signal switch is moved to right position, BCM receives input signal requesting right turn signals to flash. BCM then supplies power

- through BCM terminal 46
- to front combination lamp RH terminal 6, and
- to rear combination lamp RH terminal 3.

Ground is supplied

- to front combination lamp RH terminal 4
- through grounds E17 and E43,
- to rear combination lamp RH terminal 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 across CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the right turn signal indicator lamp.

With power and input supplied, BCM controls flashing of RH turn signal lamps.

## HAZARD LAMP OPERATION

Power is supplied at all times

- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21.

Ground is supplied

- to hazard switch terminal 1
- through grounds M30 and M66,
- to BCM terminal 52
- through grounds M30 and M66,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

When hazard switch is depressed, ground is supplied

- to BCM terminal 29
- through hazard switch terminal 2.

BCM then supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 6, and
- to rear combination lamp LH terminal 3,
- through BCM terminal 46
- to front combination lamp RH terminal 6, and
- to rear combination lamp RH terminal 3.

Ground is supplied

- to front combination lamp LH terminal 4, and
- to front combination lamp RH terminal 4

# TURN SIGNAL AND HAZARD WARNING LAMPS

- through grounds E17 and E43,
- to rear combination lamp LH terminal 4, and
- to rear combination lamp RH terminal 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 across CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and input supplied, BCM controls flashing of hazard warning lamps.

## REMOTE KEYLESS ENTRY SYSTEM OPERATION

Power is supplied at all times

- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to combination meter terminal 21.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to combination meter terminals 1, 24 and 25
- through grounds M30 and M66.

When the remote keyless entry system is triggered by input from key fob, BCM supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 6, and
- to rear combination lamp LH terminal 3,
- through BCM terminal 46
- to front combination lamp RH terminal 6, and
- to rear combination lamp RH terminal 3.

Ground is supplied

- to front combination lamp LH terminal 4, and
- to front combination lamp RH terminal 4
- through grounds E17 and E43,
- to rear combination lamp LH terminal 4, and
- to rear combination lamp RH terminal 4
- through ground B103.

The BCM also supplies input to combination meter terminals 4 and 5 across CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and ground supplied, BCM controls flashing of hazard warning lamps when key fob is used to activate remote keyless entry system.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## CAN Communication System Description

AKS009MG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


AKS009MH

Refer to [LAN-21, "CAN Communication Unit"](#) .

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Schematic

AKS009MI







TKWM2260E

# TURN SIGNAL AND HAZARD WARNING LAMPS

AKS009MJ

## Wiring Diagram — TURN —

LT-TURN-01



REFER TO THE FOLLOWING.






- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2261E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02





REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (M2) -ELECTRICAL UNITS

TKWM2262E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03



REFER TO THE FOLLOWING.  
 (M4) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M75) - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Terminals and Reference Values for BCM

AKS009MK

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
2	W/L	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3468E</p>	
3	G	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3469E</p>	
4	G/R	Combination switch input 3				
5	W/G	Combination switch input 2				
6	W/R	Combination switch input 1				
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage	
29	G/R	Hazard switch signal	OFF	Hazard switch	ON	Approx. 0V
					OFF	Approx. 12V
32	GY	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3470E</p>	
33	L	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">PKIB3471E</p>	
34	PU	Combination switch output 3				
35	Y/R	Combination switch output 2				
36	Y	Combination switch output 1				
38	W/L	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN – H	—	—	—	
40	P	CAN – L	—	—	—	
42	GY	Battery power supply	OFF	—	Battery voltage	
45	G/W	Turn signal (left)	ON	Combina- tion switch	Turn left ON	<p style="text-align: right;">SKIA3009J</p>
46	PU/W	Turn signal (right)	ON	Combina- tion switch	Turn right ON	<p style="text-align: right;">SKIA3009J</p>



# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
52	B	Ground	ON	—	Approx. 0V
55	W/R	Battery power supply	OFF	—	Battery voltage

## How to Proceed With Trouble Diagnosis

AKS009ML

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-113, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-121, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Do turn signal and hazard warning lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS009MM

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
Combination meter	Battery	19
	Ignition switch ON or START position	14

Refer to [LT-117, "Wiring Diagram — TURN —"](#) .

#### OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M1	11 (LG)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M2	42 (GY)		Battery voltage	Battery voltage	Battery voltage
	55 (W/R)		Battery voltage	Battery voltage	Battery voltage

**OK or NG**

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		
M2	52 (B)		Yes

**OK or NG**

OK >> INSPECTION END

NG >> Check ground circuit harness.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## CONSULT-II Functions (BCM)

AKS009MN

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.


BCM diagnosis part	Diagnosis mode	Description
FLASHER	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.




2. Touch "START (NISSAN BASED VHCL)".



3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



4. Touch "FLASHER" on "SELECT TEST ITEM" screen.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## DATA MONITOR

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
HAZARD SW "ON/OFF"	Displays "Hazard ON (ON)/Hazard OFF (OFF)" status, determined from hazard switch signal.
TURN SIGNAL R "ON/OFF"	Displays "Turn right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn left (ON)/Other (OFF)" status, determined from lighting switch signal.
BRAKE SW "ON/OFF"	Displays "Brake lamp (ON)/Other (OFF)" status, determined from brake switch signal.

## ACTIVE TEST

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

### Display Item List

Test item	Description
FLASHER	Turn signal lamp (right or left) can be operated by any ON-OFF operations.

## Turn Signal Lamp Does Not Operate

AKS009MO

### 1. CHECK BULB

Check bulb standard of each turn signal lamp is correct.

#### OK or NG

- OK >> GO TO 2.  
NG >> Replace turn signal lamp bulb.

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓜ With CONSULT-II  
 Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "TURN SIGNAL R" and "TURN SIGNAL L" turns ON-OFF linked with operation of lighting switch.

- When lighting switch is : TURN SIGNAL R ON**  
**TURN RH position**
- When lighting switch is : TURN SIGNAL L ON**  
**TURN LH position**

DATA MONITOR			
MONITOR			
TURN SIGNAL R	ON		
TURN SIGNAL L	ON		
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7600E

ⓧ Without CONSULT-II  
 Refer to [LT-134, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 3.
- NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).

## 3. ACTIVE TEST

- Ⓜ With CONSULT-II
- Select "FLASHER" during active test. Refer to [LT-124, "ACTIVE TEST"](#).
  - Make sure "FLASHER RIGHT" and "FLASHER LEFT" operates.

**Turn signal lamp should operate**

ⓧ Without CONSULT-II  
 GO TO 4.

OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 4.


ACTIVE TEST			
FLASHER		RH	
RH		LH	OFF
MODE	BACK	LIGHT	COPY

PKIA7749E

## 4. CHECK SHORT CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector and all turn signal lamp connectors.
- Check continuity (short circuit) between BCM harness connector and ground.

Terminal			Continuity
BCM		Ground	
Connector	Terminal (Wire color)		
RH	M2		46 (PU/W)
LH		45 (G/W)	



OK or NG

- OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Hazard Warning Lamp Does Not Operate But Turn Signal Lamp Operate

AKS009M0

### 1. CHECK BULB

Make sure bulb standard of each turn signal lamp is correct.

OK or NG


- OK >> GO TO 2.
- NG >> Replace bulb.

### 2. CHECK HAZARD SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "HAZARD SW" turns ON-OFF linked with operation of hazard switch.


**When hazard switch is ON : HAZARD SW ON position**



☒ Without CONSULT-II

Check voltage between BCM harness connector M1 terminal 29 (G/R) and ground.

Terminal (+)		(-)	Condition	Voltage
Connector	Terminal (Wire color)			
M1	29 (G/R)	Ground	Hazard switch is ON	Approx. 0V
			Hazard switch is OFF	Battery voltage



OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.


### 3. CHECK HAZARD SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and hazard switch connector.
3. Check continuity BCM harness connector M1 terminal 29 (G/R) and hazard switch connector M282 terminal 2 (G/R).

**29 (G/R) – 2 (G/R) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## 4. CHECK GROUND


Check continuity hazard switch harness connector M282 terminal 1 (B) and ground.

**1 (B) – Ground : Continuity should exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



## 5. CHECK HAZARD SWITCH


1. Disconnect hazard switch connector.
2. Check continuity hazard switch.

Terminal		Condition	Continuity
Hazard switch			
1	2	Hazard switch is ON	Yes
		Hazard switch is OFF	No

OK or NG

OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).

NG >> Replace hazard switch.



## Turn Signal Indicator Lamp Does Not Operate

### 1. CHECK BULB

Check bulb of turn signal indicator lamp in combination meter.

OK or NG

OK >> Replace combination meter.

NG >> Replace indicator bulb.

AKS005KV

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## TURN SIGNAL AND HAZARD WARNING LAMPS

---

### **Bulb Replacement (Front Turn Signal Lamp)**

AKS009MW

Refer to [LT-34, "Bulb Replacement"](#) in "HEADLAMP (FOR USA)".

### **Bulb Replacement (Rear Turn Signal Lamp)**

AKS009MX

Refer to [LT-159, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

### **Removal and Installation of Front Turn Signal Lamp**

AKS009MY

Refer to [LT-35, "Removal and Installation"](#) in "HEADLAMP (FOR USA)".

### **Removal and Installation of Rear Turn Signal Lamp**

AKS009MZ

Refer to [LT-159, "Removal and Installation"](#) in "REAR COMBINATION LAMP".



# LIGHTING AND TURN SIGNAL SWITCH

## LIGHTING AND TURN SIGNAL SWITCH


PFP:25540

### Removal and Installation

AKS000M4

#### REMOVAL

1. Remove steering column cover. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Remove mounting bolts of cluster lid A and combination meter. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
3. While pressing pawls in direction as shown in the figure, pull lighting and turn signal switch toward driver door and disconnect from the base.
4. Disconnect lighting and turn signal switch connector.



#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HAZARD SWITCH

## HAZARD SWITCH


PFP:25290

### Removal and Installation (M/T)

AKS0081D

#### REMOVAL

1. Remove console boot (M/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Remove connector.
3. Remove screws.
4. Remove hazard switch.



#### INSTALLATION


Installation is the reverse order of removal.

### Removal and Installation (A/T)

AKS0081E

#### REMOVAL

1. Remove console finisher (A/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Remove connector.
3. Remove screws.
4. Remove hazard switch.



#### INSTALLATION

Installation is the reverse order of removal.

# COMBINATION SWITCH


PFP:25567

## COMBINATION SWITCH

### Wiring Diagram — COMBSW —

AKS009M3

## LT-COMBSW-01





— — — — — : DATA LINE

REFER TO PG-POWER.

TO LAN-CAN

BCM (BODY CONTROL MODULE) M1, M2

COMBINATION SWITCH M29



REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2264E

# COMBINATION SWITCH

## Combination Switch Reading Function

AKS009M4

For details, refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) in "BCS" section.

## CONSULT-II Function (BCM)

AKS009M5

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
COMB SW	DATA MONITOR	Displays BCM input data in real time.

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# COMBINATION SWITCH

4. Touch "COMB SW".



A  
B  
C  
D

## DATA MONITOR

### Operation Procedure

1. Touch "COMB SW" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects item and monitor them.

F  
G

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all signals will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

H

### Display Item List

Monitor item name	Contents
TURN SIGNAL R "ON/OFF"	Displays "Turn Right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn Left (ON)/Other (OFF)" status, determined from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays "Auto light switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR FOG SW "ON/OFF"	Displays "Front fog lamp switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR WIPER HI "ON/OFF"	Displays "Front Wiper HI (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER LOW "ON/OFF"	Displays "Front Wiper LOW (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER INT "ON/OFF"	Displays "Front Wiper INT (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WASHER SW "ON/OFF"	Displays "Front Washer Switch (ON)/Other (OFF)" status, determined from wiper switch signal.
INT VOLUME "1 - 7"	Displays intermittent operation knob setting (1 - 7), determined from wiper switch signal.
RR WIPER ON <sup>NOTE</sup> "OFF"	—
RR WIPER INT <sup>NOTE</sup> "OFF"	—
RR WASHER SW <sup>NOTE</sup> "OFF"	—

I  
J  
LT  
L  
M

#### NOTE:

This item is displayed, but cannot be monitored.

# COMBINATION SWITCH

AKS009M6

## Combination Switch Inspection

### 1. SYSTEM CHECK

- Referring to table below, check which system malfunctioning switch belongs to.

System 1	System 2	System 3	System 4	System 5
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
INT VOLUME 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	LIGHT SW 1ST
INT VOLUME 2	RR WIPER ON	—	FR FOG	—

>> Check the system to which malfunctioning switch belongs, and GO TO 2.

### 2. SYSTEM CHECK

 With CONSULT-II

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- Connect CONSULT-II, and select "COMB SW" on "SELECT TEST ITEM" screen.
- Select "DATA MONITOR".
- Select "START", and confirm that other switches in malfunctioning system operate normally.  
Example: When the auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in System 3, to which the auto light switch belongs, turn ON-OFF normally.

DATA MONITOR			
MONITOR			
TURN SIGNAL R	OFF		
TURN SIGNAL L	OFF		
HIBEAM SW	OFF		
HEAD LAMP SW1	OFF		
HEAD LAMP SW2	OFF		
LIGHT SW 1ST	OFF		
PASSING SW	OFF		
AUTO LIGHT SW	OFF		
FR FOG SW	OFF		
		Page Down	
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7602E

 Without CONSULT-II

Operating combination switch, and confirm that other switches in malfunctioning system operate normally.  
Example: When the auto light switch is malfunctioning, confirm that FRONT WIPER LOW and FRONT WIPER INT in System 3, to which auto light switch belongs, operate normally.

#### Check results


Other switches in malfunctioning system operate normally.>>Replace lighting switch or wiper switch.  
Other switches in malfunctioning system do not operate normally.>>GO TO 3.

# COMBINATION SWITCH

## 3. HARNESS INSPECTION


1. Disconnect BCM and combination switch connectors.
2. Check for continuity between BCM harness connector of the suspect system and the corresponding combination switch connector terminals.

Suspect system	Terminal				Continuity	
	BCM		Combination switch			
	Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
1	M1	Input 1	6 (W/R)	M29	6 (W/R)	Yes
		Output 1	36 (Y)		1 (Y)	
2		Input 2	5 (W/G)		7 (W/G)	
		Output 2	35 (Y/R)		2 (Y/R)	
3		Input 3	4 (G/R)		10 (G/R)	
		Output 3	34 (PU)		3 (PU)	
4		Input 4	3 (G)		9 (G)	
		Output 4	33 (L)		4 (L)	
5		Input 5	2 (W/L)		8 (W/L)	
		Output 5	32 (GY)		5 (GY)	



3. Check for continuity between each terminal of BCM harness connector in suspect malfunctioning system and ground.

Suspect system	Terminal				Continuity
	BCM		Ground		
	Connector	Terminal (Wire color)			
1	M1	Input 1	6 (W/R)	Ground	No
		Output 1	36 (Y)		
2		Input 2	5 (W/G)		
		Output 2	35 (Y/R)		
3		Input 3	4 (G/R)		
		Output 3	34 (PU)		
4		Input 4	3 (G)		
		Output 4	33 (L)		
5		Input 5	2 (W/L)		
		Output 5	32 (GY)		



### OK or NG

OK >> GO TO 4.

NG >> Check harness between BCM and combination switch for open or short circuit.

# COMBINATION SWITCH


## 4. BCM OUTPUT TERMINAL INSPECTION

1. Turn lighting switch and wiper switch into OFF.
2. Set wiper dial position 4.
3. Connect BCM and combination switch connectors, and check BCM output terminal voltage waveform of suspect malfunctioning system.

Suspect system	Terminal		
	Combination switch (+)		(-)
	Connector	Terminal (Wire color)	
1	M29	1 (Y)	Ground
2		2 (Y/R)	
3		3 (PU)	
4		4 (L)	
5		5 (GY)	

### OK or NG

- OK >> Open circuit in combination switch, GO TO 5.  
 NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .



## 5. COMBINATION SWITCH INSPECTION

Referring to table below, perform combination switch inspection.

Procedure										
1	2		3	4		5		6		7
Replace lighting switch	Confirm check results	OK	INSPECTION END	Confirm check results	OK	INSPECTION END	Confirm check results	OK	INSPECTION END	
		NG	Replace wiper switch		NG	Replace switch base		NG	Confirm symptom again	

>> INSPECTION END

### Removal and Installation

For details, refer to [LT-129, "LIGHTING AND TURN SIGNAL SWITCH"](#) .

AKS009M7



# STOP LAMP


PPF:26550

## STOP LAMP


### Wiring Diagram — STOP/L —

AKS009MA

#### LT-STOP/L-01



- ⬡HP : WITH HIGH-MOUNTED STOP LAMP ON THE REAR PARCEL SHELF
- ⬡HS : WITH HIGH-MOUNTED STOP LAMP IN THE REAR AIR SPOILER



REFER TO THE FOLLOWING.  
 ⬡E108, ⬡B1 -SUPER MULTIPLE JUNCTION (SMJ)  
 ⬡E101 -FUSE BLOCK-JUNCTION BOX (J/B)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# STOP LAMP

## Bulb Replacement of High-Mounted Stop Lamp WITH REAR SPOILER

AKS009MB

1. Remove high-mounted stop lamp. Refer to [LT-138, "Removal and Installation of High-Mounted Stop Lamp"](#) .
2. Replace together with high-mounted stop lamp.

**High-mounted stop lamp** : LED

## WITHOUT REAR SPOILER

1. Remove high-mounted stop lamp. Refer to [LT-138, "Removal and Installation of High-Mounted Stop Lamp"](#) .
2. Replace together with high-mounted stop lamp.

**High-mounted stop lamp** : LED

## Bulb Replacement of Rear Combination Lamp (Stop Lamp)


AKS009MC

Refer to [LT-159, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".

## Removal and Installation of High-Mounted Stop Lamp REMOVAL (WITH REAR SPOILER)

AKS009MD

1. Remove rear spoiler. Refer to [EI-35, "REAR SPOILER"](#) in "EI" section.
2. Remove screws and remove high-mounted stop lamp from rear spoiler.
3. Disconnect high-mounted stop lamp connector.




## INSTALLATION

Installation is the reverse order of removal.

## REMOVAL (WITHOUT REAR SPOILER)

1. Remove rear parcel shelf finisher. Refer to [EI-41, "REAR PARCEL SHELF FINISHER"](#) in "EI" section.
2. Remove screws and remove high-mounted stop lamp from rear parcel shelf finisher.
3. Disconnect high-mounted stop lamp connector.



## INSTALLATION

Installation is the reverse order of removal.

## Removal and Installation of Rear Combination Lamp (Stop Lamp)

AKS009ME

Refer to [LT-159, "Removal and Installation"](#) in "REAR COMBINATION LAMP".

# STEP LAMP

## STEP LAMP

PFP:26420

### Bulb Replacement

AKS000M5

Wiring diagram. Refer to [LT-176, "Wiring Diagram — ROOM/L —"](#) .

1. Remove step lamp. Refer to [LT-139, "Removal and Installation"](#) .
2. Remove bulb.


**Step lamp : 12V - 5W**

### Removal and Installation

AKS000M6

#### REMOVAL

1. Remove clips which are lower part of front door finisher and lift finisher up.
2. Disconnect step lamp connector.
3. Press pawl on reverse side and remove the step lamp.



#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# BACK-UP LAMP



PPF:26550

AKS0007X

## BACK-UP LAMP

### Wiring Diagram — BACK/L — A/T MODELS

LT-BACK/L-01




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM2266E

# BACK-UP LAMP





M/T MODELS

LT-BACK/L-02



REFER TO PG-POWER.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



REFER TO THE FOLLOWING.  
 (F102), (B1) -SUPER MULTIPLE JUNCTION (SMJ)


TKWM2267E

## PARKING, LICENSE PLATE AND TAIL LAMPS

PFP:26550

### Component Parts and Harness Connector Location

AKS009K2



PKIB6125E

## System Description

AKS009K6

Control of the parking, license plate, side marker and tail lamp operation is dependent upon the position of lighting switch (combination switch). When the lighting switch is placed in the 1ST position, the BCM (body control module) receives input signal requesting the parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) located in the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to parking, license plate, side marker and tail lamps, which then illuminate.

Power is supplied at all times

- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R, and
- to tail lamp relay, located in IPDM E/R,
- through 15A fuse (No. 78 located in IPDM E/R)
- to CPU located in IPDM E/R.

Power is also supplied at all times

- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM (body control module) terminal 42.

With ignition switch in the ON or START position, power is supplied

- to CPU located in IPDM E/R, from battery direct,

## PARKING, LICENSE PLATE AND TAIL LAMPS

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

With ignition switch in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43.

### OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if auto light system is activated), the BCM receives input signal requesting parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R across CAN communication lines. The CPU located in IPDM E/R controls tail lamp relay coil, which when energized, directs power

- through IPDM E/R terminal 22
- to front side marker lamp LH terminal 1
- to front combination lamp LH terminal 7
- to license plate lamp LH terminal 1
- to rear combination lamp LH terminal 1
- to front side marker lamp RH terminal 1
- to front combination lamp RH terminal 7
- to license plate lamp RH terminal 1, and
- to rear combination lamp RH terminal 1.

Ground is supplied at all times

- to front side marker lamp LH terminal 2
- through grounds E17 and E43,
- to front combination lamp LH terminal 4
- through grounds E17 and E43,
- to license plate lamp LH terminal 2
- through grounds B5 and B29,
- to rear combination lamp LH terminal 4
- through ground B103,
- to front side marker lamp RH terminal 2
- through grounds E17 and E43,
- to front combination lamp RH terminal 4
- through grounds E17 and E43,
- to license plate lamp RH terminal 2
- through grounds B5 and B29,
- to rear combination lamp RH terminal 4
- through ground B103.

With power and ground supplied, parking, license plate, side marker and tail lamps illuminate.

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

### EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST (or 2ND) position, and ignition switch is turned from ON or ACC to OFF, battery saver control feature is activated.

Under this condition, parking, license plate, side marker and tail lamps remain illuminated for 5 minutes, then the parking, license plate, side marker and tail lamps are turned off.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# PARKING, LICENSE PLATE AND TAIL LAMPS

---

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## **CAN Communication System Description**

AKS009K7

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## **CAN Communication Unit**

AKS009K8


Refer to [LAN-21, "CAN Communication Unit"](#) .



# PARKING, LICENSE PLATE AND TAIL LAMPS

## Schematic

AKS009K9



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


TKWM2529E

# PARKING, LICENSE PLATE AND TAIL LAMPS

AKS009KA

## Wiring Diagram — TAIL/L —

LT-TAIL/L-01



— — — — — : DATA LINE




REFER TO PG-POWER.

NEXT PAGE

TO LAN-CAN

BCM (BODY CONTROL MODULE) (M1), (M2)

COMBINATION SWITCH (M29)







REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M4) -FUSE BLOCK-JUNCTION BOX (J/B)  
 (M1), (M2) -ELECTRICAL UNITS

TKWM2268E



# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-03







TKWM2270E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for BCM

AKS009KB

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	W/L	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3468E</p>
3	G	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3469E</p>
4	G/R	Combination switch input 3			
5	W/G	Combination switch input 2			
6	W/R	Combination switch input 1			
11	LG	Ignition switch (ACC)	ACC	—	Battery voltage
32	GY	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3470E</p>
33	L	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">PKIB3471E</p>
34	PU	Combination switch output 3			
35	Y/R	Combination switch output 2			
36	Y	Combination switch output 1			
38	W/L	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN – H	—	—	—
40	P	CAN – L	—	—	—
42	GY	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0V
55	W/R	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

AKS009KC

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
22	R/L	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF	Approx. 0V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0V	
48	L	CAN – H	—	—	—	
49	P	CAN – L	—	—	—	
60	B/W	Ground	ON	—	Approx. 0V	

# PARKING, LICENSE PLATE AND TAIL LAMPS

AKS009KD

## How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-142, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-150, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Do the parking, license plate and tail lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS009KE

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71

Refer to [LT-146, "Wiring Diagram — TAIL/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal (+)		Terminal (-)	Ignition switch position		
Connector	Terminal (Wire color)		OFF	ACC	ON
M1	11 (LG)	Ground	Approx. 0V	Battery voltage	Battery voltage
	38 (W/L)		Approx. 0V	Approx. 0V	Battery voltage
M2	42 (GY)		Battery voltage	Battery voltage	Battery voltage
	55 (W/R)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



PKIB5197E

# PARKING, LICENSE PLATE AND TAIL LAMPS


## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		Yes
M2	52 (B)		

OK or NG

- OK >> INSPECTION END
- NG >> Check ground circuit harness.



AKS009KF

### CONSULT-II Functions (BCM)

Refer to [LT-18, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP.

Refer to [LT-54, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP (FOR CANADA).

### CONSULT-II Functions (IPDM E/R)

Refer to [LT-21, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP.

Refer to [LT-57, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP (FOR CANADA).

AKS00CNU

## Parking, License Plate and Tail Lamps Do Not Illuminate

AKS009KG

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓟ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "LIGHT SW 1 ST" turns ON-OFF linked with operation of lighting switch.


**When lighting switch is 1ST : LIGHT SW 1 ST ON position**

ⓧ Without CONSULT-II

Refer to [LT-134, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Check combination switch (lighting switch). Refer to [LT-134, "Combination Switch Inspection"](#).



PKIA7607E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT


# PARKING, LICENSE PLATE AND TAIL LAMPS

## 2. ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
3. Touch "ON" screen.
4. Make sure parking, license plate, side marker and tail lamp operates.

**Parking, license plate, side marker and tail lamp should operate**



☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#) .
2. Make sure parking, license plate, side marker and tail lamp operates.

**Parking, license plate, side marker and tail lamp should operate**


OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 4.

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "TAIL & CLR REQ" turns ON when lighting switch is in 1ST position.

**When lighting switch is 1ST : TAIL & CLR REQ ON position**



OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .



# PARKING, LICENSE PLATE AND TAIL LAMPS

## 4. CHECK INPUT SIGNAL


🔌 With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front side marker, front combination lamp, license plate lamp and rear combination lamp connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
5. Touch "ON" screen.
6. When tail lamp relay is operating, check voltage between front side marker lamp, front combination lamp, license plate lamp, rear combination lamp harness connector and ground.


🔌 Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front side marker, front combination lamp, license plate lamp and rear combination lamp connectors.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When tail lamp relay is operating, check voltage between front side marker lamp, front combination lamp, license plate lamp, rear combination lamp harness connector and ground.


Terminal				Voltage
Front side marker lamp (+)		(-)		
Connector	Terminal (Wire color)			
RH	E28	1 (R/L)	Ground	Battery voltage
LH	E40			



Terminal				Voltage
Front combination lamp (+) (Parking)		(-)		
Connector	Terminal (Wire color)			
RH	E24	7 (R/L)	Ground	Battery voltage
LH	E41			



Terminal				Voltage
License plate lamp (+)		(-)		
Connector	Terminal (Wire color)			
RH	B153	1 (G)	Ground	Battery voltage
LH	B152			




# PARKING, LICENSE PLATE AND TAIL LAMPS

Terminal		(-)	Voltage	
Rear combination lamp (+) (Tail and side marker)				Ground
Connector		Terminal (Wire color)		
RH	B111	1 (R/L)		
LH	B101			

## OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.




# PARKING, LICENSE PLATE AND TAIL LAMPS

## 5. CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front side marker lamp harness connector.

Terminal					Continuity
IPDM E/R		Front side marker lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R/L)	RH	E28	1 (R/L)	Yes
		LH	E40		




4. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

Terminal					Continuity
IPDM E/R		Front combination lamp (Parking)			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R/L)	RH	E24	7 (R/L)	Yes
		LH	E41		




5. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

Terminal					Continuity
IPDM E/R		License plate lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R/L)	RH	B153	1 (G)	Yes
		LH	B152		



6. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

Terminal					Continuity
IPDM E/R		Rear combination lamp (Tail and side marker)			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E7	22 (R/L)	RH	B111	1 (R/L)	Yes
		LH	B101		



OK or NG


- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 6. CHECK GROUND


1. Check continuity between front side marker lamp harness connector and ground.

Terminal			Ground	Continuity
Front side marker lamp				
Connector	Terminal (Wire color)			
RH	E28	2 (B)		Yes
LH	E40			




2. Check continuity between front combination lamp harness connector and ground.

Terminal			Ground	Continuity
Front combination lamp (Parking)				
Connector	Terminal (Wire color)			
RH	E24	4 (B/W)		Yes
LH	E41			




3. Check continuity between license plate lamp harness connector and ground.

Terminal			Ground	Continuity
License plate lamp				
Connector	Terminal (Wire color)			
RH	B153	2 (B)		Yes
LH	B152			



4. Check continuity between rear combination lamp harness connector and ground.

Terminal			Ground	Continuity
Rear combination lamp (Tail and side marker)				
Connector	Terminal (Wire color)			
RH	B111	4 (B)		Yes
LH	B101			



### OK or NG

- OK >> Check bulb or replace rear combination lamp.  
 NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Parking, License Plate, Side marker and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

AKS004R0

### 1. CHECK IPDM E/R

1. Turn ignition switch ON. Place combination switch (lighting switch) in ON position. Turn ignition switch OFF.

2. Make sure parking, license plate, side marker and tail lamps turn OFF after approximately 10 minutes.

OK or NG

OK >> INSPECTION END.

NG >> Ignition relay malfunction. Refer to [PG-17, "Function of Detecting Ignition Relay Malfunction"](#).


## Bulb Replacement

### FRONT SIDE MARKER LAMP

AKS005ID

1. Remove front side marker lamp. Refer to [LT-157, "FRONT SIDE MARKER LAMP"](#).
2. Turn bulb socket left to release lock and remove it.
3. Remove bulb.


Front side marker lamp : 12V - 3.8W



### LICENSE PLATE LAMP

1. Remove license plate lamp. Refer to [LT-158, "Removal"](#).
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb from it's socket.

License plate lamp : 12V - 5W



### FRONT TURN SIGNAL (PARKING) LAMP

For bulb replacement, refer to [LT-34, "Bulb Replacement"](#) in "HEADLAMP (FOR USA)".

### TAIL LAMP

For bulb replacement, refer to [LT-159, "Bulb Replacement"](#) in "REAR COMBINATION LAMP".


## Removal and Installation

### FRONT SIDE MARKER LAMP

AKS005IE

#### Removal

1. Insert a slotted screwdriver or similar tool into fender protector gap to push front side marker lamp metal clip in direction 1 (see figure) while pulling in direction 2. Remove front side marker lamp from vehicle.
2. Disconnect connectors of front side marker lamp.



# PARKING, LICENSE PLATE AND TAIL LAMPS


## Installation

Installation is the reverse order of removal.

## LICENSE PLATE LAMP

### Removal

1. While pressing pawl on reverse side, push license plate towards you to remove.
2. Disconnect the license plate lamp connector.



## Installation

Installation is the reverse order of removal.

## FRONT TURN SIGNAL (PARKING) LAMP

For front turn signal (parking) lamp removal and installation procedures, refer to [LT-35, "Removal and Installation"](#) in "HEADLAMP (FOR USA)".

## TAIL LAMP

### Removal

For tail lamp removal and installation procedures, refer to [LT-159, "Removal and Installation"](#) in "REAR COMBINATION LAMP".

# REAR COMBINATION LAMP

## REAR COMBINATION LAMP


PFP:26554

### Bulb Replacement

AKS00AB3


#### REAR FENDER SIDE (REAR TURN SIGNAL LAMP BULB)

1. Open trunk and remove trunk rear finisher. Refer to [EI-47, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) in "EI" section.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.



#### TRUNK LID SIDE (BACK-UP LAMP)

1. Remove trunk lid finisher. Refer to [EI-47, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) in "EI" section.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.



<b>Stop/tail lamp (rear fender side)</b>	<b>: LED</b>
	<b>(Replace together with rear combination lamp assembly.)</b>
<b>Rear turn signal lamp (rear fender side)</b>	<b>: 12V - 21W</b>
<b>Back-up lamp (trunk lid side)</b>	<b>: 12V - 18W</b>
<b>Rear side marker lamp (rear fender side)</b>	<b>: LED</b>
	<b>(Replace together with rear combination lamp assembly.)</b>


## Removal and Installation

### REMOVAL

AKS00AB4

#### Rear Fender Side


1. Open trunk and remove trunk rear finisher. Refer to [EI-47, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) in "EI" section.
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp installation nuts.
4. Pull the rear combination lamp toward rear of vehicle and remove from vehicle.
5. Remove seal packing from vehicle.



# REAR COMBINATION LAMP

## Trunk Lid Side

1. Remove trunk lid finisher. Refer to [EI-47, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#) in "EI" section.
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp installation nuts.
4. Remove rear combination lamp from trunk lid.
5. Remove seal packing from trunk lid.



## INSTALLATION

Installation is the reverse order of removal.

- Install a new seal packing to rear combination lamp.

### **CAUTION:**

**Seal packing cannot be reused.**

Rear combination lamp mounting nut  : 3.2 N·m (0.33 kg·m, 28 in·lb)



# VANITY MIRROR LAMP

## VANITY MIRROR LAMP

PFP:96400


### Bulb Replacement

AKS000N3

Wiring diagram. Refer to [LT-176, "Wiring Diagram — ROOM/L —"](#) .

1. Insert a thin screwdriver in lens end and remove lens.
2. Remove bulb together with substrate.

**Vanity mirror lamp : 12V - 1.32W**



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# MAP LAMP

## MAP LAMP

PFP:26430


### Bulb Replacement

AKS0092S

Wiring diagram. Refer to [LT-176, "Wiring Diagram — ROOM/L —"](#) .

1. Insert a small screwdriver into lens hinge gap and remove lens.
2. Remove bulb.

**Map lamp : 12V - 8W**




### Removal and Installation

#### REMOVAL

1. Insert a clip driver or a suitable tool and disengage the pawl fittings of the map lamp.
2. Disconnect connector and remove map lamp.

AKS0092T



#### INSTALLATION

Installation is the reverse order of removal.

# TRUNK ROOM LAMP

## TRUNK ROOM LAMP

PFP:26470


### Bulb Replacement, Removal and Installation REMOVAL

AKS0092V

Wiring diagram. Refer to [LT-176, "Wiring Diagram — ROOM/L —"](#).

1. Unfold pawl A and remove lens.
2. Remove trunk room lamp while pressing pawl B in the direction of the arrow.
3. Disconnect trunk room lamp connector.

**Trunk room lamp : 12V - 3.4W**



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# PERSONAL LAMP

## PERSONAL LAMP

PFP:26415


### Bulb Replacement

AKS000MY

Wiring diagram. Refer to [LT-176, "Wiring Diagram — ROOM/L —"](#) .

1. Remove personal lamp. Refer to [LT-164, "Removal and Installation"](#) .
2. Insert a screwdriver or similar tool and remove lens.
3. Remove bulb.

**Personal lamp : 12V - 8W**



AKS000MZ

### Removal and Installation

#### REMOVAL

1. Use a clip driver or similar tool to press metal clip and remove personal lamp.
2. Disconnect personal lamp connector.

#### INSTALLATION

Installation is the reverse order of removal.

# IGNITION KEY HOLE ILLUMINATION

## IGNITION KEY HOLE ILLUMINATION

PFP:48476

### Removal and Installation


AKS000JY

#### REMOVAL (WITHOUT INTELLIGENT KEY SYSTEM)

Wiring diagram. Refer to [LT-176. "Wiring Diagram — ROOM/L —"](#).

1. Remove cluster lid A and steering lock escutcheon. Refer to [IP-10. "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Pull out ring, turn bulb socket to left to release lock and remove it.

**Ignition key hole illumination : 12V - 1.4W**




#### REMOVAL (WITH INTELLIGENT KEY SYSTEM)

Wiring diagram. Refer to [LT-176. "Wiring Diagram — ROOM/L —"](#).

1. Remove instrument lower driver panel. Refer to [IP-10. "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Turn bulb socket to left to release lock and remove it.

**Ignition key hole illumination : 12V - 1.4W**



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# GLOVE BOX LAMP

## GLOVE BOX LAMP

PFP:68520


### Bulb Replacement, Removal and Installation REMOVAL

AKS000JZ

Wiring diagram. Refer to [LT-197, "Wiring Diagram — ILL —"](#).

1. Remove instrument lower passenger panel. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Turn bulb socket left to release lock and remove it.

**Glove box lamp : 12V - 1.4W**



### INSTALLATION

Installation is the reverse order of removal.

# ASHTRAY ILLUMINATION

## ASHTRAY ILLUMINATION

PFP:25860


### Bulb Replacement, Removal and Installation REMOVAL

AKS00AB6

Wiring diagram. Refer to [LT-197, "Wiring Diagram — ILL —"](#).

1. Remove console finisher (A/T) or console boot (M/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Turn bulb socket to left to release lock and remove it.

**Ashtray illumination : 12V - 1.4W**



### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# CIGARETTE LIGHTER ILLUMINATION

## CIGARETTE LIGHTER ILLUMINATION

PFP:25331

### Bulb Replacement, Removal and Installation REMOVAL

AKS000K1


Wiring diagram. Refer to [LT-197, "Wiring Diagram — ILL —"](#).

1. Remove console finisher (A/T) or console boot (M/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) in "IP" section.
2. Open hooks and remove bulb socket.

**Cigarette lighter illumination : 12V - 0.8W**

#### **CAUTION:**

**When replacing bulb, replace assembly together with illumination ring.**



### INSTALLATION

Installation is the reverse order of removal.



# INTERIOR ROOM LAMP


PPF:26410

AKS005PZ

## INTERIOR ROOM LAMP

### Component Parts and Harness Connector Location

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



PKIB6105E

# INTERIOR ROOM LAMP

AKS009KY

## System Description

When map lamp switch is in DOOR position, map lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch driver side, unlock signal from keyfob, door lock and unlock switch, key cylinder lock and unlock switch, ignition switch.

When map lamp turns ON, there is a gradual brightening over 1 second. When map lamp turns OFF, there is a gradual dimming over 1 second.

Map lamp timer is controlled by BCM (body control module).

Map lamp timer control settings can be changed with CONSULT-II.

Ignition keyhole illumination turns ON at time when driver door is opened (door switch ON) or removed keyfob from key cylinder. Illumination turns OFF when driver door is closed (door switch OFF).

Step lamp turns ON at time when driver door, passenger door, RH rear door, or LH rear door is opened (door switch ON). Lamp turns OFF when driver, passenger doors are closed (all door switches OFF).

## POWER SUPPLY AND GROUND

Power is supplied at all times (without Intelligent Key system)

- through 10A fuse [No. 21, located in fuse block (J/B)]
- to key switch terminal 2,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55.

Power is supplied at all times (with Intelligent Key system)

- through 15A fuse (No.33, located in fuse, fusible link and relay box)
- to key switch and ignition knob switch terminals 1 and 3,
- through 10A fuse [No.18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55.

When key plate inserted to key switch, power is supplied (without Intelligent Key system)

- through key switch terminal 1
- to BCM terminal 37.

When inserted key plate to key switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37.

When moved ignition knob switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 2
- to intelligent key unit terminal 27.

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 52
- through grounds terminals M30 and M66.

When driver side door is opened, ground is supplied

- to BCM terminal 62
- through front door switch driver side terminal 1
- through case ground of front door switch driver side.

When passenger side door is opened, ground is supplied

- to BCM terminal 12
- through front door switch passenger side terminal 1
- through case ground of front door switch passenger side.

# INTERIOR ROOM LAMP

When rear door LH is opened, ground is supplied

- to BCM terminal 63, and
- to personal lamp LH terminal 1
- through rear door switch LH terminal 1
- through case ground of rear door switch LH.

A

When rear door RH is opened, ground is supplied

- to BCM terminal 13, and
- to personal lamp RH terminal 1
- through rear door switch RH terminal 1
- through case ground of rear door switch RH.

B

C

D

When driver side door is unlocked by door lock and unlock switch, BCM receives a ground signal

- to BCM terminal 22
- from power window main switch (door lock and unlock switch) terminal 14 and power window sub switch (front passenger side) (door lock and unlock switch) terminal 16
- to power window main switch (door lock and unlock switch) terminal 17 and power window sub switch (front passenger side) (door lock and unlock switch) terminal 11
- through grounds terminals M30 and M66.

E

F

When front driver side door is unlocked by driver side door lock assembly (door key cylinder switch), BCM receives a ground signal

- to BCM terminal 22
- through power window main switch (door lock and unlock switch) terminal 14
- to power window main switch (door lock and unlock switch) terminal 6
- through front door key cylinder switch (driver side) terminal 3
- to front door key cylinder switch (driver side) terminal 2
- through grounds M30 and M66.

G

H

I

When a signal, or combination of signals is received by BCM, ground is supplied

- to map lamp terminal 2
- through BCM terminal 48.

J

With power and supplied, the interior lamp illuminates.

LT

## SWITCH OPERATION

When driver door switch is ON (door is opened), ground is supplied

- to ignition keyhole illumination terminal 2
- through BCM terminal 1.

L

And power is supplied

- through BCM terminal 41
- to ignition keyhole illumination terminal 1.

M

When any door switch is ON (door is opened), ground is supplied

- to step lamp (driver side and passenger side) terminal 2
- through BCM terminal 47.

And power is supplied

- through BCM terminal 41
- to step lamp (driver side and passenger side) terminal 1.

When map lamp switch is ON, ground is supplied

- to map lamp terminal 1
- through grounds M30 and M66.

And power is supplied

- through BCM terminal 41
- to map lamp terminal 3.

When rear door switch LH or RH is ON (door is opened), ground is supplied

# INTERIOR ROOM LAMP

---

- to rear door switch LH or RH terminal 1
- through personal lamp LH or RH terminal 1.

And power is supplied

- through BCM terminal 41
- to personal lamp LH and RH terminal 2.

When vanity mirror lamp (driver side and passenger side) is ON, ground is supplied

- to vanity mirror lamp (driver side and passenger side) terminal 2
- through grounds M30 and M66.

And power is supplied

- through BCM terminal 41
- to vanity mirror lamp (driver side and passenger side) terminal 1.

When trunk room lamp switch is OPEN, ground is supplied

- to BCM terminal 57
- through trunk room lamp switch terminals 1 and 2
- through grounds B5 and B29.

When trunk room lamp is ON, ground is supplied

- to trunk room lamp terminal 2
- through BCM terminal 64.

And power is supplied

- to trunk room lamp terminal 1
- through BCM terminal 41.

## ROOM LAMP TIMER OPERATION

### Without Intelligent Key System

When map lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for map lamp ON/OFF.

In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to key switch terminal 2.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37.

Ground is supplied

- to power window main switch (door lock and unlock switch) terminal 14
- through BCM terminal 22.

At the time that driver door is opened, BCM detects that driver door is unlocked. It determines that map lamp timer operation condition is met, and turns the map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON),

Power is supplied

- to BCM terminal 37
- through key switch terminal 1.

When key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. BCM detects that key has been removed, determines that map lamp timer conditions are met, and turns the map lamp ON for 30 seconds.

When driver door opens → closes, and the key is not inserted in the key switch (key switch OFF), BCM terminal 62 changes between 0V (door open) → 12V (door closed). The BCM determines that conditions for map lamp operation is met, and turns the map lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked power window main switch (door lock and unlock switch) or door key cylinder switch]
- Driver door is opened (driver door switch turns ON)
- Ignition switch ON.

# INTERIOR ROOM LAMP

## With Intelligent Key System

When the map lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 second) for map lamp ON/OFF.

In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- through 15A fuse [No. 33, located in fuse and fuse block (J/B)]
- to key switch and ignition knob switch terminals 1 and 3.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37. And not turned ignition knob switch, power will not be supplied to Intelligent Key unit.

Ground is supplied

- to power window main switch (door lock and unlock switch) terminal 14
- through BCM terminal 22.

At the time that driver door are opened, BCM detects that driver door is unlocked. It determines that map lamp timer operation conditions is met, and turns map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON), or turned ignition knob switch,

Power is supplied

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37,
- through key switch and ignition knob switch terminal 2
- to intelligent key unit terminal 27.

When the key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. And turned ignition knob switch, power supply to Intelligent Key unit is terminated. BCM detects that key has been removed, determines that map lamp timer conditions is met, and turns map lamp ON for 30 seconds.

When driver door opens → closes, and key is not inserted in key switch (or not turned ignition knob switch), BCM terminal 62 changes between 0V (door open) → 12V (door closed). BCM determines that conditions for map lamp operation is met, and turns map lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked keyfob, power window main switch (door lock and unlock switch) or door key cylinder switch].
- Driver door is opened (driver door switch turns ON).
- Ignition switch ON.

## INTERIOR LAMP BATTERY SAVER CONTROL

If interior lamp is left "ON", it will not be turned out even when door is closed.

BCM turns off interior lamp automatically to save battery 30 minutes after ignition switch is turned off.

BCM controls interior lamps listed below:

- Trunk room lamp
- Vanity mirror lamp
- Map lamp
- Personal lamp

After lamps turn OFF by the battery saver system, the lamps illuminate again when

- signal from power window main switch (door lock and unlock switch) or key cylinder is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder, or turned ignition knob switch.

Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

A

B

C

D

E

F

G

H

I

J

LT

L


M



# INTERIOR ROOM LAMP

(OK) : Without Intelligent Key

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M





# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —

AKS005Q1

LT-ROOM/L-01



REFER TO THE FOLLOWING.



- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4), (M5) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2273E



# INTERIOR ROOM LAMP

## LT-ROOM/L-02



REFER TO THE FOLLOWING.



(D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)

(M1), (M2) -ELECTRICAL UNITS

TKWM2274E

# INTERIOR ROOM LAMP



LT-ROOM/L-03



TKWM2275E

# INTERIOR ROOM LAMP


LT-ROOM/L-04




(M8)  
W



(B117)  
W



(R2)  
W



(R4), (R9)  
W

REFER TO THE FOLLOWING.



(B1) -SUPER MULTIPLE JUNCTION (SMJ)

(M1), (M75), (B4)  
-ELECTRICAL UNITS

TKWM2276E

# INTERIOR ROOM LAMP

LT-ROOM/L-05





REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (B4) -ELECTRICAL UNITS

TKWM2277E

# INTERIOR ROOM LAMP

LT-ROOM/L-06






REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M1), (B4) -ELECTRICAL UNITS

TKWM2278E

# INTERIOR ROOM LAMP

LT-ROOM/L-07



REFER TO THE FOLLOWING.

(B1), (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -ELECTRICAL UNITS

TKWM2279E

# INTERIOR ROOM LAMP

## Terminals and Reference Values for BCM

AKS009KZ

Terminal No.	Wire color	Signal name	Measuring condition			Reference value	
			Ignition switch	Operation or condition			
1	PU	Ignition keyhole illumination signal	OFF	Door is locked. (SW OFF)		Battery voltage	
				Door is unlocked. (SW ON)		Approx. 0V	
12	P	Front door switch AS signal	OFF	Front door switch AS	ON (open)	Approx. 0V	
					OFF (closed)	Battery voltage	
13	P	Rear door switch RH signal	OFF	Rear door switch RH	ON (open)	Approx. 0V	
					OFF (closed)	Battery voltage	
22	Y	Power window switch serial link	—	—			
37	B/P	Key-in detection switch signal	OFF	Vehicle key is removed.		Approx. 0V	
				Vehicle key is inserted.		Battery voltage	
38	W/L	Ignition power supply	ON	—		Battery voltage	
39	L	CAN – H	—	—		—	
40	P	CAN – L	—	—		—	
41	R/B	Battery saver output signal	OFF	30 minutes after ignition switch is turned to OFF		Approx. 0V	
			ON	—		Battery voltage	
42	GY	Battery power supply	OFF	—		Battery voltage	
47	Y/PU	Step lamp signal	OFF	Any door is open (ON)		Approx. 0V	
				All doors are closed (OFF)		Battery voltage	
48	PU/R	map lamp output signal	OFF	Map lamp switch: DOOR position	Any door switch	ON (open)	Approx. 0V
						OFF (closed)	Battery voltage
52	B	Ground	ON	—		Approx. 0V	
55	W/R	Battery power supply	OFF	—		Battery voltage	
57	R/W	Trunk room lamp switch signal	OFF	Trunk room lamp switch	ON (open)	Approx. 0V	
					OFF (closed)	Battery voltage	
62	W	Front door switch DR signal	OFF	Front door switch DR	ON (open)	Approx. 0V	
					OFF (closed)	Battery voltage	
63	P	Rear door switch LH signal	OFF	Rear door switch LH	ON (open)	Approx. 0V	
					OFF (closed)	Battery voltage	
64	R	Trunk room lamp signal	OFF	Trunk room lamp	ON (open)	Approx. 0V	
					OFF (closed)	Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
M

LT

# INTERIOR ROOM LAMP

AKS009L0

## How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-170, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-184, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the interior room lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

AKS009L1

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES

- Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
		21
	Ignition switch ON or START position	1

Refer to [LT-176, "Wiring Diagram — ROOM/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM connector and ground.

Terminal		Ignition switch position	
(+)		(-)	
Connector	Terminal (Wire color)	OFF	ON
M2	42 (GY)	Battery voltage	Battery voltage
	55 (W/R)	Battery voltage	Battery voltage
M1	38 (W/L)	Approx. 0V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.





# INTERIOR ROOM LAMP


## 3. CHECK GROUND CIRCUIT

Check continuity between BCM and ground.

Terminal		Ground	Continuity
Connector	Terminal (Wire color)		Yes
M2	52 (B)		

OK or NG

- OK >> INSPECTION END
- NG >> Check harness ground circuit.



PKIB5198E

AKS009L2

## CONSULT-II Functions (BCM)

- CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnosis part	Diagnosis mode	Description
INT LAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION

### CAUTION:


If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector, then turn ignition switch ON.



PIIA1095E


2. Touch "START (NISSAN BASED VHCL)".




NOTE: EXAMPLE SHOWN. ACTUAL DISPLAY MAY DIFFER. BCIA0029E

# INTERIOR ROOM LAMP

3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



4. Touch "INT LAMP" on "SELECT TEST ITEM" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "SET I/L D- UNLCK INTCON" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED " will be displayed.
7. Touch "END".

### Display Item List

Item	Description	CONSULT-II
SET I/L D-UNLCK INTCON	The 30 seconds glowing function interior room lamps and ignition keyhole illumination can be selected when driver door is released (unlocked).	ON/OFF
ROOM LAMP ON TIME SET	The time in order to escalate illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned on.	MODE 1 – 7
ROOM LAMP OFF TIME SET	The time in order to diminish illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned off.	MODE 1 – 7

Reference between "MODE" and "TIME" for "TURN ON/OFF"

MODE	1	2	3	4	5	6	7
Time (sec.)	0.5	1	2	3	4	5	0

## DATA MONITOR

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT 3 MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

# INTERIOR ROOM LAMP

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

## Display Item List

Monitor item		Contents
IGN ON SW	"ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from ignition switch signal.
KEY ON SW	"ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from key switch signal.
DOOR SW - DR	"ON/OFF"	Displays status of driver door as judged from driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from passenger door switch signal.
DOOR SW - RR	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch RH signal.
DOOR SW - RL	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch LH signal.
BACK DOOR SW <sup>NOTE</sup>	"OFF"	—
KEY CYL LK - SW	"ON/OFF"	Displays "Door locked (ON) status, determined from key cylinder lock switch in driver door.
KEY CYL UN - SW	"ON/OFF"	Displays "Door unlocked (OFF) status, determined from key cylinder lock switch in driver door.
CDL LOCK SW	"ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF) status, determined from locking detection switch in driver door.
CDL UNLOCK SW	"ON/OFF"	Displays "Door unlocked (OFF)" status, determined from locking detection switch in passenger door.
I- KEY LOCK	"ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
I- KEY UNLOCK	"ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.
KEYLESS LOCK	"ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
KEYLESS UNLOCK	"ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.

### NOTE:

This item is displayed, but cannot be monitored.

## ACTIVE TEST

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

## Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.
IGN ILLUM	Ignition key hole illumination can be operated by ON-OFF operation.
STEP LAMP TEST	All step lamp can be operated by ON-OFF operation.
LUGGAGE LAMP TEST <sup>NOTE</sup>	—

### NOTE:

This item is displayed, but cannot be tested.

# INTERIOR ROOM LAMP

AKS009L3

## Map Lamp Control Does Not Operate

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-187, "Display Item List"](#) for switches and their functions.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E

### 2. ACTIVE TEST

- Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
- When map lamp switch is in "DOOR" position, use active test to make sure map lamp operates.

**Map lamp should operate.**

#### OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).  
 NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6881E


### 3. CHECK MAP LAMP INPUT

- Turn ignition switch OFF.
- Check voltage between map lamp harness connector R52 terminal 2 (PU/W) and ground.

**2 (PU/W) - Ground : Battery voltage.**

#### OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 4.




### 4. CHECK MAP LAMP

- Disconnect map lamp connector.
- Check continuity between map lamp.

Terminal		Condition	Continuity
Map lamp			
2	3	Map lamp switch is DOOR	Yes
		Map lamp switch is OFF	No

#### OK or NG

- OK >> GO TO 5.  
 NG >> Replace Map lamp.



# INTERIOR ROOM LAMP


## 5. CHECK MAP LAMP CIRCUIT

1. Disconnect BCM connector and map lamp connector.
2. Check continuity between BCM harness connector M2 terminal 41 (R/B) and map lamp harness connector R52 terminal 3 (R/B).

**41 (R/B) - 3 (R/B) : Continuity should exist.**

### OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK MAP LAMP CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M2 terminal 48 (PU/R) and map lamp harness connector R52 terminal 2 (PU/W).

**48 (PU/R) - 2 (PU/W) : Continuity should exist.**

### OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



## Ignition key Hole illumination Control Does Not Operate

AKS009L5

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-187, "Display Item List"](#) for switches and their functions.

### OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR			
MONITOR			
IGN ON SW		ON	
KEY ON SW		ON	
DOOR SW-DR		ON	
DOOR SW-AS		ON	
DOOR SW-RR		OFF	
DOOR SW-RL		OFF	
BACK DOOR SW		OFF	
KEY CYL LK-SW		OFF	
KEY CYL UN-SW		OFF	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIB3532E

### 2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP".
2. Select "IGN ILLUM" active test to make sure lamp operates.

**Ignition key hole illumination should operate.**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.

ACTIVE TEST			
IGN ILLUM		ON	
		OFF	
MODE	BACK	LIGHT	COPY

PKIA6375E

# INTERIOR ROOM LAMP


## 3. CHECK IGNITION KEY HOLE ILLUMINATION INPUT

1. Turn ignition switch OFF.
2. Open the driver side door.
3. Check voltage between ignition key hole illumination harness connector M309 terminal 1 (R/B) and ground.

**1 (R/B) - Ground : Battery voltage.**

OK or NG

- OK >> GO TO 4.  
NG >> GO TO 6.




## 4. CHECK IGNITION KEY HOLE ILLUMINATION BULB

1. Disconnect ignition key hole illumination connector.
2. Check continuity between ignition key hole illumination terminal 1 and 2.

**1 - 2 : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Replace ignition key hole illumination. Refer to [LT-165](#), "[Removal and Installation](#)".




## 5. CHECK IGNITION KEY HOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector and key hole illumination connector.
2. Check continuity between BCM harness connector M1 terminal 1 (PU) and key hole illumination harness connector M309 terminal 2 (PU).

**1 (PU) - 2 (PU) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-16](#), "[Removal and Installation of BCM](#)".  
NG >> Repair harness or connector.




## 6. CHECK IGNITION KEY HOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector and key hole illumination connector.
2. Check continuity between BCM harness connector M2 terminal 41 (R/B) and key hole illumination harness connector M309 terminal 1 (R/B).

**41 (R/B) - 1 (R/B) : Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-16](#), "[Removal and Installation of BCM](#)".  
NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

AKS009L6

## All Step Lamps Does Not Operate

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed below turn ON-OFF linked with switch operation.

Switch name	CONSULT screen
Driver side door switch	DOOR SW - DR
Passenger side door switch	DOOR SW - AS

#### OK or NG

- OK >> GO TO 2.  
 NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E


### 2. CHECK STEP LAMP INPUT

- Turn ignition switch OFF.
- Check voltage between step lamp (driver side) harness connector D10 terminal 1 (R/B) and ground.

**1 (R/B) - Ground : Battery voltage.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 4.




### 3. CHECK STEP LAMP CIRCUIT

- Disconnect BCM connector and front door driver side step lamp connector.
- Check continuity between BCM harness connector M2 terminal 47 (Y/PU) and front door step lamp (driver side) harness connector D10 terminal 2 (Y/PU).

**47 (Y/PU) - 2 (Y/PU) : Continuity should exist.**

#### OK or NG

- OK >> Replace BCM if step lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




### 4. CHECK STEP LAMP CIRCUIT

- Disconnect BCM connector and step lamp connector.
- Check continuity between BCM harness connector M2 terminal 41 (R/B) and front door step lamp (driver side) harness connector D10 terminal 1 (R/B).

**41 (R/B) - 1 (R/B) : Continuity should exist.**

#### OK or NG

- OK >> Replace BCM if step lamps does not work after setting the connector again. Refer to [BCS-16, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## All Interior Room Lamps Does Not Operate

AKS009L7

### 1. CHECK POWER SUPPLY CIRCUIT


1. All interior room lamps switch are OFF.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M2 terminal 41 (R/B) and ground.

**41 (R/B) - Ground : Battery voltage.**

#### OK or NG

OK >> Repair harness or connector. In a case of making a short circuit, be sure to disconnect battery negative cable after repairing harness, and then reconnect.

NG >> Replace BCM. Refer to [BCS-16, "Removal and Installation of BCM"](#) .



## Bulb Replacement MAP LAMP

AKS009L8

Refer to [LT-162, "Bulb Replacement"](#) in "MAP LAMP".

### STEP LMP

Refer to [LT-139, "Bulb Replacement"](#) in "STEP LAMP".

## Removal and Installation MAP LAMP

AKS009L9

Refer to [LT-162, "Removal and Installation"](#) in "MAP LAMP".

### STEP LAMP

Refer to [LT-139, "Removal and Installation"](#) in "STEP LAMP".



**ILLUMINATION****System Description**

AKS009MR

Control of illumination lamps operation is dependent upon the position of lighting switch (combination switch). When lighting switch is placed in the 1ST or 2ND position (or if auto light system is activated), BCM (body control module) receives input signal requesting illumination lamps to illuminate. This input signal is communicated to IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. CPU (central processing unit) located in the IPDM E/R controls tail lamp relay coil. This relay, when energized, directs power to illumination lamps, which then illuminate.

Power is supplied at all times

- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R, and
- to tail lamp relay, located in IPDM E/R.

Power is also supplied at all times

- through 50A fusible link (letter F, located in fuse, fusible link and relay box)
- to BCM terminal 55,
- through 10A fuse [No.18 located in fuse block (J/B)]
- to BCM terminal 42,
- through 15A fuse (No. 78 located in IPDM E/R)
- to CPU located in IPDM E/R.

With ignition switch in ON or START position, power is supplied

- to CPU located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14 located in fuse block (J/B)]
- to combination meter terminals 22 and 23,
- through 10A fuse [No.12 located in fuse block (J/B)]
- to display and A/C auto amp. terminal 2, and
- to NAVI control unit terminal 26 (with navigation system).

With ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11
- to combination meter terminal 18
- to NAVI control unit terminal 6 (with navigation system), and
- to display unit terminal 19 (with navigation system).

Ground is supplied

- to BCM terminal 52
- to display and A/C auto amp. terminal 5
- to combination meter terminal 1, 24, and 25
- to NAVI control unit terminal 1 and 4 (with navigation system), and
- to display unit terminal 22 and 24 (with navigation system)
- through grounds M30 and M66,
- to IPDM E/R terminals 38 and 60
- through grounds E17 and E43.

**ILLUMINATION OPERATION BY LIGHTING SWITCH**

With lighting switch in the 1ST or 2ND position (or if auto light system is activated), BCM receives input signal requesting illumination lamps to illuminate. This input signal is communicated to IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls tail lamp relay coil, which, when energized, directs power

- through IPDM E/R terminal 22

# ILLUMINATION

---

- to combination meter terminal 10
- to glove box lamp terminal 1
- to A/T illumination terminal 1 (with A/T)
- to illumination control switch terminal 1
- to VDC off switch (illumination) terminal 3
- to hazard switch (illumination) terminal 3
- to heated seat switch (driver side) (illumination) terminal 5 (with heater seat)
- to heated seat switch (passenger side) (illumination) terminal 5 (with heater seat)
- to A/C and audio controller terminal 9
- to display and A/C auto amp. terminal 1
- to ashtray illumination and cigarette lighter socket illumination terminal 5
- to NAVI control unit (illumination) terminal 25 (with navigation system)
- to NAVI switch RH (illumination) terminal 2 (with navigation system)
- to snow mode switch (illumination) terminal 5 (AWD models)
- to audio unit terminal 8
- to upper glove box lamp terminal 1 (without navigation system)
- to trunk lid opener switch (illumination) terminal 3, and
- to combination switch (spiral cable) terminal 26
- through combination switch (spiral cable) terminal 18
- to ASCD steering switch illumination
- to steering wheel audio control switch illumination (with steering wheel audio control switch).

Ground is supplied at all times

- to combination meter terminal 9
- to NAVI switch terminal 3 (with navigation system)
- to VDC off switch (illumination) terminal 4
- to A/T illumination terminal 2 (with A/T)
- to hazard switch (illumination) terminal 4
- to display and A/C auto amp. terminal 21
- to A/C and audio controller terminal 10
- to heated seat switch (driver side) (illumination) terminal 6 (with heated seat)
- to heated seat switch (passenger side) (illumination) terminal 6 (with heated seat)
- to combination switch (spiral cable) terminals 21 and 27 (with steering wheel audio control switch)
- to snow mode switch (illumination) terminal 6 (AWD models)
- to audio unit terminal 7, and
- to trunk lid opener switch (illumination) terminal 4
- through illumination control switch terminal 2,
- to ashtray illumination and cigarette lighter socket illumination terminal 4
- to illumination control switch terminal 3
- to upper glove box lamp terminal 2 (without navigation system), and
- to glove box lamp terminal 2
- through grounds M30 and M66.

With power and ground supplied, illumination lamps illuminate.

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the lighting switch is in the 1ST or 2ND position (or if auto light system is activated), and ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, illumination lamps remain illuminated for 5 minutes, then illumination lamps are turned off.

When lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps are turned off by battery saver control, and illumination lamps illuminate again.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

---

## CAN Communication System Description

AKS009MS

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

AKS0093P

Refer to [LAN-21, "CAN Communication Unit"](#) .

A

B

C

D

E

F

G

H

I

J

LT


L

M

# ILLUMINATION

AKS009MT

## Schematic






TKWM2280E

# ILLUMINATION

## Wiring Diagram — ILL —

AKS009MU

LT-ILL-01



REFER TO THE FOLLOWING.



- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M1), (M2) -ELECTRICAL UNITS

TKWM2281E

# ILLUMINATION

LT-ILL-02

▬ : DATA LINE






REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)

TKWM2282E

# ILLUMINATION

LT-ILL-03






REFER TO THE FOLLOWING.

(M4) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM2283E

# ILLUMINATION

LT-ILL-04



REFER TO THE FOLLOWING.

(M4) - FUSE BLOCK-JUNCTION BOX (J/B)



TKWM2284E



# ILLUMINATION

LT-ILL-05

⬡ : WITH A/T




\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

TKWM2285E

# ILLUMINATION

LT-ILL-06



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

M31  
W



5	4	3	2	1		
12	11	10	9	8	7	6

M38  
W

10	8	4	2		
9	7	6	5	3	1

M40  
W



TKWM2286E



# ILLUMINATION

LT-ILL-08

AW : AWD MODELS  
 AC : WITH STEERING WHEEL AUDIO CONTROL SWITCH



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


TKWM2288E

# ILLUMINATION

LT-ILL-09

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

ON : WITHOUT NAVIGATION SYSTEM



TKWM2289E

---

## Removal and Installation GLOVE BOX LAMP

AKS009MV

Refer to [LT-166, "Bulb Replacement, Removal and Installation"](#) .

# BULB SPECIFICATIONS

## BULB SPECIFICATIONS

PFP:26297

### Headlamp

AKS000MP

Item	Wattage (W)
Low	35 (D2R)
High/Fog	60/55 (HB2)

### Exterior Lamp

AKS000MQ

Item	Wattage (W)
Front combination lamp	Turn signal/Parking lamp 21/5
Rear combination lamp	Stop/Tail lamp LED
	Turn signal lamp 21
	Back-up lamp 18
	Rear side marker lamp LED
Front side marker lamp	3.8
License plate lamp	5
High-mounted stop lamp (parcel shelf mount)	LED
High-mounted stop lamp (rear air spoiler mount)	LED

### Interior Lamp/Illumination

AKS000MR

Item	Wattage (W)
Glove box lamp	1.4
Ignition key hole illumination lamp	1.4
Ashtray illumination lamp	1.4
Cigarette lighter illumination lamp	0.8
Map lamp	8
Personal lamp	8
Step lamp	5
Trunk room lamp	3.4
Vanity mirror lamp	1.32

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# BULB SPECIFICATIONS

---