

FRONT AXLE & FRONT SUSPENSION

SECTION **FA**

CONTENTS

PRECAUTIONS AND PREPARATION	2	Third Link and Upper Link.....	17
Precautions.....	2	Tension Rod and Stabilizer Bar.....	19
Special Service Tools.....	3	Transverse Link and Lower Ball Joint.....	19
Commercial Service Tools	4	FULL-ACTIVE SUSPENSION	21
FRONT AXLE AND FRONT SUSPENSION	5	Outline	21
ON-VEHICLE SERVICE	6	On-vehicle Service.....	23
Front Axle and Front Suspension Parts.....	6	Repair of Component Parts	26
Front Wheel Bearing.....	9	TROUBLE DIAGNOSES FOR FULL-ACTIVE	
Front Wheel Alignment.....	9	SUSPENSION SYSTEM	49
FRONT AXLE	11	Contents.....	49
Wheel Hub and Steering Knuckle	11	SERVICE DATA AND SPECIFICATIONS (SDS)	111
FRONT SUSPENSION	15	General Specifications.....	111
Coil Spring and Shock Absorber	16	Inspection and Adjustment.....	112


Note: Refer to Foldout page for “FULL-ACTIVE SUSPENSION WIRING DIAGRAM”.

When you read wiring diagrams:

- Read GI section, “HOW TO READ WIRING DIAGRAMS”.
 - See EL section, “POWER SUPPLY ROUTING” for power distribution circuit.
- When you perform trouble diagnoses, read GI section, “HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES”.**

GI
MA
EM
LC
EF &
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PRECAUTIONS AND PREPARATION



Precautions









- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
* Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.

SPECIAL CAUTIONS FOR FULL-ACTIVE SUSPENSION

- Stopping the engine may cause the vehicle's height to change. Therefore, the following operations should not be performed for approximately 3 minutes after the engine has been stopped.
 - (1) Disconnecting battery cables
 - (2) Removing fuses
 - (3) Jacking up the vehicle
 - (4) Inserting your arm into the wheelhouse
- Make the best use of CONSULT, the electronic diagnostic tester, during system checks or part replacement.
- Control unit retains self-diagnostic results in memory. Before disconnecting battery terminals or fuse (No. 17) check the self-diagnostic results. Failure to do this may clear important data.
- Do not allow foreign matter to enter any part of active suspensions while removing or installing parts. Carefully observe the following instructions:
 - (1) Select an area that is clean and free from dust or dirt.
 - (2) Wash your hands and work with bare hands.
 - (3) Do not remove plugs (if so equipped) until parts are ready for immediate replacement.
- Pipes are always filled with highly pressurized oil (regardless of ON-OFF engine operation). Be sure to relieve pressure before removing parts.
- Do not get under vehicle or start engine when lifting vehicle with only a jack.
- Lift vehicle with all wheels off ground and place on rigid racks before working under vehicle.
- Use only genuine "Fluid A-Active Suspension" in active suspension system.
- Fill reservoir tank with specified amount of fluid. Do not overfill in the following cases, as this may cause fluid to overflow from reservoir tank:
 - (1) When oil pressure is relieved from hydraulic lines.
 - (2) Before using vehicle after an extended period of time.
- Be extremely careful when opening multivalve unit bypass valves or pressure control unit. Doing so, may cause vehicle height to decrease abruptly.
- Be extremely careful when loosening air vent bleeders on pressure control units and accumulators because of highly pressurized oil.
- Before disposing of main accumulator, pressure control units or actuators, closely observe instructions on caution labels. Ensure to completely discharge nitrogen gas from accumulators. Each pressure control unit is equipped with a return accumulator and each actuator, with a sub-accumulator.
- Before disposing of pump or pump accumulators, slowly loosen safety plugs to completely discharge nitrogen gas from accumulators. Each gas chamber is filled with oil. Place a cloth around safety plug to prevent oil from spouting out before loosening safety plug. Pump is equipped with a small accumulator.

PRECAUTIONS AND PREPARATION

Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description	
ST29020001 (J24319-01) Steering gear arm puller		Removing tie-rod ball joint and lower ball joint
HT71780000 (—) Spring compressor		Removing and installing coil spring
ST35652000 (—) Shock absorber attachment		Fixing shock absorber
ST30031000 (J22912-01) Bearing inner race puller		Removing bearing inner race
KV99104300 (—) Filler cap adapter		Evacuating pump line
KV991044S0 (—) Oil pressure gauge adapter		Measuring actuator oil pressure
KV991V0010 (—) Brake fluid pressure gauge (Two sets are required)		Measuring actuator oil pressure
EG17710000 (—) Check adapter		Measuring input and output signals of con- trol unit

GI

MA

EM

LC

EF &

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT











HA

EL

IDX

PRECAUTIONS AND PREPARATION


Commercial Service Tools

Tool name	Description
Wheel bearing drift	 <p>Removing wheel bearing</p> <p>a: 60 mm (2.36 in) dia. b: 37 mm (1.46 in) dia.</p>
Wheel bearing drift	 <p>Installing wheel bearing</p> <p>a: 75 mm (2.95 in) dia. b: 65 mm (2.56 in) dia.</p>
Baffle plate drift	 <p>Installing baffle plate</p> <p>a: 125 mm (4.92 in) dia. b: 106 mm (4.17 in) dia.</p>
Tension rod bushing drift	 <p>Removing and installing tension rod bushing</p> <p>a: 78 mm (3.07 in) dia. b: 66 mm (2.60 in) dia. c: 62 mm (2.44 in) dia. d: 25 - 55 mm (0.98 - 2.17 in) dia.</p>
Grease seal drift	 <p>Installing wheel hub grease seal</p> <p>a: 86 mm (3.39 in) dia. b: 76 mm (2.99 in) dia.</p>
Cap drift	 <p>Installing kingpin cap</p> <p>a: 60 mm (2.36 in) dia. b: 52 mm (2.05 in) dia.</p>
Bearing drift	 <p>Installing kingpin lower bearing</p> <p>a: 57 mm (2.24 in) dia. b: 50 mm (1.97 in) dia.</p>
Bearing drift	 <p>Installing kingpin upper bearing</p> <p>a: 57 mm (2.24 in) dia. b: 46 mm (1.81 in) dia. c: 40 mm (1.57 in) dia. d: 2.5 mm (0.098 in)</p>
Grease seal drift	 <p>Installing kingpin grease seal</p> <p>a: 68 mm (2.68 in) dia. b: 58 mm (2.28 in) dia.</p>
<p>① Flare nut crows foot</p> <p>② Torque wrench</p>	 <p>Removing and installing brake piping</p> <p>a: 10 mm (0.39 in)</p>

FRONT AXLE AND FRONT SUSPENSION

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

- * Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.



GI

MA

EM

LC

EF & EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


Front Axle and Front Suspension Parts

Check front axle and front suspension parts for looseness, cracks, wear or other damage.

- Retighten all nuts and bolts to the specified torque.

Tightening torque: Refer to FRONT SUSPENSION (FA-15).

- Make sure that cotter pin is inserted.



- Check wheelarch height from the ground.

Conventional suspension models

- (1) Vehicle must be unladen*, parked on a level surface, and tires checked for proper inflation and wear (tread wear indicator must not be showing).

* Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

- (2) Bounce the vehicle up and down several times before measuring.

Standard height:


Front (Hf)
705 mm (27.76 in)

Rear (Hr)
696 mm (27.40 in)

- (3) Spring height is not adjustable. If out of specification, check for worn springs or suspension parts.

Full-active suspension models

Refer to FULL-ACTIVE SUSPENSION — “VEHICLE HEIGHT ADJUSTMENT” in Repair of Component Parts (FA-34) and SDS (FA-111).



- Check shock absorber for oil leakage or other damage.
- Check suspension lower ball joint and tie-rod ball joint for grease leakage, and dust cover for cracks or other damage.

- Check upper link free play.

- (1) Jack up front of vehicle and set stands.

- (2) Set steering wheel in straight-forward direction and lock it using key lock.

- (3) Remove front wheels.

Models with FULL-ACTIVE SUSPENSION


On axle side

- (4) Install dial gauge.

- a. Install magnet stand on third link.


- b. Set dial gauge in position.

Set dial gauge spindle in contact with flat surface of upper link. Set at 140 mm (5.51 in) from center of upper link retaining bolt on the third link side. (Reset the dial gauge.)





ON-VEHICLE SERVICE

Front Axle and Front Suspension Parts (Cont'd)



- (5) Install lever and measure free play. Insert lever [25 mm (0.98 in) wide, 350 mm (13.78 in) long, approx.] into the hole on third link. While applying a load of 147 to 196 N (15 to 20 kg, 33 to 44 lb) to lever using push-pull gauge, read dial gauge indication.
- Free play = (Gauge pointer deflection when push-pull gauge is pulled) + (Gauge pointer deflection when push-pull gauge is pushed)

Allowable free play range:
5.0 mm (0.197 in), max.




On body side

- (6) Install dial gauge.
- Install magnet stand on hoodledge wheelhouse side.
 - Set dial gauge in position. Set dial gauge spindle in contact with flat surface of upper link. Set at 140 mm (5.51 in) from center of upper link retaining bolt on bracket side. (Reset the dial gauge.)

- (7) Follow the same procedures for setting lever and measuring free play as those outlined under "On axle side" above.

Allowable free play range:
5.0 mm (0.197 in), max.

- (8) If free play exceeds specifications, replace upper link assembly.




Models without FULL-ACTIVE SUSPENSION

On axle side

- (4) Install dial gauge.
- Install magnet stand on third link.
 - Set dial gauge in position. Set dial gauge spindle in contact with flat surface of upper link. Set at 140 mm (5.51 in) from center of upper link retaining bolt on the third link side. (Reset the dial gauge.)


ON-VEHICLE SERVICE

Front Axle and Front Suspension Parts (Cont'd)




- (5) Install lever.
Insert lever [30 mm (1.18 in) outside dia., 350 mm (13.78 in) long, approx.] between lower end of third link and kingpin location.

Make sure lever does not interfere with splash guard, brake hoses, etc., when set in position.



— Free play in direction “A” —


Attach spring scale to lever tip. Pull spring scale with a force of 147 to 196 N (15 to 20 kg, 33 to 44 lb) and then read dial gauge indication.




— Free play in direction “B” —

With dial gauge held in position, invert lever. Attach spring scale to lever tip. Pull spring scale with a force of 147 to 196 N (15 to 20 kg, 33 to 44 lb) and then read dial gauge indication.
Free play = (Gauge pointer deflection in direction “A”) + (Gauge pointer deflection in direction “B”)

**Allowable free play range:
5.0 mm (0.197 in), max.**




On body side



- (6) Install dial gauge.
- Install magnet stand on hoodledge wheelhouse side.
 - Set dial gauge in position.
Set dial gauge spindle in contact with flat surface of upper link. Set at 140 mm (5.51 in) from center of upper link retaining bolt on bracket side. (Reset the dial gauge.)
- (7) Follow the same procedures for setting lever and measuring free play as those outlined under “On axle side” above.
Allowable free play range: 5.0 mm (0.197 in), max.
- (8) If free play exceeds specifications, replace upper link assembly.

Front Axle and Front Suspension Parts (Cont'd)



- Check suspension ball joint end play.
- (1) Jack up front of vehicle and set the stands.
- (2) Clamp dial indicator onto transverse link and place indicator tip on lower edge of brake caliper.
- (3) Make sure front wheels are straight and brake pedal is depressed.
- (4) Place a pry bar between transverse link and inner rim of road wheel.
- (5) While pushing and releasing pry bar, observe maximum dial indicator value.
Vertical end play: 0 mm (0 in)
- (6) If not to above specification, remove and recheck it.

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX



Front Wheel Bearing

- Check wheel bearings for smooth operation.
- Check axial end play.
Axial end play: 0.05 mm (0.0020 in) or less
- If out of specification or wheel bearing does not turn smoothly, replace wheel bearing assembly. Refer to FRONT AXLE — Wheel Hub and Steering Knuckle (FA-11).



Front Wheel Alignment

Before checking front wheel alignment, be sure to make a preliminary inspection (Unladen*).

* "Unladen": Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

PRELIMINARY INSPECTION

Make the following checks. Adjust, repair or replace if necessary.

- Check tires for wear and improper inflation.
- Check front wheel bearings for looseness.
- Check wheel runout.
Wheel runout:
Refer to SDS (FA-112).
- Check front suspension for looseness.
- Check steering linkage for looseness.
- Check that front shock absorbers work properly.
- Check vehicle posture (Unladen).

ON-VEHICLE SERVICE

Front Wheel Alignment (Cont'd)

CAMBER, CASTER AND KINGPIN INCLINATION






Camber, caster and kingpin inclination are preset at factory and cannot be adjusted.

1. Measure camber, caster and kingpin inclination of both right and left wheels with a suitable alignment gauge.

Camber, Caster and Kingpin inclination:

Refer to SDS (FA-112).

2. If camber, caster or kingpin inclination is not within specification, inspect front suspension parts. Replace damaged or worn out parts.



TOE-IN

Measure toe-in using following procedure. If out of specification, inspect and replace any damaged or worn front suspension parts.

WARNING:

- Perform following procedure always on a flat surface.
- Make sure that no person is in front of the vehicle before pushing it.

1. Move rear of vehicle up and down to stabilize the posture.
2. Push the vehicle straight ahead about 5 m (196.9 in).
3. Put a mark on base line of the tread (rear side) at the same height of hub center to be a measuring point.
4. Measure distance "A" (rear side).
5. Push the vehicle slowly ahead to turn the wheels around 180 degrees.

If the wheels have passed 180 degrees, try the above procedure again from the beginning. Never push vehicle backward.

6. Measure distance "B" (front side).

Toe-in (A - B):

Refer to SDS (FA-112).

7. Adjust toe-in by varying length of steering tie-rods.
 - (1) Loosen lock nuts.
 - (2) Adjust toe-in by turning tie-rod forward or backward.

Make sure both tie-rods are the same length.

Standard length "L":

Refer to ST section

- (3) Tighten lock nuts to the specified torque.

Lock nut tightening torque:

Refer to ST section

FRONT WHEEL TURNING ANGLE


1. Set wheels in straight-ahead position. Then move vehicle forward until front wheels rest on turning radius gauge properly.
2. Rotate steering wheel fully to the right or left; measure turning angle.

Do not hold the steering wheel on full lock for more than 15 seconds.

Wheel turning angle (Full turn):

Refer to SDS (FA-112).

FRONT AXLE



Wheel Hub and Steering Knuckle

REMOVAL

CAUTION:

Wheel bearing usually does not require maintenance. If any of the following symptoms are noted, replace wheel bearing assembly.

- Growling noise is emitted from wheel bearing during operation.
- Wheel bearing drags or turns roughly when hub is turned by hand.

Before removing the front axle assembly, disconnect the ABS wheel sensor from the assembly. Then move it away from the front axle assembly area. Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.

- Remove brake caliper assembly and rotor.



Brake line need not be disconnected from brake caliper. In this case, suspend caliper assembly with wire so as not to stretch brake hose. Be careful not to depress brake pedal, or piston will pop out.

Make sure brake hose is not twisted.

- Remove tie-rod ball joint and lower ball joint with Tool.


CAUTION:

Steering knuckle is made from aluminum alloy. Be careful not to hit steering knuckle.




FRONT AXLE

Wheel Hub and Steering Knuckle (Cont'd)




- Remove kingpin lower nut then remove steering knuckle assembly.



INSTALLATION

- Install steering knuckle assembly.
- Apply anti-rust wax as follows:
 - Portions around lower ball joint connections
 - Portions around tie-rod ball joint connections
 - Portions around kingpin lower nut location
 - Portions around ABS sensor connection




DISASSEMBLY


CAUTION:

When removing wheel bearing from steering knuckle, replace wheel bearing assembly (outer race, inner races and grease seal) with a new one.

- Remove hub cap and wheel bearing lock nut.




- Remove wheel hub with a suitable tool.




- Remove circular clip with a suitable tool.

FRONT AXLE

Wheel Hub and Steering Knuckle (Cont'd)



- Press out wheel bearing assembly from steering knuckle.



- Drive out wheel bearing inner race (to outside) from wheel hub, then remove grease seal.


INSPECTION

Wheel hub and steering knuckle

Check wheel hub and steering knuckle for any cracks.

Circular clip

Check circular clip for wear or cracks.
Replace if necessary.



ASSEMBLY


1. Press new wheel bearing assembly into steering knuckle from outside of steering knuckle.

Maximum load P:

34.3 kN (3.5 ton, 3.9 US ton, 3.44 Imp ton)

CAUTION:

- Do not press inner race of wheel bearing assembly.
- Do not apply oil or grease to mating surfaces of wheel bearing outer race and wheel hub.



2. Install circular clip into groove of steering knuckle.

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

FRONT AXLE


Wheel Hub and Steering Knuckle (Cont'd)




3. Apply multi-purpose grease to sealing lip.
4. Install grease seal.
Maximum load P:
10 kN (1 ton, 1.1 US ton, 1.0 Imp ton)
5. Install baffle plate.



6. Press wheel hub into steering knuckle.
Maximum load P:
29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)
7. Tighten wheel bearing lock nut to the specified torque.
Torque: 206 - 284 N·m (21 - 29 kg-m, 152 - 210 ft-lb)
8. Check that wheel bearings operate smoothly.



9. Stake wheel bearing lock nut.




10. Install hub cap.
Drive hub cap onto steering knuckle by lightly tapping with a plastic hammer. After hub cap is in close contact with steering knuckle, tighten bolts.

FRONT SUSPENSION


When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

*: Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.



GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX


FRONT SUSPENSION



Coil Spring and Shock Absorber

REMOVAL

Remove shock absorber fixing nuts.
Do not remove piston rod lock nut.




DISASSEMBLY

1. Set shock absorber on vise with Tool, then loosen piston rod lock nut.

Do not remove piston rod lock nut.

2. Compress spring with Tool so that shock absorber mounting insulator can be turned by hand.



3. Remove piston rod lock nut.

INSPECTION

Shock absorber assembly


- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage occurring on welded or gland packing portions.
- Check piston rod for cracks, deformation or other damage. Replace if necessary.

Mounting insulator and rubber parts

Check cemented rubber-to-metal portion for separation or cracks. Check rubber parts for deterioration. Replace if necessary.

Coil spring

Check for cracks, deformation or other damage. Replace if necessary.



ASSEMBLY

- When installing coil spring, be careful not to reverse top and bottom direction. (Top end is flat.)
- When installing coil spring on shock absorber, it must be positioned as shown in figure at left.

Third Link and Upper Link

REMOVAL

CAUTION:

Kingpin bearing usually does not require maintenance. If any of the following symptoms are noted, replace kingpin bearing assembly.


- Growling noise is emitted from kingpin bearing during operation.
- Kingpin bearing drags or turns roughly when steering knuckle is turned by hand.

1. Remove cap and kingpin upper nut.

Do not remove kingpin lower nut.

2. Remove shock absorber fixing nut and upper link fixing bolts.

3. Remove third link and upper link.



SFA720A

INSTALLATION


Third link

- Pack kingpin housing and cap with multi-purpose grease.

Grease capacity:


Kingpin housing: 10 g (0.35 oz)

Cap: 5 g (0.18 oz)



SFA727A

- Install third link and cap.



SFA728A

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


FRONT SUSPENSION

Third Link and Upper Link (Cont'd)

Upper link

- Upper link has characters "A" and "L" (or "R") on it as shown. Always install upper link with "A" side facing axle and side without a character facing vehicle body.


Upper link bushings cannot be disassembled.




DISASSEMBLY

Third link


1. Remove upper bearing (inner race and ball).



2. Remove kingpin grease seal.
3. Remove lower bearing (inner race and ball).



4. Remove upper and lower outer race.
- Be careful not to damage kingpin housing.**




ASSEMBLY

1. Press new lower bearing into kingpin housing.


Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)



FRONT SUSPENSION


Third Link and Upper Link (Cont'd)



2. Press new upper bearing into kingpin housing.

Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)




3. Install grease seal.

Maximum load P:

10 kN (1 ton, 1.1 US ton, 1.0 Imp ton)


4. Apply multi-purpose grease to oil seal lip.



Tension Rod and Stabilizer Bar

REMOVAL AND INSTALLATION


- Remove tension rod and stabilizer bar.
 - When removing tension rod bushing, place one drift on lower side of bushing and the other on upper side, and press bushing out.
 - Place arrow mark on bushing facing tension rod before installing bushing.
-
- When installing stabilizer, make sure that paint mark and clamp face in the correct direction.



Transverse Link and Lower Ball Joint

REMOVAL AND INSTALLATION

- Disconnect tension rod, stabilizer connecting rod and knuckle. Then remove transverse link assembly.
- During installation, final tightening must be done at curb weight with tires on ground.
- After installation, check wheel alignment. Refer to "Front Wheel Alignment" of ON-VEHICLE SERVICE (FA-9).




FRONT SUSPENSION

Transverse Link and Lower Ball Joint (Cont'd) INSPECTION

Transverse link

- Check transverse link for damage, cracks or deformation. Replace it if necessary.
- Check rubber bushing for damage, cracks and deformation. Replace transverse link if necessary.



Lower ball joint

Check ball joint for play. Replace transverse link assembly if any of the following cases occur. Ball stud is worn, play in axial direction is excessive or joint is hard to swing.

Swing force, turning torque and vertical end play

Before checking, turn ball joint at least 10 revolutions so that ball joint is properly broken in.

Swing force "A":

(measuring point: cotter pin hole of ball stud)

7.8 - 53.0 N (0.8 - 5.4 kg, 1.8 - 11.9 lb)

Turning torque "B":

0.49 - 3.43 N·m (5.0 - 35 kg-cm, 4.3 - 30.4 in-lb)

Vertical end play limit "C":

0 mm (0 in)

FULL-ACTIVE SUSPENSION

Outline

SPECIFICATIONS

Item	Specifications	VH45DE		
		Front	Rear	
Suspension		Multilink, independent type		
Wheel alignment (unloaded)	Toe-in	mm (in)	-1 to 1 (-0.04 to 0.04)	0 - 4 (0 - 0.16)
	Camber	(deg)	-1°40' to -0°10'	-2°00' to -1°00'
	Caster	(deg)	6°10' - 7°40'	—
	Kingpin inclination	(deg)	12°10' - 13°40'	—
Coil spring	Spring constant	N/mm (kg/mm, lb/in)	17.7 (1.8, 101)	14.7 (1.5, 84)
	Free length	mm (in)	369 (14.53)	280 (11.02)
	Coil center diameter	mm (in)	120 (4.72)	120 (4.72)
	Wire diameter	mm (in)	12 (0.47)	11 (0.43)
	No. of active coils		5.8	4.0
Power cylinder	Cylinder inside diameter	mm (in)	60 (2.36)	60 (2.36)
	Stroke	mm (in)	145.1 (5.71)	158.6 (6.24)
Tension rod outside diameter	mm (in)	20 (0.79)	—	
Stabilizer outside diameter	mm (in)	28 (1.10) (Solid)	20 (0.79) (Hollow)	
Pump	Type	6 + 6 spool, radial plunger type (combined with select valve) (arranged with power steering vane pump in tandem)		
Recommended fluid	Name	Genuine "Fluid A-Active Suspension"		
	Approx. quantity	ℓ (US qt, Imp qt)	5.7 (6, 5)	
Oil cooler radiation	kW (kcal/h, BTU/h)	2.559 (2,200, 8,730)		
Oil cooler fan motor power consumption	(W)	35		

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


FULL-ACTIVE SUSPENSION


Outline (Cont'd)

FULL-ACTIVE SUSPENSION PARTS LOCATION





SYSTEM DIAGRAM





On-vehicle Service

CHECKING FLUID LEVEL

1. Put vehicle on level ground and set selector lever in "P".
2. Make sure that no passengers nor any cargo is in vehicle. Check that necessary equipment, such as spare tire, jack, on-board tools, are provided.
3. Confirm vehicle height selector switch is in "NORMAL".
4.  With CONSULT
 - a. Connect CONSULT.
 - b. Start engine.
 - c. Check oil temperature using CONSULT data monitor. Adjust oil temperature to $60 \pm 4^\circ\text{C}$ ($140 \pm 7.2^\circ\text{F}$) by racing engine.
4.  Without CONSULT
 - a. Start engine, and warm up to raise active suspension fluid temperature about 60°C (140°F).
 5. Remove reservoir level gauge, and make sure that level is in the proper range.
 - Level gauge is a screw type, and level should be checked with the level gauge fitted securely.
 - If level is too low, add specified fluid (genuine "Fluid A-Active Suspension") through filler. Add fluid until actual level is aligned with proper UPPER range mark.

CAUTION:

- Never use a non-specified brand of fluid.
- If level is too high, suck out until proper level is reached. Otherwise, fluid may overflow when releasing pressure.
- If fluid is spilled on nearby parts, be sure to wipe clean.
- If alarm lamp is ON indicating insufficient oil quantity, erase the CONSULT self-diagnosis result data.

CHANGING FLUID

Every 96,000 km (60,000 miles) of operation, change fluid (genuine "Fluid A-Active Suspension").


1. Make sure vehicle is located in clean area and free from foreign particles. Raise vehicle and support with a rigid jack.

Do not allow foreign particles to enter hydraulic system.

2. Open bypass valves of multivalve unit and pressure control unit. Doing so, refer to "RELIEVING PRESSURE, Repair of Components Parts" (FA-28).
3. Place a container under oil cooler to catch fluid. Disconnect rubber hose to multivalve unit (on lower side of oil cooler) and drain fluid into container.
4. Lower vehicle to ground. Reduce vehicle height and drain fluid from actuators as much as possible.
5. Raise vehicle again and reconnect rubber hose to its original position.

Discard old hose clamp; replace it with a new one.

6. Close multivalve unit bypass valve and pressure control unit bypass valves.
7. Refer to "WORK PROCEDURES BY UNIT of Repair of Component Parts" (FA-26), then start with evacuating hydraulic lines.



FULL-ACTIVE SUSPENSION



On-vehicle Service (Cont'd)

CHECKING FLUID LEAKAGE

Oil leak check

Genuine "Fluid A-Active Suspension" is clear and light yellow-green when it is new. After use, it will turn to light yellow. After locating leaking point using table below as a guide, wipe away oil completely. Check that oil leaks at the same point again. Do not confuse "Fluid A-Active Suspension" oil used in other systems.

Location where oil leaks can occur	Fluid used near the same locations in systems other than active suspension system	Remarks
Inside front right fender protector	LLC (green), washer fluid (no color or blue)	—
Inside front left fender protector	—	If oil spills while replenishing reservoir tank fluid, it will flow out via oil cooler. Do not regard this as a leak of the oil cooler.
Inside undercover	LLC (green), power steering fluid (red), automatic transmission fluid (red), brake fluid (red), engine oil, etc.	Spilled oil may come in contact with front and/or rear of cover due to piping layout, unit locations, etc.
Inside wheelhouse	Brake fluid (red)	Oil may possibly leak at or around actuator, and hose and tube connections.
Inside rear pressure control unit protector	—	—
Inside pipe protector	—	Protector on outer side of left side member
Rear suspension member upper portion	Brake fluid (red), gasoline, etc.	—



Corrective measures for oil leaks

























When repairing oil leaks, or when removing piping or hydraulic parts, refer to "Repair of Component Parts" (FA-26). Perform required work associated with leak repair if instructed.

- Leaks at pipe connections
Refer to "Corrective measures for leaks at pipe connections" (FA-25).
- Leaks at pressure detection ports
 - Make sure cock is tightened to specified torque.
 - Discard copper washer under blind bolt; replace it with a new one.
 - If leakage is still present, replace faulty detection port.
- Leaks at air bleeder
 - Make sure that air bleeder is tightened to specified torque.
 - If retightening air bleeder does not eliminate leaks, replace affected unit with a new one.
- Leaks at other parts
Replace affected unit with a new one.

FULL-ACTIVE SUSPENSION

On-vehicle Service (Cont'd)

Corrective measures for leaks at pipe connections

No.	Parts to check	External shape and tightening torque N·m (kg·m, ft·lb)	Internal construction	Remedy
1	Flare nut	 <p>Pipe diameter 10 mm (0.39 in) 4.76 mm (0.1874 in)</p> <p>39 - 49 (4 - 5, 29 - 36) 15 - 18 (1.5 - 1.8, 11 - 13)</p>		
2	"I" joint (large)	 <p>49 - 69 (5 - 7, 36 - 51)</p>		
3	"I" joint (small)	 <p>49 - 69 (5 - 7, 36 - 51)</p>		
4	Flange joint (large)	 <p>15 - 18 (1.5 - 1.8, 11 - 13)</p>		
5	Flange joint (small)	 <p>15 - 18 (1.5 - 1.8, 11 - 13)</p>		
6	Hose clamp (spring)			
7	Hose clamp (screw)			
8	Copper washer "I" joint	 <p>28 - 34 (2.9 - 3.5, 21 - 25)</p>		

(1) *: Refers to items that require air bleeding.

(2) Refer to "Repair of Component Parts" for pressure relieving and air bleeding procedures.

FULL-ACTIVE SUSPENSION

Repair of Component Parts

WORK PROCEDURES BY UNIT

Removal and installation work of hydraulic parts differs due to difference in pressure application method and air bleeding procedures. This section deals with work associated with removal or installation of hydraulic parts.

Choose associated work from table below. Also use "Basic work flowchart" as a guideline. Perform only required work.

Work associated with, and classified by, each unit

○: Work necessary, X: Work not necessary

Unit to remove or install		Associated work						
		Relieving pressure	Evacuating hydraulic line	Flushing (dust removal, etc.)	Air bleeding			Vehicle height adjustment
					Pressure control unit	Actuator	Multivalve unit	
Reservoir tank		X	○	X	○	○	○	X
Pump		○	○	X	○	○	○	X
Pump accumulator		○	X	X	○	○	○	X
Multivalve unit		○	X	○	○	○	○	X
Main accumulator		○	X	○	○	○	○	X
Pressure control unit		○	X	○	○	○	○	○
Actuator		○	X	X	○	○	○	○
Drain filter		X	X	X	○	○	○	X
Oil cooler		X	X	X	○	○	○	X
Piping	Reservoir tank to pump	X	○	X	○	○	○	X
	Pump to multivalve unit	○	X	△*2	○	○	○	X
	Multivalve to pressure control unit	○	X	○	○	○	○	X
	Pressure control unit to actuator*1	○	X	△*2	○	○	○	X
	Drain pipe	△*2	X	△*2	X	△*2	X	X
Oil replacement		○	○	○	○	○	○	○


*1: Work includes pressure detection port servicing and associated piping.

*2: Except for concentrated piping units, associated work is not necessary.

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

Basic work flowchart



FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

RELIEVING PRESSURE

Before relieving pressure from hydraulic parts, carefully read "Service Notice" and familiarize yourself with its contents.

- Move vehicle to lift-up position and stop engine. Wait for at least 3 minutes before lifting vehicle.
- Lift vehicle until all four wheels are completely off the ground.
- Remove left and right fender protectors and rear pressure control unit protectors.
- Loosen lock nuts on bypass valve for front and rear pressure control units. Slowly open bypass valve until they are fully open.

Always use a closed wrench to prevent slippage when loosening lock nuts [6 mm (0.24 in) across flats].

- Loosen lock nut bypass valve on multivalve unit, and slowly tighten cock until it is fully open.

CAUTION:


Multivalve unit bypass valve is opened when tightened.

- After replacing parts or flushing hydraulic lines, close all three bypass valves securely.






Bypass valve:

: 11 - 13 N·m (1.1 - 1.3 kg·m, 8 - 9 ft·lb)

Lock nut:

: 11 - 13 N·m (1.1 - 1.3 kg·m, 8 - 9 ft·lb)

(Loosen Multivalve unit bypass valve completely.)



EVACUATING HYDRAULIC LINES

After pump, etc., is replaced, air may enter line between reservoir tank and pump, which in turn degrades oil discharge efficiency. To evacuate hydraulic line, proceed as follows:

- After parts are replaced, make sure all pipe connections are tight and secure.
- Make sure oil level in reservoir tank is correct.
- Install oil level gauge securely.
- Remove filler cap from reservoir tank and install a filler cap adapter instead.
- Connect vacuum pump (used for air conditioning system) and vacuum hose to filler cap adapter, and evacuate for at least two minutes.

If possible, use a gauge manifold to check for complete evacuation.


FLUSHING

Flushing is performed to forcefully remove foreign particles from oil lines after hydraulic parts are replaced. Bypass valves are fully opened to permit circulation of oil through entire circuit system. Therefore, foreign particles are removed from oil by filters of reservoir tank, multivalve unit and pressure control units.


FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)


- Turn ignition switch "OFF" and connect CONSULT.
- Check oil level in reservoir tank.
- Lift vehicle. Completely open front and rear pressure control unit bypass valves, as well as multivalve unit bypass valve. (Make sure multivalve unit bypass valve is tightened to open.)
- Lower vehicle until wheels are slightly off ground.
- Turn ignition switch "ON". Touch "START", "ACTIV SUS", "WORK SUPPORT", and "HYDRAULIC SYSTEM" on CONSULT display in that order.




- When display shows "1. FILLING OIL", touch "NEXT" so that display shows "2. FLUSHING" image.
- Touch "START" and wait until flush setting is completed.



- Start engine. Idle for five minutes to execute flushing. **While flushing, both flow control and fail-safe valves are held open and control pressure is held at 4,609 kPa (47 kg/cm², 668 psi) (neutral pressure).**
- After flushing is completed, stop engine.



- Turn ignition switch "ON". (Do not start engine.) Touch "NEXT" on CONSULT display. When display shows "3. CHANGEOVER OF BYPASS VALVE", touch "START".



- After flush setting is completed, lift vehicle.
- Tighten both bypass valves of front pressure and rear pressure control unit to specified torque, then secure with lock nuts.
- Completely loosen multivalve unit bypass valve and secure with lock nut.

: Bypass valve 11 - 13 N·m (1.1 - 1.3 kg·m, 8 - 9 ft·lb)

: Lock nut 11 - 13 N·m (1.1 - 1.3 kg·m, 8 - 9 ft·lb)

Always use a box wrench to prevent slippage when loosening bypass valve [6 mm (0.24 in) across flats].

- Lower vehicle until wheels are slightly off ground.

Repair of Component Parts (Cont'd)



AIR BLEEDING

Air bleeding discharges air trapped in oil in hydraulic lines during part replacement. Bleeding air from oil and oil lines is accomplished by directing, pulsating oil under pressure. Doing so, forces all air in line to accumulate at the actuator's upper section. It is then discharged into atmosphere through air bleeder located on actuator. When front or rear pressure control unit is replaced, bleed air from its interior.

- Lift vehicle until wheels are at least 50 mm (1.97 in) above ground. Start engine and idle it for approximately two minutes.
- With CONSULT set to "WORK SUPPORT" mode, call up "4. AIR BLEEDING" on display.

When "NEXT" is touched, followed by changeover of bypass valve operations, display will show "4. AIR BLEEDING".


- Check oil level in reservoir tank and add oil so that it is slightly higher than specified level.



- Touch "START" on CONSULT display. Display will then show control pattern shown in figure at left and air bleed vibration will be executed.

While air bleed vibration is being executed, both flow control and fail-safe valves are held open.


- After making sure air bleed vibration is completed on display, stop engine.




Bleeding air from actuators

- Connect vinyl tube to air bleeder of actuator requiring air bleeding.
- Slowly loosen air bleeder, drain oil until air bubbles disappear. Tighten air bleeder.
- **While bleeding air, check oil level in reservoir tank occasionally, and add oil as needed.**
- **Be careful not to spill oil on adjacent body parts.**

Air bleeder:

 **6 - 8 N·m (0.6 - 0.8 kg-m, 4.3 - 5.8 ft-lb)**

- If air is not completely bled from actuator, repeat air bleed vibration operation.



FULL-ACTIVE SUSPENSION




Repair of Component Parts (Cont'd)

Bleeding air from pressure control units

Bleed air from pressure control unit using same procedures as with actuators in the following cases:

- When noise is persistently produced.
- After any pressure control unit is replaced.

Each pressure control unit is provided with two air bleeders. Bleed air from both bleeders.



Bleeding air from multivalve unit

- (1) Race engine, or drive vehicle until oil temperature rises to 60 to 70°C (140 to 158°F) (or, more specifically, until full-active suspension oil cooler motor fan operates).
- (2) Connect CONSULT, and perform "4-wheel vibration" mode of work support to allow oil to be circulated through system.
- (3) Sudden rise in oil pressure is required for testing. For this purpose, start engine with accelerator pedal depressed. Increase engine speed to approx. 4,000 rpm, and maintain this speed for 20 seconds. Stop engine, and leave as is for 3 minutes.
- (4) Repeat step (3) above five to six times.
- (5) If noise is still heard after completing these operations, leave vehicle for more than 30 minutes. Then perform steps (1) thru (4) again.

OIL LEAK CHECK

Neutral pressure leak check

- Start engine and idle it for approximately 2 minutes.
- Set CONSULT to "WORK SUPPORT" mode and call up "5. PRESSURE LEAK CHECK 1" on CONSULT display.

When "NEXT" is touched, followed by air bleeding operations, display will show "5. PRESSURE LEAK CHECK 1".

- Touch "START" to control actuator oil pressure at 4,609 kPa (47 kg/cm², 668 psi).

While neutral pressure leak check is being executed, both flow control and fail-safe valves are held open.

- Ensure that neutral pressure control is completed on display. Then, lift vehicle and hold it for at least 3 minutes.
- Check that leaks are not present at pipes and connections. Lower vehicle so that wheels are approximately 50 mm (1.97 in) above ground.

GI

MA

EM

LC

EF & EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

High pressure leak check

- After completing neutral pressure leak checks, touch "NEXT" on CONSULT display. Display will then show "6. PRESSURE LEAK CHECK 2".
- Touch "START" on display. Actuator oil pressure is then controlled at 9,807 kPa (100 kg/cm², 422 psi) rather than at 4,609 kPa (47 kg/cm², 668 psi).

While high pressure leak check is being executed, both flow control and fail-safe valves are held open.

- After making sure high pressure leak check is completed on display, lift vehicle for at least three minutes.
- Check that leaks are not present at piping and connections. Lower vehicle so that wheels are still at least 50 mm (1.97 in) above ground.

Return line leak check

- After completing high pressure leak checks, touch "NEXT" on CONSULT display. Display now shows "7. PRESSURE LEAK CHECK 3".
- Touch "START" to control actuator oil pressure at 4,609 kPa (47 kg/cm², 668 psi) rather than at 9,807 kPa (100 kg/cm², 1,422 psi).

While return line leak check is being executed, both flow control and fail-safe valves are held open.

- After making sure return line leak check is completed on display, lift vehicle for at least three minutes.
- Check that leaks are not present at piping and connections.

PROTECTOR INSTALLATION

- Touch "NEXT" on CONSULT display. Display now shows "8. PROTECTOR INSTALL".
- Touch "START" to control actuator oil pressure at 0 kPa (0 kg/cm², 0 psi) and to open fail-safe valve.
- After making sure display is set to protector installation mode, stop engine.
- Re-install parts (fender protectors, undercover, etc.).






OIL LEVEL CHECK

1. Lower vehicle onto flat floor.
2. Start engine. Touch "NEXT" on CONSULT display. Display will then show "9. OIL LEVEL CHECK".
3. Press "END" to exit from the work support mode.

Note: The Consult does not support the inspection (oil level check) in this mode.

The work instruction is displayed on the Consult screen. Perform this operation (oil level check) after exiting the work support mode by touching "END".

4. For oil level check refer to FA-23.



FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

SYSTEM OPERATION CHECK

The system operation check is to check for proper active suspension system operation. The active suspension system has three functions:

- (1) A function that changes control pressure for all four wheels at the same time.
- (2) A function that changes it for any one wheel.
- (3) A function that activates the fail-safe valve.

Extreme care should be taken when conducting system operation checks since the vehicle moves up and down greatly.

All wheel vibration check

- Restart work support and skip to No. 10.

CAUTION:

Before conducting all wheel vibration check, make sure vehicle is placed on a flat surface with engine idling.

- Make sure there are no obstacles which may hamper the up-down vehicle movement.
- Release parking brakes to eliminate friction which may occur during vehicle height changes.

Make sure selector lever is set to "P" and foot brake is released.

- Touch "START" on CONSULT display. Display will then show control pattern as shown in diagram and all four wheels will vibrate simultaneously.

While all wheels are being vibrated, both flow control and fail-safe valves are held open.

- Make sure vehicle moves up and down smoothly without noise and vibration.
- After making sure wheel vibration control has been completed.

Single wheel vibration check

- Select either "11. VIBRATE F/R WHEEL" through "14. VIBRATE R/L WHEEL" shown on CONSULT display. Then, only selected wheel will be vibrated in a pattern similar to all wheels vibration control pattern.





Fail-safe function check

- Check that wheel vibration checks have been completed while observing CONSULT display.
- Call up "15. FAIL-SAFE FUNCTION" mode on CONSULT display.

Make sure engine is idling with vehicle on a flat surface.

- Make sure there are no obstacles that interfere with vehicle roll.
- Release parking brakes to remove friction which may occur while vehicle height changes.

Make sure selector lever is set to "P" and foot brake is released.



GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)


- Touch "START" on CONSULT display. Control pattern shown in figure at left will then appear, and each wheel and fail-safe valve is controlled.

Flow control valve is held "open" during fail-safe function checks.

- Make sure vehicle rolls to right or left and quickly returns to level position after fail-safe valve is closed.

A sound is heard when fail-safe valve is opened or closed. This is normal.

- After completing fail-safe function checks, touch "END" on CONSULT display.



VEHICLE HEIGHT ADJUSTMENT

Front wheelarch height adjustment

- Set CONSULT to work support mode. Touch "VEHICLE HEIGHT ADJ." so that "1. FRONT WHL HEIGHT ADJ." appears on CONSULT display.

Ensure the followings:

1. engine is idling,
2. selector lever is set to "P",
3. parking brake is "OFF",
4. foot brake is "OFF", and
5. vehicle is on a level surface.

- Touch "START" on CONSULT display and wait until CONSULT is ready for front wheel height adjustment.
- Set height control switch (located on center console) from "N" (Normal) to "H" (High) and then return to "N".
- Move vehicle 2 to 3 meters (7 to 10 ft) back and forth so that it settles down.



Ensure the followings:

1. engine is idling,
2. selector lever is set to "P",
3. parking brake is "OFF", and
4. foot brake is "OFF".





- Measure distance "A" between center of one front wheel and lower end of fender molding. Similarly measure distance for the other front wheel. Determine distance difference between both measured values.

During front height adjustment, front wheels are controlled in response to output value sent from vehicle height sensors. Also, rear wheels are held at neutral pressure of 4,609 kPa (47 kg/cm², 668 psi).

- Compare measured distances "A" with specifications indicated below. If any distance is outside specifications, loosen bolts on affected vehicle height sensor. Then rotate height sensor to adjust vehicle height.



Repair of Component Parts (Cont'd)



Specifications:

Distance "A"

374 - 394 mm (14.72 - 15.51 in)

Distance difference between left and right front wheels

10 mm (0.39 in) or less

- Turning left vehicle height sensor counterclockwise (when viewed from front side) by 1 graduation (5°) increases vehicle height 14 mm (0.55 in); Turning right vehicle height sensor 1 graduation clockwise increases vehicle height 14 mm (0.55 in).
- After height adjustment, tighten height sensor bolts to specified torque [5 to 7 N·m (0.5 to 0.7 kg-m, 3.6 to 5.1 ft-lb)].

Rear wheel height adjustment

- Touch "NEXT" so that "2. REAR WHL HEIGHT ADJ." appears on CONSULT display.

Ensure the followings:

1. engine is idling,
2. selector lever is set to "P",
3. parking brake is "OFF",
4. foot brake is "OFF", and
5. wheel is on a flat surface.

- Touch "START" on CONSULT display and wait until CONSULT is ready for rear wheel height adjustment.
- Measure distance "B" between center of one rear wheel and lower end of fender molding. Similarly measure distance for the other rear wheel. Determine difference between both measured values.

Make sure front wheels are held at a neutral pressure of 4,609 kPa (47 kg/cm², 668 psi) during rear vehicle height adjustment. Rear wheels are controlled in response to output value of vehicle height sensors.

- Compare measured distance "B" with specifications indicated below. If any "B" distances are outside of specifications, adjust vehicle height.

Specifications:

Distance "B"

351 - 371 mm (13.82 - 14.61 in)

Difference between left and right rear wheels


10 mm (0.39 in) or less

- Measure distance ℓ between stopper nuts seating surfaces.
- Turning connecting rod adjuster one complete rotation (1 pitch = 1.6 mm) causes vehicle height to increase by 7.5 mm (0.295 in).
- After adjusting connecting rod length, tighten stopper nut to specified torque [3 to 4 N·m (0.3 to 0.4 kg-m, 2.2 to 2.9 ft-lb)].
- Touch "END" on CONSULT display and stop engine.

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd) COMPONENT PART TIGHTENING TORQUE

Removal and installation of multivalve unit and oil cooler




- | | | |
|-----------------------------------|----------------------------|----------------------------|
| ① Multivalve unit | ⑦ Oil cooler side bracket | ⑬ Clip |
| ② Multivalve unit bracket | ⑧ Oil cooler lower bracket | ⑭ Oil cooler duct |
| ③ Front side member closing plate | ⑨ Insulator collar | ⑮ Bumper finisher |
| ④ Bolt plate | ⑩ Insulator | ⑯ Oil cooler upper bracket |
| ⑤ Lower hoodledge | ⑪ Oil cooler shroud | ⑰ Drain filter |
| ⑥ Connector bracket | ⑫ Oil cooler | |

- Before removing oil cooler or multivalve unit, remove left and right front turn signal lamps and bumper finishers. Oil cooler or multivalve unit is now accessible for removal.
- Before removing or installing multivalve unit, make sure oil cooler is removed first.

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

Removal and installation of front pressure control unit and front main accumulator



- | | | |
|---|---|------------------------------------|
| ① Front pressure control unit | ⑥ Front main accumulator | ⑪ Front unit return tube |
| ② Front main accumulator high pressure hose | ⑦ Insulator | ⑫ Front cross tube & hose set |
| ③ Pressure detection tube | ⑧ Insulator collar | ⑬ Mark (white) |
| ④ Front unit feed tube | ⑨ Pressure detection connector | ⑭ Front unit left tube |
| ⑤ Front pressure control unit bracket | ⑩ Front pressure control unit inner bracket | ⑮ Mark (blue) |
| | | ⑯ Front right actuator tube & hose |

— Removal and installation of front pressure control unit —

- Before removing or installing front pressure control unit, remove left and right front turn signal lamps bumper finishers and TCS pump. (Refer to "Removal and Installation of TCS Actuator" in BR section.) Front pressure control unit will then be accessible.
- Before discarding front pressure control unit, drill holes in return accumulator to completely discharge nitrogen gas. Make sure to follow the instruction on caution label. Caution label is located on return accumulator of front pressure control unit.


FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

— Disposal of front main accumulator —

Before discarding front main accumulator, drill holes in it to completely discharge nitrogen gas. Make sure to follow the instruction on caution label on main accumulator.

Removal and installation of pump, pump accumulator, reservoir tank and piping (in engine compartment)



- | | | |
|-------------------------------|-------------------------------|------------------------------------|
| ① Pump accumulator | ⑨ Valve mount outer insulator | ⑯ Reservoir tank |
| ② Accumulator mount insulator | ⑩ Insulator collar | ⑰ Upper hoodledge |
| ③ Pump's high pressure hose | ⑪ Left tension rod bracket | ⑱ Suction hose |
| ④ Front pressure control unit | ⑫ Multivalve unit | ⑲ To power steering bracket |
| ⑤ Side member | ⑬ Pump | ⑳ To strut housing |
| ⑥ Valve mount inner insulator | ⑭ Lower hoodledge | ㉑ Front left actuator tube & hose |
| ⑦ Tube bracket | ⑮ Tank return hose | ㉒ Front right actuator tube & hose |
| ⑧ Right tension rod bracket | | |


FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)



— Pump removal and installation —

- Before removing pump, remove pump pulley and proceed as follows:
 - (1) Insert screwdriver in pulley hole (to prevent pulley from turning), and loosen pulley nut.
 - (2) Remove pulley.
 - (3) Remove pump.
- Tighten pulley nut to specified torque after installing pulley. Be sure to install pulley key.

Pulley nut:

: 88 - 98 N-m (9.0 - 10.0 kg-m, 65 - 72 ft-lb)

- Before discarding pump, slowly loosen safety plug on accumulator (a part of pump) to discharge nitrogen gas and then loosen it completely.



— Disposal of pump accumulator —

Before disposing of pump accumulator, slowly loosen safety plug to discharge nitrogen gas and then loosen it completely.

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

Removal and installation of rear pressure control unit and rear main accumulator



- ① Control unit bracket C
- ② Control unit bracket A
- ③ Accumulator bracket C
- ④ Rear main accumulator
- ⑤ Accumulator bracket A
- ⑥ Insulator
- ⑦ Insulator collar

- ⑧ Clip
- ⑨ Control unit protector stay
- ⑩ Control unit protector
- ⑪ Accumulator bracket B
- ⑫ Insulator collar
- ⑬ Mount outer insulator

- ⑭ Mount inner insulator
- ⑮ Rear pressure control unit
- ⑯ Control unit bracket D
- ⑰ Control unit bracket B
- ⑱ Control unit bracket E
- ⑲ Side member

— Disposal of rear pressure control unit —

Before discarding rear pressure control unit, drill holes in accumulator to completely discharge nitrogen gas. Make sure to follow the instruction on caution label. Caution label is located on return accumulator of pressure control unit.


— Disposal of rear main accumulator —

Before discarding rear main accumulator, drill holes in accumulator to completely discharge nitrogen gas. Make sure to follow the instruction on accumulator caution label.

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

Removal and installation of underfloor piping




- | | | |
|-------------------------------------|-------------------------------|------------------------------------|
| ① Drain tube bracket | ⑩ Rear right actuator tube | ⑲ Drain tube bracket |
| ② Front right suspension drain tube | ⑪ Drain tube bracket | ⑳ Rear left suspension drain tube |
| ③ Front left suspension drain tube | ⑫ Rear floor tube assembly | ㉑ Rear right suspension drain tube |
| ④ Drain tube bracket | ⑬ Tube bracket | ㉒ Pressure detection tube C |
| ⑤ Drain tube connector | ⑭ Front floor tube assembly | ㉓ Rear pressure control unit |
| ⑥ Multivalve unit | ⑮ Front floor tube protector | ㉔ Rear unit connecting tube |
| ⑦ Front floor tube assembly | ⑯ Clip | ㉕ Pressure detection tube B |
| ⑧ Front left tube protector | ⑰ Rear floor tube protector | |
| ⑨ Rear right tube protector | ⑱ Rear right floor drain tube | |

GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd) Removal and installation of front actuator

Figure shows front left actuator assembly.



- | | | |
|----------------------|--------------------------|---------------------|
| ① Air filter | ④ Insulator cap seat | ⑦ Drain hose gasket |
| ② Insulator cap clip | ⑤ Actuator assembly | ⑧ Front drain hose |
| ③ Nut | ⑥ Drain hose lock spring | |

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

— Removal and installation of actuator assembly —

CAUTION:

Before removing the front actuator assembly, disconnect the vehicle height sensor from the assembly. Failure to do so may result in damaging the vehicle height sensor becoming inoperative.

1. Removal

- Except for pipes, use same removal procedures outlined for vehicles which are not equipped with active suspensions. To facilitate disassembly of actuator assembly, loosen joint adapter first:

- (1) Disconnect flange joint from upper side of actuator.
- (2) Install two dummy bolts [approximately 15 mm (0.59 in) thread size] in bolt holes used to connect joint adapter flange joint.

- Do not use flange joint bolts in place of dummy bolts.
- Do not allow foreign particles to enter oil hole in center of joint adapter.

- (3) Attach suitable rod (e.g., ratchet handle) to dummy bolt, and loosen joint adapter.



Loosen joint adapter just enough so that it can be easily removed after removing actuator assembly.

2. Installation

Install actuator assembly and tighten joint adapter to specified torque.

CAUTION:

Make sure dust boot is not twisted or deformed.



GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)


Disassembly and reassembly of front actuator

Figure shows front left actuator.



SFA008B

- | | | |
|---------------------|-----------------------------|-----------------------------|
| ① Joint adapter | ⑤ Rebound insulator stopper | ⑨ Front actuator dust cover |
| ② Wave washer | ⑥ Mount insulator | ⑩ Bound bumper |
| ③ Spool lock washer | ⑦ Coil spring | ⑪ Front actuator |
| ④ Insulator spacer | ⑧ Bumper rubber seat | |




SFA009B

— Disassembly and reassembly of actuator assembly —

1. Disassembly
 - Scribe alignment marks on actuator, coil spring and mount insulator before disassembling.

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)



- Compress coil spring using Tool.
 - Loosen joint adapter and disassemble actuator assembly.
2. Reassembly


Reassemble all parts by aligning alignment marks.

— Disposal of front actuator —

Before discarding actuator, drill holes in accumulator to completely discharge nitrogen gas. Make sure to follow the instruction on caution label on sub-accumulator (a part of actuator).

Removal and installation of rear actuator

Figure shows rear left actuator assembly.



- ① Rear joint hose protector bracket
- ② Tube bracket
- ③ Plug

- ④ Air tube
- ⑤ Rear joint hose protector
- ⑥ Rear actuator lower pin
- ⑦ Clip

- ⑧ Rear drain hose
- ⑨ Drain hose gasket
- ⑩ Actuator mount seal

CAUTION:


Before removing the rear actuator assembly, disconnect the vehicle height sensor from the assembly. Failure to do so may result in damaging the vehicle height sensor becoming inoperative.

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

Disassembly of rear actuator

Figure shows rear left actuator.



- ① Mount insulator
- ② Rear joint hose
- ③ Spring upper seat

- ④ Air tube connector
- ⑤ Bound bumper cover
- ⑥ Rear actuator dust cover

- ⑦ Coil spring
- ⑧ Bound bumper
- ⑨ Rear actuator

— Removal and installation of coil spring —

Use same procedures outlined for vehicles which are not equipped with active suspensions.


— Installation and disposal of rear actuator —

- Be careful not to twist or deform dust boot when installing actuator assembly.
- Before discarding actuator, drill holes in accumulator to completely discharge nitrogen gas. Make sure to follow the instruction on caution label on sub-accumulator (a part of actuator).

FULL-ACTIVE SUSPENSION

Repair of Component Parts (Cont'd)

Removal and installation of vehicle height sensor



GI

MA

EW

LC

EF & EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

KA

EL

IDX

NOTE

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Contents


How to Perform Diagnoses for Quick and Accurate Repair	FA- 50	
Symptom Chart	FA- 52	
Preliminary Check	FA- 56	
Diagnosis by CONSULT	FA- 56	GI
Component Parts and Harness Connector Locations	FA- 57	
Circuit Diagram for Quick Pinpoint Check	FA- 59	
Electrical System Diagnostic Procedures	FA- 60	MA
Items to Be Controlled in Relation to Abnormalities	FA- 62	
Self-diagnosis	FA- 64	
SELF-DIAGNOSTIC PROCEDURES	FA- 64	EM
FAIL-SAFE FUNCTION	FA- 67	
CAR SPEED SENSOR 1 (METER) CIRCUIT CHECK	FA- 68	LC
CAR SPEED SENSOR 2 (A/T) CIRCUIT CHECK	FA- 68	
FORE AND AFT G SENSOR CIRCUIT CHECK	FA- 69	
LATERAL G SENSOR 1-2 CIRCUIT CHECK	FA- 70	EF & EC
LATERAL G SENSOR 1 (OR 2) CIRCUIT CHECK	FA- 71	
VERTICAL G SENSOR CIRCUIT CHECK	FA- 72	
HEIGHT SENSOR CIRCUIT CHECK	FA- 73	FE
HEIGHT CONTROL SWITCH CIRCUIT CHECK	FA- 75	
HEIGHT SENSOR POWER SUPPLY CIRCUIT CHECK	FA- 76	
PRESSURE CONTROL VALVE CIRCUIT CHECK	FA- 76	AT
FLOW CONTROL VALVE CIRCUIT CHECK	FA- 77	
FAIL-SAFE VALVE CIRCUIT CHECK	FA- 77	
PUMP SOLENOID CIRCUIT CHECK	FA- 78	PD
OIL TEMPERATURE SENSOR CIRCUIT CHECK	FA- 78	
OIL WARNING CIRCUIT CHECK	FA- 79	FA
IGNITION POWER SUPPLY CIRCUIT CHECK	FA- 79	
ENGINE STALL WARNING CIRCUIT CHECK	FA- 80	
G SENSOR POWER SUPPLY CIRCUIT CHECK	FA- 80	RA
Diagnostic Procedure 1		
SYMPTOM: No warning lamp comes on when ignition switch is turned "ON".	FA- 81	
Diagnostic Procedure 2		
SYMPTOM: System is not set in self-diagnosis mode.	FA- 82	BR
Diagnostic Procedure 3		
SYMPTOM: Abnormalities when starting engine	FA- 83	ST
Diagnostic Procedure 4		
SYMPTOM: Abnormalities when stopping engine	FA- 86	RS
Diagnostic Procedure 5		
SYMPTOM: Abnormalities in vehicle height control	FA- 86	
Diagnostic Procedure 6		
SYMPTOM: Abnormalities in roll control	FA- 91	BT
Diagnostic Procedure 7		
SYMPTOM: Abnormalities in pitch control	FA- 92	HA
Hydraulic System Diagnostic Procedures	FA- 94	
Diagnostic Procedure 8		
SYMPTOM: Abnormalities when starting engine	FA- 94	EL
Diagnostic Procedure 9		
SYMPTOM: Abnormalities when engine is off	FA- 96	
Diagnostic Procedure 10		
SYMPTOM: Abnormalities in vehicle height control	FA- 98	IDX
Diagnostic Procedure 11		
SYMPTOM: Abnormalities in driving stability and riding comfort	FA-102	
Diagnostic Procedure 12		
SYMPTOM: Noise	FA-104	

Note: Refer to foldout page for "FULL-ACTIVE SUSPENSION WIRING DIAGRAM".

How to Perform Diagnoses for Quick and Accurate Repair


INTRODUCTION

- Before attempting to diagnose any part of the active suspension, refamiliarize yourself with instructions outlined under "Precautions" (FA-2).
- Trouble is usually caused by a faulty part in either the electrical or hydraulic system. However, it sometimes occurs due to a combination of problems in both systems. For this reason, reproduction tests are a must in determining the cause of the trouble.
- If diagnosis indicates hydraulic component parts are faulty, refer to "WORK PROCEDURES BY UNIT" in "Repair of Components Parts" (FA-26). Perform required operations (such as relieving pressure, bleeding air, etc.) associated with repair work.



- When voltage or resistance is measured at active suspension control unit connector terminals, always use a check adapter (EG1771000). If no abnormalities are found through this inspection, check with CONSULT set to FIELD TEST mode. Try to record data concerning faults which occur occasionally and are difficult to reproduce.

For operation of CONSULT's FIELD TEST mode, refer to CONSULT OPERATION MANUAL INTRODUCTION & SUB MODE, which is issued separately.




- When control unit is determined to be faulty, recheck with CONSULT set to self-diagnostic mode for confirmation. It is advisable to record numerals (C/U MALFUNCTION 1 through 5) indicated on CONSULT display on old control unit. Doing so, cause of trouble can be analyzed for future reference. Replace only control unit, not bracket.

Control unit bracket is secured to upper side of parcel shelf. Do not attempt to press control unit upper lid since this may damage PC boards.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

How to Perform Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Symptom Chart

PROCEDURE			Preliminary check		Diagnostic procedure												Main power supply and ground circuit check	
REFERENCE (FA-)			56	56	81	82	83	86	86	91	92	94	96	98	102	104	—	—
SYMPTOM			Preliminary check 1	Preliminary check 2	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	Diagnostic Procedure 9	Diagnostic Procedure 10	Diagnostic Procedure 11	Diagnostic Procedure 12	Control unit	Fuse
No warning lamp comes on when ignition switch is turned "ON".					①												○	
System is not set in self-diagnosis mode.						①											○	○
Electrical system problems	Abnormalities when starting engine (1) Abrupt rise in vehicle height (2) Tilting of vehicle		①	②			③											
	Abnormalities when stopping engine		①	②				③										
	Abnormal vehicle height control		①	②					③									
	Abnormal roll control		①	②						③								
	Abnormal pitch control		①	②								③						
Hydraulic system problems	Abnormalities when starting engine												④*					
	Abnormalities when stopping engine													④*				
	Abnormal vehicle height control														④*			
	Steering or riding comfort irregularities															④*		
	Noise																④*	
Self-diagnostic results	Self-diagnosis code No.	Diagnosed part																
	11	Car speedometer sensor system is faulty.																
	12	A/T output shaft revolution sensor system is faulty.																
	13	Fore and aft G sensor system is faulty.																
	14	Lateral G sensor system (1) or (2) is faulty.																
	—	Lateral G sensor system 1 is faulty.																
	—	Lateral G sensor system 2 is faulty.																
	15	Vertical G sensor system (front) is faulty.																
	16	Vertical G sensor system (rear right) is faulty.																
17	Vertical G sensor system (rear left) is faulty.																	

* Troubleshooting of the hydraulic system must be started after solving electrical system problems.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Symptom Chart (Cont'd)

PROCEDURE			Preliminary check		Diagnostic procedure												Main power supply and ground circuit check	
			56	56	81	82	83	86	86	91	92	94	96	98	102	104	—	—
REFERENCE (FA-)			Preliminary check 1	Preliminary check 2	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	Diagnostic Procedure 9	Diagnostic Procedure 10	Diagnostic Procedure 11	Diagnostic Procedure 12	Control unit	Fuse
SYMPTOM																		
Self-diagnostic results	21	Vehicle height sensor system (front right) is faulty.																
	22	Vehicle height sensor system (front left) is faulty.																
	23	Vehicle height sensor system (rear right) is faulty.																
	24	Vehicle height sensor system (rear left) is faulty.																
	25	Height control switch system is faulty.																
	26	Height sensor power supply system is faulty																
	31	Pressure control valve (front right) is faulty.																
	32	Pressure control valve (front left) is faulty.																
	33	Pressure control valve system (rear right) is faulty.																
	34	Pressure control valve system (rear left) is faulty.																
	35	Flow control valve system is faulty.																
	36	Fail-safe valve system is faulty.																
	41	Pump or pressure switch system is faulty.																
	42	Oil temperature sensor system is faulty.																
	43	Oil temperature is too high.																
	44	Pump solenoid-1 system is faulty.																
	45	Oil level is too low.																
	46	Ignition power supply system is faulty.																
	51	Engine stops during driving																
	52	G sensor power supply system is faulty.																
53	Control unit is malfunctioning internally.																①	
54	Pump solenoid-2 system is faulty.																	

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM


Symptom Chart (Cont'd)

Electrical component inspection

68	68	69	70	71	72	73	75	76	76	77	77	78	78	79	79	80	80	88	89	90	91
Car speed sensor 1 (meter)	Car speed sensor 2 (A/T)	Fore and aft G sensor	Lateral G sensor 1-2	Lateral G sensor 1 (or 2)	Vertical G sensor	Height sensor	Height control switch	Height sensor power supply	Pressure control valve	Flow control valve	Fail-safe valve	Pump solenoid	Oil temperature sensor	Oil warning	Ignition signal	Engine revolution signal	G sensor power supply	Stop lamp switch	Parking brake switch	Door switch	Neutral position switch
						①															
						①															
						①															
						①															
							①														
								①													
									①												
										①											
											①										
												①									
													①								
														①							
															①						
																①					
																	①				
																		①			
																			①		
																				①	
																					①

GI
 MA
 FM
 LG
 EF &
 EC
 FE
 AT
 PD
FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM



Preliminary Check


CHECK 1

Check hydraulic fluid level and condition. Refer to "FULL-ACTIVE SUSPENSION — On-vehicle Service". FA-23



CHECK 2



Perform self-diagnosis. Refer to "Self-diagnosis". FA-64



Diagnosis by CONSULT

CONSULT INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector.
(Data link connector is located in left dash side panel.)
3. Turn on ignition switch.
4. Touch "START".
5. Touch "ACTIV SUS".




6. Perform each diagnostic mode.

Refer to CONSULT Operation Manual "FULL-ACTIVE SUSPENSION" for details.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM


Component Parts and Harness Connector Locations




GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Component Parts and Harness Connector Locations (Cont'd)




Circuit Diagram for Quick Pinpoint Check




GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
FDX

Note: Refer to foldout page for "FULL-ACTIVE SUSPENSION WIRING DIAGRAM."

Electrical System Diagnostic Procedures

Diagnose affected parts using flowcharts below: 



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

NOTE

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Items to Be Controlled in Relation to Abnormalities

Abnormalities	Items or parts to be controlled								
	Vehicle behavior during engine starts	Vehicle behavior when engine is off	Vehicle height control (Height maintained constantly)	Roll control (Vehicle posture control during turns)	Pitch control (Vehicle posture control during starts/stoppage)	Bounce control (Damping of vertical vibration)	Variable pump control	Fan motor	Height indicator
Ignition signal	○								
Engine revolution signal	○	○	○ During engine operation	○ During engine operation	○ During engine operation	○ During engine operation	○	○	
Car speed sensor-1 (meter)			○	○		○	○		
Car speed sensor-2 (A/T)			○	○		○	○		
Fore-and-aft G sensor			○		○				
Lateral G sensor-1 (front)			○	○		○	○		
Lateral G sensor-2 (rear)			○	○		○	○		
Vertical G sensor (front)						○			
Vertical G sensor (rear right)						○			
Vertical G sensor (rear left)						○			
Vehicle height sensor (front right)			○				○		
Vehicle height sensor (front left)			○				○		
Vehicle height sensor (rear right)			○				○		
Vehicle height sensor (rear left)			○				○		
Stop lamp switch			○						
Parking switch			○						
Door switch			○						
Neutral position switch					○				
Height control switch			○						○
Oil temperature sensor							○	○	
Oil level switch									
Pressure switch									
Pressure control valve	○		○	○	○	○			
Flow control valve									

NOTE: All standard values (or indications) except those for vehicle height sensors, pressure control valves and flow control valve are shown on CONSULT display.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Items to Be Controlled in Relation to Abnormalities (Cont'd)

When to monitor			Parts operated upon detection of problem		Data monitor (monitor available or possible)	Standard values (or indication shown on display) under normal conditions
Key switch "OFF" with engine at rest	Key switch "ON" with engine at rest	During engine operation	Warning light "ON"	Fail-safe valve closed		
○		○	○			
		○	○		○	"RUN" (above 400 rpm); "STOP" (below 400 rpm)
		○	○		○	Same as speedometer reading
		○	○		○	Same as above
		○	○		○	±0.15G (with vehicle on a flat surface)
		○	○	○	○	Same as above
		○	○	○	○	Same as above
		○	○		○	Same as above
		○	○		○	Same as above
		○	○		○	Same as above
		○	○		○	385 ± 10 mm (15.16 ± 0.39 in) (wheel center-to-wheel arch distance with vehicle set at "N" (normal) height)
		○	○		○	Same as above
		○	○		○	361 ± 10 mm (14.21 ± 0.39 in) (wheel center-to-wheel arch distance with vehicle set at "N" (normal) height)
		○	○		○	Same as above
					○	"ON" (foot brake depressed); "OFF" (foot brake released)
					○	"ON" (parking brake applied); "OFF" (parking brake released)
					○	"OPEN" (any one of four doors opened); "SHUT" (all doors closed)
					○	"ON" is indicated when gear position N or P. "OFF" is indicated when gear position not N or P.
	○	○	○		○	"NORM" (vehicle set at normal position); "HI" (vehicle set at high position)
○	○	○	○		○	Oil temperature shown in one of the following indications: LOW, 50°C (122°F), 52°C (126°F) - [at increments of 2°C (3.6°F)] - 68°C (154°F), 70°C (158°F), 75°C (167°F), 90°C (194°F), 110°C (230°F) and HIGH.
	○	○	○		○	"OK" (correct oil level); "LOW" (replenishment required)
		○	○		○	"HI" [above 2,452 kPa (25 kg/cm ² , 356 psi) oil pressure]; "LOW" [below 2,452 kPa (25 kg/cm ² , 356 psi)]
○	○	○	○	○	○	4 - 7Ω (resistance)
		○	○	○	○	9 - 16Ω (resistance)

GI

MA

EM

LC

EF & EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

Self-diagnosis

SELF-DIAGNOSTIC PROCEDURES

Two self-diagnostic methods can be used to check the condition of various active suspension units or components. In one method, letters are shown on the display, with CONSULT set in the self-diagnostic mode designed. This method can locate a problem accurately. In the other method, active suspension warning lamp flashes a trouble code when height control switch (on floor console) is operated.

All system lines, except for some lateral G sensors, can be checked using either of the two self-diagnostic methods. In addition, CONSULT can show on its display the number of times ignition switch was turned "ON" after a problem occurred in the past, only one will be indicated by this method. Note that only one problem can be indicated in the active suspension warning lamp method. Even if two or more problems occurred, they will be ignored in this method. When performing diagnosis, use of the "self-diagnosis result" mode of CONSULT is therefore recommended.



When CONSULT is used:

- Turn ignition switch "OFF".
- Connect CONSULT connector to data link connector located on fuse box, at lower left side of instrument panel.
- Start engine.
- Touch "START", "ACTIV SUS" and "SELF-DIAG RESULTS" on CONSULT display in that order.



- A self-diagnostic result is shown on display. Refer to CONSULT operation manual "FULL-ACTIVE SUSPENSION" for details.

After a faulty system line has been repaired, be sure to clear self-diagnostic result memory.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

When CONSULT is not used: 



(1) Procedures

- Turn ignition switch "ON". (Do not start engine.)
- Set height control switch (on floor console) from "N" (normal) to "H" (high). Repeat above operation at least ten times within ten seconds after turning ignition switch "ON". Then return height control switch to "N".
- After all self-diagnostic requirements are met, the active suspension warning lamp flashes and self-diagnosis starts.

If more than two system lines are faulty, only one of the faulty system lines is indicated in order of priority. The warning lamp may remain on depending upon types of abnormalities (such as those in control unit, etc.). In this case, conduct self-diagnosis using CONSULT.

(2) How to read self-diagnostic indications

- Read both ten's and unit digits from number of flashes on active suspension warning lamp. (Refer to figure at left.)
- Determine location of fault in accordance with Malfunction Code table below.

All fault detection requirements are the same as those outlined under "When CONSULT is used:".

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

(3) Malfunction code table

Malfunction code No.	Description
11	Car speedometer sensor system is faulty.
12	A/T output shaft revolution sensor system is faulty.
13	Fore and aft G sensor system is faulty.
14	Lateral G sensor system (1) or (2) is faulty.
15	Vertical G sensor system (front) is faulty.
16	Vertical G sensor system (rear right) is faulty.
17	Vertical G sensor system (rear left) is faulty.
21	Vehicle height sensor system (front right) is faulty.
22	Vehicle height sensor system (front left) is faulty.
23	Vehicle height sensor system (rear right) is faulty.
24	Vehicle height sensor system (rear left) is faulty.
25	Height control switch system is faulty.
26	Height sensor power supply system is faulty.
31	Pressure control valve (front right) is faulty.

Malfunction code No.	Description
32	Pressure control valve (front left) is faulty.
33	Pressure control valve system (rear right) is faulty.
34	Pressure control valve system (rear left) is faulty.
35	Flow control valve system is faulty.
36	Fail-safe valve system is faulty.
41	Pump or pressure switch system is faulty.
42	Oil temperature sensor system is faulty.
43	Oil temperature is too high.
44	Pump solenoid-1 system is faulty.
45	Oil level is too low.
46	Ignition power supply system is faulty.
51	Engine stops during driving.
52	G sensor power supply system is faulty.
53	Control unit is internally malfunctioning.
54	Pump solenoid-2 system is faulty.
55	NORMAL

(4) Clearing self-diagnostic mode

Self-diagnostic modes can be cleared using one of the following methods:

- a. Set height control switch from "N" (normal) to "H" (high) while a self-diagnosis is being conducted.
- b. Wait approximately five minutes after setting in the self-diagnosis mode.
- c. Turn ignition switch "OFF".

(5) Clearing self-diagnostic results

A faulty system indication is not cleared even after the faulty system has been repaired. To clear the indication, use one of the following methods:

- Set the self-diagnostic mode. Refer to "(1) Procedures" above.
- Repeatedly depress and release (ON-OFF operation) foot brake at least five times within ten seconds.
- Self-diagnostic results will then be cleared.

In cases where more than two system lines are faulty, repaired system indications will be cleared. However, any other faulty system will be indicated when self-diagnosis is performed again.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

FAIL-SAFE FUNCTION

When a malfunction occurs in the parts shown in the talk below, the fail-safe system actinates to:

1. illuminate the active suspension warning lamp,
2. cut off the current to the fail-safe valve, and/or
3. regulate the pressure control valve operation.

This gradually changes the oil pressure (applied to the actuators for the four wheels) to a uniform pressure so that the vehicle can continue to be driven.

NOTES:

- A sound is produced when the fail-safe valve operates. This is not an indication of a problem. Since, the fail-safe valve closes normal oil passages and, simultaneously, links the supply pressure line [9,807 kPa (100 kg/cm², 1,422 psi)] with the return pressure line [0 kPa (0 kg/cm², 0 psi)].
- When pressure control valve function stops, control current flowing to solenoid is cut off (0 amperes). It might change briefly the vehicle height.




Major malfunctioning parts and fail-safe operations

Malfunctioning parts	Fail-safe operation		
	Active suspension warning lamp (ON)	Fail-safe valve closed (No current flow)	Other control functions
Internal parts of control unit	○	○	Control stopped
Engine stalls while driving	○	○	—
Car speed sensor	○	—	Control is accomplished by signal sent from any sensor which detects higher car speeds than the other sensors.
Fore and aft G sensor	○	—	—
Lateral G sensor	○	○	Control stopped
Vertical G sensor	○	—	Vertical G sensor control is stopped.
Pressure control valve	○	○	Control stopped
Flow control valve	○	○	Control stopped
Fail-safe valve	○	○	Control stopped
Insufficient oil level	○	—	Normal control
Height control switch	○	—	Vehicle is set to normal height.
Power supply to G sensors	○	○	Control stopped
Power supply to height sensors	○	○	Control stopped
Height sensor	○	—	Height control stopped
Pump	○	—	Normal control
Oil temperature sensor	○	—	Normal control


TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

CAR SPEED SENSOR 1 (METER) CIRCUIT CHECK



CAR SPEED SENSOR 2 (A/T) CIRCUIT CHECK



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)



FORE AND AFT G SENSOR CIRCUIT CHECK

☆ MONITOR ☆	FAILURE
SPEED SE1-MTR	0km/h
SPEED SE2	0km/h
LATER G SE1	RO.01G
LATER G SE2	LO.01G
FOR&AFT G SEN	-0.01G
VERTI G SE F	U0.03G
VERTI G SE RR	0.00G
VERTI G SE RL	D0.01G
HEIGHT SEN FR	-2mm

RECORD

SFA063B

- Start engine and wait for at least 2 seconds.
- Move vehicle to a flat surface and stop engine.
- Connect CONSULT and turn ignition switch "ON". Do not start engine.



```

    graph TD
      Start[Start engine and wait for at least 2 seconds.  
Move vehicle to a flat surface and stop engine.  
Connect CONSULT and turn ignition switch "ON". Do not start engine.] --> A1[Check fore and aft G sensor's output with CONSULT set in data monitor mode.]
      A1 -- "Greater than 1.0G" --> B[CHECK GROUND CIRCUIT.  
Check continuity between G sensor connector terminal ③ and GND (body metal) with ignition switch "OFF".  
Continuity should exist.]
      B -- "OK" --> B1[Replace fore and aft G sensor.]
      B -- "NG" --> B2[Open harness circuit. Check and repair harness between control unit and fore and aft G sensor.]
      A1 -- "Less than 1.0G" --> A2[Check fore and aft G sensor output with CONSULT set in data monitor mode.]
      A2 -- "Less than -1.0G" --> C[CHECK CONTINUITY.  
Turn ignition switch "OFF" and check continuity between fore and aft G sensor connector terminals ② and ③.  
Continuity should exist.]
      C -- "NG" --> C1[Open harness circuit or fore and aft G sensor.]
      C -- "OK" --> C2[Shorted harness circuit. Check and repair harness between control unit and fore and aft G sensor.]
      A2 -- "Within ±0.15G" --> End[OK (See NOTE below.)]
      A2 -- "Outside ±0.15G" --> D[Faulty fore and aft G sensor. Replace.]
  
```

NOTE: Also check with CONSULT set in field test mode as needed.

GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX


TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

LATERAL G SENSOR 1-2 CIRCUIT CHECK

When "LATERAL G SEN 1-2" appears on the display with CONSULT set on self-diagnostic mode, it indicates that lateral G sensors (1 and 2) deviate from the specified output characteristics. Output characteristic deviations are measured both statically and dynamically. Static characteristics occur while the vehicle is at a standstill and dynamic characteristics occur while the vehicle is operating. It is therefore necessary to investigate the cause, when the active suspension warning lamp is illuminated. Determine how the vehicle was being driven when the lamp activated. Reproduction tests should also be conducted to double-check the results.

With CONSULT set on self-diagnostic mode, the number of times when a problem occurred appears on the display. It refers to the number of times the ignition switch was turned ON and OFF after a problem occurred. It is helpful in pinpointing the time when it occurred.



NOTE: Also check with CONSULT set in field test mode as needed.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)




LATERAL G SENSOR 1 (OR 2) CIRCUIT CHECK

☆ MONITOR ☆	FAILURE
SPEED SE1-MTR	0km/h
SPEED SE2	0km/h
LATER G SE1	RO.01G
LATER G SE2	LO.01G
FOR&AFT G SEN	-0.01G
VERTI G SE F	U0.03G
VERTI G SE RR	0.00G
VERTI G SE RL	D0.01G
HEIGHT SEN FR	-2mm

RECORD

SFA063B

- Place vehicle on a flat surface and stop engine.
- Connect CONSULT and turn ignition switch "ON". (Do not start engine.)



NOTES:

- (1) When one lateral G sensor is found to be "faulty", replace both G sensors.
- (2) Also check with CONSULT set to field test mode as needed.

GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

VERTICAL G SENSOR CIRCUIT CHECK

When "VERTI G SENSOR (F, R/R, R/L)" appears on the display with CONSULT set to the self-diagnostic mode, the problem may be due to either abnormal sensors, (output or no-output) variation from "0G". No-output variation can only be determined while the vehicle is driven.

A

☆ MONITOR	★ FAILURE	
SPEED SE1-MTR		0km/h
SPEED SE2		0km/h
LATER G SE1		RO.01G
LATER G SE2		LO.01G
FOR&AFT G SEN		-0.01G
VERTI G SE F		U0.03G
VERTI G SE RR		0.00G
VERTI G SE RL		D0.01G
HEIGHT SEN FR		-2mm

RECORD

SFA063B

- Start engine and wait for at least two seconds.
- Place vehicle on a flat surface and stop engine.
- Connect CONSULT and turn ignition switch "ON". (Do not start engine.)


A Check vertical G sensor output using CONSULT data monitor.

Greater than 1.5G **B**

CHECK GROUND CIRCUIT. Turn ignition switch "OFF". Check continuity between vertical G sensor connector ③ and GND (body metal). **Continuity should exist.**

OK
Replace vertical G sensor.

NG
Open harness circuit. Check and repair harness between control unit and vertical G sensor.



Less than 1.5G


Check vertical G sensor output using CONSULT data monitor.

Less than -1.5G **C**

CHECK CONTINUITY. Turn ignition switch "OFF". Check continuity between vertical G sensor connectors ② and ③. **Continuity should exist.**

NG
Open harness circuit or vertical G sensor.

OK
Shorted harness circuit. Check and repair harness between control unit and vertical G sensor.




Greater than -1.5G

A

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)



NOTE: Also check with CONSULT set to field test mode as needed.

GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

A

☆MONITOR ☆NO FAIL	
SPEED SE1•MTR	0km/h
SPEED SE2	0km/h
LATER G SEN 1	0.00G
LATER G SEN 2	0.01G
FOR & AFT G SEN	+0.01G
VERTI G SE F	0.01G
VERTI G SE RR	0.00G
VERTI G SE RL	0.01G
HEIGHT SEN FR	-1mm

RECORD



☆MONITOR ☆NO FAIL	
HEIGHT SEN FL	-7mm
HEIGHT SEN RR	16mm
HEIGHT SEN RL	17mm
OIL TEMP SEN	LOW°C
HEIGHT SWITCH	NORM
STOP LAMP SW	OFF
PRES SW•PUMP	LOW
OIL LEVEL SW	OK
DOOR SW	SHUT

RECORD

SFA124B




HEIGHT SENSOR CIRCUIT CHECK

- Start engine and wait for at least 1 second.
- Place vehicle on a flat surface and stop engine.
- Connect CONSULT and turn ignition switch "ON". (Do not start engine.)



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)




NOTE: Also check with CONSULT set to field test mode.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

HEIGHT CONTROL SWITCH CIRCUIT CHECK




A

CHECK POWER SUPPLY.
Turn ignition switch "ON". Measure voltage across height control switch terminals ③ and ④.
Battery voltage should exist.

NG → Check height control switch power supply

OK ↓




B

CHECK GROUND CIRCUIT.
Turn ignition switch "OFF". Disconnect height control switch connector, and check continuity between connector ④ (body side) and GND (body metal).
Continuity should exist.

NG → Open harness circuit. Check and repair harness between control unit and height control switch.

OK ↓




C

CHECK CONTINUITY IN HEIGHT CONTROL SWITCH CIRCUIT.
Turn ignition switch "ON". Measure voltage across switch terminals ① and ④ or ② and ④.

NG → Replace height control switch.

OK ↓

Switch position	① - ④	② - ④
Normal (N)	Battery voltage	0V
High (H)	0V	Battery voltage



D

CHECK HEIGHT CONTROL SWITCH CIRCUIT.
Turn ignition switch "ON". Measure voltage across control unit terminals ④② and ①② or ④③ and ①②.

NG → Open harness circuit. Check and repair harness between control unit and height control switch.

OK ↓

Switch position	④② - ①②	④③ - ①②
Normal (N)	Battery voltage	0V
High (H)	0V	Battery voltage


OK

GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

HEIGHT SENSOR POWER SUPPLY CIRCUIT CHECK




- Turn ignition switch "OFF".
- Disconnect four height sensor connectors and control unit connector.

A
CHECK GROUND CIRCUIT.
Check continuity between height sensor connector ① and ground.
Continuity should exist.

OK → Shorted harness circuit
Check and repair harness between control unit and height sensor.

NG




B
CHECK HEIGHT SENSOR.
Disconnect height sensor connector and check continuity between sensor terminal ① and ③. (Check all four sensors.)
Resistance: Approx. 2 kΩ

NG (when any one of the sensors shows approx. 0Ω)
→ Replace sensors.

OK (All sensors)

Replace control unit.

PRESSURE CONTROL VALVE CIRCUIT CHECK




A
CHECK PRESSURE CONTROL VALVE.
Turn ignition switch "OFF". Disconnect affected pressure control valve connector, and measure resistance between terminals ① and ②.
Resistance: 4 - 7Ω

0Ω or infinity

→ Faulty control valve.
Replace pressure control unit.

OK



B
CHECK PRESSURE CONTROL VALVE CIRCUIT.
Turn ignition switch "OFF". Measure resistance between control unit terminal ⑩② and either terminal ⑩④, ⑩⑤, ⑩⑫ or ⑩⑬.
Resistance: 4 - 7Ω

0Ω or infinity

→ Check and repair harness between control unit and pressure control valve.

- ⑩④: Pressure control valve (front right)
- ⑩⑤: Pressure control valve (front left)
- ⑩⑫: Pressure control valve (rear right)
- ⑩⑬: Pressure control valve (rear left)







OK

Replace control unit.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)





FLOW CONTROL VALVE CIRCUIT CHECK



Replace control unit.

FAIL-SAFE VALVE CIRCUIT CHECK

When "FAIL-SAFE VALVE" appears on the display with CONSULT set on self-diagnostic mode, the fail-safe valve circuit may be open or shorted. Fail-safe valve self-diagnosis is performed when the ignition switch is "ON" with the engine at rest.







Replace control unit.






TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

PUMP SOLENOID CIRCUIT CHECK




OIL TEMPERATURE SENSOR CIRCUIT CHECK



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)

OIL WARNING CIRCUIT CHECK




Check fluid level in reservoir tank. NG Add fluid.

OK

A

CHECK CONTINUITY IN OIL LEVEL SWITCH CIRCUIT. Turn ignition switch "OFF". Disconnect oil level switch connector, and check continuity between terminals ① and ② (switch side). **Continuity should exist.** NG Replace oil level switch.

OK




B

CHECK OIL LEVEL SWITCH CIRCUIT. Turn ignition switch "OFF". Disconnect control unit connector and check continuity between terminals ⑤④ and ⑩②. **Continuity should exist.** NG Check and repair harness between control unit and oil level switch.

OK

Replace control unit.



IGNITION POWER SUPPLY CIRCUIT CHECK

When "IGN-ON PWR SUPPLY" appears on the display with CONSULT set on self-diagnostic mode, either the 15-ampere IGN fuse (#27) is burned out or the control unit is faulty.

A

Check 15A IGN fuse (#27) condition. NG Replace fuse.

OK

Turn ignition switch "OFF" and wait for at least 3 minutes. Then disconnect battery terminal and leave it disconnected for at least 30 seconds.*

↓

Connect battery terminal. Start engine and check again. NG Replace control unit.

OK

Normal

- Attention, vehicle height abruptly changes when battery terminal is disconnected, immediately after ignition switch is turned "OFF".
- After fuse is replaced, always perform operation marked "*". Otherwise, active suspension warning lamp remains on, although system is in good order. (Auto "turn-off" function does not activate.)




GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM


Self-diagnosis (Cont'd)

ENGINE STALL WARNING CIRCUIT CHECK

When "WARN ENGINE STALL" appears on the display with CONSULT set on self-diagnostic mode, it indicates that the engine is running at speeds less than 400 rpm. When the vehicle is operating, it is at rest with the ignition "ON". Otherwise, with the engine revolution signal line to the ECM (ECCS control module) open. If CONSULT judges the problem to be an "engine stall", the active suspension warning lamp will illuminate and, at the same time, the fail-safe valve will be de-energized. The result is a fail-safe condition (control stopped) which may cause vehicle posture to change while operating.





G SENSOR POWER SUPPLY CIRCUIT CHECK




TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Self-diagnosis (Cont'd)



GI
MA
EM
LC
EF &
EC
FE
AT





Diagnostic Procedure 1

SYMPTOM:

No warning lamp comes on when ignition switch is turned "ON".

PD
FA









RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 2

SYMPTOM:

System is not set in self-diagnosis mode.



Replace control unit.

Diagnostic Procedure 3

SYMPTOM:

Abnormalities when starting engine

Note:


When engine is started, the flow control valve is energized for approx. 10 seconds changing the vehicle height gradually. After this period, the flow control valve is de-energized. The vehicle height is gradually controlled to a level according to the signals from the G sensor and vehicle height sensor. Accordingly, possible troubles when starting engine are as follows:

- 1) abrupt rise in vehicle height (malfunctioning flow control valve),
- 2) tilting of vehicle (difference in outputs of G sensors), and
- 3) abnormal control signal from control unit.

1) ABRUPT RISE IN VEHICLE HEIGHT

Note:

If the flow control valve is seized in the de-energized position, the vehicle may raise immediately after starting the engine. This indicates that the control level of the pressure control valve is set at 5,002 kPa (51 kg/cm², 725 psi). For about 10 seconds after starting the engine, a sudden change in the supply pressure also causes the control pressure to be increased abruptly to 5,002 kPa (51 kg/cm², 725 psi). Similar behavior may occur if a disconnection occurs in the flow control valve circuit. In this case, however, the fail-safe function prevents the trouble from occurring.



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 3 (Cont'd)


2) TILTING OF VEHICLE

Note:

If front and rear G sensors or lateral G sensors outputs are different, the vehicle position may tilt approx. 10 seconds after starting engine. After some time, the vehicle may recover its level position. This is because, if the outputs of G sensors are not equal, the difference in output causes a change in vehicle position. The amount of control is increased gradually to bring the vehicle to the normal level.

a) Tilting in fore and aft direction

- Park vehicle on level ground, and stop engine.
- Connect CONSULT, and set ignition switch to ON. (Engine OFF)



A

☆MONITOR	☆NO FAIL	
SPEED SE1•MTR		0km/h
SPEED SE2		0km/h
LATER G SEN 1		0.00G
LATER G SEN 2		0.01G
FOR & AFT G SEN		+0.01G
VERTI G SE F		0.01G
VERTI G SE RR		0.00G
VERTI G SE RL		0.01G
HEIGHT SEN FR		-1mm
RECORD		

SFA078B

B

☆MONITOR	☆NO FAIL	
VALVE PRES F/R		51kg/
VALVE PRES F/L		51kg/
VALVE PRES R/R		51kg/
VALVE PRES R/L		51kg/
FLOW CONT VAL		ON
FAIL-SAFE VAL		OFF
PUMP		MODE2
RECORD		

SFA076B

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 3 (Cont'd)

b) Tilting in lateral direction

A

☆MONITOR ☆NO FAIL

SPEED SE1•MTR	0km/h
SPEED SE2	0km/h
LATER G SEN 1	0.00G
LATER G SEN 2	0.01G
FOR & AFT G SEN	+0.01G
VERTI G SE F	0.01G
VERTI G SE RR	0.00G
VERTI G SE RL	0.01G
HEIGHT SEN FR	-1mm

RECORD

SFA078B

B


☆MONITOR ☆NO FAIL

VALVE PRES F/R	51kg/
VALVE PRES F/L	51kg/
VALVE PRES R/R	51kg/
VALVE PRES R/L	51kg/
FLOW CONT VAL	ON
FAIL-SAFE VAL	OFF
PUMP	MODE2

RECORD

SFA076B

- Park vehicle on level ground, and stop engine.
- Connect CONSULT, and set ignition switch to ON. (Engine OFF)



GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 4

SYMPTOM:

Abnormalities when stopping engine

Note:

When engine is stopped, the system operates to maintain system pressure at a fixed level (charged balancing pressure). First, the pump stops, eliminating the pump discharge pressure, which causes the main check valve to close. Simultaneously, the control level of the pressure control valve is gradually changed to the neutral pressure [5,002 kPa (51 kg/cm², 725 psi)]. Because no oil is fed from the pump, the supply pressure flows out to the return pressure side via the pressure control valve. As a result, the supply pressure lowers gradually. When the pressure lowers to 5,002 kPa (51 kg/cm², 725 psi), the operation check valve closes, shutting off the return pressure outlet. After the operation check valve closes, the supply pressure and return pressure gradually become equal (charged balancing pressure). Approximately 3 minutes after stopping the engine, the fail-safe valve and pressure control valve are de-energized, and no longer operational.

During the above-mentioned operation, some mismatching may occur between the operation of the hydraulic system and the electrical units due to the ambient temperature. The status of control is existing at the time the engine stopped. Such a minor mismatching should not be regarded as a problem. It is requested to fully understand the conditions and situations under which such mismatch occurs.

- (1) If either battery terminal is disconnected or the active suspension fuse (No. 17) is removed (within 3 minutes after stopping the engine), the vehicle height may change. This is normal. However, care should be taken when performing maintenance near the vehicle.
- (2) Depending on the ambient temperature and pressure control valve status when the engine was stopped, some mismatching may occur between the operation of the hydraulic system and the electrical units. It creates a jerk of the vehicle body. This is normal.
- (3) When ambient temperature is very low, vehicle height may drop a little about 3 minutes after stopping the engine. This is normal.
- (4) When jacking up the vehicle, be sure to wait about 3 minutes after stopping the engine. The vehicle body may jerk a little after stopping the engine.
- (5) If the engine is restarted promptly, the vehicle body may slightly jerk depending on the ambient temperature and loaded condition of the vehicle. This, however, is normal.

A

☆ MONITOR ☆ NO FAIL	▼
SPEED SE1-MTR	0km/h
SPEED SE2	0km/h
LATER G SEN 1	0.00G
LATER G SEN 2	L0.01G
FOR & AFT G SEN	+0.01G
VERTI G SE F	U0.01G
VERTI G SE RR	0.00G
VERTI G SE RL	D0.01G
HEIGHT SEN FR	-1mm

RECORD

☆ MONITOR ☆ NO FAIL	☐
HEIGHT SEN FL	-7mm
HEIGHT SEN RR	16mm
HEIGHT SEN RL	17mm
OIL TEMP SEN	LOW°C
HEIGHT SWITCH	NORM
STOP LAMP SW	OFF
PRES SW-PUMP	LOW
OIL LEVEL SW	OK
DOOR SW	SHUT

RECORD

SFA541B

Diagnostic Procedure 5

SYMPTOM:

Abnormalities in vehicle height control

Note:

The vehicle height controller causes the vehicle height to change. Nevertheless, its changing speed [2 to 3 mm (0.08 to 0.12 in)/sec] is slower than that caused by the G sensor. If the vehicle height changes too slowly, it is attributable to a malfunction of the vehicle height controller.

A

Does the difference between vehicle height measured value and reference value agree with the value displayed on CONSULT data monitor screen to within a range of ±10mm (±0.39 in)? mm (in)

Vehicle height reference value	Front (A)	385 (15.16)
	Rear (B)	361 (14.21)




↓ OK

A

NG → Go to "Vehicle height adjustment". Refer to FULL-ACTIVE SUSPENSION — Repair of Components Parts. FA-34

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 5 (Cont'd)



1) FAULTY PHENOMENA AND SENSORS REQUIRING INSPECTION

Symptom	Sensors requiring inspection
Vehicle will not level even if parked on level ground for a long time.	Vehicle height sensors (for four wheels) (Note 1) Stop lamp switch (Note 2)
Vehicle tilts while driving.	Parking brake switch (Note 2) Door switch (Note 2)
Vehicle height will not change even if height control switch is operated.	Above-listed items and height control switch (Note 3)

The following phenomena are related to a normal system.

- When the parking brake or foot brake is applied, the braking force creates a stress in suspension system. In this condition, height of all four wheels may not change uniformly when height control switch is operated.
- If a wheel is mounted on the shoulder of a road or on a large curb [approx. 100 mm (3.94 in) in height], the system automatically stops its vehicle height control function. Therefore, the vehicle remains in the tilted position.
- As long as the active suspension warning lamp is ON, the vehicle height control function is inactive. The vehicle may not level itself.

Notes:

- (1) A vehicle height sensor is connected to each wheel. If any one of them should fail, or its neutral position become incorrect. Then, height changes will occur not only in the affected wheel but in the other wheels also. To adjust vehicle height using the vehicle height sensor, refer to "Full-active suspension — Repair of Components: Vehicle height adjustment". Use the vehicle height adjustment mode of the CONSULT work support mode.
- (2) For inspection of the stop lamp switch, parking brake switch and door switch, refer to "2) Inspection of other sensors".
- (3) For inspection of the height control switch, refer to "Self-diagnosis HEIGHT CONTROL SWITCH CIRCUIT CHECK. FA-75".

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 5 (Cont'd)

2) INSPECTION OF OTHER SENSORS

a) Stop lamp switch

Turn OFF ignition switch.
Connect CONSULT, and set ignition switch to ON.

A

☆ MONITOR	☆ NO FAIL	
HEIGHT SEN FL	-7mm	
HEIGHT SEN RR	16mm	
HEIGHT SEN RL	17mm	
OIL TEMP SEN	LOW°C	
HEIGHT SWITCH	NORM	
STOP LAMP SW	OFF	
PRES SW·PUMP	LOW	
OIL LEVEL SW	OK	
DOOR SW	SHUT	

RECORD

SFA082B

A

CHECK ON-OFF OPERATION OF STOP LAMP SWITCH.
Depress and release foot brake pedal several times. Check whether stop lamp switch display is normal on CONSULT data monitor screen.

Foot brake operation	CONSULT display
Depressed	ON
Released	OFF

OK → Normal

NG

B

For terminal arrangement, refer to Circuit Diagram for Quick Pinpoint Check.

SFA523B

Set ignition switch to OFF.
Depress and release foot brake pedal several times. Check whether brake lamp operation is normal.

NG → Check brake lamp circuit.

OK

B

CHECK STOP LAMP CIRCUIT.
Disconnect C/U connector, and depress and release foot brake pedal several times. Check whether voltage between vehicle side connector terminals 52 and 102 is normal (ignition switch: OFF).

Foot brake operation	Voltage
Depressed	Battery voltage
Released	0 V

NG → Check and repair harness between control unit and stop lamp switch.

OK

Damaged control unit
(Replace)

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 5 (Cont'd)

② Parking brake switch

Turn OFF ignition switch.
Connect CONSULT, and set ignition switch to ON.

A

CHECK ON-OFF OPERATION OF PARKING BRAKE LAMP SWITCH.
Apply and release parking brake several times. Check whether parking brake lamp switch display is normal on CONSULT data monitor screen.

Parking brake operation	CONSULT display
Applied	ON
Released	OFF

OK → Normal

NG →

A

☆ MONITOR ☆ NO FAIL ▲

PARK BRAKE SW	OFF
ENGINE	STOP
N-RANGE SW	OFF

RECORD

SFA084B

B

For terminal arrangement, refer to Circuit Diagram for Quick Pinpoint Check.

SFA524B

Set ignition switch to OFF.
Apply and release parking brake several times. Check whether brake warning lamp operation is normal.

NG → Check and repair brake warning lamp circuit.

OK →

B

CHECK PARKING BRAKE LAMP CIRCUIT.
Disconnect C/U connector, and apply and release parking brake several times. Check whether voltage between vehicle side connector terminals ⑤⑥ and ⑩② is normal (ignition switch: OFF).

Parking brake operation	Voltage
Applied	0 V
Released	Battery voltage

NG → Check and repair harness between control unit and parking brake switch.

OK →

OK → Damaged control unit (Replace)

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 5 (Cont'd)

Ⓒ Door switch

Turn OFF ignition switch.
Connect CONSULT and set ignition switch to ON.

A

CHECK ON-OFF OPERATION OF DOOR SWITCH.

Open and close doors several times.
Check whether door switch displayed is normal on CONSULT data monitor screen.

(Room lamp switch: DOOR)

Door position	CONSULT display
All doors are closed	SHUT
One or more doors are open	OPEN

OK → Normal

NG

NG → Check and repair room lamp circuit.

OK

NG → Check and repair harness between control unit and door switch.

OK

Damaged control unit
(Replace)

A

☆ MONITOR	☆ NO FAIL	
HEIGHT SEN FL	-7mm	
HEIGHT SEN RR	16mm	
HEIGHT SEN RL	17mm	
OIL TEMP SEN	LOW°C	
HEIGHT SWITCH	NORM	
STOP-LAMP SW	OFF	
PRES SW-PUMP	LOW	
OIL LEVEL SW	OK	
DOOR SW	SHUT	

RECORD

SFA082B

B

For terminal arrangement, refer to Circuit Diagram for Quick Pinpoint Check.

SFA525B

Set ignition switch to OFF.
Open and close doors several times.
Check whether room lamp lights normally. (Room lamp switch: DOOR)

B

Disconnect C/U connector, and open and close doors several times. Check whether voltage between vehicle side connector terminal ⑤ and terminal ⑩② is normal. (Room lamp switch: DOOR, ignition switch: OFF)

Door position	Voltage
All doors are closed	0 V
One or more doors are open	Approx. 12 V

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 5 (Cont'd)

A ☆MONITOR ☆NO FAIL ▲

PARK BRAKE SW	OFF
ENGINE	STOP
N-RANGE SW	OFF

RECORD

SFA084B

B ACTIVE SUS C/UNIT (B33)

For terminal arrangement, refer to Circuit Diagram for Quick Pinpoint Check.

DISCONNECT

SFA089B

d Neutral position switch

A Observe neutral position switch ON-OFF operation displayed on CONSULT data monitor screen. Display should agree with operation.

NG → Refer to "TROUBLE DIAGNOSES" in AT section.

OK ↓

B CHECK HARNESS BETWEEN NP RELAY AND C/U. Check whether resistance between C/U connector terminal 45 and GND changes in NP range.

NG → Check and repair harness between control unit and NP relay.

OK ↓

Replace control unit.

Diagnostic Procedure 6

SYMPTOM:

Abnormalities in roll control

- 1) The vehicle body moved in the roll direction while parking. The vehicle body rolled (moved sideways) after starting the engine, but it gradually returned level.

- Park vehicle on level ground, and stop engine.
- Connect CONSULT, and set ignition switch to ON. (Engine OFF)

A ☆MONITOR ☆NO FAIL ▼

SPEED SE1-MTR	0km/h
SPEED SE2	0km/h
LATER G SEN 1	0.00G
LATER G SEN 2	0.01G
FOR & AFT G SEN	+0.01G
VERTI G SE F	0.01G
VERTI G SE RR	0.00G
VERTI G SE RL	0.01G
HEIGHT SEN FR	-1mm

RECORD

SFA078B

A Check output signal on CONSULT data monitor screen. Are output values of lateral G sensors 1 and 2 within $\pm 0.15G$?

NG → Damaged lateral G sensor 1 or 2 (Replace both sensors as a set.)

OK ↓

Go to "Hydraulic System Diagnostic Procedures". Refer to Diagnostic Procedures 8 to 12. FA-94

GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 6 (Cont'd)

A

☆MONITOR	☆NO FAIL	<input type="checkbox"/>
SPEED SE1•MTR	0km/h	
SPEED SE2	0km/h	
LATER G SEN 1	0.00G	
LATER G SEN 2	L0.01G	
FOR & AFT G SEN	+0.01G	
VERTI G SE F	U0.01G	
VERTI G SE RR	0.00G	
VERTI G SE RL	D0.01G	
HEIGHT SEN FR	-1mm	

RECORD

SFA078B

- 2) The vehicle body moved in the roll direction while driving. The vehicle body rolled, but gradually returned level.

- Park vehicle on level ground, and stop engine.
- Connect CONSULT, and set ignition switch to ON. (Engine OFF)

A

Check output signal on CONSULT data monitor screen. Are output values of lateral G sensors 1 and 2 and vertical G sensors (rear right and rear left) within $\pm 0.15G$?
Gravity $\pm 0.15G$

NG → Damaged G sensor (Replace)

OK

Go to "Hydraulic System Diagnostic Procedures". Refer to Diagnostic Procedures 8 to 12. FA-94

A

☆MONITOR	☆NO FAIL	<input type="checkbox"/>
SPEED SE1•MTR	0km/h	
SPEED SE2	0km/h	
LATER G SEN 1	0.00G	
LATER G SEN 2	L0.01G	
FOR & AFT G SEN	+0.01G	
VERTI G SE F	U0.01G	
VERTI G SE RR	0.00G	
VERTI G SE RL	D0.01G	
HEIGHT SEN FR	-1mm	

RECORD

SFA078B

Diagnostic Procedure 7

SYMPTOM:

Abnormalities in pitch control

- 1) The vehicle body moved in the pitch direction while parked. After starting the engine, the vehicle body moved in the pitch direction (tilted forward or backward), but it gradually returned level.

- Park vehicle on level ground, and stop engine.
- Connect CONSULT, and set ignition switch to ON. (Engine OFF)

A

Check output signal on CONSULT data monitor screen. Is output of fore and aft G sensor within $\pm 0.15G$?
Gravity $\pm 0.15G$

NG → Damaged fore and aft G sensor (Replace)

OK

Go to "Hydraulic System Diagnostic Procedures". Refer to Diagnostic Procedures 8 to 12. FA-94

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 7 (Cont'd)

A

☆ MONITOR	☆ NO FAIL	
SPEED SE1-MTR	0km/h	
SPEED SE2	0km/h	
LATER G SEN 1	0.00G	
LATER G SEN 2	L0.01G	
FOR & AFT G SEN	+0.01G	
VERTI G SE F	U0.01G	
VERTI G SE RR	0.00G	
VERTI G SE RL	D0.01G	
HEIGHT SEN FR	-1mm	

RECORD

SFA078B

2) While driving, the vehicle body moved in the pitch direction. The vehicle body moved in the pitch direction, but it gradually returned level.

- Park vehicle on level ground, and stop engine.
- Connect CONSULT, and set ignition switch to ON. (Engine OFF)

A

Check output signal on CONSULT data monitor screen.
Are outputs of fore and aft G sensor and vertical G sensor (front) within $\pm 0.15G$?
Gravity $\pm 0.15G$

NG → Damaged fore and aft G sensor or vertical G sensor (Replace)

OK

Go to "Hydraulic System Diagnostic Procedures"
Refer to Diagnostic Procedures 8 to 12.
FA-94

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


Hydraulic System Diagnostic Procedures

Troubleshooting of the hydraulic system must be started after solving electrical system problems, referring to "Electrical System Diagnostic Procedures", FA-60.

Diagnostic Procedure 8


SYMPTOM:

Abnormalities when starting engine



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 8 (Cont'd)



Note: Fully loaded state means five adults [68 kg (150 lb) each] and cargo [68 kg (150 lb)].

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

A ☆ MONITOR ☆ NO FAIL ▲


VALVE PRES F/R	51kg/
VALVE PRES F/L	51kg/
VALVE PRES R/R	51kg/
VALVE PRES R/L	51kg/
FLOW CONT VAL	ON
FAIL-SAFE VAL	OFF
PUMP	MODE2

RECORD

SFA076B



Diagnostic Procedure 9

SYMPTOM: Abnormalities when engine is off.



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 9 (Cont'd)




GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 10


SYMPTOM:

Abnormalities in vehicle height control



TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 10 (Cont'd)



GI

MA

EM

LC

EF & EC

FE

AT

PD

FA

RA

BR

ST

RS

BT




HA

EL

IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 10 (Cont'd)



SFA091B

Ⓒ

Movement of some wheels is not smooth.

Using CONSULT active test mode, change control pressure of four wheels from 1,765 to 9,807 kPa (18 to 100 kg/cm², 256 to 1,422 psi). Do all four wheels move smoothly up and down?

Pressure control unit of affected wheel is faulty (Replace).

All four wheels move smoothly.

A


MEASURE CONTROL PRESSURE:

- With engine stopped, lift up vehicle until all four wheels are completely off the ground.
 - Remove front right fender protector and rear pressure control unit protector.
 - Loosen lock nut on each pressure detection port cock, and check that each cock is tightened to specified torque. Temporarily tighten each lock nut.
 - Remove blind bolt.
Be sure to loosen this bolt very carefully. Oil may spout out if cock is faulty.
 - Install oil pressure gauge adapter (special tool) and brake pressure tester to each wheel.
Securely tighten each joint. Do not forget to fit copper washer to adapter joint.
 - Gradually loosen pressure detection port cock to the fully open position while making sure no oil is leaking out from any joint.
 - Connect vinyl tube to air bleeder of brake fluid pressure tester. Loosen air bleeder gradually to allow air to bleed out completely, then tighten air bleeder.
- (1) Take care to prevent oil from getting on vehicle body when bleeding air.
 - (2) After completing measurement, securely tighten each cock, and release residual pressure from air bleeder tester before disconnecting joints.
 - (3) Do not forget to install blind bolts.

Ⓓ

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 10 (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



Diagnostic Procedure 11

SYMPTOM:

Abnormalities in driving stability and riding comfort

Driving stability or riding comfort deteriorated.

Any problem in vehicle height control?

Yes → Go to "Abnormalities of vehicle height control". Refer to Diagnostic Procedure 10. FA-98

No

Stop engine, and connect brake fluid pressure tester to pressure detection port.
For connection of brake fluid pressure tester, refer to Diagnostic Procedure 10. FA-98

A

CHECK CONTROL PRESSURE STEP RESPONSE.

- Connect CONSULT, and start engine. After vehicle height stabilizes, select "PRESSURE CONTROL VALVE STEP RESPONSE" mode of CONSULT active test. This will cause actuator control pressure to be regulated to 2,648 kPa (27 kg/cm², 384 psi) for all wheels.
- Under this condition, touch "START" key on CONSULT screen. This will cause control pressure of selected wheel to vary as shown at left. Check whether actual oil pressure follows this change in control value.

Normal

Oil pressure change is abnormal on only one wheel.

Oil pressure change is abnormal on both front wheels, or on both rear wheels.

Oil pressure change is abnormal on all four wheels.

Go to "Electrical System Diagnostic Procedures". Refer to Diagnostic Procedures 1 to 7. FA-81

Replace affected pressure control unit.

Was problem solved?

Yes No (Problem still exists).

END

Replace affected actuator.

No (Abnormal)

Is flow control valve operation normal on CONSULT data monitor screen?


Go to "Electrical System Diagnostic Procedures". Refer to Diagnostic Procedures 1 to 7. FA-81

Yes (Normal)

Replace multi valve unit.

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 11 (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12

SYMPTOM: Noise

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
1	Thudding noise As if vehicle floor is being hit with a boulder	Heard directly after starting engine, or during cranking, or directly after cranking. Sometimes heard within 3 minutes after stopping engine.	Warning lamp illuminates due to drop in voltage	<p>Check method and remedy</p> <pre> graph TD Start[Open and close fail-safe valve using CONSULT.] --> Branch1{Similar noise is not heard.} Branch1 --> End1[Check other causes.] Start --> Branch2{Similar noise is heard.} Branch2 --> Step1[Charge or replace battery.] Step1 --> Step2[Re-check for noise.] Step2 --> Branch3{No noise is heard.} Branch3 --> End2[END] Step2 --> Branch4{Noise is heard.} Branch4 --> Step3[Replace multi valve.] </pre>
2	Clicking noise As if floor is being hit with pebbles	1.5 to 2 seconds after starting engine		<pre> graph TD Start[Re-start engine more than 3 minutes after stopping.] --> Branch1{No noise is heard.} Branch1 --> End1[Check other causes.] Start --> Branch2{Noise is heard after starting engine.} Branch2 --> Step1[Check return pipes of front and rear pressure control valves for vibration when noise is heard.] Step1 --> Step2[Replace unit where the greater vibration is felt.] </pre>
3	Booming noise Like a steam whistle of a steamboat	Heard when driving on bad roads at low speeds and low engine rpm, or when suspension is continuously caused to oscillate largely. (When oil temperature is high)	Vibration of floor	<p>Check by using method (a) or (b), preferably method (a).</p> <pre> graph TD Start[Drive vehicle with CONSULT set in fail-safe mode.] --> Branch1{Noise is heard.} Branch1 --> End1[Check other causes.] Start --> Branch2{No noise is heard.} Branch2 --> Step1[Replace pump accumulator.] Step1 --> Step2[Re-check for noise during driving.] Step2 --> Branch3{No noise is heard.} Branch3 --> End2[END] Step2 --> Branch4{Noise is heard.} Branch4 --> Step3[Replace pump assembly.] subgraph Method_b [b] Start_b[When oil temperature rises to 60°C (140°F) or higher, simultaneously move all four wheels up and down using CONSULT active test mode.] --> Branch5{No noise is heard.} Branch5 --> End3[Check other cause.] Start_b --> Step1 end </pre>

Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19 MPH) when fail-safe valve is closed by CONSULT.

*2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.

*3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.

*4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12 (Cont'd)

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
4	<p>Creaking noise</p> <p>Like the noise heard when underfloor plumbing is vibrating</p>	<p>Heard when suspension oscillates slowly and broadly up and down, particularly during its compression stroke. Front side or rear side is the source of noise.</p>	<p>Often accompanied by noise of No. 5</p>	<p>Check by using methods (a) or (b), preferably method (a).</p> <pre> graph TD A[Drive vehicle with CONSULT set in fail-safe mode.] -- "Noise is heard." --> B[Check other causes.] A -- "No noise is heard." --> C[Bleed air from suspect pressure control unit.] C -- "Noise is heard." --> D[Move all four wheels up and down simultaneously using CONSULT's active test mode.] D -- "No noise is heard." --> E[Check other causes.] D -- "Noise is heard." --> C E --> F[Check again during driving.] F -- "No noise is heard." --> G[END] F -- "Noise is heard." --> H[Replace pressure control unit.] </pre>
5	<p>Squeaking noise</p> <p>Like short, abrupt repetition of a whistle</p>	<p>Heard when suspension is abruptly caused to oscillate up and down during driving. Front side or rear side is the source of noise.</p>	<p>Accompanied by noise No. 4</p>	<pre> graph TD A[Drive vehicle with CONSULT set in fail-safe mode.] -- "Noise is heard." --> B[Check other causes.] A -- "No noise is heard." --> C[Replace suspect pressure control unit.] </pre>

- Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19MPH) when fail-safe valve is closed by CONSULT.
 *2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.
 *3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.
 *4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12 (Cont'd)

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
6	Hissing noise (Heard from multi valve and surrounding portion) Like a breath escaping from between the teeth	Continuously heard while parked with engine idling, or when driving on a smooth road at low speeds.	—	Check by using method (a) or (b), preferably method (a). <pre> graph TD A[Check by setting CONSULT in fail-safe mode.] -- "*1 Heard inside compartment" --> B[Check other causes.] A -- "Not heard inside compartment Note: Heard outside compartment" --> C[Check rear return pipe for interference.] C -- "Interference is found" --> D[Repair interference] C -- "No interference" --> E[Replace multi valve.] F[Move all four wheels up and down simultaneously by using CONSULT's active test mode.] --> G[Check again.*4] G -- "Different noise is heard." --> H[Check other causes.] G -- "Noise is heard." --> I[Check again.*4] I -- "No noise is heard." --> J[END] I -- "Noise is heard." --> E </pre>
7	Intermittent hissing noise Like short, intermittent version of (6)	Heard while parked with engine idling and vehicle is oscillated up and down (by passenger getting on or out of rear seat, or other reason). Heard particularly on rear right side outside vehicle.	—	<pre> graph TD A[Check by setting CONSULT in fail-safe mode.] -- "Noise is heard." --> B[Check other causes.] A -- "No noise is heard." --> C[Normal. (This noise is created by oil flowing rapidly.) If noise is excessively loud, replace rear pressure control valve unit.] </pre>

- Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19MPH) when fail-safe valve is closed by CONSULT.
 *2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.
 *3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.
 *4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12 (Cont'd)

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
8	Whining noise A noise like a rotating motor sound	Intermittently heard at intervals of one to two minutes while parked with engine idling. This noise is heard only when oil temperature is high. It is heard from front left side on outside of vehicle.	Air is sucked from opening on left side of front bumper.	<div style="text-align: right; margin-bottom: 5px;">No noise is heard when turning ON.</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Turn oil cooler fan ON and OFF using CONSULT active test mode.</div> <div style="text-align: right; margin-bottom: 5px;">Check other causes.</div> <div style="text-align: center; margin-bottom: 5px;">↓ Noise is heard when turning ON.</div> <div style="border: 1px solid black; padding: 5px;">Normal (Oil cooler fan operating noise)</div>
9	Clacking noise A noise like the one emitted when a relay is broken	Heard only once from rear side of rear seat about 1 to 3 minutes after stopping engine.	—	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Is noise accompanied by large change in vehicle height when oil temperature is normal?</div> <div style="text-align: right; margin-bottom: 5px;">No → Normal (Relay noise)</div> <div style="text-align: center; margin-bottom: 5px;">↓ Yes</div> <div style="border: 1px solid black; padding: 5px;">Replace multi valve.</div>
10	Crashing noise A big bang as if the body bottom is hitting the ground	Heard when front wheel drives down a curb of 100 mm (3.94 in) or higher at speeds of 15 km/h (9 MPH) or higher.	—	<div style="text-align: right; margin-bottom: 5px;">Noise is heard.</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Check by setting CONSULT in active test mode, with 9,807 kPa (100 kg/cm², 1,422 psi) applied to all four wheels.</div> <div style="text-align: right; margin-bottom: 5px;">Check other causes.</div> <div style="text-align: center; margin-bottom: 5px;">↓ No noise is heard.</div> <div style="border: 1px solid black; padding: 5px;"> <ul style="list-style-type: none"> • Normal, if this noise is heard when driving down from a height of 100 mm (3.94 in) or higher at speeds of 15 km/h (9 MPH) or higher. • If this noise is heard when the curb height is lower than 100 mm (3.94 in) and speed is lower than 15 km/h (9 MPH), then replace front actuator. </div>

- Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19MPH) when fail-safe valve is closed by CONSULT.
 *2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.
 *3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.
 *4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12 (Cont'd)

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
11	<p>Groaning noise</p> <p>Whirring sound like a fuel pump operating</p>	<p>Heard when vehicle body is swung back while braking at low speeds (especially when oil temperature is high)</p>	—	<pre> graph TD A[Move vehicle up and down using CONSULT active test mode. Does noise occur when vehicle height is changed?] -- No --> B[Check other causes.] A -- Yes --> C[Change vehicle height one wheel at a time, and bleed air from pressure control unit of suspect wheel.] C --> D[Re-check.] D -- "No noise is heard. *4" --> E[END] D -- "Noise is heard." --> F[If noise is still heard, bleed air from pressure control unit of other wheels.] F --> G[Re-check.] G -- "No noise is heard. *4" --> H[END] G -- "Noise is heard." --> I[Replace pressure control unit.] </pre>
12	<p>Tapping noise, or vibrating noise</p> <p>As if the suspension is being hit and vibrated</p>	<p>Heard from front or rear part of vehicle directly after driving over a small step or while driving on a bad road.</p>	—	<pre> graph TD A[Check with CONSULT set in fail-safe mode.] -- "No noise is heard." --> B[Check other causes.] A -- "Noise is heard. *1" --> C[Check pressure control valve return pipe for interference.] C -- "Interference" --> D[Repair interference.] C -- "No interference" --> E[Replace pressure control unit of suspect side.] D --> F[Re-check.] E --> F F -- "No noise is heard." --> G[END] F -- "Noise is heard. *4" --> E </pre>

- Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19MPH) when fail-safe valve is closed by CONSULT.
 *2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.
 *3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.
 *4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12 (Cont'd)

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
13	Humming*2 noise Pumping noise like when power steering is operated with the vehicle stopped	Heard in compartment when engine speed is within range from idling to 1,300 rpm.	Sometimes accompanied by floor vibration	<div style="text-align: right; margin-bottom: 5px;">Interference</div> <pre> graph TD A[Check pipes for interference.] -- Interference --> B[Repair piping.] A -- No interference --> C[Replace pump assembly.] B --> D[Re-check.*4] D -- No noise is heard --> E[END] D -- Noise is heard --> C C --> F[Re-check.*4] F -- Noise is heard --> G[Replace pump accumulator.] </pre>
14	Rattling*3 noise	Heard in compartment when engine is idling and still cold.	---	<pre> graph TD A[Does noise level lower when oil temperature rises?] -- No --> B[Check other causes.] A -- Yes --> C[Replace pump assembly.] </pre>
15	Buzzing noise	Heard on outside of vehicle (left front part) when engine is still cold	---	<pre> graph TD A[Does noise level lower when oil temperature rises?] -- No --> B[Check other causes.] A -- Yes --> C[Replace pump assembly.] </pre>
16	Creaking noise	Heard when starting engine, or when driving on a bad road at low engine rpms, or when suspension oscillates largely while driving (especially when oil temperature is low).	---	<pre> graph TD A[Check by setting CONSULT in fail-safe mode.*1] -- Noise is heard --> B[Check other causes.] A -- No noise is heard --> C[Bleed air from multi valve.] C --> D[Re-check.*4] D -- Noise is heard --> E[Replace multi valve.] D -- No noise is heard --> F[END] </pre>

- Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19MPH) when fail-safe valve is closed by CONSULT.
 *2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.
 *3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.
 *4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

TROUBLE DIAGNOSES FOR FULL-ACTIVE SUSPENSION SYSTEM

Diagnostic Procedure 12 (Cont'd)

No.	Noise and features	Occurrence	Phenomenon accompanying noise	Check method and remedy
17	Heavy creaking noise	Heard when suspension oscillates largely.	—	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Apply grease to rear active suspension upper side spring seat.</div> <div style="text-align: center;">↓</div> <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 60%;">Re-check.</div> <div style="text-align: right; font-size: small;">*4 Noise is heard.</div> </div> <div style="text-align: center;">↓</div> <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 60%;">END</div> <div style="text-align: right; font-size: small;">No noise is heard.</div> </div> <div style="text-align: center;">↓</div> <div style="border: 1px solid black; padding: 5px; width: 100px; margin-left: auto;">Check other causes.</div>
18	Rumbling noise	Heard when engine is idling or running at 1,500 rpm or higher.	—	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Apply grease to rear active suspension upper side spring seat.</div> <div style="text-align: center;">↓</div> <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 60%;">Re-check.</div> <div style="text-align: right; font-size: small;">*4 Noise is heard.</div> </div> <div style="text-align: center;">↓</div> <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 60%;">END</div> <div style="text-align: right; font-size: small;">No noise is heard.</div> </div> <div style="text-align: center;">↓</div> <div style="border: 1px solid black; padding: 5px; width: 100px; margin-left: auto;">Check other causes.</div>
19	Whizzing or rushing noise	Heard on left outside of vehicle for a few seconds after stopping engine.	—	<div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 60%;">Check operation during suspect period indicated at left.</div> <div style="text-align: right; font-size: small;">No noise is heard.</div> </div> <div style="text-align: center;">↓</div> <div style="display: flex; justify-content: space-between;"> <div style="border: 1px solid black; padding: 5px; width: 60%;"> <ul style="list-style-type: none"> ● Normal (noise caused by rapid oil flow) ● If noisy, even in compartment, replace multi valve. </div> <div style="text-align: right; font-size: small;">Noise is heard during indicated period.</div> </div> <div style="text-align: center;">↓</div> <div style="border: 1px solid black; padding: 5px; width: 100px; margin-left: auto;">Check other causes.</div>

- Notes: *1: Note that the maximum vehicle speed is less than 30 km/h (19MPH) when fail-safe valve is closed by CONSULT.
 *2: This noise resembles A/T pump noise, but pitch is lower than that of A/T pump noise.
 *3: Note that rattling noise can also be heard from engine. Rattling noise originating from pump will be heard distinctly at the inner side of front left tire house.
 *4: The term "re-check" means inspection under normal condition (not in the CONSULT fail-safe mode, etc.).

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COIL SPRING

Applied model	Conventional suspension	Full-active suspension
Identification color	Yellow x 2	Green x 1 Blue x 1

SHOCK ABSORBER

Applied model	Conventional suspension	Full-active suspension
Piston rod diameter mm (in)	12.5 (0.492)	25 (0.98)


FRONT STABILIZER BAR

Applied model	Conventional suspension	Full-active suspension
Stabilizer diameter mm (in)	29 (1.14)	28 (1.10)

TENSION ROD

Applied model	All	
Rod diameter mm (in)	20.0 (0.787)	

WHEELARCH HEIGHT (Unladen*1)



SFA818A

Applied model	Conventional suspension	Full-active suspension	
		Engine running *2	Reference (Engine stopped*3)
Front (Hf) mm (in)	705 (27.76)	687 (27.05)	690 (27.17)
Rear (Hr) mm (in)	696 (27.40)	667 (26.26)	672 (26.46)

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: Unladen, engine running and height control switch in normal (N) position.

*3: ● The data obtained when engine is stopped are reference values. For standard values, use the data obtained by running engine.

● Conditions when engine is stopped:
Unladen, full-active fluid temperature $60 \pm 4^{\circ}\text{C}$ ($140 \pm 7.2^{\circ}\text{F}$).
Ignition switch "OFF" after driver gets out of the vehicle.

● For wheelarch height measurement, wait at least 3 minutes after engine has stopped:

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*1)

Applied model	Conventional suspension	Full-active suspension	
		Engine running*3	Reference (Engine stopped*4)
Camber degree	-1°35' to -0°05'	-1°40' to -0°10'	-1°35' to -0°05'
Caster degree	5°45' - 7°15'	6°10' - 7°40'	5°55' - 7°25'
Kingpin inclination degree	12°00' - 13°30'	12°10' - 13°40'	
Toe-in			
A - B mm (in)	0 - 2 (0 - 0.08)	-1 to 1 (-0.04 to 0.04)	
Total angle 2θ degree	0' - 10'	-5' to 5'	
Front wheel turning angle			
Full turn*2 degree			
Inside	35°30' - 39°30'	35° - 39°	
Outside	32°	32°	

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

*3: Unladen, engine running and height control switch in normal (N) position.

*4: ● The data obtained when engine is stopped are reference values. For standard values, use the data obtained by running engine.

- Conditions when engine is stopped:
Unladen, full-active fluid temperature $60 \pm 4^{\circ}\text{C}$ ($140 \pm 7.2^{\circ}\text{F}$).
Ignition switch "OFF" after driver gets out of the vehicle.
- For alignment measurement, wait at least 3 minutes after engine has stopped:

WHEEL BEARING

Wheel bearing axial end play limit mm (in)	0.05 (0.0020)
Wheel bearing lock nut Tightening torque N·m (kg-m, ft-lb)	206 - 284 (21 - 29, 152 - 210)

LOWER BALL JOINT

Swing force (Measuring point: cotter pin hole of ball stud) N (kg, lb)	7.8 - 53.0 (0.8 - 5.4, 1.8 - 11.9)
Turning torque N·m (kg-cm, in-lb)	0.49 - 3.43 (5.0 - 35, 4.3 - 30.4)
Vertical end play mm (in)	0 (0)

WHEEL RUNOUT (Radial and lateral)

Unit: mm (in)

	Wheel type	Aluminum wheel
Radial runout limit		0.3 (0.012)
Lateral runout limit		0.3 (0.012)