

ENGINE LUBRICATION & COOLING SYSTEMS

SECTION LC

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

CONTENTS

PRECAUTIONS AND PREPARATION	2	System Check.....	7
Liquid Gasket Application Procedure	2	Water Pump.....	8
Special Service Tools	2	Thermostat	10
ENGINE LUBRICATION SYSTEM	3	Radiator	12
Lubrication Circuit.....	3	Cooling Fan (Crankshaft driven)	13
Oil Pressure Check.....	4	Cooling Fan (Motor driven)	13
Oil Pump.....	5	SERVICE DATA AND SPECIFICATIONS (SDS)	14
ENGINE COOLING SYSTEM	7	Engine Lubrication System.....	14
Cooling Circuit	7	Engine Cooling System	14





PRECAUTIONS AND PREPARATION



Liquid Gasket Application Procedure



- a. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- b. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- c. Apply liquid gasket to inner side as shown at the left. (Assembly should be done within 5 minutes after coating.)
- d. Wait 30 minutes before refilling engine oil and coolant.

Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description
ST25051001 (J25695-1) Oil pressure gauge	 <p style="text-align: right;">Measuring oil pressure</p> <p style="text-align: right;">Maximum measuring range: 2,452 kPa (25 kg/cm², 356 psi)</p> <p>NT558</p>
ST25052000 (J25695-2) Hose	 <p style="text-align: right;">Adapting oil pressure gauge to cylinder block</p> <p>NT559</p>
WS39930000 (—) Tube presser	 <p style="text-align: right;">Pressing the tube of liquid gasket</p> <p>NT052</p>
EG17650301 (J33984-A) Radiator cap tester adapter	 <p style="text-align: right;">Adapting radiator cap tester to radiator filler neck</p> <p style="text-align: right;">Unit: mm (in)</p> <p style="text-align: right;">a: 28 (1.10) dia.</p> <p style="text-align: right;">b: 31.4 (1.236) dia.</p> <p style="text-align: right;">c: 41.3 (1.626) dia</p> <p>NT564</p>

ENGINE LUBRICATION SYSTEM

Lubrication Circuit




GI
MA
EM
LC
EF & EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Oil Pressure Check

WARNING:

- Be careful not to burn yourself, as the engine and oil may hot.
- Oil pressure check should be done in "Neutral position".



1. Check oil level.
2. Remove oil pressure switch.



3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.


Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 98 (1.0, 14)
3,000	461 - 559 (4.7 - 5.7, 67 - 81)

If difference is extreme, check oil passage and oil pump for oil leaks.

6. Install oil pressure switch with sealant.

ENGINE LUBRICATION SYSTEM

Oil Pump




INSPECTION

If it exceeds the limit, replace gear set or entire oil pump assembly.





Standard clearance:

	Unit: mm (in)
Drive shaft to cover and housing: ①	0.024 - 0.069 (0.0009 - 0.0027)
Driven gear to driven shaft : ②	0.025 - 0.064 (0.0010 - 0.0025)
Drive and driven gear to housing: ③	0.08 - 0.130 (0.0031 - 0.0051)
Drive and driven gear to housing: ④	0.125 - 0.245 (0.0049 - 0.0096)



ENGINE LUBRICATION SYSTEM

Oil Pump (Cont'd)



REGULATOR VALVE INSPECTION

1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls freely into the valve hole by its own weight.
4. Check regulator valve to oil pump cover clearance.



Standard clearance:

L : 0.040 - 0.097 mm (0.0016 - 0.0038 in)

If damaged, replace regulator valve set or oil pump assembly.

ENGINE COOLING SYSTEM

Cooling Circuit



System Check

WARNING:

Never remove the filler cap nor radiator cap when the engine is hot. Serious burns could be caused by hot high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by first turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

ENGINE COOLING SYSTEM

System Check (Cont'd)

CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

CHECKING COOLING SYSTEM FOR LEAKS

To check for leakage, apply pressure to the cooling system with a tester.

Testing pressure:

157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher than the specified pressure may damage radiator.

CHECKING RADIATOR CAP

To check radiator cap, apply pressure to cap with a tester.






Radiator cap relief pressure:

Standard

78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)




Water Pump

REMOVAL

1. Drain coolant from drain cocks on both sides of cylinder block and radiator.
2. Remove fan coupling with fan.
3. Loosen power steering pump drive belt.
4. Remove water pump.


ENGINE COOLING SYSTEM

Water Pump (Cont'd)




CAUTION:

- When removing water pump assembly, be careful not to get coolant on drive belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.



INSPECTION

1. Check for badly rusted or corroded vanes and body assembly.
2. Check for rough operation due to excessive end play.




INSTALLATION

1. Use a scraper to remove old liquid gasket from water pump.
 - Also remove traces of liquid gasket from mating surface of cylinder block.
2. Apply a continuous bead of liquid gasket to mating surface of water pump.
 - Use Genuine Liquid Gasket or equivalent.

ENGINE COOLING SYSTEM

Thermostat



REMOVAL AND INSTALLATION

Removal



1. Drain coolant from drain cocks on both sides of cylinder block and radiator
2. Remove front ornament cover.
3. Remove water inlet and thermostat.

ENGINE COOLING SYSTEM


Thermostat (Cont'd)

Installation

- Use a scraper to remove old liquid gasket from water inlet.
- Similarly, remove liquid gasket from mating surface.
- Clean all traces of liquid gasket using white gasoline.




- Cut off tip of nozzle of liquid gasket tube at point shown in figure.
- Use Genuine Liquid Gasket or equivalent.



INSPECTION

1. Check for valve seating condition at ordinary temperatures. It should seat tightly.



2. Check valve opening temperature and maximum valve lift.

Valve opening temperature	°C (°F)	76.5 (170)
Maximum valve lift	mm/°C (in/°F)	10/90 (0.39/194)

3. Then check if valve closes at 5°C (9°F) below valve opening temperature.

- After installation, run engine for a few minutes, and check for leaks.
- Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

GI

MA

EM

LC

EF &
EC

FE

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX


ENGINE COOLING SYSTEM

Radiator



REMOVAL AND INSTALLATION


1. Remove air guide.
2. Remove radiator lower shroud.
3. Loosen both A/T upper oil cooler hose clamps and turn the clamps to make room.
4. Remove filler cap above radiator upper hose.
5. Remove undercover.
6. Drain coolant from radiator drain cock.
7. Detach A/T oil cooler hoses from clip of shroud.



8. Remove pump accumulator nuts (3) and move the pump accumulator as shown on the left.
9. Loosen bolts of A/T oil cooler hose bracket and remove bracket from radiator shroud.
10. Remove upper shroud screws (4).
11. Remove upper shroud.
12. Disconnect A/T oil cooler hoses and radiator hoses.
13. Remove radiator mounting bracket.
14. Remove radiator.

ENGINE COOLING SYSTEM

Radiator (Cont'd)




15. After repairing or replacing radiator, reinstall any part in reverse order of removal.

CAUTION:

- When disconnecting A/T oil cooler hoses and radiator hoses, check A/T fluid and engine coolant levels. Refill if necessary.
- Check level of A/T fluid. (Refer to "Checking A/T fluid" in MA section.)
- Check level of coolant. (Refer to "Checking Engine Coolant" in MA section.)


Cooling Fan (Crankshaft driven)

DISASSEMBLY AND ASSEMBLY



INSPECTION

Check fan coupling for rough operation, oil leakage or bent bimetal.



Cooling Fan (Motor driven)

This cooling fan is controlled by ECM (ECCS control module). Refer to "ENGINE AND EMISSION CONTROL SYSTEM DESCRIPTION" in EF & EC section.

GI

MA

EM

LC

EF & EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Lubrication System

Oil pressure check

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
Idle speed	More than 98 (1.0, 14)
3,000	461 - 559 (4.7 - 5.7, 67 - 81)

Regulator valve inspection

Unit: mm (in)

Regulator valve to oil pump clearance (L)	0.040 - 0.097 (0.0016 - 0.0038)
--	---------------------------------

Oil pump

Unit: mm (in)

Drive shaft to oil pump cover and housing: (C)	0.024 - 0.069 (0.0009 - 0.0027)
Driven gear to driven shaft: (F)	0.025 - 0.064 (0.0010 - 0.0025)
Drive and driven gear to oil pump housing: (G)	0.08 - 0.130 (0.0031 - 0.0051)
Drive and driven gear to oil pump housing: (H)	0.125 - 0.245 (0.0049 - 0.0096)

Engine Cooling System

Thermostat

	Standard
Valve opening temperature °C (°F)	76.5 (170)
Maximum valve lift mm/°C (in/°F)	10/90 (0.39/194)

Radiator

Unit: kPa (kg/cm², psi)

Cap relief pressure	
Standard	78 - 98 (0.8 - 1.0, 11 - 14)
Limit	59 - 98 (0.6 - 1.0, 9 - 14)
Leakage test pressure	157 (1.6, 23)