

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

POWER SUPPLY ROUTING	2	BODY NO.2 HARNESS	51
Schematic	2	ROOM LAMP HARNESS	52
Wiring Diagram — POWER —	3	FRONT DOOR HARNESS	53
BATTERY POWER SUPPLY—IGNITION SW.IN ANY POSITION	3	REAR DOOR HARNESS	54
ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”	7	Wiring Diagram Codes (Cell Codes)	55
IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”	9	ELECTRICAL UNITS LOCATION	58
GROUND	13	Electrical Units Location	58
Ground Distribution	13	ENGINE COMPARTMENT	59
MAIN HARNESS	13	PASSENGER COMPARTMENT	60
ENGINE ROOM HARNESS	16	LUGGAGE COMPARTMENT	63
ENGINE HARNESS	19	Fuse	64
ENGINE CONTROL HARNESS	20	Fusible Link	64
BODY HARNESS	22	Circuit Breaker	64
BODY NO.2 HARNESS	24	HARNESS CONNECTOR	65
HARNESS	26	Description	65
Harness Layout	26	HARNESS CONNECTOR (TAB-LOCKING TYPE)	65
HOW TO READ HARNESS LAYOUT	26	HARNESS CONNECTOR (SLIDE-LOCKING TYPE)	66
OUTLINE	27	JOINT CONNECTOR (J/C)	67
MAIN HARNESS	28	Terminal Arrangement	67
ENGINE ROOM HARNESS	31	ELECTRICAL UNITS	68
ENGINE HARNESS	34	Terminal Arrangement	68
ENGINE CONTROL HARNESS	35	SMJ (SUPER MULTIPLE JUNCTION)	70
BODY HARNESS AND REAR CONTROL HAR- NESS	37	Terminal Arrangement	70
BODY NO. 2 HARNESS	39	STANDARDIZED RELAY	73
ROOM LAMP HARNESS	41	Description	73
FRONT DOOR HARNESS	42	NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS	73
REAR DOOR HARNESS	43	TYPE OF STANDARDIZED RELAYS	73
Splice Location	44	FUSE BLOCK - JUNCTION BOX (J/B) NO.1	75
HOW TO READ SPLICE LOCATION	44	Terminal Arrangement	75
MAIN HARNESS	45	FUSE BLOCK - JUNCTION BOX (J/B) NO.2	76
ENGINE ROOM HARNESS	46	Terminal Arrangement	76
ENGINE HARNESS	48	FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)	77
ENGINE CONTROL HARNESS	49	Terminal Arrangement	77
BODY HARNESS AND REAR CONTROL HAR- NESS	50	FUSE, FUSIBLE LINK AND RELAY BOX	78


POWER SUPPLY ROUTING

POWER SUPPLY ROUTING

Schematic

PFP:00011

EKS000DP





TKWM0220E

POWER SUPPLY ROUTING

Wiring Diagram — POWER — BATTERY POWER SUPPLY— IGNITION SW. IN ANY POSITION




EKS000DQ

PG-POWER-01



POWER SUPPLY ROUTING

PG-POWER-02





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TKWM0238E

POWER SUPPLY ROUTING

PG-POWER-03



REFER TO THE FOLLOWING.


(M1, E201, E202, B1, R1) -FUSE BLOCK- JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TKWM0221E



POWER SUPPLY ROUTING



TKWM0222E

POWER SUPPLY ROUTING

ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”



REFER TO THE FOLLOWING.
(E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1, E201, E202) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1


1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TKWM0239E

POWER SUPPLY ROUTING


PG-POWER-06



POWER SUPPLY ROUTING

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”

PG-POWER-07



REFER TO THE FOLLOWING.

(E205) -SUPER MULTIPLE JUNCTION (SMJ)

(M1), (E202), (B2), (R1) -FUSE BLOCK-

JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

(E3) -FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

B	51	52	53	54	55	56	57
---	----	----	----	----	----	----	----


58

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TKWM0223E

POWER SUPPLY ROUTING

PG-POWER-08



REFER TO THE FOLLOWING.



(M1, E201)
-FUSE BLOCK-JUNCTION
BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWM0224E

POWER SUPPLY ROUTING

PG-POWER-09



REFER TO THE FOLLOWING.

(M143, M145, E215, B201)
-FUSE BLOCK-JUNCTION BOX (J/B) NO.2



31 32 33 34 35 36 37 38

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TKWM0225E

POWER SUPPLY ROUTING

PG-POWER-10



REFER TO THE FOLLOWING.

(M1, B1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

GROUND


GROUND

Ground Distribution MAIN HARNESS

PFP:00011

EKS000DR

A
B
C
D
E
F
G
H
I
J
PG




A Next page

GROUND

A Preceding page


CONNECTOR NUMBER	CONNECT TO
(M82)	Display (Terminal No. 22)
(M82)	Display (Terminal No. 24)
(M83)	Multifunction switch
(M91)	Combination flasher unit
(M92)	Front cigarette lighter socket
(M96)	Handset (Option)
(M97)	A/T device
(M100)	Front power socket
(M102)	Console box lamp
(M106)	Mode door motor (Passenger side)
(M107)	Air mix door motor (Passenger side)
(M108)	Power steering control unit
(M109)	CD auto changer
(M144)	Fuse block (J/B) No. 2 • Blower relay
(B503)	Rear sunshade rear switch (Terminal No. 5)
(B503)	Rear sunshade rear switch (Terminal No. 3)
(D32)	Door mirror (Passenger side) • Turn signal • Door mirror defogger
(D35)	Passenger side door mirror control unit (LCU04)
(D37)	Front power window regulator (Passenger side)
(D39)	Passenger door control unit
(D41)	Front door lock actuator (Passenger side)



Body ground

CKIM0080E

GROUND




CKIM0081E

GROUND

ENGINE ROOM HARNESS

CON-NECTOR NUMBER	CONNECT TO
(E3)	Fuse, fusible link and relay block (J/B) (Terminal No. 29R) • Ignition relay • Park/Neutral position relay
(E4)	Front wiper relay
(E31)	Front shock absorber actuator RH
(E36)	A/T pv ign relay
(E38)	ICC brake hold relay (With ICC)
(E52)	ICC sensor (With ICC)
(E73)	Brake fluid level switch (Terminal No. 1)
(E73)	Brake fluid level switch (Terminal No. 2)
(E201)	Fuse block (J/B) No. 1 (Terminal No. 1E) • Accessory relay • Trunk lid opener relay
(R1)	Fuse block (J/B) No. 1 (Terminal No. 5K)
(R5)	Vanity mirror lamp (Driver side) • Homelink universal transceiver
(R13)	Rear interior lamp • Personal lamp LH • Personal lamp RH
(R11)	Rear sunshade front switch
(R9)	Auto anti-dazzling inside mirror
(R12)	Vanity mirror lamp (Passenger side)
(R6)	Front interior lamp • Spot lamp LH • Spot lamp RH • Interior lamp ill switch
(F3)	Power steering solenoid valve
(F103)	Shield wire [(TCM (Transmission control module)] (For circuit from terminal No. 2)

J/C: Joint connector





Next page


CKIM0082E

GROUND



A Preceding page



CONNECTOR NUMBER	CONNECT TO
(E65)	Front combination lamp LH (Terminal No. 6) • Parking




CONNECTOR NUMBER	CONNECT TO
(E45)	Front combination lamp RH (Terminal No. 8) • Headlamp
(E26)	Daytime light control unit
(E45)	Front combination lamp RH (Terminal No. 2) • Turn signal
(E46)	Front combination lamp RH (Terminal No. 10) • Headlamp aiming motor
(E46)	Front combination lamp RH (Terminal No. 16) • Side marker
(E47)	Washer level switch
(E54)	Hood switch
(E61)	Front shock absorber actuator LH
(E65)	Front combination lamp LH (Terminal No. 2) • Turn signal
(E65)	Front combination lamp LH (Terminal No. 8) • Headlamp
(E66)	Front combination lamp LH (Terminal No. 10) • Headlamp aiming motor
(E66)	Front combination lamp LH (Terminal No. 16) • Side marker
(E75)	Front wiper motor
(E45)	Front combination lamp RH (Terminal No. 6) • Parking



A
B
C
D
E
F
G
H
I
J
PG


GROUND



CKIM0017E

GROUND

ENGINE HARNESS




A
B
C
D
E
F
G
H
I
J
L
M

CKIM0018E

PG

GROUND


ENGINE CONTROL HARNESS



A B Next page

CKIM0083E

GROUND




A
B
C
D
E
F
G
H
I
J

PG
L
M

CKIM0084E

GROUND

BODY HARNESS




GROUND

A
B
C
D
E
F
G
H
I
J
PG
L
M

CON-NECTOR NUMBER	CONNECT TO
(B45)	Dropping resistor
(B30)	AV and NAVI control unit (With NAVI) (Terminal No. 1)
(B30)	AV and NAVI control unit (With NAVI) (Terminal No. 4)
(B30)	AV and NAVI control unit (With NAVI) (Terminal No. 5)
(B33)	AV control unit (For Canada with rear control switch) (Terminal No. 1)
(B33)	AV control unit (For Canada with rear control switch) (Terminal No. 4)
(B33)	AV control unit (For Canada with rear control switch) (Terminal No. 5)
(B37)	Active damper suspension control unit (Terminal No. 8)
(B37)	Active damper suspension control unit (Terminal No. 23)
(B46)	Trunk lid key cylinder switch (Unlock switch)
(B47)	License lamp LH
(B48)	License lamp RH
(B50)	Rear view camera
(B53)	Rear combination lamp LH • Stop/Tail • Back-up • Turn signal
(B54)	Trunk room lamp switch
(B58)	Rear combination lamp RH • Stop/Tail • Back-up • Turn signal
(B69)	Voice activated control module
(B72)	Option connector-1 for voice activated system (Terminal No. 1)
(B72)	Option connector-1 for voice activated system (Terminal No. 2)
(B73)	Dual mode muffler control unit


GB3
B57
Body ground




CKIM0085E

GROUND

BODY NO.2 HARNESS



GROUND



A
B
C
D
E
F
G
H
I
J

CKIM0024E

PG

L

M

HARNESS

HARNESS

PFP:00011

Harness Layout

HOW TO READ HARNESS LAYOUT

EKS000DS

The following Harness Layouts use a map style grid to help locate connectors on the drawings:


- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness and Rear Control Harness
- Body No.2 Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.




SEL252V

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9	—	—		
• Ground terminal etc.	—			

SKIA0404E

HARNESS

OUTLINE




A
B
C
D
E
F
G
H
I
J

PG

L
M

HARNESS

MAIN HARNESS



CKIM0090E

HARNESS

A3	★ (M1) SMJ	Fuse block (J/B) No. 1	
A4	(M4) SMJ	BCM (Body control module)	
A4	(M5) SMJ	To (B5)	
A3	(M6) GY/24	To (B6)	(With NAVI and for Canada with rear control switch)
B4	(M7) W/24	To (B7)	(With NAVI and for Canada with rear control switch)
B4	(M8) B/1	Parking brake switch	
A3	(M9) P/20	Joint connector-1	
A3	(M10) B/20	Joint connector-2	
A3	(M11) SMJ	To (D1)	
C3	(M12) W/8	Shift lock control unit	
A2	(M13) GY/6	VDC off switch	
B3	(M15) SMJ	To (E205)	
B3	(M16) Y/4	To (E206)	
A3	(M17) W/3	Illumination control switch	
A2	(M18) W/4	Headlamp aiming switch	
B2	(M19) W/10	Door mirror remote control switch (With memory mirror)	
B3	(M20) GY/4	Active damper suspension select switch	
B2	(M21) GY/20	Joint connector-3	
B2	(M22) L/20	Joint connector-4	
A1	(M23) W/18	To (R3)	
B2	(M24) -	Body ground	
B2	(M25) -	Body ground	
A2	(M28) W/10	Door mirror remote control switch (Without memory mirror)	
B3	(M29) W/2	Low tire pressure warning check switch	
B3	(M31) W/16	Data link connector	
C3	(M32) W/16	NATS IMMU	
B2	(M33) W/6	Headlamp battery saver control unit	
C3	(M34) W/8	Headlamp battery saver control unit	
C3	(M35) BR/24	ASCD control unit (Without ICC)	
B3	(M37) W/3	ICC warning chime (With ICC)	
B1	(M38) P/20	Joint connector-5	
B2	(M39) W/8	To (M40)	
B1	(M40) W/8	To (M39)	
C1	(M41) BR/20	Combination meter	
B1	★ (M42) BR/24	Combination meter	
C1	★ (M43) W/24	Combination meter	
B1	(M44) B/2	Sunload sensor	
D1	(M45) W/6	Joint connector-6	
C1	★ (M46) B/20	Joint connector-7	
C1	(M47) GY/20	Joint connector-8	
D1	(M48) B/20	Joint connector-9	
E2	(M50) GY/3	AV control unit	(Except for Canada with rear control switch)
C3	(M51) GY/6	ADP steering switch	
C3	(M52) W/8	Steering wheel angle sensor	
D3	(M53) GY/8	Combination switch (Spiral cable)	
D3	(M54) Y/6	Combination switch (Spiral cable)	
C3	(M55) W/12	Combination switch (Lighting switch)	
D2	(M56) GY/12	Combination switch (Front wiper switch)	
D3	(M57) W/3	Tilt sensor	
D3	(M58) W/2	Tilt motor	
C2	(M59) W/3	Telescopic sensor	
C2	(M60) W/2	Telescopic motor	
D2	★ (M61) W/4	To (M40)	
D2	(M64) W/4	Key switch and key lock solenoid	
D2	(M65) W/6	NATS antenna amp.	
D3	(M68) W/2	In-vehicle sensor	
D2	(M69) GY/4	Steering lock control unit	
D2	(M70) B/5	Ignition switch	
D1	(M71) W/4	Hazard switch	
D2	(M72) W/2	Ignition key hole illumination	
E1	(M74) W/3	Warning chime	
E2	(M75) W/4	Clock	
E2	(M77) GY/24	AV control unit	{ Except for Canada with rear control switch }
E1	(M78) W/24	AV control unit	
F1	★ (M79) G/20	Joint connector-11	
E1	★ (M80) R/20	Joint connector-12	

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

CKIM0091E

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

PG

HARNESS

E1	(M81) P/20	: Joint connector-13
D1	(M82) GY/24	: Display
E1	(M83) W/20	: Multifunction switch
E2	(M84) W/16	: Low tire pressure warning control unit
D3	(M86) W/12	: Audio unit
E3	(M87) W/16	: Audio unit
E3	(M88) W/12	: Audio unit
E2	(M89) BR/2	: Antenna amp. (Via sub-harness)
D3	(M90) W/6	: Cooling unit assembly
E3	(M91) W/8	: Combination flasher unit
E3	(M92) W/3	: Front cigarette lighter socket
E3	(M93) B/6	: Rear vent door motor
E3	(M94) W/6	: Heated seat switch (Driver side)
F3	(M95) BR/6	: Heated seat switch (Passenger side)
F3	(M96) W/4	: Handset (Option)
E4	(M97) W/12	: A/T device
E4	(M99) B/6	: Yaw rate and side G sensor
G4	(M100) B/2	: Front power socket
B5	(M101) W/24	: To (B501)
F4	(M102) W/2	: Console box lamp
F4	(M103) Y/28	: Air bag diagnosis sensor unit
E2	(M106) W/3	: Mode door motor (Passenger side)
E2	(M107) W/3	: Air mix door motor (Passenger side)
F1	(M108) W/8	: Power steering control unit
F2	(M109) W/16	: CD auto changer
F1	(M110) W/3	: Optical sensor
D1	(M111) W/6	: To (M411)
F2	(M112) W/6	: Blower motor
E1	(M114) -	: Body ground
F1	(M115) -	: Body ground
G1	(M116) W/2	: Glove box lamp
G1	(M117) W/2	: Trunk lid opener cancel switch
F1	(M118) W/3	: Intake door motor
F2	(M119) GY/20	: A/C auto amp.
F2	(M120) GY/16	: A/C auto amp.
F2	(M121) Y/4	: Front passenger air bag module
E1	(M123) L/20	: Joint connector-14
G1	(M124) B/20	: Joint connector-15
F1	(M125) B/20	: Joint connector-16
G1	★ (M126) B/20	: Joint connector-17
G1	(M127) OR/20	: Joint connector-18
G1	★ (M128) OR/20	: Joint connector-19
E1	(M129) B/20	: Joint connector-20
G1	★ (M130) W/6	: Joint connector-21
F3	(M132) W/24	: To (E222)
F3	★ (M133) W/12	: To (E223)
G2	★ (M135) SMJ	: To (F105)
G3	(M137) W/3	: To (B207) (With rear view camera)
G3	(M138) BR/24	: To (B208) (With ICC)
G3	(M139) W/4	: To (B209) (With rear view camera or rear heated seat)
G3	(M140) GY/6	: To (B210)
G2	★ (M141) SMJ	: To (B211)
G2	(M142) SMJ	: To (D31)
G2	★ (M143) W/10	: Fuse block (J/B) No. 2
F3	(M144) W/8	: Fuse block (J/B) No. 2
F3	★ (M145) W/8	: Fuse block (J/B) No. 2

Main sub-harness-1

★ (M401) W/4	: To (M61)
★ (M402) B/2	: Stop lamp switch
(M403) BR/2	: ASCD brake switch (Without ICC)
(M404) BR/2	: ICC brake switch (With ICC)

Main sub-harness-2

(M41) W/6	: To (M11)
(M402) B/2	: Instrument speaker LH
(M403) BR/2	: Instrument speaker CENTER
(M404) BR/2	: Instrument speaker RH


★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

CKM0092E

HARNESS

ENGINE ROOM HARNESS

Engine Compartment



A
B
C
D
E
F
G
H
I
J
K
L
M
PG

HARNESS


C1	E1	-	: Engine room box
A1	E2	-	: Fuse, fusible link and relay box
C1	E3	SMJ	: Fuse, fusible link and relay block (J/B)
A1	E4	B/5	: Front wiper relay
A1	E5	L/4	: Headlamp relay-2
D1	E15	SB/4	: ASCD pump (With ICC)
D1	E16	SB/4	: ASCD pump (Without ICC)
D2	E20	GY/2	: Front wheel sensor RH
D1	E21	DGY/8	: VDC actuator
D1	E22	SB/8	: VDC actuator
D2	E23	B/2	: VDC actuator
D2	E24	-	: Body ground
D3	E26	SB/8	: Daytime light control unit
D2	E27	SB/6	: Daytime light control unit
D2	E28	SB/4	: Daytime light control unit
D1	E31	GY/6	: Front shock absorber actuator RH
C3	E32	SB/8	: To (F32)
C2	E33	GY/10	: To (F33)
C2	E34	G/10	: To (F34)
C2	E35	GY/9	: To (E305)
C1	E36	L/4	: A/T pv ign relay
C1	E37	-	: Fuse block
C1	E38	GY/6	: ICC brake hold relay (With ICC)
B2	E42	-	: Body ground
C3	E43	B/1	: Horn low
B2	E44	-	: Body ground
B2	E45	DGY/8	: Front combination lamp RH
B2	E46	SB/8	: Front combination lamp RH
B3	E47	BR/2	: Washer level switch
B3	E48	GY/2	: Front washer motor
B3	E49	B/3	: Refrigerant pressure sensor
C3	E52	-6	: ICC sensor (With IC/C)
C3	E54	GY/2	: Hood switch
D3	E55	GY/2	: VDC relay box
D3	E56	DGY/8	: VDC relay box
D3	E57	B/2	: VDC relay box
C3	E58	B/2	: Ambient sensor
C3	E59	-	: Body ground

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

CKIM0094E

HARNESS

Passenger Compartment





E201	W/8 : Fuse block (J/B) No. 1
E202	W/4 : Fuse block (J/B) No. 1
E203	W/4 : Fuse block (J/B) No. 1
E204	BR/8 : BCM (Body control module)
E205	SMJ : To M15
E206	Y/4 : To M16
E211	W/20 : To B11
E212	BR/6 : To B12 (With active damper suspension)
E213	E214
E215	W/6 : Fuse block (J/B) No. 2
E216	P/20 : Joint connector-25
E218	SMJ : VDC/TCS/ABS control unit
E222	W/24 : To M132
★ E223	W/12 : To M133
★ E224	BR/4 : To B204
E225	W/20 : To B205 (With ICC)

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

ENGINE HARNESS

- : Battery (+)
- : Fuse, fusible link and relay box and fuse, fusible link
- : and relay block (J/B)
- : Battery (+)
- ★ E305 GY/9 : To **E35**
- : Body ground
- B/3 : Power steering pressure sensor
- : Alternator
- : Alternator
- GY/2 : Alternator
- : Alternator
- E311 GY/1 : Starter motor
- : Starter motor
- : Starter motor
- ★ E315 GY/10 : To **F5**
- ★ E317 B/3 : Crankshaft position sensor (POS)
- ★ E318 L/4 : Heated oxygen sensor 2 (Bank 2)
- ★ E319 G/4 : Heated oxygen sensor 2 (Bank 1)




For detail ground distribution information,
refer to "GROUND DISTRIBUTION".

- ★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW or TROUBLE DIAGNOSES in EC and
AT sections.

HARNESS

ENGINE CONTROL HARNESS



CKIM0097E

HARNESS


Engine control harness

D3	F1 GY/1	: Oil pressure switch	F41	G/6	: To (F221)
D3	F2 B/1	: Compressor	F42	GY/4	: Heated oxygen sensor 1 (Bank 2)
E3	F3 BR/2	: Power steering solenoid valve	F43	GY/3	: Absolute pressure sensor
E3	F4 B/3	: Camshaft position sensor (PHASE)	F101	SMJ	: ECM
E4	F5 GY/10	: To (E15)	F102	SMJ	: ECM
F3	F7 GY/5	: Mass air flow sensor	F103	W/24	: TCM (Transmission control module)
F3	F8 -	: Engine ground	F104	GY/24	: TCM (Transmission control module)
F3	F9 -	: Engine ground	F105	SMJ	: To (M35)
D3	F12 B/3	: Intake valve timing control position sensor (Bank 1)	F106	P/20	: Joint connector-28
D3	F13 G/2	: Intake valve timing control solenoid valve (Bank 1)	F107	P/20	: Joint connector-29
D3	F14 GY/2	: Cooling fan speed control solenoid valve	F108	L/12	: Joint connector-30
F3	F15 GY/3	: Ignition coil (With power transistor) No. 1			
F3	F16 GY/3	: Ignition coil (With power transistor) No. 3			
F3	F17 GY/3	: Ignition coil (With power transistor) No. 5	F201	G/6	: To (F21)
F2	F18 GY/3	: Ignition coil (With power transistor) No. 7	F202	GY/2	: Injector No. 1
E2	F19 G/6	: Electric throttle control actuator	F203	GY/2	: Injector No. 3
F2	F20 L/6	: Electric throttle control actuator	F204	GY/2	: Injector No. 5
F1	F21 G/6	: To (F201)	F205	GY/2	: Injector No. 7
F2	F22 G/4	: Heated oxygen sensor 1 (Bank 1)			
E1	F23 GY/2	: Condenser			
F2	F24 SB/2	: To (F26)	F221	G/6	: To (F41)
E1	F25 L/2	: EVAP canister purge volume control solenoid valve	F222	GY/2	: Injector No. 2
F1	F26 G/10	: A/T unit assembly	F223	GY/2	: Injector No. 4
G1	F27 G/8	: A/T unit assembly	F224	GY/2	: Injector No. 6
F1	F28 B/8	: A/T unit assembly	F225	GY/2	: Injector No. 8
D2	F29 B/2	: VIAS control solenoid valve			
C2	F30 B/3	: Intake valve timing control position sensor (Bank 2)			
C2	F31 G/2	: Intake valve timing control solenoid valve (Bank 2)	F241	B/4	: To (F40)
C2	F32 SB/8	: To (E32)	F242	GY/2	: Knock sensor (Bank 1)
C2	F33 GY/10	: To (E33)	F243	GY/2	: Knock sensor (Bank 2)
C2	F34 G/10	: To (E34)			
D2	F35 GY/3	: Ignition coil (With power transistor) No. 2			
C2	F36 GY/3	: Ignition coil (With power transistor) No. 4	F261	SB/2	: To (F24)
D2	F37 GY/3	: Ignition coil (With power transistor) No. 6	F262	GY/2	: Engine coolant temperature sensor
D1	F38 GY/3	: Ignition coil (With power transistor) No. 8			
E1	F40 DGY/4	: To (F241)			

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and
AT sections.

HARNESS

BODY HARNESS AND REAR CONTROL HARNESS



CKIM0099E

Harness


Body harness

A3	(B1) W/8	: Fuse block (J/B) No. 1	
A3	(B2) W/6	: Fuse block (J/B) No. 1	
A3	(B3) W/3	: Front vertical G sensor	
A2	(B4) W/8	: BCM (Body control module)	
A1	(B5) SMJ	: To (M5)	
A3	(B6) GY/24	: To (M6)	
B1	(B7) W/24	: To (M7) (With NAVI and for Canada with rear control switch)	
A1	(B8) BR/6	: Rear window defogger and door mirror defogger relay	
A1	(B10) L/4	: Door mirror defogger relay	
B1	(B11) W/20	: To (E21)	
A3	(B12) BR/6	: To (E212)	
C2	(B13) Y/12	: Air bag diagnosis sensor unit	
B2	(B14) Y/2	: Front LH side air bag module	
C3	(B15) W/10	: Front power seat (Driver side) (Via sub-harness)	
A3	(B16) -	: Body ground	
B3	(B17) -	: Body ground	
B3	(B18) Y/2	: LH side air bag (Satellite) sensor	
B3	(B19) W/4	: Front LH seat belt pre-tensioner	
B3	(B20) W/3	: Front door switch (Driver side)	
B2	(B21) W/15	: To (D51)	
B1	(B22) GY/15	: To (D51) (With rear power seat)	
C3	(B23) W/18	: Rear power seat LH (Via sub-harness)	
D2	(B24) Y/2	: LH side curtain air bag module	
D2	(B25) W/1	: Condenser (Rear window defogger)	
D2	(B26) W/6	: Rear shock absorber actuator LH	
C2	(B27) W/16	: Option connector-2 for voice activated system	
E2	(B29) GY/24	: AV and NAVI control unit	
F2	(B30) W/24	: AV and NAVI control unit	{ (With NAVI)
E2	(B31) GY/3	: AV and NAVI control unit	
E2	(B32) GY/24	: AV control unit	{ (For Canada with rear control switch)
F2	(B33) W/24	: AV control unit	
E2	(B34) GY/3	: AV control unit	
E3	(B35) SB/4	: Rear wheel sensor	
E3	(B36) GY/2	: Dual mode muffler actuator	
D3	(B37) W/24	: Active damper suspension control unit	
D3	(B38) GY/24	: Active damper suspension control unit	
E3	(B40) GY/6	: Joint connector-31	
D4	(B45) W/2	: Dropping resistor	

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and
AT sections.

HARNESS

BODY NO. 2 HARNESS



CKIM0101E

A
B
C
D
E
F
G
H
I
J
K
L
M
PG

HARNESS

Body No. 2 harness


G1	(B201) W/4	: Fuse block (J/B) No. 2	D3	(B241) P/20	: Joint connector-36
F3	(B202) W/4	: To (E203)	D3	(B242) OR/20	: Joint connector-37
F2	(B203) W/4	: To (E202)	C3	(B243) W/24	: ICC unit
F1	★ (B204) BR/4	: To (E224)	C3	(B244) GY/24	: ICC unit
G1	(B205) W/20	: To (E225) (With ICC)	C3	(B245) G/24	: ICC unit
G1	(B206) W/3	: To (M137) (With rear view camera)	C1	(B246) W/4	: Remote key/less entry receiver
G1	(B207) W/3	: To (M138) (With ICC)	C4	★ (B251) SB/8	: To (B401)
F3	(B208) BR/24	: To (M139) (With rear view camera or rear heated seat)	C2	★ (B256)	- : Body ground
G3	(B209) W/4	: To (M140) (With rear sunshade)	D2	(B259) W/4	: Fuel lid opener actuator
F3	★ (B210) GY/6	: To (M141)	C4	(B261) W/12	: To (B61)
F1	★ (B211) SMJ	: To (M141)	C4	(B262) BR/8	: To (B62)
E2	(B213) Y/12	: Air bag diagnosis sensor unit	B4	★ (B263) W/10	: To (B63)
E2	(B214) Y/2	: Front RH side air bag module	B3	(B264) W/16	: To (B64)
F2	(B215) W/8	: Front power seat (Passenger side) (Via sub-harness)	B3	(B265) W/2	: To (B65) (With ICC)
F3	(B216) -	: Body ground	B3	(B266) W/3	: To (B66)
F3	★ (B217) -	: Body ground	C3	(B267) Y/2	: To (B67)
E3	(B218) Y/2	: RH side air bag (Satellite) sensor	B3	(B268) Y/2	: To (B68)
E3	(B219) W/4	: Rear RH seat belt pre-tensioner			
F3	(B220) W/3	: Front door switch (Passenger side)			
F2	(B221) W/15	: To (D71)			
F2	(B222) GY/15	: To (D71) (With rear power seat)	D4	★ (B401) SB/8	: To (B251)
E2	(B223) W/18	: Rear power seat RH (Via sub-harness)	D3	★ (B402) B/2	: EVAP canister vent control valve
D1	(B224) Y/2	: RH side curtain air bag module	E3	★ (B403) GY/3	: EVAP control system pressure sensor
D1	(B225) W/6	: Rear sunshade unit	E4	★ (B404) G/2	: Vacuum cut valve bypass valve
D2	(B226) W/6	: Rear shock absorber actuator RH			
E1	(B227) W/3	: Rear vertical G sensor			
D2	(B228) GY/2	: Condenser			
B2	(B231) B/6	: BOSE speaker amp.	D1	(B421) B/1	: Rear window defogger (-)
C2	(B232) W/4	: BOSE speaker amp.	D1	★ (B422)	- : Body ground
B1	(B233) LGY/8	: BOSE speaker amp.			
B2	(B234) B/24	: BOSE speaker amp.			
B2	(B235) W/2	: Woofer			
C2	(B236) GY/24	: Rear view camera control unit			
C1	(B237) W/2	: High-mounted stop lamp			
B1	(B238) W/2	: Trunk room lamp			
B2	★ (B239) W/6	: Fuel level sensor unit and fuel pump			
D2	★ (B240) W/4	: Fuel pump control module (FPCM)			

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and
AT sections.

CKIM0102E

HARNESS

ROOM LAMP HARNESS



CKIM0103E


A
B
C
D
E
F
G
H
I
J
L
M

PG

HARNESS


FRONT DOOR HARNESS

LH Side



CKIM0045E

RH Side




CKIM0046E

HARNESS


REAR DOOR HARNESS

LH Side



CKIM0047E

RH Side



CKIM0048E


HARNESS

Splice Location

HOW TO READ SPLICE LOCATION


EKS0014G

- "GT2", "T4" etc., which are shown in the wiring diagram, refer to wiring harness splice points. These points are located in shaded areas "GT2", "T4", etc. in illuminations under the title "Splice Location".
- Wiring harness splice points are subject to change without prior notice.



HARNESS

MAIN HARNESS



CKIM0105E

HARNESS


ENGINE ROOM HARNESS Engine Compartment



CKIM0106E

HARNESS

Passenger Compartment



A
B
C
D
E
F
G
H
I
J

PG


L

M

CKIM0107E

HARNESS


ENGINE HARNESS



CKIM0108E

HARNESS

ENGINE CONTROL HARNESS




A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIM0109E

HARNESS


BODY HARNESS AND REAR CONTROL HARNESS



CKIM0110E

HARNESS

BODY NO.2 HARNESS



A
B
C
D
E
F
G
H
I
J

PG


L

M

CKIM0111E

HARNESS


ROOM LAMP HARNESS



CKIM0112E


HARNESS

FRONT DOOR HARNESS LH Side



CKIM0057E


RH Side



PG


HARNESS

REAR DOOR HARNESS LH Side



CKIM0059E

RH Side



CKIM0060E

HARNESS

Wiring Diagram Codes (Cell Codes)

EKS000DT

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
ACTIVE	SCS	Active Damper Suspension System
AP/SEN	EC	Absolute Pressure Sensor
APPS	EC	Accelerator Pedal Position Sensor
ASCD	ACS	Automatic Speed Control Device
AT/IND	DI	A/T Indicator
AUDIO	AV	Audio
AUT/DP	SE	Automatic Drive Positioner - IVMS
BACK/L	LT	Back-up Lamp
BRK/SW	EC	Brake Switch
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CD/CHG	AV	CD Auto Changer
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
CLOCK	DI	Clock
COMM	LAN	IVMS - Communication Check, Power Supply & Ground
COOL/V	EC	Cooling Fan Speed Control Solenoid Valve
D/C	AT	Direct Clutch Solenoid Valve
D/CF	AT	Direct Clutch Solenoid Valve Function
D/LOCK	BL	Power Door Lock - IVMS
DEF	GW	Rear Window Defogger
DLC	EC	Data Link Connectors
DTRL	LT	Headlamp - With Daytime Light System
E/BRE	AT	Low Coast Brake Solenoid Valve
ECTS	EC	Engine Coolant Temperature Sensor
EPS	STC	Electronic Controlled Power Steering System
F/PUMP	EC	Fuel Pump
FR/B	AT	Front Brake Solenoid Valve
FR/BF	AT	Front Brake Solenoid Valve Function
FLS1	EC	Fuel Level Sensor Function (SLOSH)
FLS2	EC	Fuel Level Sensor Circuit
FLS3	EC	Fuel Level Sensor Circuit (Ground Signal)
FPCM	EC	Fuel Pump Control Module
FPSW1	AT	Pressure Switch 1 (FR/B)
FPSW3	AT	Pressure Switch 3 (I/C)
FPSW5	AT	Pressure Switch 5 (D/C)
FPSW6	AT	Pressure Switch 6 (HLR/C)
FTS	AT	A/T Fluid Temperature Sensor
FTTS	EC	Fuel tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp

A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

HLR/C	AT	High and Low Reverse Clutch Solenoid Valve
HLR/CF	AT	High and Low Reverse Clutch Solenoid Valve Function
HORN	WW	Horn
HSEAT	SE	Heated Seat
I/C	AT	Input Clutch Solenoid Valve
I/CF	AT	Input Clutch Solenoid Valve
I/LOCK	AT	Solenoid Valve and Pressure Switch
I/MIRR	GW	Inside Mirror (Auto-anti dazzling mirror)
IATS	EC	Intake Air Temperature Sensor
ICC	ACS	Intelligent Cruise Control System
IGN/SG	EC	Ignition Signal
ILL	LT	Illumination
INF/D	DI	Information Display (With Navi and For Canada With Rear Control Switch)
INF/D	DI	Information Display (Without Navi and For Canada Without Rear Control Switch)
INJECT	EC	Injector
INT/L	LT	Vanity Mirror and Trunk Room Lamps
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
IVCSB1	EC	Intake Valve Timing Control Position Sensor Bank 1
IVCSB2	EC	Intake Valve Timing Control Position Sensor Bank 2
KEYLES	BL	Remote Keyless Entry System-VMS
KS	EC	Knock Sensor
LC/B	AT	Low Coast Break Solenoid Valve
LC/BF	AT	Low Coast Break Solenoid Valve Function
LOAD/S	DI	Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
METER	DI	Speedometer, Tachometer, Temp., Oil and Fuel Gauges
MIL	EC	Malfunction Indicator Lamp
MIRROR	GW	Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	IVIS (Infiniti Vehicle Immobilizer System - NATS)
NAVI	AV	Navigation System
NONDTC	AT	Non-detective Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater Bank 1
O2H1B2	EC	Heated Oxygen Sensor 1 Heater Bank 2
O2H2B1	EC	Rear Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Rear Heated Oxygen Sensor 2 Heater Bank 2
O2S1B1	EC	Heated Oxygen Sensor 1 Bank 1
O2S1B2	EC	Heated Oxygen Sensor 1 Bank 2
O2S2B1	EC	Rear Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Rear Heated Oxygen Sensor 2 Bank 2
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PHONE	AV	Telephone
PNP/SW	EC	Park/Neutral Position Switch
PNP/SW	AT	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS)(POS)
POWER	AT	Transmission Control Module Power Supply
POWER	EC	ECM Power Supply For Back-up Lamp
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor

HARNESS

PS/SEN	EC	Power Steering Pressure Sensor
R/VIEW	DI	Rear View Camera Control System
RCTS	EC	Radiator Coolant Temperature Sensor
REMOTE	AV	Audio (Remote Control Switch)
ROOM/L	LT	Interior Room Lamp - IVMS
RP/SEN	EC	Refrigerant Pressure Sensor
S/SIG	EC	Start Signal
SEAT	SE	Power Seat
SHADE	EI	Rear Sunshade
SHIFT	AT	A/T Shift Lock System
SROOF	BL	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STEP/L	LT	Step Lamp - IVMS
STOP/L	LT	Stop Lamp
STSIG	AT	Start Signal
SW/ILL	GW	Power Window Switch Illumination - IVMS
T&FLID	BL	Trunk Lid and Fuel Lid Opener
T/MTR	EC	Throttle Control Motor
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock Up)
TCV	AT	Torque Converter Clutch Solenoid Valve
TM/RLY	EC	Throttle Control Motor Relay
TPS	EC	Throttle Position Sensor
TRNSMT	BL	Integrated HOMELINK (TM) Transmitter
TRSA/T	AT	Turbine Revolution Sensor
TURN	LT	Turn Signal and Hazard Warning Lamps
VDC	BRC	Vehicle Dynamics Control System
VEHSEC	BL	Vehicle Security System - IVMS
VENT/V	EC	EVAP Canister Vent Control Valve
VEXH	EX	Variable Exhaust Muffler Control System
VIAS/V	EC	Variable Air Induction Control System
VOICE	DI	Voice Activated Control System
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
W/ANT	AV	Audio Antenna
WARN	DI	Warning Lamps
WINDOW	GW	Power Window - IVMS
WIPER	WW	Wiper and Washer

ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location

EKS003SA



Use parts code, if applicable, and chassis number to find correct parts number in parts catalog. Parts codes are shown in illustration.

NOTICE:

Parts codes in illustration are those in effect at the time of the first service manual edition. Information might not be maintained in the timely manner. Always confirm correct parts code using appropriate parts catalog.

ELECTRICAL UNITS LOCATION


ENGINE COMPARTMENT




CKIM0087E

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT



A Dash side LH




In back of the fuse block (J/B) No. 1



ELECTRICAL UNITS LOCATION


A
B
C
D
E
F
G
H
I
J

PG
L
M



CKIM0027E

ELECTRICAL UNITS LOCATION





CKIM0028E

ELECTRICAL UNITS LOCATION

LUGGAGE COMPARTMENT

A
B
C
D
E
F
G
H
I
J

PG
L
M




CKIM0089E

ELECTRICAL UNITS LOCATION

Fuse

EKS003SB

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

EKS003SC

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

EKS003SD

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

EKS000DY

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]



JOINT CONNECTOR (J/C)

JOINT CONNECTOR (J/C)

Terminal Arrangement

PFP:B4341

EKS001B1

A

B

C

D

E

F

G

H











I

J

PG

L

M



CKIM0069E





ELECTRICAL UNITS

ELECTRICAL UNITS

PFP:23710

Terminal Arrangement

EKS003SE



CKIM0114E

ELECTRICAL UNITS

A

B

C

D

E

F

G

H

I


J

PG


L

M


BCM (BODY CONTROL MODULE)




(White)



(Brown)




(White)




(White)




ICC UNIT



(White)



(Gray)



(Green)



CKIM0115E


SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

PFP:B4341

Terminal Arrangement

EKS001B2




SMJ (SUPER MULTIPLE JUNCTION)


A
B
C
D
E
F
G
H
I
J

PG

L
M





ENGINE CONTROL HARNESS



CKIM0062E

SMJ (SUPER MULTIPLE JUNCTION)



CKIM0063E

STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

EKS000E4

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make















1T 1 Transfer

1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W


FUSE BLOCK - JUNCTION BOX (J/B) NO.1

FUSE BLOCK - JUNCTION BOX (J/B) NO.1

Terminal Arrangement

PFP:24350

EKS00178



CKIM0064E


FUSE BLOCK - JUNCTION BOX (J/B) NO.2

FUSE BLOCK - JUNCTION BOX (J/B) NO.2

PFP:24350

Terminal Arrangement

EKS00175



CKIM0065E



FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

FUSE, FUSIBLE LINK AND RELAY BLOCK (J/B)

PFP:24382

Terminal Arrangement

EKS00176





FUSE, FUSIBLE LINK AND RELAY BOX

FUSE, FUSIBLE LINK AND RELAY BOX


PFP:24382

Terminal Arrangement

EKS00177



C to L FUSIBLE LINK
No. 71 to 78 FUSE



No. 81, 82 FUSE

CKIM0113E