

SECTION **LAN**
LAN SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

CONTENTS

LAN	CAN
PRECAUTIONS 3	PRECAUTIONS 20
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 3	Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 20
IVMS (LAN) 4	Precautions For Trouble Diagnosis 20
Overall Description 4	CAN SYSTEM 20
OUTLINE 4	Precautions For Harness Repair 20
BCM (BODY CONTROL MODULE) 4	CAN SYSTEM 20
LCU (LOCAL CONTROL UNIT) 4	CAN COMMUNICATION 21
CONTROLLED SYSTEMS 4	System Description 21
Component Parts and Harness Connector Location... 5	CAN Communication Unit 21
Sleep/Wake-up Control 5	TYPE 1 21
SLEEP CONTROL 5	TYPE 2 22
WAKE-UP CONTROL 6	CAN SYSTEM (TYPE 1) 24
Fail-safe System 6	System Description 24
CONSULT-II Function 6	Component Parts and Harness Connector Location.. 24
DIAGNOSTIC ITEMS DESCRIPTION 6	Wiring Diagram — CAN — 25
DIAGNOSTIC ITEMS APPLICATION 7	Work Flow 27
On Board Diagnosis 7	CHECK SHEET 28
DIAGNOSIS ITEM 7	CHECK SHEET RESULTS (EXAMPLE) 29
Schematic 8	Circuit Check Between VDC/TCS/ABS Control Unit and Steering Angle Sensor 32
POWER SUPPLY, GROUND AND COMMUNICATION CIRCUITS 8	Circuit Check Between Steering Angle Sensor and Combination Meter 34
Wiring Diagram - COMM - 9	ECM Circuit Check 34
POWER SUPPLY, GROUND AND COMMUNICATION CIRCUITS 9	VDC/TCS/ABS Control Unit Circuit Check 35
Schematic - BCM - 14	Steering Angle Sensor Circuit Check 35
Schematic - LCU01 - 16	Combination Meter Circuit Check 36
DRIVER'S DOOR CONTROL UNIT 16	TCM Circuit Check 36
Schematic - LCU02 - 17	CAN Communication Circuit Check 37
DRIVER'S SEAT CONTROL UNIT 17	Component Inspection 41
Schematic - LCU03 - 18	ECM/TCM INTERNAL CIRCUIT INSPECTION... 41
DRIVER'S SIDE DOOR MIRROR CONTROL UNIT 18	CAN SYSTEM (TYPE 2) 42
Schematic - LCU04 - 19	System Description 42
PASSENGER SIDE DOOR MIRROR CONTROL UNIT 19	Component Parts and Harness Connector Location.. 42
	Schematic 43
	Wiring Diagram — CAN — 44
	Work Flow 47
	CHECK SHEET 48

LAN

CHECK SHEET RESULTS (EXAMPLE)	49	VDC/TCS/ABS Control Unit Circuit Check	63
Circuit Check Between VDC/TCS/ABS Control Unit and ICC Sensor	59	ICC Sensor Circuit Check	63
Circuit Check Between ICC sensor and ICC Unit...	60	ICC Unit Circuit Check	64
Circuit Check Between ICC Unit and Steering Angle Sensor	61	Steering Angle Sensor Circuit Check	64
Circuit Check Between Steering Angle Sensor and Combination Meter	62	Combination Meter Circuit Check	65
ECM Circuit Check	62	TCM Circuit Check	65
		CAN Communication Circuit Check	66
		Component Inspection	70
		ECM/TCM INTERNAL CIRCUIT INSPECTION...	70

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS006SI

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

A
B
C
D
E
F
G
H
I
J

LAN

L
M

IVMS (LAN)**Overall Description
OUTLINE**

The In-Vehicle Multiplexing System, IVMS (LAN system), consists of a BCM (Body Control Module) and four LCUs (Local Control Units). Some switches and electrical loads are connected to each LCU. Some electrical systems are directly connected to the BCM. Control of each LCU, (which is provided by a switch and electrical load), is accomplished by the BCM, via multiplex data lines (A-1, A-2 or A-3) connected between them.

BCM (BODY CONTROL MODULE)

The BCM, which is a master unit of the IVMS (LAN), consists of microprocessor, memory and communication LSI sections and has communication and control functions. It receives data signals from the LCUs and sends electrical load data signals to them.

LCU (LOCAL CONTROL UNIT)

The LCUs, which are slave units of the BCM, have only a communication function and consist of communication LSI and input-output interface circuits. They receive data signals from the BCM, control the ON/OFF operations of electrical loads and the sleep operation, as well as send switch signals to the BCM.

CONTROLLED SYSTEMS


The IVMS controls several body-electrical systems. The systems included in the IVMS are as follows:

- Power window system (Refer to [GW-16, "POWER WINDOW SYSTEM"](#))
- Power door lock system (Refer to [BL-19, "POWER DOOR LOCK SYSTEM"](#))
- Remote keyless entry system (Refer to [BL-53, "REMOTE KEYLESS ENTRY SYSTEM"](#))
- Vehicle security (Theft warning) system (Refer to [BL-155, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#))
- Reverse interlock door mirror system (Refer to [GW-80, "REVERSE INTERLOCK DOOR MIRROR SYSTEM"](#))
- Interior room lamp (Refer to [LT-82, "INTERIOR ROOM LAMP"](#))
- Step lamp (Refer to [LT-110, "STEP LAMP"](#))
- Illumination (Refer to [LT-132, "ILLUMINATION"](#))
- Automatic drive positioner (Refer to [SE-13, "AUTOMATIC DRIVE POSITIONER"](#))
- Auto light (Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#))
- Door warning lamp (Refer to [DI-28, "WARNING LAMPS"](#))
- Ignition key warning chime (Refer to [DI-50, "WARNING CHIME"](#))
- Light warning chime (Refer to [DI-50, "WARNING CHIME"](#))
- Seat belt warning chime (Refer to [DI-50, "WARNING CHIME"](#))
- Front wiper and washer system (Refer to [WW-3, "FRONT WIPER AND WASHER SYSTEM"](#))
- Rear window defogger (Refer to [GW-60, "REAR WINDOW DEFOGGER"](#))
- Trouble diagnosis system
 - with CONSULT-II
 - ON BOARD

Also, IVMS has the "sleep/wake-up control" function. IVMS puts itself (the whole IVMS system) to sleep under certain conditions to prevent unnecessary power consumption. Then, when a certain input is detected, the system wakes itself up. For more detailed information, refer to "Sleep/Wake-up Control".

Component Parts and Harness Connector Location


EKS001PE



CKIM0010E

Sleep/Wake-up Control
SLEEP CONTROL

EKS001PF




SEL465TA

“Sleep” control prevents unnecessary power consumption. After the following conditions are met, the BCM suspends the communication between itself and all LCUs. The whole IVMS is set in the “sleep” mode.

- Ignition switch “OFF”
- All electrical loads (in the IVMS) “OFF”
- Timer “OFF”

WAKE-UP CONTROL



As shown above, when the BCM detects a “wake-up” signal, it wakes up the whole system and starts communicating again. The “sleep” mode of all LCUs is now canceled, and the BCM returns to the normal control mode. When any one of the following switches are turned ON, the “sleep” mode is canceled:

- All switches combined or connected with BCM
- All switches combined or connected with LCU

Fail-safe System

EKS001PG

Fail-safe system operates when the signal from LCU is judged to be malfunctioning by BCM. If LCU sends no signal or an irregular signal to BCM a certain number of times in succession, the IVMS is set in a fail-safe condition. In the fail-safe condition, the electrical loads controlled by the switch on the questionable LCU will be operated at fail-safe mode.

CONSULT-II Function

EKS001R9

CONSULT-II executes the following functions by combining data reception and command transmission via the communication line from BCM. IVMS communication inspection, work support (only function setting of seats and steering wheel), self-diagnosis, data monitor, and active test display.

DIAGNOSTIC ITEMS DESCRIPTION

IVMS diagnosis position	Diagnosis mode	Description
IVMS– COMM CHECK	IVMS– COMM DIAGNOSIS	Diagnosis of continuity in the communication line(s), and of the function of the IVMS-communication interface between the body control module and the local control units, accomplished by transmitting a signal from the body control module to the local control units.
	WAKE–UP DIAGNOSIS	Diagnosis of the “wake-up” function of local control units by having a technician input the switch data into the local control unit that is in the temporary “sleep” condition.
Each system inspection	Work support	Changes the setting for each function.
	Self-diagnosis results	Carries out self-diagnosis.
	Data monitor	Displays data relative to the body control module (BCM) input signals and various control related data for each system.
	Active test	Turns on/off actuators, relay and according to the commands transmitted by the CONSULT-II unit.
BCM PART NUMBER		Displays BCM part No.

DIAGNOSTIC ITEMS APPLICATION

Test item	Diagnosed system	MODE					
		IVMS COMM DIAGNOSIS	WAKE-UP DIAGNOSIS	SELF DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	WORK SUPPORT
IVMS-COMM CHECK	IVMS communication and wake-up function	×	×				
DOOR LOCK	Power door lock system			×	×	×	
AUTO DRIVE POSITIONER	Automatic drive positioner / Reverse interlock door mirror system			×	×	×	×
WIPER	Front wiper and washer system				×	×	×
REAR DEFOGGER	Rear window defogger				×	×	
IGN KEY WARN ALM	Warning chime				×	×	
LIGHT WARN ALM	Warning chime				×	×	
SEAT BELT TIMER	Warning chime				×	×	
THEFT WARNING SYSTEM	Vehicle security (Theft warning) system				×	×	×
STEP LAMP	Step lamps				×	×	
MULTI-REMOTE CONT-SYS	Remote keyless entry system				×	×	×
INTERIOR ILLUMINATION	Interior room lamp				×	×	×
SUNROOF RELAY	Sunroof				×	×	
DOOR OPEN WARNING	Warning lamps				×	×	
AUTO LIGHT SYSTEM	Headlamp				×	×	×

A
B
C
D
E
F
G
H
I
J
LAN

X: Applicable

For diagnostic item in each control system, read the CONSULT-II Operation Manual.

On Board Diagnosis

EKS001RA

ON BOARD DIAGNOSTIC RESULTS INDICATOR LAMP

- Front map lamps and step lamps (all seats) act as the indicators for the on board diagnosis.


DIAGNOSIS ITEM

Diagnosis item	Content
IVMS communication diagnosis	Diagnosis any error or inability of communication between BCM and LCUs.
Switch monitor	Monitoring conditions of switches connected to BCM, LCUs and door control units.
Power door lock system self-diagnosis	Diagnose malfunctions in the each door lock actuator system.
Auto drive positioner self-diagnosis	Diagnose malfunctions in the each motor and sensor in the electrical load parts of the driver power seat system (sliding, reclining, and lifter [front/rear]), of the steering wheel system (tilt, telescoping), and of door mirror.

L
M


Schematic

POWER SUPPLY, GROUND AND COMMUNICATION CIRCUITS




**Wiring Diagram - COMM -
POWER SUPPLY, GROUND AND COMMUNICATION CIRCUITS**

LAN-COMM-01



REFER TO THE FOLLOWING.

- (M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (M4) - ELECTRICAL UNITS





A
B
C
D
E
F
G
H
I
J
L
M

LAN





LAN-COMM-02

REFER TO PG-POWER.



REFER TO THE FOLLOWING.

- (D1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (E203) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1
- (M4), (B4) -ELECTRICAL UNITS





REFER TO THE FOLLOWING.
 (M5), (B21), (D31) -SUPER
 MULTIPLE JUNCTION (SMJ)

A
B
C
D
E
F
G
H
I
J
L
M

LAN





LAN-COMM-04



REFER TO THE FOLLOWING.
 (M5), (B211), (B221) -SUPER
 MULTIPLE JUNCTION (SMJ)

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM0436E




REFER TO THE FOLLOWING.


(D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Schematic - BCM -






A
B
C
D
E
F
G
H
I
J
LAN
L
M

PRECEDING PAGE

**Schematic - LCU01 -
DRIVER'S DOOR CONTROL UNIT**

EKS001PM




TKWM0956E

Schematic - LCU02 -
DRIVER'S SEAT CONTROL UNIT

EKS001PN


A
B
C
D
E
F
G
H
I
J
LAN
L
M



TKWM0118E

**Schematic - LCU03 -
DRIVER'S SIDE DOOR MIRROR CONTROL UNIT**


EKS001PO



TKWM0119E

**Schematic - LCU04 -
PASSENGER SIDE DOOR MIRROR CONTROL UNIT**

EKS001PP



TKWM0120E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS006SJ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions For Trouble Diagnosis
CAN SYSTEM**


EKS001PR

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.


**Precautions For Harness Repair
CAN SYSTEM**

EKS001PS

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



CAN COMMUNICATION

System Description

EKS001PT

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00GFJ


Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan	
Axle	2WD	
Engine	VK45DE	
Transmission	A/T	
Brake control	VDC	
ICC system		×
CAN system type	1	2
CAN system trouble diagnosis	LAN-24	LAN-42

×: Applicable

TYPE 1

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	TCM	Combination meter	Steering angle sensor	VDC/TCS/ABS control unit	ECM
Engine speed signal	R	R		R	T
Engine coolant temperature signal		R			T
Accelerator pedal position signal	R			R	T
Battery voltage signal	R				T
Closed throttle position signal	R				T
Wide open throttle position signal	R				T
Fuel consumption monitor signal		R			T
Current gear position signal	T	R		R	R
Next gear position signal	T			R	R
Shift change signal	T			R	R
Shift pattern signal	T				R
Steering wheel angle sensor signal			T	R	


CAN COMMUNICATION

[CAN]

Signals	TCM	Combination meter	Steering angle sensor	VDC/TCS/ABS control unit	ECM
Air conditioner switch signal		T			R
Headlamp switch signal		T			R
Rear window defogger switch signal		T			R
Stop lamp switch signal	R	T			
Vehicle speed signal		R		T	
	R	T			R
A/T position indicator lamp signal	T	R			
Manual mode signal	R	T			
Not Manual mode signal	R	T			
Manual mode shift up signal	R	T			
Manual mode shift down signal	R	T			
Manual mode indicator signal	T	R			
Output shaft revolution signal	T				R
Turbine revolution signal	T				R
A/T CHECK indicator lamp signal	T	R			

TYPE 2

System Diagram



Input/output Signal Chart

T: Transmit R: Receive

Signals	TCM	Combina- tion meter	Steering angle sen- sor	ICC unit	ICC sen- sor	VDC/ TCS/ABS control unit	ECM
ICC system display signal		R		T			
ICC sensor signal				R	T		
Engine speed signal	R	R		R		R	T
Engine coolant temperature signal		R					T
Accelerator pedal position signal	R			R		R	T
Battery voltage signal	R						T
Closed throttle position signal	R			R			T
Wide open throttle position signal	R						T
Fuel consumption monitor signal		R					T
Current gear position signal	T	R		R		R	R
Next gear position signal	T					R	R
Shift change signal	T					R	R
Shift pattern signal	T						R

CAN COMMUNICATION

[CAN]

Signals	TCM	Combina- tion meter	Steering angle sen- sor	ICC unit	ICC sen- sor	VDC/ TCS/ABS control unit	ECM	
Steering wheel angle sensor signal			T			R		A
Air conditioner switch signal		T					R	B
Headlamp switch signal		T					R	
Rear window defogger switch signal		T					R	C
Stop lamp switch signal	R	T						
Vehicle speed signal		R		R		T		D
	R	T					R	
A/T position indicator lamp signal	T	R		R				
Manual mode signal	R	T						E
Not Manual mode signal	R	T						
Manual mode shift up signal	R	T						F
Manual mode shift down signal	R	T						
Manual mode indicator signal	T	R						
Output shaft revolution signal	T			R			R	G
Turbine revolution signal	T			R			R	
A/T CHECK indicator lamp signal	T	R						H

A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

EKS003L7

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS003L8



SKIA3772E

CAN SYSTEM (TYPE 1)



[CAN]

Wiring Diagram — CAN —


EKS003L9

LAN-CAN-01

▬ : DATA LINE



M31
W



M41
BR

REFER TO THE FOLLOWING.



F105 -SUPER MULTIPLE JUNCTION (SMJ)

F103 -ELECTRICAL UNITS

A
B
C
D
E
F
G
H
I
J

LAN

L
M



REFER TO THE FOLLOWING.

(E218), (F102) -ELECTRICAL UNITS

Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "VDC", and "A/T" displayed on CONSULT-II.

(Example)	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT DIAG MODE</td></tr> <tr><td style="text-align: center;">WORK SUPPORT</td></tr> <tr><td style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DATA MONITOR</td></tr> <tr><td style="text-align: center;">DATA MONITOR (SPEC)</td></tr> <tr><td style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;">Scroll Down</td></tr> <tr><td style="text-align: center;">BACK LIGHT COPY</td></tr> </table>	SELECT DIAG MODE	WORK SUPPORT	SELF-DIAG RESULTS	DATA MONITOR	DATA MONITOR (SPEC)	CAN DIAG SUPPORT MNTR	ACTIVE TEST		Scroll Down	BACK LIGHT COPY	➔	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DTC RESULTS</td><td style="text-align: center;">TIME</td></tr> <tr><td style="text-align: center;">CAN COMM CIRCUIT [U1000]</td><td style="text-align: center;">0</td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> <tr><td colspan="2" style="text-align: center;">F.F.DATA</td></tr> <tr><td style="text-align: center;">ERASE</td><td style="text-align: center;">PRINT</td></tr> <tr><td style="text-align: center;">MODE BACK LIGHT COPY</td></tr> </table>	SELF-DIAG RESULTS		DTC RESULTS	TIME	CAN COMM CIRCUIT [U1000]	0					F.F.DATA		ERASE	PRINT	MODE BACK LIGHT COPY	PKIA8260E
SELECT DIAG MODE																													
WORK SUPPORT																													
SELF-DIAG RESULTS																													
DATA MONITOR																													
DATA MONITOR (SPEC)																													
CAN DIAG SUPPORT MNTR																													
ACTIVE TEST																													
Scroll Down																													
BACK LIGHT COPY																													
SELF-DIAG RESULTS																													
DTC RESULTS	TIME																												
CAN COMM CIRCUIT [U1000]	0																												
F.F.DATA																													
ERASE	PRINT																												
MODE BACK LIGHT COPY																													

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "VDC", and "A/T" displayed on CONSULT-II.

(Example)	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: center;">SELECT DIAG MODE</td></tr> <tr><td style="text-align: center;">WORK SUPPORT</td></tr> <tr><td style="text-align: center;">SELF-DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DATA MONITOR</td></tr> <tr><td style="text-align: center;">DATA MONITOR (SPEC)</td></tr> <tr><td style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;">Scroll Down</td></tr> <tr><td style="text-align: center;">BACK LIGHT COPY</td></tr> </table>	SELECT DIAG MODE	WORK SUPPORT	SELF-DIAG RESULTS	DATA MONITOR	DATA MONITOR (SPEC)	CAN DIAG SUPPORT MNTR	ACTIVE TEST		Scroll Down	BACK LIGHT COPY	➔	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">CAN DIAG SUPPORT MNTR</td></tr> <tr><td colspan="2" style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;">PRSENT</td></tr> <tr><td style="text-align: center;">INITIAL DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">TRANSMIT DIAG</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">TCM</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">VDC/TCS/ABS</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">METER/M&A</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">ICC</td><td style="text-align: center;">UNKWKN</td></tr> <tr><td style="text-align: center;">BCM/SEC</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">IPDM E/R</td><td style="text-align: center;">OK</td></tr> <tr><td style="text-align: center;">AWD/4WD/e4WD</td><td style="text-align: center;">UNKWKN</td></tr> <tr><td style="text-align: center;">PRINT</td><td style="text-align: center;">Scroll Down</td></tr> <tr><td style="text-align: center;">MODE BACK LIGHT COPY</td></tr> </table>	CAN DIAG SUPPORT MNTR		ENGINE			PRSENT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWKN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWKN	PRINT	Scroll Down	MODE BACK LIGHT COPY	PKIA8343E
SELECT DIAG MODE																																									
WORK SUPPORT																																									
SELF-DIAG RESULTS																																									
DATA MONITOR																																									
DATA MONITOR (SPEC)																																									
CAN DIAG SUPPORT MNTR																																									
ACTIVE TEST																																									
Scroll Down																																									
BACK LIGHT COPY																																									
CAN DIAG SUPPORT MNTR																																									
ENGINE																																									
	PRSENT																																								
INITIAL DIAG	OK																																								
TRANSMIT DIAG	OK																																								
TCM	OK																																								
VDC/TCS/ABS	OK																																								
METER/M&A	OK																																								
ICC	UNKWKN																																								
BCM/SEC	OK																																								
IPDM E/R	OK																																								
AWD/4WD/e4WD	UNKWKN																																								
PRINT	Scroll Down																																								
MODE BACK LIGHT COPY																																									

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-28, "CHECK SHEET"](#).
4. Based on the data monitor results, put marks "v" onto the items with "NG" or "UNKWKN" in the check sheet table. Refer to [LAN-28, "CHECK SHEET"](#).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

5. According to the check sheet results (example), start inspection. Refer to [LAN-29, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—

Symptoms :

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
VDC
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
VDC
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between VDC/TCS/ABS control unit and steering angle sensor. Refer to [LAN-32, "Circuit Check Between VDC/TCS/ABS Control Unit and Steering Angle Sensor"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-

PKIA8655E




Case 2

Check harness between steering angle sensor and combination meter. Refer to [LAN-34, "Circuit Check Between Steering Angle Sensor and Combination Meter"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	-

PKIA8656E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-34, "ECM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKW N	—	UNKW N	—	UNKW N	UNKW N
VDC	NG	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	NG	UNKW N	UNKW N	UNKW N	—	UNKW N	—

PKIA8657E




Case 4

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-35, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKW N	—	UNKW N	—	UNKW N	UNKW N
VDC	NG	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	NG	UNKW N	UNKW N	UNKW N	—	UNKW N	—

PKIA8658E



CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-35, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—

PKIA8659E




Case 6

Check combination meter circuit. Refer to [LAN-36, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	UNKWN ✓	UNKWN
VDC	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—

PKIA8660E



A
B
C
D
E
F
G
H
I
J
L
M


LAN

Case 7

Check TCM circuit. Refer to [LAN-36, "TCM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN ✓
VDC	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—

PKIA8661E



Case 8

Check CAN communication circuit. Refer to [LAN-37, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
VDC	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—

PKIA8662E

Circuit Check Between VDC/TCS/ABS Control Unit and Steering Angle Sensor

EKS003LB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(control unit side, sensor side and harness side)
 - VDC/TCS/ABS control unit
 - Steering angle sensor
 - Between VDC/TCS/ABS control unit and steering angle sensor

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector and harness connector E224.
2. Check continuity between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B), 63 (P/B) and harness connector E224 terminals 6 (LG/B), 5 (P/B).

61 (LG/B) – 6 (LG/B) : Continuity should exist.
63 (P/B) – 5 (P/B) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B263.
2. Check continuity between harness connector B204 terminals 6 (LG/B), 5 (P/B) and harness connector B263 terminals 9 (LG/B), 8 (P/B).

6 (LG/B) – 9 (LG/B) : Continuity should exist.
5 (P/B) – 8 (P/B) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B6.
2. Check continuity between harness connector B63 terminals 9(LG/B), 8 (P/B) and harness connector B6 terminals 23(LG/B), 24 (P/B).

9(LG/B) – 23(LG/B) : Continuity should exist.
8(P/B) – 24(P/B) : Continuity should exist.

OK or NG

- OK >> GO TO 5.
 NG >> Repair harness.




5. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check continuity between harness connector M6 terminals 23(LG/B), 24 (P/B) and steering angle sensor harness connector M52 terminals 4 (LG/B), 5 (P/B).

23(LG/B) – 4(LG/B) : Continuity should exist.
24(P/B) – 5(P/B) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-27, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Steering Angle Sensor and Combination Meter

EKS003LC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection. (sensor side, meter side and harness side)
 - Steering angle sensor
 - Combination meter

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector, steering angle sensor connector and combination meter connector.
2. Check continuity between steering angle sensor harness connector M52 terminals 4 (LG/B), 5 (P/B) and combination meter harness connector M41 terminals 15(LG/B), 16 (P/B).

4(LG/B) – 15(LG/B) : Continuity should exist.
5(P/B) – 16(P/B) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-27, "Work Flow"](#) .
 NG >> Repair harness.



EKS003LD

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection. (control module side and harness side)
 - ECM
 - Harness connector F34
 - Harness connector E34

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F102 terminals 174(LG/B) and 171(P/B).

174(LG/B) – 171(P/B) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between VDC/TCS/ABS control unit and ECM.



VDC/TCS/ABS Control Unit Circuit Check

EKS003LE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check the terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection. (control unit side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E218 terminals 61(LG/B) and 63(P/B).

61(LG/B) – 63(P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between ECM and VDC/TCS/ABS control unit.



EKS003LF

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check the terminals and connector of steering angle sensor for damage, bend and loose connection. (sensor side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M52 terminals 4(LG/B) and 5(P/B).

4(LG/B) – 5(P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between combination meter and steering angle sensor.



SKIA3777E

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check terminals and connector of combination meter for damage, bend and loose connection.(meter side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M41 terminals 15 (LG/B) and 16 (P/B).

15(LG/B) – 16(P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between steering angle sensor and combination meter.



TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(control module side and harness side)

- TCM
- Harness connector F105
- Harness connector M135

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F103 terminals 6 (LG/B) and 7(P/B).

6(LG/B) – 7(P/B) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace TCM.
 NG >> Repair harness between combination meter and TCM.



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(control module side, control unit side, meter side, sensor side and harness side)
 - TCM
 - Combination meter
 - Steering angle sensor
 - VDC/TCS/ABS control unit
 - ECM
 - Between TCM and ECM

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect TCM connector and harness connector F105.
2. Check continuity between TCM harness connector F103 terminals 6 (LG/B) and 7(P/B).

6(LG/B) – 7(P/B) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between TCM and harness connector F105.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between TCM harness connector F103 terminals 6 (LG/B), 7 (P/B) and ground.

6(LG/B) – ground : Continuity should not exist.

7(P/B) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between TCM and harness connector F105.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect combination meter connector, steering angle sensor connector and harness connector M6.
2. Check continuity between Data Link Connector M31 terminals 6 (LG/B) and 14(P/B).


6(LG/B) – 14(P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector M6 and harness connector M135
- Harness between harness connector M6 and Data Link Connector
- Harness between harness connector M6 and combination meter
- Harness between harness connector M6 and steering angle sensor



5. CHECK HARNESS FOR SHORT CIRCUIT

- Check continuity between Data Link Connector M31 terminals 6 (LG/B), 14(P/B) and ground.

6(LG/B) – ground : Continuity should not exist.


14(P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector M6 and harness connector M135
- Harness between harness connector M6 and Data Link Connector
- Harness between harness connector M6 and combination meter
- Harness between harness connector M6 and steering angle sensor



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector B63.
2. Check continuity between harness connector B6 terminals 23(LG/B) and 24(P/B).

23(LG/B) – 24(P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector B6 and harness connector B63.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B6 terminals 23(LG/B), 24(P/B) and ground.


23(LG/B) – ground : Continuity should not exist.

24(P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector B6 and harness connector B63.



8. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector B204.
2. Check continuity between harness connector B263 terminals 9(LG/B) and 8(P/B).

9(LG/B) – 8(P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Repair harness between harness connector B263 and harness connector B204.



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B263 terminals 9(LG/B), 8(P/B) and ground.


9(LG/B) – ground : Continuity should not exist.

8(P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Repair harness between harness connector B263 and harness connector B204.



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector and harness connector E34.
2. Check continuity between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B) and 63(P/B).


61(LG/B) – 63(P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E34 and harness connector E224
- Harness between harness connector E34 and VDC/TCS/ABS control unit



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B), 63(P/B) and ground.

61(LG/B) – ground : Continuity should not exist.


63(P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E34 and harness connector E224
- Harness between harness connector E34 and VDC/TCS/ABS control unit



12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector.
2. Check continuity between ECM harness connector F102 terminals 174 (LG/B) and 171(P/B).

174(LG/B) – 171(P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between ECM and harness connector F34.



13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F102 terminals 174 (LG/B), 171 (P/B) and ground.


174(LG/B) – ground : Continuity should not exist.

171(P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 14.

NG >> Repair harness between ECM and harness connector F34.



14. ECM/TCM INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-41, "ECM/TCM INTERNAL CIRCUIT INSPECTION"](#)

OK or NG


OK >> Connect all the connectors and diagnose again. Refer to [LAN-27, "Work Flow"](#).

NG >> Replace ECM and/or TCM.

Component Inspection ECM/TCM INTERNAL CIRCUIT INSPECTION

- Remove ECM and TCM from vehicle.
- Check resistance between ECM terminals 174 and 171.
- Check resistance between TCM terminals 6 and 7.

Unit	Terminal	Resistance value (Ω)
ECM	174 - 171	Approx. 108 - 132
TCM	6 - 7	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

PFP:23710


System Description

EKS003LX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS003LY




SKIA3778E

CAN SYSTEM (TYPE 2)

[CAN]

Schematic

EKS003SF



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)



[CAN]

Wiring Diagram — CAN —


EKS003LZ

LAN-CAN-03

▬ : DATA LINE



(M31)
W



(M41)
BR

REFER TO THE FOLLOWING.

(F105) -SUPER MULTIPLE JUNCTION (SMJ)

(F103) -ELECTRICAL UNITS


TKWM1045E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-04

▬ : DATA LINE



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M6)
GY

3	2	1		
8	7	6	5	4

(M52)
W

1	2	3	4		
5	6	7	8	9	10

(B63)
W

REFER TO THE FOLLOWING.





(B243) -ELECTRICAL UNITS

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TKWM0367E

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E218), (F102) -ELECTRICAL UNITS

Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "VDC", "ICC", and "A/T" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]	0		
			F.F.DATA
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "VDC", "ICC", and "A/T" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSNT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
TCM	OK		
VDC/TCS/ABS	OK		
METER/M&A	OK		
ICC	UNKWN		
BCM/SEC	OK		
IPDM E/R	OK		
AWD/4WD/e4WD	UNKWN		
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-48. "CHECK SHEET"](#).
4. Based on the data monitor results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-48. "CHECK SHEET"](#).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

5. According to the check sheet results (example), start inspection. Refer to [LAN-49. "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

Symptoms :

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
VDC
SELF-DIAG RESULTS

Attach copy of
ICC
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
VDC
CAN DIAG SUPPORT
MNTR

Attach copy of
ICC
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between VDC/TCS/ABS control unit and ICC sensor. Refer to [LAN-59, "Circuit Check Between VDC/TCS/ABS Control Unit and ICC Sensor"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8664E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check harness between ICC sensor and ICC unit. Refer to [LAN-60, "Circuit Check Between ICC sensor and ICC Unit"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN ✓	UNKWN ✓
VDC	NG	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
ICC	NG	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—

PKIA8665E



CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check harness between ICC unit and steering angle sensor. Refer to [LAN-61, "Circuit Check Between ICC Unit and Steering Angle Sensor"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8666E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check harness between steering angle sensor and combination meter. Refer to [LAN-62. "Circuit Check Between Steering Angle Sensor and Combination Meter"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN ✓	UNKWN ✓
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—

PKIA8667E



CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check ECM circuit. Refer to [LAN-62. "ECM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKW ^N	—	UNKW ^N	—	—	—	UNKW ^N	UNKW ^N
VDC	NG	UNKW ^N	UNKW ^N	—	—	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N
ICC	NG	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N
A/T	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—

PKIA8668E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check VDC/TCS/ABS control unit circuit. Refer to [LAN-63, "VDC/TCS/ABS Control Unit Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓
ICC	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	UNKWN	—

PKIA8669E



CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check ICC sensor circuit. Refer to [LAN-63. "ICC Sensor Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8670E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check ICC unit circuit. Refer to [LAN-64, "ICC Unit Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8671E



CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check steering angle sensor circuit. Refer to [LAN-64, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8672E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 10

Check combination meter circuit. Refer to [LAN-65, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	TCM
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN ✓	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN ✓	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓	—

PKIA8673E




Case 11

Check TCM circuit. Refer to [LAN-65, "TCM Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						TCM
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8674E



Case 12

Check CAN communication circuit. Refer to [LAN-66, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis						TCM
			ECM	VDC/TCS /ABS	ICC SENSOR	ICC	STRG	METER /M&A	
ENGINE	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN
VDC	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN
ICC	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—

PKIA8675E

Circuit Check Between VDC/TCS/ABS Control Unit and ICC Sensor

EKS003NB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection. (control unit side, sensor side and harness side)
 - VDC/TCS/ABS control unit
 - ICC sensor

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J

LAN

L
M


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector, VDC/TCS/ABS control unit connector and ICC sensor connector.
2. Check continuity between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B), 63 (P/B) and ICC sensor harness connector E52 terminals 3 (LG/B), 6 (P/B).

61(LG/B) – 3(LG/B) : Continuity should exist.
63(P/B) – 6(P/B) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between ICC sensor and ICC Unit

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(sensor side, unit side and harness side)
 - ICC sensor
 - ICC unit
 - Between ICC sensor and ICC unit

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector and harness connector E224.
2. Check continuity between ICC sensor harness connector E52 terminals 3(LG/B), 6 (P/B) and harness connector E224 terminals 6 (LG/B), 5 (P/B).

3 (LG/B) – 6 (LG/B) : Continuity should exist.
6 (P/B) – 5 (P/B) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check continuity between harness connector B204 terminals 6 (LG/B), 5 (P/B) and ICC unit connector B243 terminals 14 (LG/B), 5 (P/B).

6 (LG/B) – 14 (LG/B) : Continuity should exist.
5 (P/B) – 5 (P/B) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between ICC Unit and Steering Angle Sensor

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(unit side, sensor side and harness side)
 - ICC unit
 - Steering angle sensor
 - Between ICC unit and steering angle sensor

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector and harness connector B263.
2. Check continuity between ICC unit harness connector B243 terminals 14 (LG/B), 5 (P/B) and harness connector B263 terminals 9 (LG/B), 8 (P/B).

- 14 (LG/B) – 9 (LG/B) : Continuity should exist.**
5 (P/B) – 8 (P/B) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B6.
2. Check continuity between harness connector B63 terminals 9(LG/B), 8 (P/B) and harness connector B6 terminals 23(LG/B), 24 (P/B).

- 9 (LG/B) – 23 (LG/B) : Continuity should exist.**
8 (P/B) – 24 (P/B) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check continuity between harness connector M6 terminals 23(LG/B), 24 (P/B) and steering angle sensor harness connector M52 terminals 4 (LG/B), 5 (P/B).

- 23 (LG/B) – 4 (LG/B) : Continuity should exist.**
24 (P/B) – 5 (P/B) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Steering Angle Sensor and Combination Meter

EKS003M2

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection. (sensor side, meter side and harness side)
 - Steering angle sensor
 - Combination meter

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector, steering angle sensor connector and combination meter connector.
2. Check continuity between steering angle sensor harness connector M52 terminals 4 (LG/B), 5 (P/B) and combination meter harness connector M41 terminals 15(LG/B), 16 (P/B).

- 4 (LG/B) – 15 (LG/B) : Continuity should exist.**
- 5 (P/B) – 16 (P/B) : Continuity should exist.**

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#).
- NG >> Repair harness.



EKS003M3

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection. (control module side and harness side)
 - ECM
 - Harness connector F34
 - Harness connector E34

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F102 terminals 174 (LG/B) and 171 (P/B).

- 174 (LG/B) – 171 (P/B) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between VDC/TCS/ABS control unit and ECM.



VDC/TCS/ABS Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check the terminals and connector of VDC/TCS/ABS control unit for damage, bend and loose connection. (control unit side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect VDC/TCS/ABS control unit connector.
2. Check resistance between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B) and 63 (P/B).

61 (LG/B) – 63 (P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace VDC/TCS/ABS control unit.
 NG >> Repair harness between ECM and VDC/TCS/ABS control unit.



ICC Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check the terminals and connector of ICC sensor for damage, bend and loose connection. (sensor side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC sensor connector.
2. Check resistance between ICC sensor harness connector E52 terminals 3 (LG/B) and 6 (P/B).

3 (LG/B) – 6 (P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace ICC sensor.
 NG >> Repair harness between VDC/TCS/ABS control unit and ICC sensor.



ICC Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Check the terminals and connector of ICC unit for damage, bend and loose connection. (unit side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ICC unit connector.
2. Check resistance between ICC unit harness connector B243 terminals 14 (LG/B) and 5 (P/B).

14 (LG/B) – 5 (P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace ICC unit.
 NG >> Repair harness between ICC sensor and ICC unit.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Check the terminals and connector of steering angle sensor for damage, bend and loose connection.(sensor side and harness side)

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M52 terminals 4 (LG/B) and 5 (P/B).

4 (LG/B) – 5 (P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between combination meter and steering angle sensor.



Combination Meter Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Check terminals and connector of combination meter for damage, bend and loose connection.(meter side and harness side)

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M41 terminals 15 (LG/B) and 16 (P/B).

15 (LG/B) – 16 (P/B) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace combination meter.
NG >> Repair harness between steering angle sensor and combination meter.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(control module side and harness side)
 - TCM
 - Harness connector F105
 - Harness connector M135

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F103 terminals 6 (LG/B) and 7(P/B).

6 (LG/B) – 7 (P/B) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace TCM.
NG >> Repair harness between combination meter and TCM.



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check following terminals and connector for damage, bend and loose connection.(control module side, control unit side, unit side, meter side, sensor side and harness side)
 - TCM
 - Combination meter
 - Steering angle sensor
 - ICC unit
 - ICC sensor
 - VDC/TCS/ABS control unit
 - ECM
 - Between TCM and ECM

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect TCM connector and harness connector F105.
2. Check continuity between TCM harness connector F103 terminals 6 (LG/B) and 7(P/B).

6 (LG/B) – 7 (P/B) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between TCM and harness connector F105.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between TCM harness connector F103 terminals 6 (LG/B), 7 (P/B) and ground.

6 (LG/B) – ground : Continuity should not exist.

7 (P/B) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between TCM and harness connector F105.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect combination meter connector, steering angle sensor connector and harness connector M6.
2. Check continuity between Data Link Connector M31 terminals 6 (LG/B) and 14 (P/B).


6 (LG/B) – 14 (P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector M6 and harness connector M135
- Harness between harness connector M6 and Data Link Connector
- Harness between harness connector M6 and combination meter
- Harness between harness connector M6 and steering angle sensor



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between Data Link Connector M31 terminals 6 (LG/B), 14 (P/B) and ground.

6 (LG/B) – ground : Continuity should not exist.


14 (P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector M6 and harness connector M135
- Harness between harness connector M6 and Data Link Connector
- Harness between harness connector M6 and combination meter
- Harness between harness connector M6 and steering angle sensor



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector B63.
2. Check continuity between harness connector B6 terminals 23 (LG/B) and 24 (P/B).

23 (LG/B) – 24 (P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector B6 and harness connector B63.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B6 terminals 23 (LG/B), 24 (P/B) and ground.


23 (LG/B) – ground : Continuity should not exist.

24 (P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector B6 and harness connector B63.



8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector B204 and ICC unit connector.
2. Check continuity between harness connector B263 terminals 9 (LG/B) and 8 (P/B).


9 (LG/B) – 8 (P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B263 and harness connector B204
- Harness between harness connector B263 and ICC unit



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector B263 terminals 9 (LG/B), 8 (P/B) and ground.

9 (LG/B) – ground : Continuity should not exist.


8 (P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector B263 and harness connector B204
- Harness between harness connector B263 and ICC unit



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ICC sensor connector, VDC/TCS/ABS control unit connector and harness connector E34.
2. Check continuity between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B) and 63 (P/B).


61 (LG/B) – 63 (P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E34 and harness connector E224
- Harness between harness connector E34 and VDC/TCS/ABS control unit
- Harness between harness connector E34 and ICC sensor



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between VDC/TCS/ABS control unit harness connector E218 terminals 61 (LG/B), 63 (P/B) and ground.

61 (LG/B) – ground : Continuity should not exist.


63 (P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E34 and harness connector E224
- Harness between harness connector E34 and VDC/TCS/ABS control unit
- Harness between harness connector E34 and ICC sensor



12. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector.
2. Check continuity between ECM harness connector F102 terminals 174 (LG/B) and 171(P/B).

174(LG/B) – 171(P/B) : Continuity should not exist.

OK or NG

OK >> GO TO 13.

NG >> Repair harness between ECM and harness connector F34.



13. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F102 terminals 174 (LG/B), 171 (P/B) and ground.


174(LG/B) – ground : Continuity should not exist.

171(P/B) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 14.

NG >> Repair harness between ECM and harness connector F34.



14. ECM/TCM INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-70, "ECM/TCM INTERNAL CIRCUIT INSPECTION"](#)

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#) .


NG >> Replace ECM and/or TCM.

Component Inspection ECM/TCM INTERNAL CIRCUIT INSPECTION

EKS003M9

- Remove ECM and TCM from vehicle.
- Check resistance between ECM terminals 174 and 171.
- Check resistance between TCM terminals 6 and 7.

Unit	Terminal	Resistance value (Ω)
ECM	174 – 171	Approx. 108 - 132
TCM	6 – 7	



PKIA0298E