


# BRAKE SYSTEM

## SECTION **BR**

### CONTENTS

<b>PRECAUTIONS AND PREPARATION</b> .....	2	Assembly.....	13	GI
Precautions.....	2	Installation.....	13	MA
Commercial Service Tools.....	2	<b>REAR DISC BRAKE</b> .....	14	EM
<b>BRAKE HYDRAULIC LINE/CONTROL VALVE</b> .....	3	Pad Replacement.....	14	LC
Brake Hydraulic Line.....	3	Removal.....	16	EC
Dual Proportioning Valve.....	4	Disassembly.....	16	FE
<b>CHECK AND ADJUSTMENT</b> .....	5	Inspection — Caliper.....	17	CL
Checking Brake Fluid Level.....	5	Inspection — Rotor.....	18	MT
Checking Brake Line.....	5	Assembly.....	18	AT
Changing Brake Fluid.....	5	Installation.....	19	PD
Bleeding Brake System.....	5	<b>PARKING BRAKE CONTROL</b> .....	20	FA
<b>BRAKE PEDAL AND BRACKET</b> .....	6	Removal and Installation.....	20	RA
Removal and Installation.....	6	Inspection.....	21	BR
Inspection.....	6	Adjustment.....	21	ST
Adjustment.....	6	<b>ANTI-LOCK BRAKE SYSTEM</b> .....	22	BF
<b>MASTER CYLINDER</b> .....	7	Purpose.....	22	HA
Removal.....	7	Operation.....	22	EL
Disassembly.....	7	ABS Hydraulic Circuit.....	22	IDX
Inspection.....	8	System Components.....	23	
Assembly.....	8	System Description.....	23	
Installation.....	8	Removal and Installation.....	25	
<b>BRAKE BOOSTER/VACUUM HOSE</b> .....	9	Wiring Diagram — ABS —.....	27	
Brake Booster.....	9	<b>TROUBLE DIAGNOSES</b> .....	32	
Vacuum Hose.....	10	Contents.....	32	
<b>FRONT DISC BRAKE</b> .....	11	How to Perform Trouble Diagnoses for Quick and Accurate Repair.....	32	
Pad Replacement.....	11	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	65	
Removal.....	12	General Specifications.....	65	
Disassembly.....	12	Inspection and Adjustment.....	65	
Inspection — Caliper.....	12			
Inspection — Rotor.....	13			

## PRECAUTIONS AND PREPARATION



### Precautions

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- To clean or wash all parts of master cylinder, disc brake caliper and wheel cylinder, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.
- Use flare nut wrench when removing and installing brake tube.
- Always torque brake lines when installing.

### WARNING:


- Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.

### Commercial Service Tools


Tool name	Description
① Flare nut crows foot ② Torque wrench	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> </div> <div style="width: 45%;">                     Removing and installing each brake piping                 </div> </div> <p style="margin-top: 10px;">NT360</p> <p style="margin-top: 10px;"><b>a: 10 mm (0.39 in)</b></p>
Brake fluid pressure gauge	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> </div> <div style="width: 45%;">                     Measuring brake fluid pressure                 </div> </div> <p style="margin-top: 10px;">NT151</p>

# BRAKE HYDRAULIC LINE/CONTROL VALVE

## Brake Hydraulic Line



GI  
MA  
EM  
LC  
EC  
FE  
CL



### REMOVAL

#### CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

- All hoses must be free from excessive bending, twisting and pulling.


1. Connect vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Remove flare nut connecting brake tube and hose, then withdraw lock spring.
4. Cover openings to prevent entrance of dirt whenever disconnecting brake line.

MT  
AT  
PD  
FA  
RA

### INSPECTION

Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.

BR  
ST



### INSTALLATION

#### CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.

1. Tighten all flare nuts and connecting bolts.

#### Specification:

##### Flare nut

15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

##### Connecting bolt



17 - 20 N·m (1.7 - 2.0 kg-m, 12 - 14 ft-lb)

BF  
HA  
EL  
IDX

# BRAKE HYDRAULIC LINE/CONTROL VALVE

## Brake Hydraulic Line (Cont'd)

2. Refill until new brake fluid comes out of each air bleeder valve.
3. Bleed air. Refer to "Bleeding Brake System" (BR-5).



## Dual Proportioning Valve

### INSPECTION

#### CAUTION:

- Carefully monitor brake fluid level at master cylinder.
- Use new brake fluid "DOT 3".
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on paint areas, wash it away with water immediately.


1. Connect Tool to air bleeders of front and rear brakes on either LH and RH side.
2. Bleed air from the Tool.
3. Check fluid pressure by depressing brake pedal.

Unit: kPa (kg/cm<sup>2</sup>, psi)

Applied pressure (Front brake)	5,884 (60, 853)
Output pressure (Rear brake)	3,629 - 4,021 (37 - 41, 526 - 583)

4. Bleed air after disconnecting the Tool. Refer to "Bleeding Brake System" (BR-5).

# CHECK AND ADJUSTMENT



## Checking Brake Fluid Level

- Check fluid level in reservoir tank. It should be between Max and Min lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.
- Release parking brake lever and see if brake warning lamp goes off. If not, check brake system for leaks.

GI

## Checking Brake Line

### CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

MA

EM

1. Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.
2. Check for oil leakage by fully depressing brake pedal while engine is running.

LC

EC

## Changing Brake Fluid

### CAUTION:

- Refill with new brake fluid "DOT 3".
- Always keep fluid level higher than minimum line on reservoir tank.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

FE

CL




MT

1. Clean inside of reservoir tank, and refill with new brake fluid.
2. Connect a vinyl tube to each air bleeder valve.
3. Drain brake fluid from each air bleeder valve by depressing brake pedal.
4. Refill until brake fluid comes out of each air bleeder valve. Use same procedure as in bleeding hydraulic system to refill brake fluid. Refer to "Bleeding Brake System" (BR-5).

AT

PD

FA



## Bleeding Brake System

### CAUTION:


- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- Fill reservoir with new brake fluid "DOT 3". Make sure it is full at all times while bleeding air out of system.
- Place a container under master cylinder to avoid spillage of brake fluid.
- For models with ABS, turn ignition switch OFF and disconnect ABS actuator connectors or battery ground cable.

RA

BR

ST

BF



HA

EL

IDX


- Bleed air in the following order.  
Right rear brake → Left rear brake →  
Right front brake → Left front brake

  1. Connect a transparent vinyl tube to air bleeder valve.
  2. Fully depress brake pedal several times.
  3. With brake pedal depressed, open air bleeder valve to release air.
  4. Close air bleeder valve.
  5. Release brake pedal slowly.
  6. Repeat steps 2. through 5. until clear brake fluid comes out of air bleeder valve.


# BRAKE PEDAL AND BRACKET

## Removal and Installation

SEC. 465



SBR565CC



N·m (kg-m, ft-lb)

SBR463CA

### Inspection


Check brake pedal for following items.

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion

### Adjustment

Check brake pedal free height from dash reinforcement panel. Adjust if necessary.

- H: Free height**  
Refer to SDS (BR-65).
- D: Depressed height**  
Refer to SDS. (BR-65).  
Under force of 490 N (50 kg, 110 lb) with engine running
- C<sub>1</sub>, C<sub>2</sub>: Clearance between pedal stopper and threaded end of stop lamp switch and ASCD switch**  
0.3 - 1.0 mm (0.012 - 0.039 in)
- A: Pedal free play**  
1 - 3 mm (0.04 - 0.12 in)



SBR824B


1. Loosen lock nut and adjust pedal free height by turning brake booster input rod. Then tighten lock nut.
2. Check pedal free play.

**Make sure that stop lamps go off when pedal is released.**

3. Check brake pedal's depressed height while engine is running. If lower than specification, check brake system for leaks, accumulation of air or any damage to components (master cylinder, wheel cylinder, etc.); then make necessary repairs.

# MASTER CYLINDER

SEC. 460



SBR851C

## Removal


### CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve, depressing brake pedal to empty fluid from master cylinder.
3. Remove brake pipe flare nuts.
4. Remove master cylinder mounting nuts.

## Disassembly

1. Bend claws of stopper cap outward.



## MASTER CYLINDER

### Disassembly (Cont'd)

2. Remove valve stopper while piston is pushed into cylinder.
3. Remove piston assemblies.

If it is difficult to remove secondary piston assembly, gradually apply compressed air through fluid outlet.

4. Draw out reservoir tank.

### Inspection

Check for the following items.

**Replace any part if damaged.**

**Master cylinder:**

- Pin holes or scratches on inner wall.

**Piston:**

- Deformation of or scratches on piston cups.

### Assembly

1. Insert secondary piston assembly. Then insert primary piston assembly.

- Pay attention to alignment of secondary piston slit with valve stopper mounting hole of cylinder body.

2. Install stopper cap.

**Before installing stopper cap, ensure that claws are bent inward.**

3. Push reservoir tank seals.
4. Push reservoir tank into master cylinder.

5. Install valve stopper while piston is pushed into cylinder.

### Installation

**CAUTION:**

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.






1. Place master cylinder onto brake booster and secure mounting nuts lightly.
2. Torque mounting nuts.

**12 - 15 N·m (1.2 - 1.5 kg-m, 9 - 11 ft-lb)**

3. Fill up reservoir tank with new brake fluid.
4. Plug all ports on master cylinder with fingers to prevent air suction while releasing brake pedal.
5. Have driver depress brake pedal slowly several times until no air comes out of master cylinder.
6. Fit brake lines to master cylinder.
7. Tighten flare nuts.


**15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)**

8. Bleed air from brake system. Refer to "Bleeding Brake System" (BR-5).







# BRAKE BOOSTER/VACUUM HOSE




SBR002A




SBR365AA



SBR232CB



SBR281A



SBR116B

## Brake Booster

### ON-VEHICLE SERVICE

#### Operating check

- Stop engine and depress brake pedal several times. Check that pedal stroke does not change.
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.

#### Airtight check

- Start engine, and stop it after one or two minutes. Depress brake pedal several times slowly. The pedal should go further down the first time, and then it should gradually rise thereafter.
- Depress brake pedal while engine is running, and stop engine with pedal depressed. The pedal stroke should not change after holding pedal down for **30 seconds**.

## REMOVAL

### CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- Be careful not to deform or bend brake pipes, during removal of booster.

## INSPECTION

### Output rod length check

1. Apply vacuum of  $-66.7 \text{ kPa}$  ( $-500 \text{ mmHg}$ ,  $-19.69 \text{ inHg}$ ) to brake booster with a handy vacuum pump.
2. Check output rod length.

**Specified length:**

**10.275 - 10.525 mm (0.4045 - 0.4144 in)**

## INSTALLATION



### CAUTION:

- Be careful not to deform or bend brake pipes, during installation of booster.
- Replace clevis pin if damaged.
- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Take care not to damage brake booster mounting bolt thread when installing. Due to the acute angle of installation, the threads can be damaged with the dash panel.

# BRAKE BOOSTER/VACUUM HOSE

## Brake Booster (Cont'd)

1. Before fitting booster, temporarily adjust clevis to dimension shown.
2. Fit booster, then secure mounting nuts (brake pedal bracket to master cylinder) lightly.
3. Connect brake pedal and booster input rod with clevis pin.
4. Secure mounting nuts.  
**Specification: 13 - 16 N·m (1.3 - 1.6 kg-m, 9 - 12 ft-lb)**
5. Install master cylinder. Refer to "Installation" in "MASTER CYLINDER" (BR-8).
6. Bleed air. Refer to "Bleeding Brake System" (BR-5).



## Vacuum Hose

### REMOVAL AND INSTALLATION

#### CAUTION:

When installing vacuum hoses, pay attention to the following points.

- Do not apply any oil or lubricants to vacuum hose and check valve.
- Insert vacuum tube into vacuum hose as shown.
- Install check valve, paying attention to its direction.


### INSPECTION

#### Hoses and connectors

Check vacuum lines, connections and check valve for airtightness, improper attachment chafing and deterioration.



#### Check valve

Check vacuum with a vacuum pump.



Connect to booster side	Vacuum should exist.
Connect to engine side	Vacuum should not exist.

# FRONT DISC BRAKE



## Pad Replacement

### WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

### CAUTION:

- When cylinder body is open, do not depress brake pedal because piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.

1. Remove master cylinder reservoir cap.
2. Remove pin bolt.
3. Open cylinder body upward. Then remove pad retainers, and inner and outer shims.


**Standard pad thickness:**

10 mm (0.39 in)

**Pad wear limit:**

2.0 mm (0.079 in)

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.




- |                             |                   |                 |
|-----------------------------|-------------------|-----------------|
| ① Shim cover                | ⑧ Pad retainer    | ⑭ Cylinder body |
| ② Inner shim                | ⑨ Outer pad       | ⑮ Air bleeder   |
| ③ Inner pad                 | ⑩ Outer shim      | ⑯ Piston seal   |
| ④ Pin bolt                  | ⑪ Connecting bolt | ⑰ Piston        |
| ⑤ Main pin                  | ⑫ Copper washer   | ⑱ Dust seal     |
| ⑥ Torque member fixing bolt | ⑬ Brake hose      | ⑲ Torque member |
| ⑦ Retainer boot             |                   |                 |

## FRONT DISC BRAKE

### Removal


#### WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.



Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.



### Disassembly

#### WARNING:

Do not place your fingers in front of piston.

#### CAUTION:

Do not scratch or score cylinder wall.

1. Push out piston with piston boot with compressed air.
2. Remove piston seal with a suitable tool.

### Inspection — Caliper

#### CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

#### CAUTION:

Use brake fluid to clean. Never use mineral oil.

#### PISTON

#### CAUTION:


Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign materials are stuck to sliding surface.

Check piston for score, rust, wear, damage or presence of foreign materials. Replace if any of the above conditions are observed.

#### SLIDE PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks or other damage. Replace if any of the above conditions are observed.

# FRONT DISC BRAKE



## Inspection — Rotor

### RUBBING SURFACE

Check rotor for roughness, cracks or chips.

### RUNOUT

1. Secure rotor to wheel hub with at least two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

**Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to "Front Wheel Bearing" in FA section.**

#### Maximum runout:

**0.07 mm (0.0028 in)**

3. If the runout is out of specification, find minimum runout position as follows:
  - a. Remove nuts and rotor from wheel hub.
  - b. Shift the rotor one hole and secure rotor to wheel hub with nuts.
  - c. Measure runout.
  - d. Repeat steps a. to c. so that minimum runout position can be found.
4. If the runout is still out of specification, turn rotor with on-car brake lathe ("MAD, DL-8700", "AMMCO 700 and 705" or equivalent).

### THICKNESS


#### Thickness variation (At least 8 positions):

**Maximum 0.01 mm (0.0004 in)**

If thickness variation exceeds the specification, turn rotor with on-car brake lathe.


#### Rotor repair limit:

**18.0 mm (0.709 in)**



## Assembly

1. Insert piston seal into groove on cylinder body.
2. With piston boot fitted to piston, insert piston boot into groove on cylinder body and install piston.
3. Properly secure piston boot.



## Installation

### CAUTION:



- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.

1. Install brake hose to caliper securely.

**Fit brake hose between the caliper protrusions.**

2. Install all parts and secure all bolts.
3. Bleed air. Refer to "Bleeding Brake System" (BR-5).

## REAR DISC BRAKE



### Pad Replacement

#### WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.

#### CAUTION:

- When cylinder body is open, do not depress brake pedal because piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims in replacing pads.
- If shims are rusted or show peeling of rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.


1. Remove master cylinder reservoir cap.
2. Release parking brake.
3. Remove brake cable mounting bolts from the rear suspension.
4. Remove pin bolts.
5. Remove cylinder body. Then remove pad retainers, and inner and outer shims.

#### Standard pad thickness:

9.5 mm (0.374 in)


#### Pad wear limit:

2.0 mm (0.079 in)




6. When installing new pads, push piston into cylinder body by gently turning piston clockwise, as shown.

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.



# REAR DISC BRAKE


## SEC. 441



- |                          |                |                             |
|--------------------------|----------------|-----------------------------|
| ① Nut                    | ⑮ O-ring       | ⑳ Adjusting nut             |
| ② Washer                 | ⑯ Push rod     | ㉑ Cup                       |
| ③ Return spring          | ⑰ Key plate    | ㉒ Piston                    |
| ④ Parking brake lever    | ⑱ Ring C       | ㉓ Dust seal                 |
| ⑤ Cam boot               | ⑲ Seat         | ㉔ Inner shim                |
| ⑥ Cam                    | ⑳ Spring       | ㉕ Inner pad                 |
| ⑦ Brake hose             | ㉑ Spring cover | ㉖ Outer pad                 |
| ⑧ Connecting bolt        | ㉒ Ring B       | ㉗ Outer shim                |
| ⑨ Copper washer          | ㉓ Piston seal  | ㉘ Pin                       |
| ⑩ Bleed screw            | ㉔ Ring A       | ㉙ Pin boot                  |
| ⑪ Pin bolt               | ㉕ Spacer       | ㉚ Pad retainer              |
| ⑫ Cable mounting bracket | ㉖ Wave washer  | ㉛ Torque member             |
| ⑬ Cylinder               | ㉗ Spacer       | ㉜ Torque member fixing bolt |
| ⑭ Strut                  | ㉘ Ball bearing |                             |

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## REAR DISC BRAKE




### Removal

#### WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne particles or other materials.


1. Remove brake cable mounting bracket bolt and lock spring.
2. Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.




### Disassembly


1. Remove piston by turning it counterclockwise with suitable commercial service tool or long nose pliers.



2. Pry off ring A from piston with suitable pliers and remove adjusting nut.



3. Disassemble cylinder body.
  - a. Pry off ring B with suitable pliers, then remove spring cover, spring and seat.
  - b. Pry off ring C, then remove key plate, push rod and strut.







## REAR DISC BRAKE

### Disassembly (Cont'd)

c. Remove piston seal.

**Be careful not to damage cylinder body.**



4. Remove return spring, stopper bolt and lever.

### Inspection — Caliper

#### CAUTION:

**Use brake fluid to clean cylinder. Never use mineral oil.**

#### CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

#### TORQUE MEMBER

Check for wear, cracks or other damage. Replace if necessary.

#### PISTON

##### CAUTION:

**Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign matter is stuck to sliding surface.**

Check piston for score, rust, wear, damage or presence of foreign materials.

Replace if any of the above conditions are observed.

#### PIN AND PIN BOOT

Check for wear, cracks or other damage.

Replace if any of the above conditions are observed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


BF

HA

EL

IDX

## REAR DISC BRAKE



### Inspection — Rotor

#### RUBBING SURFACE

Check rotor for roughness, cracks or chips.

#### RUNOUT

1. Secure rotor to wheel hub with two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

**Make sure that axial end play is within the specifications before measuring. Refer to “Rear Wheel Bearing” in RA section.**

3. Change relative positions of rotor and wheel hub so that runout is minimized.

**Maximum runout:**

**0.07 mm (0.0028 in)**

#### THICKNESS

**Rotor repair limit:**

**Standard thickness**


**9 mm (0.35 in)**

**Minimum thickness**

**8 mm (0.31 in)**


**Thickness variation (At least 8 portions)**

**Maximum 0.02 mm (0.0008 in)**




### Assembly

1. Install cup in the specified direction.




2. Fit push rod into square hole in key plate. Also match convex portion of key plate with concave portion of cylinder.





3. Install ring C with a suitable tool.

# REAR DISC BRAKE


## Assembly (Cont'd)



4. Install seat, spring, spring cover and ring B while depressing with suitable commercial service tool or press and drift.



5. Install cup, adjuster, bearing, spacers, washers and ring A with a suitable tool.



6. Fit lever and tighten stopper bolt.  
7. Fit return spring in the order shown.

## Installation

### CAUTION:

- Refill with new brake fluid "DOT 3".
  - Never reuse drained brake fluid.
1. Install brake hose to caliper securely.
  2. Install all parts and secure all bolts.
  3. Bleed air. Refer to "Bleeding Brake System" (BR-5).

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

**BR**

ST

BF


HA

EL


IDX

# PARKING BRAKE CONTROL

SEC. 443




SBR861C




## Removal and Installation

1. To remove parking brake cable, first remove center console.
2. Disconnect warning lamp connector.
3. Remove bolts, slacken off and remove adjusting nut.



4. Remove lock plate, then disconnect cable from caliper.



- When installing parking brake cable at rear caliper, make sure to align matchmark on cable guide.

# PARKING BRAKE CONTROL

## Inspection

1. Check control lever for wear or other damage. Replace if necessary.
2. Check wires for discontinuity or deterioration. Replace if necessary.
3. Check warning lamp and switch. Replace if necessary.
4. Check parts at each connecting portion and, if found deformed or damaged, replace.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

BF

HA




EL

IDX

## Adjustment

Pay attention to the following points after adjustment.

- There is no drag when control lever is being released.
- Parking brake lever returns to stopper bolt when control lever for rear disc brake is released.



1. Pull control lever up by 4 or 5 notches.
2. Insert a box wrench into opening in control lever and loosen self-lock adjusting nut to slacken cables.
3. Completely push control lever down.
4. Forcefully depress brake pedal about five times (so that caliper is automatically set in position.).
5. Pull lever up by 4 or 5 notches.
6. Turn adjusting nut as shown in figure and adjust lever stroke to specified value.
7. Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.
8. Bend warning lamp switch plate. Warning lamp should come on when lever is pulled "A" notches. It should go off when the lever is fully released.

**Number of notches : 7 - 9 [196 N (20 kg, 44 lb)]**

**Number of "A" notches : 1**

# ANTI-LOCK BRAKE SYSTEM

## Purpose

The Anti-Lock Brake System (ABS) consists of electronic and hydraulic components. It allows for control of braking force so that locking of the wheels can be avoided.


The ABS:

- 1) Improves proper tracking performance through steering wheel operation.
- 2) Increases obstacle avoidance through steering wheel operation.
- 3) Improves vehicle stability.

## Operation


- The ABS will not operate at speeds below 5 to 10 km/h (3 to 6 MPH) to completely stop the vehicle. (The speeds will vary according to road conditions.)
- The ABS has self-test capabilities. A mechanical noise may be heard as the ABS performs a self-test the first time the vehicle reaches 10 km/h (6 MPH). This is a normal part of the self-test feature. If a malfunction is found during this check, the anti-lock warning light will come on.
- During ABS operation, a mechanical noise may be heard. This is a normal condition.

## ABS Hydraulic Circuit



# ANTI-LOCK BRAKE SYSTEM

## System Components





## System Description

### SENSOR

The sensor unit consists of a gear-shaped sensor rotor and a sensor element. The element contains a bar magnet wound with a coil. The sensor is installed on the back side of the brake rotor or the final drive. As the wheel rotates, the sensor generates a sine-wave pattern. The frequency and voltage increase(s) as the rotating speed increases.


### CONTROL UNIT

The control unit computes the wheel rotating speed by the signal current sent from the sensor. Then it supplies a DC current to the actuator solenoid valve. It also controls ON-OFF operation of the solenoid valve relay and motor relay. If any electrical malfunction should be detected in the system, the warning light is turned on. In this condition, the ABS will be deactivated, and the vehicle's brake system reverts to normal operation.



# ANTI-LOCK BRAKE SYSTEM

## System Description (Cont'd)



### ACTUATOR

The actuator contains:

- An electric motor and pump
- Two relays
- Six solenoid valves, each inlet and outlet for
  - LH front
  - RH front
  - LH and RH rear

These components control the hydraulic circuit. The ABS control unit directs the actuator to increase, hold or decrease hydraulic pressure to all or individual wheels.

### ABS actuator operation

		Inlet solenoid valve	Outlet solenoid valve	
Normal brake operation		OFF (Open)	OFF (Closed)	Master cylinder brake fluid pressure is directly transmitted to caliper via the inlet solenoid valve.
ABS operation	Pressure hold	ON (Closed)	OFF (Closed)	Hydraulic circuit is shut off to hold the caliper brake fluid pressure.
	Pressure decrease	ON (Closed)	ON (Open)	Caliper brake fluid is sent to reservoir via the outlet solenoid valve. Then it is pushed up to the master cylinder by pump.
	Pressure increase	OFF (Open)	OFF (Closed)	Master cylinder brake fluid pressure is transmitted to caliper.





# ANTI-LOCK BRAKE SYSTEM

## Removal and Installation

### CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth. When removing the front wheel hub or final drive assemblies, first remove the ABS wheel sensor from the assembly. Failure to do so may result in damage to the sensor wires making the sensor inoperative.


### WHEEL SENSORS



### SENSOR ROTOR

#### Removal

1. Remove the front wheel hub or final drive companion flange. Refer to FA and PD sections.
2. Remove the sensor rotor using suitable puller, drift and bearing replacer.





#### Installation

Install the sensor rotor using suitable drift and press.

- Always replace sensor rotor with new one.
- Pay attention to the direction of front sensor rotor as show in figure.


# ANTI-LOCK BRAKE SYSTEM

## Removal and Installation (Cont'd)



### CONTROL UNIT

Location: Under trunk side finisher LH.



### ACTUATOR

#### Removal


1. Disconnect battery cable.
2. Drain brake fluid. Refer to "Changing Brake Fluid" (BR-5).
3. Apply different colored paint to each pipe connector and actuator to prevent incorrect connection.
4. Disconnect connector, brake pipes and remove fixing nuts and actuator ground cable.

#### Installation

##### CAUTION:

After installation, refill brake fluid. Then bleed air. Refer to "Bleeding Brake System" (BR-5).

1. Tighten actuator ground cable.  
**Place ground cable at a notch of mounting bracket.**
2. Connect brake pipes temporarily.
3. Tighten fixing nuts.
4. Tighten brake pipes.
5. Fix actuator harness clip on the mounting bracket.
6. Connect connector and battery cable.




### ACTUATOR RELAYS

1. Disconnect battery cable.
2. Remove actuator relay cover.
3. Pull out relays.


# ANTI-LOCK BRAKE SYSTEM

## Wiring Diagram — ABS —

BR-ABS-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX





Refer to last page (Foldout page).  
F3, M63

# ANTI-LOCK BRAKE SYSTEM

## Wiring Diagram — ABS — (Cont'd)

BR-ABS-02




Refer to last page (Foldout page).

(M9), (E109)

# ANTI-LOCK BRAKE SYSTEM


## Wiring Diagram — ABS — (Cont'd)

BR-ABS-03





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
**BR**

ST  
BF  
HA  
EL  
IDX



# ANTI-LOCK BRAKE SYSTEM



## Wiring Diagram — ABS — (Cont'd)



# ANTI-LOCK BRAKE SYSTEM

## Wiring Diagram — ABS — (Cont'd)

BR-ABS-05




Refer to last page (Foldout page).

(M10) , (B1)  
(F3) , (M63)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## Contents

<b>How to Perform Trouble Diagnoses for Quick and Accurate Repair</b> .....	BR-32
<b>Self-diagnosis</b> .....	BR-33
<b>Consult</b> .....	BR-36
<b>Consult Inspection Procedure</b> .....	BR-37
<b>Component Parts and Harness Connector Location</b> .....	BR-42
<b>Preliminary Check</b> .....	BR-43
<b>Ground Circuit Check</b> .....	BR-44
<b>Circuit Diagram for Quick Pinpoint Check</b> .....	BR-45
<b>Diagnostic Procedure 1 Warning lamp does not work</b> .....	BR-46
<b>Diagnostic Procedure 2 Control unit or ground circuit</b> .....	BR-48
<b>Diagnostic Procedure 3 Actuator solenoid valve</b> .....	BR-50
<b>Diagnostic Procedure 4 Wheel sensor or rotor</b> .....	BR-51
<b>Diagnostic Procedure 5 Motor relay or motor</b> .....	BR-53
<b>Diagnostic Procedure 6 Solenoid valve relay</b> .....	BR-56
<b>Diagnostic Procedure 7 Power supply</b> .....	BR-59
<b>Diagnostic Procedure 8 Memory volt stop</b> .....	BR-60
<b>Diagnostic Procedure 9 Pedal vibration and noise</b> .....	BR-61
<b>Diagnostic Procedure 10 Long stopping distance</b> .....	BR-62
<b>Diagnostic Procedure 11 Unexpected pedal action</b> .....	BR-62
<b>Diagnostic Procedure 12 ABS does not work</b> .....	BR-63
<b>Diagnostic Procedure 13 ABS works frequently</b> .....	BR-63
<b>Electrical Component Inspection</b> .....	BR-64



## How to Perform Trouble Diagnoses for Quick and Accurate Repair

### INTRODUCTION


The ABS system has an electronic control unit to control major functions. The control unit accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. It is also important to check for conventional problems: such as air leaks in the booster or lines, lack of brake fluid, or other problems with the brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a ABS complaint. The customer is a very good source of information on such problems; especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS controlled vehicle.





## Self-diagnosis

### FUNCTION




- When a problem occurs in the ABS, the warning light on the instrument panel comes on.
- A maximum of three malfunctions are stored in the memory of the ABS control unit.

**Erase the self-diagnosis results stored in the control unit after malfunctions are repaired (See next page).**

- The self-diagnosis results are identified by Consult or LED on the control unit.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

### SELF-DIAGNOSIS PROCEDURE




## TROUBLE DIAGNOSES

### Self-diagnosis (Cont'd)

#### HOW TO READ SELF-DIAGNOSTIC RESULTS (Malfunction codes)

- Determine the code No. by counting the number of times the LED flashes on and off.
- The malfunction code chart is given on the next page.



#### HOW TO ERASE SELF-DIAGNOSTIC RESULTS (Malfunction codes)

- Disconnect ABS control unit connectors or battery negative terminal for at least one minute.
- When using CONSULT, touch "ERASE" on the CONSULT screen with self-diagnostic results mode.

# TROUBLE DIAGNOSES

## Self-diagnosis (Cont'd)

### MALFUNCTION CODE/SYMPTOM CHART

Code No. (No. of LED flashes)	Malfunctioning part and circuit	Diagnostic procedure	
01	Front right sensor (open-circuit)	4	GI
02	Front left sensor (open-circuit)	4	
03	Rear sensor (open-circuit)	4	MA
05	Front right sensor (short-circuit)	4	
06	Front left sensor (short-circuit)	4	EM
07	Rear sensor (short-circuit)	4	
11	Actuator front right inlet solenoid valve (open-circuit)	3	LC
12	Actuator front left inlet solenoid valve (open-circuit)	3	
13	Actuator rear inlet solenoid valve (open-circuit)	3	EC
15	Actuator front right outlet solenoid valve (open-circuit)	3	FE
16	Actuator front left outlet solenoid valve (open-circuit)	3	
17	Actuator rear outlet solenoid valve (open-circuit)	3	CL
21	Actuator front right inlet solenoid valve (short-circuit)	3	MT
22	Actuator front left inlet solenoid valve (short-circuit)	3	
23	Actuator rear inlet solenoid valve (short-circuit)	3	AT
25	Actuator front right outlet solenoid valve (short-circuit)	3	PD
26	Actuator front left outlet solenoid valve (short-circuit)	3	
27	Actuator rear outlet solenoid valve (short-circuit)	3	FA
41	Solenoid valve relay circuit (unable to turn off)	6	
42	Solenoid valve relay circuit (unable to turn on)	6	RA
43	Actuator motor or motor relay (unable to turn off)	5	
44	Actuator motor or motor relay (unable to turn on)	5	BR
47	Power supply (High voltage)	7	
48	Power supply (Low voltage)	7	ST
45, 46, 77 LED deactivation or continuous activation	Control unit Ground circuit	2	BF
Warning light does not come on when ignition switch is turned on.	Fuse, warning light bulb or warning light circuit Control unit power supply circuit	1	HA
Pedal vibration and noise	—	9	
Long stopping distance	—	10	EL
Unexpected pedal action	—	11	
ABS does not work.	—	12	IDX
ABS works frequently.	—	13	

## TROUBLE DIAGNOSES






### Consult

#### CONSULT APPLICATION TO ABS

ITEM	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST
Front right wheel sensor	X	X	—
Front left wheel sensor	X	X	—
Rear wheel sensor	X	X	—
Stop lamp switch	—	X	—
Engine revolution signal	—	X	—
Front right inlet solenoid valve	X	X	X
Front right outlet solenoid valve	X	X	X
Front left inlet solenoid valve	X	X	X
Front left outlet solenoid valve	X	X	X
Rear inlet solenoid valve	X	X	X
Rear outlet solenoid valve	X	X	X
Actuator solenoid valve relay	X	X	—
Actuator motor relay (ABS MOTOR is shown on the Data Monitor screen.)	X	X	X
ABS warning light	—	X	—
Battery voltage (SENSOR VOLT is shown on the Data Monitor screen.)	X	X	—

X: Applicable.

—: Not applicable.



## Consult Inspection Procedure

### SELF-DIAGNOSIS PROCEDURE

**A**

- 1) Turn ignition switch OFF.
- 2) Connect Consult to Data Link Connector for Consult.

- 1) Start engine.
- 2) Drive vehicle over 15 km/h (9 MPH) for at least one minute.

**B** 1) Stop vehicle with engine running and touch "START" on Consult screen.

**C** 2) Touch "ABS".

**D** 3) Touch "SELF-DIAG RESULTS".

- The screen shows the detected malfunction and the times of ignition switch ON and OFF after it occurred.

Make the necessary repairs following the diagnostic procedures.

**E** After the malfunctions are repaired, erase the self-diagnostic results stored in the control unit by touching "ERASE".

Check warning lamp for deactivation after driving vehicle over 15 km/h (9 MPH) for at least one minute.

Test the ABS in a safe area to verify that it functions properly.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## TROUBLE DIAGNOSES

### Consult Inspection Procedure (Cont'd)


#### SELF-DIAGNOSTIC RESULTS MODE

Diagnostic item	Diagnostic item is detected when ...	Diagnostic procedure
FR RH SENSOR [OPEN]	● Circuit for front right wheel sensor is open. (An abnormally high input voltage is entered.)	4
FR LH SENSOR [OPEN]	● Circuit for front left wheel sensor is open. (An abnormally high input voltage is entered.)	4
REAR SENSOR [OPEN]	● Circuit for rear sensor is open. (An abnormally high input voltage is entered.)	4
FR RH SENSOR [SHORT]	● Circuit for front right wheel sensor is shorted. (An abnormally low input voltage is entered.)	4
FR LH SENSOR [SHORT]	● Circuit for front left wheel sensor is shorted. (An abnormally low input voltage is entered.)	4
REAR SENSOR [SHORT]	● Circuit for rear sensor is shorted. (An abnormally low input voltage is entered.)	4
FR RH IN ABS SOL [OPEN]	● Circuit for front right inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR LH IN ABS SOL [OPEN]	● Circuit for front left inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
RR IN ABS SOL [OPEN]	● Circuit for rear inlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR RH IN ABS SOL [SHORT]	● Circuit for front right inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
FR LH IN ABS SOL [SHORT]	● Circuit for front left inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
RR IN ABS SOL [SHORT]	● Circuit for rear inlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
FR RH OUT ABS SOL [OPEN]	● Circuit for front right outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR LH OUT ABS SOL [OPEN]	● Circuit for front left outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
RR OUT ABS SOL [OPEN]	● Circuit for rear outlet solenoid valve is open. (An abnormally low output voltage is entered.)	3
FR RH OUT ABS SOL [SHORT]	● Circuit for front right outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
FR LH OUT ABS SOL [SHORT]	● Circuit for front left outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
RR OUT ABS SOL [SHORT]	● Circuit for rear outlet solenoid valve is shorted. (An abnormally high output voltage is entered.)	3
ABS ACTUATOR RELAY [ON FAILURE]	● Actuator solenoid valve relay is ON, even control unit sends off signal.	6
ABS ACTUATOR RELAY [OFF FAILURE]	● Actuator solenoid valve relay is OFF, even control unit sends on signal.	6
ABS MOTOR [ON FAILURE]	● Actuator motor is running, even control unit sends off signal.	5
ABS MOTOR [OFF FAILURE]	● Actuator motor is not running, even control unit sends on signal.	5
BATTERY VOLT [VB-HIGH]	● Power source voltage supplied to ABS control unit is abnormally high.	7
BATTERY VOLT [VB-LOW]	● Power source voltage supplied to ABS control unit is abnormally low.	7
CONTROL UNIT	● Function of calculation in ABS control unit has failed.	2
MEMORY VOLT STOP	● Connectors for ABS control unit or battery terminals are disconnected.	8

# TROUBLE DIAGNOSES


## Consult Inspection Procedure (Cont'd)

### DATA MONITOR PROCEDURE



1) Turn ignition switch OFF.  
2) Connect Consult to Data Link Connector for Consult.  
3) Turn ignition switch ON.


GE  
MA  
EM




**A** 1) Touch "START" on Consult screen.  
**B** 2) Touch "ABS".  
**C** 3) Touch "DATA MONITOR".

LC  
EC


**D** 1) Touch "SETTING" on "SELECT MONITOR ITEM" screen.  
**E** 2) Touch "LONG TIME" on "SET RECORDING COND" screen.  
**D** 3) Touch "START" on "SELECT MONITOR ITEM".



FE  
CL



MT  
AT



PD  
FA

RA  
BR

ST  
BF

HA  
EL

IDX






# TROUBLE DIAGNOSES

## Consult Inspection Procedure (Cont'd)

### ACTIVE TEST PROCEDURE

- When conducting Active test, vehicle must be stationary.
- When ABS warning lamp stays on, never conduct Active test.

- 1) Turn ignition switch OFF.
- 2) Connect Consult to Data Link Connector for Consult.
- 3) Start engine.



- 1) Touch "START" on Consult screen.
- 2) Touch "ABS".
- 3) Touch "ACTIVE TEST".

- 1) Select active test item by touching screen.
- 2) Touch "START".

Carry out the active test by touching screen key.



# TROUBLE DIAGNOSES

## Consult Inspection Procedure (Cont'd)









### DATA MONITOR MODE

MONITOR ITEM	CONDITION	SPECIFICATION
FR RH SENSOR FR LH SENSOR REAR SENSOR	Drive vehicle. (Each wheel is rotating.)	Wheel speed signal (Almost the same speed as speedometer.)
STOP LAMP SW	Brake is depressed.	Depress the pedal: ON Release the pedal: OFF
ENG RPM SIGNAL	Engine is running.	Engine stops: STOP Engine is running: RUN
FR RH IN SOL FR RH OUT SOL FR LH IN SOL FR LH OUT SOL REAR IN SOL REAR OUT SOL	1. Drive vehicle at speeds over 15 km/h (9 MPH) for at least one minute. 2. Engine is running.	Operating conditions for each solenoid valve are indicated. ABS is not operating: OFF
MOTOR RLY		ABS is not operating: OFF ABS is operating: ON
ACTUATOR RLY	Ignition switch is ON or engine is running.	Ignition switch ON (Engine stops): OFF Engine running: ON
WARNING LAMP		ABS warning lamp is turned on: ON ABS warning lamp is turned off: OFF
SENSOR VOLT		Power supply voltage for control unit

### ACTIVE TEST MODE






TEST ITEM	CONDITION	JUDGEMENT												
FR RH SOLENOID FR LH SOLENOID FRONT SOLENOID REAR SOLENOID	Engine is running.	Brake fluid pressure control operation  <table style="margin-left: 40px;"> <tr> <td></td> <td>IN SOL</td> <td>OUT SOL</td> </tr> <tr> <td>UP (Increase):</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>KEEP (Hold):</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>DOWN (Decrease):</td> <td>ON</td> <td>ON</td> </tr> </table>		IN SOL	OUT SOL	UP (Increase):	OFF	OFF	KEEP (Hold):	ON	OFF	DOWN (Decrease):	ON	ON
		IN SOL	OUT SOL											
UP (Increase):	OFF	OFF												
KEEP (Hold):	ON	OFF												
DOWN (Decrease):	ON	ON												
ABS MOTOR		ABS actuator motor ON: Motor runs OFF: Motor stops												

Component Parts and Harness Connector Location




# TROUBLE DIAGNOSES


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
**BR**  
ST  
BF  
HA  
EL  
IDX



## Preliminary Check



# TROUBLE DIAGNOSES




## Ground Circuit Check

### ACTUATOR MOTOR GROUND

- Check resistance between actuator motor ground terminal and body ground.


**Resistance: approximately 0Ω**



### CONTROL UNIT GROUND

- Check resistance between control unit connector terminals and ground.

**Resistance: approximately 0Ω**




### ACTUATOR GROUND

- Check resistance between actuator harness 8-pin connector (body side) terminal ① and ground.

**Resistance: approximately 0Ω**

# TROUBLE DIAGNOSES

## Circuit Diagram for Quick Pinpoint Check










GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
**BR**  
ST  
BF  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 1 (Not self-diagnostic item)



Warning lamp does not work when ignition switch is turned ON.



Ⓐ  
(Go to next page.)

# TROUBLE DIAGNOSES

## Diagnostic Procedure 1 (Not self-diagnostic item) (Cont'd)



\*: Specifications may vary depending on the type of tester.  
 Before performing this inspection, refer to the instruction manual of the tester.


GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 PD  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 2

### CONTROL UNIT OR GROUND CIRCUIT


(Malfunction code No. 45, 46, 77, LED deactivation or continuous activation)



- Disconnect connectors from control unit and actuator. Check terminals for damage or connection. Then reconnect connectors.
  - Carry out self-diagnosis again.
- Does warning light activate again?**

No → Inspection end

Yes




**SOLENOID VALVE RELAY CHECK**

Refer to SOLENOID VALVE RELAY in Electrical Components Inspection (BR-64).

NG → Replace solenoid valve relay.

OK



**SOLENOID VALVE RELAY GROUND CIRCUIT**

- Disconnect actuator 8-pin connector.
- Check continuity between actuator 8-pin connector (body side) terminal ⑫ and body ground.

**Continuity should exist.**

NG → Repair harness and connectors.

OK

**B**

- Disconnect control unit connectors and actuator 6-pin connector.
- Check continuity between control unit connector terminal ⑫ and actuator 6-pin connector (body side) terminal ⑪.

**Continuity should exist.**

NG → Repair harness and connectors.

OK

**C**

- Check continuity between actuator 6-pin connector (actuator side) terminal ⑪ and solenoid valve relay box terminal ⑩.

Actuator	Relay box	Continuity
11 ⊕	30 ⊖	Yes
11 ⊖	30 ⊕	No

NG → Replace actuator assembly.

**Note: Pay attention to tester polarity\*.**

OK

Ⓐ



(Go to next page.)

\*: Specifications may vary depending on the type of tester. Before performing this inspection, refer to the instruction manual of the tester.



# TROUBLE DIAGNOSES

## Diagnostic Procedure 2 (Cont'd)




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
**BR**  
ST  
BF  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 3


### ACTUATOR SOLENOID VALVE (Malfunction code No. 11 - 13, 15 - 17, 21 - 23, 25 - 27)



- Disconnect connectors from control unit and actuator. Check terminals for damage or loose connection. Then reconnect connectors.
  - Carry out self-diagnosis again.
- Does warning light activate again?**

No → Inspection end

Yes




- A**
- ACTUATOR SOLENOID VALVE CHECK**
- Disconnect control unit connectors.
  - Check resistance between control unit connector terminals.

Code No. (LED flashes.)	Terminals
11, 21	⑦ - ⑧
12, 22	⑦ - ⑩
13, 23	⑦ - ⑨
15, 25	⑦ - ⑭
16, 26	⑦ - ⑳
17, 27	⑦ - ㉓

**Resistance: 3.7 - 8.0Ω**

OK → Replace control unit.

NG



- B**
- Disconnect actuator connectors.
  - Check resistance between actuator connector (actuator side) terminals.

Code No. (LED flashes.)	Terminals
11, 21	⑥ - ②
12, 22	⑥ - ①
13, 23	⑥ - ③
15, 25	⑥ - ㉔
16, 26	⑥ - ㉔
17, 27	⑥ - ㉔

**Resistance: 3.7 - 8.0Ω**

NG → Replace actuator.

OK

- C**
- Check continuity between control unit connector terminals and actuator connector (body side) terminals.

Code No. (LED flashes.)	Control unit	Actuator
11, 21	⑧	②
12, 22	⑩	①
13, 23	⑨	③
15, 25	⑭	㉔
16, 26	⑳	㉔
17, 27	㉓	㉔
42	⑦	⑥

**Continuity should exist.**


NG → Repair harness and connector.

OK


Ⓐ  
(Go to next page.)

# TROUBLE DIAGNOSES

## Diagnostic Procedure 3 (Cont'd)





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



## Diagnostic Procedure 4

### WHEEL SENSOR OR ROTOR

(Malfunction code No. 01 - 03, 05 - 07)







Ⓑ  
(Go to next page.)

**Note: Wheel position should be distinguished by code No. (LED flashes).**

# TROUBLE DIAGNOSES

## Diagnostic Procedure 4 (Cont'd)



**B**

- Disconnect wheel sensor connector.
- Check continuity between control unit connector terminals and wheel sensor connector (body side) terminals.

Code No. (LED flashes.)	Control unit	Wheel sensor
01, 05 (Front RH)	⑬	①
	⑭	②
02, 06 (Front LH)	⑰	①
	⑱	②
03, 07 (Rear)	⑮	②
	⑯	①

Continuity should exist.

OK Note

**CHECK WHEEL SENSOR.**

Refer to WHEEL SENSOR in Electrical Components Inspection (BR-64).

NG

Note

Repair harness and connectors between control unit connector and wheel sensor connector.

**C** Note

**WHEEL SENSOR MECHANICAL CHECK**

Check for any foreign materials and clearance between sensor and rotor.

**Clearance:**

**Front**

Make sure the sensor is installed of minimum clearance.

**Rear**

0.31 - 0.82 mm (0.0122 - 0.0323 in)

NG Note

Clean sensor fixing portion, reinstall or replace sensor.

OK

**D** Note

Check sensor rotor for teeth damage.

NG Note

Replace sensor rotor.

OK

- Carry out self-diagnosis again. Does the malfunction code No. (LED flashes) indicate wheel sensor?

Yes





Go to **D** in Diagnostic Procedure 2.

No

Go to applicable diagnostic procedure for malfunction code No. (LED flashes).

**Note: Wheel position should be distinguished by code No. (LED flashes).**

## Diagnostic Procedure 5 MOTOR RELAY OR MOTOR (Malfunction code No. 43, 44)



**MOTOR POWER SUPPLY CIRCUIT**

- Check 30A fusible link [d] and 10A fuse [26] for actuator. For fusible link and fuse layout, refer to POWER SUPPLY ROUTING in EL section.

NG → (B) (Skip page.)

OK

- Disconnect connectors from control unit and actuator. Check terminals for damage or loose connection. Then reconnect connectors.
- Carry out self-diagnosis again.

**Does warning light activate again?**

No → Inspection end

**A**

- Disconnect actuator connectors.
- Check voltage between connector (body side) terminals and ground.

Terminals	Ignition switch
⑤ - ground	ON position
⑩ - ground	---

**Battery voltage should exist.**

NG → Repair harness and connectors between battery and actuator connector (body side) terminals.

**B**

**MOTOR RELAY CIRCUIT**

- Remove motor relay.
- Disconnect actuator connectors.
- Check continuity between actuator connector (actuator side) terminals and relay connector terminals or body ground.

NG → Replace actuator assembly.

Actuator connector	Relay connector	Continuity
④	⑧7	Yes
⑩	③⑨	Yes
⑧	③⑤	Yes
⑤	③⑤	Yes
④	Ground	No

**C**

- Check continuity between actuator connector (body side) terminal ⑧ and ground.

**Continuity should not exist.**

OK → (A) (Go to next page.)

**D**

- Disconnect control unit connectors.
- Check continuity between control unit terminals (control unit side) ⑤ and ②, ③, ②②, ②7, ②⑧.

**Continuity should not exist.**




OK → Repair harness and connectors.

NG → Replace control unit.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX




# TROUBLE DIAGNOSES

## Diagnostic Procedure 5 (Cont'd)



# TROUBLE DIAGNOSES

## Diagnostic Procedure 5 (Cont'd)



**B**

● Replace fusible link or fuse.  
Is it blown out when it is replaced or ignition switch is turned "ON"?

No → Inspection end

Yes →

**G** MOTOR POWER SUPPLY CIRCUIT

● Disconnect connectors from actuator and control unit.  
● Check continuity between actuator connector (body side) terminals and ground.

Fuse/Fusible link	Terminals
Fusible link <b>d</b>	④ - ground ⑩ - ground
Fuse <b>26</b>	⑤ - ground

Continuity should not exist.

NG → Repair harness and connector.

OK →

**H**

● Remove motor ground.  
● Check continuity between actuator connector (actuator side) terminals and ground.

Fuse/Fusible link	Terminals
Fusible link <b>d</b>	④ - ground ⑩ - ground
Fuse <b>26</b>	⑤ - ground

Continuity should not exist.

NG → Replace actuator assembly.

OK →

**I**

● Check continuity between control unit terminals.

Fuse/Fusible link	Terminals
Fusible link <b>d</b>	⑪ - ②, ③, ⑫, ⑰, ⑱
Fuse <b>26</b>	① - ②, ③, ⑫, ⑰, ⑱

Continuity should not exist.

NG → Replace control unit.

OK →


Replace actuator assembly.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 6

### SOLENOID VALVE RELAY (Malfunction code No. 41, 42)




#### SOLENOID VALVE POWER SUPPLY CHECK

- Check 30A fusible link [c] and 10A fuse [26] for actuator. For fusible link and fuse layout, refer to POWER SUPPLY ROUTING in EL section.

NG → (B) (See next page.)

OK



- Disconnect connectors from control unit and actuator. Check terminals for damage or loose connection. Then reconnect connectors.
- Carry out self-diagnosis again.  
**Does warning light activate again?**

No → Inspection end

Yes

#### SOLENOID VALVE POWER SUPPLY CHECK

- Disconnect connectors from actuator.
- Check voltage between actuator 2-pin connector (body side) terminals and ground.

Terminals	Ignition switch
⑤ - ground	ON position
⑨ - ground	—

**Battery voltage should exist.**

NG → Repair harness and connector.

OK

#### SOLENOID VALVE RELAY CHECK

Refer to SOLENOID VALVE RELAY in Electrical Components Inspection (BR-64).

NG → Replace solenoid valve relay.

OK

#### SOLENOID VALVE RELAY CIRCUIT CHECK

Check continuity between relay terminals and actuator connector (actuator side) terminals.

Relay terminals	Connector terminals	Continuity
③⑩	⑥	Yes
③⑦	⑨	Yes
③⑦a	②①	Yes
③⑥	⑦	Yes
③⑤	⑤	Yes
Ground	⑦	No

NG → Replace actuator.






OK

(Go to next page.)



# TROUBLE DIAGNOSES


## Diagnostic Procedure 6 (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
DX

# TROUBLE DIAGNOSES

## Diagnostic Procedure 6 (Cont'd)



**G**


● Check continuity between actuator connector (actuator side) terminals and ground.

Fuse/Fusible link	Terminals
Fusible link <b>C</b>	⑥ - ground ⑨ - ground
Fuse <b>26</b>	⑤ - ground

**Continuity should not exist.**

NG → Replace actuator assembly.

OK →



**H**

● Check continuity between control unit terminals (control unit side).


Fuse/Fusible link	Terminals
Fusible link <b>C</b>	⑦ - ②, ③, ⑳, ㉑, ㉒
Fuse <b>26</b>	① - ②, ③, ⑳, ㉑, ㉒

**Continuity should not exist.**

NG → Replace control unit.

OK →

Replace actuator assembly.



### Diagnostic Procedure 7

#### POWER SUPPLY

(Malfunction code No. 47, 48)

● Disconnect control unit connectors.  
Check terminals for damage or connection. Then reconnect connectors.  
● Carry out self-diagnosis again.  
**Does warning light activate again?**

No → Inspection end

Yes

**CONTROL UNIT POWER SUPPLY**

● Disconnect control unit connectors.  
● Check voltage between connector terminal ① and ground when ignition switch is turned ON.  
**Battery voltage should exist.**

NG → Check harness and connectors between battery and control unit connector terminal ①, 10A fuse 26 or battery. For fuse layout, refer to POWER SUPPLY ROUTING in EL section.

OK

**CONTROL UNIT GROUND CIRCUIT**


Refer to CONTROL UNIT GROUND in Ground Circuit Check (BR-44).

NG → Repair harness and connectors.

OK

Replace control unit.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



## Diagnostic Procedure 8

### MEMORY VOLT STOP

- Disconnect control unit connectors. Check terminals for damage or loose connection. Then reconnect connectors.
  - Turn ignition switch ON and OFF more than two times.
  - Carry out self-diagnosis again.
- Does warning light activate again?**

No → Inspection end

Yes

- A**
- CONTROL UNIT POWER SUPPLY**
- Disconnect control unit connectors.
  - Check voltage between connector terminal 29 and ground.
- Battery voltage should exist.**

NG → Check harness and connectors between battery and control unit connector terminal 29 or 7.5A fuse 8. For fuse layout, refer to POWER SUPPLY ROUTING in EL section.

OK


- CONTROL UNIT GROUND CIRCUIT**
- Refer to CONTROL UNIT GROUND in Ground Circuit Check (BR-44).

NG → Repair harness and connectors.

OK


Replace control unit.

**Note: MEMORY VOLT STOP is always indicated after disconnecting control unit connector.**



**Diagnostic Procedure 9**



**SYMPTOM: Pedal vibration and noise**



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
PD  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



## Diagnostic Procedure 10

**SYMPTOM: Long stopping distance**




## Diagnostic Procedure 11

**SYMPTOM: Unexpected pedal action**




**Diagnostic Procedure 12**

**SYMPTOM: ABS does not work.**




**Diagnostic Procedure 13**

**SYMPTOM: ABS works frequently.**



# TROUBLE DIAGNOSES




## Electrical Components Inspection

### WHEEL SENSOR

Check resistance for each sensor.

**Resistance: 0.6 - 3.3 kΩ**



### ACTUATOR MOTOR RELAY AND SOLENOID VALVE RELAY

	Solenoid valve relay	Actuator motor relay solenoid valve relay
Condition	Continuity existence between terminals ⑤⑩ and ⑧⑦a	Continuity existence between terminals ⑤⑩ and ⑧⑦
Battery voltage not applied between termi- nals ⑤⑩ and ⑧⑥.	Yes	No
Battery voltage applied between terminals ⑤⑩ and ⑧⑥.	No	Yes



# SERVICE DATA AND SPECIFICATIONS (SDS)

## General Specifications

<b>Front brake</b>	
Brake model	CL22VF disc brake
Cylinder bore diameter mm (in)	54.0 (2.126)
Pad mm (in) Length x width x thickness	112.8 x 44.8 x 10.0 (4.44 x 1.764 x 0.394)
Rotor outer diameter x thickness mm (in)	252 x 20 (9.92 x 0.79)
<b>Rear brake</b>	
Brake model	CL11H disc brake
Cylinder bore diameter mm (in)	38.18 (1.5031)
Pad mm (in) Length x width x thickness	75.0 x 40.0 x 9.5 (2.953 x 1.575 x 0.374)
Rotor outer diameter x thickness mm (in)	258 x 9 (10.16 x 0.35)

Model	Without ABS		With ABS
	M/T	A/T	
Master cylinder			
Cylinder bore diameter mm (in)	22.22 (7/8)		23.81 (15/16)
Control valve	Proportioning valve (built into master cylinder)		
Valve model			
Split point kPa (kg/cm <sup>2</sup> , psi) x reducing ratio	1,961 (20, 284) x 0.4		
Brake booster			
Booster model	M23		M195T
Diaphragm diameter mm (in)	230 (9.06)		Primary: 205 (8.07) Secondary: 180 (7.09)
Recommended brake fluid	DOT 3		

## Inspection and Adjustment

### DISC BRAKE

Brake model	CL22VF	CL11H
Pad wear limit mm (in) Minimum thickness	2.0 (0.079)	
Rotor repair limit mm (in) Minimum thickness	18.0 (0.709)	8 (0.31)

### BRAKE PEDAL

Free height "H" mm (in) M/T	181 - 191 (7.13 - 7.52)
A/T	191 - 201 (7.52 - 7.91)
Depressed height "D" mm (in) [under force of 490 N (50 kg, 110 lb) with engine running]	110 (4.33)
Pedal free play "A" mm (in)	1 - 3 (0.04 - 0.12)
Clearance "C" between pedal stopper and threaded end of stop lamp switch or ASCD switch mm (in)	0.3 - 1.0 (0.012 - 0.039)

### PARKING BRAKE

Type	Center lever
Number of notches [under force of 196 N (20 kg, 44 lb)]	7 - 9
Number of notches when warning lamp switch comes on	1