

SECTION **EC**

CI
MA
EM
LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS

PRECAUTIONS AND PREPARATION4	Malfunction Indicator Lamp (MIL).....34
Special Service Tools4	OBD System Operation Chart.....38
Supplemental Restraint System (SRS) "AIR BAG".....4	CONSULT43
Precautions for On Board Diagnostic (OBD) System of Engine and A/T.....4	Generic Scan Tool (GST)56
Engine Fuel & Emission Control System.....5	TRUBLE DIAGNOSIS — Introduction58
Precautions.....6	Introduction58
ENGINE AND EMISSION CONTROL OVERALL SYSTEM8	Diagnostic Worksheet.....59
Circuit Diagram.....8	TRUBLE DIAGNOSIS — Work Flow60
System Diagram.....9	Work Flow.....60
ECCS Component Parts Location.....10	Description for Work Flow.....61
Vacuum Hose Drawing.....12	TRUBLE DIAGNOSIS — Basic Inspection62
System Chart.....13	Basic Inspection.....62
ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION14	TRUBLE DIAGNOSIS — General Description66
Multiport Fuel Injection (MFI) System.....14	Diagnostic Trouble Code (DTC) Chart.....66
Distributor Ignition (DI) System.....16	Fail-Safe Chart.....83
Air Conditioning Cut Control.....17	Symptom Matrix Chart (For New CT/CS).....84
Fuel Cut Control (at no load & high engine speed).....18	Symptom Matrix Chart (For Old CT/CS).....87
EVAPORATIVE EMISSION SYSTEM19	CONSULT Reference Value in Data Monitor Mode.....90
Description.....19	Major Sensor Reference Graph in Data Monitor Mode.....93
Inspection.....19	ECM Terminals and Reference Value.....95
Evaporative Emission Line Drawing.....21	TRUBLE DIAGNOSIS FOR POWER SUPPLY102
POSITIVE CRANKCASE VENTILATION23	Main Power Supply and Ground Circuit.....102
Description.....23	TRUBLE DIAGNOSIS FOR DTC P0100105
Inspection.....23	Mass Air Flow Sensor (MAFS) (DTC: 0102).....105
BASIC SERVICE PROCEDURE24	TRUBLE DIAGNOSIS FOR DTC P0105110
Fuel Pressure Release.....24	Absolute Pressure Sensor (DTC: 0803).....110
Fuel Pressure Check.....24	TRUBLE DIAGNOSIS FOR DTC P0110117
Injector Removal and Installation.....25	Intake Air Temperature Sensor (DTC: 0401).....117
Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment.....26	TRUBLE DIAGNOSIS FOR DTC P0115122
ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION32	Engine Coolant Temperature Sensor (ECTS) (DTC: 0103).....122
Introduction.....32	TRUBLE DIAGNOSIS FOR DTC P0120126
Two Trip Detection Logic.....32	Throttle Position Sensor (DTC: 0403).....126
Diagnostic Trouble Code (DTC).....32	TRUBLE DIAGNOSIS FOR DTC P0125131
Freeze Frame Data.....33	Engine Coolant Temperature (ECT) Sensor (DTC: 0908).....131
	TRUBLE DIAGNOSIS FOR DTC P0130136
	Front Heated Oxygen Sensor (Front HO2S) (DTC: 0303).....136

CONTENTS (Cont'd)

TROUBLE DIAGNOSIS FOR DTC P0130	141	TROUBLE DIAGNOSIS FOR DTC P0600	229
Closed Loop Control (DTC: 0307).....	141	A/T Control.....	229
TROUBLE DIAGNOSIS FOR DTC P0135	142	TROUBLE DIAGNOSIS FOR DTC P0605	232
Front Heated Oxygen Sensor Heater (DTC:		Engine Control Module (ECM)-ECCS Control	
0901).....	142	Module (DTC: 0301).....	232
TROUBLE DIAGNOSIS FOR DTC P0136	145	TROUBLE DIAGNOSIS FOR DTC P0705	234
Rear Heated Oxygen Sensor (Rear HO2S)		Park/Neutral Position Switch (DTC: 1003).....	234
(DTC: 0707).....	145	TROUBLE DIAGNOSIS FOR DTC P1105	239
TROUBLE DIAGNOSIS FOR DTC P0171	150	Manifold Absolute Pressure (MAP)/Barometric	
Fuel Injection System Function (Lean side)		Pressure (BARO) Switch Solenoid Valve (DTC:	
(DTC: 0115).....	150	1302).....	239
TROUBLE DIAGNOSIS FOR DTC P0172	155	TROUBLE DIAGNOSIS FOR DTC P1320	245
Fuel Injection System Function (Rich side) (DTC:		Ignition Signal (DTC: 0201).....	245
0114).....	155	TROUBLE DIAGNOSIS FOR DTC P1336	250
TROUBLE DIAGNOSIS FOR DTC P0180	159	Crankshaft Position Sensor (CKPS) (OBD) (DTC:	
Tank Fuel Temperature Sensor (DTC: 0402).....	159	0905).....	250
TROUBLE DIAGNOSIS FOR DTC P0300 - P0304	162	TROUBLE DIAGNOSIS FOR DTC P1400	254
No. 4 - 1 Cylinder Misfire, Multiple Cylinder		EGRC-Solenoid Valve (DTC: 1005).....	254
Misfire (DTC: 0701 - 0605).....	162	TROUBLE DIAGNOSIS FOR DTC P1401	258
TROUBLE DIAGNOSIS FOR DTC P0325	166	EGR Temperature Sensor (DTC: 0305).....	258
Knock Sensor (KS) (DTC: 0304).....	166	TROUBLE DIAGNOSIS FOR DTC P1441	263
TROUBLE DIAGNOSIS FOR DTC P0335	169	Vacuum Cut Valve Bypass Valve (DTC: 0801).....	263
Crankshaft Position Sensor (CKPS) (OBD) (DTC:		TROUBLE DIAGNOSIS FOR DTC P1445	268
0802).....	169	Evaporative Emission (EVAP) Canister Purge	
TROUBLE DIAGNOSIS FOR DTC P0340	173	Volume Control Valve (DTC: 1008).....	268
Camshaft Position Sensor (CMP) (DTC: 0101).....	173	TROUBLE DIAGNOSIS FOR DTC P1447	274
TROUBLE DIAGNOSIS FOR DTC P0400	177	Evaporative Emission (EVAP) Control System	
EGR Function (DTC: 0302).....	177	Purge Flow Monitoring (DTC: 0111).....	274
TROUBLE DIAGNOSIS FOR DTC P0402	185	TROUBLE DIAGNOSIS FOR DTC P1605	281
EGRC-BPT Valve Function (DTC: 0306).....	185	A/T Diagnosis Communication line (DTC: 0804).....	281
TROUBLE DIAGNOSIS FOR DTC P0420	187	TROUBLE DIAGNOSIS FOR DTC P1900	284
Three Way Catalyst Function (DTC: 0702).....	187	Cooling Fan (DTC: 1308).....	284
TROUBLE DIAGNOSIS FOR DTC P0440	190	TROUBLE DIAGNOSIS FOR NON-DETECTABLE	
Evaporative Emission (EVAP) Control System		ITEMS	296
(Small Leak) (DTC: 0705).....	190	Injector.....	296
TROUBLE DIAGNOSIS FOR DTC P0443	199	Start Signal.....	299
Evaporative Emission (EVAP) Canister Purge		Fuel Pump.....	301
Control Valve/Solenoid Valve (DTC: 0807).....	199	Power Steering Oil Pressure Switch.....	306
TROUBLE DIAGNOSIS FOR DTC P0446	207	IACV-Air Regulator.....	309
Evaporative Emission (EVAP) Canister Vent		IACV-FICD Solenoid Valve.....	312
Control Valve (DTC: 0903).....	207	5th Position Switch.....	316
TROUBLE DIAGNOSIS FOR DTC P0450	212	Rear Window Defogger Signal.....	318
Evaporative Emission (EVAP) Control System		Electrical Load Signal.....	320
Pressure Sensor (DTC: 0704).....	212	MIL & Data Link Connectors.....	322
TROUBLE DIAGNOSIS FOR DTC P0500	216	TROUBLE DIAGNOSIS — Index	323
Vehicle Speed Sensor (VSS) (DTC: 0104).....	216	Alphabetical & P No. Index for DTC.....	323
TROUBLE DIAGNOSIS FOR DTC P0505	220	SERVICE DATA AND SPECIFICATIONS (SDS)	325
Idle Air Control Valve (IACV) — Auxiliary Air		General Specifications.....	325
Control (AAC) Valve (DTC: 0205).....	220	Inspection and Adjustment.....	325
TROUBLE DIAGNOSIS FOR DTC P0510	225		
Closed Throttle Position Switch (DTC: 0203).....	225		

CONTENTS (Cont'd)

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

PRECAUTIONS AND PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J36471-A) Front heated oxygen sensor wrench	 Loosening or tightening front heated oxygen sensor NT379
(J36470) Rear heated oxygen sensor wrench	 Loosening or tightening rear heated oxygen sensor NT379

Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Precautions for On Board Diagnostic (OBD) System of Engine and A/T

The ECM (ECCS control module) has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM or A/T control unit before returning the vehicle to the customer.

PRECAUTIONS AND PREPARATION

Engine Fuel & Emission Control System

ECM

- Do not disassemble ECM (ECCS control module).
- Do not turn diagnosis mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to


self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WIRELESS EQUIPMENT

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far as possible away from the ECM.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.

BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.



ECCS PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.






ECM HARNESS HANDLING

- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

SEF181P

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PRECAUTIONS AND PREPARATION




Precautions

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Before replacing ECM, perform ECM Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-95.
- After performing each TROUBLE DIAGNOSIS, perform "OVERALL FUNCTION CHECK" or "DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE". The DTC should not be displayed in the "DTC CONFIRMATION PROCEDURE" if the repair is completed. The "OVERALL FUNCTION CHECK" should be a good result if the repair is completed.

PRECAUTIONS AND PREPARATION

Precautions (Cont'd)

- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram




System Diagram



*1: Throttle position sensor with throttle position switch



- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- PS
- BT
- HA
- EL
- IDX

ECCS Component Parts Location




ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location (Cont'd)




- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL
- IDX

Vacuum Hose Drawing



ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart



*1: These sensors are not directly used to control the engine system. They are used only for the on board diagnosis.


*2: The DTC related to A/T will be sent to ECM.

*3: This sensor is not used to control the engine system under normal conditions.

*4: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

Multiport Fuel Injection (MFI) System

INPUT/OUTPUT SIGNAL LINE



BASIC MULTI-PORT FUEL INJECTION SYSTEM

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below.


(Fuel increase)

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D" (A/T models only)
- High-load, high-speed operation

(Fuel decrease)

- During deceleration
- During high speed operation

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION



Multiport Fuel Injection (MFI) System (Cont'd)

MIXTURE RATIO FEEDBACK CONTROL

The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The warm-up three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about front heated oxygen sensor, refer to page EC-136. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Rear heated oxygen sensor is located downstream of the warm-up three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

OPEN LOOP CONTROL

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Engine idling
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High-engine coolant temperature
- During warm-up
- After shifting from "N" to "D"
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both Manufacturing differences (i.e. mass air flow sensor hot wire) and characteristic changes during operation (i.e. injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short-term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short-term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION


Multiport Fuel Injection (MFI) System (Cont'd)

FUEL INJECTION TIMING

Two types of systems are used.

Sequential multiport fuel injection system

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.




Simultaneous multiport fuel injection system

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.




FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Distributor Ignition (DI) System

INPUT/OUTPUT SIGNAL LINE



ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Distributor Ignition (DI) System (Cont'd)

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine.

The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM detects information such as the injection pulse width and camshaft position sensor signal. Responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec


A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- Hot engine operation
- During acceleration


The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions.

If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM (ECCS control module). The ECM retards the ignition timing to eliminate the knocking condition.



Air Conditioning Cut Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION


This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.

Fuel Cut Control (at no load & high engine speed)

INPUT/OUTPUT SIGNAL LINE



If the engine speed is above 3,000 rpm with no load (for example, in neutral and engine speed over 3,000 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.


Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different than deceleration control listed under multiport fuel injection on EC-14.

EVAPORATIVE EMISSION SYSTEM

Description



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.


The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating.

EVAP canister purge volume control valve is controlled by engine control module. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control valve is proportionally regulated as the air flow increases.

EVAP canister purge control valve shuts off the vapor purge line during decelerating and idling, and under normal operating conditions the valve is usually open.

EVAP shut valve shuts off the vapor charge line when fuel is being supplied to the fuel tank.



Inspection

EVAP CANISTER

Check EVAP canister as follows:


1. Pinch the fresh air vent hose.
2. Blow air in port (A) and check that it flows freely out of port (B).

EVAPORATIVE EMISSION SYSTEM

Inspection (Cont'd)

TIGHTENING TORQUE

Tighten EVAP canister as shown in the figure.




FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.


CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.



EVAPORATIVE EMISSION (EVAP) SHUT VALVE

- When pushing down the shutter inside the fuel filler opening, the EVAP shut valve is closed.
 - When releasing the shutter, the valve is open.
1. Insert steel tube as shown in the figure.
 2. Blow air from one side of the EVAP shut valve tube (a) or (b) and check that there is no air flow.



EVAP CANISTER PURGE CONTROL VALVE

Refer to EC-199.

VACUUM CUT VALVE

Refer to EC-267.

EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

Refer to EC-268.

EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL SOLENOID VALVE


Refer to EC-199.

TANK FUEL TEMPERATURE SENSOR

Refer to EC-159.

EVAPORATIVE EMISSION SYSTEM


Evaporative Emission Line Drawing



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

EVAPORATIVE EMISSION SYSTEM

Evaporative Emission Line Drawing (Cont'd)



POSITIVE CRANKCASE VENTILATION

Description

This system returns blow-by gas to the intake collector.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.



The ventilating air is then drawn from the air duct

into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the intake collector under all conditions.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Inspection



PCV (Positive Crankcase Ventilation)

With engine running at idle, remove PCV valve from breather separator. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.



PCV HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



Fuel Pressure Release

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.
(Touch "START", and after engine stalls, crank it two or three times to release all fuel pressure.)
3. Turn ignition switch off.

1. Remove fuse for fuel pump.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch off and reconnect fuel pump fuse.

Fuel Pressure Check

- a. When reconnecting fuel line, always use new clamps.
- b. Make sure that clamp screw does not contact adjacent parts.
- c. Use a torque driver to tighten clamps.
- d. Use Pressure Gauge to check fuel pressure.

1. Release fuel pressure to zero.
2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
3. Install pressure gauge between fuel filter and fuel tube.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.



At idling:

Approximately 235 kPa (2.4 kg/cm², 34 psi)

A few seconds after ignition switch is turned OFF to ON:

Approximately 294 kPa (3.0 kg/cm², 43 psi)

6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
7. Plug intake manifold with a rubber cap.
8. Connect variable vacuum source to fuel pressure regulator.





BASIC SERVICE PROCEDURE

Fuel Pressure Check (Cont'd)

9. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.



Injector Removal and Installation

1. Release fuel pressure to zero.
2. Remove injector tube assembly with injectors from intake manifold.
3. Remove injectors from injector tube assembly.
 - Push injector tail piece.
 - Do not pull on the connector.
4. Install injectors as follows:
 - 1) Clean exterior of injector tail piece.
 - 2) Use new O-rings.

CAUTION:

After properly connecting injectors to fuel tube assembly, check connections for fuel leakage.

5. Assemble injectors to injector tube assembly.
6. Install injector tube assembly to intake manifold.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment

PREPARATION


- Make sure that the following parts are in good order.

- (1) Battery
- (2) Ignition system
- (3) Engine oil and coolant levels
- (4) Fuses
- (5) ECM harness connector
- (6) Vacuum hoses
- (7) Air intake system
(Oil filler cap, oil level gauge, etc.)
- (8) Fuel pressure
- (9) Engine compression
- (10) EGR valve operation
- (11) Throttle valve

- (12) Evaporative emission (EVAP) canister purge control valve






- On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
- When checking idle speed, ignition timing and mixture ratio of A/T models, shift lever to "N" position.
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower, rear defogger.
- Keep front wheels pointed straight ahead.
- Make the check after the cooling fan has stopped.

Overall inspection sequence



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



START

- Visually check the following:
- Air cleaner clogging
 - Hoses and ducts for leaks
 - EGR valve operation
 - Electrical connectors
 - Gasket
 - Throttle valve and throttle position sensor operations

A Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge and ensure that engine speed is below 1,000 rpm.

B Open engine hood and run engine at about 2,000 rpm for about 2 minutes under no-load.

C Perform the diagnostic test mode II (Self-diagnostic results).

OK

NG

Repair or replace components as necessary.

D Run engine at about 2,000 rpm for about 2 minutes under no-load. Race engine two or three times under no-load, then run engine for about 1 minute at idle speed.

- E**
1. Select "IGNITION TIMING ADJ" in WORK SUPPORT mode.
 2. Touch "START".
1. Stop engine and disconnect throttle position sensor harness connector.
 2. Start engine.

Race engine (2,000 - 3,000 rpm) 2 or 3 times under no-load and run engine at idle speed.

F Check ignition timing with a timing light.
20°±2° BTDC (A/T in "N" position)

OK

NG







A

B

CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX





BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



Ⓒ

K

Check idle speed.

Read idle speed in "DATA MONITOR" mode with CONSULT.
OR
 Check idle speed.

700±50 rpm (A/T in "N" position)

OK

NG

Check IACV-AAC valve and replace if necessary.

Check IACV-AAC valve harness and repair if necessary.

Check ECM function* by substituting another known good ECM.

* ECM may be the cause of a problem, but this is rarely the case.

L

Set the diagnostic test mode II (front heated oxygen sensor monitor).

Run engine at about 2,000 rpm for about 2 minutes under no-load.

M N

Check front heated oxygen sensor signal.

- See "FR O2 MNTR" in "DATA MONITOR" mode.
- Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
1 cycle: RICH → LEAN → RICH
2 cycles: RICH → LEAN → RICH → LEAN → RICH

OR

Make sure that malfunction indicator lamp goes on and off more than 5 times during 10 seconds at 2,000 rpm.

OK



D

INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



- Check front heated oxygen sensor harness:
1. Turn off engine and disconnect battery ground cable.
 2. Disconnect ECM harness connector from ECM
 3. Disconnect front heated oxygen sensor harness connector and connect terminal for front heated oxygen sensor to ground with a jumper wire.
 4. Check for continuity between terminal (46) of ECM harness connector and ground metal on vehicle body.

Continuity exists ... OK
Continuity does not exist ... NG

OK →
NG → Repair harness. →

Connect ECM harness connector to ECM.

1. Select "ENG COOLANT TEMP" in "ACTIVE TEST" mode.
2. Set "COOLANT TEMP" at 20°C (68°F).

- Disconnect engine coolant temperature sensor harness connector.
- Connect a resistor (2.5 kΩ) between terminals of engine coolant temperature sensor harness connector.


Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. (Be careful to start engine after setting "COOLANT TEMP" or installing a 2.5 kΩ resistor.)

Race engine two or three times under no-load then run engine at idle speed.

E

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)



*: ECM may be the cause of a problem, but this is rarely the case.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Introduction

The ECM (ECCS control module) has an on board diagnostic system, which detects engine system malfunctions related to sensors or actuators. The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two Trip Detection Logic).

Two Trip Detection Logic

When a malfunction is detected for the first time, the malfunction (DTC and freeze frame data) is stored in the ECM memory. (1st trip) The malfunction indicator lamp will not light up at this stage.

If the same malfunction is detected during the next drive, this second detection causes the malfunction indicator lamp to light up. (2nd trip) Specific on board diagnostic items will light up or blink the MIL even in the 1st trip as below.

Items	MIL		
	1st trip		2nd trip lighting up
	Blinking	Lighting up	
Misfire (Possible three way catalyst damage)— DTC: P0300-P0304 (0701-0605) is being detected	X		
Misfire (Possible three way catalyst damage)— DTC: P0300-P0304 (0701-0605) has been detected		X	
Three way catalyst function — DTC: P0420 (0702)		X	
Closed loop control — DTC: P0130 (0307)		X	
Except above			X

The “trip” in the “Two Trip Detection Logic” means performing of the “DTC Confirmation Procedure”.

Diagnostic Trouble Code (DTC)

HOW TO READ DTC

The diagnostic trouble code can be read by the following methods.

(Either code for the 1st trip or the 2nd trip can be read.)

1. The number of blinks of the malfunction indicator lamp in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0101, 0201, 1003, 1104, etc.

These DTCs are controlled by NISSAN.

2. CONSULT or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT also displays the malfunctioning component or system.)


- **Output of the trouble code means that the indicated circuit has a malfunction. However, in case of the Mode II and GST they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**


CONSULT can identify them. Therefore, using CONSULT (if available) is recommended.

HOW TO ERASE DTC

The diagnostic trouble code can be erased by the following methods.

-  Selecting “ERASE” in the “SELF DIAG RESULTS” mode with CONSULT.

-  Selecting Mode 4 with GST (Generic Scan Tool).

-  Changing the diagnostic test mode from Diagnostic Test Mode II to Mode I by turning the mode selector on the ECM. (Refer to EC-36.)

- **If the battery terminal is disconnected, the diagnostic trouble code will be lost within 24 hours.**

- **When you erase the DTC, using CONSULT or GST is easier and quicker than switching the mode selector on the ECM.**

HOW TO ERASE DTC

- **If a DTC is displayed for both ECM and A/T control unit, it needs to be erased for both ECM and A/T control unit.**

- **If diagnostic trouble code is not for A/T related items (refer to EC-80), skip steps 2 through 4.**


1. If the ignition switch stays “ON” after repair work, be sure to turn ignition switch “OFF” once. Wait for at least 5 seconds and then turn it “ON” (engine stopped) again.
2. Turn CONSULT “ON” and touch “A/T”.
3. Touch “SELF-DIAG RESULTS”.
4. Touch “ERASE”. (The DTC in the A/T control unit will be erased.) Touch “BACK” twice.
5. Touch “ENGINE”.
6. Touch “SELF-DIAG RESULTS”.
7. Touch “ERASE”. (The DTC in the ECM will be erased.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Diagnostic Trouble Code (DTC) (Cont'd)

How to erase DTC (With CONSULT)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.



SEF338QA



HOW TO ERASE DTC

- If the diagnostic trouble code is not for A/T related items (refer to EC-80), skip step 2.
1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" (engine stopped) again.
 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
 3. Select Mode 4 with GST (Generic Scan Tool).



HOW TO ERASE DTC

- If the diagnostic trouble code is not for A/T related items (refer to EC-80), skip step 2.
1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait for at least 5 seconds and then turn it "ON" again.
 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
 3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. (See page EC-36.)

Freeze Frame Data

The ECM has a memory function which stores the driving condition at the moment the ECM detects a malfunction. This includes fuel system status, calculated load value, engine coolant temperature, short fuel trim, long fuel trim, engine speed, vehicle speed.

Stored data is called Freeze Frame Data.

The data is useful for tracking down conditions at the time of the malfunction. Such conditions include whether

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Freeze Frame Data (Cont'd)

vehicle was running or stopped, engine warm up, air-fuel ratio, etc.


This data can be utilized to duplicate the malfunction and to diagnose the trouble.

The data will be erased along with the diagnostic trouble code by the above-mentioned method.

The data can be stored only for the 1st trip. It can not be renewed even at the 2nd trip. The freeze frame data can be stored for only one item. Therefore, the ECM has the following priorities to update the data.

Priority	Detected items
1	Misfires — DTC: P0300-P0304 (0701-0605) Fuel Injection System Function — DTC: P0172 (0114), P0171 (0115)
2	Except the above items (includes A/T items)

For example, an EGR malfunction (Priority: 2) was detected and the freeze frame data was stored at the 1st trip. After that, misfire (Priority: 1) is detected in another trip, and freeze frame data is updated from the EGR malfunction for the misfire.



Malfunction Indicator Lamp (MIL)

1. The malfunction indicator lamp will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the malfunction indicator lamp does not light up, refer to WARNING LAMPS AND CHIME in EL section (or see EC-322).
2. When the engine is started, the malfunction indicator lamp should go off.
If the lamp remains on, the on board diagnostic system has detected an engine system malfunction.

ON BOARD DIAGNOSTIC SYSTEM FUNCTION




The on board diagnostic system has the following four functions.

1. BULB CHECK : This function checks the MIL bulb for damage (blown, open circuit, etc.).
2. MALFUNCTION WARNING : This is a usual driving condition. When a malfunction is detected twice (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected.
Only the following malfunctions will light up or blink the MIL even in the 1st trip.
 - "Misfire (Possible three way catalyst damage)"
 - "Three way catalyst function"
 - "Closed loop control"
3. SELF-DIAGNOSTIC RESULTS : This function allows diagnostic trouble codes to be read.
4. FRONT HEATED OXYGEN SENSOR MONITOR : This function allows the fuel mixture condition (lean or rich), monitored by front heated oxygen sensor, to be read.

How to switch the diagnostic test (function) modes and details of the above functions are described later. (Refer to EC-36.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

Condition		Diagnostic Test Mode I	Diagnostic Test Mode II	
Ignition switch in "ON" position 	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS	GI
	Engine running 	MALFUNCTION WARNING	FRONT HEATED OXYGEN SENSOR MONITOR	MA EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd) HOW TO SWITCH DIAGNOSTIC TEST MODES



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MALFUNCTION INDICATOR LAMP on the instrument panel should stay ON. If it remains OFF, check the bulb. (Refer to WARNING LAMPS AND CHIME in EL section or see EC-322.)



DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MALFUNCTION INDICATOR LAMP	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning (The "1 trip" or "2 trip" is shown in the "MIL Illumination" of the "DTC Chart". Refer to EC-66).
OFF	No malfunction

- These Diagnostic Trouble Code Numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

DIAGNOSTIC TEST MODE II—SELF-DIAGNOSTIC RESULTS

In this mode, a diagnostic trouble code is indicated by the number of blinks of the MALFUNCTION INDICATOR LAMP as shown below.



Long (0.6 second) blinking indicates the two LH digits of number and short (0.3 second) blinking indicates the two RH digits of number. For example, the malfunction indicator lamp blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003" and refers to the malfunction of the park/neutral position switch.

In this way, all the detected malfunctions are classified by their diagnostic trouble code numbers. The DTC "0505" refers to no malfunction. (See Diagnostic Trouble Code (DTC) Chart, EC-66.)

HOW TO ERASE DIAGNOSTIC TEST MODE II (Self-diagnostic results)

The diagnostic trouble code can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES".)

- If the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

DIAGNOSTIC TEST MODE II — FRONT HEATED OXYGEN SENSOR MONITOR

In this mode, the MALFUNCTION INDICATOR LAMP displays the condition of the fuel mixture (lean or rich) which is monitored by the front heated oxygen sensor.

MALFUNCTION INDICATOR LAMP	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the front heated oxygen sensor function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MALFUNCTION INDICATOR LAMP comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBID System Operation Chart

RELATIONSHIP BETWEEN MIL, DTC, CONSULT AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the DTC and the freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the MIL will come on. For details, refer to "Two Trip Detection Logic" on EC-32.
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset. The MIL will remain on until the vehicle is driven (in the recorded driving pattern) 3 times with no malfunction.
- The DTC and the freeze frame data can be displayed until the vehicle is driven 40 times (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data can be displayed until the vehicle is driven 80 times. The "TIME" IN "SELF-DIAGNOSTIC RESULTS" mode of CONSULT will count in response to the number of times the vehicle is driven.

SUMMARY CHART


Items	MIL (goes off)	DTC, Freeze Frame Data (no display)
Fuel Injection System	3 (pattern C)	80 (pattern B)
Misfire	3 (pattern C)	80 (pattern B)
Except the aboves	3 (pattern B)	40 (pattern A)

Details about patterns "A", "B", and "C" are on EC-40.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBd System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, CONSULT AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern C) without any malfunctions.
- *3: When a malfunction is detected for the first time, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern B) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: Other screen except DATA MONITOR (AUTO TRIG) can not display the malfunction.


- *6: DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.
- *7: The malfunction can not be displayed because the timing to set DATA MONITOR (AUTO TRIG) screen was missed against the NG detection.
- *8: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern B) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving pattern A>



<Driving pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will reset when the malfunction is detected twice regardless of the driving pattern.
- The B counter will count the number of times driving pattern B is satisfied without the malfunction.
- The DTC will not be displayed after the B counter reaches 80.

<Driving pattern C>

Driving pattern C means the vehicle operation as follows:

(1) Driving pattern A should be satisfied.

(2) The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), "T" should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), "T" should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:


Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1), (2). (*1 in "OBD SYSTEM OPERATION CHART")
- The C counter will be counted up when (1), (2) are satisfied without the same malfunction.
- The MIL will go off when the C counter reaches 3. (*2 in "OBD SYSTEM OPERATION CHART")

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, CONSULT AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When a malfunction is detected for the first time, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame data will not be displayed after vehicle is driven 40 times (pattern A) without the same malfunction.
(The DTC and the freeze frame data still remain in ECM.)
- *5: Other screen except DATA MONITOR (AUTO TRIG) can not display the malfunction.

- *6: DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.
- *7: The malfunction can not be displayed because the timing to set DATA MONITOR (AUTO TRIG) screen was missed against the NG detection.
- *8: The DTC and the freeze frame data will not be displayed after vehicle is driven 40 times (pattern A) without the same malfunction.
(The DTC and the freeze frame data still remain in ECM.)

AEC527


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBd System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving pattern A>



AEC574

- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.


<Driving pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected twice regardless of the driving pattern (*1 in "OBD SYSTEM OPERATION CHART").
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION




CONSULT

CONSULT INSPECTION PROCEDURE


1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT.
(Data link connector for CONSULT is located behind the fuse box cover.)



3. Turn on ignition switch.
4. Touch "START".




5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT Operation Manual.



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

ECCS COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		Item	DIAGNOSTIC TEST MODE					
			WORK SUP-PORT	SELF-DIAG-NOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNC-TION TEST	FREEZE FRAME DATA*
ECCS COMPONENT PARTS	INPUT	Camshaft position sensor		X	X			X
		Mass air flow sensor		X	X			
		Engine coolant temperature sensor		X	X	X		X
		Front heated oxygen sensor		X	X		X	
		Rear heated oxygen sensor		X	X			
		Vehicle speed sensor		X	X		X	X
		Throttle position sensor	X	X	X		X	
		Tank fuel temperature sensor		X	X	X		
		EVAP control system pressure sensor		X	X			
		Absolute pressure sensor		X	X			
		EGR temperature sensor		X	X			
		Intake air temperature sensor		X	X			
		Crankshaft position sensor (OBD)		X				
		Knock sensor		X				
		Ignition switch (start signal)			X		X	
		Closed throttle position switch		X				
		Closed throttle position switch (throttle position sensor signal)			X		X	
		Air conditioner switch			X			
	Park/Neutral position switch		X	X		X		
	Power steering oil pressure switch			X		X		
	Air conditioner pressure switch			X				
	Battery voltage			X				
	OUTPUT	Injectors			X	X	X	
		Power transistor (Ignition timing)	X	X (Ignition signal)	X	X	X	
		IACV-AAC valve	X	X	X	X	X	
		EVAP canister purge volume control valve		X	X	X		
		Air conditioner relay			X			
		Fuel pump relay	X		X	X	X	
Cooling fan				X	X	X		
EGRC-solenoid valve			X	X	X	X		
Front heated oxygen sensor heater			X	X				
EVAP canister purge control solenoid valve			X	X	X			
EVAP canister vent control valve			X	X				
Vacuum cut valve bypass valve			X	X				
MAP/BARO switch solenoid valve		X	X	X				
Calculated load value			X			X		

X: Applicable

*: The items appear on CONSULT screen in FREEZE FRAME DATA mode only if a diagnostic trouble code (DTC) is detected. For details, refer to EC-54.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".
Freeze frame data	ECM stores the driving condition at the moment a malfunction is detected, and the stored data can be read. [Regarding the details, refer to "Freeze Frame Data" (EC-33).]
ECM part numbers	ECM part numbers can be read.

GI

MA

EM

LC

EC

FE

CL

MT

WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> • IGN SW "ON" • ENG NOT RUNNING • ACC PEDAL NOT PRESSED 	When adjusting throttle position sensor initial position
IGNITION TIMING ADJ	<ul style="list-style-type: none"> • IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANKSHAFT POSITION SENSOR. 	When adjusting initial ignition timing
IACV-AAC VALVE ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> • ENGINE WARMED UP • NO-LOAD 	When adjusting idle speed
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> • FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

SELF-DIAGNOSTIC MODE

Regarding items detected in "SELF-DIAG RESULTS" mode, refer to "Diagnostic Trouble Code (DTC) chart" (See page EC-66.)

DATA MONITOR MODE

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
CMPS-RPM (REF) [rpm]	○	○	<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. 	<ul style="list-style-type: none"> The accuracy of detection becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS AIR/FL SE [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
COOLAN TEMP/S [°C] or [°F]	○	○	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
FR O2 SENSOR [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the front heated oxygen sensor is displayed. 	
RR O2 SENSOR [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the rear heated oxygen sensor is displayed. 	
FR O2 MNTR [RICH/LEAN]	○	○	<ul style="list-style-type: none"> Display of front oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
RR O2 MNTR [RICH/LEAN]	○		<ul style="list-style-type: none"> Display of rear heated oxygen sensor signal: RICH ... means the amount of oxygen downstream three way catalyst is relatively large. LEAN ... means the amount of oxygen downstream three way catalyst is relatively small. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
VHCL SPEED SE [km/h] or [mph]	○	○	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 	

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks	
BATTERY VOLT [V]	○	○	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 		GI
THRTL POS SEN [V]	○	○	<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 		MA
TANK F/TMP SE [°C] or [°F]	○		<ul style="list-style-type: none"> The fuel temperature judged from the tank fuel temperature sensor signal voltage is displayed. 		EM
EGR TEMP SEN [V]	○		<ul style="list-style-type: none"> The signal voltage of the EGR temperature sensor is displayed. 		LC
INT/A TEMP SE [°C] or [°F]	○		<ul style="list-style-type: none"> The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated. 		EC
START SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal. 	FE
CLSD THL/P SW [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the closed throttle position switch signal. 		CL
AIR COND SIG [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 		MT
P/N POSI SW [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position switch signal. 		AT
PW/ST SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated. 		PD
LOAD SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the electrical load signal and/or lighting switch. ON ... rear defogger is operating and/or lighting switch is on. OFF ... rear defogger is not operating and lighting switch is not on. 		FA RA
AMB TEMP SW	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the ambient air temperature switch signal. 		BR
IGNITION SW [ON/OFF]	○		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 		ST
A/C PRESS SW [ON/OFF]	○		<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioning triple-pressure switch (medium-pressure side) determined by the pressure of the air conditioning high pressure side. 		RS BT
INJ PULSE [msec]		○	<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated. 	HA
B/FUEL SCHDL [msec]		○	<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 		EL
IGN TIMING [BTDC]		○	<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 		IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
IACV-AAC/V [%]		○	<ul style="list-style-type: none"> Indicates the idle air control valve (AAC valve) control value computed by ECM according to the input signals. 	
PURG VOL C/V [step]			<ul style="list-style-type: none"> Indicates the EVAP canister purge volume control valve computed by the engine control module according to the input signals. The opening becomes larger as the value increases. 	
A/F ALPHA [%]		○	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
EVAP SYS PRES [V]			<ul style="list-style-type: none"> The signal voltage of EVAP control system pressure sensor is displayed. 	
AIR COND RLY [ON/OFF]			<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 	
FUEL PUMP RLY [ON/OFF]			<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
COOLING FAN [HI/LOW/OFF]			<ul style="list-style-type: none"> The control condition of the cooling fan (determined by ECM according to the input signal) is indicated. HI ... High speed operation LOW ... Low speed operation OFF ... Stop 	
EGRC SOL/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EGRC-sole-noid valve (determined by ECM according to the input signal) is indicated. ON ... EGR operation is cut-off OFF ... EGR is operational 	
VENT CONT/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is indicated. ON ... Closed OFF ... Open 	
FR O2 HEATER			<ul style="list-style-type: none"> Indicates [ON/OFF] condition of front heated oxygen sensor heater determined by ECM according to the input signals. 	
VC/V BYPASS/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON ... Open OFF ... Closed 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks	
PURG CONT S/V [ON/OFF]			<ul style="list-style-type: none"> The control condition of the EVAP canister purge control solenoid valve (computed by the engine control module according to the input signals) is indicated. ON ... Canister purge is operational OFF ... Canister purge operation is cut-off 	GI MA EM	
CAL/LD VALUE [%]			<ul style="list-style-type: none"> "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	LC	
ABSOL TH-P/S [%]			<ul style="list-style-type: none"> "Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. 	EC	
MASS AIRFLOW [gm/s]			<ul style="list-style-type: none"> Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor. 	FE CL	
MAP/BARO SW/V [MAP/BARO]			<ul style="list-style-type: none"> The control condition of the MAP/BARO switch solenoid valve (determined by ECM according to the input signal) is indicated. MAP ... Intake manifold absolute pressure BARO ... Barometric pressure 	MT AT	
ABSOL PRES/SE [V]			<ul style="list-style-type: none"> The signal voltage of the absolute pressure sensor is displayed. 	PD	
VOLTAGE [V]			<ul style="list-style-type: none"> Voltage measured by the voltage probe. 	FA	
PULSE [msec] or [Hz] or [%]			<ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> Only "#" is displayed if item is unable to be measured. Figures with "#"s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. 	RA BR

ST

RS

BT

HA

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Front heated oxygen sensor
IACV-AAC/V OPENING	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connector IACV-AAC valve
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor Fuel injectors
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Adjust initial ignition timing
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Air conditioner switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils
COOLING FAN	<ul style="list-style-type: none"> Ignition switch: ON Turn the cooling fan "ON" and "OFF" using CONSULT. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> Harness and connector Cooling fan motor
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connector Fuel pump relay
EGRC SOLENOID VALVE	<ul style="list-style-type: none"> Ignition switch: ON Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector Solenoid valve
SELF-LEARNING CONT	<ul style="list-style-type: none"> In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		
PURG VOL CONT/V	<ul style="list-style-type: none"> Engine: After warming up, run engine at 1,500 rpm. Change the EVAP canister purge volume control valve opening step using CONSULT. 	Engine speed changes according to the opening step.	<ul style="list-style-type: none"> Harness and connector EVAP canister purge volume control valve
PURG CONT S/V	<ul style="list-style-type: none"> Start engine. Turn the EVAP canister purge control solenoid valve "ON" and "OFF" using CONSULT and listen for operating sound. 	EVAP canister purge control solenoid valve makes an operating sound. Check vacuum signal for EVAP canister purge control valve. VC ON ... Vacuum exists. VC OFF ... Vacuum does not exist.	<ul style="list-style-type: none"> Harness and connector EVAP canister purge control solenoid valve Vacuum hose
MAP/BARO SW/V	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the MAP/BARO switch solenoid valve between "MAP" and "BARO" using CONSULT and listen for operating sound. 	MAP/BARO switch solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector MAP/BARO switch solenoid valve
TANK F/TEMP SEN	<ul style="list-style-type: none"> Change the tank fuel temperature using CONSULT. 		

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST MODE

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
SELF-DIAG RESULTS	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Displays the results of on board diagnostic system. 	—		Objective system	GI
CLOSED THROTTLE POSI (CLOSED THROTTLE POSITION SWITCH CIRCUIT)	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Closed throttle position switch circuit is tested when throttle is opened and closed fully. ("IDLE POSITION" is the test item name for the vehicles in which idle is selected by throttle position sensor.) 	Throttle valve: opened	OFF	<ul style="list-style-type: none"> Harness and connector Throttle position sensor (Closed throttle position switch) Throttle position sensor (Closed throttle position switch) adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	MA
		Throttle valve: closed	ON		EC
THROTTLE POSI SEN CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	<ul style="list-style-type: none"> Harness and connector Throttle position sensor Throttle position sensor adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	FE CL MT
PARK/NEUT POSI SW CKT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Inhibitor/Neutral position switch circuit is tested when shift lever is manipulated. 	OUT OF N/P-RANGE	OFF	<ul style="list-style-type: none"> Harness and connector Neutral position switch/ Inhibitor switch Linkage + Inhibitor switch adjustment 	AT
		IN N/P-RANGE	ON		PD
FUEL PUMP CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose.		<ul style="list-style-type: none"> Harness and connector Fuel pump Fuel pump relay Fuel filter clogging Fuel level 	FA RA
EGRC SOL/V CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) EGRC-solenoid valve circuit is tested by checking solenoid valve operating noise. 	The solenoid valve makes an operating sound every 3 seconds.		<ul style="list-style-type: none"> Harness and connector EGRC-solenoid valve 	BR ST
COOLING FAN CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Cooling fan circuit is tested when cooling fan is rotated. 	<ul style="list-style-type: none"> The cooling fan rotates and stops every 3 seconds. 		<ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay 	RS

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)
START SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON → START Start signal circuit is tested when engine is started by operating the starter. Battery voltage and water temperature before cranking, and average battery voltage, mass air flow sensor output voltage and cranking speed during cranking are displayed. 	Start signal: OFF → ON		<ul style="list-style-type: none"> Harness and connector Ignition switch
PW/ST SIGNAL CIRCUIT	<ul style="list-style-type: none"> Ignition switch: ON (Engine running) Power steering circuit is tested when steering wheel is rotated fully and then set to a straight line running position. 	Locked position	ON	<ul style="list-style-type: none"> Harness and connector Power steering oil pressure switch Power steering oil pump
		Neutral position	OFF	
VEHICLE SPEED SEN CKT	<ul style="list-style-type: none"> Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor input signal is greater than 4 km/h (2 MPH)		<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor Electric speedometer
IGN TIMING ADJ	<ul style="list-style-type: none"> After warming up, idle the engine. Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value on the screen.		<ul style="list-style-type: none"> Adjust ignition timing (by moving crankshaft position sensor or distributor) Camshaft position sensor drive mechanism
MIXTURE RATIO TEST	<ul style="list-style-type: none"> Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining the front heated oxygen sensor output at 2,000 rpm under non-loaded state. 	<ul style="list-style-type: none"> Front heated oxygen sensor COUNT: More than 5 times during 10 seconds 		<ul style="list-style-type: none"> INJECTION SYS (Injector, fuel pressure regulator, harness or connector) IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) VACUUM SYS (Intake air leaks) Front heated oxygen sensor circuit Front heated oxygen sensor operation Fuel pressure high or low Mass air flow sensor

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)	
POWER BALANCE	<ul style="list-style-type: none"> • After warming up, idle the engine. • Injector operation of each cylinder is stopped one after another, and resultant change in engine rotation is examined to evaluate combustion of each cylinder. (This is only displayed for models where a sequential multiport fuel injection system is used.) 	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.	<ul style="list-style-type: none"> • Injector circuit (Injector, harness or connector) • Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) • Compression • Valve timing 	GI MA EM LC
IACV-AAC/V SYSTEM	<ul style="list-style-type: none"> • After warming up, idle the engine. • IACV-AAC valve system is tested by detecting change in engine speed when IACV-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% and at 20%.	<ul style="list-style-type: none"> • Harness and connector • IACV-AAC valve • Air passage restriction between air inlet and IACV-AAC valve • IAS (Idle adjusting screw) adjustment 	<div style="background-color: black; color: white; padding: 2px; text-align: center; font-weight: bold;">EC</div> FE CL
★EVAP (SMALL LEAK)	<ul style="list-style-type: none"> • After warming up, idle the engine etc. • EVAP system is tested by using the evaporative gas pressure in the fuel tank or engine intake manifold pressure. 	<ul style="list-style-type: none"> • EVAP control system has no leak. • EVAP control system operates properly. 	<ul style="list-style-type: none"> • Incorrect fuel tank vacuum relief valve • Incorrect fuel filler cap used • Fuel filler cap remains open or fails to close. • Foreign matter caught in fuel filler cap. • Leak is in line between intake manifold and EVAP canister purge control valve. • Foreign matter caught in EVAP canister vent control valve. • EVAP canister or fuel tank leaks • EVAP purge line tube leaks • EVAP purge line rubber tube bent. • Blocked or bent rubber tube to EVAP control system pressure sensor • EVAP canister purge control valve • EVAP canister purge volume control valve • EVAP canister purge control solenoid valve • Absolute pressure sensor • Tank fuel temperature sensor • MAP/BARO switch solenoid valve • Blocked or bent rubber tube to MAP/BARO switch solenoid valve 	MT AT PD FA RA BR ST RS BT HA EL IDX

★: Always select "SINGLE TEST" with CONSULT when performing the "FUNCTION TEST".

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)

FREEZE FRAME DATA

Freeze frame data item	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> ECCS component part/control system has a trouble code, it is displayed as "PXXXX". [Refer to "Alphabetical & P No. Index for DTC (EC-323).]
FUEL SYS DATA	<ul style="list-style-type: none"> "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. <ul style="list-style-type: none"> "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM [%]	<ul style="list-style-type: none"> "Short term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM [%]	<ul style="list-style-type: none"> "Long term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short term fuel trim.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> The vehicle speed at the moment a malfunction is detected is displayed.
MAP*1 [kPa]	<ul style="list-style-type: none"> The intake manifold absolute pressure at the moment a malfunction is detected is displayed.

*1: This item is not displayed on CONSULT. Only for Generic Scan Tool (GST).

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT (Cont'd)


REAL TIME DIAGNOSIS IN DATA MONITOR MODE

CONSULT has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.


1. "AUTO TRIG" (Automatic trigger):
 - The malfunction will be identified on the CONSULT screen in real time. In other words, DTC and malfunction item will be displayed at the moment the malfunction is detected by ECM.
 - DATA MONITOR can be performed continuously until a malfunction is detected. However, DATA MONITOR cannot continue any longer after the malfunction detection.
2. "MANU TRIG" (Manual trigger):
 - DTC and malfunction item will not be displayed automatically on CONSULT screen even though a malfunction is detected by ECM.
 - DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

1. "AUTO TRIG"
 - While trying to detect the DTC by performing the "DTC CONFIRMATION PROCEDURE", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
 - While narrowing down the possible causes, CONSULT should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC CONFIRMATION PROCEDURE", the moment a malfunction is found the DTC will be displayed. (Refer to GI section, "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".)
2. "MANU TRIG"
 - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.




ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION



Generic Scan Tool (GST)


DESCRIPTION

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has five different functions explained on the next page. ISO9141 is used as the protocol. The name "GST" or "Generic Scan Tool" is used in this service manual.




GST INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)



3. Turn ON ignition switch.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.




For further information, see the GST Operation Manual of the tool maker.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Generic Scan Tool (GST) (Cont'd)

FUNCTION

Diagnostic test mode		Function	
MODE 1	(CURRENT DATA)	This mode accesses to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.	GI
MODE 2	(FREEZE DATA)	This mode accesses to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze Frame Data" (EC-54).]	MA
MODE 3	(TROUBLE CODES)	This mode accesses to emission-related power train trouble codes which were stored by ECM.	EM
MODE 4	(CLEAR CODES)	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> • Clear number of diagnostic trouble codes (MODE 1) • Clear diagnostic trouble codes (MODE 3) • Clear trouble code for freeze frame data (MODE 1) • Clear freeze frame data (MODE 2) • Clear heated oxygen sensor test data (MODE 5) • Reset status of system monitoring test (MODE 1) 	LC
MODE 5	(O2 TEST RESULTS)	This mode accesses to the on board heated oxygen sensor monitoring test results.	EC
			FE
			CL
			MT
			AT
			PD
			FA
			RA
			BR
			ST
			RS
			BT
			HA
			EL
			IDX



Introduction

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the problems. A road test with CONSULT (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on the next page.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on EC-59 should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

TROUBLE DIAGNOSIS — Work Flow

Work Flow



*1: If the incident cannot be duplicated, see "Incident Simulation Tests" of "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section.

*2: If the on board diagnostic system cannot be performed, check main power supply and ground circuit (See TROUBLE DIAGNOSIS FOR POWER SUPPLY EC-102).

TROUBLE DIAGNOSIS — Work Flow

Description for Work Flow


STEP	DESCRIPTION	
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET" as shown on the next page.	GI
STEP II	Before confirming the concern, check and write down (print out using CONSULT or Generic Scan Tool) the Diagnostic Trouble Code (DTC) and the freeze frame data, then erase the code and the data. (Refer to EC-32.) The DTC and the freeze frame data can be used when duplicating the incident at STEP III & IV. Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See page EC-84.)	MA EM
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.) If the malfunction code is detected, skip STEP IV and perform STEP V.	EM LC
STEP IV	Try to detect the Diagnostic Trouble Code (DTC) by driving in (or performing) the "DTC CONFIRMATION PROCEDURE". Check and read the DTC and freeze frame data by using CONSULT or Generic Scan Tool. During the DTC verification, be sure to connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.) In case the "DTC CONFIRMATION PROCEDURE" is not available, perform the "OVERALL FUNCTION CHECK" instead. The DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "OVERALL FUNCTION CHECK" is the same as the DTC detection.	EC FE CL
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION on next page. Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-84.)	MT AT
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT. Refer to EC-90. The "DIAGNOSTIC PROCEDURE" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the DIAGNOSTIC PROCEDURE. For details, refer to GI section ("HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", "Circuit Inspection"). Repair or replace the malfunction parts.	PD FA RA
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC CONFIRMATION PROCEDURE" and confirm the normal code (Diagnostic trouble code No. 0505 or P0000) is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM and A/T control unit. (Refer to EC-32.)	BR ST RS

BT

HA

EL

IDX




Basic Inspection

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.



A

BEFORE STARTING

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Vacuum hoses for splits, kinks, or improper connections
 - Wiring for improper connections, pinches, or cuts

C

IGN TIMING ADJ

IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.

START


SEF555N

B

CONNECT CONSULT TO THE VEHICLE. Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. (Refer to page EC-43.)

DOES ENGINE START?

No → Go to **E**



C

CHECK IGNITION TIMING.


1. Warm up engine sufficiently.
2. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.
3. Touch "START".
4. Check ignition timing at idle using timing light.

Ignition timing:
 $20^{\circ} \pm 2^{\circ}$ BTDC

NG → Adjust ignition timing by turning camshaft position sensor.

1. Warm up engine sufficiently.
2. Stop engine and disconnect throttle position sensor harness connector.
3. Start engine.
4. Check ignition timing at idle using timing light.

Ignition timing:
 $20^{\circ} \pm 2^{\circ}$ BTDC



OK

↓

(Go to **A** on next page.)

TROUBLE DIAGNOSIS — Basic Inspection

Basic Inspection (Cont'd)

D IGN TIMING ADJ

IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START. AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.

START

SEF546N

D **CHECK IDLE ADJ. SCREW INITIAL SET RPM.**

- Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.
- When touching "START", does engine speed fall to 650 ± 50 rpm (A/T in "N" position)?

OR

Does engine run at 650 ± 50 rpm (A/T in "N" position)?

NG → Adjust engine speed by turning idle adjusting screw.

OK →

D

Throttle position sensor harness connector

SEF470R

E **CHECK CLOSED THROTTLE POSITION SWITCH IDLE POSITION (A/T model only).**

- Disconnect throttle position sensor harness connector and closed throttle position switch harness connector.
- Check continuity between closed throttle position switch terminals ⑤ and ⑥ under the following conditions.
 - Raise engine speed to 2,000 rpm.
 - Gradually lower engine speed.

Continuity should exist (Closed throttle position switch closes) at 900 ± 150 rpm with transmission in N position.

NG → Adjust continuity signal by rotating throttle position sensor body. Then, go to ③.

OK →

E

DISCONNECT

Throttle position switch connector

SEF436Q

Reconnect throttle position sensor harness connector and closed throttle position switch harness connector.

OK →

F THRTL POS SEN ADJ

*** ADJ MONITOR ***

THRTL POS SEN	0.52V
===== MONITOR =====	
CMPS•RPM (REF)	0rpm
CLSD THL/P SW	ON

SEF441R

F **CHECK THROTTLE POSITION SENSOR IDLE POSITION. (M/T model only)**

- Perform "THRTL POS SEN. ADJ." in "WORK SUPPORT" mode.
- Check that output voltage of throttle position sensor is approx. 0.3 to 0.7V (Throttle valve fully closes.) and "CLSD THL/P SW" stays "ON".

OR

Measure output voltage of throttle position sensor using voltmeter, and check that it is approx. 0.3 to 0.7V. (Throttle valve fully closed.)

NG → Adjust output voltage to 0.5V by rotating throttle position sensor body. Then, go to ③.

OK →

F

CONNECT

H.S.

Radiator shroud

SEF654R

RESETTING IDLE POSITION MEMORY

- Warm up engine sufficiently.
- Turn ignition switch "OFF" and wait for at least 5 seconds.
- Disconnect throttle position harness connector.
- Start engine and wait for at least 3 seconds in "N" position.
- Reconnect throttle position harness connector while running engine.


OK →

NG →

③

TROUBLE DIAGNOSIS — Basic Inspection

Basic Inspection (Cont'd)



TROUBLE DIAGNOSIS — Basic Inspection

NOTE

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
(P0000)	0505	No failure (NO SELF DIAGNOSTIC FAILURE INDICATED...)	<ul style="list-style-type: none"> • No malfunction related to OBD system is detected by either ECM or A/T control unit.
P0100	0102	Mass air flow sensor circuit (MASS AIR FLOW SEN)	<ul style="list-style-type: none"> • An excessively high or low voltage is entered to ECM. • Voltage sent to ECM is not practical when compared with the camshaft position sensor signal and throttle position sensor signals.
P0105	0803	Absolute pressure sensor (ABSOL PRESS SEN-SOR)	<ul style="list-style-type: none"> • An excessively low or high voltage from the sensor is sent to ECM. <p>.....</p> <ul style="list-style-type: none"> • A low voltage from the sensor is sent to ECM under heavy load driving conditions. <p>.....</p> <ul style="list-style-type: none"> • A high voltage from the sensor is sent to ECM under light load driving conditions.
P0110	0401	Intake air temperature sensor circuit (INT AIR TEMP SEN)	<ul style="list-style-type: none"> • An excessively low or high voltage from the sensor is detected by the ECM. • Voltage sent to ECM is not practical when compared with the engine coolant temperature sensor signal.
P0115	0103	Engine coolant temperature sensor circuit (COOLANT TEMP SEN)	<ul style="list-style-type: none"> • An excessively high or low voltage from the sensor is detected by the ECM.
P0120	0403	Throttle position sensor circuit (THROTTLE POSI SEN)	<ul style="list-style-type: none"> • An excessively low or high voltage from the sensor is detected by the ECM. • Voltage sent to ECM is not practical when compared with the mass air flow sensor and camshaft position sensor signals.
P0125	0908	Engine coolant temperature sensor function (*COOLANT TEMP SEN)	<ul style="list-style-type: none"> • Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine. • Engine coolant temperature is insufficient for closed loop fuel control.

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC *1 CONFIRMATION PROCEDURE" Quick Ref.	"OVERALL FUNCTION CHECK" *2 Quick Ref.	Fail Safe System	MIL Illumination	Reference Page	
• No failure	—	—	—	—	—	GI MA EM
• Harness or connectors (The sensor circuit is open or shorted.) • Mass air flow sensor	RUNNING	RUNNING	X	2 trip	EC-105	LC
• Harness or connectors (Absolute pressure sensor circuit is open or shorted.) • Absolute pressure sensor	IGN: ON	—				EC
• Absolute pressure sensor	—	IGN: ON	—	2 trip	EC-110	FE CL
• Hoses (Hoses between the intake manifold and absolute pressure sensor have come off or are clogged.) • Intake air leaks • Absolute pressure sensor	RUNNING	—				MT AT
• Harness or connectors (The sensor circuit is open or shorted.) • Intake air temperature sensor	IGN: ON	—	—	2 trip	EC-117	PD
• Harness or connectors (The sensor circuit is open or shorted.) • Engine coolant temperature sensor	IGN: ON	—	X	2 trip	EC-122	FA
• Harness or connectors (The sensor circuit is open or shorted.) • Throttle position sensor	LIFTING	IGN: ON	X	2 trip	EC-126	RA
• Harness or connectors (High resistance in the sensor circuit) • Engine coolant temperature sensor • Thermostat	—	RUNNING	—	2 trip	EC-131	BR ST

*1: • This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

• During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

• This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0130	0303	Front heated oxygen sensor circuit (FRONT O2 SENSOR)	<ul style="list-style-type: none"> • An excessively high voltage from the sensor is detected by the ECM. • The voltage from the sensor is constantly approx. 0.3V. • The specified maximum and minimum voltages from the sensor are not reached. • It takes more than the specified time for the sensor to respond between rich and lean.
P0130	0307	Closed loop control (CLOSED LOOP)	<ul style="list-style-type: none"> • The closed loop control function does not operate even when vehicle is driving in the specified condition.
P0135	0901	Front heated oxygen sensor heater circuit (FR O2 SEN HEATER)	<ul style="list-style-type: none"> • The current amperage in the heater circuit is out of the normal range. (The improper voltage drop signal is entered to ECM through the heater.)
P0136	0707	Rear heated oxygen sensor circuit (REAR O2 SENSOR)	<ul style="list-style-type: none"> • An excessively high voltage from the sensor is detected by the ECM. • The specified maximum and minimum voltages from the sensor are not reached. • It takes more than the specified time for the sensor to respond between rich and lean.
P0171	0115	Fuel injection system function (FUEL SYS DIAG-LEAN)	<ul style="list-style-type: none"> • Fuel injection system does not operate properly. • The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.)
P0172	0114	Fuel injection system function (FUEL SYS DIAG-RICH)	<ul style="list-style-type: none"> • Fuel injection system does not operate properly. • The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.)
P0180	0402	Tank fuel temperature sensor circuit (TANK FUEL TEMP SEN)	<ul style="list-style-type: none"> • An excessively low or high voltage from the sensor is sent to ECM. • Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor and intake air temperature sensor.

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC *1 CONFIRMA- TION PRO- CEDURE" Quick Ref.	*2 "OVERALL FUNCTION CHECK" Quick Ref.	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Front heated oxygen sensor • Injectors • Intake air leaks • Fuel pressure 	—	RUNNING	—	2 trip	EC-136	GI MA EM LC
<ul style="list-style-type: none"> • The front heated oxygen sensor circuit is open or shorted. • Front heated oxygen sensor 	—	RUNNING	—	1 trip	EC-141	EC
<ul style="list-style-type: none"> • Harness or connectors (The heater circuit is open or shorted.) • Front heated oxygen sensor heater 	RUNNING	—	—	2 trip	EC-142	FE
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Rear heated oxygen sensor • Fuel pressure • Injectors • Intake air leaks 	—	RUNNING (DRIVING)	—	2 trip	EC-145	CL MT
<ul style="list-style-type: none"> • Intake air leak • Front heated oxygen sensor • Injectors • Incorrect fuel pressure • Mass air flow sensor • Lack of fuel 	RUNNING	—	—	2 trip	EC-150	AT PD
<ul style="list-style-type: none"> • Front heated oxygen sensor • Injectors • Exhaust gas leak • Incorrect fuel pressure • Mass air flow sensor 	RUNNING	—	—	2 trip	EC-155	FA RA
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Tank fuel temperature sensor 	IGN: ON	—	—	2 trip	EC-159	BR ST

*1: • This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

• During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

• This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...	
CONSULT GST	MIL			
P0300	0701	Multiple cylinders' misfire (MULTI CYL MISFIRE)	(Three way catalyst damage) The misfire occurs, which will damage three way catalyst by overheating.	(Exhaust quality deterioration) The misfire occurs, which will not damage three way catalyst but will affect emission deterioration.
P0301	0608	No. 1 cylinder's misfire (CYL 1 MISFIRE)		
P0302	0607	No. 2 cylinder's misfire (CYL 2 MISFIRE)		
P0303	0606	No. 3 cylinder's misfire (CYL 3 MISFIRE)		
P0304	0605	No. 4 cylinder's misfire (CYL 4 MISFIRE)		
P0325 (*4)	0304	Knock sensor circuit (KNOCK SENSOR)	<ul style="list-style-type: none"> An excessively low or high voltage from the sensor is detected by the ECM. 	
P0335	0802	Crankshaft position sensor (OBD) circuit [CRANK POS SEN (OBD)]	<ul style="list-style-type: none"> The proper pulse signal from the sensor is not detected by the ECM while the engine is running at the specified rpm. 	
P0340	0101	Camshaft position sensor circuit (CAMSHAFT POSI SEN)	<ul style="list-style-type: none"> Either 1° or 180° signal is not detected by the ECM for the first few seconds during engine cranking. Either 1° or 180° signal is not detected by the ECM often enough while the engine speed is higher than the specified rpm. The relation between 1° and 180° signals is not in the normal range during the specified rpm. 	

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

*4: Freeze frame data is not stored in the ECM for the "Knock sensor". The MIL will not light up for a "Knock sensor" malfunction.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

—: Not applicable

Check Items (Possible Cause)	“DTC *1 CONFIRMA- TION PRO- CEDURE” Quick Ref.	*2 “OVERALL FUNCTION CHECK” Quick Ref.	Fail Safe System	MIL Illumination	Reference Page
<ul style="list-style-type: none"> • Improper spark plug • The ignition secondary circuit is open or shorted. • Insufficient compression • Incorrect fuel pressure • EGR valve • The injector circuit is open or shorted. • Injectors • Intake air leak • Lack of fuel • Magnetized flywheel (drive plate) 	DRIVING	—	—	(Three way catalyst dam- age) 1 trip (Exhaust quality dete- rioration) 2 trip	EC-162
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Knock sensor 	RUNNING	—	—	—	EC-166
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open.) • Crankshaft position sensor (OBD) 	RUNNING	—	—	2 trip	EC-169
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Camshaft position sensor • Starter motor • Starting system circuit (EL section) • Dead (Weak) battery 	RUNNING	—	—	2 trip	EC-173

*1: • This is Quick Reference of “DTC CONFIRMATION PROCEDURE”.
Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The “OVERALL FUNCTION CHECK” is a simplified and effective way to inspect a component or circuit.
In some cases, the “OVERALL FUNCTION CHECK” is used rather than a “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE”.
When no DTC CONFIRMATION PROCEDURE is available, the “NG” result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

- During an “NG” OVERALL FUNCTION CHECK, the DTC might not be confirmed.
- This is Quick Reference of “OVERALL FUNCTION CHECK”.
Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected Items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0400	0302	EGR function (EGR SYSTEM)	<ul style="list-style-type: none"> The EGR flow is excessively low or high during the specified driving condition.
P0402	0306	EGRC-BPT valve function (EGRC-BPT VALVE)	<ul style="list-style-type: none"> EGRC-BPT valve does not operate properly.
P0420	0702	Warm-up three way catalyst function (TW CATALYST SYSTEM)	<ul style="list-style-type: none"> Warm-up three way catalyst does not operate properly. Warm-up three way catalyst does not have enough oxygen storage capacity.
P0440	0705	EVAP control system (small leak) [EVAP (SMALL LEAK)]	<ul style="list-style-type: none"> EVAP control system has a leak. EVAP control system does not operate properly.

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

—: Not applicable

Check Items(Possible Cause)	*1 "DTC CONFIRMATION PROCEDURE" Quick Ref.	*2 "OVERALL FUNCTION CHECK" Quick Ref.	Fail Safe System	MIL Illumination	Reference Page
<ul style="list-style-type: none"> • EGR valve stuck closed, open or leaking • Passage blocked • EGRC-solenoid valve • Tube leaking for EGR valve vacuum • EGRC-BPT valve leaking 	—	RUNNING	—	2 trip	EC-177
<ul style="list-style-type: none"> • EGRC-BPT valve • Rubber tube (blocked or misconnected) 	—	RUNNING	—	2 trip	EC-185
<ul style="list-style-type: none"> • Warm-up three way catalyst • Exhaust tube • Intake air leak • Injectors • Injector leak 	—	RUNNING	—	1 trip	EC-187
<ul style="list-style-type: none"> • Incorrect fuel tank vacuum relief valve • Incorrect fuel filler cap used • Fuel filler cap remains open or fails to close. • Foreign matter caught in fuel filler cap. • Leak is in line between intake manifold and EVAP canister purge control valve. • Foreign matter caught in EVAP canister vent control valve. • EVAP canister or fuel tank leaks • EVAP purge line (Pipe or rubber tube) leaks • EVAP purge line rubber tube bent. • Blocked or bent rubber tube to EVAP control system pressure sensor • Loose or disconnected rubber tube • EVAP canister purge control valve • EVAP canister purge volume control valve • EVAP canister purge control solenoid valve • Absolute pressure sensor • Tank fuel temperature sensor • MAP/BARO switch solenoid valve • Blocked or bent rubber tube to MAP/BARO switch solenoid valve 	RUNNING	IGN: OFF	—	2 trip	EC-190

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

*1: • This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

• During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

• This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0443	0807	EVAP canister purge control valve/solenoid valve circuit (PURG CONT/V & S/V)	<ul style="list-style-type: none"> • An improper voltage signal is sent to ECM through the solenoid valve. • EVAP canister purge control valve does not operate properly (stuck open).
P0446	0903	EVAP canister vent control valve circuit (VENT CONTROL VALVE)	<ul style="list-style-type: none"> • An improper voltage signal is sent to ECM through EVAP canister vent control valve circuit. • EVAP canister vent control valve circuit does not operate properly.
P0450	0704	EVAP control system pressure sensor (EVAP SYS PRES SEN)	<ul style="list-style-type: none"> • An improper voltage signal from EVAP control system pressure sensor is sent to ECM.
P0500	0104	Vehicle speed sensor circuit (VEHICLE SPEED SEN)	<ul style="list-style-type: none"> • The almost 0 km/h (0 MPH) signal from the sensor is detected by the ECM even when vehicle is driving.
P0505	0205	Idle speed control function (IACV-AAC VALVE)	<ul style="list-style-type: none"> • The idle speed control function does not operate properly.
P0510	0203	Closed throttle position switch (CLOSED THRL POS SW)	<ul style="list-style-type: none"> • Battery voltage from the throttle position switch is sent to ECM with the throttle valve opened.
P0600	—	Signal circuit from A/T control unit to ECM (A/T COMM LINE)	<ul style="list-style-type: none"> • ECM receives incorrect voltage from A/T control unit continuously. *5 This can be detected only by "DATA MONITOR (AUTO TRIG)".
P0605	0301	ECM (ECM)	<ul style="list-style-type: none"> • ECM calculation function is malfunctioning.

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

*5: For details, refer to each DTC Confirmation Procedure in AT section.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items(Possible Cause)	“DTC CONFIRMATION PROCEDURE” Quick Ref. *1	“OVERALL FUNCTION CHECK” Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> • Harness or connectors (The solenoid valve circuit is open or shorted.) • EVAP canister purge control solenoid valve 	IGN: ON	—	—	2 trip	EC-199	GI MA EM LC
<ul style="list-style-type: none"> • EVAP canister purge control valve • EVAP canister purge control solenoid valve • Vacuum hoses for clogging or disconnection • EVAP control system pressure sensor 	LIFTING	—	—	2 trip	EC-207	EC
<ul style="list-style-type: none"> • Harness or connectors (EVAP canister vent control valve circuit is open or shorted.) 	RUNNING	—	—	2 trip	EC-207	FE
<ul style="list-style-type: none"> • EVAP canister vent control valve • EVAP control system pressure sensor • Blocked rubber tube to EVAP canister vent control valve 	—	IGN: OFF	—	2 trip	EC-212	GL MT
<ul style="list-style-type: none"> • Harness or connectors (The EVAP control system pressure sensor circuit is open or shorted.) • EVAP control system pressure sensor • EVAP canister vent control valve (The valve is stuck open.) 	IGN: ON	—	—	2 trip	EC-216	AT
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Vehicle speed sensor 	DRIVING	LIFTING	—	2 trip	EC-220	PD FA
<ul style="list-style-type: none"> • Harness or connectors (The valve circuit is open.) • IACV-AAC valve 	RUNNING	—	—	2 trip	EC-225	RA
<ul style="list-style-type: none"> • Harness or connectors (The valve circuit is shorted.) • IACV-AAC valve 	RUNNING	—	—	2 trip	EC-229	BR
<ul style="list-style-type: none"> • Harness or connectors (The closed throttle position switch circuit is shorted.) • Closed throttle position switch 	—	RUNNING	—	2 trip	EC-232	ST
<ul style="list-style-type: none"> • Harness or connectors (The circuit between ECM and A/T control unit is open or shorted.) 	RUNNING	RUNNING	—	—	EC-232	RS BT HA EL IDX
<ul style="list-style-type: none"> • ECM (ECCS control module) 	RUNNING	—	X	2 trip	EC-232	

*1: • This is Quick Reference of “DTC CONFIRMATION PROCEDURE”

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The “OVERALL FUNCTION CHECK” is a simplified and effective way to inspect a component or circuit.

In some cases, the “OVERALL FUNCTION CHECK” is used rather than a “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE”.

When no DTC CONFIRMATION PROCEDURE is available, the “NG” result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

• During an “NG” OVERALL FUNCTION CHECK, the DTC might not be confirmed.

• This is Quick Reference of “OVERALL FUNCTION CHECK”.

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0705	1003	Park/Neutral position switch circuit (PARK/NEUT POSI SW)	<ul style="list-style-type: none"> The signal of the park/neutral position switch is not changed in the process of engine starting and driving.
P1105	1302	MAP/BARO switch solenoid valve (MAP/BARO SW SOL/V)	<ul style="list-style-type: none"> MAP/BARO switch solenoid valve remains at the voltage supplied, even though ECM is no longer supplying the voltage to the valve. There is little difference between absolute pressure sensor input voltage at ambient barometric pressure and that at intake manifold pressure.
P1320	0201	Ignition signal circuit (IGN SIGNAL-PRIMARY)	<ul style="list-style-type: none"> The ignition signal in the primary circuit is not detected by the ECM during engine cranking or running.
P1336	0905	Crankshaft position sensor (OBD) [CRANK P/S (OBD)-COG]	<ul style="list-style-type: none"> The chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM.
P1400	1005	EGRC-solenoid valve circuit (EGRC SOLENOID/V)	<ul style="list-style-type: none"> An improper voltage signal is sent to the ECM through the solenoid valve.
P1401	0305	EGR temperature sensor circuit (EGR TEMP SENSOR)	<ul style="list-style-type: none"> An excessively low or high voltage from the sensor is detected by the ECM, even when engine coolant temperature is low or high.
P1441	0801	Vacuum cut valve bypass valve (VCV BYPASS/V)	<ul style="list-style-type: none"> An improper voltage signal is sent to ECM through the bypass valve. <p>.....</p> <ul style="list-style-type: none"> Vacuum cut valve bypass valve does not operate properly.

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	“DTC CONFIRMATION PROCEDURE” Quick Ref. *1	“OVERALL FUNCTION CHECK” Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> • Harness or connectors (The switch circuit is open or shorted.) • Neutral position switch • Inhibitor switch 	—	IGN: ON	—	2 trip	EC-234	GI MA EM
<ul style="list-style-type: none"> • Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) • Hoses (Hoses are clogged or disconnected.) • Absolute pressure sensor • MAP/BARO switch solenoid valve 	RUNNING	—	—	2 trip	EC-239	LC EC
<ul style="list-style-type: none"> • Harness or connectors (The ignition primary circuit is open or shorted.) • Power transistor unit • Camshaft position sensor • Camshaft position sensor circuit 	RUNNING	—	—	2 trip	EC-245	FE CL
<ul style="list-style-type: none"> • Harness or connectors • Crankshaft position sensor (OBD) • Flywheel (Drive plate) 	RUNNING	—	—	2 trip	EC-250	MT
<ul style="list-style-type: none"> • Harness or connectors (The valve circuit is open or shorted.) • EGRC-solenoid valve 	—	IGN: ON (RUNNING)	—	2 trip	EC-254	AT
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • EGR temperature sensor 	RUNNING	—	—	2 trip	EC-258	PD FA
<ul style="list-style-type: none"> • Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted.) • Vacuum cut valve bypass valve 	RUNNING	—	—	2 trip	EC-263	RA
<ul style="list-style-type: none"> • Vacuum cut valve bypass valve • Vacuum cut valve • Bypass hoses for clogging • EVAP control system pressure sensor 	—	IGN: OFF	—	2 trip	EC-263	BR ST

*1: • This is Quick Reference of “DTC CONFIRMATION PROCEDURE”.

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The “OVERALL FUNCTION CHECK” is a simplified and effective way to inspect a component or circuit.

In some cases, the “OVERALL FUNCTION CHECK” is used rather than a “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE”.

When no DTC CONFIRMATION PROCEDURE is available, the “NG” result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

• During an “NG” OVERALL FUNCTION CHECK, the DTC might not be confirmed.

• This is Quick Reference of “OVERALL FUNCTION CHECK”.

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

ENGINE RELATED ITEMS

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P1445	1008	EVAP canister purge volume control valve (PURG VOLUME CONT/V)	<ul style="list-style-type: none"> • An improper voltage signal is sent to ECM through the valve. <hr style="border-top: 1px dotted black;"/> <ul style="list-style-type: none"> • The canister purge flow is detected during the specified driving condition, even when EVAP canister purge volume control valve is completely shut off.
P1447	0111	EVAP control system purge flow monitoring (EVAP PURG FLOW/MON)	<ul style="list-style-type: none"> • EVAP control system does not operate properly. • EVAP control system has a leak in line between intake manifold and EVAP control system pressure sensor.
P1605	0804	A/T diagnosis communication line (A/T DIAG COMM LINE)	<ul style="list-style-type: none"> • An incorrect signal from A/T control unit is detected by the ECM.
P1900	1308	Cooling fan circuit (COOLING FAN)	<ul style="list-style-type: none"> • Cooling fan does not operate properly. (Overheat) • Cooling system does not operate properly. (Overheat) • Engine coolant was not added to the system using the proper filling method.

Note: A dead (weak) battery will reduce the accuracy of the on board diagnosis and may cause the MIL to light up without any malfunctions.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.

RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.

DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).

RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).

LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).

DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	"DTC *1 CONFIRMATION PRO- CEDURE" Quick Ref.	"OVERALL *2 FUNCTION CHECK" Quick Ref.	Fail Safe System	MIL Illumination	Reference Page	
<ul style="list-style-type: none"> • Harness or connectors (The valve circuit is open or shorted.) • EVAP canister purge volume control valve 	RUNNING					GI MA EM
<ul style="list-style-type: none"> • EVAP control system pressure sensor • EVAP canister purge volume control valve (The valve is stuck open.) • EVAP canister purge control valve • Hoses (Hoses are connected incorrectly.) 	LIFTING	—	—	2 trip	EC-268	LC EC
<ul style="list-style-type: none"> • EVAP canister purge volume control valve stuck closed • EVAP canister purge control valve stuck closed • EVAP control system pressure sensor • Loose or disconnected rubber tube • Blocked rubber tube • EVAP canister purge control solenoid valve • Blocked or bent rubber tube to MAP/BARO switch solenoid valve • Cracked EVAP canister • Absolute pressure sensor • MAP/BARO switch solenoid valve 	—	LIFTING (M/T models) RUNNING (A/T models)	—	2 trip	EC-274	FE CL MT AT PD
<ul style="list-style-type: none"> • Harness or connectors (The communication line circuit is open or shorted.) • Dead (Weak) battery • A/T control unit 	RUNNING	—	—	2 trip	EC-281	FA
<ul style="list-style-type: none"> • Harness or connectors. (The cooling fan circuit is open or shorted.) • Cooling fan • Radiator hose • Radiator • Radiator cap • Water pump • Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", (EC-294).</p>	—	IGN: ON (RUNNING)	—	2 trip	EC-284	RA BR ST RS

*1: • This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

• During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

• This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

DX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

A/T RELATED ITEMS (Be sure to erase the DTC stored in ECM after the A/T related repair.)

Diagnostic trouble code No.		Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
CONSULT GST	MIL		
P0705	1101	Inhibitor switch circuit (INHIBITOR SWITCH)	<ul style="list-style-type: none"> A/T control unit does not receive the correct voltage signal from the switch based on the gear position.
P0710	1208	Fluid temperature sensor (FLUID TEMP SENSOR)	<ul style="list-style-type: none"> A/T control unit receives an excessively low or high voltage from the sensor.
P0720	1102	Revolution sensor (VHCL SPEED SEN-A/T)	<ul style="list-style-type: none"> A/T control unit does not receive the proper voltage signal from the sensor.
P0725	1207	Engine speed signal (ENGINE SPEED SIG)	<ul style="list-style-type: none"> A/T control unit does not receive the proper voltage signal from the ECM.
P0731	1103	Improper shifting to 1st gear position (A/T 1ST SIGNAL)	<ul style="list-style-type: none"> A/T cannot be shifted to the 1st gear position even electrical circuit is good.
P0732	1104	Improper shifting to 2nd gear position (A/T 2ND SIGNAL)	<ul style="list-style-type: none"> A/T cannot be shifted to the 2nd gear position even electrical circuit is good.
P0733	1105	Improper shifting to 3rd gear position (A/T 3RD SIGNAL)	<ul style="list-style-type: none"> A/T cannot be shifted to the 3rd gear position even electrical circuit is good.
P0734	1106	Improper shifting to 4th gear position or TCC (A/T 4TH SIGNAL OR TCC)	<ul style="list-style-type: none"> A/T cannot be shifted to the 4th gear position or perform lock-up even electrical circuit is good.
P0740	1204	T/C clutch solenoid valve (TOR CONV CLUTCH SV)	<ul style="list-style-type: none"> A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P0745	1205	Line pressure solenoid valve (LINE PRESSURE S/V)	<ul style="list-style-type: none"> A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P0750	1108	Shift solenoid valve A (SHIFT SOLENOID/V A)	<ul style="list-style-type: none"> A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P0755	1201	Shift solenoid valve B (SHIFT SOLENOID/V B)	<ul style="list-style-type: none"> A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.
P1705	1206	Throttle position sensor Throttle position switch (THRTL POSI SEN-A/T)	<ul style="list-style-type: none"> A/T control unit receives an excessively low or high voltage from the sensor.
P1760	1203	Overrun clutch solenoid valve (OVERRUN CLUTCH S/V)	<ul style="list-style-type: none"> A/T control unit detects the improper voltage drop when it tries to operate the solenoid valve.

*1: DRIVING pattern 1-6 means as follows:

- Pattern 1 should meet b and c.
- Pattern 2 should meet a and c.
- Pattern 3 should meet a through e.
- Pattern 4 should meet a and b.
- Pattern 5 should meet a through c.
- Pattern 6 should meet a through d.

a: Selector lever is in "D" position.

b: Vehicle speed is over 10 km/h (6 MPH).

c: Throttle opening is over 1/8.

d: Engine speed is over 450 rpm.

e: A/T fluid temperature is 20 - 120°C (68 - 248°F).

*: For details, refer to each DTC CONFIRMATION PROCEDURE in AT section.

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

X: Applicable
—: Not applicable

Check Items (Possible Cause)	“DTC CONFIRMATION PROCEDURE” Quick Ref. *1	“OVERALL FUNCTION CHECK” Quick Ref. *2	Fail Safe System	MIL Illumination	Reference Page
<ul style="list-style-type: none"> • Harness or connectors (The switch circuit is open or shorted.) • Inhibitor switch 	DRIVING (pattern 1)	—	—	2 trip	See “Self-diagnosis”, “TROUBLE DIAGNOSES” in AT section.
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Fluid temperature sensor 	DRIVING (pattern 6)	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Revolution sensor 	DRIVING (pattern 2)	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The signal circuit is open or shorted.) 	DRIVING (pattern 5)	—	X	2 trip	
<ul style="list-style-type: none"> • Shift solenoid valve A • Shift solenoid valve B • Overrun clutch solenoid valve • Line pressure solenoid valve • Each clutch • Hydraulic control circuit 	DRIVING (pattern 3)	—	—	2 trip	
<ul style="list-style-type: none"> • T/C clutch solenoid valve 					
<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • T/C clutch solenoid valve 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Line pressure solenoid valve 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve A 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve B 	IGN: ON	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Throttle position sensor • Throttle position switch 	DRIVING (pattern 4)	—	X	2 trip	
<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Overrun clutch solenoid valve 	IGN: ON	—	X	2 trip	

*1: • This is Quick Reference of “DTC CONFIRMATION PROCEDURE”.
Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

*2: • The “OVERALL FUNCTION CHECK” is a simplified and effective way to inspect a component or circuit.
In some cases, the “OVERALL FUNCTION CHECK” is used rather than a “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE”.
When no DTC CONFIRMATION PROCEDURE is available, the “NG” result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

- During an “NG” OVERALL FUNCTION CHECK, the DTC might not be confirmed.
- This is Quick Reference of “OVERALL FUNCTION CHECK”.
Details are described in each TROUBLE DIAGNOSIS FOR DTC PXXXX.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Diagnostic Trouble Code (DTC) Chart (Cont'd)

INSPECTION PRIORITY

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)		
1	<ul style="list-style-type: none"> • ECM (P0605, 0301) • Mass air flow sensor circuit (P0100, 0102) • Throttle position sensor circuit (P0120, 0403) • EGRC-solenoid valve circuit (P1400, 1005) • A/T diagnosis communication line (P1605, 0804) 	<ul style="list-style-type: none"> • Camshaft position sensor circuit (P0340, 0101) • Vehicle speed sensor circuit (P0500, 0104) • Intake air temperature sensor circuit (P0110, 0401) • Knock sensor circuit (P0325, 0304) • Tank fuel temperature sensor (P0180, 0402) 	<ul style="list-style-type: none"> • Engine coolant temperature sensor circuit (P0115, 0103) (P0125, 0908) • Ignition signal circuit (P1320, 0201) • Park/Neutral position switch circuit (P0705, 1003) • Signal circuit from A/T control unit to ECM (P0600)
2	<ul style="list-style-type: none"> • EGR temperature sensor circuit (P1401, 0305) • Absolute pressure sensor circuit (P0105, 0803) • MAP/BARO switch solenoid valve circuit (P1105, 1302) • EVAP canister purge control valve/solenoid valve circuit (P0443, 0807) • Vacuum cut valve bypass valve (P1441, 0801) • A/T related sensors, solenoid valves and switches (P0705-P0710, 1101-1208) 	<ul style="list-style-type: none"> • Crankshaft position sensor circuit (P0335, 0802), (P1336, 0905) • Front heated oxygen sensor heater circuit (P0135, 0901) • Cooling fan circuit (P1900, 1308) • EVAP control system pressure sensor circuit (P0450, 0704) • EVAP canister vent control valve circuit (P0446, 0903) 	<ul style="list-style-type: none"> • Front heated oxygen sensor circuit (P0130, 0303) • Rear heated oxygen sensor circuit (P0136, 0707) • EVAP canister purge volume control valve circuit (P1445, 1008) • EVAP control system purge flow monitoring (P1447, 0111) • Closed throttle position switch circuit (P0510, 0203)
3	<ul style="list-style-type: none"> • EGR function (P0400, 0302) • EGRC-BPT valve function (P0402, 0306) • IACV-AAC valve circuit (P0505, 0205) 	<ul style="list-style-type: none"> • Misfire (P0300 - P0304, 0701 - 0605) • Closed loop control (P0130, 0307) • Improper shifting (P0731 - P0734, 1103 - 1106) 	<ul style="list-style-type: none"> • Fuel injection system function (P0172, 0114), (P0171, 0115) • Three way catalyst function (P0420, 0702) • EVAP control system (small leak) (P0440, 0705)

TROUBLE DIAGNOSIS — General Description

Fail-Safe Chart

The ECM enters fail-safe mode, if any of the following DTCs is recorded due to the open or short circuit.

DTC No.		Detected Items	Engine operating condition in fail-safe mode														
CONSULT GST	MIL																
P0100	0102	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.														
P0115	0103	Engine coolant temperature sensor circuit	<p>Engine coolant temperature will be determined based on the time after turning ignition switch "ON" or "START".</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Engine coolant temperature decided</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or Start</td> <td style="text-align: center;">40°C (104°F)</td> </tr> <tr> <td>More than 4 minutes after ignition ON or Start</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td style="text-align: center;">40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table>	Condition	Engine coolant temperature decided	Just as ignition switch is turned ON or Start	40°C (104°F)	More than 4 minutes after ignition ON or Start	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)						
Condition	Engine coolant temperature decided																
Just as ignition switch is turned ON or Start	40°C (104°F)																
More than 4 minutes after ignition ON or Start	80°C (176°F)																
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)																
P0120	0403	Throttle position sensor circuit	<p>Throttle position will be determined based on the amount of mass air flow and the engine speed. Therefore, acceleration will be poor.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th style="text-align: center;">Driving condition</th> </tr> </thead> <tbody> <tr> <td>When engine is idling</td> <td style="text-align: center;">Normal</td> </tr> <tr> <td>When accelerating</td> <td style="text-align: center;">Poor acceleration</td> </tr> </tbody> </table>		Driving condition	When engine is idling	Normal	When accelerating	Poor acceleration								
	Driving condition																
When engine is idling	Normal																
When accelerating	Poor acceleration																
—	—	Start signal circuit	<p>If the ECM always receives a start signal, the ECM will judge the start signal "OFF" when engine speed is above 1,000 rpm. This prevents extra enrichment. After the engine speed is below 200 rpm, start-up enrichment will be allowed until the engine speed reaches 1,000 rpm.</p>														
—	—	ECM	<p>Fail-safe system activating condition when ECM is malfunctioning The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates, i.e. if the ECM detects a malfunction condition in the CPU of ECM, the MALFUNCTION INDICATOR LAMP on the instrument panel lights to warn the driver.</p> <p>Engine control, with fail-safe system, operates when ECM is malfunctioning When the fail-safe system is operating, fuel injection, ignition timing, fuel pump operation, IACV-AAC valve operation and cooling fan operation are controlled under certain limitations.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th style="text-align: center;">Operation</th> </tr> </thead> <tbody> <tr> <td>Engine speed</td> <td style="text-align: center;">Engine speed will not rise more than 3,000 rpm.</td> </tr> <tr> <td>Fuel injection</td> <td style="text-align: center;">Simultaneous multiport fuel injection system</td> </tr> <tr> <td>Ignition timing</td> <td style="text-align: center;">Ignition timing is fixed at the preset valve.</td> </tr> <tr> <td>Fuel pump</td> <td style="text-align: center;">Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.</td> </tr> <tr> <td>IACV-AAC valve</td> <td style="text-align: center;">Full open</td> </tr> <tr> <td>Cooling fans</td> <td style="text-align: center;">Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.</td> </tr> </tbody> </table>		Operation	Engine speed	Engine speed will not rise more than 3,000 rpm.	Fuel injection	Simultaneous multiport fuel injection system	Ignition timing	Ignition timing is fixed at the preset valve.	Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.	IACV-AAC valve	Full open	Cooling fans	Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.
	Operation																
Engine speed	Engine speed will not rise more than 3,000 rpm.																
Fuel injection	Simultaneous multiport fuel injection system																
Ignition timing	Ignition timing is fixed at the preset valve.																
Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls.																
IACV-AAC valve	Full open																
Cooling fans	Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.																

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (For New CT/CS)

SYSTEM		SYMPTOM														Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	OVERCOOLS		OVERCHARGING
New CT/CS		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	1P	1X	
Fuel	Fuel pump circuit	●	●	●	○	●		●	●			○		○			EC-301
	Fuel pressure regulator system	●	●	●	○	○	○	●	●	○		●					EC-24
	Injector circuit	●	●	●	○	●		●	●			●					EC-296
	Evaporative emission system	○	○	○	○	○	○	○	○	○		○					EC-19
Air	Positive crankcase ventilation system	○	○	○	○	○	○	○	○	○		○	○				EC-23
	IACV-Air regulator circuit	●	○	●	○	●	●	●	●	○		○					EC-309
	Incorrect idle speed adjustment	○	○				○	○	○	○		○					EC-26
	IACV-AAC valve circuit	●	●	●	○	●	●	●	●	●		●		○			EC-220
	IACV-FICD solenoid valve circuit	○	○	○	○	○	○	○	○	○		○					EC-312
Ignition	Incorrect ignition timing adjustment	○	○	●	●			●	●			●					EC-26
	Ignition circuit	●	●	●	●	●		●	●			●					EC-245
EGR	EGRC-solenoid valve circuit		○	●	○							○					EC-254
	EGR system	●	●	●	○	○	○	●	●	○		○					EC-177
Main power supply and ground circuit		●	●	●	○	○		○	○		○	○		○			EC-102
Cooling	Cooling fan circuit	○	○	○	○	○	○	○	○	○	●	○		○	●		EC-284
Air conditioner circuit		○	○	○	○	○	○	○	○	○		○		○			HA section

● ; High Possibility Item
○ ; Low Possibility Item

(continued on next page)

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (For New CT/CS) (Cont'd)

SYSTEM — ECCS system	SYMPTOM														Reference page	
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	OVERCOOLS		OVERCHARGING
New CT/CS	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	1P	1X	
ECCS	●	●	●	●	●		○	○			○					EC-173
	●	●	●	●	●		●	●			●					EC-105
		●	●	○	●		●	●			●					EC-136
	●	●	●	○	●	○	●	●	○		●					EC-122, 131
		●	●		●	●	●	●	●		●					EC-126
		●	○		○	●	○	○	●		○					EC-62
		○	○		○						○					EC-216
			●	●	○						○					EC-166
	○	○	○	○	○	○	○	○	○	○	○					EC-83, 232
	○															EC-299
			○		○		○	○			○					EC-234
		○					○	○								EC-306

● ; High Possibility Item
○ ; Low Possibility Item

(continued on next page)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (For New CT/CS) (Cont'd)

SYSTEM — Engine mechanical & other		SYMPTOM														Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	OVERCOOLS		OVERCHARGING
New CT/CS		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	1P	1X	
Fuel	Fuel tank	●	●														—
	Fuel piping	○	○	○	○	○		○	○			○					
	Vapor lock		○														
	Valve deposit	○	○	○	○	○		○	○			○					
	Poor fuel (Heavy weight gasoline, Low octane)	○	○	○	○	○		○	○			○					
Air	Air duct		○	○		○		○	○			○					FE section
	Air cleaner		●	●		○		●	●			●					
	Air leakage from air duct (Mass air flow sensor — throttle body)	○	○	○	○	○	○	○	○	○		○					
	Throttle body, Throttle wire	○	●	●		●	●	●	●	●		●					
	Air leakage from intake manifold/Collector/Gasket	○	○	●	○	○	○		●	●	○	○					
Cranking	Battery	○	○	○		○		○	○			○		○		○	EL section
	Alternator circuit	○	○	○		○		○	○			○		○		○	
	Starter circuit	●															
	Flywheel	●															
	Clutch interlock switch																
	Inhibitor switch	●															
	Theft warning circuit	○															
Engine	Cylinder head	●	○	○	○	○		●	○			○					—
	Cylinder head gasket	○	●	○	○	○		●	○		○	○	○				
	Cylinder block	○	○	○	○	●		○	○			○	○				
	Piston	●	○	○	○	○		○	○			○	○				
	Piston ring	○	○	○	○	○		○	○			○	○				
	Connecting rod	○	○	○	○	○		○	○			○	○				
	Bearing	○	○	○	○	○		○	○			○	○				
	Crankshaft	○	○	○	○	○		○	○			○	○				
Valve mechanism	Timing chain	●	○	●	○	●		○	○			○					
	Camshaft	●	○	○	○	○		○	○			○					
	Intake valve	○	○	○	○	○		●	○			○	○				
	Exhaust valve	○	●	○	○	○		●	○			○	○				
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	○	○	●	○	●		●	○			○	○				
	Three way catalyst	○	○	○	○	○		○	○			○					
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	○	●	○	○	○		○	○			○	○				
	Oil level (Low)/Filthy oil	○	○	○	○	○		○	○			○	○				
Cooling	Radiator/Hose/Radiator filler cap	○	○	○	○	○		○	○		○	○					
	Thermostat	○	○	○	○	○	○	○	○	○	○	○			○		
	Water pump	○	○	○	○	○		○	○			○	○				
	Water gallery	○	○	○	○	○		○	○			○	○				
	Cooling fan	○	○	○	○	○	○	○	○	○	○	○			○		
Coolant level (low)/Contaminated coolant	○	○	○	○	○		○	○			○	○					

● ; High Possibility Item
○ ; Low Possibility Item

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (For Old CT/CS)

SYSTEM — Basic engine control system		SYMPTOM														Reference page			
		HARD/NO START (COLD)	HARD/NO RE-START (HOT)	ROUGH IDLE	ENGINE STALL	HESITATION/FLAT SPOT/SURGE	LACK OF POWER/POOR ACCELERATION	NO RETURN TO IDLE/HIGH IDLE	SPARK KNOCK (PINGING)	BACK FIRE	AFTER FIRE	ENGINE RUN ON (DIESELING)	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERHEATS		OVERCOOLS	OVERCHARGING	BATTERY DEAD (UNDER CHARGE)
		1A	1B	1C	1F	1H	1R	1S	1M	1J	1L	1K	1T	1V	1N		1P	1X	1Y
Fuel	Fuel pump circuit	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	EC-301
	Fuel pressure regulator system	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	EC-24
	Injector circuit	●	●	●	●	●	○	○	○	○	○	○	●	○	○	○	○	○	EC-296
	Evaporative emission system	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-19
Air	Positive crankcase ventilation system	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-23
	IACV-Air regulator circuit	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	EC-309
	Incorrect idle speed adjustment	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-26
	IACV-AAC valve circuit	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	EC-220
Ignition	IACV-FICD solenoid valve circuit	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-312
	Incorrect ignition timing adjustment	○	○	●	○	●	○	○	○	○	○	○	○	○	○	○	○	○	EC-26
EGR	Ignition circuit	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	EC-245
	EGRC-solenoid valve circuit	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-254
Main power supply and ground circuit	EGR system	○	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	EC-177
	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-102
Cooling	Cooling fan circuit	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-284
Air conditioner circuit	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	HA section

● ; High Possibility Item
○ ; Low Possibility Item

(Continued on next page)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (For Old CT/CS) (Cont'd)

SYSTEM — ECCS system		SYMPTOM															Reference page		
		HARD/NO START (COLD)	HARD/NO RE-START (HOT)	ROUGH IDLE	ENGINE STALL	HESITATION/FLAT SPOT/SURGE	LACK OF POWER/POOR ACCELERATION	NO RETURN TO IDLE/HIGH IDLE	SPARK KNOCK (PINGING)	BACK FIRE	AFTER FIRE	ENGINE RUN ON (DIESELING)	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERHEATS	OVERCOOLS		OVERCHARGING	BATTERY DEAD (UNDER CHARGE)
		1A	1B	1C	1F	1H	1R	1S	1M	1J	1L	1K	1T	1V	1N	1P		1X	1Y
ECCS	Camshaft position sensor circuit	●	○	●	●	●	●	●	○	○	○	○	○	○	○	○	○	EC-173	
	Mass air flow sensor circuit	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	EC-26	
	Front heated oxygen sensor circuit			●	●	●	●	○	○	○	○	○	○	○	○	○	○	EC-136	
	Engine coolant temperature sensor circuit	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	EC-122, 131	
	Throttle position sensor circuit			●	●	●	●	○	○	○	○	○	○	○	○	○	○	EC-126	
	Incorrect throttle position sensor adjustment			○	●	○	○	○	○	○	○	○	○	○	○	○	○	EC-62	
	Vehicle speed sensor circuit				○	○	○	○	○	○	○	○	○	○	○	○	○	EC-216	
	Knock sensor circuit					●	○	○	○	○	○	○	○	○	○	○	○	EC-166	
	ECM	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	EC-83, 232	
	Start signal circuit	○	○															EC-299	
	Park/Neutral position switch circuit			○		○	○						○					EC-234	
	Power steering oil pressure switch circuit			○	○													EC-306	

● ; High Possibility Item
○ ; Low Possibility Item

(Continued on next page)

TROUBLE DIAGNOSIS — General Description

Symptom Matrix Chart (For Old CT/CS) (Cont'd)

SYSTEM — Engine mechanical & other		SYMPTOM																	Reference page
		HARD/NO START (COLD)	HARD/NO RE-START (HOT)	ROUGH IDLE	ENGINE STALL	HESITATION/FLAT SPOT/SURGE	LACK OF POWER/POOR ACCELERATION	NO RETURN TO IDLE/HIGH IDLE	SPARK KNOCK (PINGING)	BACK FIRE	AFTER FIRE	ENGINE RUN ON (DIESELING)	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	OVERHEATS	OVERCOOLS	OVERCHARGING	BATTERY DEAD (UNDER CHARGE)	
		1A	1B	1C	1F	1H	1R	1S	1M	1J	1L	1K	1T	1V	1N	1P	1X	1Y	
Fuel	Fuel tank	○	○		○														—
	Fuel piping	○	○	○	○	○	○		○	○	○								
	Vapor lock		○	○	○	○	○												
	Valve deposit	○	○	○	○	○	○		○	○			○						
Air	Poor fuel (Heavy weight gasoline, Low octane)	○	○	○	○	○	○		○	○			○						
	Air duct			○	○	○	○						○						
	Air cleaner			●	●	●	○						●						
	Air leakage from air duct (Mass air flow sensor — throttle body)	○	○	○	○	○	○	○	○	○			○						
	Throttle body, Throttle wire	○		●	●	●	●	○					○						
Cranking	Air leakage from intake manifold/Collector/Gasket	○	○	●	○	●	●	○	○	○			○						
	Battery	○	○	○	○	○	○						○				○	○	
	Alternator circuit	○	○	○	○	○	○						○				○	○	
	Starter circuit	●	●																
	Flywheel	●	○																
	Clutch interlock switch	●	○																
	Inhibitor switch	●	○																
Engine	Theft warning circuit	○	○																
	Cylinder head	●	○	●	○	○	○		○	○			○						
	Cylinder head gasket	○	○	●	○	○	○		○	○			○	○	○				
	Cylinder block	○	○	○	○	○	○	●					○	○	○				
	Piston	●	○	○	○	○	○		○	○			●	○					
	Piston ring	○	○	○	○	○	○		○	○			○	○					
	Connecting rod	○	○	○	○	○	○		○	○			○						
	Bearing	○	○	○	○	○	○		○	○			○						
Valve mechanism	Crankshaft	○	○	○	○	○	○		○	○			○						
	Timing chain	○	○	○	○	●	●		○	○			○						
	Camshaft	○	○	○	○	○	○		○	○			○						
	Intake valve	○	○	●	○	○	○		○	○			○	○					
Exhaust	Exhaust valve	○	○	●	●	○	○		○	○	○		○	○					
	Hydraulic lash adjuster			○	○	○	○		○	○			○						
	Exhaust manifold/Tube/Muffler/Gasket	○	○	●	○	○	○	●		○	○		○						
Lubrication	Three way catalyst	○	○	○	○	○	○		○	○	○		○						
	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	○	○	○	○	○	○		○				○	○					
Cooling	Oil level (Low)/Filthy oil	○	○	○	○	○	○		○				○	○					
	Radiator/Hose/Radiator filler cap	○	○	○	○	○	○		○				○		○				
	Thermostat	○	○	○	○	○	○	○		○			○		○	○			
	Water pump	○	○	○	○	○	○		○				○		○				
	Water gallery	○	○	○	○	○	○		○				○		○				
	Cooling fan	○	○	○	○	○	○	○		○			○		○				
	Coolant level (low)/Contaminated coolant	○	○	○	○	○	○		○				○		○				

● ; High Possibility Item
○ ; Low Possibility Item

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — General Description

CONSULT Reference Value in Data Monitor Mode

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
 - * Specification data may not be directly related to their components signals/values/operations.
- i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.
- If the real-time diagnosis results are NG and the on board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

MONITOR ITEM	CONDITION		SPECIFICATION
CMPS-RPM (REF)	<ul style="list-style-type: none"> • Tachometer: Connect • Run engine and compare tachometer indication with the CONSULT value. 		Almost the same speed as the CONSULT value.
MAS AIR/FL SE	<ul style="list-style-type: none"> • Engine: After warming up • Air conditioner switch "OFF" • Shift lever "N" • No-load 	Idle	1.3 - 1.7V
		2,000 rpm	1.7 - 2.1V
COOLAN TEMP/S	<ul style="list-style-type: none"> • Engine: After warming up 		More than 70°C (158°F)
FR O2 SENSOR	<ul style="list-style-type: none"> • Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
FR O2 MNTR			LEAN ↔ RICH Changes more than 5 times during 10 seconds.
RR O2 SENSOR	<ul style="list-style-type: none"> • Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 ↔ Approx. 2.2V
RR O2 MNTR			LEAN ↔ RICH
VHCL SPEED SE	<ul style="list-style-type: none"> • Turn drive wheels and compare speedometer indication with the CONSULT value 		Almost the same speed as the CONSULT value
BATTERY VOLT	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) 		11 - 14V
THRTL POS SEN	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) 	Throttle valve fully closed	0.3 - 0.7V
		Throttle valve fully opened	Approx. 4.0V
EGR TEMP SEN	<ul style="list-style-type: none"> • Engine: After warming up 		Less than 4.5V
START SIGNAL	<ul style="list-style-type: none"> • Ignition switch: ON → START 		OFF → ON
CLSD THL/P SW	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) 	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	<ul style="list-style-type: none"> • Engine: After warming up, idle the engine 	Air conditioner switch "OFF"	OFF
		Air conditioner switch "ON" (Compressor operates.)	ON
P/N POSI SW	<ul style="list-style-type: none"> • Ignition switch: ON 	Shift lever "P" or "N"	ON
		Except above	OFF

TROUBLE DIAGNOSIS — General Description

CONSULT Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION		SPECIFICATION	
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF	GI
		The steering wheel is turned	ON	
IGNITION SW	<ul style="list-style-type: none"> Ignition switch ON → OFF 		ON → OFF	MA
A/C PRESS SW	<ul style="list-style-type: none"> Air conditioner high pressure side: Increasing to 1,422 - 1,618 kPa (14.5 - 16.5 kg/cm², 206 - 235 psi) Air conditioner high pressure side: Except above 		ON	EM
			OFF	
LOAD SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON 	Rear window defogger is operating.	ON	LC
		Rear window defogger is not operating.	OFF	
AMB TEMP SW	<ul style="list-style-type: none"> Ignition switch: ON Compare ambient temperature with the following: 	Below 19°C (66°F)	OFF	EC
		19 - 25°C (66 - 77°F)	—	
		Above 25°C (77°F)	ON	
INJ PULSE	<ul style="list-style-type: none"> Engine: After warming up Air conditioner switch "OFF" Shift lever "N" No-load 	Idle	2.4 - 3.2 msec.	FE
		2,000 rpm	1.9 - 3.2 msec.	
B/FUEL SCHDL	ditto	Idle	1.0 - 1.6 msec	CL
		2,000 rpm	0.7 - 1.3 msec	
IGN TIMING	ditto	Idle	20° BTDC	MT
		2,000 rpm	More than 25° BTDC	
IACV-AAC/V	ditto	Idle	20 - 40%	AT
		2,000 rpm	—	
PURG VOL C/V	ditto	Vehicle stopped	0 step	PD
		Vehicle running	—	
A/F ALPHA	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	51 - 160%	FA
EVAP SYS PRES	<ul style="list-style-type: none"> Ignition switch: ON 		Approx. 3.4V	
AIR COND RLY	<ul style="list-style-type: none"> Air conditioner switch OFF → ON 		OFF → ON	RA
FUEL PUMP RLY	<ul style="list-style-type: none"> Ignition switch is turned to ON (Operates for 1 second) Engine running and cranking When engine is stopped (stops in 1.0 seconds) 		ON	BR
		Except as shown above	OFF	
COOLING FAN	<ul style="list-style-type: none"> After warming up engine, idle the engine. Air conditioner switch "OFF" 	Engine coolant temperature is 94°C (201°F) or less	OFF	ST
		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)	LOW	
		Engine coolant temperature is 100°C (212°F) or more	HIGH	RS

TROUBLE DIAGNOSIS — General Description

CONSULT Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION
EGRC SOL/V	<ul style="list-style-type: none"> • Engine: After warming up • Air conditioner switch: "OFF" • Shift lever: "N" • No-load 	Idle ON
		Racing up to 1,500 - 2,000 rpm OFF
VENT CONT/V	<ul style="list-style-type: none"> • Ignition switch: ON 	OFF
FR O2 HEATER	<ul style="list-style-type: none"> • Engine speed: Idle 	ON
	<ul style="list-style-type: none"> • Engine speed: Above 4,400 rpm 	OFF
VC/V BYPASS/V	<ul style="list-style-type: none"> • Ignition switch: ON 	OFF
PURG CONT S/V	<ul style="list-style-type: none"> • Engine: After warming up 	Idle OFF
		2,000 rpm ON
CAL/LD VALUE	<ul style="list-style-type: none"> • Engine: After warming up • Air conditioner switch "OFF" • Shift lever "N" • No-load 	Idle 10.0 - 24.0%
		2,500 rpm 11.0 - 25.0%
ABSOL TH/P/S	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) 	Throttle valve fully closed 0.0%
		Throttle valve fully opened Approx. 84%
MASS AIRFLOW	<ul style="list-style-type: none"> • Engine: After warming up • Air conditioner switch "OFF" • Shift lever "N" • No-load 	Idle 1.5 - 4.5 gm/s
		2,500 rpm 6.0 - 14.0 gm/s
MAP/BARO SW/V	<ul style="list-style-type: none"> • Ignition switch: ON 	OFF
ABSOL PRES/SE	<ul style="list-style-type: none"> • Engine: After warming up 	Engine is not running Approx. 4.4V
		Idle Approx. 1.2V


Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.
(Select "HI SPEED" in "DATA MONITOR" with CONSULT.)

THRTL POS SEN, ABSOL TH·P/S, CLSD THL/P SW

Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL/P SW" when depressing the accelerator pedal with the ignition switch "ON".


The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL/P SW" is changed from "ON" to "OFF".



CMPS·RPM (REF), MAS AIR/FL SE, THRTL POS SEN, RR O2 SENSOR, FR O2 SENSOR, INJ PULSE


Below is the data for "CMPS·RPM (REF)", "MAS AIR/FL SE", "THRTL POS SEN", "RR O2 SENSOR", "FR O2 SENSOR" and "INJ PULSE" when revving quickly up to 4,800 rpm under no load after warming up engine sufficiently.

Each value is for reference, the exact value may vary.




TROUBLE DIAGNOSIS — General Description


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)



- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.




- "RR O2 SENSOR" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "FR O2 SENSOR" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE" should increase when depressing the accelerator pedal and should decrease when the pedal is released.



ECM Terminals and Reference Value

PREPARATION

1. ECM is located behind the front passenger seat side dash. For this inspection, remove the front passenger side dash.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX




2. Remove ECM harness protector.



3. Perform all voltage measurements with the connectors connected. Extend tester probe as shown to perform tests easily.

ECM HARNESS CONNECTOR TERMINAL LAYOUT



SEF064P

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and Ⓣ (ECCS ground).

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
1	W	Ignition signal	Engine is running. └ Idle speed	0.3 - 0.6V*
			Engine is running. └ Engine speed is 2,000 rpm	Approximately 0.9V*
2	Y	Ignition check	Engine is running. └ Idle speed	Approximately 12V*
3	Y/R	Tachometer	Engine is running. └ Idle speed	Approximately 0.9V*
4	R/B	ECCS relay (Self-shutoff)	Engine is running. Ignition switch "OFF" └ For a few seconds after turning ignition switch "OFF".	0 - 1V
			Ignition switch "OFF" └ A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
5	L	EVAP canister purge volume control valve	Engine is running.	0 - 0.4V
6	YL		└ Idle speed	
7	Y/L (M/T models)	5th position switch	Ignition switch "ON"	1.0 - 8.0V
			Ignition switch "ON" └ Gear is in "5th position" (M/T models).	Approximately 0V
	R/B (A/T models)	A/T check signal	Ignition switch "ON"	1.0 - 8.0V
			Engine is running.	
8	B/P	Fuel pump relay	Ignition switch "ON" └ For 1 second after turning ignition switch "ON"	Approximately 0.9V
			Engine is running. Ignition switch "ON" └ 1 second after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
9	OR/B	Air conditioner triple-pressure switch	Ignition switch "ON"	Approximately 7V
10	B	ECCS ground	Engine is running. └ Idle speed	Engine ground
12	Y/B	Air conditioner hand power switch	Ignition switch "ON"	Approximately 12V

* Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	
13	OR/L	Cooling fan relay (High)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)	GI
			Engine is running. └ Cooling fan (High) is operating.	0.07 - 0.30V	MA
14	L/G	Cooling fan relay (Low)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)	EM
			Engine is running. └ Cooling fan (Low) is operating.	0.07 - 0.20V	LC
15	B/P	Air conditioner relay	Engine is running. └ Both air conditioner switch and blower switch are "ON".	0.08 - 0.3V	EC
			Engine is running. └ Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)	FE CL
16	W/B	EVAP canister purge volume control valve	Engine is running.	BATTERY VOLTAGE (11 - 14V)	MT
17	R/G		└ Idle speed		
18	OR	Malfunction indicator lamp	Ignition switch "ON"	Approximately 0.1V	AT
			Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)	
19	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	PD FA
20	OR	Start signal	Ignition switch "ON"	Approximately 0V	RA
			Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)	
21	OR/L	Air conditioner switch	Engine is running. └ Both air conditioner switch and blower switch are "ON". (Compressor operates)	Approximately 0V	BR
			Engine is running. └ Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)	ST
22	G/OR (M/T models) R/G (A/T models)	Neutral position switch (M/T models) Inhibitor switch (A/T models)	Ignition switch "ON" └ Gear position is "Neutral position" (M/T models) └ Gear position is "N" or "P" (A/T models)	Approximately 0V	RS BT
			Ignition switch "ON" └ Except the above gear position	Approximately 4V	HA
23	W	Throttle position sensor	Ignition switch "ON" └ Accelerator pedal released	0.3 - 0.7V	EL
			Ignition switch "ON" └ Accelerator pedal fully depressed	Approximately 4V	IDX

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
24	L/G	A/T signal No. 1	Ignition switch "ON" Engine is running. Idle speed	6 - 8V
25	PU/W	Power steering oil pressure switch	Engine is running. Steering wheel is being turned.	0V
			Engine is running. Steering wheel is not being turned.	Approximately 5V
26	Y/G	Vehicle speed sensor	Engine is running. Slowly rotating front wheels	Approximately 1.8 - 2.4V* (AC voltage)
27	L/G	Throttle position switch (Closed position)	Ignition switch "ON" (Warm-up condition) Accelerator pedal released	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "ON" Accelerator pedal depressed	Approximately 0V
28	L/W	Intake air temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with intake air temperature.
29	L/W	A/T signal No. 2	Ignition switch "ON" Engine is running. Idle speed	6 - 8V
30	L/R	A/T signal No. 3	Ignition switch "ON"	0V
33	R/Y	Throttle position sensor signal	Ignition switch "ON" Accelerator pedal released	Approximately 0.4V
			Ignition switch "ON" Accelerator pedal fully depressed	Approximately 3V
38	B/R	Ignition switch	Ignition switch "OFF"	0V
			Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
39	B	ECCS ground	Engine is running. Idle speed	Engine ground
40 44	W W	Camshaft position sensor (Reference signal)	Engine is running.	Approximately 2.7V* (AC voltage)
43	B	ECCS ground	Engine is running. Idle speed	Engine ground (Probe this terminal with ⊖ tester probe when measuring.)
41	B	Camshaft position sensor (Position signal)	Engine is running.	Approximately 2.7V* (AC voltage)

* Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	
46	W	Front heated oxygen sensor	Engine is running. └ After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V (periodically change)	GI
47	W	Mass air flow sensor	Engine is running. (Warm-up condition) └ Idle speed	1.3 - 1.7V	MA
			Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm.	1.7 - 2.1V	EM
48	B	Mass air flow sensor ground	Engine is running. (Warm-up condition) └ Idle speed	0.005 - 0.02V	LC
49	LG/R	Throttle position sensor power supply	Ignition switch "ON"	Approximately 5V	EC
50	B	Sensors' ground	Engine is running. (Warm-up condition) └ Idle speed	0.001 - 0.02V	FE
51	L/OR	Engine coolant temperature sensor	Engine is running.	0 - 4.84V Output voltage varies with engine coolant temperature.	CL
52	W	Rear heated oxygen sensor	Engine is running. └ After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 2.2V**	MT
53	P	Crankshaft position sensor (OBD)	Engine is running. (A/T: N range, M/T: Neutral) └ Idle speed (Air conditioner switch "OFF".)	More than 0.2V* (AC range)	AT
54	W	Knock sensor	Engine is running. └ Idle speed	2.0 - 3.0V	PD
55	L/R	Rear defogger relay	Ignition switch "ON" └ Rear defogger is "OFF".	Approximately 0V	FA
			Ignition switch "ON" └ Rear defogger is "ON".	BATTERY VOLTAGE (11 - 14V)	RA
56 61	B/W B/W	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	BR
57	L/W	Ambient temperature switch	Engine is running. └ Idle speed	0V	ST
			Engine is running. └ Idle speed └ Air conditioner is operating.	Approximately 0.2V	RS
58	R	Data link connector for GST	Engine is running. └ Idle speed	Approximately 9V	BT

* Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

** During the on board diagnosis for the open circuit, approx. 1.5 - 5V will appear. This is not a malfunction. (Refer to page EC-145.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
62	B/W	EGR temperature sensor	Engine is running. (Warm-up condition) └ Idle speed	Less than 4.5V
			Engine is running. (Warm-up condition) └ EGR system is operating.	0 - 3.0V
63	Y	Tank fuel temperature sensor	Engine is running.	0 - 5.0V Output voltage varies with fuel temperature.
64	G/B	Data link connector for CONSULT	Engine is running.	Approximately 0.1V
65	G		└ Idle speed (CONSULT is connected and turned on)	Approximately 4 - 9V
68	G/W			Approximately 3.5V*
66	W	Absolute pressure sensor	Ignition switch "ON" └ Engine is not running.	Approximately 4.4V
			Engine is running. (Warm-up condition) └ Idle speed (5 seconds after starting engine)	Approximately 1.2V
67	G	EVAP control system pressure sensor	Ignition switch "ON"	Approximately 3.4V
69	Y/B	MAP/BARO switch solenoid valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
70	R	Power supply (Back-up)	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
101	BR	IACV-AAC valve (Open)	Ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)
			Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm	0 - 4V
102	W/B	Injector No. 1	Engine is running	BATTERY VOLTAGE (11 - 14V)
104	G/B	Injector No. 3		
107	Y/B	Injector No. 2		
109	L/B	Injector No. 4		
103	L/R	EGRC-solenoid valve	Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
			Engine is running. (Warm-up condition) └ Idle speed	Approximately 0V
105	Y/R	EVAP canister purge control solenoid valve	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)
106	B	ECCS ground	Engine is running. └ Idle speed	Engine ground
108	B	Rear heated oxygen sensor heater	Ignition switch "ON" Engine is running.	0 - Approximately 0.3V

* Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS — General Description

ECM Terminals and Reference Value (Cont'd)

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA	
111	B	Rear heated oxygen sensor heater ground	Engine is running. └ Idle speed	0.02 - 0.1V	GI
112	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	MA
113	R	Current return	Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)	EM
114	OR/L	REC relay	Ignition switch "ON" └ Relay is operating.	BATTERY VOLTAGE (11 - 14V)	LC
115	L	Front heated oxygen sensor heater	Engine is running. └ Engine speed is below 4,400 rpm.	Approximately 0V	EC
			Engine is running. └ Engine speed is above 4,400 rpm.	BATTERY VOLTAGE (11 - 14V)	FE
116	Y/G	EVAP canister vent control valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	CL
117	Y/G	Vacuum cut valve bypass valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	MT
118	B	ECCS ground	Engine is running. └ Idle speed	Engine ground	AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX


Main Power Supply and Ground Circuit

EC-MAIN-01








Refer to last page (Foldout page).

- (E109), (M9)
- (M63), (F3)



TROUBLE DIAGNOSIS FOR POWER SUPPLY


Main Power Supply and Ground Circuit (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)




D

CHECK HARNESS CONTINUITY BETWEEN ECCS RELAY AND ECM.

1. Disconnect ECM harness connector.
2. Disconnect ECCS relay.
3. Check harness continuity between ECM terminals (56), (61) and terminal (3).
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.




E

CHECK VOLTAGE BETWEEN ECCS RELAY AND GROUND.

Check voltage between terminals (2), (5) and ground with CONSULT or tester.
Voltage: Battery voltage

NG → Check the following.
• Harness for open or short between ECCS relay and battery
If NG, repair harness or connectors.




F

CHECK OUTPUT SIGNAL CIRCUIT.

Check harness continuity between ECM terminal (4) and terminal (1).
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.




G

CHECK ECCS RELAY.

1. Apply 12V direct current between relay terminals (1) and (2).
2. Check continuity between relay terminals (3) and (5).
12V (1) - (2) applied:
Continuity exists.
No voltage applied:
No continuity

NG → Replace ECCS relay.



H


CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals (10), (19), (39), (43), (106), (112) and engine ground.
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

Check ECM pin terminals for damage and check the connection of ECM harness connector.

INSPECTION END



Mass Air Flow Sensor (MAFS) (DTC: 0102)

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to the hot wire as air flow increases. This maintains the temperature of the hot wire. The ECM detects the air flow by means of this current change.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Item (Possible Cause)
P0100 0102	A) An excessively high or low voltage from the sensor is sent to ECM. B)C) Rationally incorrect voltage is sent to ECM, compared with the calculated value by camshaft position sensor signal and throttle position sensor signal.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Mass air flow sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the DTC cannot be confirmed, perform "Procedure for malfunction B". If there is no problem on "Procedure for malfunction B", perform "Procedure for malfunction C", "OVERALL FUNCTION CHECK".

Procedure for malfunction A

- ① 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 3 seconds.

OR

- ② 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Start engine and wait at least 3 seconds.
- 3) Select "MODE 3" with GST.

OR

- ③ 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Start engine and wait at least 3 seconds.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform diagnostic test mode II (Self-diagnostic results) with ECM.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0100

Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)

Procedure for malfunction B


- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up sufficiently.
- 4) Run engine for at least 10 seconds at idle speed.

OR

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Run engine for at least 10 seconds at idle speed.
- 4) Select "MODE 3" with GST.

OR

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Run engine for at least 10 seconds at idle speed.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform diagnostic test mode II (Self-diagnostic results) with ECM.



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of mass air flow sensor. During this check a DTC might not be confirmed.

Procedure for malfunction C

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Select "DATA MONITOR" mode with CONSULT.
- 4) Check the voltage of mass air flow sensor with "DATA MONITOR".
- 5) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

OR


- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Select "MODE 1" with GST.
- 4) Check the mass air flow with "MODE 1".
- 5) Check for linear mass air flow rise in response to increases to about 4,000 rpm in engine speed.

OR

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Check the voltage between ECM terminal ④7 and ground.
- 4) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

FUEL SYS #1	OPEN
FUEL SYS #2	UNUSED
CALC LOAD	22%
COOLANT TEMP	30°C
SHORT FT #1	0%
LONG FT #1	2%
ENGINE SPD	1000RPM
VEHICLE SPD	0km/h
IGN ADVANCE	20.0°
INTAKE AIR	26°C
MAF	0.0gm/sec
THROTTLE POS	0%
O2S LOCATION	3
O2S B1,S1	0.680V
O2FT B1,S1	0%
O2S B1,S2	0.080V


SEF003P





TROUBLE DIAGNOSIS FOR DTC P0100

Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)

EC-MAFS-01




GI
MA
EM
LC
EC
FE
CL
WT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Refer to last page (Foldout page).







E109, M9
M63, F3



TROUBLE DIAGNOSIS FOR DTC P0100



Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)

DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR DTC P0100

Mass Air Flow Sensor (MAFS) (DTC: 0102) (Cont'd)



COMPONENT INSPECTION

Mass air flow sensor

1. Turn ignition switch "ON".
2. Start engine and warm it up sufficiently.
3. Check voltage between terminal Ⓐ and ground.

Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up sufficiently.)	1.3 - 1.7
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA


EL

FDX



Absolute Pressure Sensor (DTC: 0803)

The absolute pressure sensor is connected to the MAP/BARO switch solenoid valve by a hose. The sensor detects ambient barometric pressure and intake manifold pressure and sends the voltage signal to the ECM. As the pressure increases, the voltage rises. The absolute pressure sensor is not used to control the engine system. It is used only for on board diagnosis.



Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0105 0803	A) An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> • Harness or connectors (Absolute pressure sensor circuit is open or shorted.) • Absolute pressure sensor
	B) A low voltage from the sensor is sent to ECM under heavy load driving conditions.	<ul style="list-style-type: none"> • Absolute pressure sensor
	C) A high voltage from the sensor is sent to ECM under light load driving conditions.	<ul style="list-style-type: none"> • Hoses (Hoses between the intake manifold and absolute pressure sensor are disconnected or clogged.) • Intake air leaks • Absolute pressure sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the DTC cannot be confirmed, perform "Procedure for malfunction B", "OVER-ALL FUNCTION CHECK". If there is no problem on "Procedure for malfunction B", perform "Procedure for malfunction C".

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 6 seconds.

OR



- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Select "MODE 3" with GST.

OR



- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0105

Absolute Pressure Sensor (DTC: 0803) (Cont'd)

If the DTC cannot be confirmed, perform "Procedure for malfunction B", "OVERALL FUNCTION CHECK" on next page.

Procedure for malfunction C



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 4) Start engine and let it idle.
- 5) Wait at least 15 seconds.

GI

MA

OR



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine.
- 4) Let engine idle and wait at least 15 seconds.
- 5) Select "MODE 3" with GST.

EM

LC

OR



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine.
- 4) Let engine idle and wait at least 15 seconds.
- 5) Turn ignition switch "OFF".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0105

Absolute Pressure Sensor (DTC: 0803) (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of absolute pressure sensor circuit. During this check, a DTC might not be confirmed.

Procedure for malfunction B

- 1) Turn ignition switch "ON".
- 2) Select "ABSOL PRES/SE" in "DATA MONITOR" mode with CONSULT.
- 3) Make sure that the voltage of "ABSOL PRES/SE" is more than 1.74 [V].

OR

- 1) Turn ignition switch "ON".
- 2) Select "MAP" in "MODE 1" with GST.
- 3) Make sure that the pressure of "MAP" is more than 46 kPa (0.47 kg/cm², 6.7 psi).

OR

- 1) Turn ignition switch "ON".
- 2) Make sure that the voltage between ECM terminal 66 and ground is more than 1.74 [V].


If the DTC cannot be confirmed, perform "Procedure for malfunction C" on the previous page.

☆ MONITOR	☆ NO FAIL
ABSOL PRES/SE	4.4V
RECORD	

SEF577Q

ENGINE SPD	0RPM
COOLANT TEMP	69°C
VEHICLE SPD	0MPH
IGN ADVANCE	3.0°
CALC LOAD	0.0%
MAP	101 kPa
MAF	0.25gm/s
THROTTLE POS	0.0%
INTAKE AIR	27°C
FUEL SYS #1	OL
FUEL SYS #2	UNUSED
SHORT FT #1	0.0%
LONG FT #1	0.0%
O2S B1 S1	0.000V
O2FT B1 S1	0.0%
O2S B1 S2	0.000V

SEF518R




SEF471R




TROUBLE DIAGNOSIS FOR DTC P0105

Absolute Pressure Sensor (DTC: 0803) (Cont'd)

EC-AP/SEN-01



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX








TROUBLE DIAGNOSIS FOR DTC P0105

Absolute Pressure Sensor (DTC: 0803) (Cont'd)

DIAGNOSTIC PROCEDURE

If the trouble is duplicated after "Procedure for malfunction A or B", perform "Procedure A" below. If the trouble is duplicated after "Procedure for malfunction C", perform "Procedure B" on next page.




Procedure A



TROUBLE DIAGNOSIS FOR DTC P0105

Absolute Pressure Sensor (DTC: 0803) (Cont'd)


Procedure B



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0105

Absolute Pressure Sensor (DTC: 0803) (Cont'd) COMPONENT INSPECTION



Absolute pressure sensor

1. Remove absolute pressure sensor with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch "ON" and check output voltage between terminal ② and engine ground.

The voltage should be 3.2 to 4.8 V.

4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg, -3.87 psi) to absolute pressure sensor as shown in figure and check the output voltage.


The voltage should be 1.0 to 1.4 V lower than the value measured in step 3.

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace absolute pressure sensor.

TROUBLE DIAGNOSIS FOR DTC P0110



Intake Air Temperature Sensor (DTC: 0401)

The intake air temperature sensor is built into the air cleaner. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit employs a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decrease in response to the temperature rise.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.

GI
MA
EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

261

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Item (Possible Cause)
P0110 0401	A) An excessively low or high voltage from the sensor is sent to ECM. B) Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Intake air temperature sensor.



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Procedure for malfunction A and B



- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - (1) Turn ignition switch "ON".
 - (2) Select "DATA MONITOR" mode with CONSULT.
 - (3) Check the engine coolant temperature.
 - (4) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- 2) Turn ignition switch "ON".
- 3) Select "DATA MONITOR" mode with CONSULT.
- 4) Wait at least 5 seconds.

OR

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - (1) Turn ignition switch "ON".
 - (2) Select MODE 1 with GST.
 - (3) Check the engine coolant temperature.
 - (4) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- 2) Turn ignition switch "ON" and wait at least 5 seconds.
- 3) Select MODE 3 with GST.

OR

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
 - (1) Turn ignition switch "ON".
 - (2) Check voltage between ECM terminal 51 and ground.
Voltage: More than 1.0 (V)
 - (3) If the voltage is not more than 1.0 (V), turn ignition switch "OFF" and cool down engine.
- 2) Turn ignition switch "ON" wait at least 5 seconds.



TROUBLE DIAGNOSIS FOR DTC P0110


Intake Air Temperature Sensor (DTC: 0401) (Cont'd)

- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform diagnostic test mode II (Self-diagnostic results) with ECM.




TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)

EC-IATS-01







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)

DIAGNOSTIC PROCEDURE




TROUBLE DIAGNOSIS FOR DTC P0110

Intake Air Temperature Sensor (DTC: 0401) (Cont'd)


COMPONENT INSPECTION

Intake air temperature sensor

Check resistance as shown in the figure.



SEF007P




SEF012P

Intake air temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38


- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL
- IDX

TROUBLE DIAGNOSIS FOR DTC P0115



Engine Coolant Temperature Sensor (ECTS) (DTC: 0103)

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



⟨Reference data⟩

Engine coolant temperature °C (°F)	Voltage (V)	Resistance (kΩ)
-10 (14)	4.4	9.2
20 (68)	3.5	2.5
50 (122)	2.2	0.8
90 (194)	0.9	0.2

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Item (Possible Cause)
P0115 0103	<ul style="list-style-type: none"> An excessively high or low voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Engine coolant temperature sensor


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch "ON".
 - 2) Select "DATA MONITOR" mode with CONSULT.
 - 3) Wait at least 5 seconds.
- OR
- 1) Turn ignition switch "ON" and wait at least 5 seconds.
 - 2) Select "MODE 3" with GST.
- OR
- 1) Turn ignition switch "ON" and wait at least 5 seconds.
 - 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 - 3) Perform diagnostic test mode II (Self-diagnostic results) with ECM.




TROUBLE DIAGNOSIS FOR DTC P0115

Engine Coolant Temperature Sensor (ECTS) (DTC: 0103) (Cont'd)

EC-ECTS-01







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0115

Engine Coolant Temperature Sensor (ECTS) (DTC: 0103) (Cont'd)

DIAGNOSTIC PROCEDURE




TROUBLE DIAGNOSIS FOR DTC P0115

Engine Coolant Temperature Sensor (ECTS) (DTC: 0103) (Cont'd)

COMPONENT INSPECTION

Engine coolant temperature sensor

Check resistance as shown in the figure.



Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

Throttle Position Sensor (DTC: 0403)

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This controls engine operation such as fuel cut. The throttle position sensor unit contains a built-in "Wide open and closed throttle position switch".




Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0120 0403	<ul style="list-style-type: none"> • An excessively low or high voltage from the sensor is sent to ECM. • Voltage sent to ECM is not practical when compared with mass air flow sensor and camshaft position sensor signals. 	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Throttle position sensor

TROUBLE DIAGNOSIS FOR DTC P0120


Throttle Position Sensor (DTC: 0403) (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the throttle position sensor. During this check, a DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT.
- 5) Select "THRTL POS SEN" and "ABSOL TH+P/S" in "DATA MONITOR" mode with CONSULT.
- 6) Press RECORD on CONSULT SCREEN at the same time accelerator pedal is depressed.
- 7) Print out the recorded data and check the following:

GI
MA
EM



LC
EC

- The voltage when accelerator pedal fully released is 0.3 - 0.7V.
- The voltage rise is linear in response to accelerator pedal depression.
- The voltage when accelerator pedal fully depressed is approximately 4V.


OR

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON".
- 4) Check the voltage between ECM terminal ②③ and ④③ (ground) and check the following:

FE
CL

- The voltage when accelerator pedal fully released is 0.3 - 0.7V.
- The voltage rise is linear in response to accelerator pedal depression.
- The voltage when accelerator pedal fully depressed is approximately 4V.

MT
AT
PD



RA
BR
ST

RS
BT




HA
EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0120

Throttle Position Sensor (DTC: 0403) (Cont'd)






EC-TPS-01



TROUBLE DIAGNOSIS FOR DTC P0120

Throttle Position Sensor (DTC: 0403) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
1. Turn ignition switch "OFF".
2. Disconnect throttle position sensor harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ① and ground with CONSULT or tester.
Voltage: Approximately 5V

NG → Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screw.
3. Check harness continuity between terminal ③ and engine ground.
Continuity should exist.
If OK, check harness for short.

NG → Check the following.
• Harness connectors (F4), (M64)
• Harness for open or short between ECM and throttle position sensor
• Harness for open or short between A/T control unit and throttle position sensor
If NG, repair harness or connectors.

C
CHECK INPUT SIGNAL CIRCUIT.
1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal ②③ and terminal ②.
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

ADJUST THROTTLE POSITION SENSOR.
Perform BASIC INSPECTION, EC-62.

CHECK COMPONENT
(Throttle position sensor).
Refer to "COMPONENT INSPECTION" on next page.

NG → Replace throttle position sensor. To adjust it, perform BASIC INSPECTION, EC-62.

Disconnect and reconnect harness connectors in the circuit. Then retest.


Trouble is not fixed.
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0120

Throttle Position Sensor (DTC: 0403) (Cont'd) COMPONENT INSPECTION




Throttle position sensor

1. Start engine and warm it up sufficiently.
2. Turn ignition switch "OFF".
3. Disconnect throttle position sensor harness connector.
4. Check resistance between terminals ② and ③ while opening throttle valve manually.

Throttle valve conditions	Resistance at 25°C (77°F)
Completely closed	Approximately 0.5 kΩ
Partially open	0.5 - 4.0 kΩ
Completely open	Approximately 4.0 kΩ

If NG, replace throttle position sensor.

To adjust throttle position sensor, perform "BASIC INSPECTION", EC-62.




SEF594K

Engine Coolant Temperature (ECT) Sensor (DTC: 0908)

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



SEF012P

<Reference data>

Engine coolant temperature °C (°F)	Voltage (V)	Resistance (kΩ)
-10 (14)	4.4	9.2
20 (68)	3.5	2.5
50 (122)	2.2	0.8
90 (194)	0.9	0.2

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0125 0908	<ul style="list-style-type: none"> • Rationally incorrect voltage from the sensor is sent to ECM, even when some time has passed after starting the engine. • Engine coolant temperature is insufficient for closed loop fuel control. 	<ul style="list-style-type: none"> • Harness or connectors (High resistance in the circuit) • Engine coolant temperature sensor • Thermostat


TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the engine coolant temperature sensor circuit. During this check, a DTC might not be confirmed.

Note: If both DTC P0115 (0103) and P0125 (0908) are displayed, first perform TROUBLE DIAGNOSIS FOR DTC P0115. (See EC-122.)



- 1) Turn ignition switch "ON".
- 2) Select "COOLANT TEMP/S" in "DATA MONITOR" mode with CONSULT.
- 3) Start engine and run it at idle speed.
- 4) Check that the engine coolant temperature rises to 25°C (77°F) or more within 15 minutes. (Be careful not to overheat engine.)

OR





- 1) Turn ignition switch "ON".
- 2) Select "MODE 1" with GST.
- 3) Start engine and run it at idle speed.
- 4) Check that the engine coolant temperature rises to 25°C (77°F) or more within 15 minutes. (Be careful not to overheat engine.)

OR




- 1) Turn ignition switch "ON".
- 2) Probe voltage meter between ECM terminal ⑤1 and ground.
- 3) Start engine and run it at idle speed.
- 4) Check that voltage of engine coolant temperature changes to less than 3.3 (V) within 15 minutes. (Be careful not to overheat engine.)





TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

EC-ECTS-01







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

DIAGNOSTIC PROCEDURE




TROUBLE DIAGNOSIS FOR DTC P0125

Engine Coolant Temperature (ECT) Sensor (DTC: 0908) (Cont'd)

COMPONENT INSPECTION

Engine coolant temperature sensor

Check resistance as shown in the figure.



Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.0
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX



Front Heated Oxygen Sensor (Front HO2S) (DTC: 0303)

The front HO2S is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0130 0303	<ul style="list-style-type: none"> • An excessively high voltage from the sensor is sent to ECM. • The voltage from the sensor is constantly approx. 0.3V. • The maximum and minimum voltages from the sensor do not reach the specified voltages. • The sensor does not respond between rich and lean within the specified time. 	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Front heated oxygen sensor • Fuel pressure • Injectors • Intake air leaks

TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (DTC: 0303) (Cont'd)

OVERALL FUNCTION CHECK




Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a DTC might not be confirmed.

- 1) Start engine and warm it up sufficiently.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
 - 5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.35V at least once.







- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeter probes between ECM terminal ④⑥ (sensor signal) and ④③ (engine ground).
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
 - Malfunction indicator lamp goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.35V at least one time.

TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (DTC: 0303) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A

CHECK INPUT SIGNAL CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal (46) and terminal (2).
Continuity should exist.
4. Check harness continuity between ECM terminal (46) (or terminal (2)) and ground.
Continuity should not exist.

NG

Repair harness or connectors.

OK

Loosen and retighten engine ground screws.

B

CLEAR THE SELF-LEARNING DATA

1. Start engine and warm it up sufficiently.
2. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode with CONSULT.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Are the DTCs P0171, P0172 detected? Is it difficult to start engine?

Yes

Go to "TROUBLE DIAGNOSIS FOR DTC P0171, P0172", EC-150, 155.

OR

2. Turn ignition switch "OFF" and wait at least 5 seconds.
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 3 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure diagnostic trouble code No. 0102 is displayed in Diagnostic Test Mode II.
6. Erase the diagnostic test mode II (Self-diagnostic results) memory. Make sure diagnostic trouble code No. 0505 is displayed in Diagnostic Test Mode II.
7. Run engine for at least 10 minutes at idle speed.
Are the DTCs 0114, 0115 detected? Is it difficult to start engine?

No

A

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0130

Front Heated Oxygen Sensor (Front HO2S) (DTC: 0303) (Cont'd)



COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals ③ and ①.

Resistance: 3.3 - 6.3Ω at 25°C (77°F)

Check continuity between terminals ② and ①, ③ and ②.

Continuity should not exist.

If NG, replace the front heated oxygen sensor.

CAUTION:


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

TROUBLE DIAGNOSIS FOR DTC P0130

Closed Loop Control (DTC: 0307)

- The closed loop control has one trip detection logic.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0130 0307	<ul style="list-style-type: none"> • The closed loop control function does not operate even when vehicle is driving in the specified condition. 	<ul style="list-style-type: none"> • The front heated oxygen sensor circuit is open or short. • Front heated oxygen sensor • Front heated oxygen sensor heater



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the closed loop control. During this check, a DTC might not be confirmed.

- 1) Start engine and warm it up sufficiently.
- 2) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT, and select "FR O2 SENSOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
 - "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.

5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 |
FR O2 MNTR R-L-R-L-R-L-R-L-R-L-R

R = "FR O2 MNTR", "RICH"
L = "FR O2 MNTR", "LEAN"

OR


- 1) Start engine and warm it up sufficiently.
- 2) Check that malfunction indicator lamp goes on more than 5 times in 10 seconds while keeping at 2,000 rpm in Diagnostic Test Mode II.

DIAGNOSTIC PROCEDURE

Refer to TROUBLE DIAGNOSIS FOR DTC P0130, EC-136.
Refer to TROUBLE DIAGNOSIS FOR DTC P0135, EC-142.

Front Heated Oxygen Sensor Heater (DTC: 0901)

SYSTEM DESCRIPTION



The ECM performs ON/OFF control of the front heated oxygen sensor heater corresponding to the engine conditions.

Engine speed (rpm)	Engine condition	Front heated oxygen sensor heater
Above 4,400	—	OFF
Below 4,400	Heavy load	OFF
	Except above	ON

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0135 0901	<ul style="list-style-type: none"> The current amperage in the front heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM through the front heated oxygen sensor heater.) 	<ul style="list-style-type: none"> Harness or connectors (The front heated oxygen sensor heater circuit is open or shorted.) Front heated oxygen sensor heater

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 5 seconds at idle speed.

OR



- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Select "MODE 3" with GST.

OR




- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P0135



Front Heated Oxygen Sensor Heater (DTC: 0901) (Cont'd)

EC-FRO2/H-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






Refer to last page (Foldout page).



TROUBLE DIAGNOSIS FOR DTC P0135

Front Heated Oxygen Sensor Heater (DTC: 0901) (Cont'd)

DIAGNOSTIC PROCEDURE



COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals ③ and ①.

Resistance: 3.3 - 6.3Ω at 25°C (77°F)


Check continuity between terminals ② and ①, ③ and ②.

Continuity should not exist.

If NG, replace the front heated oxygen sensor.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



Rear Heated Oxygen Sensor (Rear HO2S) (DTC: 0707)

The rear heated oxygen sensor (Rear HO2S), downstream three way catalyst, monitors the oxygen level in the exhaust gas. This sensor is made of ceramic titania, the electric resistance of which drastically changes at the ideal air-fuel ratio.

The output voltage of the sensor, depending on its resistance, is approximately 0 to 2.2V.

The ECM supplies the sensor with approximately 2V and then measures the output voltage depending on its resistance.

The rear heated oxygen sensor is not directly used to control the engine system.

It is used only for the on board diagnosis of three way catalyst.

ON BOARD DIAGNOSIS LOGIC

The rear heated oxygen sensor has a much longer switching time between rich and lean, due to the oxygen storage capacity of the up-stream three way catalyst. To judge the malfunctions of rear heated oxygen sensor, ECM monitors the sensor's voltage value and the switching response during the various driving condition such as fuel-cut.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0136 0707	<ul style="list-style-type: none"> An excessively high voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open.) Rear heated oxygen sensor
	<ul style="list-style-type: none"> The maximum and minimum voltages from the sensor are not reached to the specified voltages. It takes more time for the sensor to respond between rich and lean than the specified time. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is shorted.) Rear heated oxygen sensor Fuel pressure Injectors Intake air leaks

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

TROUBLE DIAGNOSIS FOR DTC P0136


Rear Heated Oxygen Sensor (Rear HO2S) (DTC: 0707) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a DTC might not be confirmed.




- 1) Start engine and warm it up sufficiently.
- 2) Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT.
- 3) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.
"RR O2 SENSOR" should be above 0.60V at least once when the "FUEL INJECTION" is +25%.
"RR O2 SENSOR" should be below 0.55V at least once when the "FUEL INJECTION" is -25%.



- OR
- 1) Start engine and warm it up sufficiently.
 - 2) Set voltmeter probes between ECM terminals 52 (sensor signal) and 43 (engine ground).
 - 3) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.
(depress and release accelerator pedal as soon as possible)
The voltage should be above 0.6V at least once.
If the voltage is above 0.6V at step 3, step 4 is not necessary.
 - 4) Check the voltage when racing up to 6,000 rpm under no load. Or keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be below 0.55V at least once.



Note: After starting the engine, the output voltage of the rear heated oxygen sensor indicates higher voltage (approx. 5V at highest) than the normal operating range for about 7 seconds. This is due to checking for open circuits in rear heated oxygen sensor by on board diagnosis. Therefore, if you measure the voltage (at ECM terminal 52) during this diagnosis, the higher voltage will appear. (CONSULT will also show the higher voltage, GST may show approx. 0V.) This is not a malfunction even though it is out of the normal range.



TROUBLE DIAGNOSIS FOR DTC P0136


Rear Heated Oxygen Sensor (Rear HO2S) (DTC: 0707) (Cont'd)

EC-RRO2-01



Refer to last page (Foldout page).






M63, F3



TROUBLE DIAGNOSIS FOR DTC P0136

Rear Heated Oxygen Sensor (Rear HO2S) (DTC: 0707) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
1. Turn ignition switch "OFF".
2. Disconnect rear heated oxygen sensor harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal (52) and terminal (b).
Continuity should exist.
4. Check harness continuity between ECM terminal (52) (or terminal (b)) and ground.
Continuity should not exist.

NG → Repair harness or connectors.

OK
Loosen and retighten engine ground screws.

B
CHECK POWER SUPPLY.
1. Disconnect rear heated oxygen sensor harness connector.
2. Turn ignition switch "ON".
3. Check voltage between terminal (c) and ground.
Voltage: Battery voltage

NG → Repair harness or connectors.

C
CHECK GROUND CIRCUIT.
1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between terminal (a) and ECM terminal (108).
Continuity should exist.
If OK, check harness for short.

NG → Check the following.
• Harness connectors (F208), (F11)
• Harness for open or short between rear heated oxygen sensor and ECM
If NG, repair harness or connectors.

D
CHECK GROUND CIRCUIT.
Check harness continuity between ECM terminal (111) and ground.
Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

CHECK COMPONENT
(Rear heated oxygen sensor heater). Refer to "COMPONENT INSPECTION" on next page.

NG → Replace rear heated oxygen sensor.

OK
Disconnect and reconnect harness connectors in the circuit. Then retest.

↓ Trouble is not fixed.
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

TROUBLE DIAGNOSIS FOR DTC P0136

Rear Heated Oxygen Sensor (Rear HO2S) (DTC: 0707) (Cont'd)

COMPONENT INSPECTION

Rear heated oxygen sensor heater


Check resistance between terminals (a) and (c).

Resistance: 5.2 - 8.2Ω at 25°C (77°F)

If NG, replace heated oxygen sensor.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


Fuel Injection System Function (Lean side) (DTC: 0115)

ON BOARD DIAGNOSIS LOGIC

With Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large, the ECM judges the condition as the fuel system malfunction and light up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0171 0115	<ul style="list-style-type: none"> • Fuel injection system does not operate properly. • The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> • Intake air leak • Front heated oxygen sensor • Injectors • Exhaust gas leak • Incorrect fuel pressure • Lack of fuel • Mass air flow sensor



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- 6) Start engine again and run it for at least 10 minutes at idle speed.
The DTC should be detected at this stage, if a malfunction exists.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.

OR

TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Lean side) (DTC: 0115) (Cont'd)



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0102 is detected.
- 6) Erase the DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 8) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0115 should be detected at this stage, if a malfunction exists.
- 9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX



TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Lean side) (DTC: 0115) (Cont'd)

EC-FUEL-01







Refer to last page (Foldout page).



TROUBLE DIAGNOSIS FOR DTC P0171

Fuel Injection System Function (Lean side) (DTC: 0115) (Cont'd)





DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0171


Fuel Injection System Function (Lean side) (DTC: 0115) (Cont'd)




**Fuel Injection System Function (Rich side)
(DTC: 0114)**

ON BOARD DIAGNOSIS LOGIC

With Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large, the ECM judges the condition as the fuel system malfunction and light up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0172 0114	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> Front heated oxygen sensor Injectors Exhaust gas leak Incorrect fuel pressure Mass air flow sensor



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- 6) Start engine again and run it for at least 10 minutes at idle speed.
The DTC P0172 should be detected at this stage, if a malfunction exists.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.


OR

- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0102 is detected.
- 6) Erase the DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 8) Start engine again and run it for at least 10 minutes at idle speed.
The DTC 0114 should be detected at this stage, if a malfunction exists.
- 9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction.

TROUBLE DIAGNOSIS FOR DTC P0172


Fuel Injection System Function (Rich side) (DTC: 0114) (Cont'd)

EC-FUEL-01



Refer to last page (Foldout page).




(E109), (M9)
(M63), (F3)



TROUBLE DIAGNOSIS FOR DTC P0172

Fuel Injection System Function (Rich side) (DTC: 0114) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK EXHAUST AIR LEAK.
Start engine and run it at idle. Listen for the sound of the exhaust air leak upstream three way catalyst.

NG → Repair or replace.

OK

CHECK INTAKE AIR LEAK.
Start engine and run it at idle. Listen for the sound of the intake air leak downstream mass air flow sensor.

NG → Repair or replace.

OK

B
CHECK FRONT HEATED OXYGEN SENSOR.
1. Turn ignition switch "OFF".
2. Disconnect front heated oxygen sensor harness connector and ECM harness connector.
3. Check harness continuity between ECM terminal (46) and terminal (2).
Continuity should exist.
4. Check harness continuity between ECM terminal (46) (or terminal (2)) and ground.
Continuity should not exist.

NG → Repair harness or connectors.

OK

CHECK FUEL PRESSURE.
1. Release fuel pressure to zero. Refer to page EC-24.
2. Install fuel pressure gauge and check fuel pressure.
At idle:
Approx. 235 kPa (2.4 kg/cm², 34 psi)
A few seconds after ignition switch is turned OFF to ON:
Approx. 294 kPa (3.0 kg/cm², 43 psi)

NG → Check fuel pump and circuit. Refer to EC-301.

OK

CHECK MASS AIR FLOW SENSOR.
Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.
1.5 - 4.5 gm/sec: at idling
6.0 - 14.0 gm/sec: at 2,500 rpm
OR
Check "mass air flow" in MODE 1 with GST.
1.5 - 4.5 gm/sec: at idling
6.0 - 14.0 gm/sec: at 2,500 rpm

NG → Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-105.



OK

(A)



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0172

Fuel Injection System Function (Rich side) (DTC: 0114) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P0180



Tank Fuel Temperature Sensor (DTC: 0402)

The tank fuel temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

Fluid temperature °C (°F)	Voltage (V)	Resistance (kΩ)
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Causes)
P0180 0402	<ul style="list-style-type: none"> An excessively high or low voltage is sent to ECM. Rationally incorrect voltage is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor. 	<ul style="list-style-type: none"> Harness or connectors (the sensor circuit is open or shorted.) Tank fuel temperature sensor




DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch "ON".
 - 2) Select "DATA MONITOR" mode with CONSULT.
 - 3) Wait at least 12 seconds.
- OR
- 1) Turn ignition switch "ON" and wait at least 12 seconds.
 - 2) Select "MODE 3" with GST.
- OR
- 1) Turn ignition switch "ON" and wait at least 12 seconds.
 - 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 - 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0180

Tank Fuel Temperature Sensor (DTC: 0402) (Cont'd)






EC-TFTS-01



TROUBLE DIAGNOSIS FOR DTC P0180

Tank Fuel Temperature Sensor (DTC: 0402) (Cont'd)

DIAGNOSTIC PROCEDURE



COMPONENT INSPECTION

Tank fuel temperature sensor

Check resistance as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90


If NG, replace tank fuel temperature sensor.

No. 4 - 1 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0605)

ON BOARD DIAGNOSIS LOGIC

If a misfire occurs, the engine speed will fluctuate. If the fluctuation is detected by the crankshaft position sensor (OBD), the misfire is diagnosed.

The misfire detection logic consists of the following two conditions.



1. One Trip Detection Logic (Three Way Catalyst Damage)

When a misfire is detected which will overheat and damage the three way catalyst, the malfunction indicator lamp (MIL) will start blinking; even during the first trip. In this condition, ECM monitors the misfire every 200 revolutions.

If the misfire frequency decreases to a level that will not damage the three way catalyst, the MIL will change from blinking to lighting up.


(After the first trip detection, the MIL will light up from engine starting. If a misfire is detected that will cause three way catalyst damage, the MIL will start blinking.)

2. Two Trip Detection Logic (Exhaust quality deterioration)


When a misfire that will not damage the three way catalyst (but will affect exhaust emission) occurs, the malfunction indicator lamp will light up based on the second consecutive trip detection logic. In this condition, ECM monitors the misfire for every 1,000 revolutions of the engine.

Diagnostic Trouble Code Nos.	Malfunction is detected when ...	Check Items (Possible Cause)
P0300 (0701)	• Multiple cylinders misfire.	• Improper spark plug • Insufficient compression
P0301 (0608)	• No. 1 cylinder misfires.	• Incorrect fuel pressure • EGR valve
P0302 (0607)	• No. 2 cylinder misfires.	• The injector circuit is open or shorted. • Injectors
P0303 (0606)	• No. 3 cylinder misfires.	• Intake air leak • The ignition secondary circuit is open or shorted.
P0304 (0605)	• No. 4 cylinder misfires.	• Lack of fuel • Magnetized flywheel (drive plate)


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)

-  1) Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT.
 2) Start engine and warm it up sufficiently.
 3) Turn ignition switch "OFF" and wait at least 3 seconds.
 4) Start engine again and drive at 1,500 - 3,000 rpm for at least 8 minutes.

OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 3 seconds.
 3) Start engine again and drive at 1,500 - 3,000 rpm for at least 8 minutes.
 4) Select "MODE 3" with GST.







OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 3 seconds.
 3) Start engine again and drive at 1,500 - 3,000 rpm for at least 8 minutes.
 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0300 - P0304

No. 4 - 1 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0605) (Cont'd)



DIAGNOSTIC PROCEDURE



CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

TROUBLE DIAGNOSIS FOR DTC P0300 - P0304

No. 4 - 1 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0605) (Cont'd)



(A)

E
CHECK SPARK PLUGS.
 Remove the spark plugs and check for fouling, etc.

NG → Repair or replace spark plug(s).

OK

F
CHECK FUEL PRESSURE.
 1. Release fuel pressure to zero. (Refer to page EC-24.)
 2. Install fuel pressure gauge and check fuel pressure.
At idle:
Approx. 235 kPa (2.4 kg/cm², 34 psi)

NG → Check fuel pump and circuit.

OK

CHECK COMPRESSION PRESSURE.
 • Check compression pressure.
Standard:
kPa (kg/cm², psi)/300 rpm
1,236 (12.6, 179)
Minimum:
kPa (kg/cm², psi)/300 rpm
1,040 (10.6, 151)
Difference between each cylinder:
kPa (kg/cm², psi)/300 rpm
98 (1.0, 14)



NG → Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

OK

CHECK IGNITION TIMING.
 Perform BASIC INSPECTION, EC-62.

NG → Adjust ignition timing.

OK

CHECK MASS AIR FLOW SENSOR.
 Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT.
1.5 - 4.5 gm/sec: at idling
6.0 - 14.0 gm/sec: at 2,500 rpm
 OR
 Check "mass air flow" in MODE 1 with GST.
1.5 - 4.5 gm/sec: at idling
6.0 - 14.0 gm/sec: at 2,500 rpm


NG → Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-105. If NG, repair or replace it.

OK


(Go to (B) on next page)

TROUBLE DIAGNOSIS FOR DTC P0300 - P0304

No. 4 - 1 Cylinder Misfire, Multiple Cylinder Misfire (DTC: 0701 - 0605) (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



COMPONENT INSPECTION

Ignition wires


1. Inspect wires for cracks, damage, burned terminals and for improper fit.
2. Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance:

13.6 - 18.4 kΩ/m (4.15 - 5.61 kΩ/ft) at 25°C (77°F)

If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

TROUBLE DIAGNOSIS FOR DTC P0325



Knock Sensor (KS) (DTC: 0304)

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

*** Freeze frame data will not be stored in the ECM for the knock sensor. The MIL will not light for knock sensor malfunction.**

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0325 0304	<ul style="list-style-type: none"> • An excessively low or high voltage from the knock sensor is sent to ECM. 	<ul style="list-style-type: none"> • Harness or connectors (The knock sensor circuit is open or shorted.) • Knock sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: Before performing the following procedure, confirm that battery voltage is more than 10V.



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 5 seconds at idle speed.

OR



- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Select "MODE 3" with GST.

OR






- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0325

Knock Sensor (KS) (DTC: 0304) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

Loosen and retighten engine ground screws.

A
CHECK INPUT SIGNAL CIRCUIT.
1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and knock sensor sub-harness connector.
3. Check harness continuity between terminal (b) and ECM terminal (54).
Continuity should exist.

NG → Check the following.
• Harness connectors
• (F26), (F61)
• Harness for open or short between ECM and knock sensor
If NG, repair harness or connectors.

Check harness continuity between knock sensor and knock sensor sub-harness connector

NG → Repair harness or connectors.


CHECK COMPONENT (Knock sensor). Refer to "COMPONENT INSPECTION" below.

NG → Replace knock sensor.

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END





COMPONENT INSPECTION

Knock sensor

1. Disconnect knock sensor harness connector.
2. Check continuity between terminal (a) and ground.
Resistance: 500 - 620 kΩ [at 25°C (77°F)]
• It is necessary to use an ohmmeter which can measure more than 10 MΩ.

CAUTION:
Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



**Crankshaft Position Sensor (CKPS) (OBD)
(DTC: 0802)**

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil. When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis of misfire.

GI
MA
EM
LC
EC

FE
CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0335 0802	<ul style="list-style-type: none"> The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	<ul style="list-style-type: none"> Harness or connectors (The crankshaft position sensor (OBD) circuit is open.) Crankshaft position sensor (OBD)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
2) Start engine and run it for at least 15 seconds at idle speed.

OR

- 1) Start engine and run it for at least 15 seconds at idle speed.
2) Select "MODE 3" with GST.




OR

- 1) Start engine and run it for at least 15 seconds at idle speed.
2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0335

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802) (Cont'd)





EC-CKPS-01



TROUBLE DIAGNOSIS FOR DTC P0335

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802) (Cont'd)

DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0335



Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0802) (Cont'd)

COMPONENT INSPECTION

Crankshaft position sensor (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.
5. Check resistance as shown in the figure.
Resistance: Approximately $166.5 - 203.5\Omega$ at 20°C (68°F)





Camshaft Position Sensor (CMPS)(DTC: 0101)

The camshaft position sensor is a basic component of the ECCS. It monitors engine speed and piston position. These input signals to the ECM are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° signal and 4 slits for a 180° signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.


The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Diagnostic Trouble Code No.	Malfunction is detected when	Check items (Possible cause)
P0340 0101	<ul style="list-style-type: none"> • Either 1° or 180° signal is not sent to ECM for the first few seconds during engine cranking. • Either 1° or 180° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed. • The relation between 1° and 180° signal is not in the normal range during the specified engine speed. 	<ul style="list-style-type: none"> • Harness or connectors (The camshaft position sensor circuit is open or shorted.) • Camshaft position sensor • Starter motor (Refer to EL section.) • Starting system circuit (Refer to EL section.) • Dead (Weak) battery

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: Before performing the following procedure, confirm that battery voltage is more than 10.5V.

- 
 - 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
 - 2) Crank engine for at least 2 seconds.
- OR



 - 1) Crank engine for at least 2 seconds.
 - 2) Select "MODE 3" with GST.
- OR


 - 1) Crank engine for at least 2 seconds.
 - 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 - 3) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P0340


Camshaft Position Sensor (CMPS)(DTC: 0101) (Cont'd)

EC-CMPS-01



Refer to last page (Foldout page).






- E109, M9
- M63, F3



TROUBLE DIAGNOSIS FOR DTC P0340

Camshaft Position Sensor (CMPS)(DTC: 0101) (Cont'd)

DIAGNOSTIC PROCEDURE (DETECTABLE CIRCUIT)






GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0340

Camshaft Position Sensor (CMPS)(DTC: 0101) (Cont'd)

DIAGNOSTIC PROCEDURE (NON-DETECTABLE CIRCUIT)



COMPONENT INSPECTION

Camshaft position sensor


1. Start engine
2. Check voltage between terminals ③, ④ and ground with AC range.

Condition	Terminals	Voltage
Engine running at idle	③ and ground ④ and ground	Approximately 2.7V* (AC)

*: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


If NG, replace distributor assembly with camshaft position sensor.

3. Visually check signal plate for damage or dust.



EGR Function (DTC: 0302)

SYSTEM DESCRIPTION




GI
MA
EM
LC
EC

This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve. This causes the port vacuum to be discharged into the atmosphere and the EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- Engine stopped
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction


FE
CL
MT



AT
PD
FA
RA

SEF641Q

BR
ST
RS



SEF783K

COMPONENT DESCRIPTION

Exhaust gas recirculation (EGR) valve

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.

BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

EGRC-solenoid valve

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve).

When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve.



ON BOARD DIAGNOSIS LOGIC

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0400 0302	A) The exhaust gas recirculation (EGR) flow is excessively low during the specified driving condition.	<ul style="list-style-type: none"> • EGR valve stuck closed • EGRC-BPT valve leaking • Passage blocked • EGRC-solenoid valve • Tube leaking for EGR valve • EGR temperature sensor
	B) The exhaust gas recirculation (EGR) flow is excessively high during the specified driving condition.	<ul style="list-style-type: none"> • EGRC-solenoid valve • EGR valve leaking or stuck open • EGR temperature sensor

OVERALL FUNCTION CHECK

Use this procedure to check the overall EGR function. During this check, a DTC might not be confirmed.

Before starting with the following procedure, check the engine coolant temperature of the freeze frame data with CONSULT or Generic Scan Tool.

If the engine coolant temperature is higher than or equal to 60°C (140°F), perform only "Procedure for malfunction A".

If the engine coolant temperature is lower than 60°C (140°F), perform both "Procedure for malfunction A" and "Procedure for malfunction B". In this case, check DTCs in the ECM and perform inspections one by one based on "INSPECTION PRIORITY", EC-82.




TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)



Procedure for malfunction A

- 1) Start engine and warm it up sufficiently.
- 2) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should lift up and down without sticking.
- 3) Disconnect EFI (EGR temperature sensor) sub-harness connector.
- 4) Check voltage between EGR temperature sensor sub-harness connector terminal ② and ground at idle speed.
Less than 4.5V should exist.
- 5) Turn ignition switch "OFF".
Check harness continuity between EGR temperature sensor sub-harness connector terminal ⑥ and ECM terminal ⑤0.
Continuity should exist.
- 6) Perform "COMPONENT INSPECTION", "EGR temperature sensor", EC-184.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Overall function check




Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.

SEF642Q

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

Procedure for malfunction B



- 1) Start engine.
- 2) Turn EGRC-solenoid valve "ON" in "ACTIVE TEST" mode with CONSULT.
- 3) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.

EGR valve should be closed and should not lift up.

OR


- 1) Confirm the engine coolant temperature is lower than 55°C (131°F) in "Mode 1" with generic scan tool. Perform the following steps before its temperature becomes higher than 55°C (131°F).
- 2) Start engine.
- 3) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.

EGR valve should be closed and should not lift up.



OR

- 1) Confirm the voltage between ECM terminals (51) and (43) is higher than 2.08V. Perform the following steps before the voltage becomes lower than 2.08V.
- 2) Start engine.
- 3) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.

EGR valve should be closed and should not lift up.



Overall function check




Check the EGR valve lifting when revving engine from 2,000 rpm up to 4,000 rpm.

SEF642Q


TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

EC-EGRC1-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX







Refer to last page (Foldout page).
M63, F3

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)

DIAGNOSTIC PROCEDURE






INSPECTION START

A
CHECK VACUUM SOURCE TO EGR VALVE.
 1. Start engine and warm it up sufficiently.
 2. Race engine speed at about 2,000 - 4,000 rpm.
 3. Disconnect vacuum hose to EGR valve.
 4. Make sure that vacuum exists.
Vacuum should exist.

OK → **CHECK COMPONENTS (EGR valve).**
 Refer to "COMPONENT INSPECTION", EC-184.
 ↓ NG
 Replace malfunctioning component(s).

↓ NG
B
CHECK VACUUM HOSE.
 Check vacuum hose for clogging, cracks or improper connection.


↓ NG
C
CHECK COMPONENT (EGRC-solenoid valve).
 1. Turn ignition switch "ON".
 2. Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.
 OR
 1. Turn ignition switch "ON".
 2. Turn EGRC-solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound.
 OR
 1. Warm up engine sufficiently.
 2. Turn ignition switch "OFF" and wait at least 5 seconds.
 3. Turn ignition switch "ON".
 4. Check operating sound of the solenoid valve when depressing and fully releasing accelerator pedal.

NG → Repair or replace EGRC-solenoid valve or repair circuit.

↓ OK
 (A)

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0400

EGR Function (DTC: 0302) (Cont'd)



COMPONENT INSPECTION

EGR valve

Apply vacuum to EGR valve vacuum port with a hand vacuum pump.

EGR valve spring should lift.

If NG, replace EGR valve.



EGRC-solenoid valve

Check solenoid valve, following the table as shown below:

Conditions	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes



If NG, replace the solenoid valve.

EGR temperature sensor

Check resistance change and resistance value.

EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10


If NG, replace EGR temperature sensor.



EGRC-BPT valve

1. Plug one of two ports of EGRC-BPT valve.
2. Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.
3. If a leakage is noted, replace the valve.

EGRC-BPT Valve Function (DTC: 0306)



SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

ON BOARD DIAGNOSIS LOGIC

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0402 0306	<ul style="list-style-type: none"> The EGRC-BPT valve does not operate properly. 	<ul style="list-style-type: none"> EGRC-BPT valve Misconnected rubber tube Blocked rubber tube



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a DTC might not be confirmed.

1. Disconnect the rubber tube to the fuel pressure regulator at the intake manifold.
2. Disconnect the rubber tube to the EGRC-solenoid valve at the EGRC-BPT valve. Connect the intake manifold and the EGRC-BPT valve with a rubber tube that has 1 mm (0.04 in) dia. orifice installed. (The intake manifold vacuum will be directly applied to the EGRC-BPT valve.)
3. Start engine.
4. Check for the EGR valve lifting with engine at less than 1,500 rpm under no load.
EGR valve should remain closed.
5. Check the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.
EGR valve should lift up, and go down without sticking when the engine is returned to idle.
6. Check rubber tube between EGRC-solenoid valve and throttle body for misconnection, cracks or blockages.

TROUBLE DIAGNOSIS FOR DTC P0402

EGRC-BPT Valve Function (DTC: 0306) (Cont'd)




COMPONENT INSPECTION

EGRC-BPT valve

- 1) Plug one of two ports of EGRC-BPT valve.
- 2) Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve.
Leakage should exist.

Three Way Catalyst Function (DTC: 0702)

ON BOARD DIAGNOSIS LOGIC



The ECM monitors the switching frequency ratio of front heated oxygen sensor and rear heated oxygen sensor.

A warm-up three way catalyst with high oxygen storage capacity will indicate a low switching frequency of rear heated oxygen sensor. As oxygen storage capacity decreases, the rear heated oxygen sensor switching frequency will increase.

When the frequency ratio of front heated oxygen sensor and rear heated oxygen sensor approaches a specified limit value, the second stage diagnosis is applied.

The second stage diagnosis switches the mixture ratio feedback control using front heated oxygen sensor to rear heated oxygen sensor.

Then ECM measures the switching lag time between front heated oxygen sensor and rear heated oxygen sensor.


The longer lag time indicates the greater oxygen storage capacity. If the lag time is within the specified level, the warm-up three way catalyst malfunction is diagnosed.

- The warm-up three way catalyst function has one trip detection logic.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P0420 0702	<ul style="list-style-type: none"> • Warm-up three way catalyst does not operate properly. • Warm-up three way catalyst does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> • Warm-up three way catalyst • Exhaust tube • Intake air leak • Injectors • Injector leak

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the warm-up three way catalyst. During this check, a DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- 2) Set "MANU TRIG" and "HI SPEED", then select "FR O2 SENSOR", "RR O2 SENSOR", "FR O2 MNTR", "RR O2 MNTR" in "DATA MONITOR" mode with CONSULT.
- 3) Touch "RECORD" on CONSULT screen with engine speed held at 2,000 rpm constant under no load.
- 4) Make sure that the switching frequency between "RICH" and "LEAN" of "RR O2 SENSOR" is very less than that of "FR O2 SENSOR".

Switching frequency ratio =

Rear heated oxygen sensor switching frequency

Front heated oxygen sensor switching frequency


This ratio should be less than 0.8.

If the ratio is greater than 0.8, the warm-up three way catalyst is not operating properly.

OR

TROUBLE DIAGNOSIS FOR DTC P0420

Three Way Catalyst Function (DTC: 0702) (Cont'd)



- 1) Start engine and warm it up sufficiently.
- 2) Set voltmeter probes between ECM terminals ④⑥ (front heated oxygen sensor signal) and ④③ (engine ground), and ECM terminals ⑤② (rear heated oxygen sensor signal) and ④③ (engine ground).
- 3) Keep engine speed at 2,000 rpm constant under no load.
- 4) Make sure that the voltage switching frequency (high & low) between ECM terminals ⑤② and ④③ is very less than that of ECM terminals ④⑥ and ④③.

Switching frequency ratio =

Rear heated oxygen sensor voltage switching frequency

Front heated oxygen sensor voltage switching frequency

This ratio should be less than 0.8.




If the ratio is greater than 0.8, it means warm-up three way catalyst does not operate properly.

Note: If the voltage at terminal ④⑥ does not switch periodically more than 5 times within 10 seconds at step 3, perform TROUBLE DIAGNOSIS FOR DTC P0130 (Front heated oxygen sensor) first. (See page EC-136.)

TROUBLE DIAGNOSIS FOR DTC P0420

Three Way Catalyst Function (DTC: 0702) (Cont'd)

DIAGNOSTIC PROCEDURE



GI
MA
EM
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705)

ON BOARD DIAGNOSIS LOGIC

This diagnosis uses two methods to detect leaks in the EVAP purge line.

The first method, the pressure test, makes use of vapor pressure in the fuel tank. The second method, the vacuum test, makes use of engine intake manifold vacuum.

Pressure test


The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank.

If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge control valve. If no pressure does not increase, the ECM will perform the "Vacuum test".

Vacuum test

If pressure does not increase in the "Pressure test", the ECM will check for leaks in the line between the fuel tank and EVAP canister purge control valve, under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control valve and EVAP canister purge control valve are opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge control valve and EVAP canister purge volume control valve will be closed.




TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0440 0705	<ul style="list-style-type: none"> • EVAP control system has a leak. • EVAP control system does not operate properly. 	<ul style="list-style-type: none"> • Incorrect fuel tank vacuum relief valve • Incorrect fuel filler cap used • Fuel filler cap remains open or fails to close. • Foreign matter caught in fuel filler cap. • Leak is in line between intake manifold and EVAP canister purge control valve. • Foreign matter caught in EVAP canister vent control valve. • EVAP canister or fuel tank leaks • EVAP purge line (pipe and rubber tube) leaks • EVAP purge line rubber tube bent. • Blocked or bent rubber tube to EVAP control system pressure sensor • Loose or disconnected rubber tube • EVAP canister purge control valve • EVAP canister purge volume control valve • EVAP canister purge control solenoid valve • Absolute pressure sensor • Tank fuel temperature sensor • MAP/BARO switch solenoid valve • Blocked or bent rubber tube to MAP/BARO switch solenoid valve

CAUTION:

- Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine rubber tube as a replacement.



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



CAUTION:

Always select "SINGLE TEST" with CONSULT when performing the "FUNCTION TEST".

- 1) Select "EVAP (SMALL LEAK)" in "FUNCTION TEST" mode with CONSULT.
- 2) Make sure that "OK" is displayed with "EVAP (SMALL LEAK)". (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".)
- 3) Check fuel filler cap and fuel tank when the fuel tank is more than 3/4 full.
Refer to "DIAGNOSTIC PROCEDURE", EC-193.

TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EVAP control system (Small leak). During this check, a DTC might not be confirmed.

NOTE:

Prepare one-way valve (Part No. 14958 V6700) for this test.



- 1) Turn ignition switch "OFF".
- 2) Completely fill fuel tank.
- 3) Set up one-way valve (Part No. 14958 V6700), pressure gauge and suitable pump as shown at left. Pressurize the system to 13.3 kPa (100 mmHg, 3.94 inHg, 1.93 psi). Measure the amount of depressurization in kPa (mmHg, inHg) after one minute with the system left unattended.
- 4) Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12V until the end of test.)
- 5) Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
- 6) Disconnect rubber tube between vacuum cut valve and EVAP shut valve. Set up one-way valve (Part No. 14958 V6700), pressure gauge and suitable pump as shown at left.
- 7) Increase system pressure until gauge registers 13.3 kPa (100 mmHg, 3.94 inHg, 1.93 psi). [If pump is rated at a discharge volume of 0.13ℓ (1/8 US qt, 1/8 Imp qt) for one operating stroke, it is capable of increasing pressure to 13.3 kPa (100 mmHg, 3.94 inHg, 1.93 psi) with approximately 60 operating strokes. If pressure does not increase at all during the test, diagnosis will be ineffective ("NG").]





CAUTION:

Do not allow pump pressure to exceed 13.3 kPa (100 mmHg, 3.94 inHg, 1.93 psi). A higher pressure may damage fuel tank and EVAP canister.

- 8) Make sure that after one minute the amount of pressure recovery is within the following.

The measured amount in step 3 + 4.51 kPa (33.87 mmHg, 1.333 inHg, 0.654 psi).







- 9) Check fuel filler cap and fuel tank. Refer to "DIAGNOSTIC PROCEDURE", EC-193.



TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)







DIAGNOSTIC PROCEDURE



G
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)



Ⓑ

1 **CHECK EVAP PURGE LINE.**
 Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks. Refer to "EVAPORATIVE EMISSION SYSTEM, EC-21."
 To locate cracked areas, apply soapy water to locations in question. Apply pump pressure as shown in the figure at left. Air bubbles will appear from cracked areas.
CAUTION:
Do not allow pump pressure to exceed 13.3 kPa (100 mmHg, 3.94 inHg, 1.93 psi). A higher pressure may damage fuel tank and EVAP canister.

- Do not use super color check liquid, etc.
- Do not depressurize inside EVAP purge line.

1. Turn ignition switch "OFF".
2. Apply 12 volts DC to EVAP canister vent control valve. The valve will close. (Continue to apply 12V until the end of test.)
3. Apply 12 volts DC to vacuum cut valve bypass valve. The valve will open. (Continue to apply 12V until the end of test.)
4. Disconnect rubber tube between vacuum cut valve and EVAP shut valve. Set up one-way valve (Part No. 14958 V6700), pressure gauge and suitable pump as shown at left.

NG → Repair or replace it.

OK

Clean EVAP purge line (pipe and rubber tube) using air blower.

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Evaporative Emission (EVAP) Control System
(Small Leak) (DTC: 0705) (Cont'd)

COMPONENT INSPECTION

EVAP canister purge volume control valve



1. Disconnect EVAP canister purge volume control valve harness connector.
2. Check resistance between the following terminals.
terminal ② and terminals ①, ③
terminal ⑤ and terminals ④, ⑥

Resistance:

Approximately 30Ω [At 25°C (77°F)]

3. Reconnect EVAP canister purge volume control valve harness connector.
4. Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
(Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
5. Turn ignition switch "ON".
6. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.
If NG, replace the EVAP canister purge volume control valve.

OR




1. Disconnect EVAP canister purge volume control valve harness connector.
2. Check resistance between the following terminals.
terminal ② and terminals ①, ③
terminal ⑤ and terminals ④, ⑥


Resistance:

Approximately 30Ω [At 25°C (77°F)]


3. Reconnect EVAP canister purge volume control valve harness connector.
4. Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
(Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
5. Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
If NG, replace the EVAP canister purge volume control valve.




SEF353Q



SEF507R



SEF763P




SEF482R

TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)

EVAP canister purge control solenoid valve

Check air passage continuity.



Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL


IDX



EVAP canister purge control valve

Check EVAP canister purge control valve as follows:

1. Blow air in port (A), (B) and (C), and check that there is no leakage.
2. Apply vacuum to port (A). [Approximately -13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg)]
Blow air in port (C) and check that it flows freely out of port (B).




EVAP canister vent control valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals (1) and (2)	No
No supply	Yes

If NG, clean valve using air blower or replace as necessary.



Absolute pressure sensor

1. Remove absolute pressure sensor from bracket with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch "ON" and check output voltage between terminal (2) and engine ground.
The voltage should be 3.2 to 4.8 V.
4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg, -3.87 psi) to absolute pressure sensor as shown in figure and check the output voltage.
The voltage should be 1.0 to 1.4 V lower than the value measured in step 3.


TROUBLE DIAGNOSIS FOR DTC P0440

Evaporative Emission (EVAP) Control System (Small Leak) (DTC: 0705) (Cont'd)


CAUTION:

Always calibrate the vacuum pump gauge when using it.


5. If NG, replace absolute pressure sensor.




SEF500R



SEF498R



MEC488B



SEF651Q

MAP/BARO switch solenoid valve

1. Start engine and warm it up sufficiently.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
3. Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
4. If NG, replace solenoid valve.

OR

1. Remove MAP/BARO switch solenoid valve.
2. Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

3. If NG, replace solenoid valve.

Tank fuel temperature sensor


Check resistance as shown in the figure.

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

If NG, replace tank fuel temperature sensor.


Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807)

SYSTEM DESCRIPTION



This system controls the vacuum signal applied to the EVAP canister purge control valve. When the ECM detects any of the following conditions, current does not flow through the EVAP canister purge control solenoid valve. The solenoid valve cuts the vacuum signal so that the EVAP canister purge control valve remains closed.

- Ignition switch "ON"
- Closed throttle position
- Low or high engine coolant temperature
- During deceleration
- Engine stopped
- Low vehicle speed (M/T models)




COMPONENT DESCRIPTION

EVAP canister purge control solenoid valve

The EVAP canister purge control solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal (from the intake manifold to the EVAP canister purge control valve) is cut.

When the ECM sends an ON (ground) signal, the vacuum signal passes through the EVAP canister purge control solenoid valve. The signal then opens the EVAP canister purge control valve.



EVAP canister purge control valve

When the vacuum signal is cut by EVAP canister purge control solenoid valve, EVAP canister purge control valve closes.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0443

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)

EVAPORATIVE EMISSION SYSTEM DIAGRAM



Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0443 0807	A) The improper voltage signal is sent to ECM through EVAP canister purge control solenoid valve. B) EVAP canister purge control valve does not operate properly (stuck open).	<ul style="list-style-type: none"> • Harness or connectors (The EVAP canister purge control solenoid valve circuit is open or shorted.) • EVAP canister purge control solenoid valve • EVAP canister purge control valve • EVAP canister purge control solenoid valve • Vacuum hoses for clogging or disconnection • EVAP control system pressure sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the DTC cannot be confirmed, perform "Procedure for malfunction B" on next page.

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.

OR



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 3" with GST.


OR



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0443

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)



Procedure for malfunction B

- 1) Jack up drive wheels.
- 2) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up until the engine coolant temperature rises to 60 to 80°C (140 to 176°F), then stop engine. (If the engine coolant temperature exceeds the above range, stop engine and wait until the temperature cools down to within this range.)
- 4) Start engine and let it idle for at least 70 seconds.
- 5) Maintain the following conditions for at least 30 seconds.

Gear position:

"2" or "D" range (A/T)

"3rd" or "4th" gear (M/T)

Vehicle speed:

40 - 80 km/h (25 - 50 MPH)

Engine speed:

1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)

ENGINE SPD	825RPM
COOLANT TEMP	69°C
VEHICLE SPD	0MPH
IGN ADVANCE	8.0°
CALC LOAD	28.2%
MAP	36KPaA
MAF	5.20gm/s
THROTTLE POS	0.0%
INTAKE AIR	27°C
FUEL SYS #1	OLDRIVE
FUEL SYS #2	UNUSED
SHORT FT #1	0.8%
LONG FT #1	0.0%
O2S B1 S1	0.200V
O2FT B1 S1	0.8%
O2S B1 S2	0.010V

SEF519R



- 1) Jack up drive wheels.
- 2) Turn ignition switch "ON" and select "MODE 1" mode with GST.
- 3) Start engine and warm it up until the engine coolant temperature rises to 60 to 80°C (140 to 176°F), then stop engine. (If the engine coolant temperature exceeds the above range, stop engine and wait until the temperature cools down to within this range.)
- 4) Start engine and let it idle for at least 70 seconds.
- 5) Maintain the following conditions for at least 30 seconds.

Gear position:

"2" or "D" range (A/T)

"3rd" or "4th" gear (M/T)

Vehicle speed:

40 - 80 km/h (25 - 50 MPH)


Engine speed:

1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)

- 6) Select "MODE 3" mode with GST.



- 1) Jack up drive wheels.
- 2) Turn ignition switch "ON".
- 3) Start engine and warm it up until the voltage between ECM terminal ⑤ and ground drops to 1.2 to 1.9V. (If the voltage drops below the above range, stop engine and wait until the voltage rises to within this range.)
- 4) Start engine and let it idle for at least 70 seconds.

TROUBLE DIAGNOSIS FOR DTC P0443

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)

- 5) Maintain the following conditions for at least 30 seconds.

Gear position:

“2” or “D” range (A/T)

“3rd” or “4th” gear (M/T)

Vehicle speed:

40 - 80 km/h (25 - 50 MPH)

Engine speed:

1,500 - 2,500 rpm

Voltage between ECM terminal ⑤¹ and ground:


More than 0.8V

- 6) Turn ignition switch “OFF”, wait at least 5 seconds and then turn “ON”.
- 7) Perform “Diagnostic Test Mode II (Self-diagnostic results)” with ECM.

TROUBLE DIAGNOSIS FOR DTC P0443




Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)

EC-CANI/V-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Refer to last page (Foldout page).
M63, F3







TROUBLE DIAGNOSIS FOR DTC P0443

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)

DIAGNOSTIC PROCEDURE





Procedure for malfunction A



TROUBLE DIAGNOSIS FOR DTC P0443

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)

Procedure for malfunction B



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P0443

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (DTC: 0807) (Cont'd)

COMPONENT INSPECTION


EVAP canister purge control solenoid valve

Check air passage continuity.





Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.



EVAP canister purge control valve

1. Blow air in ports (A), (B) and (C) and check that there is no leakage.
2. Apply vacuum to port (A). [Approximately -13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg, -1.93 to -2.90 psi)] Then blow air in port (C) and check that air flows freely out of port (B).



Evaporative Emission (EVAP) Canister Vent Control Valve (DTC: 0903)

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative loss system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative loss system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0446 0903	A) An improper voltage signal is sent to ECM through EVAP canister vent control valve.	<ul style="list-style-type: none"> • Harness or connectors [EVAP canister vent control valve circuit is open or shorted.]
	B) EVAP canister vent control valve does not operate properly.	<ul style="list-style-type: none"> • EVAP canister vent control valve • EVAP control system pressure sensor • Blocked rubber tube to EVAP canister vent control valve

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Before performing the following procedure, confirm that battery voltage is more than 12V.

Perform "Procedure for malfunction A". If the DTC cannot be confirmed, perform "Procedure for malfunction B" on next page.

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 5 seconds.

OR



- 1) Start engine and wait at least 5 seconds.
- 2) Select "MODE 3" with GST.

OR



- 1) Start engine and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0446


Evaporative Emission (EVAP) Canister Vent Control Valve (DTC: 0903) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a DTC might not be confirmed.

Procedure for malfunction B

- 1) Remove EVAP canister vent control valve from EVAP canister and disconnect hoses from the valve.
- 2) Check air passage continuity.






Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals (1) and (2)	No
No supply	Yes

TROUBLE DIAGNOSIS FOR DTC P0446

Evaporative Emission (EVAP) Canister Vent Control Valve (DTC: 0903) (Cont'd)





EC-VENT/V-01



TROUBLE DIAGNOSIS FOR DTC P0446

Evaporative Emission (EVAP) Canister Vent Control Valve (DTC: 0903) (Cont'd)

DIAGNOSTIC PROCEDURE




TROUBLE DIAGNOSIS FOR DTC P0446

Evaporative Emission (EVAP) Canister Vent Control Valve (DTC: 0903) (Cont'd)

COMPONENT INSPECTION


EVAP canister vent control valve

Check air passage continuity.



Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals (1) and (2)	No
No supply	Yes

If NG, clean valve using air blower or replace as necessary.



EVAP control system pressure sensor

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
4. Check output voltage between terminal (2) and engine ground.

Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg, 0 psi)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg, -1.35 psi)	0.4 - 0.6

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace EVAP control system pressure sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

TROUBLE DIAGNOSIS FOR DTC P0450




Evaporative Emission (EVAP) Control System Pressure Sensor (DTC: 0704)

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.




Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0450 0704	<ul style="list-style-type: none"> An improper voltage signal from EVAP control system pressure sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The EVAP control system pressure sensor circuit is open or shorted.) EVAP control system pressure sensor EVAP canister vent control valve (The valve is stuck open.)


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Turn ignition switch "ON".
 4) Select "DATA MONITOR" mode with CONSULT.
 5) Wait at least 12 seconds.

OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Turn ignition switch "ON" and wait at least 12 seconds.
 4) Select "MODE 3" with GST.


OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Turn ignition switch "ON" and wait at least 12 seconds.
 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.


TROUBLE DIAGNOSIS FOR DTC P0450

Evaporative Emission (EVAP) Control System Pressure Sensor (DTC: 0704) (Cont'd)

EC-PRE/SE-01







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0450

Evaporative Emission (EVAP) Control System Pressure Sensor (DTC: 0704) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
 1. Turn ignition switch "OFF".
 2. Disconnect EVAP control system pressure sensor harness connector.
 3. Turn ignition switch "ON".
 4. Check voltage between terminal ③ and engine ground with CONSULT or tester.
Voltage: Approximately 5V

NG → Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Loosen and retighten ground screw.
 3. Check harness continuity between terminal ① and engine ground.
Continuity should exist.
 If OK, check harness for short.

NG → Check the following.

- Harness connectors (Models with ABS)
 - ① T22, ② B33
 - (Models without ABS)
 - ③ T31, ④ B36
- Harness connectors
 - ⑤ B35, ⑥ F41
- Harness connectors
 - ⑦ F4, ⑧ M64
- Harness for open or short between ECM and EVAP control system pressure sensor
- Harness for open or short between A/T control unit and EVAP control system pressure sensor

If NG, repair harness or connectors.

C
CHECK INPUT SIGNAL CIRCUIT.
 1. Disconnect ECM harness connector.
 2. Check harness continuity between ECM terminal ⑥7 and terminal ②.
Continuity should exist.
 If OK, check harness for short.



NG → Repair harness or connectors.

CHECK COMPONENT
 (EVAP canister vent control valve).
 Refer to "COMPONENT INSPECTION", EC-211.

OK → (A)

TROUBLE DIAGNOSIS FOR DTC P0450

Evaporative Emission (EVAP) Control System Pressure Sensor (DTC: 0704) (Cont'd)



COMPONENT INSPECTION

EVAP control system pressure sensor

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
4. Check output voltage between terminal ② and engine ground.


Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg, 0 psi)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg, -1.35 psi)	0.4 - 0.6

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace EVAP control system pressure sensor.


TROUBLE DIAGNOSIS FOR DTC P0500



Vehicle Speed Sensor (VSS) (DTC: 0104)

The vehicle speed sensor is installed in the transmission. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

Diagnostic Trouble Code No.	Malfunction is detected when	Check items (Possible cause)
P0500 0104	<ul style="list-style-type: none"> • The almost 0 km/h (0 MPH) signal from the vehicle speed sensor is sent to ECM even when the vehicle is driving. 	<ul style="list-style-type: none"> • Harness or connector (The vehicle speed sensor circuit is open or shorted.) • Vehicle speed sensor



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of vehicle speed sensor. During this check, a DTC might not be confirmed.


- 1) Jack up drive wheels.
- 2) Start engine.
- 3) Perform "VEHICLE SPEED SEN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

- 2) Start engine.
- 3) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT.

The vehicle speed on CONSULT should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

OR



TROUBLE DIAGNOSIS FOR DTC P0500

Vehicle Speed Sensor (VSS) (DTC: 0104) (Cont'd)

FUEL SYS #1	CLOSED
FUEL SYS #2	UNUSED
CALC LOAD	57%
COOLANT TEMP	87°C
SHORT FT #1	1%
LONG FT #1	-3%
ENGINE SPD	2225RPM
VEHICLE SPD	57MPH
IGN ADVANCE	34.0°
INTAKE AIR	43°C
MAF	26.2gm/sec
THROTTLE POS	12%
O2S LOCATION	3
O2S B1,S1	0.090V
O2FT B1,S1	0%
O2S B1,S2	0.070V

SEF942N



- 1) Jack up drive wheels.
- 2) Start engine.
- 3) Read vehicle speed sensor signal in "MODE 1" with GST.

The vehicle speed on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

OR

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Start engine and warm it up sufficiently.
- 2) Perform test drive for at least 10 seconds continuously in the following recommended condition.

Engine speed : (A/T models) 2,000 - 3,200 rpm
(M/T models) 1,800 - 2,600 rpm

Intake manifold vacuum : (A/T models) -53.3 to -40.0 kPa
(-400 to -300 mmHg, -15.75 to -11.81 inHg, -7.73 to -5.80 psi)
(M/T models) -53.3 to -26.7 kPa
(-400 to -200 mmHg, -15.75 to -7.87 inHg, -7.73 to -3.87 psi)

Gear position : Suitable position (except "N" or "P" position)

- 3) Stop the vehicle, turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Even though Diagnostic Trouble Code is not detected, perform the above test drive at least one more time.

GI

MA

EM

LC

EC

FE

CL

WT

AT

PD

FA

BA

BR

ST

RS

BT

HA



EL

IDX



TROUBLE DIAGNOSIS FOR DTC P0500

Vehicle Speed Sensor (VSS) (DTC: 0104) (Cont'd)

EC-VSS-01





Refer to last page (Foldout page).



TROUBLE DIAGNOSIS FOR DTC P0500

Vehicle Speed Sensor (VSS) (DTC: 0104) (Cont'd)


DIAGNOSTIC PROCEDURE




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205)

SYSTEM DESCRIPTION



This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).



COMPONENT DESCRIPTION

IACV-AAC valve

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.

TROUBLE DIAGNOSIS FOR DTC P0505


Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)

Diagnostic Trouble Code No.	Malfunction is detected when	Check items (Possible cause)
P0505 0205	A) The IACV-AAC valve does not operate properly.	<ul style="list-style-type: none"> • Harness or connectors (The IACV-AAC valve circuit is open.) • IACV-AAC valve
	B) The IACV-AAC valve does not operate properly.	<ul style="list-style-type: none"> • Harness or connectors (The IACV-AAC valve circuit is shorted.) • IACV-AAC valve


DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the DTC cannot be confirmed, perform "Procedure for malfunction B".


Procedure for malfunction A

-  1) Turn ignition switch "ON".
 2) Select "DATA MONITOR" mode with CONSULT.
 3) Wait at least 2 seconds.


OR

-  1) Turn ignition switch "ON" and wait at least 2 seconds.
 2) Select "MODE 3" with GST.


OR

-  1) Turn ignition switch "ON" and wait at least 2 seconds.
 2) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.


Procedure for malfunction B

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
 4) Start engine and run it for at least 30 seconds at idle speed.

OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Start engine again and run it for at least 30 seconds at idle speed.
 4) Select "MODE 3" with GST.




OR

-  1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Start engine again and run it for at least 30 seconds at idle speed.
 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P0505

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)

EC-AAC/V-01







Refer to last page (Foldout page).

M63, F3

TROUBLE DIAGNOSIS FOR DTC P0505

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)

DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0505

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (DTC: 0205) (Cont'd)

COMPONENT INSPECTION

IACV-AAC valve


Disconnect IACV-AAC valve harness connector.

- Check IACV-AAC valve resistance.


Resistance:

Approximately 10Ω at 25°C (77°F)

- Check plunger for seizing or sticking.
- Check for broken spring.




TROUBLE DIAGNOSIS FOR DTC P0510



Closed Throttle Position Switch (DTC: 0203)

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control. When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge control valve when the throttle position sensor is malfunctioning.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0510 0203	<ul style="list-style-type: none"> Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened. 	<ul style="list-style-type: none"> Harness or connectors. (The closed throttle position switch circuit is shorted.) Closed throttle position switch.



OVERALL FUNCTION CHECK


Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a DTC might not be confirmed.

- NO TOOLS**
- 1) Start engine and warm it up sufficiently.
 - 2) Check the voltage between ECM terminal ②7 and ground under the following conditions.
 - At idle: Battery voltage**
 - At 2,000 rpm: Approximately 0V**

TROUBLE DIAGNOSIS FOR DTC P0510

Closed Throttle Position Switch (DTC: 0203) (Cont'd)

EC-TP/SW-01




Refer to last page (Foldout page).

M63 F3

4 5 6 F25
GY






F1
W **H.S.**



TROUBLE DIAGNOSIS FOR DTC P0510

Closed Throttle Position Switch (DTC: 0203) (Cont'd)

DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P0510

Closed Throttle Position Switch (DTC: 0203) (Cont'd)

COMPONENT INSPECTION

Closed throttle position switch

1. Start engine and warm it up sufficiently.
2. Turn ignition switch "OFF".
3. Disconnect throttle position switch harness connector.
4. Check continuity between terminals ⑤ and ⑥ while opening throttle valve manually.



Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely open	No

If NG, replace throttle position switch.

TROUBLE DIAGNOSIS FOR DTC P0600

A/T Control

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/deceleration. Voltage signals are exchanged between ECM and A/T control unit.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Item (Possible Cause)
P0600	<ul style="list-style-type: none"> ECM receives incorrect voltage from A/T control unit continuously. 	<ul style="list-style-type: none"> Harness or connectors (The circuit between ECM and A/T control unit is open or shorted.)

*: This DTC can be detected only by "DATA MONITOR (AUTO TRIG)" with CONSULT.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine, and race more than 1,000 rpm once, then wait at least 40 seconds.

OVERALL FUNCTION CHECK





Use this procedure to check the overall function of the A/T control. During this check, a DTC might not be confirmed.

- 1) Turn ignition switch "ON".
- 2) Start engine.
- 3) Check voltage between ECM terminal ②④ and ground.
ECM terminal ②⑨ and ground.
Voltage: Approximately 7V

TROUBLE DIAGNOSIS FOR DTC P0600





A/T Control (Cont'd)

EC-AT/C-01



TROUBLE DIAGNOSIS FOR DTC P0600

A/T Control (Cont'd) DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and A/T control unit harness connector.
3. Check harness continuity between ECM terminal ②④ and terminal ⑩, ECM terminal ②⑨ and terminal ⑪, ECM terminal ③⑩ and terminal ⑫.
Continuity should exist.

NG
Check the following.
• Harness connectors
 F4, M64
• Harness continuity between ECM and A/T control unit.
If NG, repair harness or connectors.

B
CHECK INPUT SIGNAL CIRCUIT.
Check harness continuity between ECM terminal ②④ and ground, ECM terminal ②⑨ and ground, ECM terminal ③⑩ and ground.
Continuity should not exist.

NG
Check the harness between ECM and A/T control unit.
If NG, repair harness.


OK
Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P0605



Engine Control Module (ECM)-ECCS Control Module (DTC: 0301)


The ECM consists of a microcomputer, diagnostic test mode selector, and connectors for signal input and output and for power supply. The unit controls the engine.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
P0605 0301	• ECM calculation function is malfunctioning.	• ECM (ECCS control module)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE


- 1) Turn ignition switch "ON".
 - 2) Select "DATA MONITOR" mode with CONSULT.
 - 3) Start engine.
 - 4) Run engine for at least 30 seconds at idle speed.
- OR
- 1) Turn ignition switch "ON".
 - 2) Select "Mode 3" with GST.
 - 3) Start engine.
 - 4) Run engine for at least 30 seconds at idle speed.
- OR
- 1) Turn ignition switch "ON".
 - 2) Start engine and wait at least 30 seconds.
 - 3) Turn ignition switch "OFF" and wait at least 5 seconds.
 - 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR DTC P0605

Engine Control Module (ECM)-ECCS Control Module (DTC: 0301) (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P0705




Park/Neutral Position Switch (DTC: 1003)

When the gear position is "P" (A/T models only) or "N", park/neutral position is "ON".

ECM detects the position because the continuity of the line (the "ON" signal) exists.

ECM receives signals from park position switch via A/T control unit.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
P0705 1003	<ul style="list-style-type: none"> The signal of the park/neutral position switch is not changed in the process of engine starting and driving. 	<ul style="list-style-type: none"> Harness or connectors (The neutral position switch or inhibitor switch circuit is open or shorted.) Neutral position switch (M/T models) Inhibitor switch (A/T models)



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the park/neutral position switch. During this check, a DTC might not be confirmed.

- Turn ignition switch "ON".
- Perform "PARK/NEUT POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.

OR



- Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT.
- Check the "P/N POSI SW" signal under the following conditions.

Condition (Gear position)	Known good signal
"N" and "P" (A/T only) position	ON
Except the above position	OFF

OR

- Turn ignition switch "ON".
- Check voltage between ECM terminal ② and body ground under the following conditions.


Condition (Gear position)	Voltage (V) (Known good data)
"N" and "P" (A/T only) position	Approx. 0
Except the above position	Approx. 4




TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003) (Cont'd)

EC-PNP/SW-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003) (Cont'd)

DIAGNOSTIC PROCEDURE

Neutral position switch

INSPECTION START

A

CHECK GROUND CIRCUIT.

1. Disconnect neutral position switch harness connector.
2. Check harness continuity between terminal (a) and body ground.
Continuity should exist.
If OK, check harness for short.

NG

Check the following.

- Harness connectors (E202), (E19)
 - Harness for open or short between neutral position switch and body ground
- If NG, repair harness or connectors.

OK

B

CHECK INPUT SIGNAL CIRCUIT.

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal (22) and terminal (b).
Continuity should exist.
If OK, check harness for short.

NG

Check the following.

- Harness connectors (F3), (M63)
 - Harness connectors (M9), (E109)
 - Harness connectors (E19), (E202)
 - Harness for open or short between ECM and neutral position switch
- If NG, repair harness or connectors.

OK

CHECK COMPONENT
(Neutral position switch).
Refer to MT section

NG

Replace neutral position switch.




OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.






Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END





TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003) (Cont'd)



Inhibitor switch (A/T control unit)


INSPECTION START



CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSIS FOR DTC P0705

Park/Neutral Position Switch (DTC: 1003) (Cont'd)




Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (DTC: 1302)

SYSTEM DESCRIPTION



This system allows the absolute pressure sensor to monitor either ambient barometric pressure or intake manifold pressure. The MAP/BARO switch solenoid valve switches between two passages by ON-OFF pulse signals from the ECM. (One passage is from the intake air duct, the other is from the intake manifold.) Either ambient barometric pressure or intake manifold pressure is applied to the absolute pressure sensor.

Solenoid	Conditions
ON	<ul style="list-style-type: none"> Immediately after starting engine or More than 5 minutes after the solenoid valve shuts OFF.
	<ul style="list-style-type: none"> Throttle valve is shut or almost fully shut for more than 1 second and Vehicle speed is less than 100 km/h (62 MPH).



COMPONENT DESCRIPTION

The MAP/BARO switch solenoid valve switches its air flow passage according to the voltage signal sent from the ECM. When voltage is supplied from the ECM, the MAP/BARO switch solenoid turns "ON". Then, the absolute pressure sensor can monitor the ambient barometric pressure. When voltage is not supplied from the ECM, the MAP/BARO switch solenoid valve turns "OFF". Then, the sensor monitors intake manifold pressure.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1105 1302	<ul style="list-style-type: none"> MAP/BARO switch solenoid valve receives the voltage supplied though ECM does not supply the voltage to the valve. There is little difference between MAP/BARO switch solenoid valve input voltage at ambient barometric pressure and voltage at intake manifold pressure. 	<ul style="list-style-type: none"> Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) Hoses (Hoses are clogged or disconnected.) Absolute pressure sensor MAP/BARO switch solenoid valve

TROUBLE DIAGNOSIS FOR DTC P1105

Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (DTC: 1302) (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 4) Start engine and let it idle.
- 5) Wait at least 8 seconds.

OR



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine and let it idle.
- 4) Wait at least 8 seconds.
- 5) Select "MODE 3" with GST.

OR




- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Start engine and let it idle.
- 4) Wait at least 8 seconds.
- 5) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P1105

Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (DTC: 1302) (Cont'd)

EC-SW/V-01




— : Detectable line for DTC
 — : Non-detectable line for DTC

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



Refer to last page (Foldout page).






M63, F3



TROUBLE DIAGNOSIS FOR DTC P1105



Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (DTC: 1302) (Cont'd)

DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR DTC P1105

Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (DTC: 1302) (Cont'd)



D

CHECK POWER SUPPLY.

1. Turn ignition switch "OFF".
2. Disconnect MAP/BARO switch solenoid valve harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal ② and engine ground with CONSULT or tester.

Voltage: Battery voltage
If OK, check harness for short.

NG → Check the following.

- Harness connectors (F3, M63)
- 7.5A fuse
- Harness for open or short between MAP/BARO switch solenoid valve and fuse

If NG, repair harness or connectors.

E

CHECK OUTPUT SIGNAL CIRCUIT.

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal ⑥9 and terminal ① with CONSULT or tester.

Continuity should exist.
If OK, check harness for short.

NG → Repair harness or connectors.

OK

A

CHECK COMPONENT
(Absolute pressure sensor).
Refer to "COMPONENT INSPECTION" of "TROUBLE DIAGNOSIS FOR DTC P0105", EC-116.

NG → Replace absolute pressure sensor.

OK

CHECK COMPONENT
(MAP/BARO switch solenoid valve).
Refer to "COMPONENT INSPECTION" on next page.

NG → Replace MAP/BARO switch solenoid valve.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1105

Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (DTC: 1302) (Cont'd)

COMPONENT INSPECTION

MAP/BARO switch solenoid valve




1. Start engine and warm it up sufficiently.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
3. Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
4. If NG, replace solenoid valve.

OR


1. Remove MAP/BARO switch solenoid valve.
2. Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

3. If NG, replace solenoid valve.



TROUBLE DIAGNOSIS FOR DTC P1320



Ignition Signal (DTC: 0201)

Ignition coil & power transistor (Built into distributor)

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Item (Possible Cause)
P1320 0201	<ul style="list-style-type: none"> The ignition signal in the primary circuit is not sent during engine cranking or running. 	<ul style="list-style-type: none"> Harness or connectors (The ignition primary circuit is open or shorted.) Power transistor unit. Resistor Camshaft position sensor Camshaft position sensor circuit

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: If both DTC P0340 (0101) and P1320 (0201) are displayed, perform TROUBLE DIAGNOSIS FOR DTC P0340 first. (See EC-173.)

- 1) Turn ignition switch "ON".
 2) Select "DATA MONITOR" mode with CONSULT.
 3) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)

OR

- 1) Turn ignition switch "ON".
 2) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
 3) Select MODE 3 with GST.

OR


- NO TOOLS
 1) Turn ignition switch "ON".
 2) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
 4) Perform diagnostic test mode II (Self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)




EC-IGN/SG-01

: Detectable line for DTC
 : Non-detectable line for DTC



Refer to last page (Foldout page).






E109, M9
 M63, F3



TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)





DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)




TROUBLE DIAGNOSIS FOR DTC P1320

Ignition Signal (DTC: 0201) (Cont'd)

COMPONENT INSPECTION


Ignition coil

1. Disconnect ignition coil harness connector.
2. Remove distributor cap.
3. Check resistance as shown in the figure.



Terminal	Resistance
c - d	Approximately 1 Ω
c - e	Approximately 20 k Ω

If NG, replace distributor assembly.




Power transistor

1. Disconnect camshaft position sensor & power transistor harness connector and ignition coil harness connector.
2. Check power transistor resistance between terminals ② and ⑧.

Terminals	Resistance	Result
② and ⑧	Except 0 Ω	OK
	0 Ω	NG

If NG, replace distributor assembly.



Resistor

1. Disconnect resistor harness connector.
2. Check resistance between terminals ① and ②.

Resistance: Approximately 2.2 k Ω

If NG, replace resistor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS



BT

HA

EL

IDX

TROUBLE DIAGNOSIS FOR DTC P1336



Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0905)

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not directly used to control the engine system.

It is used only for the on board diagnosis of misfire.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1336 0905	<ul style="list-style-type: none"> • A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM. 	<ul style="list-style-type: none"> • Harness or connectors • Crankshaft position sensor (OBD) • Flywheel (Drive plate)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 4 minutes at idle speed.

OR



- 1) Start engine and run it for at least 4 minutes at idle speed.
- 2) Select "MODE 3" with GST.

OR






- 1) Start engine and run it for at least 4 minutes at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TROUBLE DIAGNOSIS FOR DTC P1336

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0905) (Cont'd)

EC-CKPS-01







CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1336

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0905) (Cont'd)

DIAGNOSTIC PROCEDURE





TROUBLE DIAGNOSIS FOR DTC P1336

Crankshaft Position Sensor (CKPS) (OBD) (DTC: 0905) (Cont'd)

COMPONENT INSPECTION

Crankshaft position sensor (OBD)

1. Disconnect crankshaft position sensor (OBD) harness connector. GI
2. Loosen the fixing bolt of the sensor. MA
3. Remove the sensor. EM
4. Visually check the sensor for chipping. LC
5. Check resistance as shown in the figure. EC
Resistance: Approximately 166.5 - 203.5Ω at 20°C (68°F) FE



EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




EGRC-Solenoid Valve (DTC: 1005)

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve.)

When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1400 1005	<ul style="list-style-type: none"> • The improper voltage signal is sent to ECM through EGRC-solenoid valve. 	<ul style="list-style-type: none"> • Harness or connectors (The EGRC-solenoid valve circuit is open or shorted.) • EGRC-solenoid valve



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGRC-solenoid valve circuit. During this check, a DTC might not be confirmed.



- 1) Turn ignition switch "ON".
 2) Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

- 1) Turn ignition switch "ON".
 2) Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and check the operating sound, according to ON/OFF switching.

OR


- 1) Start engine and warm it up sufficiently.
 2) Turn ignition switch "OFF" and wait at least 5 seconds.
 3) Start engine again.
 4) Check the voltage between ECM terminal (103) and ground at idle speed.
Voltage: 0.04 - 0.08V
 5) Check that the voltage changes to battery voltage and returns to 0.04 - 0.08V when the engine speed increases to about 2,500 rpm.



TROUBLE DIAGNOSIS FOR DTC P1400

EGRC-Solenoid Valve (DTC: 1005) (Cont'd)

EC-EGRC/V-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Refer to last page (Foldout page).

M63, F3




101	102	103	104	105	106	1	2	3	4	20	21	22	23	38	39	40	41	53	54	55	56					
107	108	109	110	111	112	5	6	7	8	9	10	24	25	26	27	28	42	43	44	45	46	57	58	59	60	61
113	114	115	116	117	118	11	12	13	14	19	29	30	31	32	33	49	50	47	48	62	63	64	65	70		
						15	16	17	18		34	35	36	37			51	52	66	67	68	69				

TROUBLE DIAGNOSIS FOR DTC P1400

EGRC-Solenoid Valve (DTC: 1005) (Cont'd)


DIAGNOSTIC PROCEDURE



INSPECTION START


A
CHECK POWER SUPPLY.
 1. Disconnect EGRC-solenoid valve sub-harness connector.
 2. Turn ignition switch "ON".
 3. Check voltage between terminal (a) and ground with CONSULT or tester.
Voltage: Battery voltage

NG
 Check the following.
 • Harness connectors (M63, F3)
 • 10A fuse
 • Harness for open or short between EGRC-solenoid valve sub-harness connector and fuse
 If NG, repair harness or connectors.



OK
B
CHECK OUTPUT SIGNAL CIRCUIT.
 1. Disconnect ECM harness connector.
 2. Check harness continuity between ECM terminal (103) and terminal (b).
Continuity should exist.
 If OK, check harness for short.

NG
 Check the following.
 • Harness for open or short between EGRC-solenoid valve sub-harness connector and ECM
 If NG, repair harness or connectors.



OK
 Check the following.
 • Harness for open or short between EGRC-solenoid valve and EGRC-solenoid valve sub-harness connector

NG
 Repair harness or connectors.


OK
CHECK COMPONENT (EGRC-solenoid valve).
 Refer to "COMPONENT INSPECTION" on next page.

NG
 Replace EGRC-solenoid valve.

OK
 Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
 Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.


INSPECTION END



EGR Temperature Sensor (DTC: 0305)

The EGR temperature sensor detects temperature changes in the EGR passage way. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passage way changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases.

This sensor is not directly used to control the engine system. It is used only for the on board diagnosis.



(Reference data)





EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1401 0305	A) An excessively low voltage from the EGR temperature sensor is sent to ECM, even when engine coolant temperature is low.	<ul style="list-style-type: none"> • Harness or connectors (The EGR temperature sensor circuit is shorted.) • EGR temperature sensor • Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve
	B) An excessively high voltage from the EGR temperature sensor is sent to ECM, even when engine coolant temperature is high.	<ul style="list-style-type: none"> • Harness or connectors (The EGR temperature sensor circuit is open.) • EGR temperature sensor • Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve

TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGR temperature sensor. During this check, a DTC might not be confirmed.
Procedure for malfunctions A and B



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Confirm that engine coolant temperature and intake air temperature are lower than 40°C (104°F). (If necessary, wait until the temperatures equal atmospheric temperature.)
- 3) Confirm that "EGR TEMP SEN" reading is between 3.45V and 5.0V.
- 4) Start engine and warm it up sufficiently.
- 5) Run engine at idle for at least 2 minutes.
- 6) Confirm that EGR valve is not lifting. If NG, go to TROUBLE DIAGNOSES FOR DTC P0400 and P0402. (See pages EC-177 and 185.)
- 7) Read "EGR TEMP SEN" at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.0V.
- 8) If step 7 is OK, perform TROUBLE DIAGNOSES FOR DTC P0400, P0402 and P1400. (See pages EC-177, 185 and 254.)






OR

- 1) Turn ignition switch "ON".
- 2) Confirm that voltage between ECM terminals ⑤①, ②⑧ and ground are more than 2.72V. (If necessary, wait until engine coolant temperature and intake air temperature equal atmospheric temperature.)
- 3) Confirm that voltage between ECM terminal ⑥② and ground is between 3.45V and 5.0V.
- 4) Start engine and warm it up sufficiently.
- 5) Run engine at idle for at least 2 minutes.
- 6) Confirm that EGR valve is not lifting. If NG, go to TROUBLE DIAGNOSES FOR DTC P0400 and P0402. (See pages EC-177 and 185.)
- 7) Check voltage between ECM terminal ⑥② and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.
Voltage should decrease to less than 1.0V.
- 8) If step 7 is OK, perform TROUBLE DIAGNOSES FOR DTC P0400, P0402 and P1400. (See pages EC-177, 185 and 254.)

TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd)


EC-EGR/TS-01



TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd)


DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
 1) Disconnect EFI (EGR temperature sensor) sub-harness connector.
 2) Turn ignition switch "ON".
 3) Check voltage between terminal **(b)** and ground with CONSULT or tester.
Voltage: Approximately 5V

NG → Repair harness or connectors.




B
CHECK GROUND CIRCUIT.
 1) Turn ignition switch "OFF".
 2) Check harness continuity between terminal **(g)** and engine ground.
Continuity should exist.
 If OK, check harness for short.

NG → Check the following.
 • Harness continuity between ECM and EGR temperature sensor sub-harness connector
 • Harness for open or short between A/T control unit and EGR temperature sensor
 If NG, repair harness or connector.

Check harness for open or short between EGR temperature sensor and EGR temperature sensor sub-harness connector.

NG → Repair harness or connectors.



CHECK COMPONENT
 (EGR temperature sensor).
 Refer to "COMPONENT INSPECTION" on next page.

NG → Replace EGR temperature sensor.

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END


GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS FOR DTC P1401

EGR Temperature Sensor (DTC: 0305) (Cont'd) COMPONENT INSPECTION


EGR temperature sensor

Check resistance change and resistance value.




EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

If NG, replace EGR temperature sensor.



TROUBLE DIAGNOSIS FOR DTC P1441



Vacuum Cut Valve Bypass Valve (DTC: 0801)

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.


The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

GI
MA
EM

EVAPORATIVE EMISSION SYSTEM DIAGRAM



LC
EC
FE
CL
MT

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1441 0801	A) An improper voltage signal is sent to ECM through vacuum cut valve bypass valve.	<ul style="list-style-type: none"> • Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted.) • Vacuum cut valve bypass valve
	B) Vacuum cut valve bypass valve does not operate properly.	<ul style="list-style-type: none"> • Vacuum cut valve bypass valve • Vacuum cut valve • Bypass hoses for clogging • EVAP control system pressure sensor

AT
PD
FA
RA

BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1441

Vacuum Cut Valve Bypass Valve (DTC: 0801) (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "OVERALL FUNCTION CHECK", "Procedure for malfunction B".

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 5 seconds.

OR




- 1) Start engine and wait at least 5 seconds.
- 2) Select "MODE 3" with GST.

OR



- 1) Start engine and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.



OVERALL FUNCTION CHECK


Procedure for malfunction B

- 1) Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
- 2) Apply vacuum to port (A) and check that there is no suction from port (B).
- 3) Apply vacuum to port (B) and check that there is suction from port (A).
- 4) Blow air in port (B) and check that there is a resistance to flow out of port (A).
- 5) Supply battery voltage to the terminal.
- 6) Blow air in port (A) and check that air flows freely out of port (B).
- 7) Blow air in port (B) and check that air flows freely out of port (A).

TROUBLE DIAGNOSIS FOR DTC P1441

Vacuum Cut Valve Bypass Valve (DTC: 0801) (Cont'd)



EC-BYPS/V-01



Refer to EL-POWER.

- : Detectable line for DTC
- : Non-detectable line for DTC
- AB : Models with ABS
- OA : Models without ABS

- *1: AB 1
- OA 1
- *2: AB 9
- OA 5







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1441

Vacuum Cut Valve Bypass Valve (DTC: 0801) (Cont'd)

DIAGNOSTIC PROCEDURE

Procedure for malfunction A




TROUBLE DIAGNOSIS FOR DTC P1441

Vacuum Cut Valve Bypass Valve (DTC: 0801) (Cont'd)

DIAGNOSTIC PROCEDURE

Procedure for malfunction B



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




COMPONENT INSPECTION

Vacuum cut valve bypass valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals	Yes
No supply	No

If NG, replace vacuum cut valve bypass valve.




Vacuum cut valve

Check vacuum cut valve as follows:


1. Plug port (C) and (D) with fingers.
2. Apply vacuum to port (A) and check that there is no suction from port (B).
3. Apply vacuum to port (B) and check that there is suction from port (A).
4. Blow air in port (B) and check that there is a resistance to flow out of port (A).
5. Open port (C) and (D).
6. Blow air in port (A) check that air flows freely out of port (C).
7. Blow air in port (B) check that air flows freely out of port (D).

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (DTC: 1008)

SYSTEM DESCRIPTION



This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



COMPONENT DESCRIPTION

The EVAP canister purge volume control valve uses a step motor to control the flow rate of fuel vapor from the EVAP canister. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

TROUBLE DIAGNOSIS FOR DTC P1445

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (DTC: 1008) (Cont'd)

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1445 1008	A) An improper voltage signal is sent to ECM through the valve.	<ul style="list-style-type: none"> • Harness or connectors (The valve circuit is open or shorted.) • EVAP canister purge volume control valve
	B) The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control valve is completely closed.	<ul style="list-style-type: none"> • EVAP control system pressure sensor • EVAP canister purge volume control valve (The valve is stuck open.) • EVAP canister purge control valve • Hoses (Hoses are connected incorrectly.)

GI
MA
EM
LC

EC

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the DTC cannot be confirmed, perform "Procedure for malfunction B".

FE
CL

Procedure for malfunction A

- 1) Jack up drive wheels.
- 2) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and let it idle for at least 90 seconds.
- 4) Move selector/gearshift lever to "1" range (A/T) or "1st" gear (M/T).
- 5) Race engine from idle to 2,000 to 3,000 rpm more than 10 times.

MT
AT
PD

OR

- 1) Jack up drive wheels.
- 2) Start engine and let it idle for at least 90 seconds.
- 3) Move selector/gearshift lever to "1" range (A/T) or "1st" gear (M/T).
- 4) Race engine from idle to 2,000 to 3,000 rpm more than 10 times.
- 5) Select "MODE 3" with GST.

FA
RA
BR

OR


- 1) Jack up drive wheels.
- 2) Start engine and let it idle for at least 90 seconds.
- 3) Move selector/gearshift lever to "1" range (A/T) or "1st" gear (M/T).
- 4) Race engine from idle to 2,000 to 3,000 rpm more than 10 times.
- 5) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 6) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

ST
RS
BT

Procedure for malfunction B

- 1) Jack up drive wheels.
- 2) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up until the engine coolant temperature rises to 60 to 80°C (140 to 176°F), then stop engine. (If the engine coolant temperature exceeds the above range, stop engine and wait until the temperature falls to within this range.)
- 4) Start engine and let it idle for at least 70 seconds.

HA
EL
IDX



SEF345Q

TROUBLE DIAGNOSIS FOR DTC P1445

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (DTC: 1008) (Cont'd)

- Maintain the following conditions for at least 50 seconds.

Gear position:

“2” or “D” range (A/T)

“3rd” or “4th” gear (M/T)

Vehicle speed:

40 - 80 km/h (25 - 50 MPH)

Engine speed:

1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)

OR

ENGINE SPD	825RPM
COOLANT TEMP	69°C
VEHICLE SPD	0MPH
IGN ADVANCE	8.0°
CALC LOAD	28.2%
MAP	36KPaA
MAF	5.20gm/s
THROTTLE POS	0.0%
INTAKE AIR	27°C
FUEL SYS #1	OLDRIVE
FUEL SYS #2	UNUSED
SHORT FT #1	0.8%
LONG FT #1	0.0%
O2S B1 S1	0.200V
O2FT B1 S1	0.8%
O2S B1 S2	0.010V

SEF519R



- Jack up drive wheels.
- Turn ignition switch “ON” and select “MODE 1” mode with GST.
- Start engine and warm it up until the engine coolant temperature rises to 60 to 80°C (140 to 176°F), then stop engine. (If the engine coolant temperature exceeds the above range, stop engine and wait until the temperature falls to within this range.)
- Start engine and let it idle for at least 70 seconds.
- Maintain the following conditions for at least 50 seconds.

Gear position:

“2” or “D” range (A/T)

“3rd” or “4th” gear (M/T)

Vehicle speed:

40 - 80 km/h (25 - 50 MPH)

Engine speed:


1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)

- Select “MODE 3” with GST.

OR



- Jack up drive wheels.
- Turn ignition switch “ON”.
- Start engine and warm it up until the voltage between ECM terminal ⑤① and ground drops to 1.2 - 1.9V, then stop engine. (If the voltage drops below the above range, stop engine and wait until the voltage rises to within this range.)
- Start engine and let it idle for at least 70 seconds.
- Maintain the following conditions for at least 50 seconds.

Gear position:

“2” or “D” range (A/T)

“3rd” or “4th” gear (M/T)

Vehicle speed:

40 - 80 km/h (25 - 50 MPH)

Engine speed:

1,500 - 2,500 rpm

Voltage between ECM terminal ⑤① and ground:




More than 0.8V

- Turn ignition switch “OFF”, wait at least 5 seconds and then turn “ON”.
- Perform “Diagnostic Test Mode II (Self-diagnostic results)” with ECM.

TROUBLE DIAGNOSIS FOR DTC P1445

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (DTC: 1008) (Cont'd)

EC-PGC/V-01







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1445

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (DTC: 1008) (Cont'd)

DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR DTC P1445

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (DTC: 1008) (Cont'd)

COMPONENT INSPECTION

EVAP canister purge volume control valve

1. Disconnect EVAP canister purge volume control valve harness connector.
2. Check resistance between the following terminals.
terminal ② and terminals ①, ③
terminal ⑤ and terminals ④, ⑥

Resistance:

Approximately 30Ω [At 25°C (77°F)]

3. Reconnect EVAP canister purge volume control valve harness connector.
4. Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
(Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
5. Turn ignition switch "ON".
6. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.
If NG, replace the EVAP canister purge volume control valve.


OR

1. Disconnect EVAP canister purge volume control valve harness connector.
2. Check resistance between the following terminals.
terminal ② and terminals ①, ③
terminal ⑤ and terminals ④, ⑥


Resistance:

Approximately 30Ω [At 25°C (77°F)]


3. Reconnect EVAP canister purge volume control valve harness connector.
4. Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
(Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
5. Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
If NG, replace the EVAP canister purge volume control valve.




SEF353Q



SEF507R




SEF763P



SEF482R

**Evaporative Emission (EVAP) Control System
Purge Flow Monitoring (DTC: 0111)**



SYSTEM DESCRIPTION

In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control valve and EVAP canister purge control valve are open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

ON BOARD DIAGNOSIS LOGIC

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a fault is determined.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1447 0111	<ul style="list-style-type: none"> • EVAP control system does not operate properly. • EVAP control system has a leak between intake manifold and EVAP control system pressure sensor. 	<ul style="list-style-type: none"> • EVAP canister purge volume control valve stuck closed • EVAP canister purge control valve stuck closed • EVAP control system pressure sensor • Loose or disconnected rubber tube • Blocked rubber tube • EVAP canister purge control solenoid valve • Blocked or bent rubber tube to MAP/BARO switch solenoid valve • Cracked EVAP canister • Absolute pressure sensor • MAP/BARO switch solenoid valve

TROUBLE DIAGNOSIS FOR DTC P1447


Evaporative Emission (EVAP) Control System Purge Flow Monitoring (DTC: 0111) (Cont'd)

☆ MONITOR	☆ NO FAIL	<input type="checkbox"/>
CMPS•RPM(REF)	787rpm	
COOLAN TEMP/S	86°C	
VHCL SPEED SE	0km/h	
CLSD THL/P SW	O N	
B/FUEL SCHDL	1.1msec	
PURG VOL C/V	0step	
EVAP SYS PRES	3.36V	
VENT CONT/V	OFF	
VC/V BYPASS/V	OFF	
RECORD		

SEF508R

■ ACTIVE TEST	<input type="checkbox"/>		
PURG VOL CONT/V	20Step		
===== MONITOR =====			
CMPS•RPM(REF)	712rpm		
VHCL SPEED SE	0km/h		
B/FUEL SCHDL	1.1msec		
EVAP SYS PRES	3.36V		
PURG CONT S/V	O N		
Qu	UP	DWN	Qd

SEF509R



OVERALL FUNCTION CHECK

Use this procedure to check the overall monitoring function of the EVAP control system purge flow. During this check, a DTC might not be confirmed.

- 1) Lift up drive wheels (M/T models).
- 2) Start engine.
- 3) Select "EVAP SYS PRES" in "DATA MONITOR" mode with CONSULT.
- 4) Check EVAP control system pressure sensor value at idle speed.
- 5) Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT and set "PURG VOL CONT/V" to 20 steps by touching "UP" or "Qu".
- 6) Maintain the following conditions for at least 30 seconds. Verify that EVAP control system pressure sensor value ("EVAP SYS PRES") stays 0.1V less than the value at idle speed for at least 2 seconds.

Engine speed:

Approx. 2,000 rpm

Gear position (for M/T models):

Any position other than "Neutral" or "Reverse"

CAUTION:

Do not run vehicle at speeds greater than 80 km/h (50 MPH).

OR

- 1) Lift up drive wheels.
- 2) Start engine and warm it up sufficiently.
- 3) Turn ignition switch "OFF", wait at least 5 seconds.
- 4) Start engine and wait at least 70 seconds.
- 5) Set voltmeter probes to ECM terminals 67 (EVAP control system pressure sensor signal) and 43 (ground).
- 6) Check EVAP control system pressure sensor value at idle speed.
- 7) Establish and maintain the following conditions for at least 30 seconds.

Air conditioner switch: ON

Steering wheel: Fully turned

Headlamp switch: ON

Rear window defogger switch: ON

Engine speed: Approx. 3,500 rpm

Intake manifold vacuum:

-73.3 to -60.0 kPa (-550 to -450 mmHg,

-21.65 to -17.72 inHg, -10.63 to -8.70 psi)

Gear position:

M/T models

Any position other than "Neutral" or "Reverse"

A/T models

Any position other than "P", "N" or "R".

Return all conditions to normal. Repeat this procedure at least 5 times.

Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed for at least 2 seconds.







CAUTION:

Do not run vehicle at speeds greater than 80 km/h (50 MPH).

TROUBLE DIAGNOSIS FOR DTC P1447



Evaporative Emission (EVAP) Control System Purge Flow Monitoring (DTC: 0111) (Cont'd)

DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR DTC P1447

Evaporative Emission (EVAP) Control System Purge Flow Monitoring (DTC: 0111) (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1447

Evaporative Emission (EVAP) Control System Purge Flow Monitoring (DTC: 0111) (Cont'd)

COMPONENT INSPECTION

EVAP canister purge volume control valve

- 1) Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals.
terminal ② and terminals ①, ③
terminal ⑤ and terminals ④, ⑥

Resistance:

Approximately 30Ω [At 25°C (77°F)]

- 3) Reconnect EVAP canister purge volume control valve harness connector.
- 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
(Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5) Turn ignition switch "ON".
- 6) Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.
If NG, replace the EVAP canister purge volume control valve.


OR

- 1) Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals.
terminal ② and terminals ①, ③
terminal ⑤ and terminals ④, ⑥


Resistance:

Approximately 30Ω [At 25°C (77°F)]


- 3) Reconnect EVAP canister purge volume control valve harness connector.
- 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
(Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5) Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
If NG, replace the EVAP canister purge volume control valve.




SEF353Q



SEF507R



SEF763P



SEF482R



TROUBLE DIAGNOSIS FOR DTC P1447

Evaporative Emission (EVAP) Control System Purge Flow Monitoring (DTC: 0111) (Cont'd)

EVAP canister purge control valve

Check EVAP canister purge control valve as follows:

1. Blow air in port (A), (B) and (C), and check that there is no leakage.
2. Apply vacuum to port (A) with pump. [Approximately -13.3 to -20.0 kPa (-100 to -150 mmHg, -3.94 to -5.91 inHg, -1.93 to -2.90 psi)]
Blow air in port (C) and check that it flows freely out of port (B).




EVAP canister purge control solenoid valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.



EVAP control system pressure sensor

1. Remove EVAP control system pressure sensor with its harness connector connected.
2. Remove hose from EVAP control system pressure sensor.
3. Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
4. Check output voltage between terminal (2) and engine ground.

Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg, 0 psi)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg, -1.35 psi)	0.4 - 0.6

CAUTION:


Always calibrate the vacuum pump gauge when using it.

5. If NG, replace EVAP control system pressure sensor.

TROUBLE DIAGNOSIS FOR DTC P1447

Evaporative Emission (EVAP) Control System Purge Flow Monitoring (DTC: 0111) (Cont'd)

Absolute pressure sensor



1. Remove absolute pressure sensor with its harness connector connected.
2. Remove hose from absolute pressure sensor.
3. Turn ignition switch "ON" and check output voltage between terminal ② and engine ground.

The voltage should be 3.2 to 4.8 V.


4. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg, -3.87 psi) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4 V lower than the value measured in step 3.

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace absolute pressure sensor.




MAP/BARO switch solenoid valve

1. Start engine and warm it up sufficiently.
2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
3. Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
4. If NG, replace solenoid valve.


OR

1. Remove MAP/BARO switch solenoid valve.
2. Check air passage continuity.



Condition	Air passage continuity between ① and ②	Air passage continuity between ① and ③
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

3. If NG, replace solenoid valve.



TROUBLE DIAGNOSIS FOR DTC P1605

A/T Diagnosis Communication line (DTC: 0804)

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from A/T control unit to ECM. Therefore, be sure to erase the malfunction information such as DTC not only in A/T control unit but also ECM after the A/T related repair.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Item (Possible Cause)
P1605 0804	<ul style="list-style-type: none"> • An incorrect signal from A/T control units is sent to ECM. 	<ul style="list-style-type: none"> • Harness or connectors (The communication line circuit between ECM and A/T control unit is open or shorted.) • Dead (Weak) battery • A/T control unit

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: Before performing the following procedure, confirm that battery voltage is more than 10.5V.



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and let it idle for at least 40 seconds.

OR



- 1) Turn ignition switch "ON".
- 2) Start engine and let it idle for at least 40 seconds.
- 3) Select "MODE 3" with GST.

OR







- 1) Turn ignition switch "ON".
- 2) Start engine and let it idle for at least 40 seconds.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform diagnostic test mode II (self-diagnostic results) with ECM.

TROUBLE DIAGNOSIS FOR DTC P1605





A/T Diagnosis Communication line (DTC: 0804) (Cont'd)

EC-ATDIAG-01



TROUBLE DIAGNOSIS FOR DTC P1605

A/T Diagnosis Communication line (DTC: 0804) (Cont'd)




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Cooling Fan (DTC: 1308)


SYSTEM DESCRIPTION

Cooling fan control



The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, air conditioner system pressure and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

Operation



TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

ON BOARD DIAGNOSIS LOGIC

This diagnosis continuously monitors the engine coolant temperature.

If the cooling fan or another component in the cooling system malfunctions, the engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Diagnostic trouble code No.	Malfunction is detected when ...	Check Items (Possible Cause)
P1900 1308	<ul style="list-style-type: none"> • Cooling fan does not operate properly (Overheat). • Cooling fan system does not operate properly (Overheat). • Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> • Harness or connectors. (The cooling fan circuit is open or shorted.) • Cooling fan • Radiator hose • Radiator • Radiator cap • Water pump • Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", (EC-294).</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- a. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED FLUIDS AND LUBRICANTS").
- b. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)





OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.



- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "DIAGNOSTIC PROCEDURE" (EC-288).
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "DIAGNOSTIC PROCEDURE" (EC-288).
- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT (LOW speed and HI speed).


OR

- 3) Start engine.
Be careful not to overheat engine.
- 4) Set temperature control lever to full cold position.
- 5) Turn air conditioner switch "ON".
- 6) Turn blower fan switch "ON".
- 7) Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
- 8) Make sure that cooling fan operates at low speed.
- 9) Turn ignition switch "OFF".
- 10) Turn air conditioner switch and blower fan switch "OFF".
- 11) Disconnect engine coolant temperature sensor harness connector.
- 12) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 13) Restart engine and make sure that cooling fan operates at higher speed than low speed.
Be careful not to overheat engine.


TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

EC-COOL/F-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST



Refer to last page (Foldout page).

(E109), (M9)
(M63), (F3)




101	102	103	104	105	106	1	2	3	4	20	21	22	23	36	39	40	41	53	54	55	56					
107	108	109	110	111	112	5	6	7	8	9	10	24	25	26	27	28	42	43	44	45	46	57	58	59	60	61
113	114	115	116	117	118	11	12	13	14	19	29	30	31	32	33	47	48	62	63	64	65	66	67	68	69	70
						15	16	17	18		34	35	36	37	49	50	51	52	66	67	68	69				

RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START




A
CHECK COOLING FAN LOW SPEED OPERATION.
 1. Disconnect cooling fan relay-1.

2. Turn ignition switch "ON".
 3. Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.
 OR
 2. Turn ignition switch "ON".
 3. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

OR
 2. Start engine.
 3. Set temperature lever at full cold position.
 4. Turn air conditioner switch "ON".
 5. Turn blower fan switch "ON".
 6. Run engine at idle for a few minutes with air conditioner operating.
 7. Make sure that cooling fan operates at low speed.






NG → Check cooling fan low speed control circuit. (Go to PROCEDURE A.)

OK
 (A)



TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)



(A)

B

CHECK COOLING FAN HIGH SPEED OPERATION.

1. Turn ignition switch "OFF".
2. Reconnect cooling fan relay-1.
3. Disconnect cooling fan relay-2.
4. Turn ignition switch "ON".
5. Perform "COOLING FAN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

OR

4. Turn ignition switch "ON".
5. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.

OR

4. Turn air conditioner switch and blower fan switch "OFF".
5. Disconnect engine coolant temperature sensor harness connector.
6. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
7. Restart engine and make sure that cooling fan operates at higher speed than low speed.

NG → Check cooling fan high speed control circuit. (Go to **PROCEDURE B**.)





OK

(B)
(Go to EC-293.)

GF
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)



PROCEDURE A

INSPECTION START

C
CHECK POWER SUPPLY.
 1. Turn ignition switch "OFF".
 2. Disconnect cooling fan relay-2.
 3. Turn ignition switch "ON".
 4. Check voltage between terminals ②, ⑤ and ground with CONSULT or tester.
Voltage: Battery voltage

NG → Check the following.
 • Harness connectors
 • M9, E109
 • 7.5A fuse
 • Harness for open or short between cooling fan relay-2 and fuse
 • Harness for open or short between cooling fan relay-2 and battery
 If NG, repair harness or connectors.

D
CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect cooling fan motor harness connector.
 3. Check harness continuity between terminal ③ and terminal a .
Continuity should exist.
 If OK, check harness for short.
 4. Check harness continuity between terminals c , d and body ground.
Continuity should exist.
 If OK, check harness for short.

NG → Repair harness or connectors.

E
CHECK OUTPUT SIGNAL CIRCUIT.
 1. Disconnect ECM harness connector.
 2. Check harness continuity between ECM terminal ⑭ and terminal ① .
Continuity should exist.

NG → Check the following.
 • Harness connectors
 • E109, M9
 • Harness connectors
 • M63, F3
 • Harness for open or short between cooling fan relay-2 and ECM
 If NG, repair harness or connectors.


CHECK COMPONENT
 (Cooling fan relay-2).
 Refer to "COMPONENT INSPECTION", EC-295.

NG → Replace cooling fan relay.


OK
 (Go to C on next page.)

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)





GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






PROCEDURE B

INSPECTION START




TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)



TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)




C

CHECK COOLING SYSTEM FOR LEAK.
Apply pressure to the cooling system with a tester, and check if the pressure drops.
Testing pressure:
157 kPa (1.6 kg/cm², 23 psi)
Pressure should not drop.
CAUTION:
Higher than the specified pressure may cause radiator damage.

NG → Check the following for leak.
• Hose
• Radiator
• Water pump
Refer to LC section ("Water Pump").

GI
MA
EM




D

CHECK RADIATOR CAP.
Apply pressure to cap with a tester.
Radiator cap relief pressure:
78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

NG → Replace radiator cap.

LC
EC



E

CHECK THERMOSTAT.
1. Check valve seating condition at normal room temperatures. It should seat tightly.
2. Check valve opening temperature and valve lift.
Valve opening temperature:
76.5°C (170°F) [standard]
Valve lift:
More than 10 mm/90°C (0.39 in/194°F)
3. Check if valve is closed at 5°C (9°F) below valve opening temperature.
For details, refer to LC section ("Thermostat").

NG → Replace thermostat

FE
CL
MT
AT
PD

OK → Check engine coolant temperature sensor. Refer to "COMPONENT INSPECTION", EC-125.

NG → Replace engine coolant temperature sensor.

FA
RA

If the cause can not be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-294.

BR
ST

INSPECTION END

RS

Perform FINAL CHECK by the following procedure after repair is completed.

1. Warm up engine. Run the vehicle for at least 20 minutes. Pay attention to engine coolant temperature gauge on the instrument panel. If the reading shows an abnormally high temperature, another part may be malfunctioning.
2. Stop vehicle and let engine idle. Check the intake and exhaust systems for leaks by listening for noise or visually inspecting the components.
3. Allow engine to cool and visually check for oil and coolant leaks. Then, perform "OVERALL FUNCTION CHECK".

BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

MAIN 12 CAUSES OF OVERHEATING

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> • Blocked radiator • Blocked condenser • Blocked radiator grille • Blocked bumper 	<ul style="list-style-type: none"> • Visual 	No blocking	—
	2	<ul style="list-style-type: none"> • Coolant mixture 	<ul style="list-style-type: none"> • Coolant tester 	50 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section
	3	<ul style="list-style-type: none"> • Coolant level 	<ul style="list-style-type: none"> • Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section
	4	<ul style="list-style-type: none"> • Radiator cap 	<ul style="list-style-type: none"> • Pressure tester 	78 - 98 kPa (0.8 - 1.0 kg/cm ² , 11 - 14 psi) 59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See "System Check" "ENGINE COOLING SYSTEM" in LC section
ON*2	5	<ul style="list-style-type: none"> • Coolant leaks 	<ul style="list-style-type: none"> • Visual 	No leaks	See "System Check" "ENGINE COOLING SYSTEM" in LC section
ON*2	6	<ul style="list-style-type: none"> • Thermostat 	<ul style="list-style-type: none"> • Touch the upper and lower radiator hoses 	Both hoses should be hot	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section
ON*1	7	<ul style="list-style-type: none"> • Cooling fan 	<ul style="list-style-type: none"> • CONSULT 	Operating	See "TROUBLE DIAGNOSIS FOR DTC P1900" (EC-284)
OFF	8	<ul style="list-style-type: none"> • Combustion gas leak 	<ul style="list-style-type: none"> • Color checker chemical tester 4 Gas analyzer 	Negative	—
ON*3	9	<ul style="list-style-type: none"> • Coolant temperature gauge 	<ul style="list-style-type: none"> • Visual 	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> • Coolant overflow to reservoir tank 	<ul style="list-style-type: none"> • Visual 	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section
OFF*4	10	<ul style="list-style-type: none"> • Coolant return from reservoir tank to radiator 	<ul style="list-style-type: none"> • Visual 	Should be initial level in reservoir tank	See "ENGINE MAINTENANCE" in MA section
OFF	11	<ul style="list-style-type: none"> • Cylinder head 	<ul style="list-style-type: none"> • Straight gauge feeler gauge 	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLINDER HEAD" in EM section
	12	<ul style="list-style-type: none"> • Cylinder block and pistons 	<ul style="list-style-type: none"> • Visual 	No scuffing on cylinder walls or piston	See "Inspection", "CYLINDER BLOCK" in EM section

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.


TROUBLE DIAGNOSIS FOR DTC P1900

Cooling Fan (DTC: 1308) (Cont'd)

COMPONENT INSPECTION

Cooling fan relays-1 and -2

Check continuity between terminals ③ and ⑤.



SEF511P

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



SEF512P

Cooling fan motor

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.



	Speed	Terminals	
		(⊕)	(⊖)
Cooling fan motor	Low	Ⓐ	Ⓓ
	High	Ⓐ, Ⓑ	Ⓒ, Ⓓ

Cooling fan motor should operate.



If NG, replace cooling fan motor.

Injector

EC-INJECT-01



Refer to last page (Foldout page).








TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Injector (Cont'd)


COMPONENT DESCRIPTION

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Injector (Cont'd)



COMPONENT INSPECTION


Injector

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.
Resistance: 10 - 14Ω at 25°C (77°F)
 If NG, replace injector.

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Start Signal


EC-S/SIG-01



- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST

Refer to last page (Foldout page).
M63 , F3

- RS
- BT
- HA
- EL
- IDX



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Start Signal (Cont'd) DIAGNOSTIC PROCEDURE

A

■ START SIGNAL CKT ■

1. CLOSE THROTTLE. SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY.

NEXT START

SEF191L



A

☆ MONITOR ☆ NO FAIL

START SIGNAL	OFF
CLSD TH/P SW	ON
AIR COND SIG	OFF
P/N POSI SW	ON


RECORD

SEF111P




Fuel Pump

SYSTEM DESCRIPTION



The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 180° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to perform. If the 180° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops



COMPONENT DESCRIPTION



The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump (Cont'd)

EC-F/PUMP-01



Refer to last page (Foldout page).

M63, F3
B1, M10











101	102	103	104	105	106	1	2	3	4	20	21	22	23	38	39	40	41	53	54	55	56					
107	108	109	110	111	112	5	6	7	8	9	10	24	25	26	27	28	42	43	44	45	46	57	58	59	60	61
113	114	115	116	117	118	11	12	13	14	19	29	30	31	32	33	47	48	62	63	64	65	70				
						15	16	17	18		34	35	36	37	49	50	51	52	66	67	68	69				

TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS





Fuel Pump (Cont'd) DIAGNOSTIC PROCEDURE

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump (Cont'd)




TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Fuel Pump (Cont'd) COMPONENT INSPECTION

Fuel pump relay

Check continuity between terminals ③ and ⑤.




Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.

Fuel pump


1. Disconnect fuel pump harness connector.
2. Check resistance between terminals (a) and (b).
Resistance: 0.2 - 5.0Ω at 25°C (77°F)
If NG, replace fuel pump.





GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Power Steering Oil Pressure Switch

EC-PST/SW-01



Refer to last page (Foldout page).




TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Power Steering Oil Pressure Switch (Cont'd)

DESCRIPTION

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



A

■ PW/ST SIGNAL CIRCUIT ■

HOLD STEERING WHEEL
IN A FULL
LOCKED POSITION
THEN
TOUCH START

NEXT START

MEF023E



A

☆ MONITOR ☆ NO FAIL


PW/ST SIGNAL OFF

RECORD

SEF591I




DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS


Power Steering Oil Pressure Switch (Cont'd)



B

CHECK GROUND CIRCUIT.
 1. Turn ignition switch "OFF".
 2. Disconnect power steering oil pressure switch harness connector.
 3. Check harness continuity between terminal **(b)** and engine ground.
Continuity should exist.
 If OK, check harness for short.

NG → Repair harness or connectors.



C

CHECK INPUT SIGNAL CIRCUIT.
 1. Disconnect ECM harness connector.
 2. Check harness continuity between ECM terminal **(25)** and terminal **(a)**.
Continuity should exist.
 If OK, check harness for short.

NG → Check the following.

- Harness connectors **(F3, M63)**
- Harness connectors **(M9, E109)**
- Harness for open or short between ECM and power steering oil pressure switch

If NG, repair harness or connectors.

CHECK COMPONENT
 (Power steering oil pressure switch).
 Refer to "COMPONENT INSPECTION" below.


NG → Replace power steering oil pressure switch.

OK → Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END



COMPONENT INSPECTION

Power steering oil pressure switch


1. Disconnect power steering oil pressure switch harness connector then start engine.
2. Check continuity between terminals **(a)** and **(b)**.

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No


If NG, replace power steering oil pressure switch.

IACV-Air Regulator


EC-AIRREG-01



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



Refer to last page (Foldout page).
 (M63), (F3)




TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

IACV-Air Regulator (Cont'd)

DESCRIPTION

The idle air control valve (IACV)-air regulator provides an air by-pass when the engine is cold for a fast idle during warm-up. A bimetal, heater and rotary shutter are built into the IACV-air regulator. When the bimetal temperature is low, the air by-pass port opens. As the engine starts and electric current flows through a heater, the bimetal begins to turn the shutter to close the by-pass port. The air passage remains closed until the engine stops and the bimetal temperature drops.



SEF636B

DIAGNOSTIC PROCEDURE

A

■ FUEL PUMP CIRCUIT ■
 PINCH FUEL FEED HOSE WITH FINGERS IS THERE ANY PRESSURE PULSATION ON THE FUEL FEED HOSE?
 OR
 DOES THE FUEL PUMP RELAY MAKE AN OPERATING SOUND EVERY 3 SECONDS?

NEXT NO YES

MEF591B

A


■ ACTIVE TEST ■

FUEL PUMP RELAY ON


== MONITOR ==
 CMPS-RPM(REF) 0rpm

ON ON/OFF OFF


MEF309F



SEF477P




SEF517R



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

IACV-Air Regulator (Cont'd)



B

CHECK POWER SUPPLY.


1. Turn ignition switch "OFF".
2. Disconnect EFI (IACV-air regulator) sub-harness connector.
3. Turn ignition switch "ON".
4. Check voltage between terminal (a) and ground with CONSULT or tester.

Battery voltage should exist for 5 seconds after ignition switch is turned "ON".

NG → Check the following.

- Harness connectors (M63, F3)
- Harness for open or short between IACV-air regulator sub-harness connector and fuel pump relay

If NG, repair harness or connectors.



C

CHECK GROUND CIRCUIT.

1. Turn ignition switch "OFF".
2. Check harness continuity between terminal (h) and body ground.

Continuity should exist.

If OK, check harness for short.

NG → Check the following.

- Harness for open or short between IACV-air regulator sub-harness connector and body ground

If NG, repair harness or connectors.

Check harness continuity between IACV-air regulator sub-harness connector and IACV-air regulator.


NG → Repair harness or connectors.

CHECK COMPONENT (IACV-air regulator).

Refer to "COMPONENT INSPECTION" below.

NG → Replace IACV-air regulator.

INSPECTION END



COMPONENT INSPECTION

IACV-air regulator

Disconnect EFI (IACV-air regulator) sub-harness connector.

- Check IACV-air regulator resistance.

Resistance:



Approximately 70 - 80Ω at 25°C (77°F)

- Check IACV-air regulator for clogging.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

IACV-FICD Solenoid Valve

EC-FICD-01



Refer to last page (Foldout page).
 E109, M9
 M63, F3







TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

IACV-FICD Solenoid Valve (Cont'd)


DESCRIPTION

The idle air adjusting (IAA) unit is made up of the IACV-AAC valve, IACV-FICD solenoid valve and idle adjusting screw. It receives the signal from the ECM and controls the idle speed at the preset value.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

IACV-FICD Solenoid Valve (Cont'd)



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

IACV-FICD Solenoid Valve (Cont'd)

COMPONENT INSPECTION

IACV-FICD solenoid valve

Disconnect EFI (IACV-FICD solenoid valve) sub-harness connector.

- Check for clicking sound when applying 12V direct current to terminals.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL




IDX



- Check plunger for seizing or sticking.
- Check for broken spring.


5th Position Switch

EC-5TH/P-01






Refer to last page (Foldout page).

(M63), (F3)
(E109), (M9)



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

5th Position Switch (Cont'd) DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK GROUND CIRCUIT.
1. Turn ignition switch "OFF".
2. Disconnect 5th position switch harness connector.
3. Check harness continuity between terminal (b) and engine ground.
Continuity should exist.
If OK, check harness for short.

NG → Check the following.
• Harness connectors (E202, E19)
• Harness for open or short between 5th position switch and engine ground
If NG, repair harness or connectors.

B
CHECK INPUT SIGNAL CIRCUIT.
1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal (7) and terminal (a).
Continuity should exist.
If OK, check harness for short.

NG → Check the following.
• Harness connectors (F3, M63)
• Harness connectors (M9, E109)
• Harness connectors (E17, E201)
• Harness for open or short between ECM and 5th position switch
If NG, repair harness or connectors.

CHECK COMPONENT
(5th position switch).
Refer to MT section ("ON-VEHICLE SERVICE").

NG → Replace 5th position switch.

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.



Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Rear Window Defogger Signal

EC-LD/SIG-01



Refer to last page (Foldout page).



- M10, B1
- M63, F3
- M20



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Rear Window Defogger Signal (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK OVERALL FUNCTION.
 1. Turn ignition switch "OFF".
 2. Disconnect ECM harness connector.
 3. Turn ignition switch "ON".
 4. Check voltage between ECM terminal (55) and ground with CONSULT or tester.
Voltage: Battery positive voltage

NG →

Check the following.

- Harness connectors (M63), (F3)
- Harness connectors (M10), (B1)
- Harness for open or short between ECM and rear window defogger relay
- Harness for open or short between rear window defogger timer and rear window defogger relay [For BASE grade models] Refer to EL section ("REAR WINDOW DEFOGGER").
- Harness for open or short between smart entrance control unit and rear window defogger relay [For SE grade models] Refer to EL section ("REAR WINDOW DEFOGGER").

If NG, repair harness or connectors.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.



Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Electrical Load Signal

EC-LD/SIG-01




Refer to last page (Foldout page).

M10, B1

M63, F3


M20



TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS

Electrical Load Signal (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK OVERALL FUNCTION.
 1. Turn ignition switch "OFF".
 2. Disconnect ECM harness connector.
 3. Turn ignition switch "ON".
 4. Check voltage between ECM terminal (55), (60) and ground with CONSULT or tester.
Voltage between (55) and ground:
 Rear window defogger "ON"
 Battery positive voltage
 Rear window defogger "OFF"
 0V
Voltage between (60) and ground:
 Lighting switch "ON" or daytime running light "ON"
 Battery positive voltage
 Lighting switch "OFF" or daytime running light "OFF"
 0V

NG
 Check the following.
 For terminal (55)
 • Harness connectors (M63), (F3)
 • Harness for open or short between ECM and rear window defogger relay
 • Harness for open or short between timer and rear window defogger relay
 Refer to EL section ("REAR WINDOW DEFOGGER").
 For terminal (60)
 • Harness connectors (M63), (F3), (M9), (E109)
 • Diode (E112)
 • Harness continuity between ECM and lighting switch
 • Diode (E111) for Canada models
 If NG, repair harness or connectors.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check loose connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

Alphabetical & P No. Index for DTC

ALPHABETICAL INDEX FOR DTC

Items (CONSULT screen terms)	DTC		Reference page	Items (CONSULT screen terms)	DTC		Reference page
	MIL*1	CONSULT GST*2			MIL*1	CONSULT GST*2	
*COOLANT TEMP SEN	0908	P0125	EC-131	FUEL SYS DIAG-LEAN	0115	P0171	EC-150
ABSOL PRESS SEN- SOR	0803	P0105	EC-110	FUEL SYS DIAG-RICH	0114	P0172	EC-155
A/T 1ST SIGNAL	1103	P0731	AT section	IACV-AAC VALVE	0205	P0505	EC-220
A/T 2ND SIGNAL	1104	P0732	AT section	IGN SIGNAL-PRIMARY	0201	P1320	EC-245
A/T 3RD SIGNAL	1105	P0733	AT section	INHIBITOR SWITCH	1101	P0705	AT section
A/T 4TH SIG OR TCC	1106	P0734	AT section	INT AIR TEMP SEN	0401	P0110	EC-117
A/T COMM LINE	—	P0600	EC-229	KNOCK SENSOR	0304	P0325	EC-166
A/T DIAG COMM LINE	0804	P1605	EC-281	LINE PRESSURE S/V	1205	P0745	AT section
CAMSHAFT POSI SEN	0101	P0340	EC-173	MAP/BARO SW SOL/V	1302	P1105	EC-239
CLOSED LOOP	0307	P0130	EC-141	MASS AIR FLOW SEN	0102	P0100	EC-105
CLOSED THRL POS SW	0203	P0510	EC-225	MULTI CYL MISFIRE	0701	P0300	EC-162
COOLANT TEMP SEN	0103	P0115	EC-122	OVERRUN CLUTCH S/V	1203	P1760	AT section
COOLING FAN	1308	P1900	EC-284	PARK/NEUT POSI SW	1003	P0705	EC-234
CRANK P/S (OBD) COG	0905	P1336	EC-250	PURG CONT/V & S/V	0807	P0443	EC-199
CRANK POS SEN (OBD)	0802	P0335	EC-169	PURG VOLUME CONT/V	1008	P1445	EC-268
CYL 1 MISFIRE	0608	P0301	EC-162	REAR O2 SENSOR	0707	P0136	EC-145
CYL 2 MISFIRE	0607	P0302	EC-162	SHIFT SOLENOID/V A	1108	P0750	AT section
CYL 3 MISFIRE	0606	P0303	EC-162	SHIFT SOLENOID/V B	1201	P0755	AT section
CYL 4 MISFIRE	0605	P0304	EC-162	TANK FUEL TEMP SEN	0402	P0180	EC-159
ECM	0301	P0605	EC-232	THROTTLE POSI SEN	0403	P0120	EC-126
EGR SYSTEM	0302	P0400	EC-177	THRTL POSI SEN A/T	1206	P1705	AT section
EGR TEMP SENSOR	0305	P1401	EC-258	TOR CONV CLUTCH SV	1204	P0740	AT section
EGRC SOLENOID/V	1005	P1400	EC-254	TW CATALYST SYSTEM	0702	P0420	EC-187
EGRC-BPT VALVE	0306	P0402	EC-185	VC/V BYPASS/V	0801	P1441	EC-263
ENGINE SPEED SIG	1207	P0725	AT section	VEHICLE SPEED SEN	0104	P0500	EC-216
EVAP PURG FLOW/ MON	0111	P1447	EC-274	VENT CONTROL VALVE	0903	P0446	EC-207
EVAP SYS PRES SEN	0704	P0450	EC-212	VHCL SPEED SEN A/T	1102	P0720	AT section
EVAP (SMALL LEAK)	0705	P0440	EC-190				
FLUID TEMP SENSOR	1208	P0710	AT section				
FRONT O2 SENSOR	0303	P0130	EC-136				
FR O2 SEN HEATER	0901	P0135	EC-142				

*1: These are controlled by NISSAN.

*2: These are prescribed by SAE J2012.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TROUBLE DIAGNOSIS — Index

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

DTC		Items (CONSULT screen terms)	Reference page
CONSULT GST*2	MIL*1		
P0000	0505	NO SELF-DIAGNOSTIC FAILURE INDICATED	—
P0100	0102	MASS AIR FLOW SEN	EC-105
P0105	0803	ABSOL PRESS SEN- SOR	EC-110
P0110	0401	INT AIR TEMP SEN	EC-117
P0115	0103	COOLANT TEMP SEN	EC-122
P0120	0403	THROTTLE POSI SEN	EC-126
P0125	0908	*COOLANT TEMP SEN	EC-131
P0130	0307	CLOSED LOOP	EC-141
P0130	0303	FRONT O2 SENSOR	EC-136
P0135	0901	FR O2 SEN HEATER	EC-142
P0136	0707	REAR O2 SENSOR	EC-145
P0171	0115	FUEL SYS DIAG-LEAN	EC-150
P0172	0114	FUEL SYS DIAG-RICH	EC-155
P0180	0402	TANK FUEL TEMP SEN	EC-159
P0300	0701	MULTI CYL MISFIRE	EC-162
P0301	0608	CYL 1 MISFIRE	EC-162
P0302	0607	CYL 2 MISFIRE	EC-162
P0303	0606	CYL 3 MISFIRE	EC-162
P0304	0605	CYL 4 MISFIRE	EC-162
P0325	0304	KNOCK SENSOR	EC-166
P0335	0802	CRANK POS SEN (OBD)	EC-169
P0340	0101	CAMSHAFT POSI SEN	EC-173
P0400	0302	EGR SYSTEM	EC-177
P0402	0306	EGRC-BPT VALVE	EC-185
P0420	0702	TW CATALYST SYSTEM	EC-187
P0440	0705	EVAP (SMALL LEAK)	EC-190

DTC		Items (CONSULT screen terms)	Reference page
CONSULT GST*2	MIL*1		
P0443	0807	PURG CONT/V & S/V	EC-199
P0446	0903	VENT CONTROL VALVE	EC-207
P0450	0704	EVAP SYS PRES SEN	EC-212
P0500	0104	VEHICLE SPEED SEN	EC-216
P0505	0205	IACV-AAC VALVE	EC-220
P0510	0203	CLOSED THRL POS SW	EC-225
P0600	—	A/T COMM LINE	EC-229
P0605	0301	ECM	EC-232
P0705	1003	PARK/NEUT POSI SW	EC-234
P0705	1101	INHIBITOR SWITCH	AT section
P0710	1208	FLUID TEMP SENSOR	AT section
P0720	1102	VHCL SPEED SEN A/T	AT section
P0725	1207	ENGINE SPEED SIG	AT section
P0731	1103	A/T 1ST SIGNAL	AT section
P0732	1104	A/T 2ND SIGNAL	AT section
P0733	1105	A/T 3RD SIGNAL	AT section
P0734	1106	A/T 4TH SIG OR TCC	AT section
P0740	1204	TOR CONV CLUTCH SV	AT section
P0745	1205	LINE PRESSURE S/V	AT section
P0750	1108	SHIFT SOLENOID/V A	AT section
P0755	1201	SHIFT SOLENOID/V B	AT section
P1105	1302	MAP/BARO SW SOL/V	EC-239
P1320	0201	IGN SIGNAL-PRIMARY	EC-245
P1400	1005	EGRC SOLENOID/V	EC-254
P1401	0305	EGR TEMP SENSOR	EC-258
P1441	0801	VC/V BYPASS/V	EC-263
P1445	1008	PURG VOLUME CONT/V	EC-268
P1447	0111	EVAP PURG FLOW/ MON	EC-274
P1605	0804	A/T DIAG COMM LINE	EC-281
P1705	1206	THRTL POSI SEN A/T	AT section
P1760	1203	OVERRUN CLUTCH S/V	AT section
P1900	1308	COOLING FAN	EC-284

*1: These are controlled by NISSAN.

*2: These are prescribed by SAE J2012.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

FUEL PRESSURE REGULATOR	
Fuel pressure at idling kPa (kg/cm ² , psi)	
Vacuum hose is connected	Approximately 235 (2.4, 34)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

Inspection and Adjustment

Idle speed*1	rpm	
No-load*2 (in "N" position)		700±50
Air conditioner: ON (in "N" position)		1,000 or more
Ignition timing		20°±2° BTDC
Throttle position sensor idle position	V	0.3 - 0.7

*1: Feedback controlled and needs no adjustments

*2: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater, fan & rear defogger)

IGNITION COIL

Primary voltage	V	Battery voltage (11 - 14)
Primary resistance [at 20°C (68°F)]	Ω	Approximately 1.0
Secondary resistance [at 20°C (68°F)]	kΩ	Approximately 26.0

MASS AIR FLOW SENSOR

Supply voltage	V	Battery voltage (11 - 14)
Output voltage	V	1.3 - 1.7
Mass air flow	gm/sec	1.5 - 4.5 at idle* 6.0 - 14.0 at 2,500 rpm*

*: Engine is warmed up sufficiently and idling under no-load.

ENGINE COOLANT TEMPERATURE SENSOR

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 kΩ
50 (122)	0.68 - 1.00 kΩ
90 (194)	0.236 - 0.260 kΩ

EGR TEMPERATURE SENSOR

EGR temperature °C (°F)	Voltage (V)	Resistance (MΩ)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

FUEL PUMP

Resistance [at 25°C (77°F)]	Ω	0.2 - 5.0
-----------------------------	---	-----------

IACV-AAC VALVE

Resistance [at 25°C (77°F)]	Ω	Approximately 10.0
-----------------------------	---	--------------------

INJECTOR

Resistance [at 25°C (77°F)]	Ω	10 - 14
-----------------------------	---	---------

RESISTOR

Resistance [at 25°C (77°F)]	kΩ	Approximately 2.2
-----------------------------	----	-------------------

THROTTLE POSITION SENSOR

Accelerator pedal conditions	Resistance [at 25°C (77°F)]
Completely released	Approximately 0.5 kΩ
Partially released	0.5 - 4.0 kΩ
Completely depressed	Approximately 4.0 kΩ

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CALCULATED LOAD VALUE

	Calculated load value %
At idle	10.0 - 24.0
At 2,500 rpm	11.0 - 25.0

INTAKE AIR TEMPERATURE SENSOR

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 k Ω
80 (176)	0.27 - 0.38 k Ω

REAR HEATED OXYGEN SENSOR HEATER

Resistance [at 25°C (77°F)]	Ω	5.2 - 8.2
-----------------------------	----------	-----------

CRANKSHAFT POSITION SENSOR (OBD)

Resistance [at 20°C (68°F)]	Ω	166.5 - 203.5
-----------------------------	----------	---------------