

ELECTRICAL SYSTEM

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

SECTION EL

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

CONTENTS

PRECAUTIONS	3	Wiring Diagram	28
Supplemental Restraint System (SRS) "AIR BAG"	3	Aiming Adjustment	30
Special Service Tools	3	Bulb Replacement	31
HARNES CONNECTOR	4	EXTERIOR LAMP	32
Description	4	Clearance, License, Tail and Stop Lamps/Wiring Diagram	32
STANDARDIZED RELAY	5	Back-up Lamp/Wiring Diagram	33
Description	5	Front Fog Lamp/Wiring Diagram	34
POWER SUPPLY ROUTING	8	Turn Signal and Hazard Warning Lamps/Wiring Diagram	35
Wiring Diagram	8	Stop and Tail Lamp Sensor Check	36
Fuse Block Internal Circuit	10	Combination Flasher Unit Check	36
Fuse	11	Bulb Specifications	36
Fusible Link	11	INTERIOR LAMP	37
Circuit Breaker Inspection	11	Illumination/Wiring Diagram	37
BATTERY	12	Interior, Spot, Foot and Luggage Room Lamps/Wiring Diagram	38
How to Handle Battery	12	METER AND GAUGES	40
Service Data and Specifications (SDS)	14	Combination Meter	40
STARTING SYSTEM	15	Speedometer, Tachometer, Temp., Oil, Fuel and Boost Gauges/Wiring Diagram	41
Wiring Diagram	15	Inspection/Fuel Gauge and Water Temperature Gauge	42
Construction	16	Fuel Tank Gauge Unit Check	43
Removal and Installation	16	Fuel Warning Lamp Sensor Check	43
Service Data and Specifications (SDS)	17	Thermal Transmitter Check	44
CHARGING SYSTEM	18	Oil Pressure Sending Unit Check	44
Wiring Diagram	18	Boost Sensor Check	44
Construction	19	Vehicle Speed Sensor Signal Check	44
Removal and Installation	20	WARNING LAMPS AND CHIME	45
Service Data and Specifications (SDS)	21	Warning Lamps/Schematic	45
COMBINATION SWITCH	22	Warning Lamps/Wiring Diagram	46
Combination Switch/Check	22	Warning Chime/Wiring Diagram	47
Combination Switch/Replacement	23	Diode Check	48
INSTRUMENT SWITCH	24	Warning Chime Check	48
Check	24		
HEADLAMP	26		
Operation (Daytime light system equipped model)	26		
Schematic	26		

CONTENTS (Cont'd)

TIME CONTROL SYSTEM	49	Antenna Rod Replacement	84
Description	49	Radio Fuse Check	85
Wiring Diagram	50	Window Antenna Repair	86
Trouble Diagnoses	51	POWER SEAT	87
WIPER AND WASHER	63	Wiring Diagram — SEAT —	87
Front Wiper and Washer/Wiring Diagram	63	MULTI-REMOTE CONTROL SYSTEM	88
Rear Wiper and Washer/Wiring Diagram	64	Wiring Diagram — MULTI —	88
Headlamp Washer/Wiring Diagram	65	Circuit Diagram for Quick Pinpoint Check	90
Installation	66	Trouble Diagnoses Preliminary Inspection	91
Washer Nozzle Adjustment	67	Trouble Diagnoses	92
Check Valve	67	Replacing Remote Controller or Control Unit	98
Wiper Amplifier Check	67	AUTOMATIC SPEED CONTROL DEVICE (ASCD)	99
POWER WINDOW	68	Component Parts and Harness Connector	
Wiring Diagram	68	Location	99
Power Window Amp. Inspection	69	Wiring Diagram	100
POWER DOOR LOCK	70	Trouble Diagnoses	101
Wiring Diagram	70	THEFT WARNING SYSTEM	119
Door Lock Timer Inspection	71	Component Parts and Harness Connector	
Electrical Components Inspection	72	Location	119
POWER DOOR MIRROR	73	Wiring Diagram	120
Wiring Diagram	73	Trouble Diagnoses	125
TRUNK LID AND FUEL FILLER LID OPENER	74	LOCATION OF ELECTRICAL UNITS	144
Wiring Diagram	74	Engine Compartment	144
CONVERTIBLE ROOF	75	Passenger Compartment	145
Wiring Diagram	75	Luggage Compartment	146
HORN, CIGARETTE LIGHTER, CLOCK	77	HARNES LAYOUT	148
Wiring Diagram	77	Outline	148
REAR WINDOW DEFOGGER & HEATER		Engine Room Harness	149
MIRROR	78	Engine Control Harness	152
Wiring Diagram	78	Main Harness	154
Filament Check	79	Air Bag Harness	157
Filament Repair	80	Body Harness	158
AUDIO AND POWER ANTENNA	81	Door Harness LH	164
Audio/Wiring Diagram	81	Door Harness RH	164
Power Antenna/Wiring Diagram	83	Back Door Harness	165
Location of Antenna	84	Alternator Harness	165

PRECAUTIONS



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bags (located in the center of the steering wheel and on the instrument panel on the passenger side), sensors, a diagnosis unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- a. To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- b. Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- c. All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS.

Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description
26081 30P00 (right) 26086 30P00 (left) Headlamp aimer adapter	 <p>Attaching headlamp aimer</p> <p>NT217</p>
(J36126) Washer nozzle adjusting tool	 <p>Adjusting washer nozzle</p> <p>NT218</p>

CI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]




SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make

1T 1 Transfer

1M•1B 1 Make, 1 Break















SEL882H

EL

IDX

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE or GREEN
2M				BROWN
1M-1B				GRAY

SEL883H

STANDARDIZED RELAY

NOTE

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

POWER SUPPLY ROUTING


Wiring Diagram



① Power antenna timer, A/T control unit, Theft warning control unit, Auto A/C control amp., Key hole illumination, Foot lamp, Audio, Clock, Air bag control unit, Warning chime, Interior lamp, Spot lamp, Luggage room lamp (C), Trunk room lamp (C), Door mirror defogger relay
 ② Stop lamp switch, ASCD control unit, shift lock control unit, Anti-lock brake system control unit, Power steering control unit

POWER SUPPLY ROUTING


Wiring Diagram (Cont'd)




GI
MA
EM
LC
EF &
TC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER SUPPLY ROUTING

Fuse Block Internal Circuit



POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX





Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness or vinyl or rubber parts.



Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.




Circuit breakers are used in the following systems.

- Power window & power door lock
- Power seat

BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
 - The terminal connections should be clean and tight.
 - At every routine maintenance, check the electrolyte level.
-
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)
-
- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL



WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

BATTERY

How to Handle Battery (Cont'd)


- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



SULPHATION

When a battery has been left unattended for a long period of time and has a specific gravity of less than 1.100, it will be completely discharged, resulting in sulphation on the cell plates.

Compared with a battery discharged under normal conditions, the current flow in a "sulphated" battery is not as smooth although its voltage is high during the initial stage of charging, as shown in the figure at the left.



SPECIFIC GRAVITY CHECK

Read hydrometer and thermometer indications at eye level.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

BATTERY

How to Handle Battery (Cont'd)

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps Time

50	1 hour
25	2 hours
10	5 hours
5	10 hours


Service Data and Specifications (SDS)

Applied model	M/T	A/T	
		Except convertible	Convertible
Type	65D26L	80D26L	55D23L
Capacity	V-AH	12-65	12-60


STARTING SYSTEM

FOR U.S.A. MODEL &
CANADA A/T MODEL

Wiring Diagram





FOR CANADA M/T MODEL



STARTING SYSTEM

Construction



Removal and Installation

REMOVAL

1. Remove starter insulator.
2. Remove starter harness connector and cable.
3. Remove starter fixing bolt and nut and remove starter.

INSTALLATION

- Installation procedure is in reverse order of removal.

STARTING SYSTEM

Service Data and Specifications (SDS)

STARTER

Type		M2T25281
		Reduction gear
System voltage		V 12
No-load	Terminal voltage	V 11.0
	Current	A 70
	Revolution	rpm More than 2,000
Minimum length of brush		mm (in) 11.5 (0.453)
Brush spring tension (With new brush)		N (kg, lb) 13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)
Minimum diameter of commutator		mm (in) 31.4 (1.236)
Difference in height of pinion assembly		mm (in) 0.3 - 2.0 (0.012 - 0.079)

GI

MA

EM

LG

EF &

EC

FE

GL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX



CHARGING SYSTEM

Wiring Diagram



CHARGING SYSTEM

Construction



***Rear bearing**

CAUTION:

Rear cover may be hard to remove because a ring is used to lock outer race of rear bearing. Be careful not to lose this ring during removal.


GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

CHARGING SYSTEM


Removal and Installation

REMOVAL

1. Loosen alternator belt.
2. Remove alternator adjusting bar.
3. Remove harness connector and cable from alternator.



4. Remove stabilizer bracket fixing bolts.
5. Remove radiator lower hose bracket and push lower hose upward to make room.



6. Remove alternator fixing bolt and take out alternator as shown in the figure.

INSTALLATION

- Installation procedure is in reverse order of removal.

CHARGING SYSTEM

Service Data and Specifications (SDS)

ALTERNATOR

Type		LR180-734C	A2T33593A
		HITACHI make	mitsubishi make
Applied engine		VG30DE	VG30DETT
Nominal rating	V-A	12-80	12-90
Ground polarity		Negative	
Minimum revolution under no-load (when 13.5 volts is applied)	rpm	Less than 1,000	Less than 1,300
Hot output current	A/rpm	More than 65/2,500 More than 80/5,000	More than 20/1,300 More than 61/2,500
Regulated output voltage	V	14.1 - 14.7	
Minimum length of brush	mm (in)	More than 6.0 (0.236)	5.0 (0.197)
Brush spring pressure	N (g, oz)	1.000 - 3.432 (102 - 350, 3.60 - 12.34)	4.609 - 5.786 (470 - 590, 16.58 - 20.81)
Slip ring minimum outer diameter	mm (in)	More than 26.0 (1.024)	More than 22.1 (0.870)

GI

MA

EM

LC

EF &

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT





HA

EL

IDX

COMBINATION SWITCH

Combination Switch/Check



ASC SWITCH

	RESUME ACCEL	N	SET COAST	OFF	CANCEL
13	<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
12	<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
11	<input type="checkbox"/>				<input type="checkbox"/>


DIMMER SWITCH

	A	B	C
5			<input type="checkbox"/>
6			<input type="checkbox"/>
8			<input type="checkbox"/>
9			<input type="checkbox"/>
43		<input type="checkbox"/>	
44		<input type="checkbox"/>	

TURN SIGNAL SWITCH

	R	N	L
1	<input type="checkbox"/>		<input type="checkbox"/>
2	<input type="checkbox"/>		<input type="checkbox"/>
3			<input type="checkbox"/>


COMBINATION SWITCH




Combination Switch/Replacement

For removing/installing air bag module and spiral cable, refer to RS section.

- Each switch can be replaced without removing combination switch base.



- To remove combination switch base, remove base attaching screw and turn after pushing on it.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

INSTRUMENT SWITCH

Check



LIGHTING SWITCH

	OFF	1ST	2ND
1			○
2			○
3			○
4			○
5		○	○
6		○	○
7	⊗	○	○

REAR DEFOGGER & HEATER MIRROR SWITCH

	OFF	ON
11		○
12		○
13	⊗	○

ASCD MAIN SWITCH

	OFF	N	ON
14			○
15		○	○
16		○	○

FRONT FOG LAMP SWITCH

	OFF	ON
17		○
18		○
19	⊗	○

HEADLAMP WASHER SWITCH

	OFF	ON
8		○
9		○

ILLUMINATION CONTROL SWITCH

	V	N	A
20			○
21	○		○
12	○		○


CLUSTER ILLUMINATION

22	○
23	○


INSTRUMENT SWITCH

Check (Cont'd)







A/C SWITCH AUTO TYPE



A/C SWITCH MANUAL TYPE



HAZARD SWITCH



CI
MA
EM
LG
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Operation (Daytime light system equipped model)

After starting the engine with the lighting switch in the "OFF" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	x	x	○	x	x	○	○	x	○	△*	△*	○	△*	△*	○	○	x	○
	Low beam	x	x	x	x	x	x	x	○	x	x	x	x	x	x	x	x	○	x
Clearance and tail lamp		x	x	x	○	○	○	○	○	○	x	x	x	○	○	○	○	○	○
License and instrument illumination lamp		x	x	x	○	○	○	○	○	○	x	x	x	○	○	○	○	○	○

○ : Lamp "ON"

x : Lamp "OFF"


△ : Lamp dims.

□ : Added functions

* : When starting the engine with the parking brake released, the daytime light system will come ON.
When starting the engine with the parking brake pulled, the daytime light system will not come ON.


Schematic

FOR CANADA



HEADLAMP Schematic (Cont'd)

FOR U.S.A.




- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

HEADLAMP


Wiring Diagram

FOR CANADA



HEADLAMP Wiring Diagram (Cont'd)

FOR U.S.A.



HEADLAMP

Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall, screen or headlamp tester. When operating any aimer, it should be in good repair, calibrated and used according to the operation manual supplied with the unit.

HEADLAMP AIMER ADAPTER



Attach the headlamp aimer using Tool (aimer adapter). Place the aimer adapter on the 3 points of the headlamp, then push the lever down to secure it.

If no aimer is available, aiming adjustment can be done as follows:


For details, refer to the regulations in your own country.

CAUTION:

- Make sure tires are inflated to correct pressures.
- Place vehicle and tester on the same flat surface.
- See that there is no load in the vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).



- Turn headlamp low beam on.
- Use adjusting screws to perform aiming adjustment.
 - First tighten the adjusting screw all the way and then make adjustment by loosening the screw.




- Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown at left.
 - Dotted lines in illustration show center of headlamp.
- "H": Horizontal center line of headlamps
 "W_L": Distance between each headlamp center


HEADLAMP

Aiming Adjustment (Cont'd)

Push the tongue and pull the lever up to remove the adapter.



Bulb Replacement



The Headlamp is a semi-sealed beam type which uses a replaceable Headlamp (halogen) bulb. A bulb can be replaced from inside the engine compartment without removing the Headlamp assembly.

CAUTION:

High pressure halogen gas is sealed inside the halogen bulb. The bulb may break if the glass envelope is scratched or the bulb is dropped.

Hold the plastic base when handling the bulb. Never touch the glass envelope.

REMOVING HEADLAMP BULB

1. Disconnect battery negative cable.
2. Disconnect electrical connector from rear end of bulb.
3. Turn plastic base counterclockwise until it is free from headlamp reflector, then remove it.
4. Remove headlamp bulb. Do not shake or rotate bulb when removing it.

REPLACING HEADLAMP BULB

1. Insert bulb into headlamp reflector with plastic base facing downward and turn it clockwise until it stops.
2. Push electrical connector into bulb plastic base until it snaps and stops.

CAUTION:


Do not touch the bulb.

- **Use the same number and wattage as originally installed:**

	Inside (High beam)	Outside (Low beam)
Wattage (W)	65	55
Bulb no.	9005	9006


EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/ Wiring Diagram



EXTERIOR LAMP


Back-up Lamp/Wiring Diagram



GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram






US : For U.S.A.
CN : For Canada

Turn Signal and Hazard Warning Lamps/Wiring Diagram



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

EXTERIOR LAMP



Stop and Tail Lamp Sensor Check

- Before checking, ensure that bulbs meet specifications.

STOP LAMP

1. Start engine.
2. Stop lamp switch on.

TAIL LAMP

1. Start engine.
2. Lighting switch on.

Combination Flasher Unit Check


- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

Bulb Specifications

	Wattage (W)	Bulb No.
Front combination lamp		
Turn signal/Clearance	27/8	1157
Front side marker	3.8	194
Rear combination lamp		
Turn signal	27	1156
Stop/Tail	27/8	1157
Back-up lamp	27	1156
Rear side marker lamp	3.8	194
License plate lamp	3.8	194
Front fog lamp	35	
High-mounted stop lamp	13	
Interior lamp	10	
Spot lamp	3.6	
Luggage room lamp	3.4	
Foot lamp	2	

INTERIOR LAMP

Illumination/Wiring Diagram




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

INTERIOR LAMP

Interior, Spot, Foot and Luggage Room Lamps/ Wiring Diagram


EXCEPT CONVERTIBLE



INTERIOR LAMP

Interior, Spot, Foot and Luggage Room Lamps/ Wiring Diagram (Cont'd)



CONVERTIBLE



- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX


METER AND GAUGES

Combination Meter







METER AND GAUGES

Speedometer, Tachometer, Temp., Oil, Fuel and Boost Gauges/Wiring Diagram




CI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Inspection/Fuel Gauge and Water Temperature Gauge



Main tank



Sub tank



Fuel Tank Gauge Unit Check

- For removal, refer to FE section.
- Check the resistance between terminals **G** and **E**.

2 seater model:

Ohm-meter		Float position		Resistance value (Ω)		
(+)	(-)	mm (in)				
G	E	1*	Full	Main	41.0 (1.614)	8.6 - 11.6
			Sub	40.0 (1.575)		
		2*	1/2	Main	137.0 (5.39)	55.4 - 68.6
			Sub	139.5 (5.49)		
		3*	Empty	Main	232.0 (9.13)	157.6 - 170.6
				Sub	261.0 (10.28)	

1* and 3*: When float rod is in contact with stopper.


2+2 seater model:


Ohm-meter		Float position		Resistance value (Ω)	
(+)	(-)	mm (in)			
G	E	1*	Full	21.0 (0.827)	4.3 - 5.8
		2*	1/2	115.0 (4.53)	27.7 - 34.3
		3*	Empty	207.0 (8.15)	78.3 - 84.8

1* and 3*: When float rod is in contact with stopper.

Fuel Warning Lamp Sensor Check

- It will take a short time for the bulb to light.






Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90Ω
100°C (212°F)	Approx. 21 - 24Ω



Oil Pressure Sending Unit Check

Check the resistance between the terminals of oil pressure sending unit and body ground.

Oil pressure kPa (kg/cm ² psi)	Resistance (Ω)
0 (0, 0) (Engine is stopped)	More than 83
392 (4, 57)	Approx. 26 - 37
588 (6, 85)	Approx. 18 - 26




Boost Sensor Check

1. Connect vacuum pump gauge to boost sensor vacuum hose.
2. Disconnect harness connector from boost sensor and connect battery and voltmeter as shown.
3. Apply vacuum pressure to boost sensor by vacuum pump gauge and measure voltages.

Voltage:

**Approx. 2.2V at 0 kPa (0 kg/cm², 0 psi)
(Atmospheric pressure)**

Approx. 1.3V at -55 kPa (-0.56 kg/cm², -8 psi)




Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transmission.
Location: Refer to "LOCATION OF ELECTRICAL UNITS".
2. Turn vehicle speed sensor pinion quickly and measure voltage across (a) and (b).


WARNING LAMPS AND CHIME

Warning Lamps/Schematic




- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

Warning Lamps/Wiring Diagram




Warning Chime/Wiring Diagram



GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX


WARNING LAMPS AND CHIME




Diode Check

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual of the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.



Warning Chime Check

TIME CONTROL SYSTEM

Description

FUNCTION

- Time control unit has the following functions.

	Item	Details of control
1, 2	Intermittent wiper control	Regulates intermittent time from approximately 3 to 23 seconds depending on the intermittent wiper volume setting.
3	Washer and wiper combination control	Wiper is operated in conjunction with washer switch.
4	Light warning chime timer	When driver's door is opened with light switch ON and ignition switch OFF, warning chime sounds.
5	Ignition key warning chime timer	When driver's door is opened with ignition switch OFF, warning chime sounds.
6	Seat belt warning chime timer	Sounds warning chime for about 7 seconds if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened).
7	Seat belt warning lamp timer	Seat belt warning lamp blinks for about 7 seconds when ignition switch is turned to "ON".
8	Rear defogger timer	Rear defogger operates for about 15 minutes when defogger switch is ON.
9	Interior lamp timer	Fades out interior lamp when driver's side door is opened and closed.
10	Door key hole illumination	Illuminates for about 7 seconds when door outside handle is pulled.
11	Illumination control	The brightness of the instrument panel light can be adjusted.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TIME CONTROL SYSTEM

Wiring Diagram



TIME CONTROL SYSTEM

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE	Preliminary Check			Main Power Supply and Ground Circuit Check	Diagnostic Procedure											
	EL-52	EL-52	EL-52		EL-54	EL-54	EL-55	EL-55	EL-56	EL-57	EL-58	EL-59	EL-59	EL-60	EL-61	EL-62
REFERENCE PAGE	EL-52	EL-52	EL-52	EL-54	EL-54	EL-55	EL-55	EL-56	EL-57	EL-58	EL-59	EL-59	EL-60	EL-61	EL-62	
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Main power supply and Ground circuit	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	Diagnostic Procedure 9	Diagnostic Procedure 10	Diagnostic Procedure 11	
Wiper & washer	Intermittent wiper does not operate.			<input type="checkbox"/>	<input type="checkbox"/>											
	Intermittent time of wiper cannot be adjusted.					<input type="checkbox"/>										
	Wiper and washer activate individually but not in combination.						<input type="checkbox"/>									
Warning	Light warning chime does not activate.	<input type="checkbox"/>		<input type="checkbox"/>				<input type="checkbox"/>								
	Ignition key warning chime does not activate.		<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>							
	Seat belt warning chime does not activate.			<input type="checkbox"/>	<input type="checkbox"/>					<input type="checkbox"/>						
	Seat belt warning lamp does not come on, or does not go off after coming on.				<input type="checkbox"/>						<input type="checkbox"/>					
Rear defogger	Rear defogger does not activate, or go off after activating.			<input type="checkbox"/>								<input type="checkbox"/>				
Illumination	Interior lamp does not fade out after driver's door is closed.			<input type="checkbox"/>									<input type="checkbox"/>			
	Door key hole illumination does not come on even if door handle is pulled.				<input type="checkbox"/>									<input type="checkbox"/>		
	Illumination control does not actuate.														<input type="checkbox"/>	

GI
 MA
 EM
 LG
 EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA

EL

IDX


TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK


Preliminary check 1

- Light warning chime does not activate.




Preliminary check 2

- Ignition key warning chime does not activate.



Preliminary check 3


- Seat belt warning chime does not activate.



TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



(US) : For U.S.A.
 (CN) : For Canada
 (C) : Except convertible model

1 2 3 4 5 6 7 8 9 10
 11 12 13 14 15 16 17 18 19 20

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)





MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply

Terminals	Battery voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
⑨ - ⑮	Yes	Yes	Yes
⑤ - ⑮	No	No	Yes
② - ⑮	No	Yes	Yes


Ground circuit

Terminals	Continuity
⑮ - Ground	Yes



DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.



A

INTERMITTENT WIPER VOLUME INPUT SIGNAL CHECK

Measure resistance between control unit harness terminals ⑭ and ⑮ while turning intermittent wiper volume.


Position of wiper knob	Resistance [Ω]
S	0
L	Approx. 1 k

OK

Replace control unit.

NG

Check intermittent wiper volume.
Check harness continuity between TCU and wiper switch.



DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.

A

WASHER SWITCH INPUT SIGNAL CHECK

- 1) Turn ignition switch to "ACC".
- 2) Measure voltage between control unit harness terminals ⑬ and ⑭.

Condition of washer switch	Voltage [V]
OFF	Approx. 12
ON	0

NG

Check harness continuity between TCU and washer switch.

OK

B

WIPER AMP. OUTPUT SIGNAL CHECK

Measure voltage between control unit harness terminals ① and ⑮ after operating washer switch.


0V for approx. 3 seconds after washer has operated.

NG

Replace control unit.

OK

Replace wiper amp.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX





TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Light warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 1" before referring to the following flow chart.






TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Ignition key warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 2" before referring to the following flow chart.



A Step 3

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑮ and ⑱.

Condition of driver's door	Voltage [V]
Door is closed.	Approx. 12
Door is open.	0

NG → Check door switch. Check harness continuity between TCU and door switch.

B Step 2

CHIME OUTPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑲ and ⑳.

Condition of driver's door	Voltage [V]
Door is closed.	Approx. 12
Door is open.	Pointer deflects intermittently

OK → Check chime. Check harness continuity between TCU and chime.

C Step 1

IGNITION KEY SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑩ and ⑮.

Condition	Voltage [V]
Key is inserted.	Approx. 12
Key is pulled.	0

NG → Check ignition key switch. Check harness continuity between TCU and ignition key switch.

OK → Replace control unit.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: Seat belt warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 3" before referring to the following flow chart.






TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)




DIAGNOSTIC PROCEDURE 7

SYMPTOM: Seat belt warning lamp does not come on, or does not go off after coming on.



DIAGNOSTIC PROCEDURE 8

SYMPTOM: Rear defogger does not activate, or does not go off after activating.





GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9

SYMPTOM: Interior lamp does not fade out after driver's door is closed.



A

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑩ and ⑬.

Condition of driver's door	Voltage [V]
Door is closed.	Approx. 12
Door is open.	0

NG

Check door switch.
Check harness continuity between TCU and door switch.

OK

B

INTERIOR LAMP SIGNAL CHECK
Measure voltage between control unit harness terminals ⑭ and ⑮.

Condition of driver's door	Voltage [V]
Door is closed.	0 → Approx. 12
Door is open.	0

OK

Check interior lamp and harness between TCU and interior lamp.

NG



Replace TCU.

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 10

SYMPTOM: Door key hole illumination does not come on even if door handle is pulled.



A

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ⑰ and ⑱.

Condition of driver's handle	Voltage [V]
Handle is pulled.	0
Handle is released.	Approx. 12

NG → Check door handle switch. Check harness continuity between TCU and door handle switch.

OK ↓

B

KEY HOLE ILLUMINATION SIGNAL CHECK
Measure voltage between control unit harness terminals ⑳ and ㉑.

Condition of driver's door	Voltage [V]
Door is closed.	0 → Approx. 12
Door is open.	0

OK → Check key hole illumination and harness between TCU and key hole illumination.

NG ↓

Replace TCU.











GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 11

SYMPTOM: Illumination control does not actuate.




WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram



GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

Rear Wiper and Washer/Wiring Diagram




REAR WIPER AND WASHER SWITCH

	MIST	OFF	ON	WASH
20	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
21	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
22	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
23	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Ⓒ : VG30DETT engine A/T model for Canada and VG30DE engine model except convertible

Headlamp Washer/Wiring Diagram



- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

WIPER AND WASHER

Installation

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "C" or "D" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "C" or "D".

Clearance "C": 0 - 10 mm (0 - 0.39 in)

Clearance "D": 73 - 88 mm (2.87 - 3.46 in)

- Tighten windshield wiper arm nuts to specified torque.


Front wiper:

: 26 - 32 N·m (2.7 - 3.3 kg·m, 20 - 24 ft·lb)

Rear wiper:


: 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)

Front wiper and washer



- *1: 364 (14.33)
- *2: 200 (7.87)
- *3: 411 (16.18)
- *4: 255 (10.04)
- *5: 173 (6.81)
- *6: 198 (7.80)
- *7: 370 (14.57)
- *8: 416 (16.38)


All the diameters of these circles are less than 80 (3.15).



Unit: mm (in)


SEL025N

Rear wiper and washer




- *1: 170 (6.69)
- *2: 50 (1.97)
- *3: 220 (8.66)

All the diameters of these circles are less than 80 (3.15).



Unit: mm (in)


SEL026N



SEL024J

- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER AND WASHER



Washer Nozzle Adjustment

- Adjust washer nozzle with J36126 as shown in the figure at left.

Before attempting to turn the nozzle, gently tap the end of the tool to free the nozzle. This will prevent "rounding out" the small female square in the center of the nozzle.

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA




EL

IDX



Check Valve

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.




Wiper Amplifier Check

- Connect as shown in the figure at left.
- If test lamp comes on when connected to terminal ⑥ and battery ground, wiper amplifier is normal.


POWER WINDOW

Wiring Diagram



POWER WINDOW

Power Window Amp. Inspection



AMP. OPERATION

Connections	Operations						
	Manual operation			One-touch (Auto) Operation			
24 Power source (IGN)	12V	12V	12V	12V	12V	12V	12V
27 Ground	Ground	Ground	Ground	Ground	Ground	Ground	Ground
23 From ignition SW (ON or ST)	ON or ST	ON or ST	ON or ST	ON or ST	ON or ST	ON or ST	ON or ST
28 Input signal To FR driver side power window SW (AUTO) (1)	OFF	OFF	OFF	OFF	ON	OFF	OFF
21 Input signal To FR driver side power window SW (UP) (3)	OFF	ON	OFF	OFF	OFF	OFF	OFF
22 Input signal To FR driver side power window SW (DOWN) (2)	OFF	OFF	ON	OFF	ON	OFF	OFF
25 Output signal FR driver side regulator ("Up" power source)	Approx. 0V	Approx. over 9V	Approx. 0V	Approx. 0V	Approx. 0V	Approx. 0V	Approx. 0V
26 Output signal FR driver side regulator ("Down" power source)	Approx. 0V	Approx. 0V	Approx. over 9V	Approx. 0V	Approx. over 9V	Approx. 0V	Approx. over 9V
Regulator Operating Condition	Stop	Upward operation	Downward operation	Stop	Starting	Keeps operating until fully open, then stops automatically.	
					Downward operation		

Carry out this operation check in this chart from left to right

POWER WINDOW AMP. – Front driver side door (Behind door trim)

SBF219F

POWER DOOR LOCK

Door Lock Timer Inspection

- Carry out the following inspections:

(1) Check power source and ground.

(2) Check input signals.

If the input signal is NG, go to ELECTRICAL COMPONENTS INSPECTION.

(3) Check output signals.

If the input signal is OK and the output signal is NG, replace the door lock timer.

If the input signal and output signal are OK, check door lock actuator in ELECTRICAL COMPONENTS INSPECTION.

GI

MA

EM

Lock & unlock operation by lock knob or main switch

(The voltages are approximate values.)

LC

EF &
EC

FE

CL

MT

AT

PD

	Connections	Operations			
		Lock knob switch LH		Lock knob switch RH	
		Unlock → Lock	Lock → Unlock	Unlock → Lock	Lock → Unlock
1	Power source	12V	12V	12V	12V
5	Ground	Ground	Ground	Ground	Ground
7	Key switch	Either key switch or door switches are off.			
4	Door switch LH	(Key is not in the ignition or all doors are closed.)			
10	Input signals Lock knob switch LH	ON → OFF (Ground) → (Open)	OFF → ON (Open) → (Ground)	—	—
9	Input signals Lock knob switch RH	—	—	ON → OFF (Ground) → (Open)	OFF → ON (Open) → (Ground)
2	Output signals Door lock actuator (Lock power source)	0V → 12V → 0V (Approx. 1.0 sec.)	0V	0V → 12V → 0V (Approx. 1.0 sec.)	0V
3	Output signals Door lock actuator (Unlock power source)	0V	0V → 12V → 0V (Approx. 1.0 sec.)	0V	0V → 12V → 0V (Approx. 1.0 sec.)

Key reminder operation

(The voltages are approximate values.)

FA

RA

BR

ST

RS

BT

HA

	Connections	Operations			
		Lock knob switch LH		Lock knob switch RH	
		Unlock →	Lock →	Automatically unlocked	Unlock → Lock → Automatically unlocked
1	Power source	12V		12V	
5	Ground	0V		0V	
7	Key switch	ON (12V) — Key is in the ignition.			
4	Door switch	ON (Ground) — Either door is open.			
10	Input signals Lock knob switch LH	ON → OFF (Ground) → (Open)	ON → ON (Ground) → (Ground)	—	
9	Input signals Lock knob switch RH	—		ON → OFF (Ground) → (Open)	ON → ON (Ground) → (Ground)
2	Output signals Door lock actuator (Lock power source)	0V → 12V → 0V (Approx. 0.3 sec.)		0V → 12V → 0V (Approx. 0.3 sec.)	
3	Output signals Door lock actuator (Unlock power source)	0V → 12V → 0V (Approx. 1.4 sec.)		0V → 12V → 0V (Approx. 1.4 sec.)	


EL

IDX

POWER DOOR LOCK


Electrical Components Inspection

Key switch




Terminals	Condition	Continuity
83 - 84	Key is in the ignition.	Yes
	Key is not in the ignition.	No

Door switch




Terminals	Condition	Continuity
86 - 88	Door is closed.	No
	Door is open.	Yes

Lock knob switch (Built-in front door lock actuator)



Terminals	Condition	Continuity
3 - 4	Lock	No
	Unlock	Yes

Door lock actuator




Terminals		Operation
⊕	⊖	
①	②	Lock
②	①	Unlock


POWER DOOR MIRROR

Wiring Diagram

EXCEPT CONVERTIBLE ROOF TYPE




CONVERTIBLE ROOF TYPE



TRUNK LID AND FUEL FILLER LID OPENER


Wiring Diagram



CONVERTIBLE ROOF

Wiring Diagram

STORAGE LID AND TRUNK LID OPENER SYSTEM




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CONVERTIBLE ROOF

Wiring Diagram (Cont'd)


ROOF OPENER SYSTEM



MEL971D

HORN, CIGARETTE LIGHTER, CLOCK

Wiring Diagram




- GI
- MA
- EM
- LC
- EF & EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA

EL





IDX

REAR WINDOW DEFOGGER & HEATER MIRROR

Wiring Diagram



REAR WINDOW DEFOGGER & HEATER MIRROR



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament to determine point where tester needle swings abruptly.

- When measuring voltage, wind a piece of tin foil around the top of the negative probe and press the foil against the wire with your finger as shown.

GI

MA

EW

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth




REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.


Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

Audio/Wiring Diagram

EXCEPT BOSE SYSTEM



GI

WA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


AUDIO AND POWER ANTENNA

Audio/Wiring Diagram (Cont'd)

BOSE SYSTEM




Power Antenna/Wiring Diagram



GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX


Location of Antenna




Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.



2. Withdraw antenna rod while raising it by operating antenna motor.





AUDIO AND POWER ANTENNA

Antenna Rod Replacement (Cont'd)

INSTALLATION

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.



Radio Fuse Check

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX



Window Antenna Repair

ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.



2. If an element is broken, no continuity will exist.




3. To locate broken point, move probe to left and right along element to determine point where tester needle swings abruptly.

ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-80).

POWER SEAT


Wiring Diagram — SEAT —



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI —



MULTI-REMOTE CONTROL SYSTEM


Wiring Diagram — MULTI — (Cont'd)



GI
MA
EM
LC
EF & EC
FE
GL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Circuit Diagram for Quick Pinpoint Check




Ⓢ : Convertible model
 Ⓢ : Except convertible model

Trouble Diagnoses Preliminary Inspection


PRELIMINARY INSPECTION PROCEDURE 1

All functions of multi remote control system do not function.




PRELIMINARY INSPECTION PROCEDURE 2

Door lock and unlock do not function.




PRELIMINARY INSPECTION PROCEDURE 3

Back door or trunk lid open function does not function.




PRELIMINARY INSPECTION PROCEDURE 4

Interior light or spot light does not function.



PRELIMINARY INSPECTION PROCEDURE 5

Panic alarm does not function.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX


MULTI-REMOTE CONTROL SYSTEM



Trouble Diagnoses


DIAGNOSTIC PROCEDURE 1

Remote controller buzzer does not sound when the button is pressed.





Note:

Remote controller does not function if battery is not set correctly.








DIAGNOSTIC PROCEDURE 2

All remote controls do not function even if remote controller buzzer does sound.



MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

Door lock and unlock remote control do not function. Everything else does function.



A

CHECK DOOR LOCK AND UNLOCK SIGNAL FOR DOOR LOCK TIMER.

- 1) Remove key from ignition.
- 2) Close all doors and trunk lid.
- 3) Remove door lock timer 12-pin connector.

Push remote controller buttons and check continuity between terminals ① and GND, ② and GND.

Terminals	Operation	Continuity
① - GND	Lock	Yes
	Unlock	No
② - GND	Unlock	Yes
	Lock	No

OK → Check power door lock system.

NG

Does continuity exist continually?

Yes → Repair harness. (There might be incorrect grounding.)

No

B

Remove remote control unit 12-pin connector.
Check continuity between remote control unit terminals and door lock timer.

NG → Repair harness.

Terminals	
Remote control	Door lock timer
①	②
②	①

Continuity should exist.

OK





Replace control unit.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 4

Trunk lid open remote control does not function. Everything else does function.



DIAGNOSTIC PROCEDURE 5

Interior light or spot light (convertible model) does not function. Everything else does function.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

Panic alarm function does not function. Everything else does function.




A

CHECK PANIC ALARM CIRCUIT.
Disconnect 12-pin connector from remote control unit.
Ground remote control unit connector terminal ⑱.

Does panic alarm function function?

Yes → Replace control unit.

No



B

Disconnect 16-pin connector from theft warning control unit.
Check continuity between terminals ⑱ of remote control unit connector and ⑲ of theft warning control unit.
Does continuity exist?


Yes → Check theft warning system.

No

Repair harness.

DIAGNOSTIC PROCEDURE 7

Hazard indicator flashing does not function. Everything else does function.




A

CHECK HAZARD INDICATOR FLASHING CIRCUIT.
Disconnect 12-pin connector from remote control unit.
Ground remote control unit connector terminal ⑲.

Does hazard indicator flashing function function?

Yes → Replace control unit.

No



B

Disconnect remote control relay-2 connector.
Check continuity between terminals ⑲ of remote control unit connector and remote control relay-2.
Does continuity exist?

Yes → Check remote control relay-2 and harness.

No

Repair harness.



MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

Theft warning is actuated when door is unlocked or trunk lid is opened with remote control.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



A




CHECK THEFT WARNING CANCEL SIGNAL CIRCUIT.

- 1) Disconnect theft warning control unit 16-pin connector.
- 2) Remove key from ignition.
- 3) Close all doors and back door or trunk lid.

Check voltage between terminal ⑨ and GND when door unlock remote control function is operated.

Terminal	Operation	Voltage
⑨ - GND	Door is unlocked.	12V → 0V → 12V

Does voltmeter gauge move when door is unlocked?



Replacing Remote Controller or Control Unit

If the remote controller or the control unit needs to be replaced or if an additional remote controller needs to be set, enter the Identity (ID) code manually.

ID Code Entry Procedure

To enter the ID code, follow this procedure.

“Setting mode”.

Three steps must be followed to establish the “setting mode”.

- (1) Open the trunk.
- (2) Close and lock all doors.
- (3) Insert and remove the key from the ignition more than six times within 10 seconds.

- **At this time, the original ID codes are eliminated.**

ID code entry:

- (4) Unlock and lock the driver’s door inside lock lever once.
 - (5) Push lock button on the new remote controller once (for example, if door is locked using the remote controller during this ID code entry enable state, a new ID code can be entered).
- **At this time, the new ID code is entered.**
- (6) If you need to enter additional remote controllers (including the original) repeat the step (4) and (5) for each additional controller.
 - (7) This ID code entry enable state and setting mode remain until any one of the doors is opened.









Note

- **If the same ID code that existing in the memory is input, the entry is canceled, and no ID code will be entered.**
- **Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.**
- **Any ID codes entered after termination of the “setting” mode will not be accepted. Additionally remote control signals will be inhibited when an ID code has not been entered during the “setting” mode.**

AUTOMATIC SPEED CONTROL DEVICE (ASCD) **(ASCD)**

Component Parts and Harness Connector Location


GI
MA
EW
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




SEL078TA

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram




AUTOMATIC SPEED CONTROL DEVICE (ASCD)




Trouble Diagnoses

CONSULT


1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector.




3. Turn on ignition switch.
4. Turn on ASCD main switch.
5. Touch START (on CONSULT display).
6. Touch ASCD.
7. Touch SELF-DIAG RESULTS.



- Self-diagnostic results are shown on display. Refer to table on the next page.



8. Touch DATA MONITOR.



- Touch START.
- Data monitor results are shown on display. Refer to table on the next page.

For further information, read the CONSULT Operation Manual.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Self-diagnostic results

Diagnostic item	Description
* NO SELF DIAGNOSTIC FAILURE INDICATED. FURTHER TESTING MAY BE REQUIRED.**	<ul style="list-style-type: none"> • Even if no self diagnostic failure is indicated, further testing may be required as far as the customer complains.
POWER SUPPLY-VALVE	<ul style="list-style-type: none"> • The power supply circuit for the valves is open. (An abnormally high voltage is entered.)
VACUUM PUMP	<ul style="list-style-type: none"> • The vacuum pump circuit is open or shorted. (An abnormally high or low voltage is entered.)
AIR VALVE	<ul style="list-style-type: none"> • The air valve circuit is open or shorted. (An abnormally high or low voltage is entered.)
VHCL SP•S/FAILSAFE	<ul style="list-style-type: none"> • The vehicle speed sensor or the fail-safe circuit is malfunctioning.
CONTROL UNIT	<ul style="list-style-type: none"> • The ASCD control unit is malfunctioning.
RELEASE VALVE	<ul style="list-style-type: none"> • The release valve circuit is open or shorted. (An abnormally high or low voltage is entered.)
BRAKE SW/STOP/L SW	<ul style="list-style-type: none"> • The brake switch or stop lamp switch is malfunctioning.

Data monitor

Monitored item	Description
BRAKE SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the brake switch circuit.
STOP LAMP SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the stop lamp switch circuit.
SET SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the set switch circuit.
RESUME/ACC SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the resume/accelerate switch circuit.
CANCEL SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the cancel circuit.
VHCL SPEED SE	<ul style="list-style-type: none"> • The present vehicle speed computed from the vehicle speed sensor signal is displayed.
SET VHCL SPD	<ul style="list-style-type: none"> • The preset vehicle speed is displayed.
VACUUM PUMP	<ul style="list-style-type: none"> • The operation time of the vacuum pump is displayed.
AIR VALVE	<ul style="list-style-type: none"> • The operation time of the air valve is displayed.
PW SUP-VALVE	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the circuit for the air valve and the release valve.
CRUISE LAMP	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the cruise lamp circuit.
A/T•OD CANCEL	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the OD cancel circuit.
FAIL SAFE•LOW	<ul style="list-style-type: none"> • The fail-safe (LOW) circuit function is displayed.
FAIL SAFE•SPD	<ul style="list-style-type: none"> • The fail-safe (SPEED) circuit function is displayed.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	Diagnostic Procedure								Electrical Components Inspection							
	EL-105	EL-108	EL-108	EL-109	EL-109	EL-111	EL-112	EL-114	EL-115	EL-116	EL-117	EL-117	EL-117	EL-117	EL-117	EL-118
SYMPTOM	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	ASCD wire adjustment	ASCD actuator/ASCD pump	ASCD main switch	ASCD steering switch	ASCD cancel switch and stop lamp switch	Clutch switch (For M/T models)	Inhibitor switch (For A/T models)	Vehicle speed sensor
ASCD control unit cannot be set properly.	○									○	○	○	○	○	○	○
Engine hunts		○							○	○						
Large difference between set speed and actual vehicle speed.			○						○	○						
Deceleration is greatest immediately after ASCD has been set.				○					○	○						
ACCEL switch will not operate.	○					○						○				
RESUME switch will not operate.	○						○					○	○			
Set speed cannot be canceled.					○				○	○			○			
"CRUISE" indicator lamp blinks.								○		○		○	○			

GI

MA

EM

LC

FF &
FC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK








AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: ASCD control cannot be set.



(Next page)

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

D

☆ MONITOR ☆ NO FAIL

SET SW ON

RECORD

SEL950P

D ASCD control unit connector (M93)

SEL706QA

E

☆ MONITOR ☆ NO FAIL


VHCL SPEED SE 45mph

RECORD

SEL084T

E ASCD control unit connector (M93)

SEL707QA



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

F

☆ MONITOR ☆ NO FAIL

PW SUP-VALVE ON

RECORD

SEL860R

F

⑧

CHECK OUTPUT FOR ASCD ACTUATOR/ASCD PUMP.

1. Read out "PW SUP- VALVE" in "Data monitor" mode while driving.

PW SUP-VALVE:
ON (When ASCD is operating.)
OFF (When ASCD is not operating.)

OR

1. Check voltage between control unit harness terminals ⑧ and ③.

Voltage is 0V.

NG → Repair ASCD control unit.

OK →

F

1. Disconnect ASCD control unit connector.

2. Measure resistance between control unit harness terminals ⑧ and ⑨, ⑩, ⑭.

Terminals	Resistance (Ω)
⑧ - ⑨	Approx. 8 - 45
⑧ - ⑩	Approx. 65
⑧ - ⑭	Approx. 65

OK → Repair ASCD control unit.

NG → Repair short or open circuit in ASCD actuator assembly.

F

ASCSD control unit connector (M93)

CONNECT

H.S.

ASCSD control unit connector (M93)

DISCONNECT

H.S.


SEL708QA

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 2

SYMPTOM: Engine hunts.



DIAGNOSTIC PROCEDURE 3

SYMPTOM: Large difference between set vehicle speed and actual speed.





AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 4

SYMPTOM: Deceleration is greatest immediately after ASCD has been set.



DIAGNOSTIC PROCEDURE 5

SYMPTOM: Set speed cannot be cancelled.






OK
©
(Next page)

GI
MA
EM
LC
BF &
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: ACCEL switch will not operate.

A



☆ MONITOR ☆ NO FAIL


RESUME/ACC SW ON

RECORD


SEL861R

A

ASCD control unit connector (M93)



RESUME/ACCEL switch "ON"



RESUME/ACCEL switch "Released"


SEL789QA

B

RESUME/ACCEL switch "ON"



SEL862R



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: RESUME switch will not operate.

A



☆ MONITOR ☆ NO FAIL

RESUME/ACC SW ON

RECORD


SEL863R

Check constant-speed function for operation using SET/COAST switch. NG → Go to "DIAGNOSTIC PROCEDURE 1" (EL-105).

OK ↓


A

CHECK RESUME/ACCEL SWITCH CIRCUIT.

 See "RESUME/ACC SW" in "Data monitor" mode.

RESUME/ACC SW
When switch is pressed: ON
When switch is released: OFF

OR

 Check voltage between control unit harness terminals ① and ③.

- After turning on and holding RESUME/ACC switch.
- **Battery voltage should exist.**
- After releasing RESUME/ACC switch.
- **Voltage is 0V.**

NG → CHECK ASCD STEERING SWITCH. Refer to "Electrical Components Inspection" (EL-117).

OK ↓

B


Set vehicle speed at 80 km/h (50 MPH) by turning on SET/COAST switch.

OK ↓


①
(Next page)

A

ASCD control unit connector #93



RESUME/ACCEL switch "ON"




RESUME/ACCEL switch "Released"

SEL790QA

B




SET/COAST switch "ON"



SEL864R

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EP &
EC

FE

GL

MT

AT

PC

FA

RA

BF

ST

RS

BT

HA

EL



IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8


SYMPTOM: "CRUISE" indicator lamp blinks.



Terminals	Resistance [Ω]	
⑧	⑨	Approx. 8 - 45
	⑩	Approx. 65
	⑭	Approx. 65

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd) ASCD WIRE ADJUSTMENT



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

After confirming that accelerator wire is properly adjusted, adjust the tension of ASCD wire in the following manner.

- (1) After adjusting the length of the accelerator wire, turn a securing nut by 1/2 to 1 turn from throttle open starting position to the wire loosening direction to fix. (Must be securing carried out to prevent response delay of operation of the ASCD)
- (2) Securely tighten lock nut to hold adjusting nut in place.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

ASCD actuator/ASCD pump

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD main switch


Check continuity between terminals by pushing switch to each position.



Switch position	Terminals		
	14	15	16
ON	○	○	○
N		○	○
OFF			


ASCD steering switch

Check continuity between terminals by turning lever.



Lever	Terminals		
	1	2	3
SET/COAST	○	○	
RESUME/ACCEL	○		○
CANCEL	○	▶	○
	○	▶	○


ASCD cancel switch and stop lamp switch



Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section.


Clutch switch (For M/T models)



Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

Check switch after adjusting clutch pedal — refer to CL section.

Inhibitor switch (For A/T models)




Shift lever position	Terminals		
	3	4	6
"P"	○	○	
"N"	○		○
Except "N" or "P"			

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


Vehicle speed sensor

- 1 Remove vehicle speed sensor from transaxle.
- 2 Turn vehicle speed sensor pinion quickly and measure voltage across (a) and (b).



THEFT WARNING SYSTEM

Component Parts and Harness Connector Location




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


THEFT WARNING SYSTEM

Wiring Diagram

2 SEATER AND 2+2



THEFT WARNING SYSTEM Wiring Diagram (Cont'd)




CI
WA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


THEFT WARNING SYSTEM

Wiring Diagram (Cont'd)

CONVERTIBLE



THEFT WARNING SYSTEM Wiring Diagram (Cont'd)



GI
MA
EW
LC
EF & EC
FE
GL
WT
AT
PD
FA
RA
BR
ST
HA
EL
IDX

THEFT WARNING SYSTEM


NOTE

THEFT WARNING SYSTEM

Trouble Diagnoses

SYSTEM OPERATION CHECK

If ignition switch is turned to "ACC" at a step between START and ARMED or in the ARMED phase shown in this flow chart, the system operation is canceled.




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

THEFT WARNING SYSTEM




Trouble Diagnoses (Cont'd)

CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



- (A) : A/T model
- (M) : M/T model
- (UM) : M/T model for U.S.A.
- (US) : For U.S.A.
- (CN) : For Canada
- (CM) : M/T model for Canada
- (EC) : Except (CM)
- (CO) : Convertible
- (D) : Except convertible

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK


Main power supply circuit check

Terminals	Ignition switch position		
	OFF	ACC	ON
① - ⑫	Battery voltage	Battery voltage	Battery voltage




Power supply circuit check for system cancel

Terminals	Ignition switch position		
	OFF	ACC	ON
③ - ⑫	0V	Battery voltage	Battery voltage



Ground circuit check

Terminals	Continuity
⑫ - Ground	Yes






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

- SYMPTOM:**
- Indicator lamp does not blink.
 - Indicator lamp remains blinking.

Diagnostic procedure 1-(1)



GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




Diagnostic procedure 1-(2)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(3)



GI

MA

EM

LG

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX





THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)



Condition	Continuity
Tamper switch is Normal	No
Tamper switch is Removed	Yes



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Indicator lamp does not blink.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST




RS

BT

HA

EL

IDX






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Indicator lamp does not come on.



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Indicator lamp does not come on.

GI

MA

EM

LC

EF &
EC

FE

GL

MT

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL

IDX



A

DOOR LOCK SWITCH INPUT SIGNAL CHECK (LOCK SIGNAL)
Check continuity between control unit harness terminals ⑦ and ⑯.

Key position	Continuity
Neutral/Lock	No
Between neutral and lock	Yes

OK → Go to Diagnostic Procedure 4 (EL-136).
OK → Replace control unit.

NG →

DOOR LOCK SWITCH CHECK
Refer to "Electrical Components Inspection" (EL-143).

NG → Replace key cylinder switch.

OK →

B

DOOR LOCK SWITCH CIRCUIT CHECK

- Check harness continuity between control unit harness terminal ⑦ and door lock switch terminal.
- Check harness continuity between door lock switch terminal and body ground.

Continuity should exist.

NG → Repair harness or connectors.

OK →




CHECK THE CONNECTIONS AT EACH CONNECTOR.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Alarm does not operate.



A

ALARM OUTPUT SIGNAL CHECK
Check voltage between control unit harness terminals ⑫ and ⑯.

Condition	Voltmeter
Except alarm phase	12V
Alarm phase	Pointer deflects intermittently

NG → Replace control unit.

OK

Check theft warning horn relay.

NG → Replace relay.

OK

B

THEFT WARNING HORN CIRCUIT CHECK
Check if voltage across theft warning horn relay harness terminal and body is 12V. Check continuity between theft warning horn relay terminal and control unit harness terminal ⑫.
Continuity should exist.

NG → Repair harness and connectors.

OK

C

THEFT WARNING HEADLAMP CIRCUIT CHECK
Check continuity between headlamp relay terminal and control unit harness terminal ⑫.

NG → Repair harness and connectors.

OK


Check headlamp system. Refer to "HEADLAMP" (EL-26).

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

**SYMPTOM: STARTER MOTOR can be operated.
(Starter killed phase)**



STARTER MOTOR KILL OUTPUT SIGNAL CHECK

Check voltage between control unit harness terminals ④ and ⑯ when ignition switch is turned to ON or "START".

Approx. 12V

Replace control unit.

Approx. 0 volt

Check theft warning relay.

NG

Replace theft warning relay.

OK

Repair harness between control unit and theft warning relay.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Alarm does not stop even if stop signal is given.



A

DOOR UNLOCK SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)
Check continuity between control unit harness terminals ⑪ and ⑫.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

OK → Replace control unit.

NG →

DOOR UNLOCK SWITCH CHECK
Refer to "Electrical Components Inspection" (EL-143).

NG → Replace key cylinder switch.

OK →

B

DOOR UNLOCK SWITCH CIRCUIT CHECK

- Check harness continuity between control unit harness terminal ⑪ and door unlock switch terminal.
- Check harness continuity between door unlock switch terminal and body ground.

Continuity should exist.

NG → Repair harness or connectors.

OK →

CHECK THE CONNECTIONS AT EACH CONNECTOR.



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: Alarm does not stop even if stop signal is given.

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



A

BACK DOOR UNLOCK SWITCH OR TRUNK LID UNLOCK SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)
Check continuity between control unit harness terminals ⑩ and ⑯.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

OK → Replace control unit.

NG

BACK DOOR UNLOCK SWITCH OR TRUNK LID UNLOCK SWITCH CHECK
Refer to "Electrical Components Inspection" (EL-143).

NG → Replace key cylinder switch.

OK →

B

BACK DOOR UNLOCK SWITCH OR TRUNK LID UNLOCK SWITCH CIRCUIT CHECK

- Check harness continuity between control unit harness terminal ⑩ and back door unlock switch terminal or trunk lid unlock switch terminal.
- Check harness continuity between back door unlock switch terminal or trunk lid unlock switch terminal and body ground.

NG → Repair harness or connectors.

OK →

OK

CHECK THE CONNECTIONS AT EACH CONNECTOR.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches


Check continuity between terminal and switch body.



Hood switch

Check continuity between terminals when hood switch is pushed and released.

Terminal	Pushed	Released
a		○
b		○



Door unlock sensor

	LOCK	UNLOCK
5		○
6		○

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Key cylinder tamper switch, door lock switch and door unlock switch


• Door

	TAMPER SWITCH		DOOR LOCK SWITCH		DOOR UNLOCK SWITCH		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral	Between full stroke and neutral	Full stroke
1				○			
2				○		○	
3		○		○		○	
4		○		○		○	

• Back door or trunk lid


	TAMPER SWITCH		UNLOCK SWITCH		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral
1				○	
2		○		○	
3		○		○	

Tamper switch for door




Reed switch turns on when tamper switch is removed from door.

Tamper switch for back door or trunk lid




Reed switch turns on when key cylinder is removed.




Driver's side (015)

Passenger side (012)



Back door or trunk lid (032)



SEL270U

GI

MA

EM

LC

EF & EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX


LOCATION OF ELECTRICAL UNITS

Engine Compartment



LOCATION OF ELECTRICAL UNITS

Passenger Compartment



GI

MA

EM

LC

EF &
EC

FE

GL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

LOCATION OF ELECTRICAL UNITS

2 SEATER



Luggage Compartment



LOCATION OF ELECTRICAL UNITS

Luggage Compartment (Cont'd)

2+2 SEATER



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


HARNES LAYOUT

Outline



HARNESS LAYOUT

Engine Room Harness




- | | |
|--------|---------------------------------|
| (E101) | : To main harness (M6) |
| (E102) | : To main harness (M7) |
| (E103) | : To main harness (M8) (Black) |
| (E104) | : To body harness (B1) |
| (E105) | : Fuse block |
| (E106) | : Fuse block |
| (E107) | : A/T control unit |
| (E108) | : To body harness No. 2 (B101) |
| (E109) | : To body harness No. 2 (B102) |
| (E110) | : To main harness (M12) (Black) |
| (E111) | : To main harness (M13) |
| (E112) | : To main harness (M14) (Brown) |

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS LAYOUT

Engine Room Harness (Cont'd)



HARNESS LAYOUT

Engine Room Harness (Cont'd)

(E1)	: Front wiper motor	(E28)	: Front washer motor (White)
(E2)	: Brake fluid level switch	(E29)	: Rear washer motor (Gray)
(E3)	: Starter relay (Except M/T model for Canada)	(E30)	: Washer fluid level switch (Brown) (Except for California)
(E4)	: Front wiper amplifier	(E31)	: Headlamp washer motor (Black) (For Canada)
(E5)	: Power steering oil pressure switch (Black)	(E32)	: To alternator harness (A1) (Black)
(E6)	: Power steering solenoid (Gray)	(E33)	: To alternator harness (A2) (Blue)
(E7)	: Hood switch	(E34)	: To alternator harness (A3) (A/T model)
(E8)	: Front sensor LH (For anti-lock brake system)	(E35)	: To alternator harness (M) (M/T model)
(E9)	: Relay box (Refer to page EL-144.)	(E36)	: To alternator harness (A5)
(E10)	: To engine control harness (E23) (White)	(E37)	: Inhibitor switch (A/T model)
(E11)	: To engine control harness (E24) (Gray)	(E38)	: Revolution sensor (A/T model)
(E12)	: To engine control harness (E25) (Brown)	(E39)	: To A/T solenoid harness (A/T model)
(E13)	: Body ground	(E40)	: Front sensor RH (For anti-lock brake system)
(E14)	: Headlamp LH (Low beam) (Brown)	(E41)	: ASCD pump
(E15)	: Headlamp LH (High beam) (Black)	(E42)	: Dropping resistor (A/T model)
(E16)	: Front combination lamp LH	(E43)	: Battery
(E17)	: Front fog lamp LH	(E44)	: Fusible link holder
(E18)	: Horn-low	(E45)	: Daytime light control unit (For Canada)
(E19)	: Cooling fan motor (Non-turbocharger model)	(E46)	: Headlamp washer relay (For Canada)
(E20)	: Headlamp RH (High beam) (Black)	(E47)	: Front shock absorber actuator RH (Turbocharger model)
(E21)	: Headlamp RH (Low beam) (Brown)	(E48)	: Boost sensor (Turbocharger model)
(E22)	: Body ground	(E49)	: Front shock absorber actuator LH (Turbocharger model)
(E23)	: Ambient sensor (Auto A/C model)	(E50)	: Cooling fan motor (Turbocharger model)
(E24)	: Low-pressure switch	(E51)	: Theft warning horn
(E25)	: Horn-high	(E54)	: Daytime light cancel relay (For Canada)
(E26)	: Front fog lamp RH		
(E27)	: Front combination lamp RH		

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Engine Control Harness

NON-TURBOCHARGER MODEL




- (F1) : ECM (ECCS control module)
- (F2) : To main harness (15)
- (F3) : Resistor
- (F4) : EGR temperature sensor
- (F5) : VTC solenoid valve — LH
- (F6) : Heated oxygen sensor — LH
- (F7) : IACV-Air regulator
- (F8) : To knock sensor sub-harness
- (F9) : Ignition coil No. 6
- (F10) : Engine ground
- (F11) : IACV-AAC valve
- (F12) : IACV-FICD solenoid valve
- (F13) : Ignition coil No. 4
- (F14) : PRVR control solenoid valve
- (F15) : Fuel temperature sensor
- (F16) : Ignition coil No. 2
- (F17) : Throttle position switch
- (F18) : Throttle position sensor
- (F19) : Compressor
- (F20) : To engine room harness (E10) (White)
- (F21) : To engine room harness (E11) (Gray)
- (F22) : To engine room harness (E12) (Brown)
- (F23) : Check connector
- (F24) : Check connector
- (F25) : Body ground
- (F26) : Mass air flow sensor
- (F27) : Camshaft position sensor
- (F28) : Thermal transmitter
- (F29) : Engine coolant temperature sensor
- (F30) : Power transistor unit
- (F31) : Power transistor unit
- (F32) : VTC solenoid valve — RH
- (F33) : Heated oxygen sensor — RH
- (F34) : Engine ground
- (F35) : Ignition coil No. 5
- (F36) : Ignition coil No. 3
- (F37) : Ignition coil No. 1
- (F38) : EGRC-solenoid valve
- (F39) : Injector No. 6
- (F40) : Injector No. 4
- (F41) : Injector No. 2
- (F42) : Injector No. 5
- (F43) : Injector No. 3
- (F44) : Injector No. 1

HARNESS LAYOUT

Engine Control Harness (Cont'd)

TURBOCHARGER MODEL




- F46** : Wastegate valve control solenoid valve LH (Turbocharger model)
- F47** : Wastegate valve control solenoid valve RH (Turbocharger model)
- F48** : EGRC-solenoid valve
- F49** : Boost pressure sensor

- F1** : ECM (ECCS control module)
- F2** : To main harness (MS)
- F3** : Resistor
- F4** : EGR temperature sensor
- F5** : VTC solenoid valve — LH
- F6** : Heated oxygen sensor — LH
- F7** : IACV-Air regulator
- F8** : To knock sensor sub-harness

- F9** : Injector No. 6
- F10** : Ignition coil No. 6
- F11** : Engine ground
- F12** : IACV-AAC valve
- F13** : Injector No. 4
- F14** : IACV-FICD solenoid valve
- F15** : Ignition coil No. 4
- F16** : PRVR control solenoid valve
- F17** : Fuel temperature sensor
- F18** : Injector No. 2
- F19** : Ignition coil No. 2
- F20** : Throttle position switch
- F21** : Throttle position sensor
- F22** : Compressor


- F23** : To engine room harness (E10) (White)
- F24** : To engine room harness (E11) (Gray)
- F25** : To engine room harness (E12) (Brown)
- F26** : Check connector
- F27** : Check connector
- F28** : Body ground
- F29** : Mass air flow sensor
- F30** : Camshaft position sensor
- F31** : Thermal transmitter
- F32** : Engine coolant temperature sensor
- F33** : Power transistor unit
- F34** : Power transistor unit
- F35** : VTC solenoid valve — RH
- F36** : Heated oxygen sensor — RH
- F37** : Engine ground
- F38** : Injector No. 5
- F39** : Ignition coil No. 5
- F40** : Injector No. 3
- F41** : Ignition coil No. 3
- F42** : Injector No. 1
- F43** : Ignition coil No. 1
- F44** : Ignition coil No. 1
- F45** : Ignition coil No. 1



- GI
- MA
- EW
- LC
- EF
- FC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

HARNESS LAYOUT







Main Harness



HARNES LAYOUT


Main Harness (Cont'd)

- M104 : Combination meter
- M105 : Steering angle sensor (Turbocharger model)
- M106 : To air bag harness (A111)
- M107 : Theft warning horn relay
- M109 : Warning lamp
- M110 : Steering switch
- M111 : To (B46) (Convertible)
- M112 : Inhibitor relay
- M113 : To room lamp harness (R1) (Convertible)
- M114 : Radio theft warning switch (Convertible)
- M115 : Fuel filler lid opener switch (Convertible)
- M116 : Trunk lid opener switch (Convertible)
- M118 : Diode (For Canada)
- M120 : Seat belt warning relay
- M121 : Remote control relay 2
- M122 : Remote control relay 1
- M123 : To body harness (B71) (Except convertible)
- M124 : To body harness (B72) (Except convertible)
- M125 : ABS check connector
- M126 : Trunk check connector
- M127 : Remote control relay
- M128 : Remote control relay
- M129 : Diode (For Canada)
- M130 : Diode (For Canada)
- M131 : Diode (For U.S.A.)




HARNESS LAYOUT

Air Bag Harness



- A101** : Left crash zone sensor
- A102** : Center crash zone sensor
- A103** : Right crash zone sensor
- A111** : To main harness **M106**
- A112** : Tunnel and safing sensor
- A113** : Air bag module
- A114** : Air bag control unit
- A115** : Air bag module (Passenger side-1)
- A116** : Air bag module (Passenger side-2)




GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS LAYOUT

Body Harness

2 SEATER



HARNES LAYOUT

Body Harness (Cont'd)


Body harness

- B1** : To engine room harness **(E104)**
- B2** : To main harness **(M4)**
- B4** : Fuse block
- B5** : Fuse block
- B6** : Door switch LH
- B7** : Body ground
- B8** : Fuel pump control unit
- B9** : Room lamp relay
- B10** : Diode
- B11** : Fuel pump
- B12** : Fuel tank gauge unit
- B13** : To body harness No. 2 **(B106)**
- B14** : Door switch RH
- B16** : Rear speaker RH (Bose system)
- B17** : Spot lamp
- B18** : In-vehicle sensor upper-Aspirator motor (Auto A/C model)
- B19** : Interior lamp
- B20** : To back door harness **(D201)**
- B21** : To back door harness **(D202)**
- B23** : Rear speaker LH (Bose system)
- B27** : Rear side marker lamp LH
- B28** : Stop and tail lamp sensor
- B29** : Rear combination lamp LH
- B30** : Back-up lamp LH
- B31** : License lamp
- B32** : Body ground
- B33** : Back door key switch
- B34** : Back door switch
- B35** : Back-up lamp RH
- B36** : Rear combination lamp RH
- B37** : Rear side marker lamp RH
- B38** : Power antenna timer
- B39** : Power antenna motor
- B40** : Diode
- B42** : Shock absorber control unit (Turbocharger model)
- B43** : To body harness No. 2 **(B112)** (Turbocharger model)
- B44** : Rear shock absorber actuator RH (Turbocharger model)
- B45** : Rear shock absorber actuator LH (Turbocharger model)
- B47** : Door lock timer

- B62** : Back door actuator
- B63** : HICAS relay
- B64** : Rear sub sensor
- B65** : Main sensor
- B66** : HICAS motor
- B69** : Body ground
- B70** : HICAS control unit
- B71** : To main harness **(M123)**
- B72** : To main harness **(M124)**

Body harness No. 2

- B101** : To engine room harness **(E108)**
- B102** : To engine room harness **(E109)**
- B103** : Body ground
- B104** : ABS control unit
- B105** : Actuator (For ABS)
- B106** : To body harness **(B13)**
- B107** : Body ground
- B108** : Rear sensor (For ABS)
- B109** : To main harness **(M100)**
- B111** : Diode (Turbocharger model)
- B112** : To body harness **(B43)** (Turbocharger model)




GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

HARNESS LAYOUT

Body Harness (Cont'd)

2+2 SEATER




HARNES LAYOUT

Body Harness (Cont'd)

Body harness No. 2

- (B101) : To engine room harness (E106)
- (B102) : To engine room harness (E109)
- (B103) : Body ground
- (B104) : ABS control unit
- (B105) : Actuator (For ABS)
- (B106) : To body harness (B13)
- (B107) : Body ground
- (B108) : Rear sensor (For ABS)
- (B109) : To main harness (M100)

Diode (B10) (B40)



Body harness

- (B1) : To engine room harness (E104)
- (B2) : To main harness (M4)
- (B4) : Fuse block
- (B5) : Fuse block
- (B6) : Door switch LH
- (B7) : Body ground
- (B8) : Fuel pump control unit
- (B9) : Room lamp relay
- (B10) : Diode
- (B12) : Fuel tank gauge unit
- (B13) : To body harness No. 2 (B106)
- (B14) : Door switch RH
- (B16) : Rear speaker RH (Bose system)
- (B17) : Spot lamp
- (B18) : In-vehicle sensor upper-Aspirator motor (Auto A/C model)
- (B19) : Interior lamp
- (B20) : To back door harness (B201)
- (B21) : To back door harness (B202)
- (B23) : Rear speaker LH (Bose system)
- (B27) : Rear side marker lamp LH
- (B28) : Stop and tail lamp sensor
- (B29) : Rear combination lamp LH
- (B30) : Back-up lamp LH
- (B31) : License lamp
- (B32) : Body ground
- (B33) : Back door key switch
- (B34) : Back door switch
- (B35) : Back-up lamp RH
- (B36) : Rear combination lamp RH
- (B37) : Rear side marker lamp RH
- (B38) : Power antenna timer
- (B39) : Power antenna motor
- (B40) : Diode
- (B41) : Luggage room lamp
- (B47) : Door lock timer
- (B52) : Back door actuator
- (B71) : To main harness (M123)
- (B72) : To main harness (M124)

GI

WA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

HARNESS LAYOUT

Body Harness (Cont'd)

CONVERTIBLE



HARNES LAYOUT


Body Harness (Cont'd)

Body harness

- 81 : To engine room harness (E104)
- 82 : To main harness (M4)
- 83 : To main harness (M5)
- 84 : Fuse block
- 85 : Fuse block
- 86 : Door switch LH
- 87 : Body ground
- 88 : Fuel pump control unit
- 89 : Room lamp relay
- 90 : Diode
- 91 : Fuel pump
- 92 : Fuel tank gauge unit
- 93 : To body harness No. 2 (B105)
- 94 : Door switch RH
- 97 : Rear side marker lamp LH
- 928 : Stop and tail lamp sensor
- 929 : Rear combination lamp LH
- 930 : Back-up lamp LH
- 931 : License lamp
- 932 : Body ground
- 933 : Back door key switch
- 934 : Trunk room lamp switch
- 935 : Back-up lamp RH
- 936 : Rear combination lamp RH
- 937 : Rear side marker lamp RH
- 938 : Power antenna timer
- 939 : Power antenna motor
- 940 : Diode
- 945 : To main harness (M11)
- 947 : Door lock timer
- 949 : Storage lid opener and roof opener switch
- 949 : Trunk lid opener relay
- 950 : Trunk lid opener cancel relay
- 951 : Storage lid opener cancel relay
- 952 : Storage lid interlock relay
- 953 : Trunk room lamp
- 954 : To tail harness (T1)
- 955 : To high-mounted stop lamp sub-harness (S59)
- 957 : Fuel filler lid opener solenoid
- 958 : Trunk lid opener solenoid
- 959 : To body harness (S55)
- 960 : High-mounted stop lamp
- 961 : Heater mirror relay

Body harness No. 2


- B101 : To engine room harness (E109)
- B102 : To engine room harness (E109)
- B103 : Body ground
- B104 : ABS control unit
- B105 : Actuator (For ABS)
- B106 : To body harness (B13)
- B107 : Body ground
- B108 : Rear sensor (For anti-lock brake system)
- B109 : To main harness (M100)




CI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

HARNESS LAYOUT

Door Harness LH




Door Harness RH




HARNESS LAYOUT

Back Door Harness



Alternator Harness



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX