

SECTION **LAN**
LAN SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CONTENTS

CAN

| | | | |
|---|----------|---|-----------|
| PRECAUTIONS | 2 | BCM Circuit Check | 30 |
| Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 2 | ABS Actuator and Electric Unit (Control Unit) Circuit Check | 30 |
| Precautions for Battery Service | 2 | IPDM E/R Circuit Check | 31 |
| Precautions When Using CONSULT-II | 2 | CAN Communication Circuit Check | 32 |
| CHECK POINTS FOR USING CONSULT-II | 3 | IPDM E/R Ignition Relay Circuit Check | 34 |
| Precautions For Trouble Diagnosis | 3 | Component Inspection | 34 |
| CAN SYSTEM | 3 | ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION | 34 |
| Precautions For Harness Repair | 3 | CAN SYSTEM (TYPE 2) | 35 |
| CAN SYSTEM | 3 | System Description | 35 |
| CAN COMMUNICATION | 4 | Component Parts and Harness Connector Location.. | 35 |
| System Description | 4 | Wiring Diagram — CAN — | 36 |
| CAN Communication Unit | 4 | Work Flow | 38 |
| TYPE 1 | 4 | CHECK SHEET | 39 |
| TYPE 2 | 6 | CHECK SHEET RESULTS (EXAMPLE) | 41 |
| CAN SYSTEM (TYPE 1) | 8 | Circuit Check Between Data Link Connector and Unified Meter and A/C Amp. | 51 |
| System Description | 8 | Circuit Check Between Unified Meter and A/C Amp. and BCM | 51 |
| Component Parts and Harness Connector Location... | 8 | Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit) | 51 |
| Wiring Diagram — CAN — | 9 | ECM Circuit Check | 52 |
| Work Flow | 11 | Data Link Connector Circuit Check | 53 |
| CHECK SHEET | 12 | Unified Meter and A/C Amp. Circuit Check | 53 |
| CHECK SHEET RESULTS (EXAMPLE) | 14 | BCM Circuit Check | 54 |
| Circuit Check Between TCM and Data Link Connector | 25 | ABS Actuator and Electric Unit (Control Unit) Circuit Check | 54 |
| Circuit Check Between Data Link Connector and Unified Meter and A/C Amp. | 26 | IPDM E/R Circuit Check | 55 |
| Circuit Check Between Unified Meter and A/C Amp. and BCM | 27 | CAN Communication Circuit Check | 56 |
| Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit) | 27 | IPDM E/R Check | 58 |
| ECM Circuit Check | 28 | IPDM E/R Ignition Relay Circuit Check | 58 |
| TCM Circuit Check | 28 | Component Inspection | 58 |
| Data Link Connector Circuit Check | 29 | ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION | 58 |
| Unified Meter and A/C Amp. Circuit Check | 29 | | |

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AKS0031A

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Battery Service

AKS003TZ

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precautions When Using CONSULT-II

AKS003M4

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-4, "CAN Communication Unit"](#) .

Precautions For Trouble Diagnosis CAN SYSTEM


AKS000ZD

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


Precautions For Harness Repair CAN SYSTEM

AKS000ZE

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

PFP:23710

System Description

AKS000ZF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


AKS000ZG

Go to CAN system, when selecting your CAN system type from the following table.

| | | |
|------------------------------|--|---|
| Body type | Roadster | |
| Axle | 2WD | |
| Engine | VQ35DE | |
| Transmission | A/T | M/T |
| Brake control | TCS | |
| CAN system type | 1 | 2 |
| CAN system trouble diagnosis | LAN-8. "CAN SYSTEM (TYPE 1)" | LAN-35. "CAN SYSTEM (TYPE 2)" |

TYPE 1

System Diagram



Input/ Output Signal Chart

T: Transmit R: Receive

| Signals | ECM | TCM | Unified meter and A/C amp. | BCM | ABS actuator and electric unit (control unit) | IPDM E/R |
|------------------------------------|-----|-----|----------------------------|-----|---|----------|
| Engine speed signal | T | R | R | | R | |
| Engine torque signal | T | R | | | R | |
| Engine coolant temperature signal | T | R | R | | | |
| Accelerator pedal position signal | T | R | | | R | |
| Closed throttle position signal | T | R | | | | |
| Wide open throttle position signal | T | R | | | | |
| Battery voltage signal | T | R | | | | |
| Stop lamp switch signal | | R | T | | | |
| Fuel consumption monitor signal | T | | R | | | |
| A/T self-diagnosis signal | R | T | | | | |
| A/T CHECK indicator lamp signal | | T | R | | | |
| A/T position indicator signal | | T | R | | R | |
| Manual mode gear position signal | | T | R | | | |

CAN COMMUNICATION

[CAN]


| Signals | ECM | TCM | Unified meter and A/C amp. | BCM | ABS actuator and electric unit (control unit) | IPDM E/R | |
|---|-----|-----|----------------------------|-----|---|----------|-----|
| ABS operation signal | | R | | | T | | A |
| A/T shift schedule change demand signal | | R | | | T | | B |
| A/C switch signal | R | | | T | | | C |
| A/C compressor request signal | T | | | | | R | |
| A/C compressor feedback signal | T | | R | | | | D |
| Blower fan motor switch signal | R | | | T | | | |
| Cooling fan speed request signal | T | | | | | R | |
| Position lights request signal | | | R | T | | R | E |
| Low beam request signal | | | | T | | R | |
| Low beam status signal | R | | | | | T | |
| High beam request signal | | | R | T | | R | F |
| High beam status signal | R | | | | | T | |
| Vehicle speed signal | | | R | | T | | |
| | R | R | T | R | | | G |
| Sleep request 1 signal | | | R | T | | | |
| Sleep request 2 signal | | | | T | | R | H |
| Wake up request 1 signal | | | R | T | | | |
| Door switch signal | | | R | T | | R | |
| Turn indicator signal | | | R | T | | | I |
| Seat belt buckle switch signal | | | T | R | | | |
| Buzzer output signal | | | R | T | | | J |
| Fuel level sensor signal | R | | T | | | | |
| Malfunction indicator lamp signal | T | | R | | | | |
| ASCD SET lamp signal | T | | R | | | | LAN |
| ASCD operation signal | T | R | | | | | |
| ASCD CRUISE lamp signal | T | | R | | | | L |
| ASCD OD cancel request signal | T | R | | | | | |
| Output shaft revolution signal | R | T | | | | | |
| Turbine revolution signal | R | T | | | | | M |
| Front wiper request signal | | | | T | | R | |
| Front wiper stop position signal | | | | R | | T | |
| Rear window defogger switch signal | | | | T | | R | |
| Rear window defogger control signal | R | | | | | T | |
| Manual mode signal | | R | T | | | | |
| Not manual mode signal | | R | T | | | | |
| Manual mode shift up signal | | R | T | | | | |
| Manual mode shift down signal | | R | T | | | | |
| Manual mode indicator signal | | T | R | | | | |
| Hood switch signal | | | | R | | T | |
| Theft warning horn request signal | | | | T | | R | |
| Horn chirp signal | | | | T | | R | |
| ABS warning lamp signal | | | R | | T | | |

CAN COMMUNICATION

[CAN]

| Signals | ECM | TCM | Unified meter and A/C amp. | BCM | ABS actuator and electric unit (control unit) | IPDM E/R |
|-------------------------------|-----|-----|----------------------------|-----|---|----------|
| TCS OFF indicator lamp signal | | | R | | T | |
| SLIP indicator lamp signal | | | R | | T | |
| Brake warning lamp signal | | | R | | T | |

TYPE 2 System Diagram



Input/ Output Signal Chart

T: Transmit R: Receive

| Signals | ECM | Unified meter and A/C amp. | BCM | ABS actuator and electric unit (control unit) | IPDM E/R |
|-----------------------------------|-----|----------------------------|-----|---|----------|
| Engine speed signal | T | R | | R | |
| Engine torque signal | T | | | R | |
| Engine coolant temperature signal | T | R | | | |
| Accelerator pedal position signal | T | | | R | |
| Fuel consumption monitor signal | T | R | | | |
| A/C switch signal | R | | T | | |
| A/C compressor request signal | T | | | | R |
| A/C compressor feedback signal | T | R | | | |
| Blower fan motor switch signal | R | | T | | |
| Cooling fan speed request signal | T | | | | R |
| Position lights request signal | | R | T | | R |
| Low beam request signal | | | T | | R |
| Low beam status signal | R | | | | T |
| High beam request signal | | R | T | | R |
| High beam status signal | R | | | | T |
| Vehicle speed signal | R | R | | T | |
| Sleep request 1 signal | | R | T | | |
| Sleep request 2 signal | | | T | | R |
| Wake up request 1 signal | | R | T | | |
| Door switch signal | | R | T | | R |
| Turn indicator signal | | R | T | | |
| Seat belt buckle switch signal | | T | R | | |
| Buzzer output signal | | R | T | | |

CAN COMMUNICATION

[CAN]

| Signals | ECM | Unified meter and A/C amp. | BCM | ABS actuator and electric unit (control unit) | IPDM E/R |
|-------------------------------------|-----|----------------------------|-----|---|----------|
| Fuel level sensor signal | R | T | | | |
| Malfunction indicator lamp signal | T | R | | | |
| ASCD SET lamp signal | T | R | | | |
| ASCD CRUISE lamp signal | T | R | | | |
| Front wiper request signal | | | T | | R |
| Front wiper stop position signal | | | R | | T |
| Rear window defogger switch signal | | | T | | R |
| Rear window defogger control signal | R | | | | T |
| Hood switch signal | | | R | | T |
| Theft warning horn request signal | | | T | | R |
| Horn chirp signal | | | T | | R |
| ABS warning lamp signal | | R | | T | |
| TCS OFF indicator lamp signal | | R | | T | |
| SLIP indicator lamp signal | | R | | T | |
| Brake warning lamp signal | | R | | T | |

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


System Description

AKS0035L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS0035M



CAN SYSTEM (TYPE 1)


[CAN]

Wiring Diagram — CAN —


AKS0035N

LAN-CAN-01


▬ : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M




(M8)
W



(M48)
GY



(F6)
GY



(F502)
GY

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.



(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS

TKWM1389E

LAN-CAN-02

▬ : DATA LINE



REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (E51) -ELECTRICAL UNITS

TKWT0407E

CAN SYSTEM (TYPE 1)

[CAN]

AKS00350

Work Flow

- When there are no indications of "METER A/C AMP" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

| | | | | | | | | |
|-----------|----------------------------|--|--|--|----------------------|--|--|--|
| (Example) | NISSAN | | | | SELECT SYSTEM | | | |
| | CONSULT-II | | | | ENGINE | | | |
| | ENGINE | | | | A/T | | | |
| | START (NISSAN BASED VHCL) | | | | ABS | | | |
| | START (RENAULT BASED VHCL) | | | | AIR BAG | | | |
| | SUB MODE | | | | BCM | | | |
| | | | | | METER A/C AMP | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | BACK LIGHT COPY | | | |

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.

| | | | | | | |
|-----------|-------------------------|--|--------------------------|--|-------|--|
| (Example) | SELECT DIAG MODE | | SELF-DIAG RESULTS | | | |
| | WORK SUPPORT | | DTC RESULTS TIME | | | |
| | SELF-DIAG RESULTS | | CAN COMM CIRCUIT [U1000] | | 0 | |
| | DATA MONITOR | | | | | |
| | DATA MONITOR (SPEC) | | | | | |
| | CAN DIAG SUPPORT MNTR | | | | | |
| | ACTIVE TEST | | | | | |
| | | | F.F.DATA | | | |
| | | | ERASE | | PRINT | |
| | | | MODE BACK LIGHT COPY | | | |

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.

| | | | | | | |
|-----------|-------------------------|----------------------|------------------------------|-------------|--------|--|
| (Example) | SELECT DIAG MODE | | CAN DIAG SUPPORT MNTR | | | |
| | WORK SUPPORT | | ENGINE | | | |
| | SELF-DIAG RESULTS | | INITIAL DIAG | | OK | |
| | DATA MONITOR | | TRANSMIT DIAG | | OK | |
| | DATA MONITOR (SPEC) | | TCM | | OK | |
| | CAN DIAG SUPPORT MNTR | | VDC/TCS/ABS | | OK | |
| | ACTIVE TEST | | METER/M&A | | OK | |
| | | | ICC | | UNKWVN | |
| | | | BCM/SEC | | OK | |
| | | | IPDM E/R | | OK | |
| | | AWD/4WD/e4WD | | UNKWVN | | |
| | | PRINT | | Scroll Down | | |
| | | MODE BACK LIGHT COPY | | | | |

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-12, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWVN" in the check sheet table. Refer to [LAN-12, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-14, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN | — |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | UNKWN | — | — | — | — |

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 1)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIA8678E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.


Case 1

Check harness between TCM and data link connector. Refer to [LAN-25. "Circuit Check Between TCM and Data Link Connector"](#)

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UN KN WN | UN KN WN | UN KN WN | UN KN WN |
| A/T | — | NG | UNKWN | UNKWN | — | UN KN WN | — | UN KN WN | — |
| METER A/C AMP | No indication | — | UNKWN | UN KN WN | UN KN WN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UN KN WN | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UN KN WN | UN KN WN | — | — | — | — |

PKIA8679E

/// : Malfunctioning part



PKIA2007E

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-26, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|---------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN ✓ | — | UNKWN ✓ | — |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN ✓ | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN ✓ | UNKWN ✓ | — | — | — | — |

PKIA8680E



PKIA2008E

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 3

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-27, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN | — |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | UNKWN | — | — | — | — |

PKIA8681E

/// : Malfunctioning part



PKIA2009E

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-27, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#).

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|---------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN ✓ | UNKWN ✓ |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN ✓ | — |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN ✓ | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN | — | — | UNKWN ✓ |
| ABS | — | NG | UNKWN | UNKWN ✓ | UNKWN ✓ | — | — | — | — |

PKIA662E



PKIA2010E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 5

Check ECM circuit. Refer to [LAN-28, "ECM Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKW ^N | — | UNKW ^N | UNKW ^N | UNKW ^N | UNKW ^N | UNKW ^N |
| A/T | — | NG | UNKW ^N | UNKW ^N | — | UNKW ^N | — | UNKW ^N | — |
| METER A/C AMP | No indication | — | UNKW ^N | UNKW ^N | UNKW ^N | — | UNKW ^N | UNKW ^N | — |
| BCM | — | NG | UNKW ^N | UNKW ^N | — | UNKW ^N | — | — | UNKW ^N |
| ABS | — | NG | UNKW ^N | UNKW ^N | UNKW ^N | — | — | — | — |

PKIA8683E

▨ : Malfunctioning part



PKIA2011E

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check TCM circuit. Refer to [LAN-28, "TCM Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN | — |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | UNKWN | — | — | — | — |

PKIA8684E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 7

Check data link connector circuit. Refer to [LAN-29, "Data Link Connector Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN | — |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | UNKWN | — | — | — | — |

PKIA8685E

//// : Malfunctioning part



PKIA2013E

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check unified meter and A/C amp. circuit. Refer to [LAN-29, "Unified Meter and A/C Amp. Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN ✓ | UNKWN | UNKWN | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN ✓ | — | UNKWN | — |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN ✓ | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | UNKWN | — | — | — | — |

PKIA8686E



LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 9

Check BCM circuit. Refer to [LAN-30, "BCM Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN ✓ | UNKWN | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN | — |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | UNKWN | — | UNKWN ✓ | UNKWN | — |
| BCM | — | NG | UNKWN ✓ | UNKWN ✓ | — | UNKWN ✓ | — | — | UNKWN ✓ |
| ABS | — | NG | UNKWN | UNKWN | UNKWN | — | — | — | — |

PKIA8687E

//// : Malfunctioning part



PKIA2015E

CAN SYSTEM (TYPE 1)


[CAN]

Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-30, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN ✓ | UNKWN |
| A/T | — | NG | UNKWN | UNKWN | — | UNKWN | — | UNKWN ✓ | — |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | UNKWN | — | UNKWN | UNKWN ✓ | — |
| BCM | — | NG | UNKWN | UNKWN | — | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN ✓ | UNKWN | UNKWN | — | — | — | — |

PKIA668E



PKIA2016E

LAN

CAN SYSTEM (TYPE 1)

[CAN]


Case 11

Check IPDM E/R circuit. Refer to [LAN-31, "IPDM E/R Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------------------|-------------------|-------------------|-------------------|---------------------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKW N | — | UNKW N | UNKW N | UNKW N | UNKW N | UNKW N ✓ |
| A/T | — | NG | UNKW N | UNKW N | — | UNKW N | — | UNKW N | — |
| METER A/C AMP | No indication | — | UNKW N | UNKW N | UNKW N | — | UNKW N | UNKW N | — |
| BCM | — | NG | UNKW N | UNKW N | — | UNKW N | — | — | UNKW N ✓ |
| ABS | — | NG | UNKW N | UNKW N | UNKW N | — | — | — | — |

PKIA8689E

▨ : Malfunctioning part



PKIA2017E

Case 12

Check CAN communication circuit. Refer to [LAN-32, "CAN Communication Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|-----------------|-----------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKW N ✓ | — | UNKW N ✓ | UNKW N ✓ | UNKW N ✓ | UNKW N ✓ | UNKW N ✓ |
| A/T | — | NG | UNKW N ✓ | UNKW N ✓ | — | UNKW N ✓ | — | UNKW N ✓ | — |
| METER A/C AMP | No indication ✓ | — | UNKW N | UNKW N | UNKW N | — | UNKW N | UNKW N | — |
| BCM | — | NG | UNKW N ✓ | UNKW N ✓ | — | UNKW N ✓ | — | — | UNKW N ✓ |
| ABS | — | NG | UNKW N ✓ | UNKW N ✓ | UNKW N ✓ | — | — | — | — |

PKIA8690E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-34, "IPDM E/R Ignition Relay Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | - | NG | UNKWN | - | ✓ | UNKWN | UNKWN | ✓ | UNKWN |
| A/T | - | NG | UNKWN | UNKWN | - | UNKWN | - | UNKWN | - |
| METER A/C AMP | No indication | - | UNKWN | UNKWN | ✓ | - | UNKWN | ✓ | - |
| BCM | - | NG | UNKWN | UNKWN | - | UNKWN | - | - | UNKWN |
| ABS | - | NG | UNKWN | UNKWN | UNKWN | - | - | - | - |

PKIA8692E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-34, "IPDM E/R Ignition Relay Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-------|------------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | | |
| | | | | ECM | TCM | METER /M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | - | NG | UNKWN | - | UNKWN | UNKWN | UNKWN | UNKWN | UNKWN |
| A/T | - | NG | UNKWN | ✓ | - | ✓ | - | UNKWN | - |
| METER A/C AMP | No indication | - | UNKWN | UNKWN | UNKWN | - | UNKWN | UNKWN | - |
| BCM | - | NG | UNKWN | UNKWN | - | UNKWN | - | - | UNKWN |
| ABS | - | NG | UNKWN | ✓ | UNKWN | - | - | - | - |

PKIA8691E

Circuit Check Between TCM and Data Link Connector

AKS0035P

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector side and harness side).
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F102.
2. Check continuity between A/T assembly harness connector F6 terminals 3 (L), 8 (R) and harness connector F102 terminals 26H (L), 27H (R).

3 (L) – 26H (L) : Continuity should exist.
8 (R) – 27H (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M72 terminals 26H (L), 27H (R) and data link connector M8 terminals 6 (L), 14 (R).

26H (L) – 6 (L) : Continuity should exist.
27H (R) – 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-11, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00350


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.
14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-11, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Unified Meter and A/C Amp. and BCM


1. CHECK HARNESS FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.
11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-11, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector and harness connector M15.
2. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and harness connector M15 terminals 2G (L), 7G (R).

70 (L) – 2G (L) : Continuity should exist.
71 (R) – 7G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).

2G (L) – 20 (L) : Continuity should exist.

7G (R) – 23 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-11, "Work Flow"](#).
- NG >> Repair harness.



AKS0035T

ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between ECM and A/T assembly.



AKS0035U

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F6 terminals 3 (L) and 8 (R).

3 (L) – 8 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F102.



AKS0035V

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-11, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



AKS0035W

Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS0035X

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and harness connector M15.



AKS0035Y

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R)

: Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0035Z

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R)

: Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



LKIA0030E

CAN Communication Circuit Check

AKS00360

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - A/T assembly
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ECM connector
 - A/T assembly connector
 - Harness connector F102
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and A/T assembly
 - Harness between ECM and harness connector F102



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.


- 48 (L) – ground : Continuity should not exist.**
- 49 (R) – ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-34, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-11, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS00362

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-24, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" "](#).


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

AKS00363

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

| Unit | Terminal | Resistance value (Ω) (Approx.) |
|----------|----------|-----------------------------------|
| ECM | 94 – 86 | 108 - 132 |
| IPDM E/R | 48 – 49 | |



CAN SYSTEM (TYPE 2)

PFP:23710


System Description

AKS0092Z

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

AKS00930



A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 2)


[CAN]

AKS00931


Wiring Diagram — CAN —

LAN-CAN-03


▬ : DATA LINE



NEXT PAGE



(M8)
W



(M48)
GY



REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M3), (F101) -ELECTRICAL UNITS



TKWTO408E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.


(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E51) -ELECTRICAL UNITS


TKWT0409E

Work Flow


- When there are no indications of "METER A/C AMP" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "METER A/C AMP", "BCM", and "ABS" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-39, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-39, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-41, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
METER A/C AMP
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
METER A/C AMP
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

PKIA8694E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between data link connector and unified meter and A/C amp. Refer to [LAN-51, "Circuit Check Between Data Link Connector and Unified Meter and A/C Amp."](#)

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN ✓ | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN ✓ | — | — | — | — |

PKIA8695E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 2

Check harness between unified meter and A/C amp. and BCM. Refer to [LAN-51, "Circuit Check Between Unified Meter and A/C Amp. and BCM"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8696E

//// : Malfunctioning part



PKIA2019E

CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-51, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN ✓ | UNKWN ✓ |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN ✓ | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN ✓ |
| ABS | — | NG | UNKWN | UNKWN ✓ | — | — | — | — |

PKIA8697E



LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-52, "ECM Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN ✓ | — | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ |
| METER A/C AMP | No indication | — | UNKWN | UNKWN ✓ | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN ✓ | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN ✓ | — | — | — | — |

PKIA8698E



PKIA2021E

CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-53, "Data Link Connector Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8699E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 6

Check unified meter and A/C amp. circuit. Refer to [LAN-53, "Unified Meter and A/C Amp. Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN ✓ | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN ✓ | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8700E

//// : Malfunctioning part



PKIA2023E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-54, "BCM Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8701E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]


Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-54, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8702E

//// : Malfunctioning part



PKIA2025E

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-55, "IPDM E/R Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN ✓ |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN ✓ |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8703E



Case 10

Check CAN communication circuit. Refer to [LAN-56, "CAN Communication Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|-----------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN ✓ | — | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ |
| METER A/C AMP | No indication ✓ | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN ✓ | UNKWN ✓ | UNKWN ✓ | — | — | UNKWN ✓ |
| ABS | — | NG | UNKWN ✓ | UNKWN ✓ | — | — | — | — |

PKIA8704E

A
B
C
D
E
F
G
H
I
J

LAN

L
M

CAN SYSTEM (TYPE 2)

[CAN]

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-58, "IPDM E/R Ignition Relay Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN ✓ | UNKWN |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN ✓ | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN | — | — | — | — |

PKIA8706E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-58, "IPDM E/R Ignition Relay Circuit Check"](#) .

| SELECT SYSTEM screen | | CAN DIAG SUPPORT MNTR | | | | | | |
|----------------------|---------------|-----------------------|--------------------|-------------------|-----------|---------|--------------|----------|
| | | Initial diagnosis | Transmit diagnosis | Receive diagnosis | | | | |
| | | | | ECM | METER/M&A | BCM/SEC | VDC/TCS /ABS | IPDM E/R |
| ENGINE | — | NG | UNKWN | — | UNKWN | UNKWN | UNKWN | UNKWN |
| METER A/C AMP | No indication | — | UNKWN | UNKWN | — | UNKWN | UNKWN | — |
| BCM | — | NG | UNKWN | UNKWN | UNKWN | — | — | UNKWN |
| ABS | — | NG | UNKWN | UNKWN ✓ | — | — | — | — |

PKIA8705E

Circuit Check Between Data Link Connector and Unified Meter and A/C Amp.

AKS00933

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector and unified meter and A/C amp. connector.
4. Check continuity between data link connector M8 terminals 6 (L), 14 (R) and unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R).

6 (L) – 1 (L) : Continuity should exist.

14 (R) – 11 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-38, "Work Flow"](#).
- NG >> Repair harness.

**Circuit Check Between Unified Meter and A/C Amp. and BCM**

AKS00935

1. CHECK HARNESS FOR OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following connectors.
 - ECM connector
 - Unified meter and A/C amp. connector
 - BCM connector
4. Check continuity between unified meter and A/C amp. harness connector M48 terminals 1 (L), 11 (R) and BCM harness connector M3 terminals 70 (L), 71 (R).

1 (L) – 70 (L) : Continuity should exist.

11 (R) – 71 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-38, "Work Flow"](#).
- NG >> Repair harness.

**Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)**

AKS00935

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (connector side and harness side).
 - Harness connector M15
 - Harness connector E108

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector and harness connector M15.
2. Check continuity between BCM harness connector M3 terminals 70 (L), 71 (R) and harness connector M15 terminals 2G (L), 7G (R).

70 (L) – 2G (L) : Continuity should exist.
71 (R) – 7G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E108 terminals 2G (L), 7G (R) and ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L), 23 (R).

2G (L) – 20 (L) : Continuity should exist.
7G (R) – 23 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-38, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector F102
 - Harness connector M72

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

AKS00936

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R)

: Approx. 108 – 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M8 terminals 6 (L) and 14 (R).

6 (L) – 14 (R)

: Approx. 54 – 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-38, "Work Flow"](#) .
 NG >> Repair harness between data link connector and unified meter and A/C amp.



Unified Meter and A/C Amp. Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of unified meter and A/C amp. for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect unified meter and A/C amp. connector.
2. Check resistance between unified meter and A/C amp. harness connector M48 terminals 1 (L) and 11 (R).

1 (L) – 11 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace unified meter and A/C amp.
 NG >> Repair harness between unified meter and A/C amp. and BCM.



AKS00939

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M3 terminals 70 (L) and 71 (R).

70 (L) – 71 (R) : Approx. 54 – 66Ω

OK or NG

- OK >> Replace BCM.
 NG >> Repair harness between BCM and harness connector M15.



AKS0093A

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E51 terminals 20 (L) and 23 (R).

20 (L) – 23 (R)

: Approx. 54 – 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



AKS0093B

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).

48 (L) – 49 (R)

: Approx. 108 – 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



LKIA0030E

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connector for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Unified meter and A/C amp.
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector F102.
2. Check continuity between ECM harness connector F101 terminals 94 (L) and 86 (R).

94 (L) – 86 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector F102.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F101 terminals 94 (L), 86 (R) and ground.

94 (L) – ground : Continuity should not exist.

86 (R) – ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector F102.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Unified meter and A/C amp. connector
 - BCM connector
 - Harness connector M15
- Check continuity between data link connector M8 terminals 6 (L) and 14 (R).


6 (L) – 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and harness connector M15



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M8 terminals 6 (L), 14 (R) and ground.

6 (L) – ground : Continuity should not exist.


14 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M72
- Harness between data link connector and unified meter and A/C amp.
- Harness between data link connector and BCM
- Harness between data link connector and harness connector M15



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E9 terminals 48 (L) and 49 (R).


48 (L) – 49 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E9 terminals 48 (L), 49 (R) and ground.

48 (L) – ground : Continuity should not exist.


49 (R) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E108



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-58, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-38, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Check

AKS0093D

1. CHECK IPDM E/R

1. Turn ignition switch ON and then OFF.
2. Check for illuminated parking lamps and tail lamps.

Parking lamps and tail lamps should not illuminate.

OK or NG

OK >> Replace ABS actuator and electric unit (control unit).

NG >> Replace IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

AKS0093E

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-24, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-11, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START" ."](#)

Component Inspection

AKS0093F

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 48 and 49.

| Unit | Terminal | Resistance value (Ω) (Approx.) |
|----------|----------|-----------------------------------|
| ECM | 94 – 86 | 108 - 132 |
| IPDM E/R | 48 – 49 | |

