

SECTION **EL**

CONTENTS

PRECAUTIONS	2	CHARGING SYSTEM	29
Supplemental Restraint System "AIR BAG"	2	Generator	29
HARNES CONNECTOR	3	Diode Check	30
Description	3	Assembly	31
STANDARDIZED RELAY	4	Service Data and Specifications (SDS)	32
Description	4	COMBINATION SWITCH	33
POWER SUPPLY ROUTING	6	Combination Switch/Check	33
Schematic	6	Combination Switch/Replacement	34
Wiring Diagram –POWER–	7	Steering Switch/Check	35
Fuse	13	HEADLAMP	36
Fusible Link	13	System Description (For USA)	36
Circuit Breaker Inspection	13	Low beam operation	36
BATTERY	14	High beam operation/flash-to-pass	
How to Handle Battery	14	operation	36
Methods Of Preventing Discharge	14	Wiring Diagram (For USA) –H/LAMP–	37
Checking Electrolyte Level	14	Trouble Diagnoses (For USA)	38
Specific Gravity Check	15	System Description (For Canada)	39
Hydrometer temperature correction	15	Headlamp Operation	39
Charging The Battery	16	Daytime Light Operation	40
Memory Reset	16	Operation (Daytime light system for Canada)	40
Voltage chart	17	Schematic (For Canada)	41
Service Data and Specifications (SDS)	17	Wiring Diagram (For Canada) –DTRL–	42
STARTING SYSTEM	18	Trouble Diagnoses (For Canada)	45
System Description	18	Daytime Light Control Module Inspection	
M/T models for USA	18	Table	45
M/T models for Canada	18	Bulb Replacement	47
A/T models	18	Aiming Adjustment	47
Wiring Diagram –START–	20	Low Beam	47
M/T models for USA	20	Adjustment After Headlamp Assembly	
M/T models for Canada	21	Replacement	48
A/T models	22	EXTERIOR LAMP	49
Starter	23	Back-up Lamp/Wiring Diagram –BACK/L–	49
Pinion/Clutch Check	25	Clearance, License, Tail and Stop	
Service Data and Specifications (SDS)	25	Lamps/Wiring Diagram –TAIL/L–	50
CHARGING SYSTEM	26	Front Fog Lamp/System Description	53
System Description	26	Front Fog Lamp/Wiring Diagram –F/FOG–	54
Wiring Diagram –CHARGE–	27	Turn Signal and Hazard Warning	
Trouble Diagnoses	28	Lamps/System Description	55

CONTENTS (Cont'd.)

Turn Signal Operation	55	Preliminary check 2.....	93	
Hazard Lamp Operation	55	Preliminary check 3.....	93	GI
Turn Signal and Hazard Warning Lamps/Wiring Diagram –TURN–	56	Main Power Supply And Ground Circuit Check.....	94	MA
Turn Signal and Hazard Warning Lamps/Trouble Diagnoses	58	Diagnostic Procedure 1	95	
Cornering Lamp/System Description	59	Diagnostic Procedure 2	96	EM
Cornering Lamp/Wiring Diagram –CORNER–.....	60	Diagnostic Procedure 3	96	
Combination Flasher Unit Check.....	61	Diagnostic Procedure 4	97	
Bulb Specifications.....	61	Diagnostic Procedure 5	98	LC
INTERIOR LAMP	62	Diagnostic Procedure 6	99	
Illumination/System Description.....	62	Diagnostic Procedure 7	100	
Illumination/Schematic	63	WIPER AND WASHER	101	EC
Illumination/Wiring Diagram –ILL–	64	System Description	101	
Interior, Personal and Trunk Room Lamps/Wiring Diagram –INT/L–	67	Wiper Operation	101	
METERS AND GAUGES	68	Washer Operation.....	102	FE
System Description	68	Front Wiper and Washer/Wiring Diagram – WIPER –	104	
Combination Meter.....	69	Installation	106	CL
Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram –METER–	70	Washer Nozzle Adjustment.....	107	
Inspection/Fuel Gauge and Water Temperature Gauge	72	POWER WINDOW	108	MT
Inspection/Tachometer.....	73	System Description	108	
Inspection/Speedometer and Vehicle Speed Sensor.....	74	Manual Operation	108	
Inspection/Speedometer and Fuse.....	75	Auto Feature.....	109	AT
Fuel Tank Gauge Unit Check	76	Lock Feature.....	110	
Fuel Warning Lamp Sensor Check.....	76	Component Layout.....	111	
Thermal Transmitter Check	76	Wiring Diagram –WINDOW–	112	FA
Oil Pressure Switch Check.....	77	Trouble Diagnoses	114	
Vehicle Speed Sensor Signal Check.....	77	POWER DOOR LOCK	115	RA
WARNING LAMPS AND CHIME	78	System Description	115	
Warning Lamps/System Description.....	78	Power Door Lock.....	115	
Warning Lamps/Schematic	79	Unlock.....	115	BR
Warning Lamps/Wiring Diagram –WARN–	80	Lock	115	
Warning Chime/System Description	83	Circuit Diagram for Quick Pinpoint Check.....	115	
Warning Chime/Wiring Diagram –CHIME–	84	Wiring Diagram –D/LOCK–.....	116	ST
Diode Check	85	Door Lock Timer	118	
Warning Chime Check	85	MIRROR	119	RS
TIME CONTROL SYSTEM	86	Wiring Diagram –MIRROR–	119	
System Description	86	SUNROOF	120	
Function	87	System Description	120	BT
Circuit Diagram for Quick Pinpoint Check.....	88	Power.....	120	
Wiring Diagram – TIME –	89	Tilt And Slide Operation.....	120	HA
Trouble Diagnoses	92	If The Sunroof Does Not Close	120	
Symptom Chart.....	92	Wiring Diagram –SROOF–	121	
Preliminary Check	93	HORN, CIGARETTE LIGHTER, CLOCK	122	EL
Preliminary check 1.....	93	Wiring Diagram –HORN–	122	
		REAR WINDOW DEFOGGER	123	
		System Description	123	IDX
		Wiring Diagram –DEF–.....	124	
		Filament Check.....	125	
		Filament Repair.....	126	

CONTENTS (Cont'd.)

AUDIO AND POWER ANTENNA	127	Theft Warning System Deactivation.....	162
Audio/System Description.....	127	Component Parts and Harness Connector	
With Active Speaker Audio System.....	127	Location.....	163
Without Active Speaker Audio System.....	127	Circuit Diagram for Quick Pinpoint Check.....	164
Audio/Schematic.....	129	Wiring Diagram –THEFT–.....	166
With Active Speaker Audio System.....	129	Trouble Diagnoses.....	173
Audio/Wiring Diagram –AUDIO–.....	130	System Operation Check.....	173
With Active Speaker Audio System.....	130	Power Supply And Ground Circuit Check.....	175
Without Active Speaker Audio System.....	133	Main power supply circuit check.....	175
Power Antenna/System Description.....	134	Power supply circuit check for system	
Location of Antenna.....	134	cancel.....	175
Power Antenna/Wiring Diagram –P/ANT–.....	135	Ground circuit check.....	175
Trouble Diagnoses.....	136	Diagnostic Procedure 1.....	176
Antenna Rod Replacement.....	138	Diagnostic procedure 1-(1).....	176
Window Antenna Repair.....	139	Diagnostic procedure 1-(2).....	177
AUTOMATIC SPEED CONTROL DEVICE		Diagnostic procedure 1-(3).....	178
(ASCD)	140	Diagnostic procedure 1-(4).....	179
System Description.....	140	Diagnostic Procedure 2.....	180
Component Parts and Harness Connector		Diagnostic Procedure 3.....	181
Location.....	142	Diagnostic Procedure 4.....	182
Schematic.....	143	Diagnostic Procedure 5.....	183
Wiring Diagram –ASCD–.....	144	Diagnostic Procedure 6.....	184
Trouble Diagnoses.....	149	Diagnostic Procedure 7.....	185
Symptom Chart.....	149	Diagnostic Procedure 8.....	186
Diagnostic Procedure 1.....	150	Electrical Components Inspection.....	187
Diagnostic Procedure 2.....	152	Door switches.....	187
Diagnostic Procedure 3.....	152	Hood switch.....	187
Diagnostic Procedure 4.....	152	Trunk room lamp switch.....	187
Diagnostic Procedure 5.....	153	Key cylinder switch.....	188
Diagnostic Procedure 6.....	154	Indicator lamp (security lamp).....	188
Diagnostic Procedure 7.....	155	Door unlock sensor.....	188
Diagnostic Procedure 8.....	156	LOCATION OF ELECTRICAL UNITS	189
ASCD Wire Adjustment.....	157	Engine Compartment.....	189
Electrical Components Inspection.....	158	Passenger Compartment.....	190
ASCD actuator/ASCD pump.....	158	HARNES LAYOUT	191
ASCD main switch.....	159	Outline.....	191
ASCD steering switch.....	159	Engine Room Harness.....	192
ASCD cancel switch and stop lamp		Engine Compartment.....	192
switch.....	159	Passenger Compartment.....	194
ASCD clutch pedal position switch (For		Main Harness.....	196
M/T models).....	159	Body Harness.....	198
Inhibitor switch (For A/T models).....	159	Engine Control Harness.....	200
Vehicle speed sensor.....	160	Engine Harness No. 2.....	202
THEFT WARNING SYSTEM	161	Room Lamp Harness.....	203
System Description.....	161	Air Bag Harness.....	204
Theft Warning System Activation (Without		Tail Harness.....	205
key used to lock front doors).....	161	Door Harness (LH side).....	206
Theft Warning System Activation (With key		Front.....	206
used to lock doors).....	161	Rear.....	206
Theft Warning System Operation.....	162	Door Harness (RH side).....	207

CONTENTS (Cont'd.)

Front	207	Location.....	210	GI
Rear	207	Terminal Arrangement.....	210	
SUPER MULTIPLE JUNCTION (SMJ)	208	FUSE BLOCK/FUSIBLE LINK AND FUSE BOX ..	212	
Installation.....	208	Fuse Arrangement	212	MA
Terminal Arrangement.....	209	CONTROL MODULES	213	
JOINT CONNECTOR (J/C)	210			EM

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".


When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system).....	EC SECTION	
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM.....	AT SECTION	CL
ABS	BR SECTION	
HEATER AND AIR CONDITIONING	HA SECTION	MT

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PRECAUTIONS



Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX


SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS
















- 1M 1 Make 2M 2 Make
 1T 1 Transfer 1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE, GREEN or YELLOW
2M				BROWN
1M-1B				GRAY
1M				BLUE

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

POWER SUPPLY ROUTING

Schematic




* 10A - Models without active speaker audio system
 15A - Models with active speaker audio system


POWER SUPPLY ROUTING

Wiring Diagram -POWER-

EL-POWER-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT





Refer to last page (Foldout page).
M7, E103

HA
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)


EL-POWER-02




POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)

EL-POWER-03



*10A-Models without active speaker audio system
15A-Models with active speaker audio system





Refer to last page (Foldout page).
(M7), (E103)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)


EL-POWER-04



POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)

EL-POWER-05



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX





EL-11

POWER SUPPLY ROUTING


Wiring Diagram -POWER- (Cont'd)

EL-POWER-06

FUSE BLOCK
(M11)




POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause of problem.
 - Never wrap outside of fusible link with vinyl tape.
- Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Power door lock
- Power window
- Power sun roof

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA




EL

IDX

BATTERY

CAUTION:

- a. If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- b. After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.



How to Handle Battery

METHODS OF PREVENTING DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- **During every routine maintenance, check the electrolyte level.** This also applies to batteries designated as "low maintenance" and "maintenance-free".
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal.

- Check the condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL

WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.

BATTERY




How to Handle Battery (Cont'd)

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.

SULPHATION

A battery (with specific gravity less than 1.100) will completely discharge when left unattended for a long period of time. This will result in sulphation on the cell plates.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer readings at eye level.

- When electrolyte level is too low, tilt battery case for easy measurement.

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading	Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032	21 (70)	-0.004
66 (150)	0.028	16 (60)	-0.008
60 (140)	0.024	10 (50)	-0.012
54 (129)	0.020	4 (39)	-0.016
49 (120)	0.016	-1 (30)	-0.020
43 (110)	0.012	-7 (20)	-0.024
38 (100)	0.008	-12 (10)	-0.028
32 (90)	0.004	-18 (0)	-0.032
27 (80)	0		

Corrected specific gravity	Approximate charge condition	Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged	1.170 - 1.190	1/4 charged
1.230 - 1.250	3/4 charged	1.140 - 1.160	Almost discharged
1.200 - 1.220	1/2 charged	1.110 - 1.130	Completely discharged

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL

IDX

BATTERY

How to Handle Battery (Cont'd)

CHARGING THE BATTERY

CAUTION:

- a. Do not "quick charge" a fully discharged battery.
- b. Keep the battery away from open flame while it is being charged.
- c. When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- d. If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above are referred to as initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.
- After the battery is charged, always perform a "capacity test" as follows, to assure that the battery is serviceable.

MEMORY RESET

If the battery is disconnected or goes dead the following items must be reset:

- Radio AM and FM preset
- Clock
- AUTO temperature setting trimmer
- ECCS self-learning
- Heater setting



BATTERY

How to Handle Battery (Cont'd)

- Check battery type and determine the specified current using the following table.

Fig. 1 DISCHARGING CURRENT (Load tester)

Type	Current (A)
35	225
24R	260



SEL008Z

Voltage chart

Estimated electrolyte temperature °C (°F)	Minimum voltage under 15 second load
21 (70)	9.6
16 (60)	9.5
10 (50)	9.4
4 (40)	9.3
-1 (30)	9.1
-7 (20)	8.9
-12 (10)	8.7
-18 (0)	8.5

Service Data and Specifications (SDS)

Applied model	USA	USA option and Canada
Type	35	24R
Capacity	V-AH 12-48	12-55

STARTING SYSTEM

System Description

M/T models for USA

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **b** , located in the fusible link and fuse box).

With the ignition switch in the START position, power is supplied

- through terminal ⑤ of the ignition switch
- to clutch interlock relay terminal ③.

Power is also supplied

- through terminal ⑥ of the ignition switch
- to the 10A fuse (No. **16** , located in the fuse block).

For models with theft warning system

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **26** , located in the fuse block)
- to theft warning relay-1 terminal ①.

With the ignition switch in the START position, power is supplied

- through 10A fuse (No. **16** , located in the fuse block)
- to theft warning relay-1 terminal ③
- through theft warning relay-1 terminal ④
- to clutch interlock relay terminal ①.

If the theft warning system is triggered, terminal ② of the theft warning relay-1 is grounded and power to the clutch interlock relay is interrupted.

For models without theft warning system

With the ignition switch in the START position, power is supplied

- through 10A fuse (No. **16** , located in the fuse block)
- to clutch interlock relay terminal ①.

Ground is supplied to clutch interlock relay terminal ②, when the clutch pedal is depressed through the clutch pedal position switch and body grounds **M51**, **M76**, and **M77**.

The clutch interlock relay is energized and power is supplied

- from terminal ⑤ of the clutch interlock relay
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

M/T models for Canada

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **b** , located in the fusible link and fuse box).

With the ignition switch in the START position, power is supplied:

- from ignition switch terminal ⑤
- directly to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

A/T models

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **b** , located in the fusible link and fuse box).

For USA models with theft warning system

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **26** , located in the fuse block)
- to theft warning relay-1 terminal ①.

STARTING SYSTEM

System Description (Cont'd)

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- to theft warning relay-1 terminal ③
- through theft warning relay-1 terminal ④
- to inhibitor switch terminal ②
- through inhibitor switch terminal ①, with the selector lever in the P or N position
- to terminal ① of the starter motor windings.

If the theft warning system is triggered, terminal ② of the theft warning relay-1 is grounded and power to the inhibitor switch is interrupted.

For USA models without theft warning system

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- to inhibitor switch terminal ②
- through inhibitor switch terminal ①, with the selector lever in the P or N position
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

STARTING SYSTEM

Wiring Diagram -START-


M/T models for USA

EL-START-01



Refer to last page (Foldout page).

M7, E103




STARTING SYSTEM

Wiring Diagram -START- (Cont'd)

M/T models for Canada

EL-START-02



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL


IDX

STARTING SYSTEM

Wiring Diagram -START- (Cont'd)

A/T models

EL-START-03



- (UW) : U.S.A. models with theft warning system
- (UO) : U.S.A. models without theft warning system




STARTING SYSTEM

Starter

M1T73881ZC

Plate thickness:
0.25 (0.0098)
0.50 (0.0197)



- ① Sleeve bearing
- ② Gear case
- ③ Pinion stopper
- ④ Pinion assembly
- ⑤ Shift lever
- ⑥ Plate
- ⑦ Packing

- ⑧ Adjusting plate
- ⑨ Magnetic switch assembly
- ⑩ Internal gear
- ⑪ Shaft
- ⑫ Planetary gear
- ⑬ Packing
- ⑭ Yoke

- ⑮ Armature
- ⑯ Sleeve bearing
- ⑰ Brush (+)
- ⑱ Brush spring
- ⑲ Brush (-)
- ⑳ Brush holder
- ㉑ Rear cover

SEL197R

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

STARTING SYSTEM

Starter (Cont'd)

S114-754A



AEL350

STARTING SYSTEM

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

Service Data and Specifications (SDS)

STARTER

Type	M1T73881ZC		S114-754A	
	MELMAC		HAP	
	Reduction gear type			
Applied model	A/T		M/T	
System voltage	V	12		
No-load				
Terminal voltage	V	11.0		
Current	A	Less than 88	Less than 85	
Revolution	rpm	More than 3,000	More than 2,950	
Minimum diameter of commutator	mm (in)	28.8 (1.134)	28.0 (1.102)	
Minimum length of brush	mm (in)	12.0 (0.472)	10.5 (0.413)	
Brush spring tension	N (kg, lb)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	14.7 - 17.7 (1.5 - 1.8, 3.3 - 4.0)	
Clearance of bearing metal and armature shaft	mm (in)	—	0.03 - 0.3 (0.0012 - 0.0118)	
Clearance "t" between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)	0.05 - 1.5 (0.0020 - 0.0591)	
Installed current	A	140	120	

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CHARGING SYSTEM

System Description

The generator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to generator terminal **(S)** through:

- 10A fuse (No. **(31)** , located in the fusible link and fuse box).

Voltage output through generator terminal **(B)**, to charge the battery and operate the vehicle's electrical system, is controlled by the amount of voltage detected by the IC regulator at terminal **(S)**. The charging circuit is protected by the 75A fusible link.

Terminal **(E)** of the generator supplies ground through body ground **(E41)**.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **(25)** , located in the fuse block)
- to combination meter terminal **(43)** for the charge warning lamp.


Ground is supplied to terminal **(44)** of the combination meter through terminal **(L)** of the generator. With power and ground supplied, the charge warning lamp will illuminate. When the generator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated. Refer to "Trouble Diagnoses", "CHARGING SYSTEM" (EL-28).

CHARGING SYSTEM



Wiring Diagram -CHARGE-

EL-CHARGE-01



Refer to "EL-POWER".

Refer to last page (Foldout page).



(M7), (E103)

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX


CHARGING SYSTEM

Trouble Diagnoses

Before conducting an generator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The generator can be checked easily by referring to the Inspection Table.

Before starting diagnosis, inspect the fusible link.


WITH IC REGULATOR



- 1) Use fully charged battery.
- 2) Light : Charge warning light
G.C.G. : Generator parts except IC regulator
IC-RG : IC regulator
O.K. : IC-generator is in good condition.
- 3) When reaching "Damaged G.C.G.", remove generator from vehicle and disassemble, inspect and correct or replace faulty parts.
- 4) *Method of grounding F terminal (HITACHI make only)

Gasoline engine model

Contact tip of wire with brush and attach wire to generator body.



SEL030Z


- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of generator.

Make sure connector (S, L) is connected correctly.

CHARGING SYSTEM

Generator

LR180-736B



- ① Pulley assembly
- ② Front cover
- ③ Front bearing
- ④ Retainer

- ⑤ Rotor
- ⑥ Slip ring
- ⑦ Stator
- ⑧ Condenser

- ⑨ IC regulator assembly
- ⑩ Brush holder
- ⑪ Diode assembly
- ⑫ Rear cover

: N·m (kg·m, ft·lb)

SEL287R

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CHARGING SYSTEM


Diode Check

MAIN DIODES


- In order to check diodes, they must be unsoldered from the stator.
- Use an ohmmeter to check condition of diodes as indicated in chart below.
- If any of the test results is not satisfactory, replace diode assembly.

	Ohmmeter probes		Judgement
	Positive ⊕	Negative ⊖	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Positive diode plate	
Diodes check (Negative side)	Negative diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Negative diode plate	


Type 1




Type 4




Type 2




Type 5



Type 3



Type 6



SEL039Z

Assembly

Carefully observe the following instructions.

- When soldering each stator coil lead wire to diode assembly terminal, carry out the operation as fast as possible.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX




RING FITTING IN REAR BEARING

- Fix ring into groove in rear bearing so that it is as close to the adjacent area as possible.

CAUTION:


Do not reuse rear bearing after removal.



REAR COVER INSTALLATION

- (1) Fit brush assembly, diode assembly, regulator assembly and stator.
- (2) Push brushes up with fingers and install them to rotor.

Take care not to damage slip ring sliding surface.



CHARGING SYSTEM



Service Data and Specifications (SDS)

GENERATOR

Type		LR180-736B
		HAP
Nominal rating	V-A	12-80
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,000
Hot output current (When 13.5 volts is applied)	A/rpm	More than 23/1,300 More than 63/2,500 More than 77/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	6.0 (0.236)
Brush spring pressure	N (g, oz)	1.000 - 2.452 (102 - 250, 3.60 - 8.82)
Slip ring minimum diameter	mm (in)	26.0 (1.024)
Rotor (Field coil) resistance	Ω	2.67

COMBINATION SWITCH

Combination Switch/Check




LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5									
6									
7									
8									
9									
10									
11									
12									

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13					
14					
15					
16					
17					
18					

INTERMITTENT WIPER VOLUME



TURN SIGNAL SWITCH

	R	N	L
1			
2			
3			

CORNERING LAMP SWITCH


	R	N	L
61			
62			
63			

FRONT FOG LAMP SWITCH

	OFF	ON
2		
1		


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

COMBINATION SWITCH



Combination Switch/Replacement


- Each switch can be replaced without removing combination switch base.




- To remove combination switch base, remove base attaching screws.

COMBINATION SWITCH

Steering Switch/Check



N.m (kg-m, ft-lb)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Description (For USA)

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal ⑤
- through 15A fuse (No. ③⑥ , located in the fusible link and fuse box), and
- to lighting switch terminal ⑧
- through 15A fuse (No. ③⑦ , located in the fusible link and fuse box).

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to terminal ① of the LH headlamp, and
- from lighting switch terminal ⑦
- to terminal ① of the RH headlamp.

Terminal ③ of each headlamp supplies ground through body grounds ①② and ①③. With power and ground supplied, the headlamp(s) will illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is placed in the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal ⑥
- to terminal ② of the RH headlamp, and
- from lighting switch terminal ⑨
- to terminal ② of the LH headlamp, and
- to combination meter terminal ⑪ for the HI BEAM indicator.

Ground is supplied to terminal ⑩ of the combination meter through body grounds ①⑤, ①⑥, and ①⑦. With power and ground supplied, the high beams and the HI BEAM indicator illuminate.


Theft warning system

The theft warning system will flash the high beams if the system is triggered. Refer to "System Description", "THEFT WARNING SYSTEM", (EL-161).

HEADLAMP


Wiring Diagram (For USA) -H/LAMP-

EL-H/LAMP-01



Refer to last page (Foldout page).

(M7), (E103)
(E3)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Trouble Diagnoses (For USA)

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E12) and (E37) 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E12) and (E37). 3. Check 15A fuse (No. 37), located in fusible link and fuse box). Verify battery positive voltage is present at terminal (8) of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E12) and (E37) 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E12) and (E37). 3. Check 15A fuse (No. 36), located in fusible link and fuse box). Verify battery positive voltage is present at terminal (5) of lighting switch. 4. Check lighting switch.
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/B wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/Y wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb. 2. Open in RH high beam circuit 3. Lighting switch. 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/G wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/L wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (M51), (M76) and (M77) 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds (M51), (M76) and (M77). 3. Check R/B wire between joint connector - 5 and combination meter for an open circuit.

System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control module that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 36 , located in the fusible link and fuse box)
- to daytime light control module terminal ③ and
- to lighting switch terminal ⑤.

Power is also supplied at all times

- through 15A fuse (No. 37 , located in the fusible link and fuse box)
- to daytime light control module terminal ④ and
- to lighting switch terminal ⑧.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 26 , located in the fuse block)
- to daytime light control module terminal ⑤.

Ground is supplied to daytime light control module terminal ⑩ through body grounds M51 , M76 and M77 .

HEADLAMP OPERATION

Low beam operation

When the lighting switch is moved to the 2ND position and placed in LOW ("B") position (low beam operation), power is supplied

- from lighting switch terminal ⑦
- to RH headlamp terminal ①.

Ground is supplied to RH headlamp terminal ③ through body grounds E12 and E37 .

Also, when the lighting switch is moved to the 2ND position and placed in LOW ("B") position (low beam operation), power is supplied

- from lighting switch terminal ⑩
- to LH headlamp terminal ①.

Ground is supplied

- to LH headlamp terminal ③
- from daytime light control module terminal ⑧
- through daytime light control module terminal ⑩
- through body grounds M51 , M76 and M77 .

With power and ground supplied, the low beam headlamps illuminate.

High beam operation

When the lighting switch is moved to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal ⑥
- to RH headlamp terminal ②.

Also, when the lighting switch is moved to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal ⑨
- to daytime light control module terminal ⑥
- through daytime light control module terminal ⑦
- to LH headlamp terminal ②.

Ground is supplied in the same manner as low beam operation.

With power and ground supplied, the high beam headlamps illuminate.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

System Description (For Canada) (Cont'd)

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position, power is supplied

- to daytime light control module terminal ④
- through daytime light control module terminal ⑦
- to LH headlamp terminal ②
- through LH headlamp terminal ③
- to daytime light control module terminal ⑧
- through daytime light control module terminal ⑨
- to RH headlamp terminal ②.

Ground is supplied to RH headlamp terminal ③ through body grounds (E12) and (E37).

Because the high beam headlamps are now wired in series, they operate at half illumination.

Operation (Daytime light system for Canada)

The headlamps' high beams automatically turn on after starting the engine with the lighting switch in "OFF" or "1st" position. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	X	○
	Low beam	X	X	X	X	X	X	X	○	X	X	X	X	X	X	X	X	○	X
Clearance and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○

○: Lamp "ON"

X: Lamp "OFF"

△: Lamp dims.


□: Added functions

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.

HEADLAMP

Schematic (For Canada)




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Wiring Diagram (For Canada) -DTRL-


EL-DTRL-01



Refer to "EL-POWER".

Refer to last page (Foldout page).




- (M7), (E103)
- (M6), (B1)
- (M64)
- (E3)



HEADLAMP

Wiring Diagram (For Canada) -DTRL- (Cont'd)

EL-DTRL-02




Refer to last page (Foldout page).

(M7) (E103)
(E3)




HEADLAMP

Wiring Diagram (For Canada) -DTRL- (Cont'd)


EL-DTRL-03



Preceding page



Refer to last page (Foldout page).


















HEADLAMP

Trouble Diagnoses (For Canada)






DAYTIME LIGHT CONTROL MODULE INSPECTION TABLE

(Data are reference values)


Terminal No.	Item	Condition	Judgement standard
1	Start/parking brake signal	 When turning ignition switch to "ST".	Battery positive voltage
		  When turning ignition switch to "ON" from "ST" with parking brake set.	Battery positive voltage
		  When releasing parking brake with engine running. CAUTION: Block wheels and ensure selector lever is in N or P position.	1V or less
		 When turning ignition switch to "OFF".	1V or less
2	Lighting switch (Lo beam in)	When turning lighting switch to 2nd position and placed in LOW ("B") position.	Battery positive voltage
3	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "OFF".	Battery positive voltage
4	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "OFF".	Battery positive voltage
5	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "ST".	Battery positive voltage
		 When turning ignition switch to "OFF".	1V or less
6	Lighting switch (Hi beam in)	When turning lighting switch to 2nd position and placed in HIGH ("A") position.	Battery positive voltage
		When turning lighting switch to PASS ("C") position.	Battery positive voltage
7	LH hi beam out	When turning lighting switch to 2nd position and placed in HIGH ("A") position.	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation). CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery positive voltage

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

HEADLAMP Trouble Diagnoses (For Canada) (Cont'd)

Terminal No.	Item	Condition		Judgement standard
8	LH headlamp control (ground)		When lighting switch is turned to 2nd position and placed in LOW ("B") position.	1V or less
			When releasing parking brake with engine running and turning lighting switch to "OFF" (day-time light operation). CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
9	RH hi beam out		When turning lighting switch to 2nd position and placed in HIGH ("A") position.	Battery positive voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (day-time light operation). CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
10	Ground		—	—
11	Generator		When turning ignition switch to "ON".	1V or less
			When engine is running.	Battery positive voltage
			When turning ignition switch to "OFF".	1V or less
12	—		—	—

HEADLAMP



Bulb Replacement


The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- Grasp only the plastic base when handling the bulb. Never touch the glass envelope.

1. Disconnect the battery cable.
2. Disconnect the harness connector from the back side of the bulb.
3. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
4. Pull off the rubber cap.
5. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
6. Install in the reverse order of removal.

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.





Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated according to their operation manuals. Before performing aiming adjustment, make sure of the following.

- a. Keep all tires inflated to correct pressure.
- b. Place vehicle on level ground.
- c. See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

LOW BEAM

1. Open the hood.
2. Adjust the vertical indicator by turning the adjusting screw. The bubble in the gauge should be centered on the "o" mark as shown in the illustration.



3. Adjust the horizontal indicator by turning the adjusting screw with a Philips screwdriver. The inner red line with the "o" mark should align with the indicator line. Never turn screw (A).

HEADLAMP

Aiming Adjustment (Cont'd)

ADJUSTMENT AFTER HEADLAMP ASSEMBLY REPLACEMENT

If the vehicle has had front body repair or the headlamp assembly has been replaced, check the aiming as shown in the illustration.


Vertical (Up and Down)

Adjust headlamp by turning adjusting screw so that main axis of light "M" is within acceptable range.

Horizontal (Left to Right)



Adjust headlamp by turning adjusting gear so that main axis of light "M" is parallel with vehicle center line.

If the indicators are not in the "Optimal" range, the "OK" range is acceptable.



EXTERIOR LAMP

Back-up Lamp/Wiring Diagram -BACK/L- EL-BACK/L-01



Refer to last page (Foldout page).


M7 E103
M6 B1

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L-

EL-TAIL/L-01



Refer to last page (Foldout page).


(M7), (E103)
(E3)





EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L- (Cont'd)

EL-TAIL/L-02






Refer to last page (Foldout page).
 (M6), (B1)



EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L- (Cont'd)

EL-TAIL/L-03



EXTERIOR LAMP

Front Fog Lamp/System Description

Power is supplied at all times to front fog lamp relay terminal ③ through:

- 15A fuse (No. 21 , located in the fuse block).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 15A fuse (No. 36 , located in the fusible link and fuse box)
- to lighting switch terminal ⑤
- through terminal ⑦ of the lighting switch
- to front fog lamp relay terminal ①.

Fog lamp operation

The front fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the front fog lamp switch in the ON position:

- ground is supplied to front fog lamp relay terminal ② through the front fog lamp switch and body grounds E12 and E37.

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal ⑤
- to terminal ① of each front fog lamp.

Ground is supplied to terminal ② of each front fog lamp through body grounds E12 and E37.

With power and ground supplied, the front fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA



EL

IDX


EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram -F/FOG-

EL-F/FOG-01



Refer to last page (Foldout page).



EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 24 , located in the fuse block)
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds (M51), (M76) and (M77).

LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to

- front turn signal lamp LH terminal ①
- rear combination lamp LH terminal ⑤, and
- combination meter terminal ⑩.

Ground is supplied to the front turn signal lamp LH terminal ② through body grounds (E12) and (E37).

Ground is supplied to the rear combination lamp LH terminal ⑥ through body ground (T7).

Ground is supplied to combination meter terminal ⑰ through body grounds (M51), (M76) and (M77).

With power and grounds supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to

- front turn signal lamp RH terminal ①
- rear combination lamp RH terminal ⑤, and
- combination meter terminal ⑰.

Ground is supplied to the front turn signal lamp RH terminal ② through body grounds (E12) and (E37).

Ground is supplied to the rear combination lamp RH terminal ⑥ through body ground (T7).

Ground is supplied to combination meter terminal ⑰ through body grounds (M51), (M76) and (M77).

With power and grounds supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 10A fuse (No. 22 , located in the fuse block).

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ② through body grounds (M51), (M76) and (M77).

Power is supplied through terminal ⑤ of the hazard switch to

- front turn signal lamp LH terminal ①
- rear combination lamp LH terminal ⑤, and
- combination meter terminal ⑩.

Power is supplied through terminal ⑥ of the hazard switch to

- front turn signal lamp RH terminal ①
- rear combination lamp RH terminal ⑤, and
- combination meter terminal ⑰.

Ground is supplied to terminal ② of the front turn signal lamps through body grounds (E12) and (E37).

Ground is supplied to terminal ⑥ of the rear combination lamps through body ground (T7).

Ground is supplied to combination meter terminal ⑰ through body grounds (M51), (M76) and (M77).

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

EXTERIOR LAMP


Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN-

EL-TURN-01



Refer to last page (Foldout page).


(M7) . (E103)



EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN- (Cont'd)


EL-TURN-02



CI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Refer to last page (Foldout page).

(M6) (B1)



EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 24 , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check LB/G wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 22 , located in fuse block). Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check LG/B wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E12 and E37 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E12 and E37.
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Ground T7 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check ground T7.
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Ground 	<ol style="list-style-type: none"> 1. Check grounds M51 , M76 and M77.
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 	<ol style="list-style-type: none"> 1. Check bulb in combination meter.

EXTERIOR LAMP

Cornering Lamp/System Description

The lighting switch must be in the 2ND and LOW ("B") or HIGH ("A") position for the cornering lamps to operate. The cornering lamp switch is a part of the combination switch and is controlled by the turn signal lever. The cornering lamps provide additional lighting in the direction of the turn.

Power is supplied at all times to terminal ⑧ of the lighting switch through:

- 15A fuse (No. 37), located in the fusible link and fuse box.

With the ignition switch in the ON or START position, power is supplied to cornering lamp relay terminal ③ through:

- 10A fuse (No. 24), located in the fuse block).

Power is supplied to cornering lamp relay terminal ①

- through terminal ⑩ of the lighting switch in the 2ND and LOW ("B") position or
- through terminal ⑨ of the lighting switch in the 2ND and HIGH ("A") position.

Ground is supplied to cornering lamp relay terminal ② through body grounds (E12) and (E37).

With power and ground supplied, the cornering lamp relay is energized.

Power is supplied

- from terminal ⑤ of the cornering lamp relay
- to cornering lamp switch terminal ⑥1.

RH turn

When the turn signal lever is moved to the RH position, power is supplied

- from terminal ⑥1 of the cornering lamp switch
- through terminal ⑥2 of the cornering lamp switch
- to cornering lamp RH terminal ①.

Ground is supplied to terminal ② of cornering lamp RH through body grounds (E12) and (E37).

The RH cornering lamp illuminates until the turn is completed.

LH turn

When the turn signal lever is moved to the LH position, power is supplied

- from terminal ⑥1 of the cornering lamp switch
- through terminal ⑥3 of the cornering lamp switch
- to cornering lamp LH terminal ①.

Ground is supplied to terminal ② of cornering lamp LH through body grounds (E12) and (E37).

The LH cornering lamp illuminates until the turn is completed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

EXTERIOR LAMP

Cornering Lamp/Wiring Diagram -CORNER-


EL-CORNER-01



U : For U.S.A.
N : For Canada


Refer to "EL-POWER".

Refer to last page (Foldout page).



M7, E103
E3

EXTERIOR LAMP



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

Bulb Specifications

	Wattage (12 volt)	Bulb No.	
Headlamp (Semi-sealed beam)			EC
High/Low	60/55	HB2	FE
Front turn signal lamp	27	1156NA	
Cornering lamp/Front clearance lamp	27/5	1157	CL
Front side marker lamp	3.8	194	MT
Front fog lamp	55		
Rear combination lamp			
Turn signal	27	1156	AT
Stop/Tail	27/8	1157	
Back-up	27	1156	FA
Rear side marker lamp	3.8	194	
License plate lamp	5	168	RA
High-mounted stop lamp	13	912	
Interior lamp	8		BR
Front personal lamp	10		
Trunk room lamp	3.4	158	ST

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

INTERIOR LAMP

Illumination/System Description

Power is supplied at all times

- through 15A fuse (No. 23 , located in the fuse block)
- to lighting switch terminal ⑪.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch is a thumbwheel that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The ashtray illumination and the glove box lamp are not controlled by the illumination control switch. The intensity of these lamps does not change.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Power terminal	Ground terminal
Radio	⑧	⑦
CD player*	⑳	㉕
Auto A/C amplifier*	⑬	⑭
Push control module*	⑮	⑯
PTC*	㉗**	㉓
A/T device indicator*	③	④
Hazard switch	⑦	⑧
Main power window and door lock switch	③	⑧
Ashtray	①	②
Combination meter	④①	④①
Clock*	⑤	③
ASCD main switch*	⑤	⑥
Rear window defogger switch	⑤	⑥
Glove box lamp*	②	①
Illumination control switch	①	③

* If equipped.

** Power supplied to PTC terminal ㉗ is supplied through terminal ㉗ of the push control module.


With the exception of the glove box lamp and the ashtray illumination, the ground for all of the components are controlled through terminals ④ and ⑤ of the illumination control switch and body grounds ①⑤①, ①⑦⑥ and ①⑦⑦.

When the glove box is open, glove box lamp terminal ① is grounded through the glove box lamp switch and body grounds ①⑤①, ①⑦⑥ and ①⑦⑦.

The ashtray illumination terminal ② is grounded directly through body grounds ①⑤①, ①⑦⑥ and ①⑦⑦.

INTERIOR LAMP

Illumination/Schematic




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

INTERIOR LAMP

Illumination/Wiring Diagram -ILL-

EL-ILL-01




OX : Except XE models

Next page

Next page

Refer to last page (Foldout page).

M7, E103
E3





INTERIOR LAMP

Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-02

WA : Models with active speaker audio system

A : A/T models





GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

INTERIOR LAMP

Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-03

- AS : Models with ASCD system
- WA : Models with active speaker audio system
- OA : Models without active speaker audio system
- CD : Models with CD player
- MA : Models with manual air conditioning system
- AA : Models with auto air conditioning system




INTERIOR LAMP

Interior, Personal and Trunk Room Lamps/Wiring Diagram -INT/L-

EL-INT/L-01


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



WS : Models with sun roof
OS : Models without sun roof

Refer to "EL-POWER".

Refer to last page (Foldout page).
M6, B1



System Description

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 25), located in the fuse block)
- to combination meter terminal 43 for the water temperature gauge,
- combination meter terminal 22 for the tachometer and
- combination meter terminal 2 for the fuel gauge and speedometer.

Ground is supplied

- to combination meter terminal 38
- through body grounds M51, M76 and M77.

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 37 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 3 of the ECM (ECCS control module)
- to combination meter terminal 35 for the tachometer.

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 4 for the fuel gauge
- from terminal 1 of the fuel tank gauge unit
- through terminal 3 of the fuel tank gauge unit and
- through body grounds B6 and B14.

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.




The voltage is supplied

- to combination meter terminals 3 and 19 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

METERS AND GAUGES

Combination Meter







GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METERS AND GAUGES

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram -METER-

EL-METER-01




Refer to last page (Foldout page).
(M6, B1)


METERS AND GAUGES

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram -METER- (Cont'd)


EL-METER-02



Preceding page







Refer to last page (Foldout page).





GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METERS AND GAUGES


Inspection/Fuel Gauge and Water Temperature Gauge



METERS AND GAUGES








Inspection/Tachometer



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Inspection/Speedometer and Vehicle Speed Sensor




SYMPTOM: Speedometer stays at 0 km/h (0 MPH).



METERS AND GAUGES


Inspection/Speedometer and Vehicle Speed Sensor (Cont'd)

SYMPTOM: Speedometer indication flutters.




Inspection/Speedometer and Fuse

SYMPTOM: Speedometer does not go back to 0 km/h (0 MPH).



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METERS AND GAUGES




Fuel Tank Gauge Unit Check

- For removal, refer to FE section ("Fuel Pump and Gauge", "FUEL SYSTEM").


Check the resistance between terminals (G) and (E).

Ohmmeter		Float position		Resistance value (Ω)
(+)	(-)	mm	(in)	
G	E	*3	Full	80.5 (3.169)
		*2	1/2	29.4 (1.157)
		*1	Empty	19.0 (0.748)
				Approx. 4.5 - 6
				Approx. 31.5 - 33.5
				Approx. 80 - 83



Fuel Warning Lamp Sensor Check

- It will take a short time for the bulb to light.




Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 Ω
100°C (212°F)	Approx. 21 - 24 Ω


METERS AND GAUGES



Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES

Check the continuity between the terminals of oil pressure switch and body ground.



Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transaxle.
2. Turn vehicle speed sensor pinion quickly and measure voltage across ① and ②.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Warning Lamps/System Description

If equipped with theft warning system, power is supplied at all times

- through 10A fuse (No. 20 , located in the fuse block)
- to combination meter terminal 32 for the security lamp.

Ground for the security lamp is supplied when the system is activated

- to combination meter terminal 39
- from terminal 2 of the theft warning control module.

With the ignition switch in the ON or START position, power is supplied


- through 10A fuse (No. 25 , located in the fuse block)
- to combination meter terminal 22 for the air bag warning lamp
- to combination meter terminal 43 and
- to combination meter terminal 2.

Ground is supplied for each of the warning lamps through different terminals of the combination meter.

For details of power and ground terminals for the warning lamps in the combination meter, refer to "Combination Meter", "METERS AND GAUGES".

WARNING LAMPS AND CHIME

Warning Lamps/Schematic



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX


WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram -WARN-

EL-WARN-01






WT : Models with theft warning system



WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram -WARN- (Cont'd)

EL-WARN-02





Refer to last page (Foldout page).

(M7, E103)
(M6, B1)
(F19)

WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram -WARN- (Cont'd)

EL-WARN-03



Refer to last page (Foldout page).

- M6 . B1
- M7 . E103

Warning Chime/System Description

The warning chime is a part of the combination meter and is controlled by the time control module.

Power is supplied at all times

- through 10A fuse (No. 20 , located in the fuse block)
- to time control module terminal ⑨,
- combination meter terminal ⑳, and
- key switch terminal ①.

Power is supplied at all times

- through 15A fuse (No. 23 , located in the fuse block)
- to lighting switch terminal ⑪.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 26 located in the fuse block)
- to time control module terminal ⑥.

Ground is supplied to time control module terminal ⑮ through body grounds M51 , M76 and M77 .

When a signal, or combination of signals, is received by the time control module, ground is supplied

- through time control module terminal ⑱
- to combination meter terminal ㉔.

With power and ground supplied, the warning chime will sound.

Ignition key warning chime

With the key inserted in the ignition switch in the OFF position, and the driver's door open, the warning chime will sound. A battery positive voltage signal is sent

- from key switch terminal ②
- to time control module terminal ⑲.

Ground is supplied

- from front door switch LH terminal ①
- to time control module terminal ⑩.

Front door switch LH terminal ③ is grounded through body grounds B6 and B14 .

Light warning chime

With the ignition switch in the OFF position, the driver's door open, and the lighting switch in the 1ST or 2ND position, the warning chime will sound. A battery positive voltage signal is sent

- from lighting switch terminal ⑫
- to time control module terminal ⑦.

Ground is supplied

- from front door switch LH terminal ①
- to time control module terminal ⑩.

Seat belt warning chime

With the ignition switch turned from the OFF position to the ON position, and the seat belt unfastened (seat belt switch ON), the warning chime will sound for approximately 7 seconds.

Ground is supplied

- from seat belt buckle switch terminal ①
- to time control module terminal ⑳.

Seat belt buckle switch terminal ② is grounded through body grounds B6 and B14 .

For diagnosis, refer to "TIME CONTROL SYSTEM".

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX


WARNING LAMPS AND CHIME

Warning Chime/Wiring Diagram -CHIME-

EL-CHIME-01




Refer to last page (Foldout page).



- M7, E103
- M6, B1
- E9


WARNING LAMPS AND CHIME



Diode Check


- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.

Refer to EL-69.



Warning Chime Check

Supply battery voltage to warning chime as shown in the illustration.

Warning chime should operate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

System Description

Power is supplied at all times

- to time control module terminal ⑨
- through 10A fuse (No. 20 , located in the fuse block).

With the ignition switch in the ACC or ON position, power is supplied

- to time control module terminal ⑪
- through 10A fuse (No. 12 , located in the fuse block).

With the ignition switch in the ON or START position, power is supplied

- to time control module terminal ⑥
- through 10A fuse (No. 26 , located in the fuse block).

Terminal ⑮ of the time control module is grounded through body grounds M51 , M76 and M77 .

The time control system controls operation of the

- rear window defogger,
- warning chime and
- front wiper and washer.

Rear Window Defogger

The time control module will operate the rear window defogger for 15 minutes as long as the rear window defogger switch is in the ON position. For detailed description, refer to REAR WINDOW DEFOGGER.

Warning Chime

The time control system will operate the warning chime located on the combination meter under the following conditions:

- key in ignition, ignition switch in OFF position, and driver's door open.
- ignition switch in the OFF position, driver's door open, and lighting switch in the 1ST or 2ND position.
- ignition switch turned from the OFF position to the ON position, and the seat belt unfastened.

For detailed description, refer to "WARNING LAMPS AND CHIME", (EL-83).

Front Wiper and Washer

The time control system controls operation of the intermittent feature for the front wiper. It also controls wiper motor for the washer operation.

For detailed description, refer to "FRONT WIPER AND WASHER", (EL-101).

TIME CONTROL SYSTEM

System Description (Cont'd)

FUNCTION

- Time control module has the following functions.

Item	Details of control
Intermittent wiper control	Regulates intermittent time from approximately 1 to 20 seconds depending on the intermittent wiper volume setting.
Washer and wiper combination control	Wiper is operated in conjunction with washer switch.
Light warning chime timer	When driver's door is opened with lighting switch ON and ignition switch OFF, warning chime sounds.
Ignition key warning chime timer	When driver's door is opened with the key in the ignition and the ignition switch OFF, warning chime sounds.
Seat belt warning chime timer	Sounds warning chime for about 7 seconds if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened).
Rear defogger timer	Rear defogger operates for about 15 minutes when defogger switch is ON.

GI

MA

EM

LG

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TIME CONTROL SYSTEM


Circuit Diagram for Quick Pinpoint Check




TIME CONTROL SYSTEM

Wiring Diagram -TIME-

EL-TIME-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).


M7, E103
E3

HA
EL
IDX

TIME CONTROL SYSTEM




Wiring Diagram -TIME- (Cont'd)

EL-TIME-02



Refer to last page (Foldout page).


(M7), (E103)
(E3)



TIME CONTROL SYSTEM



Wiring Diagram -TIME- (Cont'd)

EL-TIME-03



Refer to last page (Foldout page).

M7, E103
M6, B1



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TIME CONTROL SYSTEM

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE		Preliminary Check			Main Power Supply and Ground Circuit Check	Diagnostic Procedure							
		EL-93	EL-93	EL-93		EL-94	EL-95	EL-96	EL-96	EL-97	EL-98	EL-99	EL-100
REFERENCE PAGE													
SYMPTOM		Preliminary check 1	Preliminary check 2	Preliminary check 3	Main power supply and Ground circuit check	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	
Wiper & washer	Intermittent wiper does not operate.				○	○							
	Intermittent time of wiper cannot be adjusted.						○						
	Wiper and washer activate individually but not in combination.							○					
Warning	Light warning chime does not activate.	○			○				○				
	Ignition key warning chime does not activate.		○		○					○			
	Seat belt warning chime does not activate.			○	○						○		
Rear defogger	Rear defogger does not activate, or go off after activating.				○							○	


TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK


Preliminary check 1

- Light warning chime does not activate.




Preliminary check 2

- Ignition key warning chime does not activate.



Preliminary check 3

- Seat belt warning chime does not activate.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL


IDX

TIME CONTROL SYSTEM


Trouble Diagnoses (Cont'd)

MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply



Terminals	Battery positive voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
⑨ - ⑮	Yes	Yes	Yes
⑥ - ⑮	No	No	Yes
⑪ - ⑮	No	Yes	Yes



Ground circuit



Terminals	Continuity
⑮ - Ground	Yes

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.




A

WIPER RELAY OUTPUT SIGNAL CHECK

- 1.) Turn ignition switch to "ACC".
- 2.) Turn wiper switch to "INT" or "OFF".
- 3.) Measure voltage between time control module harness terminals ⑬ and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	Pointer swings from 0 to 12 every 3 to 23 seconds





B

INTERMITTENT SWITCH INPUT SIGNAL CHECK

Measure voltage between time control module harness terminals ① and ⑮.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
INT	0




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.



A

INTERMITTENT WIPER VOLUME INPUT SIGNAL CHECK
 Measure resistance between time control module harness terminals (4) and (15) while turning intermittent wiper volume.

Condition of washer switch	Voltage [V]
OFF	Approx. 12
ON	0


OK → **TRY A KNOWN GOOD TIME CONTROL MODULE.***

NG

Check intermittent wiper volume.
 Check harness continuity between time control module and wiper switch.

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.




A

WASHER SWITCH INPUT SIGNAL CHECK
 1.) Turn ignition switch to "ACC".
 2.) Measure voltage between time control module harness terminals (2) and (15).

Position of wiper knob	Resistance [Ω]
S	0
L	Approx. 1 k

NG → Check harness continuity between time control module and washer switch.



B

TIME CONTROL MODULE SIGNAL CHECK
 Measure voltage between time control module harness terminals (13) and (15) after operating washer switch.
0V for approx. 3 seconds after washer has operated.

NG → **TRY A KNOWN GOOD TIME CONTROL MODULE.***

OK

Check wiper relay and circuit.

NG → Repair wiper circuit or replace wiper relay.

*: Time control module may be the cause of a problem, but this is rarely the case.







TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Light warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 1" before referring to the following flow chart.



*: Time control module may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX




TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Ignition key warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 2" before referring to the following flow chart.



A Step 3

DOOR SWITCH INPUT SIGNAL CHECK
Measure voltage between time control module harness terminals ⑩ and ⑮.

NG → Check door switch. Check harness continuity between time control module and door switch.

Condition of driver's door	Voltage [V]
Door is closed	Approx. 12
Door is open	0

B Step 2

CHIME OUTPUT SIGNAL CHECK
Measure voltage between time control module harness terminals ⑱ and ⑮.

OK → Check chime. Check harness continuity between time control module and chime.

NG →

C Step 1

IGNITION KEY SWITCH INPUT SIGNAL CHECK
Measure voltage between time control module harness terminals ⑲ and ⑮.

NG → Check ignition key switch. Check harness continuity between time control module and ignition key switch.

OK →

TRY A KNOWN GOOD TIME CONTROL MODULE.*

*: Time control module may be the cause of a problem, but this is rarely the case.



TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: Seat belt warning chime does not activate.

- Perform "PRELIMINARY CHECK — Procedure 3" before referring to the following flow chart.



A Step 2

SEAT BELT SWITCH INPUT SIGNAL CHECK
Check continuity between time control module harness terminals ⑳ and ⑮.

Condition	Continuity
Unfastened	Yes
Fastened	No

NG → Check seat belt switch. Check harness continuity between time control module and seat belt switch.

B Step 1

CHIME OUTPUT SIGNAL CHECK
1.) Connect time control module harness connector.
2.) Turn ignition switch "ON".
3.) Measure voltage between control module harness terminals ⑱ and ⑮.

Condition of seat belt	Voltage [V]
Unfastened	Pointer deflects intermittently
Fastened	Approx. 12

OK → Check chime. Check harness continuity between time control module and chime.

TRY A KNOWN GOOD TIME CONTROL MODULE.*

*: Time control module may be the cause of a problem, but this is rarely the case.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TIME CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Rear defogger does not activate, or does not go off after activating.




A

REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK
Measure voltage between time control module harness terminals ⑫ and ⑮.

Condition of defogger switch	Voltage [V]
Defogger switch is "OFF"	Approx. 12
Defogger switch is "ON"	0

OK → Check rear window defogger relay.
Check rear window defogger circuit.



B

REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK
1.) Disconnect time control module harness connector.
2.) Check continuity between time control module harness terminals ③ and ⑮.

Condition of defogger switch	Continuity
Defogger switch is "OFF"	No
Defogger switch is "ON"	Yes

NG → Check rear window defogger switch.
Check harness continuity between time control module and rear window defogger switch.

OK → **TRY A KNOWN GOOD TIME CONTROL MODULE.***

*: Time control module may be the cause of a problem, but this is rarely the case.

System Description

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 11), located in the fuse block)
- to wiper motor terminal ④.

Low and high speed wiper operation

Ground is supplied to wiper switch terminal ⑰ through body grounds (E12) and (E37).

When the wiper switch is placed in the LO position, ground is supplied

- through terminal ⑭ of the wiper switch
- to wiper motor terminal ②.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal ⑯ of the wiper switch
- to wiper motor terminal ③.

With power and ground supplied, the wiper motor operates at high speed.

Auto stop operation

When the wiper switch is placed in the OFF position, the wiper motor will continue to operate until the wiper arms reach the base of the windshield.

When the wiper switch is placed in the OFF position, ground is supplied

- from terminal ⑭ of the wiper switch
- to wiper motor terminal ②, in order to continue wiper motor operation at low speed.

The ground path to terminal ⑭ of the wiper switch is supplied

- through terminal ⑬ of the wiper switch
- to wiper relay terminal ③
- through terminal ④ of the wiper relay
- to wiper motor terminal ⑤
- through terminal ⑥ of the wiper motor, and
- through body grounds (M51), (M76) and (M77).

The ground path is interrupted and the wiper motor stops when the wiper arms reach the base of the windshield.

Intermittent operation

Intermittent operation can be set or variable depending on the model option. The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 1 to 20 seconds. This feature is controlled by the time control module.

When the wiper switch is placed in the INT position, ground is supplied

- to time control module terminal ①
- from wiper switch terminal ⑮
- through body grounds (E12) and (E37).

The desired interval time is input

- to time control module terminal ④
- from wiper switch terminal ⑰.

Based on these two inputs, an intermittent ground is supplied

- to wiper relay terminal ②
- from time control module terminal ⑬.

With power and ground supplied, the wiper relay is activated.

When activated, an intermittent ground is supplied

- to wiper motor terminal ②
- through the wiper switch terminal ⑭
- to wiper switch terminal ⑬
- through wiper relay terminal ③
- to wiper relay terminal ⑤

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WIPER AND WASHER

System Description (Cont'd)

- through body grounds (E12) and (E37).

The wiper motor operates at low speed at the desired time interval.

For further diagnosis, refer to "TIME CONTROL SYSTEM".

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 11, located in the fuse block)
- to washer motor terminal (2).

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal (1), and
- to time control module terminal (2)
- from terminal (18) of the wiper switch
- through terminal (17) of the wiper switch, and
- through body grounds (E12) and (E37).

With power and ground supplied, the washer motor operates.

The wiper motor operates at low speed for approximately 3 seconds to clean the windshield. This feature is controlled by the time control module in the same manner as the intermittent operation.

For further diagnosis, refer to "TIME CONTROL SYSTEM".

WIPER AND WASHER

NOTE

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

WIPER AND WASHER


Front Wiper and Washer/Wiring Diagram – WIPER –

EL-WIPER-01



Refer to last page (Foldout page).



(M7), (E103)
(E3)



WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram – WIPER – (Cont'd)

EL-WIPER-02



Refer to last page (Foldout page).

(M7), (E103)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX



WIPER AND WASHER

Installation


1. Turn ignition ON.
 2. Prior to wiper arm installation, turn on wiper switch and then turn it "OFF". Allow wiper to operate until its Auto Stop position is reached before turning ignition off.
 3. Lift the blade up and then set it down onto glass surface. Set the blade center to clearance "L" just before tightening nut.
 4. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
 5. Ensure that wiper blades stop within clearance "L".
- Tighten windshield wiper arm nuts to specified torque.

Windshield wiper:

21 - 26 N·m (2.1 - 2.7 kg-m, 15 - 20 ft-lb)




- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

System Description

Power is supplied at all times

- from 30A fusible link (Letter **b**), located in the fusible link and fuse box
- to ignition switch terminal **①**.

Power is also supplied

- from 25A fusible link (Letter **g**), located in the fusible link and fuse box
- to circuit breaker terminal **①**
- through circuit breaker terminal **②**
- to ignition relay-2 (SUN ROOF) terminal **⑤**.

With ignition switch in ON or START position, power is supplied

- through ignition switch terminal **③**
- to ignition relay-2 (SUN ROOF) terminal **①**.

Ground is supplied to ignition relay-2 (SUN ROOF) terminal **②**

- through body grounds **(E12)** and **(E37)**.

The ignition relay-2 (SUN ROOF) is energized and power is supplied

- through terminal **③**
- to main power window and door lock switch terminal **②**,
- to power window switch (front RH) terminal **②**,
- to power window switch (rear LH) terminal **②**, and
- to power window switch (rear RH) terminal **②**.

Ground is supplied

- to main power window and door lock switch terminal **⑩**
- through body grounds **(M51)**, **(M76)** and **(M77)**.

MANUAL OPERATION

Front door LH

WINDOW UP

When the main power window switch front LH is pressed in the up position, power is supplied

- to front power window motor LH terminal **①**
- through main power window and door lock switch terminal **⑫**.

Ground is supplied

- to front power window motor LH terminal **②**
- through main power window and door lock switch terminal **⑯**.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the main power window switch front LH is pressed in the down position, power is supplied

- to front power window motor LH terminal **②**
- through main power window and door lock switch terminal **⑯**.

Ground is supplied

- to front power window motor LH terminal **①**
- through main power window and door lock switch terminal **⑫**.

Then, the motor lowers the window until the switch is released.

Except front LH door

FRONT DOOR RH

NOTE:

Figures in parentheses () refer to terminal Nos. arranged in order when the UP or DOWN section of power window switch is pressed.

Operation by main switch

Power is supplied

- through main power window and door lock switch terminal **(⑬, ⑭)**
- to power window switch (front RH) terminal **(③, ①)**.

The subsequent operations are the same as those outlined under "Operation by sub-switches".

Operation by sub-switches

Power is supplied

- through power window switch (front RH) terminal **(⑥, ④)**
- to power window motor (front RH) terminal **(①, ②)**.

POWER WINDOW

System Description (Cont'd)

Ground is supplied

- to front power window motor (front RH) terminal (2, 1)
- through power window switch (front RH) terminal (4, 6)
- to power window switch (front RH) terminal (1, 3)
- through main power window and door lock switch terminal (14, 13)
- to main power window and door lock switch terminal (10)
- through body grounds (M77), (M76), and (M51).

Then, the motor raises or lowers the window until the switch is released.

REAR DOOR LH

NOTE:

Figures in parentheses () refer to terminal Nos. arranged in order when the UP or DOWN section of power window switch is pressed.

Operation by main switch

Power is supplied

- through main power window and door lock switch terminal (1, 6)
- to power window switch (rear LH) terminal (1, 3).

The subsequent operations are the same as those outlined under "Operation by sub-switches".

Operation by sub-switches

Power is supplied

- through power window switch (rear LH) terminal (4, 6)
- to power window motor (rear LH) terminal (1, 2).

Ground is supplied

- to front power window motor (rear LH) terminal (2, 1)
- through power window switch (rear LH) terminal (6, 4)
- to power window switch (rear LH) terminal (3, 1)
- through main power window and door lock switch terminal (6, 1)
- to main power window and door lock switch terminal (10)
- through body grounds (M77), (M76), and (M51).

Then, the motor raises or lowers the window until the switch is released.

REAR DOOR RH

NOTE:

Figures in parentheses () refer to terminal Nos. arranged in order when the UP or DOWN section of power window switch is pressed.

Operation by main switch

Power is supplied

- through main power window and door lock switch terminal (1, 6)
- to power window switch (rear RH) terminal (1, 3).

The subsequent operations are the same as those outlined under "Operation by sub-switches".

Operation by sub-switches

Power is supplied

- through power window switch (rear RH) terminal (4, 6)
- to power window motor (rear RH) terminal (1, 2).

Ground is supplied

- to front power window motor (rear RH) terminal (2, 1)
- through power window switch (rear RH) terminal (6, 4)
- to power window switch (rear RH) terminal (3, 1)
- through main power window and door lock switch terminal (9, 7)
- to main power window and door lock switch terminal (10)
- through body grounds (M77), (M76), and (M51).

Then, the motor raises or lowers the window until the switch is released.

AUTO FEATURE

The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position.

The AUTO feature only operates on the driver's window downward movement.

When the main power window switch (front LH) is pressed and released in the AUTO position, ground signal is supplied

POWER WINDOW

System Description (Cont'd)

- to front power window motor LH terminal ①
- through main power window and door lock switch terminal ⑫.

Power is supplied

- to front power window motor LH terminal ②
- through main power window and door lock switch terminal ⑬.

Then, the front door LH window will travel to the fully open position.


LOCK FEATURE

The power window lock is designed to lock-out window operation to all windows except the front door LH window.


When the lock switch is pressed to lock position, ground of the main power window and door lock switch is disconnected. This prevents the power window motors from operating.

POWER WINDOW


Component Layout



Rear door



Front door



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT



HA

EL

IDX

POWER WINDOW

Wiring Diagram -WINDOW-





Refer to last page (Foldout page).
M7, E103

POWER WINDOW

Wiring Diagram - WINDOW- (Cont'd)

EL-WINDOW-02

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Refer to last page (Foldout page).
M6, B1

POWER WINDOW

Trouble Diagnoses

Symptom	Possible causes	Repair order
None of the power windows can be operated from any switch.	<ol style="list-style-type: none"> 1. 25A and 30A fusible links and (M2) circuit breaker. 2. Grounds (E12), (E37), (M77), (M76), and (M51). 3. Ignition relay-2 (sun roof) 4. Open/short in main power window and door lock switch circuit 	<ol style="list-style-type: none"> 1. Check 25A and 30A fusible links (Let. g and b), located in the fusible link and fuse box) and the (M2) circuit breaker. Turn ignition switch ON and verify battery positive voltage is present at terminal (2) of all power window switches. 2. Check grounds (E12), (E37), (M77), (M76), and (M51). 3. Check ignition relay-2 (sun roof) 4. Check Y/R wire between ignition relay-2 (sun roof) and main power window and door lock switch for open/short circuit.
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> 1. Driver side (front LH) power window motor circuit. 2. Driver side (front LH) power window motor. 	<ol style="list-style-type: none"> 1. Check driver side (front LH) power window motor circuit. 2. Check driver side (front LH) power window motor.
One or more passenger power windows cannot be operated.	<ol style="list-style-type: none"> 1. Power window switches (front RH, rear LH and RH). 2. Power window motors (front RH, rear LH and RH). 3. Main power window and door lock switch 4. Power window circuits. 	<ol style="list-style-type: none"> 1. Check power window switches (front RH, rear LH and RH). 2. Check power window motors (front RH, rear LH and RH). 3. Check main power window and door lock switch. 4. Check wires between main power windows and door lock switch and power window switches and motors for open/short circuits.
One or more passenger power windows cannot be operated by main switch but can be operated by passenger's switches.	Main power window and door lock switch.	Check main power window and door lock switch.

POWER DOOR LOCK

System Description

POWER DOOR LOCK

The door key will not activate the power door lock system. The main power window and door lock switch or door lock switch RH triggers the power door lock actuators.

Power is supplied at all times to door lock terminal ① through:

- 25A fusible link (letter **g** , located in the fusible link and fuse box), and
- circuit breaker.

The door lock timer terminal ⑤ is grounded through body grounds **(M51)** , **(M76)** and **(M77)** .

UNLOCK

When either the main power window and door lock switch or door lock switch RH is pressed to the unlock position:

- door lock timer terminal ② supplies voltage and
- door lock timer terminal ③ supplies ground

All door lock actuators move to the unlock position.


LOCK

When either the main power window and door lock switch or door lock switch RH is pressed to the lock position:

- door lock timer terminal ③ supplies voltage and
- door lock timer terminal ② supplies ground

All door lock actuators move to the lock position.

Circuit Diagram for Quick Pinpoint Check




AEL487

POWER DOOR LOCK

Wiring Diagram -D/LOCK-

EL-D/LOCK-01






Refer to "EL-POWER".

DOOR LOCK TIMER (M22)

Refer to last page (Foldout page).



(M7), (E103)



POWER DOOR LOCK

Wiring Diagram -D/LOCK- (Cont'd)

EL-D/LOCK-02



Refer to last page (Foldout page).


(M6), (B1)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER DOOR LOCK

Door Lock Timer

- Carry out the inspections below.
- (1) Power source and ground: Battery voltage should exist between terminals ① and ⑤.
- (2) Input signals: Continuity should exist between terminals ④, ⑩, and ground in "ON" condition, and should not exist in "OFF" condition.
- (3) Output signals: Voltage shown in the chart should exist.






- Carry out the complete inspection in the chart from left to right.

Door lock timer ① M22 terminal	Connections		Operations		
			Main power window and door lock switch/door lock switch RH		
			N	Unlock	Lock
1	Power source		12V	12V	12V
5	Ground		Ground	Ground	Ground
4	Input signal	Main power window and door lock switch/door lock switch RH (Input signal for lock)	OFF	OFF	ON
10		Main power window and door lock switch/door lock switch RH (Input signal for unlock)	OFF	ON	OFF
2	Output signal	Door lock actuator (Lock power source) VOLT METER 1	0V	0V	12V (Approx. 1.0 sec.) → 0V
3		Door lock actuator (Unlock power source) VOLT METER 2	0V	12V (Approx. 1.0 sec.) → 0V	0V

MIRROR

Wiring Diagram -MIRROR-

EL-MIRROR-01 GI



MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Description

POWER

Power is supplied to the sunroof motor assembly by the sunroof relay when the ignition switch is turned ON. The power circuit is protected by the circuit breaker. The sunroof motor assembly has an independent ground circuit.

TILT AND SLIDE OPERATION

A ground signal is sent to the internal control circuitry of the sunroof motor assembly when the sunroof switches are pressed. The motor is activated by the control circuitry. The motor turns off when the switches are released.

The sunroof will slide open when the OPEN side of the sunroof switch is pressed. It will slide closed when the CLOSE side of the switch is pressed.

The sunroof must be in the closed position for the tilt feature to operate. The rear of the sunroof will tilt up when the UP side of the tilt switch is pressed. The sunroof will return from the up position to the closed position when the DOWN side of the tilt switch is pressed.

The sun shade opens automatically when the sunroof is opened. It must be closed manually.

IF THE SUNROOF DOES NOT CLOSE



The sunroof motor may be manually operated using the wrench supplied in the tool bag (located in the trunk next to the spare tire).

1. Turn the ignition switch OFF.
2. Remove the sunroof switch assembly.
3. Insert the wrench into the sunroof motor shaft and rotate the shaft clockwise to close the sunroof.

SUNROOF

Wiring Diagram -SROOF-

EL-SROOF-01



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT

HA


EL

IDX



HORN, CIGARETTE LIGHTER, CLOCK

Wiring Diagram -HORN-

EL-HORN-01



Refer to last page (Foldout page).



(M7), (E103)
(E3)

REAR WINDOW DEFOGGER

System Description

The rear window defogger system is controlled by the time control module. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal ③
- through 20A fuse (No. ① , located in the fuse block) and
- to rear window defogger relay terminal ⑥
- through 20A fuse (No. ② , located in the fuse block).

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ①.

Ground is supplied to terminal ② of the rear window defogger switch through body grounds M51, M76 and M77.

When the rear window defogger switch is activated, ground is supplied

- through terminal ① of the rear window defogger switch
- to time control module terminal ③.

Terminal ⑫ of the time control module then supplies ground to the rear window defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to condenser terminal ①
- through terminal ② of the condenser
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the combination meter.

Power is supplied

- to terminal ⑳ of the combination meter
- from terminal ⑤ of the rear window defogger relay.

Terminal ⑳ of the combination meter is grounded through body grounds M51, M76 and M77.

For diagnosis, refer to "TIME CONTROL SYSTEM".

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA



EL

IDX

REAR WINDOW DEFOGGER


Wiring Diagram -DEF-

EL-DEF-01




Refer to last page (Foldout page).
 (M6), (B1)

REAR WINDOW DEFOGGER




Filament Check


- When measuring voltage, wrap tin foil around the top of the negative probe. Press the foil against the wire with your finger. Otherwise, the element may be damaged.



- Attach probe circuit tester (in volt range) to middle portion of each filament.



- If a filament is burned out, circuit tester registers 0 or 12 volts.



- To locate burned out point, move probe along filament. Tester needle swings abruptly at the burned point.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

REAR WINDOW DEFOGGER

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth




REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

Audio/System Description

Refer to Owner's Manual for audio system operating instructions.

WITH ACTIVE SPEAKER AUDIO SYSTEM

Power is supplied at all times

- through 10A fuse (No. 20 , located in the fuse block)
- to radio, cassette and CD player terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 15A fuse (No. 9 , located in the fuse block)
- to radio, cassette and CD player terminal 10
- to front speaker amplifier terminal 36, and
- to rear speaker amplifier terminal 18.

Ground is supplied through the case of the radio, cassette, CD player and front and rear speaker amplifiers.

When the system is on, audio signals are supplied

- through radio, cassette and CD player terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 7, 8, 9 and 10 of the rear speaker amplifier and terminals 27, 28, 29 and 30 of the front speaker amplifier.
- to tweeters and the front and rear speakers through terminals 31, 32, 33 and 34 of the front speaker amplifier and terminals 11, 12, 13 and 14 of the rear speaker amplifier.

WITHOUT ACTIVE SPEAKER AUDIO SYSTEM

Power is supplied at all times

- through 10A fuse (No. 20 , located in the fuse block)
- to radio and cassette player terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 9 , located in the fuse block)
- to radio and cassette player terminal 10.

Ground is supplied through the case of the radio and cassette player.

When the system is on, audio signals are supplied

- through radio and cassette player terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the front and rear speakers.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX


AUDIO AND POWER ANTENNA

NOTE

AUDIO AND POWER ANTENNA

Audio/Schematic

WITH ACTIVE SPEAKER AUDIO SYSTEM






GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram -AUDIO-

WITH ACTIVE SPEAKER AUDIO SYSTEM

EL-AUDIO-01




Refer to last page (Foldout page).

(M6) (B1)

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram -AUDIO- (Cont'd)


EL-AUDIO-03



U : For U.S.A.
N : For Canada

Refer to last page (Foldout page).

- M6 B1
- M63
- M64





AUDIO AND POWER ANTENNA

Audio/Wiring Diagram -AUDIO- (Cont'd)

WITHOUT ACTIVE SPEAKER AUDIO SYSTEM

EL-AUDIO-04



Refer to last page (Foldout page).
(M6, B1)

AUDIO AND POWER ANTENNA

Power Antenna/System Description

Power is supplied at all times

- through 10A fuse (No. 20 , located in the fuse block)
- to power antenna terminal ⑥.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A (without active speaker audio system) or 15A (with active speaker audio system) fuse (No. 9 , located in the fuse block)
- to power antenna terminal ①.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 26 , located in the fuse block)
- to power antenna terminal ③.

Ground is supplied to power antenna terminal ② through body ground T7 .

When the radio is turned to the ON position, battery positive voltage is supplied

- through radio terminal ⑤
- to power antenna terminal ④.


The antenna raises and is held in the extended position.

When the radio is turned to the OFF position, battery positive voltage is interrupted

- from radio terminal ⑤
- to power antenna terminal ④.

The antenna retracts.



Location of Antenna



AUDIO AND POWER ANTENNA

Power Antenna/Wiring Diagram -P/ANT-

EL-P/ANT-01



Refer to last page (Foldout page).

M6, B1

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUDIO AND POWER ANTENNA

Trouble Diagnoses

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 10A fuse (without active speaker audio system) 15A fuse (with active speaker audio system) Poor radio case ground Radio 	<ol style="list-style-type: none"> Check 10A (without active speaker audio system) or 15A (with active speaker audio system) fuse (No. 9 , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 10 of radio (and terminal 16 of rear speaker amplifier and terminal 36 of front speaker amplifier with active speakers). Check radio case ground. Remove radio for repair.
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> Radio output Radio 	<ol style="list-style-type: none"> Check radio output voltages. Remove radio for repair.
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 10A fuse Radio 	<ol style="list-style-type: none"> Check 10A fuse (No. 20 , located in fuse block) and verify battery positive voltage is present at terminal 6 of radio. Remove radio for repair.
Rear speakers are inoperative.	<p>WITH ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Rear speaker amplifier 10A fuse Poor rear amplifier case ground Rear speaker amplifier Rear speaker amplifier circuit <p>5. Radio</p> <p>WITHOUT ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Radio output Radio 	<p>WITH ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Check 10A fuse on amplifier Check rear amplifier case ground. Check rear speaker amplifier voltages. Check wires for open or short between radio, rear speaker amplifier and rear speakers. Remove radio for repair. <p>WITHOUT ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Check radio output voltages. Remove radio for repair.
Front speakers are inoperative.	<p>WITH ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Front speaker amplifier 10A fuse Poor front amplifier case ground Front speaker amplifier Front speaker amplifier circuit. <p>5. Radio</p> <p>WITHOUT ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Radio output Radio 	<p>WITH ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Check 10A fuse on amplifier Check front amplifier case ground. Check front speaker amplifier voltages. Check wires for open or short between radio, front speaker amplifier and front speakers. Remove radio for repair. <p>WITHOUT ACTIVE SPEAKER AUDIO SYSTEM</p> <ol style="list-style-type: none"> Check radio output voltages. Remove radio for repair.
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker Radio/amplifier output Speaker circuit Radio 	<ol style="list-style-type: none"> Check speaker. Check radio/amplifier output voltages. Check wires for open or short between radio/amplifier and speaker. Remove radio for repair.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> Antenna Poor radio ground Radio 	<ol style="list-style-type: none"> Check antenna. Check radio ground. Remove radio for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> Window antenna Radio 	<ol style="list-style-type: none"> Check window antenna. Remove radio for repair.
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> Poor radio ground Loose or missing ground bonding straps. Ignition condenser or rear window defogger noise suppressor condenser Generator Ignition coil or secondary wiring Radio 	<ol style="list-style-type: none"> Check radio ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check generator. Check ignition coil and secondary wiring. Remove radio for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> Poor radio ground Antenna Accessory ground Faulty accessory 	<ol style="list-style-type: none"> Check radio ground. Check antenna. Check accessory ground. Replace accessory.

AUDIO AND POWER ANTENNA

Trouble Diagnoses (Cont'd)

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. 10A fuse 3. 10A fuse (without active speaker audio system) 15A fuse (with active speaker audio system) 4. Radio signal 5. Poor power antenna ground 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 20 , located in fuse block). Verify battery positive voltage is present at terminal ⑥ of power antenna. 2. Check 10A fuse (No. 26 , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ③ of power antenna. 3. Check 10A (without active speaker audio system) or 15A (with active speaker audio system) fuse (No. 9 , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ① of power antenna. 4. Turn radio ON and verify battery positive voltage is present at terminal ④ of power antenna. 5. Check power antenna ground.

SPEAKER INSPECTION

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ②.
 - The resistance should be 2-4 Ω
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ②.
 - A momentary hum or pop should be heard

ANTENNA INSPECTION

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
 - If reception improves, check antenna ground (at body surface)
 - If reception does not improve, check main feeder cable for short circuit or open circuit.

RADIO AND AMPLIFIER INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and amplifiers connected (If either is removed for inspection, supply a ground to the case using a jumper wire.)


RADIO VOLTAGES

Terminal	Voltage (V)	
	Without Active Speaker Audio System	With Active Speaker Audio System
1	5 - 7.5	2.5 - 6.5
2	5 - 7.5	2.5 - 6.5
3	5 - 7.5	2.5 - 6.5
4	5 - 7.5	2.5 - 6.5
5	10 - 15 (0 when tape is playing)	9 - 15 (0 when tape is playing)
6	10.8 - 15.6	10.8 - 15.6
7	—	—
8	—	—
9	0	0
10	10.8 - 15.6	10.8 - 15.6
11	—	0
12	—	19 - 15
13	5 - 7.5	2.5 - 6.5
14	5 - 7.5	2.5 - 6.5
15	5 - 7.5	2.5 - 6.5
16	5 - 7.5	2.5 - 6.5

AMPLIFIER VOLTAGES

Terminal		Voltages (V)
Front Amplifier	Rear Amplifier	
27	7	2.5 - 6.5
28	8	2.5 - 6.5
29	9	2.5 - 6.5
30	10	2.5 - 6.5
31	11	4.5 - 8.5
32	12	4.5 - 8.5
33	13	4.5 - 8.5
34	14	4.5 - 8.5
35	15	0
36	16	10.8 - 15.6
37	17	—
38	18	9 - 15


AUDIO AND POWER ANTENNA



Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.



INSTALLATION

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.

Window Antenna Repair

ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT


HA

EL


IDX



2. If an element is broken, no continuity will exist.



3. To locate a burned out point, move probe along filament. Tester needle swings abruptly at the burned point.



ELEMENT REPAIR

Refer to "Filament Repair", "REAR WINDOW DEFOGGER", (EL-126).

System Description

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse (No. 26 , located in the fuse block)
- to ASCD main switch terminal ① and
- to ASCD hold relay terminal ⑤.

When ASCD main switch is in the ON position, power is supplied

- from terminal ② of the ASCD main switch
- to ASCD control module terminal ④ and
- from terminal ③ of the ASCD main switch
- to ASCD hold relay terminal ①.

Ground is supplied

- to ASCD hold relay terminal ②
- through body grounds E12 and E37.

With power and ground supplied, the ASCD hold relay is activated, and power is supplied

- from terminal ③ of the ASCD hold relay
- to ASCD control module terminal ④ and
- to ASCD clutch pedal position switch terminal ① (M/T models) or
- to inhibitor relay terminal ③ (A/T models).

Power remains supplied to ASCD control module terminal ④ when the ASCD main switch is released to the N (neutral) position.

Ground is supplied

- to ASCD control module terminal ③
- through body grounds M51, M76 and M77.

Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- inhibitor relay (A/T models)
- ASCD clutch pedal position switch (M/T models)
- ASCD cancel switch.

A vehicle speed input is supplied

- to ASCD control module terminal ⑦
- from terminal ⑤ of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal ①
- through 15A fuse (No. 18 , located in the fuse block).

When the brake pedal is depressed, power is supplied

- from terminal ② of the stop lamp switch
- to ASCD control module terminal ⑪.

Power is supplied at all times

- through 10A fuse (No. 35 , located in the fusible link and fuse box)
- to horn relay terminal ①
- through terminal ③ of the horn relay
- to ASCD steering switch terminal ⑫.

When the SET/COAST button is depressed, power is supplied

- from terminal ⑭ of the ASCD steering switch
- to ASCD control module terminal ②.

When the RESUME/ACCEL button is depressed, power is supplied

- from terminal ⑬ of the ASCD steering switch
- to ASCD control module terminal ①.

When the CANCEL button is depressed, power is supplied

- to ASCD control module terminals ① and ②.

When the system is activated, power is supplied

- to ASCD control module terminal ⑤.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

Power is interrupted when

- the shift lever is placed in P or N (A/T models)
- the clutch pedal is depressed (M/T models) or
- the brake pedal is depressed.

GI

Outputs

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control module. The ASCD actuator consists of a vacuum motor, an air valve, and a release valve.

MA

Power is supplied

- from terminal ⑧ of the ASCD control module
- to ASCD actuator terminal ①.

EM

Ground is supplied to the vacuum motor

- from terminal ⑨ of the ASCD control module
- to ASCD actuator terminal ④.

LC

Ground is supplied to the air valve

- from terminal ⑩ of the ASCD control module
- to ASCD actuator terminal ②.

EC

Ground is supplied to the release valve

- from terminal ⑭ of the ASCD control module
- to ASCD actuator terminal ③.

FE

When the system is activated, power is supplied

- from terminal ⑬ of the ASCD control module
- to combination meter terminal ⑳ and
- to A/T control unit terminal ⑶⑦ (A/T models).

CL

Ground is supplied

- to combination meter terminal ⑳⑦
- through body grounds ⑴⑤①, ⑴⑦⑥ and ⑴⑦⑦.

MT

With power and ground supplied, the CRUISE indicator illuminates.

AT

When the RESUME/ACCEL button is depressed on A/T models, a signal is sent

- from terminal ⑫ of the ASCD control module
- to A/T control unit terminal ⑴④.

FA

When this occurs, the A/T control unit cancels overdrive.

RA

BR

ST

RS

BT



HA

EL

IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic





GI
 MA
 EM
 LG
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD-

EL-ASCD-01




Refer to last page (Foldout page).
 (M7), (E103)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-02




(A) : A/T models
(M) : M/T models

Preceding page

Preceding page

Preceding page

Refer to last page (Foldout page).




(M7), (E103), (E3)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-03



Refer to last page (Foldout page).



(M7) (E103)
(E3)



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-04




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-05



Refer to last page (Foldout page).
 (M7) (E103)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE	Diagnostic Procedure								—	Electrical Components Inspection						
	EL-150	EL-152	EL-152	EL-152	EL-153	EL-154	EL-155	EL-156		EL-157	EL-158	EL-159	EL-159	EL-159	EL-159	EL-159
REFERENCE PAGE	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	ASCD Wire Adjustment	ASCD actuator/ASCD pump	ASCD main switch	ASCD steering switch	ASCD cancel switch and stop lamp switch	Clutch pedal position switch (M/T models)	Inhibitor switch (A/T models)	Vehicle speed sensor
SYMPTOM																
ASCD control module cannot be set properly.	○									○	○	○	○	○	○	○
Engine hunts.		○							○	○						
Large difference between set speed and actual vehicle speed.			○						○	○						
Deceleration is greatest immediately after ASCD has been set.				○					○	○						
ACCEL switch will not operate.	○				○							○				
RESUME switch will not operate.	○					○						○	○	○		
Set speed cannot be cancelled.							○		○	○			○	○		
"CRUISE" indicator lamp blinks.								○		○		○	○			




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: ASCD control cannot be set.



Turn ASCD main switch "OFF" and "ON" to make sure indicator illuminates.

A CHECK POWER SUPPLY FOR ASCD MAIN SWITCH.

1. Disconnect switch harness connector.
2. Do approx. 12 volts exist between switch harness terminal ① and body ground?

No → Check fuse and harness.

Yes → CHECK ASCD MAIN SWITCH. Refer to EL-159. CHECK ASCD HOLD RELAY.

OK →

B CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL MODULE.

1. Turn ASCD main switch "ON".
2. Check voltage between ASCD control module harness terminals ④ and ③.

Battery positive voltage should exist.

NG → Check continuity between ASCD control module harness terminal ④ and ASCD hold relay.

OK →

C CHECK CUT-OFF CIRCUIT FOR ASCD CONTROL MODULE.

Check voltage between ASCD control module harness terminals ⑤ and ③.

Battery positive voltage should exist.








NG → CHECK ASCD CANCEL SWITCH, ASCD CLUTCH PEDAL POSITION SWITCH (M/T models) AND INHIBITOR SWITCH (A/T models). Refer to EL-159. CHECK INHIBITOR RELAY (A/T models).

OK →

Ⓐ (Next page)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



Replace ASCD control module.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 2

SYMPTOM: Engine hunts.




DIAGNOSTIC PROCEDURE 3

SYMPTOM: Large difference between set vehicle speed and actual speed.



DIAGNOSTIC PROCEDURE 4

SYMPTOM: Deceleration is greatest immediately after ASCD has been set.






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: ACCEL switch will not operate.



Check constant-speed function for operating using SET/COAST switch.

NG

Perform "DIAGNOSTIC PROCEDURE 1". Refer to EL-150.

OK

A

Check voltage between ASCD control module harness terminals ① and ③ after turning on and holding RESUME/ACCEL switch. **Battery positive voltage should exist.**

NG

CHECK ASCD STEERING SWITCH. Refer to EL-159.

OK

B

Check voltage between ASCD control module harness terminals ① and ③ after releasing RESUME/ACCEL switch. **Voltage is 0V.**

NG

CHECK ASCD STEERING SWITCH. Refer to EL-159.

OK

C

Does vehicle accelerate when RESUME/ACCEL switch is turned on?

No

Replace ASCD control module.

Yes

Does vehicle maintain the new (faster) speed when RESUME/ACCEL switch is released?

No

Replace ASCD control module.

Yes

System is O.K.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL







IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: RESUME switch will not operate.





AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7




SYMPTOM: Set speed cannot be cancelled.



Conditions		Voltage [V]
M/T	ASCD cancel switch	Depressed: 0 Released: Approx. 12
	ASCD clutch pedal position switch	Depressed: 0 Released: Approx. 12
A/T	A/T shift lever position is at any position except N or P.	Approx. 12
	A/T shift lever position is at N or P.	0



Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0





GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 8

SYMPTOM: "CRUISE" indicator lamp blinks.



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd) ASCD WIRE ADJUSTMENT



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not overly tighten ASCD wire during adjustment.

Confirm that accelerator wire is properly adjusted.

- For accelerator cable adjustment, refer to FE section ("Adjusting Accelerator Cable", "ACCELERATOR CONTROL SYSTEM").

Adjust the ASCD wire as follows.

1. Loosen lock nut and tighten adjusting nut until throttle drum starts to move.
2. From that position turn back adjusting nut 0.5 to 1 turn, and secure lock nut.

(This prevents a delay in the operation of the ASCD.)

- For ASCD cancel switch adjustment, refer to BR and CL sections ("Adjustment", "BRAKE PEDAL AND BRACKET" and "Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT", respectively).

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION


ASCD actuator/ASCD pump

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.



AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)



ASCD main switch

Check continuity between terminals by pushing switch to each position.


Switch position	Terminal					
	1	2	3	4	5	6
ON	○	○	○	○		
N		○	○	○	ILL. ○	
OFF						



ASCD steering switch

Check continuity between terminals by pushing each button.


Button	Terminal		
	3	5	4
SET/COAST	○	○	
RESUME/ACCEL	○		○
CANCEL	○	▶	○
	○	▶	○



ASCD cancel switch and stop lamp switch

Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No


Check each switch after adjusting brake pedal — refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").



ASCD clutch pedal position switch (For M/T models)

Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

Check switch after adjusting clutch pedal — refer to CL section ("Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT").



Inhibitor switch (For A/T models)


Shift lever position	Terminal		
	3	4	6
"P"	○	○	
"N"	○		○
Except "N" or "P"			

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Vehicle speed sensor

- 1 Remove vehicle speed sensor from transaxle.
- 2 Turn vehicle speed sensor pinion quickly and measure voltage across ② and ①.



THEFT WARNING SYSTEM

System Description

Refer to Owner's Manual for theft warning system operating instructions.

Power is supplied at all times

- through 30A fusible link (letter **B** , located in the fusible link and fuse box)
- to ignition switch terminal **1**.

With the ignition switch in the START position, power is supplied

- from terminal **5** of the ignition switch
- to clutch interlock relay terminal **3** (M/T models) or
- to theft warning relay-1 terminal **3** (A/T models).

With the ignition switch in the START position, power is supplied

- from terminal **6** of the ignition switch (M/T models)
- through 10A fuse (No. **16** , located in the fuse block)
- to theft warning relay-1 terminal **3**.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **26** , located in the fuse block)
- to theft warning relay-1 terminal **1**.

Power is supplied at all times

- through 10A fuse (No. **20** , located in the fuse block)
- to theft warning control module terminal **1** and
- to combination meter terminal **32**.

Power is supplied at all times

- through 10A fuse (No. **17** , located in the fuse block)
- to trunk room lamp switch terminal **1**.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. **12** , located in the fuse block)
- to theft warning control module terminal **3**.

Ground is supplied

- to theft warning control module terminal **16**
- through body grounds **M51**, **M76** and **M77**.

THEFT WARNING SYSTEM ACTIVATION (Without key used to lock front doors)

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, the key must be removed from the ignition switch and the theft warning control module must receive signals indicating the doors, hood and trunk are closed and the doors are locked.

When a door is open, theft warning control module terminal **5** receives a ground signal from each door switch.

When a door is unlocked, theft warning control module terminal **9** receives a ground signal

- from terminal **2** of the door unlock sensor
- through body grounds **M51**, **M76** and **M77** for the front doors and
- through body grounds **B6** and **B14** for the rear doors.

When the hood is open, theft warning control module terminal **15** receives a ground signal

- from terminal **1** of the hood switch
- through body grounds **E12** and **E37**.

When the trunk lid is open, theft warning control module terminal **14** receives a ground signal

- from terminal **1** of the trunk room lamp switch
- through body ground **T7**.

If none of the described conditions exist, the theft warning system will activate automatically.

THEFT WARNING SYSTEM ACTIVATION (With key used to lock doors)

If the rear doors are locked and the key is used to lock either front door, theft warning control module terminal **7** receives a ground signal

- from terminal **1** of the front LH or RH key cylinder switch
- through body grounds **M51**, **M76** and **M77**.

If this signal is received by the theft warning control module, the theft warning system will activate automatically.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

THEFT WARNING SYSTEM

System Description (Cont'd)

Once the theft warning system has been activated, theft warning control module terminal ② supplies ground to combination meter terminal ③⑨ for the security lamp.
The security lamp will illuminate for approximately 30 seconds and then go out.

THEFT WARNING SYSTEM OPERATION

The theft warning system is triggered by

- opening a door or the trunk lid without using the key
- opening the hood
- tampering with the key cylinder in the door or trunk lid.

Once the theft warning system has been activated, if the theft warning control module receives a ground signal at terminal ⑤, terminal ⑭ or terminal ⑮ (as described under THEFT WARNING SYSTEM ACTIVATION), the theft warning system will be triggered. Also, when one of the following signals is received at the theft warning control module, the system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

When a door key cylinder switch has been tampered with, theft warning control module terminal ⑥ receives a ground signal

- from terminal ③ of the front LH or RH key cylinder switch
- through body grounds M51, M76 and M77.

When the trunk key cylinder switch has been tampered with, theft warning control module terminal ⑥ receives a ground signal

- from terminal ② of the trunk key cylinder switch
- through body ground T7.

If the theft warning system is triggered, ground is supplied

- from terminal ④ of the theft warning control module
- to theft warning relay-1 terminal ②.

With power and ground supplied, power to the clutch interlock relay (M/T models) or inhibitor switch (A/T models) is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 10A fuse (No. ③⑤), located in fusible link and fuse box
- to theft warning relay-2 terminals ① and ③, and
- to theft warning relay-3 terminal ①.

Power is supplied at all times

- through 15A fuse (No. ③⑦), located in fusible link and fuse box
- to theft warning relay-3 terminal ⑥.

Power is supplied at all times

- through 15A fuse (No. ③⑥), located in the fusible link and fuse box
- to theft warning relay-3 terminal ③.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ⑫ of the theft warning control module
- to theft warning relay-2 terminal ② and
- to theft warning relay-3 terminal ②.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key.



When the key is used to unlock a door, theft warning control module terminal ⑪ receives a ground signal from terminal ② of the front LH or RH key cylinder switch.

When the key is used to unlock the trunk lid, theft warning control module terminal ⑩ receives a ground signal from terminal ① of the trunk key cylinder switch.

When the theft warning control module receives either one of these signals, the theft warning system is deactivated.

THEFT WARNING SYSTEM


Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM


Circuit Diagram for Quick Pinpoint Check



AEL312

THEFT WARNING SYSTEM

Circuit Diagram for Quick Pinpoint Check (Cont'd)





GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Wiring Diagram -THEFT-

EL-THEFT-01





Refer to last page (Foldout page).

(M6), (B1)

THEFT WARNING SYSTEM

Wiring Diagram - THEFT- (Cont'd)

EL-THEFT-02





Refer to last page (Foldout page).
 M6, B1

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX


THEFT WARNING SYSTEM

Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-03






Refer to last page (Foldout page).



THEFT WARNING SYSTEM

Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-04




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

THEFT WARNING SYSTEM

Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-05



Refer to last page (Foldout page).



M7 . E103



THEFT WARNING SYSTEM

Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-06




Refer to last page (Foldout page).
 (M7) (E103)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

THEFT WARNING SYSTEM


Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-07



Refer to last page (Foldout page).

- (M7) (E103)
- (E3)




THEFT WARNING SYSTEM

Trouble Diagnoses

SYSTEM OPERATION CHECK

If ignition switch is set in the "ACC" position in the step of START to ARMED or in the ARMED state shown in this flow chart, the system operation is canceled.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply circuit check



Terminals	Ignition switch position		
	OFF	ACC	ON
① - ⑫	Battery positive voltage	Battery positive voltage	Battery positive voltage

GI
MA
EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA


EL

IDX



Power supply circuit check for system cancel

Terminals	Ignition switch position		
	OFF	ACC	ON
③ - ⑫	0V	Battery positive voltage	Battery positive voltage



Ground circuit check

Terminals	Continuity
⑫ - Ground	Yes




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: • Indicator lamp does not blink.
• Indicator lamp remains blinking.



Diagnostic procedure 1-(1)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(2)



A

HOOD SWITCH INPUT SIGNAL CHECK
Check continuity between theft warning control module harness terminals (15) and (16).

Condition	Continuity
Hood is open	Yes
Hood is closed	No

OK → Perform Diagnostic Procedure 2. Refer to EL-180.

NG → Check hood switch and hood fitting condition.

NG → Adjust installation of hood switch or hood.

OK → **HOOD SWITCH CHECK**
Refer to EL-187.

NG → Replace hood switch.

B

HOOD SWITCH CIRCUIT CHECK

- Check harness continuity between theft warning control module harness terminal (15) and hood switch harness terminal (1).
- Check harness continuity between hood switch terminal (2) and body ground.

Continuity should exist.

NG → Repair harness or connectors.



OK → **CHECK THE CONNECTIONS AT EACH CONNECTOR.**

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(3)



A

TRUNK ROOM LAMP SWITCH INPUT SIGNAL CHECK
Check voltage between theft warning control module harness terminals ⑭ and ⑯.

Condition	Voltage
Trunk lid is open	Approx. 0V
Trunk lid is closed	Approx. 12V

OK → Perform Diagnostic Procedure 2. Refer to EL-180.

NG

Does trunk room lamp come on?

Yes → TRUNK ROOM LAMP SWITCH CIRCUIT CHECK
Check harness continuity between theft warning control module harness terminal ⑭ and trunk room lamp harness terminal ①.

No → TRUNK ROOM LAMP SWITCH CHECK
Refer to EL-187.

B

TRUNK ROOM LAMP SWITCH CIRCUIT CHECK
Check harness continuity between theft warning control module harness terminal ⑭ and trunk room lamp harness terminal ①.

OK →




NG → Replace trunk room lamp switch.

OK → CHECK THE CONNECTIONS AT EACH CONNECTORS.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)






GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Indicator lamp does not blink.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Indicator lamp does not come on.



A

DOOR UNLOCK SENSOR INPUT SIGNAL CHECK
Check continuity between theft warning control module harness terminals ⑨ and ⑯.

Condition	Continuity
Driver's door	
Locked	No
Unlocked	Yes
Except driver's door	
All locked	No
At least one is unlocked	Yes

OK → Perform Diagnostic Procedure 4. Refer to EL-182.


OK → Replace theft warning control module.

NG

DOOR UNLOCK SENSOR CHECK
Refer to EL-188.

NG → Replace door lock actuator.

OK



B

DOOR UNLOCK SENSOR CIRCUIT CHECK

- Check harness continuity between theft warning control module harness terminal ⑨ and door lock actuator terminal ②.
- Check harness continuity between door lock actuator terminal ① and body ground.

Continuity should exist.

NG → Repair harness or connectors.

OK → CHECK THE CONNECTIONS AT EACH CONNECTOR.











GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Indicator lamp does not come on.







THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Alarm does not operate.




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: STARTER MOTOR can be operated. (Starter killed phase)



STARTER MOTOR KILL OUTPUT SIGNAL CHECK
Turn ignition switch to "ON" or "START" position. Check voltage between theft warning control module harness terminals ④ and ⑯.

Approx. 12V

Replace theft warning control module.

Approx. 0V

Check theft warning relay-1 and circuit.

NG

Replace theft warning relay-1.

OK




Repair harness between theft warning control module and clutch interlock relay (M/T models) or inhibitor switch (A/T models).

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Alarm does not stop even if stop signal is given.






GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: Alarm does not stop even if stop signal is given.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches

Check continuity between terminal ①, ② and switch body.



Terminal	Pushed	Released
1, 2		○
switch body		○

GI

MA

EM

LC

EC


FE

CL

MT

Hood switch

Check continuity between terminals when hood switch is pushed and released.




Terminal	Pushed	Released
1		○
2		○

AT

FA

RA

Trunk room lamp switch



Terminal	Trunk lid	
	Closed	Open
1		○
2		○

BR

ST

RS

BT

HA

EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



Key cylinder switch

Door

	TAMPER SWITCH		DOOR LOCK SWITCH		DOOR UNLOCK SWITCH		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral	Between full stroke and neutral	Full stroke
1				○			
2						○	
3		○		○			
4		○		○		○	


Trunk

	TAMPER SWITCH		Trunk lid unlock switch		
	Key cylinder is installed	Key cylinder is removed	Full stroke	Between full stroke and neutral	Neutral
1				○	
2		○		○	
3		○		○	



Indicator lamp (security lamp)

Check if it lights when 12V is supplied.







Door unlock sensor

	LOCK	UNLOCK
1		○
2		○

LOCATION OF ELECTRICAL UNITS


Engine Compartment



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


LOCATION OF ELECTRICAL UNITS

Passenger Compartment



HARNESS LAYOUT

Outline



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Engine Room Harness (Engine Compartment)
- Main Harness
- Body Harness

The grid reference is placed on the page where connectors are listed in number order.

To the left of the connector number code there is a grid reference.

Example:

G2 (E1): ASCD actuator

└ grid reference

To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

The approximate on-vehicle location of the connector has been found.

RA
BR
ST
RS
BT
HA


EL

IDX

HARNESS LAYOUT

ENGINE COMPARTMENT

Engine Room Harness



HARNESS LAYOUT

Engine Room Harness (Cont'd)

Engine room harness

G2 (E1) : ASCD actuator	E5 (E28) : Front turn signal lamp LH
F2 (E2) : Brake fluid level switch	D4 (E24) : Headlamp LH
F3*(E3) : Joint connectors 3-6	D4 (E25) : Clearance and cornering lamp LH
G3 (E4) : Actuator (For ABS)	E4 (E26) : Clearance lamp LH
F4 (E5) : Actuator (For ABS)	C3 (E27) : Horn
F3 (E6) : Actuator (For ABS)	C4 (E28) : Ambient sensor
F2 (E7) : Body ground (For ABS)	A2 (E29) : Clearance lamp RH
E3 (E8) : Front sensor LH (For ABS)	A3 (E30) : Clearance and cornering lamp RH
F3*(E9) : Dropping resistor (A/T models)	A3 (E31) : Headlamp RH
F3 (E10) : Hood switch (For theft warning system)	A3 (E32) : Front turn signal lamp RH
E2 (E11) : Battery	B3 (E33) : Front fog lamp RH (For standard fog lamp models)
F4*(E12) : Body ground	A3 (E34) : Front side marker RH
E3 (E13) : Fusible link and fuse box	C3 (E35) : Compressor
D3*(E14) : Relay box-2	B3 (E36) : Front fog lamp sub-harness (For optional fog lamp models)
E3*(E15) : To (E213)	B2*(E37) : Body ground
E3*(E16) : To (E214)	B2 (E38) : Washer level switch (For Canada)
E3 (E17) : To (E215)	B2 (E39) : Washer motor
E4 (E18) : Air conditioning triple-pressure switch	C2*(E40) : Relay box-1
E4*(E19) : Cooling fan motor-1	C2 (E41) : Body ground
C3*(E20) : Cooling fan motor-2	C2 (E42) : Generator
F4 (E21) : Front side marker lamp LH	D2 (E43) : Generator
E5 (E22) : Front fog lamp LH (For standard fog lamp models)	D2 (E44) : Generator


* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS LAYOUT

Engine Room Harness (Cont'd)

PASSENGER COMPARTMENT



HARNES LAYOUT

NOTE

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

HARNESS LAYOUT

Main Harness



AEL835

SMA95-081 | '95 ALTIMA | July 1994 (03) | SM5E-0U13U0

➔ Arrow Indicates Amended Information

EL-196


HARNESS LAYOUT

Main Harness (Cont'd)

Main harness

- B5 (M1) : Theft warning control module (For theft warning system)
- B4 (M2) : Circuit breaker
- A2 (M4) : To (E109)
- A2 (M5) : To (E107)
- A4* (M6) : To (E1) (SMU)
- A4* (M7) : To (E109) (SMU)
- A3 (M8) : To (D1)
- A3 (M9) : To (D2)
- A3 (M10) : To (D3)
- B4 (M11) : Fuse block
- B4 (M12) : Rear window defogger relay
- B3 (M13) : Clutch pedal position switch (M/T models for USA)
- B3 (M14) : ASCD clutch pedal position switch (M/T models)
- A5 (M15) : Data link connector for CONSULT
- B2 (M16) : To (R1)
- B2 (M17) : ASCD switch
- B3 (M18) : Mirror switch
- C4 (M19) : Illumination control switch
- C4 (M20) : ASCD control module
- A2 (M21) : Shift lock control module (A/T models)
- C4 (M22) : Door lock timer
- B2 (M23) : ASCD cancel switch
- C2 (M24) : Stop lamp switch
- E1 (M25) : Hazard switch
- D1 (M26) : Auto air conditioning unit
- E2 (M27) : Auto air conditioning unit
- D1 (M28) : Push control module
- E3 (M29) : Push control module
- E1 (M30) : Air conditioning switch
- E2 (M31) : Potentio temperature control
- D1 (M32) : Fan switch
- D1 (M33) : Clock (With active speaker audio system)
- D4 (M34) : Combination flasher unit
- D4 (M35) : Air mix door motor
- D4 (M36) : Mode door motor
- D4 (M37) : Time control module
- C1 (M38) : Rear window defogger switch
- C1 (M39) : In-vehicle sensor
- C3* (M41) : Combination meter
- C3* (M42) : Combination meter
- C3 (M43) : Combination meter
- C1 (M44) : Combination meter
- E3 (M47) : Radio
- E3 (M48) : Radio
- D4* (M49) : To (F23)
- E4* (M50) : To (F24)
- C2 (M51) : Body Ground
- E4 (M53) : Cigarette lighter
- E4 (M54) : Ashtray illumination
- E2 (M55) : Blower HI-relay
- F3 (M56) : Thermo control amp.
- F3 (M57) : Glove box lamp
- F3 (M58) : Fresh vent door motor
- D4 (M59) : To (F21)
- D4 (M60) : To (F22)
- E1 (M63) : Joint connector-7 (With audio amp. for USA)
- F1 (M64) : Joint connector-8 (With audio amp. for Canada)
- F1 (M65) : Joint connector-9 (With audio amp. for Canada)
- D2 (M66) : To (A4)
- F2 (M67) : Fan control amp.
- F2 (M68) : Glove box lamp switch
- E2 (M69) : Intake door motor
- E1 (M70) : Sunload sensor
- F1 (M73) : Tweeter RH
- G2 (M74) : To (G61)
- G2 (M75) : To (G62)
- G2 (M76) : Body ground
- G3 (M77) : Body ground
- F3 (M78) : Fan resistor
- G2 (M79) : Blower motor
- G3 (M80) : Daytime light control module (For Canada)
- G3* (M81) : A/T control unit
- B3 (M106) : To (G31)
- B4 (M107) : Data link connector for GST
- E4 (M108) : Shift lock solenoid, park position switch and A/T illumination (A/T models)
- Engine Compartment
- F5 (M111) : Power steering oil pressure switch
- F5 (M112) : Front sensor RH (For ABS)
- D5 (M113) : Body ground (For ABS)
- G5 (M114) : Wiper motor
- F5 (M115) : Horn (For theft warning system)

Diode (In joint connector-8 (M64)
In joint connector-9 (M65))




* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.



HARNESSES LAYOUT

Body Harness



AEL505

HARNES LAYOUT

Body Harness (Cont'd)


- | | |
|--|--|
| <p>B3 * (B1) : To (M6) (SMUJ)</p> <p>B4 (B3) : Front door switch LH (Driver's side)</p> <p>C3 (B6) : Body ground</p> <p>B3 (B7) : To (B101)</p> <p>C3 (B8) : Seat belt switch</p> <p>C3 (B11) : Parking brake switch</p> <p>D3 (B13) : Front door switch RH (Passenger side)</p> <p>E2 (B14) : Body ground</p> <p>E2 (B15) : To (B15)</p> <p>E3 (B18) : To (B10)</p> <p>E4 (B19) : Fuel pump</p> <p>E4 (B20) : Fuel tank gauge unit</p> <p>D2 (B21) : Rear window defogger condenser</p> | <p>D3 (B22) : Rear door switch LH</p> <p>D3 (B23) : To (T1)</p> <p>F3 (B24) : Trunk room lamp</p> <p>B3 (B25) : Rear speaker LH</p> <p>C3 (B26) : Front speaker amp.</p> <p>E3 (B27) : Rear speaker amp.</p> <p>E3 (B28) : High-mounted stop lamp (Without rear air spoiler)</p> <p>E3 (B29) : Rear-speaker RH</p> <p>F3 (B30) : Rear door switch RH</p> <p>B3 (B31) : To (M106)</p> <p>C3 * (B32) : Rear heated oxygen sensor</p> <p>E3 (B107) : To (B18)</p> <p>E4 (B102) : Rear sensor LH (For ABS)</p> <p>F4 (B103) : Rear sensor RH (For ABS)</p> |
|--|--|

* : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS LAYOUT

Engine Control Harness



HARNES LAYOUT

Engine Control Harness (Cont'd)

AEL508

Engine control harness

- * (F1) : Front oxygen sensor
- * (F2) : Camshaft position sensor
- * (F3) : Mass air flow sensor
- * (F4) : Power transistor
- * (F5) : Revolution sensor (A/T models)
- * (F6) : To terminal cord assembly (A/T models)
- * (F7) : Ignition coil
- * (F8) : Throttle position switch (A/T models)
- * (F10) : Throttle position sensor
- * (F11) : EGR temperature sensor
- * (F12) : EGR control-solenoid valve
- (F13) : Injector No. 1
- (F14) : Injector No. 2
- (F15) : Injector No. 3
- (F16) : Injector No. 4
- (F17) : Engine ground
- * (F18) : To (E206)
- * (F19) : ECM (ECCS control module)
- * (F20) : ECCS relay
- * (F21) : To (M59)
- * (F22) : To (M50)
- * (F23) : To (M49)
- * (F24) : To (M50)
- * (F25) : Crankshaft position sensor (OBD)
- * (F26) : Intake air temperature sensor
- * (F27) : Resistor
- (F28) : Condenser

* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

HARNES LAYOUT

Engine Harness No. 2



Engine harness No. 2


- E201 : Thermal transmitter
- * E202 : Engine coolant temperature sensor
- * E203 : IAC valve-FICD solenoid valve & IAC valve-AAC valve
- E204 : Oil pressure switch
- * E205 : To (F16)
- * E206 : To knock sensor
- E207 : Starter motor
- E208 : Starter motor
- * E209 : Vehicle speed sensor
- * E210 : Position switch (M/T models)
- * E211 : Inhibitor switch (A/T models)
- * E212 : Inhibitor switch (A/T models)
- * E213 : To (E15)
- * E214 : To (E16)
- E215 : To (E17)
- E216 : Battery

* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

AEL509

HARNESS LAYOUT

Room Lamp Harness



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX


HARNES LAYOUT

Air Bag Harness



HARNESS LAYOUT

Tail Harness




- (T1) : To (823)
- (T2) : Rear side marker lamp LH
- (T3) : Rear side marker lamp RH
- (T4) : Rear combination lamp LH
- (T5) : License lamp LH
- (T6) : License lamp RH
- (T7) : Body ground
- (T8) : Trunk key cylinder switch
- (T9) : Trunk room lamp switch
- (T10) : Rear combination lamp RH
- (T11) : Rear side marker lamp RH
- (T12) : Power antenna
- (T13) : High-mounted stop lamp (With rear air spoiler)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


HARNESS LAYOUT

FRONT

Door Harness (LH side)




REAR



HARNES LAYOUT

FRONT

Door Harness (RH side)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

REAR

