

HEATER AND AIR CONDITIONING

SECTION HA

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONTENTS

MANUAL AND AUTO

PRECAUTIONS AND PREPARATION	2
Precautions for Supplemental Restraint System "AIR BAG".....	2
Special Service Tools.....	6
R-134a Service Tools and Equipment.....	7
Precautions for Service Equipment.....	9

MANUAL

DESCRIPTION	11
Component Layout.....	12
Discharge Air Flow.....	13
Control Operation.....	14
TROUBLE DIAGNOSES	15
How to Perform Trouble Diagnoses for Quick and Accurate Repair.....	15
Work Flow.....	15
Operational Check.....	16
Conditions:.....	16
Procedure:.....	16
1. Check blower.....	16
2. Check discharge air.....	16
3. Check recirculation.....	17
4. Check temperature decrease.....	17
5. Check temperature increase.....	17
6. Check air conditioning switch.....	17
Symptom Chart.....	18
Diagnostic Table.....	18
Preliminary Check.....	20
Preliminary Check 1.....	20
Preliminary Check 2.....	21
Preliminary Check 3.....	22
Preliminary Check 4.....	23
Preliminary Check 5.....	24
Preliminary Check 6.....	25
Performance Test Diagnoses.....	26

Insufficient Cooling.....	26
Performance Chart.....	28
Test Condition.....	28
Test Reading.....	28
Trouble Diagnoses for Abnormal Pressure.....	29
Harness Layout.....	33
Circuit Diagram for Quick Pinpoint Check.....	35
Wiring Diagram -A/C, M-.....	36
Main Power Supply and Ground Circuit Check....	42
Power Supply Circuit Check.....	42
Push Control Module Check.....	42
Diagnostic Procedure 1.....	43
Diagnostic Procedure 2.....	45
Diagnostic Procedure 3.....	47
Diagnostic Procedure 4.....	48
Diagnostic Procedure 5.....	50
Diagnostic Procedure 6.....	51
Electrical Components Inspection.....	55
Fan Switch.....	55
Blower Motor.....	55
Blower Resistor.....	55
A/C Switch.....	55
Thermo Control Amp.....	56
Thermal Protector.....	56
Triple-Pressure Switch.....	56
A/C Relay.....	56
Control Linkage Adjustment.....	57
Mode Door.....	57
Air Mix Door (Water cock).....	57
Intake Door.....	57
Fresh Vent Door.....	57

AUTO

DESCRIPTION	59
Introduction.....	59
Features.....	59
Control Operation.....	60

CONTENTS (Cont'd.)

TROUBLE DIAGNOSES	62	Auto Amp. Check.....	102
How to Perform Trouble Diagnoses for Quick and Accurate Repair	62	Diagnostic Procedure 1	103
Work Flow.....	62	Diagnostic Procedure 2	104
Operational Check.....	63	Diagnostic Procedure 3	105
Conditions:.....	63	Diagnostic Procedure 4	106
Procedure:	63	Diagnostic Procedure 5	107
1. Check blower.....	63	Diagnostic Procedure 6	109
2. Check discharge air	63	Diagnostic Procedure 7	110
3. Check recirculation.....	64	Diagnostic Procedure 8	111
4. Check temperature decrease.....	64	Diagnostic Procedure 9	112
5. Check temperature increase.....	64	Diagnostic Procedure 10	115
6. Check ECON (ECONOMY) mode		Diagnostic Procedure 11.....	118
7. Check AUTO mode	64	Electrical Components Inspection	119
8. Check memory function	65	Blower Motor	119
Symptom Chart.....	66	Thermo Control Amp.	119
Diagnostic Table	66	Thermal Protector.....	119
Self-diagnosis.....	70	Triple-Pressure Switch.....	119
Checking Procedure.....	71	A/C Relay And Blower Hi Relay.....	119
Step 1: Checks Leds and segments	73	Control Linkage Adjustment.....	120
Step 2: Checks each sensor circuit for open or short circuit.....	73	Mode Door.....	120
Sensors and abnormalities.....	74	Air Mix Door (Water cock).....	120
Step 3: Checks mode door operation	74	Intake Door.....	121
Step 4: Checks operation of each actuator	75	Fresh Vent Door	121
Step 5: Checks temperature detected by sensors	75	SYSTEM DESCRIPTION	122
Auxiliary Mechanism: Temperature setting trimmer.....	77	Overview of Control System.....	122
Preliminary Check.....	78	Control System Input Components.....	123
Preliminary Check 1	78	Potentio Temperature Control (PTC).....	123
Preliminary Check 2	79	In-Vehicle Sensor	123
Preliminary Check 3	80	Aspirator	123
Preliminary Check 4	81	Ambient Sensor	124
Preliminary Check 5	82	Sunload Sensor	124
Preliminary Check 6	83	Control System Automatic Amplifier (Auto amp.).....	125
Preliminary Check 7	84	Ambient Temperature Input Process.....	125
Preliminary Check 8	85	Sunload Input Process	125
Performance Test Diagnoses.....	86	Control System Output Components.....	125
Insufficient Cooling	86	Air Mix Door Control (Automatic temperature control)	125
Performance Chart.....	88	Air Mix Door Motor	127
Test Condition.....	88	PBR characteristics	127
Test Reading.....	88	Mode Door Control	128
Trouble Diagnoses for Abnormal Pressure.....	89	Mode Door Motor	129
Harness Layout.....	93	Intake Door Control	129
Circuit Diagram for Quick Pinpoint Check.....	95	Intake Door Motor.....	130
Wiring Diagram -A/C, A-.....	96	Fan Speed Control	131
Main Power Supply and Ground Circuit Check..	102	Component parts.....	131
Power Supply Circuit Check For Auto A/C System.....	102	System operation	131
		Automatic Mode.....	131
		Starting Fan Speed Control.....	131
		Blower Speed Compensation.....	132

CONTENTS (Cont'd.)

Fan Control Amplifier	132
Blower Hi-Relay	133
Magnet Clutch Control.....	133

Compressor Mounting.....	139	GI
Belt Tension	139	
Fast Idle Control Device (FICD)	139	
Compressor.....	140	MA
Compressor Clutch	140	
Removal.....	140	
Inspection	141	EM
Installation.....	142	
Break-In Operation	143	LC
Thermal Protector	143	
SERVICE DATA AND SPECIFICATIONS (SDS) ...	144	


	MANUAL AND AUTO	
SERVICE PROCEDURES	134	
R-134a Service Procedure	134	
Compressor Lubricant Quantity	136	
Lubricant	136	
Checking And Adjusting.....	136	
Refrigerant Lines.....	138	

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Precautions for Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air Bag".

Precautions for Working with R-134a

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. These refrigerants must never be mixed, even in the smallest amounts. If the refrigerants are mixed, compressor malfunction is likely.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubricant other than that specified is used, compressor malfunction is likely.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - a: When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b: When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into the system.
 - c: Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - d: Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment) or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e: Do not allow lubricant to contact styrofoam parts. Damage may result.

Precautions for Working with Refrigerants

WARNING:

- Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.
- Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
- Do not store or heat refrigerant containers above 52°C (125°F).
- Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a pail of warm water.
- Do not intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.
- Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Do not introduce compressed air to any refrigerant container or refrigerant component.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Precautions for Refrigerant Connection

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:


When replacing or cleaning refrigerant cycle components, observe the following.

- Do not leave compressor on its side or upside down for more than 10 minutes. Compressor lubricant will enter low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, plug all openings immediately to prevent entry of dirt and moisture.
- When installing an air conditioning unit in the vehicle, connect the pipes as the final stage of the operation. Do not remove seal caps from pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to portions shown in illustration. Be careful not to apply lubricant to threaded portion.

Name: Nissan A/C System Lubricant Type R

Part No.: KLH00-PAGR0

- O-ring must be closely attached to inflated portion of tube.
- After inserting tube into union until O-ring is no longer visible, tighten nut to specified torque.
- After connecting line, conduct leak test and make sure that there is no leakage. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



Precautions for Servicing Compressor

- Plug all openings to prevent moisture and foreign matter from entering.
- Do not keep the compressor in the upside down position or laid on its side for more than 10 minutes. GI
- When replacing or repairing compressor, be sure to remove lubricant from the compressor and check the lubricant quantity extracted. MA
- When replacing or repairing compressor, follow Lubricant - Checking and Adjusting procedure exactly. Refer to the "Compressor Lubricant Quantity", "SERVICE PROCEDURES" (HA-136).
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated with oil, wipe it off by using a clean waste cloth moistened with thinner. EM
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour. LC
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation. EC

FE

CL

MT

AT

FA

RA

BR

ST

RS





BT

HA

EL

IDX

Special Service Tools





Tool number (Kent-Moore No.) Tool name	Description	Note
KV99231260 (J-38874) Clutch disc wrench	 <p style="text-align: right;">NT204</p>	Removing shaft nut and clutch disc
KV99232340 (J-38874) Clutch disc puller	 <p style="text-align: right;">NT206</p>	Removing clutch disc
KV99234330 (J-39024) Pulley installer	 <p style="text-align: right;">NT207</p>	Installing pulley
KV99233130 (J-39023) Pulley puller	 <p style="text-align: right;">NT208</p>	Removing pulley

R-134a Service Tools and Equipment

Never mix R-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.

Separate and non-interchangeable service equipment must be used for each type of refrigerant/lubricant. Refrigerant container fittings, service hose fittings, and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and HFC-134a (R-134a). This is to avoid mixed use of the refrigerants/lubricants.

Adapters to convert from one size fitting to the other must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.

Tool number (Kent-Moore No.) Tool name	Description	Note
R-134a refrigerant	 <p style="text-align: right;">NT196</p>	Container color: Light blue Container marking: R-134a Fitting size: Thread size • large container 1/2"-16 ACME
KLH00-PAGR0 (—) Nissan A/C System Lubricant Type R	 <p style="text-align: right;">NT197</p>	Type: Poly alkylene glycol oil (PAG), type R Application: R-134a vane rotary compressors (Nissan only) Lubricity: 40 ml (1.4 US fl oz, 1.4 Imp fl oz)
(J-39500-NI) Recovery/Recycling equipment (ACR4)	 <p style="text-align: right;">NT195</p>	Function: Refrigerant Recovery and Recycling and Recharging
(J-39400) Electronic leak detector	 <p style="text-align: right;">NT198</p>	Power supply: • DC 12 V (Cigarette lighter)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS






BT

HA

EL

IDX

R-134a Service Tools and Equipment (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Note
(J-39183) Manifold gauge set (with hoses and couplers)		Identification: • The gauge face indicates R-134a. Fitting size: Thread size • 1/2"-16 ACME
Service hoses • High side hose (J-39501-72) • Low side hose (J-39502-72) • Utility hose (J-39476-72)		Hose color: • Low hose: Blue with black stripe • High hose: Red with black stripe • Utility hose: Yellow with black stripe or green with black stripe Hose fitting to gauge: • 1/2"-16 ACME
Service couplers • High side coupler (J-39500-20) • Low side coupler (J-39500-24)		Hose fitting to service hose: • M14 x 1.5 fitting (optional) or permanently attached
(J-39650) Refrigerant weight scale		For measuring of refrigerant Fitting size: Thread size • 1/2"-16 ACME
(J-39649) Vacuum pump (Including the isolator valve)		Capacity: • Air displacement: 4 CFM • Micron rating: 20 microns • Oil capacity: 482 g (17 oz) Fitting size: Thread size • 1/2"-16 ACME

Precautions for Service Equipment

RECOVERY/RECYCLING EQUIPMENT

Follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than specified into the machine.

ELECTRONIC LEAK DETECTOR


Follow the manufacturer's instructions for tester operation and tester maintenance.

VACUUM PUMP


The lubricating oil contained inside the vacuum pump is not compatible with the specified lubricant for R-134a A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. Therefore, if the pump is switched off after evacuation the lubricating oil may migrate into the hose. To prevent this, isolate the pump from the hose after evacuation (vacuuming). This migration is avoided by placing a manual valve near the hose-to-pump connection, as follows:

- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut-off valve, disconnect the hose from the pump. As long as the hose is connected, the valve is open and lubricating oil may migrate.


Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.



RHA270D



SHA533D



RHA272D

MANIFOLD GAUGE SET

Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) along with specified lubricants.


SERVICE HOSES

Be certain that the service hoses display the markings described (colored hose with black stripe). Be certain that all hoses include positive shut off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.

Precautions for Service Equipment (Cont'd)

SERVICE COUPLERS

Never attempt to connect R-134a service couplers to an CFC-12 (R-12) A/C system. The R-134a couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination can occur.




Shut off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

REFRIGERANT WEIGHT SCALE

When using a scale which controls refrigerant flow electronically, assure the following:

- Hose fitting size is 1/2"-16 ACME
- No refrigerant other than HFC-134a (R-134a) (along with specified lubricant) has been used with the scale



CHARGING CYLINDER

Using a charging cylinder is not recommended. Refrigerant may be vented into the air through the cylinder's top valve when filling the cylinder.

Refrigeration Cycle

REFRIGERANT FLOW

The refrigerant flow is in the standard pattern. Refrigerant flows through the compressor, condenser, liquid tank, evaporator, and back to the compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.


REFRIGERANT SYSTEM PROTECTION

Triple-pressure switch


The triple- or dual-pressure switch is located on the liquid tank. If the system pressure rises or falls out of specifications, the switch opens to interrupt compressor clutch operation. Triple-pressure switch closes to turn on the cooling fan to reduce system pressure (USA model only).

Pressure relief valve







The refrigerant system is protected by a pressure relief valve. The valve is located on the end of the flexible high pressure hose near the compressor. When refrigerant system pressure increases abnormally [over 3,727 kPa (38 kg/cm², 540 psi)], the relief valve's port opens. The valve then releases refrigerant into the atmosphere.



Component Layout



Discharge Air Flow



- 1 : To face
- 2 : To foot
- 3 : To defroster


* : When recirculation switch is ON

For air flow %, refer to "Operational Check,"
"TROUBLE DIAGNOSES."

AHA366

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Control Operation

**FAN CONTROL SWITCH**

This switch turns the fan ON and OFF, and controls fan speed.

MODE SWITCHES

These switches allow control of the air discharge outlets.

When DEF or F/D mode is selected, the push control amplifier sets the intake door to "FRESH". The compressor turns on when DEF mode is selected.

TEMPERATURE CONTROL LEVER

This lever allows you to adjust the temperature of the discharge air.

RECIRCULATION SWITCH

OFF position: Outside air is drawn into the passenger compartment.

ON position: Interior air is recirculated inside the vehicle.

Recirculation is canceled when DEF or F/D mode is selected, and resumes when another mode is chosen.


AIR CONDITIONING SWITCH

The air conditioning switch controls the A/C system. When the switch is depressed with the fan ON, the compressor will turn ON. The indicator lamp will also light.

The air conditioning cooling function operates only when the engine is running.

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Operational Check

The purpose of the operational check is to confirm that the system operates properly.


CONDITIONS:

- Engine running and at normal operating temperature.

PROCEDURE:

1. Check blower


- Turn fan switch to 1-speed.
Blower should operate on low speed.
- Then turn fan switch to 2-speed, and continue checking blower speed until all speeds are checked.
- Leave blower on speed 4.



AHA210

2. Check discharge air


- Press each mode switch.



AHA212

- Confirm that discharge air comes out according to the air distribution table at left.
Refer to "Discharge Air Flow" (HA-13).






NOTE:

Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF  mode is selected.

Confirm that the intake door position is at FRESH when the F/D  mode is selected.


Intake door position is checked in the next step.

Discharge air flow


Switch mode/ indicator	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	78%	22%
	—	55%	45%
	—	—	100%

AHA213

Operational Check (Cont'd)



3. Check recirculation

- a. Press REC  switch. Recirculation indicator should illuminate.
- b. Listen for intake door position change (you should hear blower sound change slightly).

NOTE:

“Recirculation” does not operate in DEF  and F/D  modes.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA


EL

IDX




4. Check temperature decrease

- a. Slide temperature control lever to full cold.
- b. Check for cold air at discharge air outlets.



5. Check temperature increase

- a. Slide temperature control lever to full hot.
- b. Check for hot air at discharge air outlets.



6. Check air conditioning switch

Move the fan control switch to the desired (1 to 4 speed) position and push the A/C switch to turn ON the air conditioning.

The indicator lamp should come on when air conditioning is ON.

Symptom Chart

DIAGNOSTIC TABLE


PROCEDURE	Preliminary Check						Diagnostic Procedure						Main Power Supply and Ground Circuit Check			
	HA-20	HA-21	HA-22	HA-23	HA-24	HA-25	HA-43	HA-45	HA-47	HA-48	HA-50	HA-51	HA-42	HA-42	HA-42	HA-42
REFERENCE PAGE																
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Preliminary check 4	Preliminary check 5	Preliminary check 6	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	Diagnostic procedure 6	20A Fuses (#4, #5)	10A Fuse (#10)	10A Fuse (#20)	Push control module
A/C does not blow cold air.		①					○			○			○	○		
Insufficient heating.						①	○					○				
Blower motor does not rotate.		①					②						○			
Air outlet does not change.				①				②						○		○
Intake door does not change in VENT, B/L or FOOT mode.									①					○		○
Intake door is not set at "FRESH" in DEF or F/D mode.	①								○					○		○
Air mix door does not change.		①								②						
Fresh vent door does not change.											①					
Magnet clutch does not engage when A/C switch and fan switch are ON.		①										②		○	○	
Magnet clutch does not engage in DEF mode.		①	②									○		○	○	
Noise					①											

①, ②: The number means checking order.
 ○: Checking order depends on malfunction in each flow chart.

Preliminary Check

PRELIMINARY CHECK 1


Intake door is not set at "FRESH" in DEF or F/D mode.



Preliminary Check (Cont'd)

PRELIMINARY CHECK 2

A/C does not blow cold air.




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Preliminary Check (Cont'd)

PRELIMINARY CHECK 3

Magnet clutch does not engage in DEF mode.

- Perform PRELIMINARY CHECK 2 before referring to the following flow chart.








Preliminary Check (Cont'd)

PRELIMINARY CHECK 4

Air outlet does not change.

Turn ignition switch on. Does air come out normally from each duct when each mode switch is pushed?

Switch mode/ Indicator	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	78%	22%
	—	55%	45%
	—	—	100%

No → Perform **Diagnostic Procedure 2**. Refer to HA-45.


Yes ↓
INSPECTION END

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Preliminary Check (Cont'd)

PRELIMINARY CHECK 5


Noise



Preliminary Check (Cont'd)

PRELIMINARY CHECK 6


Insufficient heating



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Performance Test Diagnoses

INSUFFICIENT COOLING



Note: **A** - **F** correspond to those in Trouble Diagnoses for Abnormal Pressure. (Refer to HA-29.)

Performance Test Diagnoses (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Performance Chart

TEST CONDITION

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well ventilated place)

Doors: Closed

Door window: Open

Hood: Open

TEMP. setting: Max. COLD

Discharge Air: Face Vent

REC switch: (Recirculation) ON

Fan speed: 4-speed

A/C switch: ON

Engine speed: 1,500 rpm

Operate the air conditioning system for 10 minutes before taking measurements.

TEST READING

Recirculating-to-discharge air temperature table

Inside air at blower assembly inlet for recirculation*		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	20 (68)	4.0 - 5.4 (39 - 42)
	25 (77)	4.2 - 5.6 (40 - 42)
	30 (86)	8.5 - 11.1 (47 - 52)
	35 (95)	13.5 - 16.7 (56 - 62)
	40 (104)	18.5 - 22.3 (65 - 72)
60 - 70	20 (68)	5.4 - 6.8 (42 - 44)
	25 (77)	5.6 - 8.0 (42 - 46)
	30 (86)	11.1 - 14.1 (52 - 57)
	35 (95)	16.7 - 20.3 (62 - 69)
	40 (104)	22.3 - 26.5 (72 - 80)

* Thermometer should be placed at intake unit under RH side of instrument panel.

Ambient air temperature-to-operating pressure table


Ambient air		High-pressure (Discharge side) kPa (kg/cm ² , psi)	Low-pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	834 - 1,098 (8.5 - 11.2, 121 - 159)	122.6 - 161.8 (1.25 - 1.65, 17.8 - 23.5)
	25 (77)	1,049 - 1,363 (10.7 - 13.9, 152 - 198)	137.3 - 181.4 (1.4 - 1.85, 19.9 - 26.3)
	30 (86)	1,226 - 1,618 (12.5 - 16.5, 178 - 235)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
	35 (95)	1,255 - 1,716 (12.8 - 17.5, 182 - 249)	166.7 - 230.5 (1.7 - 2.35, 24.2 - 33.4)
	40 (104)	1,540 - 2,030 (15.7 - 20.7, 223 - 294)	201.0 - 289.3 (2.05 - 2.95, 29.2 - 41.9)

If pressure is not within range, refer to HA-29, "Trouble Diagnoses for Abnormal Pressure".

Trouble Diagnoses for Abnormal Pressure

Whenever system's high or low side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (normal) pressure range. Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-28 ("Ambient air temperature-to-operating pressure table").

Pressure measurements are effective only when ambient temperature is in the range indicated under the Performance Chart.

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high and low-pressure sides are too high.</p> <p>A</p>  <p>AC359A</p>	<ul style="list-style-type: none"> Pressure is reduced soon after water is splashed on condenser. 	<p>Excessive refrigerant charge in refrigeration cycle</p>	<p>Reduce refrigerant until specified pressure is obtained.</p>
	<p>Air suction by radiator or cooling fan is insufficient.</p>	<p>Insufficient condenser cooling performance</p> <p>↓</p> <p>① Condenser fins are clogged.</p> <p>② Improper rotation of cooling fan</p>	<ul style="list-style-type: none"> Clean condenser. Check and repair radiator or cooling fan as necessary.
	<ul style="list-style-type: none"> Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter. 	<p>Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.)</p> <p>↓</p> <p>Air in refrigeration cycle</p>	<p>Evacuate repeatedly and recharge system.</p>
	<p>Engine tends to overheat.</p>	<p>Engine cooling systems malfunction.</p>	<p>Check and repair each engine cooling system.</p>
	<ul style="list-style-type: none"> An area of the low-pressure pipe is colder than near the evaporator outlet. Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> Excessive liquid refrigerant on low-pressure side Excessive refrigerant discharge flow Expansion valve is open a little compared with the specification. <p>↓</p> <p>① Improper thermal valve installation</p> <p>② Improper expansion valve adjustment</p>	<p>Replace expansion valve.</p>

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS





BT

HA



EL

IDX

Trouble Diagnoses for Abnormal Pressure (Cont'd)


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p>AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> • Check and repair or replace malfunctioning parts. • Check lubricant for contamination.
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p>AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p>AC356A</p>	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)</p>	<p>Replace compressor.</p>
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p>AC353A</p>	<ul style="list-style-type: none"> • There is a big temperature difference between liquid tank outlet and inlet. Outlet temperature is extremely low. • Liquid tank inlet and expansion valve are frosted. • Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. • Expansion valve inlet may be frosted. • Temperature difference occurs somewhere in high-pressure side 	<p>Liquid tank inside is clogged a little.</p> <p>High-pressure pipe located between liquid tank and expansion valve is clogged.</p>	<ul style="list-style-type: none"> • Replace liquid tank. • Check lubricant for contamination. • Check and repair malfunctioning parts. • Check lubricant for contamination.

Trouble Diagnoses for Abnormal Pressure
(Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p>AC353A</p>	<p>There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.</p> <p>Areas near low-pressure pipe connection and service valve are extremely cold as compared with areas near expansion valve outlet and evaporator.</p>	<p>Expansion valve closes a little compared with the specification.</p> <p style="text-align: center;">↓</p> <p>① Improper expansion valve adjustment ② Malfunctioning thermal valve ③ Outlet and inlet may be clogged.</p> <p>Low-pressure pipe is clogged or crushed.</p>	<ul style="list-style-type: none"> ● Remove foreign particles by using compressed air. ● Check lubricant for contamination. ● Check and repair malfunctioning parts. ● Check lubricant for contamination.
<p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p>AC354A</p>	<ul style="list-style-type: none"> ● Air conditioning system does not function and does not cyclically cool the compartment air. ● The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Evaporator is frozen.</p> <p style="text-align: center;">↓</p> <p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)</p> <p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> ● Replace compressor. ● Drain water from refrigerant or replace refrigerant. ● Replace liquid tank.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

**Trouble Diagnoses for Abnormal Pressure
(Cont'd)**

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p>F</p>  <p>AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> ● If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. ● If due to foreign particles, remove expansion valve and remove particles with dry and compressed air (not shop air). ● If either of the above methods cannot correct the problem, replace expansion valve. ● Replace liquid tank. ● Check lubricant for contamination.

Harness Layout

Engine compartment




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Harness Layout (Cont'd)

Passenger compartment

A Push control module




B Mode door motor




Push control module **A**

Mode door motor **B**


Fuse block **C**




C Fuse block




D Air mix door motor



E Resistor





Circuit Diagram for Quick Pinpoint Check



GI
MA
EM
LG
EG
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Wiring Diagram -A/C, M-



HA-A/C,M-01



Refer to last page (Foldout page).
(M7), (E103)


Wiring Diagram -A/C, M- (Cont'd)

HA-A/C,M-02



Refer to last page (Foldout page).

- M7, E103
- E3
- E40



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT




HA

EL

IDX



Wiring Diagram - A/C, M- (Cont'd)

HA-A/C,M-03



Wiring Diagram - A/C, M- (Cont'd)

HA-A/C,M-04



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT



HA

EL

IDX


Wiring Diagram - A/C, M- (Cont'd)

HA-A/C,M-05




Wiring Diagram -A/C, M- (Cont'd)

HA-A/C,M-06



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).

M7, E103
E40

HA

EL


IDX

Main Power Supply and Ground Circuit Check

POWER SUPPLY CIRCUIT CHECK

Check power supply circuit for air conditioning system.

Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").




PUSH CONTROL MODULE CHECK

Check power supply circuit for push control module with ignition switch at ON.

1. Disconnect push control module harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑭ and body ground.

Voltmeter terminal		Voltage
⊕	⊖	
⑭	Body ground	Approx. 12V



Check body ground circuit for push control module with ignition switch ON.

1. Disconnect push control module harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑰ and body ground.

Ohmmeter terminal		Continuity
⊕	⊖	
⑰	Body ground	Yes

	INCIDENT	Flow chart No.
1	Fan fails to rotate.	1
2	Fan does not rotate at 1-speed.	2
3	Fan does not rotate at 2-speed.	3
4	Fan does not rotate at 3-speed.	4
5	Fan does not rotate at 4-speed.	5


Diagnostic Procedure 1

SYMPTOM: Blower motor does not rotate.

- Perform PRELIMINARY CHECK 2 before referring to the following flow chart.

Check if blower motor rotates properly at each fan speed.
Conduct check as per flow chart at left.

2 3 4 5
(Go to next page.) → B




A

CHECK POWER SUPPLY FOR BLOWER MOTOR.
Disconnect blower motor harness connector.
Do approx. 12 volts exist between blower motor harness terminal No. (45) and body ground?

No → Check 20A fuses at fuse block. Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

Yes →




B

Check circuit continuity between blower motor harness terminal No. (46) and body ground.

OK → **CHECK BLOWER MOTOR.** (Refer to HA-55.)

NG → Replace blower motor.

NG → Reconnect blower motor harness connector.




C

CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND RESISTOR.
Do approx. 12 volts exist between resistor harness terminal No. (28) and body ground?

No → Disconnect blower motor and resistor harness connectors.

Yes →



D

Note





Check circuit continuity between blower motor harness terminal No. (46) and resistor harness terminal No. (28).

(Go to next page.)




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 1 (Cont'd)



Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 2

SYMPTOM: Air outlet does not change.

- Perform **PRELIMINARY CHECK 4**, then **Main Power Supply and Ground Circuit Check** before referring to the flow chart below.

A

CHECK MODE DOOR MOTOR POSITION SWITCH.

1. Turn VENT switch ON with ignition switch at ON position.
2. Turn ignition switch OFF.
Disconnect push control module connector.
3. Turn ignition switch ON.
Check for continuity between terminal ① or ② of push control unit harness connector and body ground.
4. Using above procedures, check for continuity in any other mode, as indicated in chart.

Mode switch	Terminal No.		Continuity
	⊕	⊖	
VENT	① or ②	Body ground	Yes
B/L	② or ③		
FOOT	③ or ④		
F/D	④ or ⑤		
DEF	⑤ or ⑥		

OK

CHECK SIDE LINK.
Refer to HA-57.

NG

Disconnect mode door motor harness connector.

B Note

CHECK BODY GROUND CIRCUIT FOR MODE DOOR MOTOR.
Does continuity exist between mode door motor harness terminal No. ⑩① and body ground?

Yes

C Note

Check circuit continuity between each terminal on push control module and on mode door motor.

Terminal No.		Continuity
⊕	⊖	
Push control module	Mode door motor	Yes
①	①	
②	②	
③	③	
④	④	
⑤	⑤	
⑥	⑥	
⑦	⑦	
⑧	⑧	


OK

A
(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 2 (Cont'd)



A

Reconnect push control module and mode door motor harness connectors.

D

CHECK FOR OUTPUT OF PUSH CONTROL MODULE.
 Change the mode from VENT to DEF, or from DEF to VENT. Do approx. 12 volts exist between push control unit harness terminals ⑦ and ⑧ in both cases?

Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
⊖	⊖	Stop	Stop
⊖	⊕	VENT → DEF	Clockwise
⊕	⊖	DEF → VENT	Counterclockwise





NG

Replace push control module.

OK

Replace mode door motor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Diagnostic Procedure 3

SYMPTOM: Intake door does not change in VENT, B/L or FOOT mode.

- Perform **PRELIMINARY CHECK 1**, then **Main Power Supply and Ground Circuit Check** before referring to the flow chart below.

A

CHECK INTAKE DOOR MOTOR POSITION SWITCH.

1. Turn REC switch ON with ignition switch at ON position.
2. Turn ignition switch OFF. Disconnect push control module connector.
3. Turn ignition switch ON. Check if continuity exists between terminal No. ②① of push control module harness connector and body ground.
4. Using above procedures, check for REC switch OFF position as indicated in chart.

REC switch	Terminal No.		Continuity
	⊕	⊖	
ON	②①	Body ground	Yes
OFF	②④		

B

NG

Disconnect intake door motor harness connector.

Note

B

CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR.
Does continuity exist between intake door motor harness terminal No. ①② and body ground?

Yes

Note

C

CHECK circuit continuity between push control module harness terminal No. ②① (②④) and intake door motor harness terminal No. ②① (②④).

OK

Reconnect push control module and intake door motor harness connector.

D

Replace push control module.

No





CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR.

- Turn REC switch ON. Does continuity exist between intake door motor harness terminal No. ②① and body ground?
- Turn REC switch OFF. Does continuity exist between intake door motor harness terminal No. ①① and body ground?

Yes

Replace intake door motor.


Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 4

SYMPTOM: Air mix door does not change.


Perform Main Power Supply and Ground Circuit Check before referring to the following chart.



Note:

If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 4 (Cont'd)



E

A

E

CHECK FOR PUSH CONTROL MODULE OUTPUT.
 Do approx. 12 volts exist between push control module harness terminal No. 22 and 23 when temperature lever is slid from "HOT" to "COLD" or when temperature lever is slid from "COLD" to "HOT"?

No → Replace push control module.

Terminal No.		Air mix door motor	
22	23	Air mix door operation	Direction of linkage rotation
⊖	⊕	HOT → COLD	Clockwise
⊕	⊖	COLD → HOT	Counterclockwise
⊖	⊖	STOP	STOP



Yes →

CHECK AIR MIX DOOR.
 (Refer to HA-57.)

OK →

Replace air mix door motor.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



Diagnostic Procedure 5

SYMPTOM: Fresh vent door does not operate.

- Perform Main Power Supply and Ground Circuit Check before referring to the following chart.








Note: If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 6

SYMPTOM: Magnet clutch does not engage when A/C switch and fan switch are ON.

- Perform PRELIMINARY CHECK 2 before referring to the following chart.




```

    graph TD
      A["A CHECK POWER SUPPLY FOR COMPRESSOR.  
Disconnect compressor harness connector.  
Do approx. 12 volts exist between compressor harness terminal No. 52 and body ground?"]
      B["B CHECK POWER SUPPLY FOR THERMAL PROTECTOR.  
Disconnect thermal protector harness connector. Do approx. 12V exist between thermal protector harness terminal No. 52 and body ground?"]
      C["C CHECK THERMAL PROTECTOR.  
Check circuit continuity between thermal protector harness terminal No. 52 and compressor harness terminal No. 52."]
      D["D Check circuit continuity between A/C relay harness terminal No. 52 and thermal protector harness terminal No. 52."]
      E["E CHECK POWER SUPPLY FOR A/C RELAY.  
Do approx. 12 volts exist between A/C relay harness terminals 50, 51 and body ground?"]
      F["F CHECK A/C RELAY.  
(Refer to HA-56.)"]
      G["Reconnect A/C relay."]
      H["Check magnet clutch coil."]
      I["Replace magnet clutch. Refer to HA-140."]
      J["Replace thermal protector."]
      K["CHECK POWER SUPPLY CIRCUIT AND 10A FUSE AT FUSE BLOCK. Refer to EL section ('Wiring Diagram', 'POWER SUPPLY ROUTING')."]
      L["Replace A/C relay."]

      A -- Yes --> H
      A -- No --> B
      B -- Yes --> C
      B -- No --> D
      C -- NG --> J
      C -- OK --> A
      D -- OK --> E
      D -- NG --> A
      E -- No --> K
      E -- Yes --> F
      F -- NG --> L
      F -- OK --> G
      G --> A
      H -- OK --> I
      I --> A
      K --> A
      L --> A
  
```


Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 6 (Cont'd)



F CHECK COIL SIDE CIRCUIT OF A/C RELAY.
Do approx. 12 volts exist between ECM (ECCS control module) harness terminal No. (15) and body ground?
(For terminal arrangement, refer to HA-35.)


G Check circuit continuity between A/C relay harness terminal No. (53) and ECM (ECCS control module) harness terminal No. (15).
(For terminal arrangement, refer to HA-35.)



H Disconnect ECM (ECCS control module) harness connector.
Does continuity exist between ECM (ECCS control module) harness terminal No. (15) and body ground?
(For terminal arrangement, refer to HA-35.)


CHECK ECM (ECCS control module).
Refer to EC section ("TROUBLE DIAGNOSIS FOR DTC 31").

Reconnect ECM (ECCS control module) harness connector.



I CHECK TRIPLE-PRESSURE SWITCH CIRCUIT BETWEEN TRIPLE-PRESSURE SWITCH AND ECM (ECCS control module.)
Disconnect triple-pressure switch harness connector.
Do approx. 0 volts exist between triple-pressure switch harness terminals No. (42), (43) and body ground?


Disconnect ECM (ECCS control module) harness connector.
(Go to next page.)



J Check circuit continuity between tripple-pressure switch harness terminal No. (103) and body ground.

Replace triple-pressure switch.

CHECK TRIPLE-PRESSURE SWITCH.
(Refer to HA-56.)








Disconnect thermo control amp. harness connector.

(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 6 (Cont'd)



K Note
 Check circuit continuity between triple-pressure switch harness terminal No. ④① and thermo control amp. harness terminal No. ④①.

L Note
 Check circuit continuity between ECM (ECCS control module) harness terminal No. ②① (⑨) and triple-pressure switch harness terminal No. ④② (④③). (For terminal arrangement, refer to HA-35.)

OK
 CHECK POWER SUPPLY FOR THERMO CONTROL AMP. Disconnect thermo control amp. harness connector. Do approx. 12 volts exist between thermo control amp. harness terminal No. ④① and body ground?

OK
 Check ECM (ECCS control module). Refer to EC section ("TROUBLE DIAGNOSIS FOR DTC 31").

M
 CHECK BODY GROUND CIRCUIT FOR THERMO CONTROL AMP. Does continuity exist between thermo control amp. harness terminal No. ③⑦ and body ground?

No
 Check 10A fuses at fuse block. Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

Yes
N
 CHECK BODY GROUND CIRCUIT FOR THERMO CONTROL AMP. Does continuity exist between thermo control amp. harness terminal No. ③⑦ and body ground?

Yes
 Replace thermo control amp.

No
 Disconnect A/C switch harness connector.

O Note
 Check circuit continuity between thermo control amp. harness terminal No. ③⑦ and A/C switch harness terminal No. ⑬.

OK
NG
 CHECK A/C SWITCH. (Refer to HA-55.)



Replace A/C switch.

OK
 (Go to next page).

Note:
 If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
 MA
 EM
 LG
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Diagnostic Procedure 6 (Cont'd)



D
↓
Disconnect fan switch harness connector.


P Note
Check circuit continuity between A/C switch harness terminal No. 12 and fan switch harness terminal No. 32.

Q Note
OK
CHECK BODY GROUND CIRCUIT FOR FAN SWITCH.
Does continuity exist between fan switch harness terminal No. 104 and body ground?

Yes
CHECK FAN SWITCH.
(Refer to HA-55.)

NG → Replace fan switch.

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



Electrical Components Inspection

FAN SWITCH

Check continuity between terminals at each position.

TERMINAL	POSITION				
	OFF	1	2	3	4
28					○
29				○	○
30			○	○	○
31		○	○	○	○
32		○	○	○	○
104		○	○	○	○

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL


IDX



BLOWER MOTOR


Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.



BLOWER RESISTOR

Check continuity between terminals.




A/C SWITCH

Check continuity between terminals.

Electrical Components Inspection (Cont'd)


THERMO CONTROL AMP.

1. Run engine, and operate A/C system.
2. Connect the voltmeter from harness side.
3. Check thermo control amp. operation shown in the table.



Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 2.5 - 3.5 (37 - 38)	Turn OFF	Approx. 12V
Increasing to 4.0 - 5.0 (39 - 41)	Turn ON	Approx. 0V


THERMAL PROTECTOR



Temperature of compressor °C (°F)	Operation
Increasing to approx. 145 - 155 (293 - 311)	Turn OFF
Decreasing to approx. 130 - 140 (266 - 284)	Turn ON

If NG, replace thermal protector.

TRIPLE-PRESSURE SWITCH





	ON kPa (kg/cm ² , psi)	OFF kPa (kg/cm ² , psi)
Low-pressure side	157 - 226 (1.6 - 2.3, 23 - 33)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
Medium-pressure side*	1,422 - 1,618 (14.5 - 16.5, 206 - 235)	1,128 - 1,422 (11.5 - 14.5, 164 - 206)
High-pressure side	1,667 - 2,059 (17 - 21, 242 - 299)	2,452 - 2,844 (25 - 29, 356 - 412)

* For cooling fan motor operation.

A/C RELAY

Check circuit continuity between terminals by supplying 12 volts to coil side terminals of A/C relay.






Control Linkage Adjustment

MODE DOOR

1. Move side link by hand and hold mode door in DEF mode.
2. Install mode door motor on heater unit and connect it to main harness.
3. Turn ignition switch to ON.
4. Select VENT mode.
5. Attach mode door motor rod to side link rod holder.
6. Select DEF mode. Check that side link operates at the fully-open position.



GI
MA
EM



AIR MIX DOOR (Water cock)

1. Move air mix link by hand and hold air mix door in full cold position.
2. Install air mix door motor on heater unit and connect sub-harness.
3. Turn ignition switch to ON.
4. Slide temperature control lever to full cold.
5. Attach air mix door motor rod to air mix door link rod holder.
6. Check that air mix door operates properly when temperature control lever is slid to full hot and full cold.
7. Slide temperature control lever to full cold.
8. Attach water cock cable to air mix door linkage and secure with clip.
9. Rotate and hold water cock lever and plate in the full cold position (CLOCKWISE completely).
10. Attach water cock cable to plate and secure with clip (white mark on cable housing should be centered under the retaining clip).
11. Check that water cock operates properly when temperature lever is slid to full hot and full cold. (After several cycles, water cock lever should be midpoint of plate opening when temperature slider is full cold).


LC
EC
FE
CL
MT
AT
FA
RA



INTAKE DOOR

1. Connect intake door motor harness connector before installing intake door motor.
2. Turn ignition switch to ON.
3. Turn REC switch ON.
4. Install intake door motor on intake unit.
5. Install intake door lever.
6. Set intake door rod in REC position and fasten door rod to holder on intake door lever.
7. Check that intake door operates properly when REC switch is turned ON and OFF.

BR
ST
RS
BT



FRESH VENT DOOR

1. Connect fresh vent door motor harness connector before installing fresh vent door motor.
2. Turn ignition switch to ON.
3. Install fresh vent door motor on heater unit.
4. Attach fresh vent door rod to fresh vent door link rod holder.
5. Check that fresh vent door operates properly when bi-level switch is turned ON and OFF with the temperature control lever in the middle position.

HA
EL
IDX

NOTE

Introduction

The Automatic Temperature Control (ATC) system provides automatic regulation of the vehicles interior temperature. This system is based on the operator selected "set temperature", regardless of the outside temperature changes. This is done by utilizing a microcomputer, also referred to as the automatic amplifier, which receives input signals from several sensors. The automatic amplifier uses these input signals (including the set temperature) to automatically control:

- Outlet air volume
- Air temperature
- Air distribution

Features

- **Air mix door control (Automatic temperature control)**

The air mix door is automatically controlled so that in-vehicle temperature is maintained at a predetermined value by: The temperature setting, ambient temperature, in-vehicle temperature, amount of sunload.

- **Fan speed control**

Blower speed is automatically controlled based on temperature setting, ambient temperature, in-vehicle temperature, amount of sunload and air mix door position.

With FAN switch set to "AUTO", the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

- **Intake door control**

The intake doors are automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, amount of sunload and ON-OFF operation of the A/C switch.

- **Outlet door control**

The outlet door is automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, and amount of sunload.

- **Self-diagnostic system**

The self-diagnostic system is built into the auto amplifier to quickly locate the cause of problems.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Control Operation



AUTO SWITCH

The following components are automatically controlled so that the in-vehicle temperature will reach and maintain the set temperature.

- Compressor
- Air intake door
- Air mix door
- Mode doors
- Blower speed

The air conditioning cooling function operates only when the engine is running.

ECON (ECONOMY) SWITCH

Fully automatic control with the compressor off. With the compressor off, the system will not remove heat (cool) or de-humidify. The system will maintain the in-vehicle temperature at the set temperature when the set temperature is above the ambient (outside) temperature.

PTC (Potentio Temperature Control)





Increases or decreases the set temperature.

OFF SWITCH

The compressor and blower are off, the air intake doors are set to the outside air position, and the mode doors are set to the FOOT (78% foot and 22% defrost) position. In the OFF position the ATC system uses the vehicle's "flow through" ventilation to try to maintain the interior temperature based on the temperature set when the system was last operating.

FAN SWITCH

Manual control of the blower speed. Four speeds are available for manual control (as shown on the display screen):

low  , medium low  , medium high  , high 

Control Operation (Cont'd)

MODE SWITCH

Manual control of the air discharge outlets. Four selections are available (as shown on the display screen):



VENT (FACE)  , BI-LEVEL "B/L"  , FOOT  , FOOT and DEFROSTER "F/D" 

GI

RECIRCULATION SWITCH

ON position: Interior air is recirculated inside the vehicle.

OFF position: Automatic control resumes.

Recirculation is canceled when AUTO, DEF  or F/D  is selected, and resumes when another mode is chosen.

MA

EM

DEFROSTER SWITCH

Positions the mode doors to the defrost position. Also positions the air intake doors to the outside air position. The compressor operates at ambient temperature approx. 2°C (35°F) or above.

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



Operational Check



The purpose of the operational check is to confirm that the system operates properly.

CONDITIONS:

- Engine running and at normal operating temperature.

PROCEDURE:

1. Check blower

- Press fan switch (up side) one time. Blower should operate on low speed. The fan symbol should have one blade lit .
- Press fan switch (up side) one more time, and continue checking blower speed and fan symbol until all speeds are checked.
- Leave blower on MAX speed .


2. Check discharge air

- Press mode switch four times and DEF button.


- Confirm that discharge air comes out according to the air distribution table at left.

Refer to "Discharge Air Flow" (HA-13).


NOTE:

Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF  is selected.

Intake door position is checked in the next step.








AHA235



AHA236

Discharge air flow

Switch mode/ indicator	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	78%	22%
	—	55%	45%
	—	—	100%

AHA213

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT


HA

EL

IDX

Operational Check (Cont'd)**3. Check recirculation**


- a. Press REC  switch.
Recirculation indicator should illuminate.
- b. Listen for intake door position change (you should hear blower sound change slightly).



AHA237

4. Check temperature decrease


- a. Press the temperature decrease button until 18°C (65°F) is displayed.
- b. Check for cold air at discharge air outlets.



AHA238

5. Check temperature increase


- a. Press the temperature increase button until 32°C (85°F) is displayed.
- b. Check for hot air at discharge air outlets.



AHA239

6. Check ECON (ECONOMY) mode


- a. Press ECON switch.
- b. Display should indicate ECON (no AUTO, no MANUAL).
Confirm that the compressor clutch is not engaged (visual inspection).
(Discharge air will depend on ambient, in-vehicle, and set temperatures).



RHA107D


7. Check AUTO mode

- a. Press AUTO switch.
- b. Display should indicate AUTO (no ECON, no MANUAL).
Confirm that the compressor clutch engages (audio or visual inspection).
(Discharge air will depend on ambient, in-vehicle, and set temperatures).



RHA108D

Operational Check (Cont'd)



8. Check memory function

- a. Press OFF switch.
- b. Turn the ignition off.
- c. Turn the ignition on.
- d. Press the AUTO switch.
- e. Confirm that the set temperature remains at previous temperature.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Symptom Chart

DIAGNOSTIC TABLE

PROCEDURE		Self-diagnosis						Preliminary Check								Diagnostic Procedure			
REFERENCE PAGE		HA-71, 73	HA-71, 73	HA-72, 74	HA-72, 75	HA-72, 75	HA-77	HA-78	HA-79	HA-80	HA-81	HA-82	HA-83	HA-84	HA-85	HA-103	HA-104	HA-105	HA-106
SYMPTOM		STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	AUXILIARY MECHANISM	Preliminary Check 1	Preliminary Check 2	Preliminary Check 3	Preliminary Check 4	Preliminary Check 5	Preliminary Check 6	Preliminary Check 7	Preliminary Check 8	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4
Air outlet does not change.		①	②	○	○	○		③								○	○	○	○
Intake door does not change.		①	②		○	○			③							○	○	○	○
Insufficient cooling		○	○	○	○	○	○	○	○	①		○	○	○		○	○	○	○
Insufficient heating		○	○	○	○	○	○	○	○		①	○		○		○	○	○	○
Blower motor operation is malfunctioning.		①	②		○	○						③				○	○	○	○
Magnet clutch does not engage.		①	②		○	○							③			○	○	○	○
Discharged air temperature does not change.		①	②		○	○								③		○	○	○	○
Noise															①				
Result Self-diagnosis STEP 2	21 Ambient sensor circuit is open.	①	②			③										④			
	22 In-vehicle sensor circuit is open.	①	②			③											④		
	25 Sunload sensor circuit is open.	①	②															③	
	26 PBR circuit is open.	①	②																③

①, ②, ...: The number means checking order.
 ○: Checking order depends on malfunction in each flow chart.


Symptom Chart (Cont'd)

PROCEDURE		Self-diagnosis					Preliminary Check								Diagnostic Procedure				
REFERENCE PAGE		HA-71, 73	HA-71, 73	HA-72, 74	HA-72, 75	HA-72, 75	HA-77	HA-78	HA-79	HA-80	HA-81	HA-82	HA-83	HA-84	HA-85	HA-103	HA-104	HA-105	HA-106
SYMPTOM		STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	AUXILIARY MECHANISM	Preliminary Check 1	Preliminary Check 2	Preliminary Check 3	Preliminary Check 4	Preliminary Check 5	Preliminary Check 6	Preliminary Check 7	Preliminary Check 8	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4
Result of Self-diagnosis STEP 2	ECON 21 Ambient sensor circuit is shorted.	①	②			③										④			
	ECON 22 In-vehicle sensor circuit is shorted.	①	②			③											④		
	ECON 25 Sunload sensor circuit is shorted.	①	②															③	
	ECON 26 PBR circuit is shorted.	①	②																③
Mode door motor does not operate normally.		①	②	③	④	○										○	○	○	○
Intake door motor does not operate normally.		①	②		③	○										○	○	○	○
Air mix door motor does not operate normally.		①	②		③	○										○	○	○	○
Fresh vent door does not operate normally.		①	②		③														
Blower motor operation is malfunctioning under Starting Fan Speed Control.		①	②		○	○					③					○	○	○	○
Magnet clutch does not operate after performing Preliminary Check 6.		①	②		○	○						③			○	○	○	○	
Self-diagnosis cannot be performed.																			

①, ②,: The number means checking order.
 ○: Checking order depends on malfunction in each flow chart.

Self-diagnosis



The self-diagnostic system diagnoses sensors, door motors, blower motor, etc. by system line. Refer to applicable sections (items) for details. Shifting from normal control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from "OFF" to "ON") and pressing "OFF" switch for at least 5 seconds. The "OFF" switch must be pressed within 5 seconds after starting the engine (ignition switch is turned "ON"). This system will be canceled by either pressing AUTO (AUTO) switch or turning the ignition switch "OFF". Shifting from one step to another is accomplished by means of pushing ▲ (HOT) or ▼ (COLD) switch, as required. Additionally shifting from STEP 5 to AUXILIARY MECHANISM is accomplished by means of pushing ⚙️ (fan) UP switch.



Note:
For STEP 4 and 5, engine must be running for compressor to operate.

Self-diagnosis (Cont'd)

CHECKING PROCEDURE




*1: Conduct self-diagnosis STEP 2 under sunshine. When conducting indoors, direct light (more than 60W) at sunload sensor or Code No. 25 will indicate despite that sunload sensor is functioning properly.

Code No.	Malfunctioning sensor (including circuits)
21	Ambient sensor
22	In-vehicle sensor
25	Sunload sensor* 1
26	PBR


Note:
At any time, you can return to a previous step in the self-diagnosis by pressing the (COLD) switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Self-diagnosis (Cont'd)



Code No.	Malfunctioning part or circuit	
	Position switch	
31	VENT	Mode door motor
32	B/L	
34	FOOT	
35	F/D	
36	DEF	
37	REC	Intake door motor
38	20% FRE	
39	FRE	



Press (HOT) switch




Note

Code No. of actuators test pattern is indicated on display. Refer to HA-75.

Code No.	Actuators test pattern					
	Mode door	Intake door	Air mix door	Fresh vent door	Blower motor	Compressor
41	VENT	REC	Full Cold	Open	4 - 5V	ON
42	B/L	REC	Full Cold	Open	9 - 11V	ON
43	B/L	20% FRE	Full Hot	Close	7 - 9V	ON
44	FOOT	FRE	Full Hot	Close	7 - 9V	OFF
45	F/D	FRE	Full Hot	Close	7 - 9V	OFF
46	DEF	FRE	Full Hot	Close	10 - 12V	ON

Press (DEF) switch.

Press (HOT) switch.



Press (DEF) switch.

Temperature detected by each sensor is indicated on display. Refer to HA-75.

Ambient sensor
In-vehicle sensor

Turn ignition switch OFF or (AUTO) switch ON.

END

Note:
For STEP 4 and 5, engine must be running for compressor to operate.

Self-diagnosis (Cont'd)

STEP 1: Checks LEDs and segments

When switch's LED and segments are in good order in STEP 1 mode, the corresponding LED and fluorescent display tube will illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT


HA

EL

IDX




RHA165D



RHA166D


If LEDs or segments malfunction, LED does not come on or display shows incomplete segment.



RHA167D

STEP 2: Checks each sensor circuit for open or short circuit

Display shows "2" in STEP 2 mode. When all sensors are in good order, display shows "20". It takes approximately 4 seconds to check all sensors. If a circuit is shorted, display shows ECON mark blinks on display.



RHA501A

If two or more sensors malfunction, corresponding code Nos. respectively blink two times.

Self-diagnosis (Cont'd)

Sensors and abnormalities




If a circuit is opened or shorted, display shows its code No. when input corresponds with any of following conditions.

Code No.	Sensor	Open circuit	Short circuit
21	Ambient sensor	Less than -50°C (-58°F)	Greater than 75°C (167°F)
22	In-vehicle sensor	Less than -50°C (-58°F)	Greater than 75°C (167°F)
25	Sunload sensor*2	Less than 48.84 W/m ² (42 kcal)	Greater than 1,640 W/m ² (1,410 kcal)
26	PBR*1	Greater than 50%	Less than 30%

*1: "50%" and "30%" refer to percentage with respect to full stroke of air mix door. (Full cold: 0%, Full hot: 100%)

*2: **Conduct self-diagnosis STEP 2 under sunshine.**

When conducting indoors, direct light (more than 60W) at sunload sensor.



STEP 3: Checks mode door operation

Display shows "3" in STEP 3 mode.

When all doors are in good order, display will then show "30".

It takes approximately 16 seconds to check all mode and intake doors.

When abnormalities are detected, display shows a code No. corresponding with malfunctioning circuit, door position switch or motor.

Code No.	31	32	34	35	36	37	38	39
Malfunction	VENT	B/L	FOOT	F/D	DEF	REC	20% FRE	FRE

If any mode and intake door motor position switch is malfunctioning, mode and intake door motor will also malfunction.

If two or more mode and intake doors are out of order, corresponding code numbers respectively blink two times.

Self-diagnosis (Cont'd)

STEP 4: Checks operation of each actuator


Start engine and run at operating temperature.
Display shows "41" in STEP 4 mode.

When (DEF) switch is pressed one time, display shows "42". Thereafter, each time the switch is pressed, display advances one number at a time, up to "46", then returns to "41".

The auto amplifier will forcefully transmit an output to the affected actuators in response to code No. shown on display, as indicated in table below.

Checks must be made visually, by listening to any noise, or by touching air outlets with your hand, etc. for improper operation.
Operating condition of each actuator cannot be checked by indicators.


Actuator	Code No.					
	41	42	43	44	45	46
Mode door	VENT	B/L	B/L	FOOT	F/D	DEF
Intake door	REC	REC	20% FRE	FRE	FRE	FRE
Air mix door	Full Cold	Full Cold	Full Hot	Full Hot	Full Hot	Full Hot
Fresh vent door	OPEN	OPEN	CLOSE	CLOSE	CLOSE	CLOSE
Blower motor V	4 - 5	9 - 11	7 - 9	7 - 9	7 - 9	10 - 12
Compressor	ON	ON	ON	OFF	OFF	ON



Discharge air flow


Switch mode/indicator	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	78%	22%
	—	55%	45%
	—	—	100%

Reference code: AHA213



STEP 5: Checks temperature detected by sensors


Display shows "5" in STEP 5 mode.



- When (DEF) switch is pressed one time, display shows temperature detected by ambient sensor.
- When (DEF) switch is pressed second time, display shows temperature detected by in-vehicle sensor.
- ECON indicates display shows negative temperature reading.
- When (DEF) switch is pressed third time, display returns to original presentation "5".

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Self-diagnosis (Cont'd)






If temperature shown on display greatly differs from actual temperature: Check sensor circuit at first, then inspect sensor itself according to the procedures described in **Control System Input Components**. Refer to HA-123.


Self-diagnosis (Cont'd)

AUXILIARY MECHANISM: Temperature setting trimmer

The trimmer compensates for differences in range of $\pm 3^{\circ}\text{C}$ ($\pm 6^{\circ}\text{F}$) between temperature setting (displayed digitally) and temperature felt by driver.

Operating procedures for this trimmer are as follows:

- Begin Self-diagnosis STEP 5 mode.
- Press  (fan) UP switch to set system in auxiliary mode.
- Press either  (HOT) or  (COLD) switch as desired. Temperature will change at a rate of 0.5°C (1°F) each time a switch is pressed.




When battery cable is disconnected, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e. 0°C (0°F).

Preliminary Check

PRELIMINARY CHECK 1

Air outlet does not change.

- Perform Self-diagnosis STEP 1 before referring to the flow chart.




Preliminary Check (Cont'd)

PRELIMINARY CHECK 2

Intake door does not change.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Preliminary Check (Cont'd)


PRELIMINARY CHECK 3

Insufficient cooling



Preliminary Check (Cont'd)

PRELIMINARY CHECK 4
Insufficient heating




Note: To avoid unnecessary service of heating system, first perform TEMPERATURE SETTING TRIMMING. Refer to "AUXILIARY MECHANISM", "Self-diagnosis".

Preliminary Check (Cont'd)

PRELIMINARY CHECK 5

Blower motor operation is malfunctioning.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.




Preliminary Check (Cont'd)

PRELIMINARY CHECK 6

Magnet clutch does not engage.

- Perform Self-diagnosis STEP 1 before referring to the following flow chart.




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Preliminary Check (Cont'd)

PRELIMINARY CHECK 7

Discharged air temperature does not change.


- Perform Self-diagnosis STEP 1 before referring to the following flow chart.



Preliminary Check (Cont'd)

PRELIMINARY CHECK 8


Noise



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Performance Test Diagnoses

INSUFFICIENT COOLING



Note: **A-F** correspond to those in Trouble Diagnoses for Abnormal Pressure. (Refer to HA-89.)

Performance Test Diagnoses (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Performance Chart

TEST CONDITION

Before conducting performance test, disconnect ambient sensor harness connector and make short circuit using jumper cable.

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well ventilated place)

Doors: Closed

Door window: Open

Hood: Open

TEMP. setting: 18°C (65°F)

AUTO switch: ON

REC switch: (Recirculation) ON

Fan speed: MAX.

Engine speed: 1,500 rpm

Operate the air conditioning system for 10 minutes before taking measurements.

TEST READING

Recirculating-to-discharge air temperature table

Inside air at blower assembly inlet for recirculation*		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	20 (68)	4.0 - 5.4 (39 - 42)
	25 (77)	4.2 - 5.6 (40 - 42)
	30 (86)	8.5 - 11.1 (47 - 52)
	35 (95)	13.5 - 16.7 (56 - 62)
	40 (104)	18.5 - 22.3 (65 - 72)
60 - 70	20 (68)	5.4 - 6.8 (42 - 44)
	25 (77)	5.6 - 8.0 (42 - 46)
	30 (86)	11.1 - 14.1 (52 - 57)
	35 (95)	16.7 - 20.3 (62 - 69)
	40 (104)	22.3 - 26.5 (72 - 80)

* Thermometer should be placed at intake unit RH side of instrument panel.

Ambient air temperature-to-operating pressure table


Ambient air		High-pressure (Discharge side) kPa (kg/cm ² , psi)	Low-pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	834 - 1,098 (8.5 - 11.2, 121 - 159)	122.6 - 161.8 (1.25 - 1.65, 17.8 - 23.5)
	25 (77)	1,049 - 1,363 (10.7 - 13.9, 152 - 198)	137.3 - 181.4 (1.4 - 1.85, 19.9 - 26.3)
	30 (86)	1,226 - 1,618 (12.5 - 16.5, 178 - 235)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
	35 (95)	1,255 - 1,716 (12.8 - 17.5, 182 - 249)	166.7 - 230.5 (1.7 - 2.35, 24.2 - 33.4)
	40 (104)	1,540 - 2,030 (15.7 - 20.7, 223 - 294)	201.0 - 289.3 (2.05 - 2.95, 29.2 - 41.9)

If pressure is not within range, refer to HA-89 "Trouble Diagnoses for Abnormal Pressure".

Trouble Diagnoses for Abnormal Pressure






Whenever system's high or low side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (normal) pressure range. Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-88 ("Ambient air temperature-to-operating pressure table").

Pressure measurements are effective only when ambient temperature is in the range indicated under the Performance Chart.



Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high and low-pressure sides are too high.</p> <p>A</p>  <p>AC359A</p>	<ul style="list-style-type: none"> Pressure is reduced soon after water is splashed on condenser. 	<p>Excessive refrigerant charge in refrigeration cycle</p>	<p>Reduce refrigerant until specified pressure is obtained.</p>
	<p>Air suction by radiator or cooling fan is insufficient.</p>	<p>Insufficient condenser cooling performance</p> <p>↓</p> <p>① Condenser fins are clogged.</p> <p>② Improper rotation of cooling fan</p>	<ul style="list-style-type: none"> Clean condenser. Check and repair radiator or cooling fan as necessary.
	<ul style="list-style-type: none"> Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter. 	<p>Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.)</p> <p>↓</p> <p>Air in refrigeration cycle</p>	<p>Evacuate repeatedly and recharge system.</p>
	<p>Engine tends to overheat.</p>	<p>Engine cooling systems malfunction.</p>	<p>Check and repair each engine cooling system.</p>
	<ul style="list-style-type: none"> An area of the low-pressure pipe is colder than near the evaporator outlet. Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> Excessive liquid refrigerant on low-pressure side Excessive refrigerant discharge flow Expansion valve is open a little compared with the specification. <p>↓</p> <p>① Improper thermal valve installation</p> <p>② Improper expansion valve adjustment</p>	<p>Replace expansion valve.</p>

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

**Trouble Diagnoses for Abnormal Pressure
(Cont'd)**

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p>AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> • Check and repair or replace malfunctioning parts. • Check lubricant for contamination.
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p>AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p>AC356A</p>	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)</p>	<p>Replace compressor.</p>
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p>AC353A</p>	<ul style="list-style-type: none"> • There is a big temperature difference between liquid tank outlet and inlet. Outlet temperature is extremely low. • Liquid tank inlet and expansion valve are frosted. 	<p>Liquid tank inside is clogged a little.</p>	<ul style="list-style-type: none"> • Replace liquid tank. • Check lubricant for contamination.
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p>AC353A</p>	<ul style="list-style-type: none"> • Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. • Expansion valve inlet may be frosted. • Temperature difference occurs somewhere in high-pressure side 	<p>High-pressure pipe located between liquid tank and expansion valve is clogged.</p>	<ul style="list-style-type: none"> • Check and repair malfunctioning parts. • Check lubricant for contamination.

Trouble Diagnoses for Abnormal Pressure
(Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p>AC353A</p>	<p>There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.</p>	<p>Expansion valve closes a little compared with the specification.</p> <p>↓</p> <p>① Improper expansion valve adjustment ② Malfunctioning thermal valve ③ Outlet and inlet may be clogged.</p>	<ul style="list-style-type: none"> Remove foreign particles by using compressed air. Check lubricant for contamination.
	<p>Areas near low-pressure pipe connection and service valve are extremely cold as compared with areas near expansion valve outlet and evaporator.</p>	<p>Low-pressure pipe is clogged or crushed.</p>	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	<p>Air flow volume is not enough or is too low.</p>	<p>Evaporator is frozen.</p> <p>↓</p> <p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)</p>	<p>Replace compressor.</p>
<p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p>AC354A</p>	<ul style="list-style-type: none"> Air conditioning system does not function and does not cyclically cool the compartment air. The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Refrigerant does not discharge cyclically.</p> <p>↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p>↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> Drain water from refrigerant or replace refrigerant. Replace liquid tank.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL


IDX

Trouble Diagnoses for Abnormal Pressure
(Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p>F</p>  <p>AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> ● If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. ● If due to foreign particles, remove expansion valve and remove particles with dry and compressed air. ● If either of the above methods cannot correct the problem, replace expansion valve. ● Replace liquid tank. ● Check lubricant for contamination.

Harness Layout

Engine compartment




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Harness Layout (Cont'd)

Passenger compartment



A In-vehicle sensor




B Auto amp.




C Sunload sensor




D Fuse block (M11)




E Mode door motor



F Air mix door motor (Bottom of heater unit)



Circuit Diagram for Quick Pinpoint Check





CI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA

Ⓢ : For Canada

Wiring Diagram -A/C, A-



HA-A/C,A-01



Refer to last page (Foldout page).
 (M7), (E103)

Wiring Diagram -A/C, A- (Cont'd)

HA-A/C,A-02



Refer to last page (Foldout page).

- ⊠ (M7) E103
- ⊠ (E3)
- ⊠ (E40)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT



HA

EL

IDX




Wiring Diagram - A/C, A- (Cont'd)

HA-A/C,A-03



Wiring Diagram - A/C, A- (Cont'd)

HA-A/C,A-04



Refer to last page (Foldout page).
 (M7), (E103)



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT

HA

EL
 IDX


Wiring Diagram - A/C, A- (Cont'd)

HA-A/C,A-05




Wiring Diagram -A/C, A- (Cont'd)

HA-A/C,A-06



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).

M7, E103, E40

HA


EL

IDX

Main Power Supply and Ground Circuit Check

POWER SUPPLY CIRCUIT CHECK FOR AUTO A/C SYSTEM

Check power supply circuit for auto air conditioning system. Refer to EL section (“Wiring Diagram”, “POWER SUPPLY ROUTING”) and HA-96.




AUTO AMP. CHECK

Check power supply circuit for auto amp. with ignition switch ON.

1. Disconnect auto amp. harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑪, ⑫, ⑯ and body ground.


Voltmeter terminal		Voltage
⊕	⊖	
⑪	Body ground	Approx. 12V
⑫		
⑯		






Check body ground circuit for auto amp. with ignition switch OFF.

1. Disconnect auto amp. harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑳ and body ground.


Ohmmeter terminal		Continuity
⊕	⊖	
⑳	Body ground	Yes
⑳ (Canada only)	Body ground	Yes








Diagnostic Procedure 1

SYMPTOM: Ambient sensor circuit is open or shorted. (21 or ^{ECON}21 is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX






Diagnostic Procedure 2

SYMPTOM: In-vehicle sensor circuit is open or shorted. (22 or $\text{ECON} \text{22}$ is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)



Note:

If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 3

SYMPTOM: Sunload sensor circuit is open or shorted. (25 or ECON₂₅ is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)

```

    graph TD
      A["A  
CHECK SUNLOAD SENSOR CIRCUIT  
BETWEEN SUNLOAD SENSOR AND  
AUTO AMP.  
Disconnect sunload sensor harness  
connector.  
Do approx. 5 volts exist between sun-  
load sensor harness terminal No. 26  
and body ground?"]
      B["B  
Check circuit continuity between sun-  
load sensor harness terminal No. 38  
and auto amp. harness terminal No.  
29."]
      C["C  
Check circuit continuity  
between sunload sensor  
harness terminal No. 26  
and auto amp. harness  
terminal No. 26."]
      D["CHECK SUNLOAD SENSOR.  
(Refer to HA-124.)"]
      E["Replace auto amp."]
      F["Replace sunload sensor."]
      G["Disconnect auto amp. harness connec-  
tor."]
      H["Replace auto amp."]






      A -- No --> G
      G --> C
      C -- OK --> H
      C -- Note --> B
      B -- OK --> D
      B -- Note --> C
      D -- NG --> F
      D -- OK --> E
    
```

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 4

SYMPTOM: PBR circuit is open or shorted. (26 or ECON₂₆ is indicated on auto amp. as a result of conducting Self-diagnosis STEP 2.)



A CHECK PBR CIRCUIT BETWEEN PBR AND AUTO AMP.
Disconnect air mix door motor harness connector.
Do approx. 5 volts exist between air mix door motor harness terminal No. (33) and body ground?

No → Disconnect auto amp. harness connector.

B Note
Check circuit continuity between air mix door motor harness terminal No. (33) and auto amp. harness terminal No. (33).

OK → Replace auto amp.

Yes → Disconnect auto amp. harness connector.

C Note
Check circuit continuity between air mix door motor harness terminal No. (29) and auto amp. harness terminal No. (29).

OK → **D**

D CHECK PBR CIRCUIT BETWEEN PBR AND AUTO AMP.
Reconnect auto amp. harness connector.
Do approx. 5 volts exist between air mix door motor harness terminal No. (27) and body ground?

No → Disconnect auto amp. harness connector.

E Note
Check circuit continuity between air mix door motor harness terminal No. (27) and auto amp. harness terminal No. (27).




OK → Replace auto amp.

Yes → CHECK PBR SENSOR. (Refer to HA-127.)

NG → Replace air mix door motor (PBR).

OK → Replace auto amp.

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 5

SYMPTOM: Mode door motor does not operate normally.

- Perform Self-diagnosis STEPS 1 to 4 before referring to the following flow chart.

A

CHECK MODE DOOR MOTOR POSITION SWITCH.

1. Set up code No. 41 in Self-diagnosis STEP 4.
2. Disconnect auto amp. harness connector after turning ignition switch OFF.
3. Check if continuity exists between terminal No. (22) or (31) of auto amp. harness connector and body ground.
4. Using above procedure, check for continuity in any other mode, as indicated in chart.

Code No.	Condition	Terminal No.		Continuity
		⊕	⊖	
41	VENT	(22) or (31)	Body ground	Yes
42 or 43	B/L	(21) or (31)		
44	FOOT	(21) or (22)		
45	F/D	(30) or (22)		
45	DEF	(21) or (30)		

OK
INSPECTION END

NG
Disconnect mode door motor harness connector.

B Note
CHECK BODY GROUND CIRCUIT FOR MODE DOOR MOTOR.
Does continuity exist between mode door motor harness terminal No. (101) and body ground?

Yes
Reconnect auto amp. harness connector.

C
CHECK POWER SUPPLY FOR MODE DOOR MOTOR CONTROL CIRCUIT.
Do approx. 5 volts exist between mode door motor harness terminals and body ground?

Terminal No.		Voltage
⊕	⊖	
(21)	Body ground	Approx. 5V
(30)		
(22)		
(36)		
(31)		
(14)		




Yes
Reconnect mode door motor harness connector.

No

(A) (B)
(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 5 (Cont'd)



D

CHECK MODE DOOR MOTOR POSITION SWITCH.
Set up Self-diagnosis STEP 4.
Measure voltage across auto amp. harness terminals and body ground.

Code No.	Con- dition	Terminal No.				Body ground	
		⊕					⊖
		(22)	(31)	(21)	(30)		
41	VENT	0V	0V	5V	5V	Yes	
42 or 43	B/L	5V	0V	0V	5V		
44	FOOT	0V	5V	0V	5V		
45	D/F	0V	5V	5V	0V		
46	DEF	5V	5V	0V	0V		

0V: Approx. 0V
5V: Approx. 5V

OK → [Replace mode door motor.]
NG → [Replace auto amp.]

F

CHECK FOR AUTO AMP. OUTPUT.
Do approx. 10.5 volts exist between auto amp. harness terminals No. (5) and (6) when code No. is switched from "41" to "42" or when code No. is switched from "46" to "41"?

Code No.	Mode door motor operation	Terminal No.		Voltage V
		(6)	(5)	
41	VENT	⊕	⊖	Approx. 10.5
→42	→ B/L	⊖	⊕	
46	DEF	⊖	⊕	0
→41	→ VENT	⊖	⊖	
-	Stop	⊖	⊖	

Yes → [Replace mode door motor.]
No → [Replace auto amp.]

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.




E

Note

Check circuit continuity between each terminal on auto amp. and on mode door motor.

Terminal No.		Continuity
⊕	⊖	
Auto amp. (30)	Mode door motor (30)	Yes
(22)	(14) or (22)	
(21)	(21) or (36)	
(31)	(31)	

OK → [Replace auto amp.]



Diagnostic Procedure 6

SYMPTOM: Intake door motor does not operate normally.

- Perform Self-diagnosis STEPS 1, 2 and 4 before referring to the flow chart.

A Note

CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR. Disconnect intake door motor harness connector. Does continuity exist between intake door motor harness terminal No. (102) and body ground?

B

CHECK FOR AUTO AMP. OUTPUT. Set up Self-diagnosis STEP 4. Measure voltage across auto amp. harness terminals and body ground.

Code No.	Terminal No.		Condition	Voltage V
	⊕	⊖		
41 42	(23)	Body ground	REC	0
	(24)			12
	(32)			12
43	(23)	Body ground	20% REC	12
	(24)			0
	(32)			0
44 45 46	(23)	Body ground	FRE	0
	(24)			12
	(32)			12

0V: Approx. 0V
12V: Approx. 12V

OK

Replace intake door motor.

Note: If the result is NG or No after checking circuit continuity, repair harness or connector.

C Note



Check circuit continuity between each terminal on auto amp. and on intake door motor.

Terminal No.		Continuity
⊕	⊖	
Auto amp. (23) (24) (32)	Intake door motor (23 or 37) (24) (32)	Yes

OK

Replace auto amp.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Diagnostic Procedure 7



SYMPTOM: Air mix door motor does not operate normally.

- Perform Self-diagnosis STEPS 1, 2 and 4 before referring to the following flow chart.



Note:


If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 8

SYMPTOM: Fresh vent door motor does not operate normally.

- Perform Self-diagnosis STEP 4 before referring to the following flow chart.








Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 9

SYMPTOM: Blower motor operation is malfunctioning under Starting Fan Speed Control.

- Perform Preliminary Check 5 before referring to the following flow chart.



A CHECK POWER SUPPLY FOR FAN CONTROL AMP.
Disconnect fan control amp. harness connector.
Do approx. 12 volts exist between fan control amp. harness terminal No. (47) and body ground?

B CHECK BODY GROUND CIRCUIT FOR FAN CONTROL AMP.
Does continuity exist between fan control amp. harness terminal No. (104) and body ground?

Reconnect fan control amp. harness connector.

C CHECK FOR AUTO AMP. OUTPUT.
Set up Self-diagnosis STEP 4.
Measure voltage across fan control amp. harness terminal No. (10) and body ground.

Code No.	Terminal No.		Voltage
	⊕	⊖	
41-45	(10)	Body ground	Approx. 1 - 3V

Replace fan control amp.

D CHECK POWER SUPPLY FOR BLOWER MOTOR.
Disconnect blower motor harness connector.
Do approx. 12 volts exist between blower motor harness terminal No. (45) and body ground?


Check 20A fuses at fuse block. Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING") and HA-96.

E Check circuit continuity between blower motor harness terminal No. (46) and fan control amp. harness terminal No. (47).


CHECK BLOWER MOTOR.
(Refer to HA-119.)

Replace blower motor.

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.




Diagnostic Procedure 9 (Cont'd)




A
Disconnect auto amp. and fan control amp. harness connector.

F Note
Does continuity exist between auto amp. harness terminal No. ⑩ and fan control amp. harness terminal No. ⑩?



G
CHECK POWER SUPPLY FOR BLOWER HI-RELAY.
Do approx. 12 volts exist between blower Hi-relay harness terminals No. ④④, ④⑥ and body ground?

No
Check 10A or 20A fuses at fuse block. Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING") and HA-96.



H Note
CHECK BODY GROUND CIRCUIT FOR BLOWER HI-RELAY.
Does continuity exist between blower Hi-relay harness terminal No. ⑩③ and body ground?

I
CHECK BLOWER HI-RELAY AFTER DISCONNECTING IT.
(Refer to HA-119.)

NG
Replace blower Hi-relay.



OK
Reconnect blower Hi-relay.

B
(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Diagnostic Procedure 9 (Cont'd)



I

①

II

CHECK FOR AUTO AMP. OUTPUT.
Set up Self-diagnosis STEP 4.
Measure voltage across blower Hi-relay harness terminal No. ⑱ and body ground.

Code No.	Terminal No.		Voltage
	⊕	⊖	
45	⑱	Body ground	Less than approx. 1.5V

NG

Disconnect blower Hi-relay and auto amp. harness connectors.

J

Note

Does continuity exist between blower Hi-relay harness terminal No. ⑱ and auto amp. harness terminal No. ⑱?






Yes

Replace auto amp.

OK

Replace blower motor.


Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 10


SYMPTOM: Magnet clutch does not engage after performing Preliminary Check 6.

- Perform Preliminary Check 6 before referring to the flow chart.




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 10 (Cont'd)




(A)
Reconnect A/C relay.

Turn ignition switch ON and press OFF switch.




(F)
CHECK COIL SIDE CIRCUIT OF A/C RELAY.
Do approx. 12 volts exist between ECM (ECCS control module) harness terminal No. (15) and body ground?
(For terminal arrangement, refer to HA-95.)

(G) Note
Check circuit continuity between A/C relay harness terminal No. (53) and ECM (ECCS control module) harness terminal No. (15).
(For terminal arrangement, refer to HA-95.)




(G) Yes
(H)
CHECK COIL SIDE CIRCUIT OF A/C RELAY CONTROLLED BY ECM (ECCS control module).
Do more than 8 volts exist between ECM (ECCS control module) harness terminal No. (21) and body ground?
(For terminal arrangement, refer to HA-95.)

(H) No
CHECK ECM (ECCS control module).
Refer to EC section ("TROUBLE DIAGNOSIS FOR DTC 31").



(H) Yes
(I)
CHECK TRIPLE-PRESSURE SWITCH CIRCUIT BETWEEN TRIPLE-PRESSURE SWITCH AND ECM (ECCS control module).
Disconnect triple-pressure switch harness connector.
Do more than 8 volts exist between triple-pressure switch harness terminal No. (42) and body ground?

(I) No
Disconnect ECM (ECCS control module) harness connector.



(I) No
(J) Note
Check circuit continuity between ECM (ECCS control module) harness terminal No. (21) and triple-pressure switch harness terminal No. (42).
(For terminal arrangement, refer to HA-95.)



(I) Yes
(J)
CHECK TRIPLE-PRESSURE SWITCH.
(Refer to HA-119.)

(J) NG
Replace triple-pressure switch.

OK
(B)
(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 10 (Cont'd)



```


    graph TD
        B((B)) --> B1[Disconnect thermo control amp. harness connector.]
        B1 --> K[Check circuit continuity between thermo control amp. harness terminal No. 41 and triple-pressure switch harness terminal No. 41.]
        K -- NG --> K1[CHECK THERMO CONTROL AMP. Refer to HA-119.]
        K -- OK --> B2[Disconnect auto amp. harness connector.]
        K1 -- NG --> K2[Replace thermo control amp.]
        K1 -- OK --> B2
        B2 --> L[Check circuit continuity between auto amp. harness terminal No. 19 and thermo control amp. harness terminal No. 19.]
        L -- OK --> B3[Replace auto amp.]
        L -- NG --> B3
    
```


Note:
 If the result is NG or No after checking circuit continuity, repair harness or connector.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Diagnostic Procedure 11

SYMPTOM: Self-diagnosis cannot be performed.





Electrical Components Inspection

BLOWER MOTOR

Check blower motor for smooth rotation.

- Ensure that there are no foreign particles inside the intake unit.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL


IDX



THERMO CONTROL AMP.

1. Run engine, and operate A/C system.
2. Connect the voltmeter from harness side.
3. Check thermo control amp. operation shown in the table.


Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 2.5 - 3.5 (37 - 38)	Turn OFF	Approx. 12V
Increasing to 4.0 - 5.0 (39 - 41)	Turn ON	Approx. 0V



THERMAL PROTECTOR

Temperature of compressor °C (°F)	Operation
Increasing to approx. 145 - 155 (293 - 311)	Turn OFF
Decreasing to approx. 130 - 140 (266 - 284)	Turn ON


If NG, replace thermal protector.



TRIPLE-PRESSURE SWITCH


	ON kPa (kg/cm ² , psi)	OFF kPa (kg/cm ² , psi)
Low-pressure side	157 - 226 (1.6 - 2.3, 23 - 33)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
Medium-pressure side*	1,422 - 1,618 (14.5 - 16.5, 206 - 235)	1,128 - 1,422 (11.5 - 14.5, 164 - 206)
High-pressure side	1,667 - 2,059 (17 - 21, 242 - 299)	2,452 - 2,844 (25 - 29, 356 - 412)

* For cooling fan motor operation.



A/C RELAY AND BLOWER HI RELAY

Check circuit continuity between terminals by supplying 12 volts to coil side terminals of the relay.




Control Linkage Adjustment

MODE DOOR

1. Install mode door motor on heater unit and connect it to main harness.
2. Set up code No. 45 in Self-diagnosis STEP 4. Refer to HA-70.
3. Move side link by hand and hold mode door in DEF mode.
4. Attach mode door motor rod to side link rod holder.
5. Make sure mode door operates properly when changing from code No. 41 to 45 by pushing DEF switch.


41	42	43	44	45	46
VENT	B/L	B/L	FOOT	F/D	DEF



AIR MIX DOOR (Water cock)

1. Install air mix door motor on heater unit and connect it to main harness.
2. Set up code No. 41 in Self-diagnosis STEP 4. Refer to HA-70.
3. Move air mix door lever by hand and hold it in full cold position.
4. Attach air mix door lever to rod holder.
5. Make sure air mix door operates properly when changing from code No. 41 to 45 by pushing DEF switch.


41	42	43	44	45	46
Full cold			Full hot		



6. Set up code No. 41 in Self-diagnosis STEP 4.
7. Attach water cock cable to air mix door linkage and secure with clip.
8. Rotate and hold water cock lever AND plate in the full cold position (CLOCKWISE completely).
9. Attach water cock cable to plate and secure with clip (white mark on cable housing should be centered under the retaining clip).
10. Check that water cock operates properly when changing from code No. 41 to 45 by pushing DEF switch. (After several cycles, water cock lever should be midpoint of plate opening when code No. 41 is set.)


Control Linkage Adjustment (Cont'd)

INTAKE DOOR



1. Install intake door motor on intake unit and connect it to main harness.
2. Set up code No. 41 in Self-diagnosis STEP 4. Refer to HA-70.
3. Move intake door link by hand and hold it in REC position.
4. Attach intake door lever to rod holder.
5. Make sure intake door operates properly when changing from code No. 41 to 46 by pushing DEF switch.

41	42	43	44	45	46
REC		20% FRE	FRE		



FRESH VENT DOOR

1. Install fresh vent door motor on cooling unit and connect it to main harness.
2. Set up code No. 45 in self-diagnosis STEP 4. Refer to HA-70.
3. Move fresh vent door link by hand and hold it in CLOSE position.
4. Attach fresh vent door lever to rod holder.
5. Make sure fresh vent door operates properly when changing from code No. 41 to 46 by pushing DEF switch.

41	42	43	44	45	46
OPEN		CLOSE			


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Overview of Control System


The control system consists of

- input sensors and switches,
- the automatic amplifier (microcomputer), and
- outputs.

The relationship of these components is shown in the diagram below:



AHA373



Control System Input Components

POTENTIO TEMPERATURE CONTROL (PTC)


The PTC is built into the auto amplifier. It can be set at an interval of 1°C (2°F) through both ▲ (HOT) and ▼ (COLD) control switches. Setting temperature is digitally displayed.

IN-VEHICLE SENSOR

The in-vehicle sensor is attached to cluster lid-C. It converts variations in temperature of compartment air drawn from an aspirator into a resistance value. This value is then input into the auto amplifier.


After disconnecting in-vehicle sensor harness connector, measure resistance between terminals ②⑤ and ④⑨ at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07



ASPIRATOR


The aspirator is located on heater unit. It produces vacuum pressure due to air discharged from the heater unit, continuously taking compartment air in the aspirator.



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Control System Input Components (Cont'd)


AMBIENT SENSOR



The ambient sensor is attached to the radiator core support. It detects ambient temperature and converts it into a resistance value which is then input to the auto amplifier.

After disconnecting ambient sensor harness connector, measure resistance between terminals ③④ and ③⑨ at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07




SUNLOAD SENSOR

The sunload sensor is located on the right defroster grille. It detects sunload entering through windshield by means of a photo diode. The sensor then converts it into a current value which is then input to the auto amplifier.

Measure voltage between terminals ②⑥ and ③⑧ at vehicle harness side, using the table below.

Input current mA	Output voltage V
0	5.0
0.1	4.1
0.2	3.1
0.3	2.2
0.4	1.3
0.5	0.4

- When checking sunload sensor, select a place where sun shines directly on it.



Control System Automatic Amplifier (Auto amp.)

The auto amplifier has a built-in microcomputer which processes information sent from various sensors needed for air conditioning operation. The air mix door motor, mode door motor, intake door motor, blower motor and compressor are then controlled.

The auto amplifier is unitized with control mechanisms. Signals from various switches and Potentio Temperature Control (PTC) are directly entered into auto amplifier.

Self-diagnostic functions are also built into auto amplifier to provide quick check of malfunctions in the auto air conditioning system.

AMBIENT TEMPERATURE INPUT PROCESS

The automatic amplifier includes a "processing circuit" for the ambient sensor input. When the temperature detected by the ambient sensor increases quickly, the processing circuit allows the auto amp. to recognize an ambient temperature increase of only 0.2°C (0.4°F) per 100 seconds.

As an example, consider stopping for a cup of coffee after high speed driving. Even though the actual ambient temperature has not changed, the temperature detected by the ambient sensor will increase because heat radiated from the engine compartment can radiate to the front grille area (where the ambient sensor is located).

SUNLOAD INPUT PROCESS

The auto amp. also includes a processing circuit to "average" variations in detected sunload over a period of time. This prevents drastic swings in the ATC system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor will vary whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time. The (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the ATC system operation. On the other hand, shortly after entering a long tunnel, the system will recognize the change in sunload, and the system will react accordingly.

Control System Output Components

AIR MIX DOOR CONTROL (Automatic temperature control)

Component parts

Air mix door control system components are:

- Auto amplifier
- Air mix door motor (PBR)
- In-vehicle sensor
- Ambient sensor
- Sunload sensor


System operation

Temperature set by Potentio Temperature Control (PTC) is compensated through setting temperature correction circuit to determine target temperature.

Auto amplifier will operate air mix door motor to set air conditioning system in HOT or COLD position, depending upon relationship between conditions.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Control System Output Components (Cont'd)



AHA129

Air mix door control specification




- Example:**
- If temperature setting is set at 25°C (77°F) under no sunload condition when ambient and in-vehicle temperature is 35°C (95°F), air mix door is initially automatically set in full cold position.
 - Within some period, in-vehicle temperature will lower towards the objective temperature, and the air mix door position will shift incrementally towards the hot side and finally stay in this position **A** if mode is at AUTO position (No. ECON mode).
 - Air mix door opening position is always fed back to auto amplifier by PBR built-in air mix door motor.

AHA130

Control System Output Components (Cont'd)

AIR MIX DOOR MOTOR



The air mix door motor is attached to the bottom of the heater unit. It rotates so that the air mix door is opened to a position set by the auto amplifier. Motor rotation is conveyed through a shaft and air mix door position. It is then fed back to the auto amplifier by PBR built-in air mix door motor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX


Air mix door operation

7	8	Air mix door operation	Direction of lever movement
⊕	⊖	COLD → HOT	Clockwise (Toward passenger compartment)
⊖	⊖	STOP	STOP
⊖	⊕	HOT → COLD	Counterclockwise (Toward engine compartment)



PBR characteristics

Measure voltage between terminals 27 and 33 at vehicle harness side.



Control System Output Components (Cont'd)

MODE DOOR CONTROL


Component parts

Mode door control system components are:

- Auto amplifier
- Mode door motor
- PBR
- In-vehicle sensor
- Ambient sensor
- Sunload sensor


System operation

The auto amplifier computes the air discharge conditions according to the ambient temperature and the in-vehicle temperature. The computed discharge conditions are then corrected for sunload to determine through which outlets air will flow into the passenger compartment.



AHA133

Mode door control specification



Example:


- If temperature setting is set at 25°C (77°F) under no sunload condition when ambient and in-vehicle temperature are 30°C (86°F), mode door is set automatically at VENT position.

AHA134


Control System Output Components (Cont'd)

MODE DOOR MOTOR

The mode door motor is attached to the heater unit. It rotates so that air is discharged from the outlet set by the auto amplifier. Motor rotation is conveyed to a link which activates the mode door.



6	5	Mode door operation	Direction of side link rotation
⊕	⊖	VENT → DEF	Clockwise
⊖	⊖	STOP	STOP
⊖	⊕	DEF → VENT	Counterclockwise



INTAKE DOOR CONTROL


Components parts

Intake door control system components are:



- Auto amplifier
- Intake door motor
- PBR
- In-vehicle sensor
- Ambient sensor
- Sunload sensor

System operation

The intake door control determines intake door position based on the ambient temperature and the in-vehicle temperature. When the ECON, DEF, or OFF buttons are pushed, the auto amplifier sets the intake door at the "Fresh" position.



Control System Output Components (Cont'd)
Intake door control specification




INTAKE DOOR MOTOR

The intake door motor is attached to the intake unit. It rotates so that air is drawn from inlets set by the auto amplifier. Motor rotation is conveyed to a lever which activates the intake door.

Intake door motor operation

3	4	Intake door operation	Movement of link rotation
⊕	⊖	REC → FRE	Clockwise
⊖	⊖	STOP	STOP
⊖	⊕	FRE → REC	Counterclockwise



Control System Output Components (Cont'd)


FAN SPEED CONTROL

Component parts

Fan speed control system components are:

- Auto amplifier
- Fan control amplifier
- PBR
- In-vehicle sensor
- Ambient sensor
- Sunload sensor
- Blower Hi-relay
- Thermal transmitter

System operation



AUTOMATIC MODE

In the automatic mode, the blower motor speed is calculated by the automatic amplifier based on inputs from the:

- PBR
- in-vehicle sensor
- sunload sensor
- ambient sensor

The blower motor applied voltage ranges from approximately 4.5 volts (lowest speed) to 12 volts (highest speed).

To control blower speed (in the range of 4.5V to 10.5V), the automatic amplifier supplies a signal to the thermo control amplifier. Based on this signal, the thermo control amplifier controls the current flow from the blower motor to ground. If the computed blower voltage (from the automatic amplifier) is above 10.5 volts, the high blower relay is activated. The high blower relay provides a direct path to ground (bypassing the blower amplifier), and the blower motor operates at high speed.

STARTING FAN SPEED CONTROL

Start up from "COLD SOAK" condition (Automatic mode)

In a cold start up condition where the engine coolant temperature is below 50°C (122°F), the blower will not operate for a short period of time (up to 180 seconds). The exact start delay time varies depending on the ambient and engine coolant temperature.

In the most extreme case (very low ambient) the blower starting delay will be 180 seconds. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 50°C (122°F), at which time the blower speed will increase to the objective speed.

Start up from normal or "HOT SOAK" condition (Automatic mode)

The blower will begin operation momentarily after the AUTO button is pushed. The blower speed will gradually rise to the objective speed over a time period of 5 seconds or less (actual time depends on the objective blower speed).

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX



Control System Output Components (Cont'd)

BLOWER SPEED COMPENSATION

Sunload

When the in-vehicle temperature and the set temperature are very close, the blower will operate at low speed. The low speed varies depending on the sunload. During conditions of high sunload, the blower low speed is "normal" low speed (approx. 5.5V). During lesser sunload conditions, the low speed will drop to "low" low speed (approx. 4.5V).



Fan speed control specification



FAN CONTROL AMPLIFIER

The fan control amplifier is located on the cooling unit. It amplifies a 12-step base current flowing from the auto amplifier to change the blower speed within the range of 5V to 10.5V. Above 10.5 volts, the high relay applies a direct ground to the blower motor.

Control System Output Components (Cont'd)




BLOWER HI-RELAY

The blower Hi-relay is located on the cooling unit. It receives a signal from the auto amplifier to operate the blower motor at high speed.

MAGNET CLUTCH CONTROL

The ECM (ECCS control module) controls compressor operation using inputs from the throttle position sensor and auto amplifier.



Low temperature protection control

The auto amplifier will tell the ECM (ECCS control module) to turn the compressor "ON" or "OFF". This signal is based on input from the ambient temperature sensor.

Acceleration cut control

The ECM (ECCS control module) will turn the compressor "ON" or "OFF" based on the signal from the throttle position sensor.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX


R-134a Service Procedure

SETTING OF SERVICE TOOLS AND EQUIPMENT


DISCHARGING REFRIGERANT

WARNING:


Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment) or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.



EVACUATING SYSTEM AND CHARGING REFRIGERANT



R-134a Service Procedure (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Note: *1 Before charging refrigerant, ensure engine is off.
 *2 Before checking for leaks, start engine to activate air conditioning system then turn engine off.
 Service valve caps must be installed to prevent leakage.

Compressor Lubricant Quantity

The lubricant used to lubricate the compressor circulates through the system with the refrigerant. Whenever any component of the system is replaced or a large amount of gas leakage occurs: add lubricant to the compressor to maintain the specified amount.

If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)


LUBRICANT

Name: Nissan A/C System Lubricant Type R

Part No.: KLH00-PAGR0

CHECKING AND ADJUSTING

Adjust the lubricant quantity according to the flowchart shown below.




Compressor Lubricant Quantity (Cont'd)

(A)


1. Discharge refrigerant into refrigerant recovery/recycling equipment. Measure oil discharged into the recovery/recycling equipment.
 2. Drain the lubricant from the "old" (removed) compressor into a graduated container and record the amount of lubricant drained.
 3. Drain the lubricant from the "new" compressor into a separate, clean container.
 4. Measure an amount of new lubricant installed equal to amount drained from "old" compressor. Add this lubricant to "new" compressor through the suction port opening.
 5. Measure an amount of "new" lubricant equal to the amount recovered during discharging. Add this lubricant to "new" compressor through the suction port opening.
 6. If the liquid tank also needs to be replaced, add an additional 5 ml (0.2 US fl oz, 0.2 Imp fl oz) of lubricant at this time.
- Do not add this 5 ml (0.2 US fl oz, 0.2 Imp fl oz) of lubricant if only replacing the compressor.**

Lubricant adjusting procedure for compressor replacement




Refrigerant Lines

- Refer to HA-4.



RHA099D

Compressor Mounting



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Belt Tension

- Refer to MA section (“Checking Drive Belts”, “ENGINE MAINTENANCE”).

Fast Idle Control Device (FICD)

- Refer to EC section (“IACV-FICD Solenoid Valve”, “TROUBLE DIAGNOSIS FOR NON-DETECTIVE ITEMS”).


Compressor



Compressor Clutch


REMOVAL

- When removing center bolt, hold clutch disc with clutch disc wrench.




- Remove the drive plate using the clutch disc puller. Insert holder's three pins into the drive plate. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the drive plate. When tightening the center bolt, insert a round bar (screwdriver, etc.) between two of the pins (as shown in the left-hand figure) to prevent drive plate rotation. After removing the drive plate, remove the shims from either the drive shaft or the drive plate.

Compressor Clutch (Cont'd)




- Remove the snap ring using external snap ring pliers.




- Pulley removal
Use a commercially available pulley puller. Position the center of it on the end of the drive shaft, and remove the pulley assembly.

To prevent deformation of the pulley groove, the puller claws should be hooked under (not into) the pulley groove.

- Remove the field coil harness clip using a screwdriver.



- Remove the three field coil fixing screws and remove the field coil.



INSPECTION

Clutch disc

If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

Pulley

Check the appearance of the pulley assembly. If contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

Check coil for loose connection or cracked insulation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

Compressor Clutch (Cont'd)


INSTALLATION




- Install the field coil.
- Be sure to align the coil's pin with the hole in the compressor's front head.**
- Install the field coil harness clip using a screwdriver.



- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



- Install the drive plate on the drive shaft, together with the original shim(s). Press the drive plate down by hand.



- Using the clutch disc wrench to prevent drive plate rotation, tighten the bolt to 12 to 15 N·m (1.2 to 1.5 kg·m, 9 to 11 ft·lb) torque.

After tightening the bolt, check that the pulley rotates smoothly.

Compressor Clutch (Cont'd)

- Check clearance all the way around the clutch disc.


Disc-to-pulley clearance:

0.3 - 0.6 mm (0.012 - 0.024 in)


If the specified clearance is not obtained, replace adjusting shim and readjust.

BREAK-IN OPERATION

When replacing compressor clutch assembly, do not forget break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.



RHA080C



RHA081C

Thermal Protector

INSPECTION

- When servicing, do not allow foreign matter to get into compressor.
- Check continuity between two terminals.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

General Specifications

COMPRESSOR

Model	DKV-14C
Type	Vane rotary
Displacement cm ³ (cu in)/Rev	140 (8.54)
Direction of rotation	Clockwise (Viewed from drive end)
Drive belt	Poly V type

LUBRICANT

Model	ZEXEL make DKV-14C
Name	Nissan A/C System Lubricant Type R
Part No.	KLH00-PAGR0
Capacity ml (US fl oz, Imp fl oz)	
Total in system	200 (6.8, 7.0)
Compressor (Service part charging amount)	200 (6.8, 7.0)

REFRIGERANT

Type	R-134a	
Capacity	kg (lb)	0.70 - 0.80 (1.54 - 1.76)
	g (oz)	700 - 800 (24.64 - 28.16)

Inspection and Adjustment

ENGINE IDLING SPEED

When A/C is ON

- Refer to EC section (“Inspection and Adjustment”, “SERVICE DATA AND SPECIFICATIONS”).

BELT TENSION

- Refer to MA section (“Checking Drive Belts”, “ENGINE MAINTENANCE”).

COMPRESSOR CLUTCH

Model	DKV-14C
Clutch disc-pulley clearance	0.3 - 0.6
mm (in)	(0.012 - 0.024)