

## SECTION HA

### CONTENTS

<b>PRECAUTIONS AND PREPARATION</b> .....	2	Intake Door Motor Circuit.....	38
Supplemental Restraint System (SRS)		Magnet Clutch Circuit .....	42
“AIR BAG” .....	2	Air Mix Door .....	48
Precautions for Working with R-134a.....	2	Trouble Diagnosis For Insufficient Cooling.....	49
Contaminated Refrigerant .....	3	Performance Test Diagnoses.....	50
General Refrigerant Precautions .....	3	Performance Chart.....	52
Precautions for Refrigerant Connection .....	4	Trouble Diagnoses for Abnormal Pressure.....	53
Precautions for Servicing Compressor .....	7	Trouble Diagnosis for Insufficient Heating.....	57
Special Service Tools.....	8	Trouble Diagnosis for Noise .....	58
R-134a Service Tools and Equipment.....	9	<b>SERVICE PROCEDURES</b> .....	59
Commercial Service Tools .....	10	Checking Refrigerant Leaks .....	59
Precautions for Service Equipment .....	11	Checking Procedure .....	60
<b>DESCRIPTION</b> .....	13	R-134a Service Procedure .....	62
Refrigeration Cycle .....	13	Compressor Lubricant Quantity .....	64
Control Operation.....	14	Refrigerant Lines.....	66
Component Layout.....	15	Compressor Mounting.....	67
Discharge Air Flow.....	16	Belt Tension .....	67
Component Location.....	17	Fast Idle Control Device (FICD) .....	67
Circuit Diagram .....	19	Compressor.....	68
Wiring Diagram –HEATER–.....	20	Compressor Clutch .....	68
Wiring Diagram –A/C–.....	21	Thermal Protector .....	71
Operational Check .....	26	Heater Unit (Heater Core) .....	72
<b>TROUBLE DIAGNOSES</b> .....	28	Cooling Unit (A/C Evaporator).....	73
How to Perform Trouble Diagnoses for Quick		Blower Case and Motor .....	74
and Accurate Repair .....	28	Fan Switch and Illumination Bulbs .....	75
Main Power Supply and Ground Circuit Check.....	29	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	76
Push Control Unit.....	30	General Specifications .....	76
Blower Motor Circuit .....	31	Inspection and Adjustment.....	76
Mode Door Motor Circuit .....	35		

**When you read wiring diagrams:**

- Read GI section, “HOW TO READ WIRING DIAGRAMS”.
  - See EL section, “POWER SUPPLY ROUTING” for power distribution circuit.
- When you perform trouble diagnoses, read GI section, “HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES” and “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT”.**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## PRECAUTIONS AND PREPARATION

### Supplemental Restraint System (SRS) “AIR BAG”

The Supplemental Restraint System “AIR BAG”, used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

#### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation just before the harness connectors for easy identification.

### Precautions for Working with R-134a

#### WARNING:

- CFC-12 (R-12) refrigerant and R-134a refrigerant are not compatible. If the refrigerants are mixed, compressor malfunction is likely, refer to “Contaminated Refrigerant”. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/ Recycling Recharging equipment (ACR4) (J-39500-NI) and Refrigerant Identifier.
- Use only specified lubricant for the R-134a A/C system and R-134a components. If lubricant other than that specified is used, compressor malfunction is likely.
- The specified R-134a lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
  - a: When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
  - b: When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into the system.
  - c: Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
  - d: Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment) or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
  - e: Do not allow lubricant to contact styrofoam parts. Damage may result.

# PRECAUTIONS AND PREPARATION

## Precautions for Working with R-134a (Cont'd)

### Contaminated Refrigerant

If a refrigerant other than pure R-134a is identified in a vehicle, your options are:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere. GI
- Explain that recovery of the contaminated refrigerant could damage your service equipment and refrigerant supply. MA
- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred. EM
- If you choose to perform the repair, recover the refrigerant using only dedicated equipment and containers. **Do not recover contaminated refrigerant into your existing service equipment.** If your facility does not have dedicated recovery equipment, you may contact a local refrigerant product retailer for available service. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended. LC
- If the vehicle is within the warranty period, the air conditioner warranty is void. Please contact Nissan Customer Affairs for further assistance. EC

### WARNING:

### General Refrigerant Precautions

- **Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioner system is discharged. Always follow the manufacturers recommendations for use of the recovery/recycling equipment.** FE
- **Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioner system.** CL
- **Do not store or heat refrigerant containers above 52°C (125°F).** MT
- **Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a pail of warm water.** AT
- **Do not intentionally drop, puncture, or incinerate refrigerant containers.** FA
- **Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.** RA
- **Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.** BR
- **Do not pressure test or leak test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and R-134a have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.** ST

HA

EL

IDX

# PRECAUTIONS AND PREPARATION


## Precautions for Refrigerant Connection

A new type refrigerant connection has been introduced to all refrigerant lines except the following location:

- Expansion valve to cooling unit.

### FEATURES OF NEW TYPE REFRIGERANT CONNECTION


- The O-ring is relocated in a groove for proper installation. This eliminates the chance of the O-ring being caught in, or damaged by, the mating part. The sealing direction of the O-ring is now set vertically in relation to the contacting surface of the mating part to improve sealing characteristics.
- The reaction force of the O-ring will not occur in the direction that causes the joint to pull out, thereby facilitating piping connections.



# PRECAUTIONS AND PREPARATION


## Precautions for Refrigerant Connection (Cont'd)

### O-RING AND REFRIGERANT CONNECTION



#### CAUTION:

Refrigerant connections in some systems use different O-ring configurations. Do not confuse O-rings since they are not interchangeable. If a wrong O-ring is installed, refrigerant will leak at, or around, the connection.



#### O-ring part numbers and specifications

Connection type	O-ring size	Part number	D mm (in)	W mm (in)
Former	6	92472 N8200	4.5 (0.177)	1.40 (0.0551)
New	8	92471 N8210	6.8 (0.268)	1.85 (0.0728)
Former	8	92470 N8200	6.07 (0.2390)	1.78 (0.0701)
Former	12	92475 71L00	11.0 (0.433)	2.4 (0.094)
New	19	92474 N8210	16.5 (0.650)	2.43 (0.0957)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# PRECAUTIONS AND PREPARATION

## Precautions for Refrigerant Connection (Cont'd)

### WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

### CAUTION:


When replacing or cleaning refrigerant cycle components, observe the following.

- Do not leave compressor on its side or upside down for more than 10 minutes. Compressor lubricant will enter low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, plug all openings immediately to prevent entry of dirt and moisture.
- When installing an air conditioner unit in the vehicle, connect the pipes as the final stage of the operation. Do not remove seal caps from pipes and other components until just before connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to portions shown in illustration. Be careful not to apply lubricant to threaded portion.

Name: Nissan A/C System Lubricant Type R

Part No.: KLH00-PAGR0

- O-ring must be closely attached to inflated portion of tube.
- After inserting tube into union until O-ring is no longer visible, tighten nut to specified torque.
- After connecting line, conduct leak test and make sure that there is no leakage. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



# PRECAUTIONS AND PREPARATION

## Precautions for Servicing Compressor

- Plug all openings to prevent moisture and foreign matter from entering. GI
- Do not keep the compressor in the upside down position or laid on its side for more than 10 minutes.
- When replacing or repairing compressor, be sure to remove lubricant from the compressor and check the lubricant quantity extracted. MA
- When replacing or repairing compressor, follow lubricant checking and adjusting procedure exactly. Refer to "Compressor Lubricant Quantity", "SERVICE PROCEDURES", HA-64. EM
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated with oil, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour. LC
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation. EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

**HA**





EL

IDX

# PRECAUTIONS AND PREPARATION

## Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	Note
KV99231260 (J-38874) Clutch disc wrench	 NT204	Removing shaft nut and clutch disc
KV99232340 (J-38874) Clutch disc puller	 NT206	Removing clutch disc
KV99234330 (J-39024) Pulley installer	 NT207	Installing pulley
KV99233130 (J-39023) Pulley puller	 NT208	Removing pulley








# PRECAUTIONS AND PREPARATION

## R-134a Service Tools and Equipment

Never mix R-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.





Separate and non-interchangeable service equipment must be used for each type of refrigerant/lubricant. Refrigerant container fittings, service hose fittings, and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and R-134a. This is to avoid mixed use of the refrigerants/lubricants.

Adapters to convert from one size fitting to the other must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.


Tool number (Kent-Moore No.) Tool name	Description	Note
R-134a refrigerant	 NT196	Container color: Light blue Container marking: R-134a Fitting size: Thread size ● large container 1/2"-16 ACME
KLH00-PAGRO ( — ) Nissan A/C System Lubri- cant Type R	 NT197	Type: Polyalkylene glycol oil (PAG), type R Application: R-134a vane rotary compres- sors (Nissan only) Lubricity: 40 ml (1.4 US fl oz, 1.4 Imp fl oz)
(J-39500-NI) Recovery/Recycling equip- ment (ACR4)	 NT195	Function: Refrigerant Recovery and Recy- cling and Recharging
(J-41995) A/C leak detector	 AHA281A	Function: checks for refrigerant leaks.
(J-39183) Manifold gauge set (with hoses and couplers)	 NT199	Identification: ● The gauge face indicates R-134a. Fitting size: Thread size ● 1/2"-16 ACME

# PRECAUTIONS AND PREPARATION

## R-134a Service Tools and Equipment (Cont'd)

<p>Service hoses</p> <ul style="list-style-type: none"> <li>● High-side hose (J-39501-72)</li> <li>● Low-side hose (J-39502-72)</li> <li>● Utility hose (J-39476-72)</li> </ul>	 <p>NT201</p>	<p>Hose color:</p> <ul style="list-style-type: none"> <li>● Low hose: Blue with black stripe</li> <li>● High hose: Red with black stripe</li> <li>● Utility hose: Yellow with black stripe or green with black stripe</li> </ul> <p>Hose fitting to gauge:</p> <ul style="list-style-type: none"> <li>● 1/2"-16 ACME</li> </ul>
<p>Service couplers</p> <ul style="list-style-type: none"> <li>● High-side coupler (J-39500-20)</li> <li>● Low-side coupler (J-39500-24)</li> </ul>	 <p>NT202</p>	<p>Hose fitting to service hose:</p> <ul style="list-style-type: none"> <li>● M14 x 1.5 fitting (optional) or permanently attached</li> </ul>
<p>(J-39650) Refrigerant weight scale</p>	 <p>NT200</p>	<p>For measuring of refrigerant</p> <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> <li>● 1/2"-16 ACME</li> </ul>
<p>(J-39649) Vacuum pump (Including the isolator valve)</p>	 <p>NT203</p>	<p>Capacity:</p> <ul style="list-style-type: none"> <li>● Air displacement: 4 CFM</li> <li>● Micron rating: 20 microns</li> <li>● Oil capacity: 482 g (17 oz)</li> </ul> <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> <li>● 1/2"-16 ACME</li> </ul>

## Commercial Service Tools

Tool name	Description	Note
<p>(J-41810) Refrigerant Identifier Equipment</p>	 <p>NT765</p>	<p>Function: Checks refrigerant purity and for system contamination.</p>

# PRECAUTIONS AND PREPARATION

## Precautions for Service Equipment

### RECOVERY/RECYCLING EQUIPMENT

Follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

### ELECTRONIC LEAK DETECTOR


Follow the manufacturer's instructions for tester operation and tester maintenance.

### VACUUM PUMP


The lubricating oil contained inside the vacuum pump is not compatible with the specified lubricant for R-134a A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. Therefore, if the pump is switched off after evacuation the lubricating oil may migrate into the hose. To prevent this, isolate the pump from the hose after evacuation (vacuuming). This migration is avoided by placing a manual shut-off valve near the hose-to-pump connection, as follows:

- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator valve, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut-off valve, disconnect the hose from the pump. As long as the hose is connected, the valve is open and lubricating oil may migrate.


Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.



RHA270D



SHA533D



RHA272D

### MANIFOLD GAUGE SET

Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant R-134a along with specified lubricants.

### SERVICE HOSES

Be certain that the service hoses display the markings described (colored hose with black stripe). Be certain that all hoses include positive shut-off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# PRECAUTIONS AND PREPARATION

## Precautions for Service Equipment (Cont'd)

### SERVICE COUPLERS

Never attempt to connect R-134a service couplers to a CFC-12 (R-12) A/C system. The R-134a couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination can occur.



Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

### REFRIGERANT WEIGHT SCALE

When using a scale which controls refrigerant flow electronically, assure the following:

- Hose fitting size is 1/2"-16 ACME
- No refrigerant other than R-134a (along with specified lubricant) has been used with the scale.

### Calibration


Calibrate the scale every 3 months.

To calibrate the weight scale on the ACR4 (J-39500):

1. Press **Shift/Reset** and **Enter** at the same time.
2. Press **8787**. "A1" will be displayed.
3. Remove all weight from the scale.
4. Press **0**, then press **Enter**. "0.00" will be displayed and change to "A2."
5. Place a known weight (dumbbell or similar weight), between 10 and 19 lbs., on the center of the weight scale.
6. Enter the known weight using 4 digits. (Example 10 lbs = 10.00, 10.5 lbs = 10.50)
7. Press **Enter** – the display returns to the vacuum mode.
8. Press **Shift/Reset** and **Enter** at the same time.
9. Press **6** – the known weight on the scale is displayed.
10. Remove the known weight from the scale. "0.00" will be displayed.
11. Press **Shift/Reset** to return the ACR4 to the program mode.

### CHARGING CYLINDER

Using a charging cylinder is not recommended. Refrigerant may be vented into the air through the cylinder's top valve when filling the cylinder.



# DESCRIPTION

## Refrigeration Cycle

### REFRIGERANT FLOW

The refrigerant flow is in the standard pattern. Refrigerant flows through the compressor, condenser, liquid tank, evaporator, and back to the compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.


### REFRIGERANT SYSTEM PROTECTION

#### Triple-pressure switch

The triple or dual-pressure switch is located on the liquid tank. If the system pressure rises or falls out of specifications, the switch opens to interrupt compressor clutch operation. The triple-pressure switch closes to turn on the cooling fan to reduce system pressure.


#### Pressure relief valve

The refrigerant system is protected by a pressure relief valve. The valve is located on the end of the flexible high pressure hose near the compressor. When refrigerant system pressure increases abnormally [over 3,727 kPa (38 kg/cm<sup>2</sup>, 540 psi)], the relief valve's port opens. The valve then releases refrigerant into the atmosphere.



# DESCRIPTION

## Control Operation





### FAN CONTROL SWITCH

This switch turns the fan ON and OFF, and controls fan speed.

### MODE SWITCHES

These switches control the outlet air flow.

The indicator lamp will also light when the switch is depressed.

When DEF  or F/D  mode is selected, the push control unit sets the intake door to FRESH.

The compressor turns on when DEF  mode is selected.

### TEMPERATURE CONTROL LEVER

This lever allows you to adjust the temperature of the discharge air.

### RECIRCULATION (REC) SWITCH


OFF position: Outside air is drawn into the passenger compartment.

ON position: Interior air is recirculated inside the vehicle.

The indicator lamp will also light.

Recirculation is canceled when DEF  or F/D  mode is selected, and resumes when another mode is chosen.

Recirculation automatically occurs when the following conditions are met:

1. FACE  mode.
2. Full cold position.
3. Fan switch to 4 speed.
4. A/C switch on.

Recirculation indicator will not illuminate.

### AIR CONDITIONER (A/C) SWITCH


The air conditioner switch controls the A/C system. When the switch is depressed with the fan ON, the compressor will turn ON. The indicator lamp will also light.

**The air conditioner cooling function operates only when the engine is running.**

# DESCRIPTION

## Component Layout

SEC. 270•271•272•273•685



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

**HA**


EL

IDX


# DESCRIPTION

## Discharge Air Flow

**Air outlets**




**Foot**




**Face**

Switch "on"




**Foot and defrost**




**Bi-level**

Switch "off"



**Defrost**




- ① : To face
- ② : To foot
- ③ : To defrost

For air flow %, refer to "Operational Check,"  
"TROUBLE DIAGNOSES."



Component Location

Engine compartment




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# DESCRIPTION



## Component Location (Cont'd)

### Passenger compartment


**A** Push control unit




**B** Mode door motor



**C** Fuse block




**D** Resistor



# DESCRIPTION

## Circuit Diagram



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX






HA

AHA973

# DESCRIPTION



## Wiring Diagram -HEATER-

HA-HEATER-01



Wiring Diagram -A/C-

HA-A/C-01






GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX



# DESCRIPTION

## Wiring Diagram -A/C- (Cont'd)

HA-A/C-02



Refer to last page (Foldout page).



# DESCRIPTION

## Wiring Diagram -A/C- (Cont'd)



HA-A/C-03

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT

HA

EL

IDX



Refer to last page (Foldout page).



(M8), (E65)

\*This connector is not shown in "HARNES LAYOUT" of EL-section.

# DESCRIPTION

## Wiring Diagram -A/C- (Cont'd)

HA-A/C-04






Refer to last page (Foldout page).  
 (M8), (E65)



# DESCRIPTION

## Wiring Diagram -A/C- (Cont'd)

HA-A/C-05



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT

**HA**

EL

IDX

# DESCRIPTION

## Operational Check

The purpose of the operational check is to confirm that the system operates properly.

After operational check is completed, go to SYMPTOM TABLE in How to Perform Trouble Diagnoses for Quick and Accurate Repair, HA-28.


### CONDITIONS:

- Engine running and at normal operating temperature.

### PROCEDURE:

#### 1. Check blower


- Turn fan switch to 1-speed. Blower should operate on 1-speed.
- Then turn fan switch to 2-speed, and continue checking blower speed until all speeds are checked.
- Leave blower on 4-speed.



AHA981

#### 2. Check discharge air

- Press each mode switch.




AHA982

- Confirm that discharge air comes out according to the air distribution table at left, and that the indicator lamp illuminates.

Refer to "Discharge Air Flow", HA-16.






#### NOTE:

Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF  mode is selected.

Confirm that the intake door position is at FRESH when the F/D  mode is selected.

Intake door position is checked in the next step.


#### Discharge air flow

Switch mode/ indicator	Air outlet/distribution		
	Face	Foot	Defrost
	100%	—	—
	60%	40%	—
	—	80%	20%
	—	60%	40%
	—	—	100%


AHA983

# DESCRIPTION




## Operational Check (Cont'd)




### 3. Check recirculation

- Press REC  switch. Recirculation indicator should illuminate.
- Listen for intake door position change (you should hear blower sound change slightly).

#### NOTE:


- Recirculation does not operate in DEF  and F/D  modes.
- Recirculation automatically occurs when the following conditions are met:
  - FACE  mode.
  - Full cold position.
  - Fan switch to 4 speed.
  - A/C switch on.

Recirculation indicator will not illuminate.




### 4. Check temperature decrease

- Slide temperature control lever to full cold.
- Check for cold air at discharge air outlets.



### 5. Check temperature increase

- Slide temperature control lever to full hot.
- Check for hot air at discharge air outlets.



### 6. Check air conditioner switch

Turn the fan control switch to the desired (1 to 4 speed) position and push the A/C switch to turn ON the air conditioner.

The indicator lamp should come on when air conditioner is ON.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

# TROUBLE DIAGNOSES

## How to Perform Trouble Diagnoses for Quick and Accurate Repair

### WORK FLOW



### SYMPTOM TABLE

Symptom	Reference page
● A/C push control unit does not operate.	● Go to Trouble Diagnoses for A/C System, HA-30.
● Blower motor does not rotate.	● Go to Blower Motor Circuit, HA-31.
● Air outlet does not change.	● Go to Mode Door Motor Circuit, HA-35.
● Intake door does not change in FACE, B/L or FOOT mode.	● Go to Intake Door Motor Circuit, HA-38.
● Intake door is not set at FRESH in DEF or F/D mode.	
● Intake door is not set at RECIRC in A/C full cool mode.	
● Magnet clutch does not engage when A/C switch and fan switch are ON.	● Go to Magnet Clutch Circuit, HA-42.
● Magnet clutch does not engage in DEF mode.	
● Air mix door does not change.	● Go to Air Mix Door, HA-48.
● Insufficient Cooling.	● Go to Trouble Diagnosis for Insufficient Cooling, HA-49. ● Go to Performance Test Diagnosis, HA-50. ● Go to Performance Chart, HA-52. ● Go to Trouble Diagnoses for Abnormal Pressure, HA-53.
● Insufficient heating.	● Go to Trouble Diagnoses for Insufficient Heating, HA-57.
● Noise.	● Go to Trouble Diagnoses for Noise, HA-58.

## Main Power Supply and Ground Circuit Check

### POWER SUPPLY CIRCUIT CHECK

Check power supply circuit for air conditioner system.

Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX




### PUSH CONTROL UNIT CHECK

Check power supply circuit for push control unit with ignition switch ON.

1. Disconnect push control unit harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑭ and body ground.

Voltmeter terminal		Voltage
⊕	⊖	
⑭	Body ground	Approx. 12V



Check body ground circuit for push control unit with ignition switch OFF.

1. Disconnect push control unit harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑰ and body ground.


Ohmmeter terminal		Continuity
⊕	⊖	
⑰	Body ground	Yes

# TROUBLE DIAGNOSES

## Push Control Unit

**SYMPTOM: A/C push control unit does not operate.**

### INSPECTION FLOW




# TROUBLE DIAGNOSES

## Blower Motor Circuit

**SYMPTOM: Blower motor does not rotate.**

### INSPECTION FLOW



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

**HA**

EL

IDX


# TROUBLE DIAGNOSES

## Blower Motor Circuit (Cont'd) DIAGNOSTIC PROCEDURE

	INCIDENT	Flow chart
1	Fan fails to rotate.	1
2	Fan does not rotate at 1-speed.	2
3	Fan does not rotate at 2-speed.	3
4	Fan does not rotate at 3-speed.	4
5	Fan does not rotate at 4-speed.	5


Check if blower motor rotates properly at each fan speed.  
Conduct check as per flow chart at left.

2 3 4 5  
(Go to next page.) →



**A**  
**CHECK POWER SUPPLY FOR BLOWER MOTOR.**  
Disconnect blower motor harness connector.  
Does approx. 12 volts exist between blower motor harness terminal ⊕ and body ground?


No → Check 15A fuses at fuse block.  
Refer to EL section ("Wiring Diagram", "POWER SUPPLY ROUTING").



**B**  
Check circuit continuity between blower motor harness terminal ⊖ and body ground.

OK → Check blower motor. Refer to HA-34.


NG → Replace blower motor.



**C**  
**CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND RESISTOR.**  
Do approx. 12 volts exist between resistor harness terminal ① and body ground?

No → Disconnect blower motor and resistor harness connectors.

**D** Note  
Check circuit continuity between blower motor harness terminal ⊖ and resistor harness terminal ①. **Continuity should exist.** If OK, check harness for short.







Yes → (Go to next page.) **A**

**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.





# TROUBLE DIAGNOSES

## Blower Motor Circuit (Cont'd)



**E CHECK FAN SWITCH CIRCUIT.**  
Do approx. 12 volts exist between each fan switch harness terminal and body ground?

Flow chart	Terminal		Voltage
	⊕	⊖	
2	4	Body ground	Approx. 12V
3	3		
4	2		
5	1		



**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX


# TROUBLE DIAGNOSES

## Blower Motor Circuit (Cont'd)


### COMPONENT INSPECTION

#### Fan switch

Check continuity between terminals at each position.




TERMINAL	POSITION				
	OFF	1	2	3	4
1					○
2				○	
3			○		
4		○	○	○	
5		○	○	○	○
6		○	○	○	○



#### Blower motor

Confirm smooth rotation of the blower motor.

- Check that there are no foreign particles inside the intake unit.



#### Blower resistor


Check continuity between terminals.

# TROUBLE DIAGNOSES

## Mode Door Motor Circuit

**SYMPTOM: Air outlet does not change.**

### INSPECTION FLOW



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

**HA**

EL


IDX

# TROUBLE DIAGNOSES


## Mode Door Motor Circuit (Cont'd)

### DIAGNOSTIC PROCEDURE


**SYMPTOM: Air outlet does not change.**



AHA998



AHA999



AHA001A

**A**

#### CHECK MODE DOOR MOTOR POSITION SWITCH.

1. Press FACE switch ON with ignition switch ON.
2. Turn ignition switch OFF. Disconnect push control unit connector.
3. Check for continuity between terminal ① or ② of push control unit harness connector and body ground.
4. Using above procedures, check for continuity in any other mode, as indicated in chart.

Mode switch	Terminal No.		Continuity
	⊕	⊖	
FACE	① or ②	Body ground	Yes
B/L	② or ③		
FOOT	③ or ④		
F/D	④ or ⑤		
DEF	⑤ or ⑥		

OK

CHECK SIDE LINK  
Refer to HA-37.

NG

**B**

Note

#### CHECK BODY GROUND CIRCUIT FOR MODE DOOR MOTOR.

1. Disconnect mode door motor harness connector.
2. Check continuity between mode door motor harness terminal ① and body ground.

OK

**C**

Note

Check circuit continuity between each terminal on push control unit and on mode motor.

Terminal No.		Continuity
⊕	⊖	
Push control unit	Mode door motor	Yes
①	⑦	
②	⑥	
③	⑤	
④	④	
⑤	③	
⑥	②	
⑦	⑧	
⑧	⑨	

If OK, check harness for short.

OK

**A**




(Go to next page.)

**Note:**

If the result is NG or No after checking circuit continuity, repair harness or connector.

# TROUBLE DIAGNOSES

## Mode Door Motor Circuit (Cont'd)



### CONTROL LINKAGE ADJUSTMENT Mode Door

1. Move side link by hand and hold mode door in DEF mode.
2. Connect door motor to main harness.
3. Turn ignition switch ON.
4. Select DEF mode.
5. Install mode door motor on heater unit.
6. Attach mode door motor rod to side link rod holder.

After installing the mode door motor, check for proper operation.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Intake Door Motor Circuit

**SYMPTOM:** Intake door does not change in FACE, B/L or FOOT mode.  
Intake door is not set at FRESH in DEF or F/D mode.  
Intake door is not set at RECIRC in A/C full cool mode.


### INSPECTION FLOW



# TROUBLE DIAGNOSES

## Intake Door Motor Circuit (Cont'd)

### CHECK FOR INTAKE DOOR



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

**HA**

EL

IDX





# TROUBLE DIAGNOSES

## Intake Door Motor Circuit (Cont'd)

### DIAGNOSTIC PROCEDURE FOR INTAKE DOOR CIRCUIT

**SYMPTOM:** Intake door does not change in FACE, B/L or FOOT mode.

Intake door is not set at FRESH in DEF or F/D mode.



- A**
- CHECK INTAKE DOOR MOTOR POSITION SWITCH.**
1. Press REC switch ON with ignition switch ON.
  2. Turn ignition switch OFF.  
Disconnect push control unit connector.
  3. Check if continuity exists between terminal (21) of push control unit harness connector and body ground.
  4. Using above procedures, check for REC switch OFF position as indicated in chart.

REC switch	Terminal No.	Continuity
ON	(21)	Body ground Yes
OFF	(24)	

If OK, check harness for short.

**B** NG Note

- C**
- CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR.**
1. Disconnect intake door motor harness connector.
  2. Check continuity between intake door motor harness terminal (5) and body ground.

**C** OK Note

Check circuit continuity between push control unit harness terminal (21) (24) and intake door motor harness terminal (4) (1).  
**Continuity should exist.**  
If OK, check harness for short.

**C** OK

Reconnect push control unit and intake door motor harness connector.

- D**
- CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR.**
- Press REC switch ON. Does continuity exist between intake door motor harness terminal (7) and body ground?  
if OK, check harness for short.
  - Press REC switch OFF. Does continuity exist between intake door motor harness terminal (6) and body ground?  
if OK, check harness for short.

**D** Yes

Replace intake door motor.

**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.

OK → CHECK INTAKE DOOR LINKAGE ADJUSTMENT. Refer to HA-41.

No → Replace push control unit.







# TROUBLE DIAGNOSES

## Intake Door Motor Circuit (Cont'd)

### DIAGNOSTIC PROCEDURE FOR FULL COOL SWITCH CIRCUIT

**SYMPTOM:** Intake door is not set at REC in A/C full cool mode.



**A**

**CHECK FULL COOL SWITCH CIRCUIT**

1. Turn ignition switch to OFF.
2. Disconnect push control unit connector.
3. Check continuity from push control unit connector terminal 26 to body ground.

Temperature control lever position	Terminal	Continuity
Full cold	26	Ground
Other	26	Ground

**B**

1. Disconnect full cool switch connector.
2. Check continuity of full cool switch.

Temperature control lever position	Terminal	Continuity
Full cold	1	2
Other	1	2

**C**

1. Disconnect push control unit connector.
2. Disconnect full cool switch connector.
3. Check continuity from push control unit connector terminal 26 to full cool switch connector terminal 1.
4. Check continuity from full cool switch connector terminal 2 to body ground.

**Continuity should exist.**

OK → CHECK INTAKE DOOR LINKAGE ADJUSTMENT. Refer to procedure below.

NG → Replace full cool switch.

NG → 1. Repair harness or connectors.  
2. Repair body grounds (M2) and (M61).

### CONTROL LINKAGE ADJUSTMENT

#### Intake Door


- Control linkage for intake door is not adjustable.
- Check for free movement or intake door linkage. Remove intake door motor and move linkage by hand.
- If any stiffness or binding is detected, remove the blower case. Refer to HA-74.
- Inspect intake door and linkage. Replace parts as necessary.

# TROUBLE DIAGNOSES


## Magnet Clutch Circuit

**SYMPTOM:** Magnet clutch does not engage when A/C switch and fan switch are ON.  
Magnet clutch does not engage in DEF mode.

### INSPECTION FLOW



### CHECK FOR MAGNET CLUTCH




# TROUBLE DIAGNOSES



## Magnet Clutch Circuit (Cont'd)

### DIAGNOSTIC PROCEDURE



**SYMPTOM:** Magnet clutch does not engage when A/C switch and fan switch are ON.



**A**  
**CHECK POWER SUPPLY FOR COMPRESSOR.**  
Disconnect compressor harness connector. Do approx. 12 volts exist between compressor harness terminal ① and body ground?




**B**  
**CHECK POWER SUPPLY FOR THERMAL PROTECTOR.**  
Disconnect thermal protector harness connector. Do approx. 12V exist between thermal protector harness terminal ① and body ground?





Disconnect air conditioner relay.

**D** Note  
Check circuit continuity between air conditioner relay harness terminal ③ and thermal protector harness terminal ①. **Continuity should exist.** If OK, check harness for short.



**E**  
**CHECK POWER SUPPLY FOR AIR CONDITIONER RELAY.**  
Do approx. 12 volts exist between air conditioner relay harness terminals ⑤, ① and body ground?



**CHECK AIR CONDITIONER RELAY AFTER DISCONNECTING IT.** Refer to HA-47.


Reconnect air conditioner relay.

**Note:** If the result is NG or No after checking circuit continuity, repair harness or connector.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Magnet Clutch Circuit (Cont'd)




**F**

**CHECK COIL SIDE CIRCUIT OF AIR CONDITIONER RELAY.**  
Do approx. 12 volts exist between ECM harness terminal (15) and body ground?  
(For terminal arrangement, refer to HA-23.)

**G** Note


Check circuit continuity between air conditioner relay harness terminal (2) and ECM harness terminal (15).  
(For terminal arrangement, refer to HA-23.)  
**Continuity should exist.**  
If OK, check harness for short.



**H**

**CHECK COIL SIDE CIRCUIT OF AIR CONDITIONER RELAY CONTROLLED BY ECM.**  
Do more than 8 volts exist between ECM harness terminal (21) and body ground?  
(For terminal arrangement, refer to HA-23.)

**CHECK ECM.**  
Refer to EC section ("TROUBLE DIAGNOSIS FOR DTC 31").



**I**


**CHECK TRIPLE-PRESSURE SWITCH CIRCUIT BETWEEN TRIPLE-PRESSURE SWITCH AND ECM.**  
Disconnect triple-pressure switch harness connector.  
Do more than 8 volts exist between triple-pressure switch harness terminal (1) and body ground?

Disconnect ECM harness connector.

(Go to next page.)

**CHECK TRIPLE-PRESSURE SWITCH.**  
Refer to HA-47.

Replace triple-pressure switch.



Disconnect thermo control amp. harness connector.




(Go to next page.)

**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.



# TROUBLE DIAGNOSES

## Magnet Clutch Circuit (Cont'd)




**Note:**  
If the result is NG or No after checking circuit continuity, repair harness or connector.

# TROUBLE DIAGNOSES


## Magnet Clutch Circuit (Cont'd) ELECTRICAL COMPONENT INSPECTION

### Thermo control amp.

1. Run engine, and operate A/C system.
2. Connect the voltmeter from harness side.
3. Check thermo control amp. operation shown in the table.




Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 2.5 - 3.5 (37 - 38)	Turn OFF	Approx. 12V
Increasing to 4.0 - 5.0 (39 - 41)	Turn ON	Approx. 0V



### Thermal protector

Temperature of compressor °C (°F)	Operation
Increasing to approx. 145 - 155 (293 - 311)	Turn OFF
Decreasing to approx. 130 - 140 (266 - 284)	Turn ON

If NG, replace thermal protector.




### Triple-pressure switch

	Terminals	High-pressure side line pressure kPa (kg/cm <sup>2</sup> , psi)	Operation	Continuity
Low-pres- sure side	① - ②	Increasing to 157 - 226 (1.6 - 2.3, 23 - 33)	ON	Exists.
		Decreasing to 152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)	OFF	Does not exist.
Medium- pressure side*	③ - ④	Increasing to 1,422 - 1,618 (14.5 - 16.5, 206 - 235)	ON	Exists.
		Decreasing to 1,128 - 1,422 (11.5 - 13.5, 164 - 192)	OFF	Does not exist.
High-pres- sure side	① - ②	Decreasing to 1,275 - 1,863 (13 - 19, 185 - 270)	ON	Exists
		Increasing to 2,648 - 2,844 (27 - 29, 384 - 412)	OFF	Does not exist.

\* For cooling fan motor operation.

### Air conditioner relay

Check circuit continuity between terminals by supplying 12 volts to coil side terminals of air conditioner relay.





# TROUBLE DIAGNOSES

## Air Mix Door

**SYMPTOM: Air mix door does not change.**

### INSPECTION FLOW




### CONTROL LINKAGE ADJUSTMENT

#### Temperature control cable

1. Move temperature control knob to full hot position.
2. Unclamp temperature control cable.
3. Move air mix door lever rearward, to full hot position.
4. Install the clamp.

**After positioning control cable, check for proper operation.**



#### Water valve control rod


1. Remove heater unit, refer to HA-72.
2. Push air mix door in the direction of arrow.
3. Pull control rod in the direction of the arrow to a clearance of about 2 mm (0.08 in) between ends of rod and link lever. Connect the rod to door lever.

**After connecting the control rod, move the air mix door by hand and check for proper operation.**



## Trouble Diagnosis For Insufficient Cooling


### INSPECTION FLOW



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 FA  
 RA  
 BR  
 ST  
 RS  
 BT  
**HA**  
 EL  
 IDX

## Performance Test Diagnoses


### INSUFFICIENT COOLING



Note: **A-F** correspond to those in Trouble Diagnoses for Abnormal Pressure. Refer to HA-53.

# TROUBLE DIAGNOSES

## Performance Test Diagnoses (Cont'd)



# TROUBLE DIAGNOSES

## Performance Chart

### TEST CONDITION

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well ventilated place)

Doors: Closed

Door window: Open

Hood: Open

TEMP. setting: Max. COLD

Discharge Air: Face Vent

REC switch: (Recirculation) set

Fan speed: High speed

A/C switch: ON

Engine speed: 1,500 rpm

Operate the air conditioner system for 10 minutes before taking measurements.

### TEST READING

#### Recirculating-to-discharge air temperature table

Inside air at blower assembly inlet for recirculation*		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	20 (68)	4.0 - 5.4 (39 - 42)
	25 (77)	4.2 - 5.6 (40 - 42)
	30 (86)	8.5 - 11.1 (47 - 52)
	35 (95)	13.5 - 16.7 (56 - 62)
	40 (104)	18.5 - 22.3 (65 - 72)
60 - 70	20 (68)	5.4 - 6.8 (42 - 44)
	25 (77)	5.6 - 8.0 (42 - 46)
	30 (86)	11.1 - 14.1 (52 - 57)
	35 (95)	16.7 - 20.3 (62 - 69)
	40 (104)	22.3 - 26.5 (72 - 80)

\* Thermometer should be placed at intake unit RH side of instrument panel.

#### Ambient air temperature-to-operating pressure table


Ambient air		High-pressure (Discharge side) kPa (kg/cm <sup>2</sup> , psi)	Low-pressure (Suction side) kPa (kg/cm <sup>2</sup> , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	834 - 1,098 (8.5 - 11.2, 121 - 159)	122.6 - 161.8 (1.25 - 1.65, 17.8 - 23.5)
	25 (77)	1,049 - 1,363 (10.7 - 13.9, 152 - 198)	137.3 - 181.4 (1.4 - 1.85, 19.9 - 26.3)
	30 (86)	1,226 - 1,618 (12.5 - 16.5, 178 - 235)	152.0 - 201.0 (1.55 - 2.05, 22.0 - 29.2)
	35 (95)	1,255 - 1,716 (12.8 - 17.5, 182 - 249)	166.7 - 230.5 (1.7 - 2.35, 24.2 - 33.4)
	40 (104)	1,540 - 2,030 (15.7 - 20.7, 223 - 294)	201.0 - 289.3 (2.05 - 2.95, 29.2 - 41.9)

If pressure is not within range, refer to HA-56 "Trouble Diagnoses for Abnormal Pressure".

## Trouble Diagnoses for Abnormal Pressure




Whenever system's high or low-side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following table indicates the standard normal pressure range. Since the standard normal pressure differs from vehicle to vehicle, refer to HA-52 "Ambient air temperature-to-operating pressure table".

**Pressure measurements are effective only when ambient temperature is in the range indicated under the Performance Chart.**

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high and low-pressure sides are too high.</p> <p><b>A</b></p>  <p style="text-align: right;">AC359A</p>	<ul style="list-style-type: none"> <li>● Pressure is reduced soon after water is splashed on condenser.</li> </ul>	<p>Excessive refrigerant charge in refrigeration cycle.</p>	<p>Reduce refrigerant until specified pressure is obtained.</p>
	<p>Air suction by radiator or cooling fan is insufficient.</p>	<p>Insufficient condenser cooling performance.</p> <p style="text-align: center;">↓</p> <p>① Condenser fins are clogged. ② Improper rotation of cooling fan.</p>	<ul style="list-style-type: none"> <li>● Clean condenser.</li> <li>● Check and repair radiator or cooling fan as necessary.</li> </ul>
	<ul style="list-style-type: none"> <li>● Low-pressure pipe is not cold.</li> <li>● When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm<sup>2</sup>, 28 psi). It then decreases gradually thereafter.</li> </ul>	<p>Poor heat exchange in condenser. (After compressor operation stops, high-pressure decreases too slowly.)</p> <p style="text-align: center;">↓</p> <p>Air in refrigeration cycle.</p>	<p>Evacuate repeatedly and recharge system.</p>
	<p>Engine tends to overheat.</p>	<p>Engine cooling systems malfunction.</p>	<p>Check and repair each engine cooling system.</p>
	<ul style="list-style-type: none"> <li>● An area of the low-pressure pipe is colder than near the evaporator outlet.</li> <li>● Plates are sometimes covered with frost.</li> </ul>	<ul style="list-style-type: none"> <li>● Excessive liquid refrigerant on low-pressure side.</li> <li>● Excessive refrigerant discharge flow.</li> <li>● Expansion valve is open a little compared with the specification.</li> </ul> <p style="text-align: center;">↓</p> <p>① Improper thermal valve installation. ② Improper expansion valve adjustment.</p>	<p>Replace expansion valve.</p>



# TROUBLE DIAGNOSES

## Trouble Diagnoses for Abnormal Pressure (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p> <p><b>B</b></p>  <p style="text-align: center;">AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not as hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> <li>● Check and repair or replace malfunctioning parts.</li> <li>● Check lubricant for contamination.</li> </ul>
<p>High-pressure side is too low and low-pressure side is too high.</p> <p><b>C</b></p>  <p style="text-align: center;">AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings.</p>	<p>Replace compressor.</p>
	<p>No temperature difference between high and low-pressure sides.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings.</p>	<p>Replace compressor.</p>
<p>Both high and low-pressure sides are too low.</p> <p><b>D</b></p>  <p style="text-align: center;">AC353A</p>	<ul style="list-style-type: none"> <li>● There is a big temperature difference between liquid tank outlet and inlet. Outlet temperature is extremely low.</li> <li>● Liquid tank inlet and expansion valve are frosted.</li> </ul>	<p>Liquid tank is partly clogged.</p>	<ul style="list-style-type: none"> <li>● Replace liquid tank.</li> <li>● Check lubricant for contamination.</li> </ul>
	<ul style="list-style-type: none"> <li>● Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank.</li> <li>● Expansion valve inlet may be frosted.</li> <li>● Temperature difference occurs somewhere in high-pressure side.</li> </ul>	<p>High-pressure pipe located between liquid tank and expansion valve is clogged.</p>	<ul style="list-style-type: none"> <li>● Check and repair malfunctioning parts.</li> <li>● Check lubricant for contamination.</li> </ul>
	<ul style="list-style-type: none"> <li>● Expansion valve and liquid tank are warm or only cool to the touch.</li> </ul>	<p>Low refrigerant charge.</p> <p style="text-align: center;">↓</p> <p>Leaking fittings or components.</p>	<ul style="list-style-type: none"> <li>● Check for refrigerant leaks. Refer to "Checking Refrigerant Leaks", HA-59.</li> </ul>

# TROUBLE DIAGNOSES

## Trouble Diagnoses for Abnormal Pressure (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high and low-pressure sides are too low.</p> <p><b>D</b></p>  <p style="text-align: center;">AC353A</p>	<p>There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.</p>	<p>Expansion valve closed and past the specification.</p> <p style="text-align: center;">↓</p> <p>① Improper expansion valve adjustment.</p> <p>② Malfunctioning thermal valve.</p> <p>③ Outlet and inlet may be clogged.</p>	<ul style="list-style-type: none"> <li>● Remove foreign particles by using compressed air.</li> <li>● Check lubricant for contamination.</li> </ul>
	<p>An area of low-pressure pipe is colder than areas near the evaporator outlet.</p>	<p>Low-pressure pipe is clogged or crushed.</p>	<ul style="list-style-type: none"> <li>● Check and repair malfunctioning parts.</li> <li>● Check lubricant for contamination.</li> </ul>
	<p>Air flow volume is not enough or is too low.</p>	<p>Evaporator is frozen.</p>	<p>Check thermo control amp., if OK replace compressor.</p>
<p>Low-pressure side sometimes becomes negative.</p> <p><b>E</b></p>  <p style="text-align: center;">AC354A</p>	<ul style="list-style-type: none"> <li>● Air conditioner system does not function and does not cyclically cool the compartment air.</li> <li>● The system constantly functions for a certain period of time after compressor is stopped and restarted.</li> </ul>	<p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> <li>● Replace refrigerant.</li> <li>● Replace liquid tank.</li> </ul>

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


**HA**

EL

IDX

# TROUBLE DIAGNOSES

## Trouble Diagnoses for Abnormal Pressure (Cont'd)


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p><b>F</b></p>  <p style="text-align: right;">AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> <li>● If water is the cause, initial cooling is okay. Then the water freezes causing a blockage.</li> <li>● Replace refrigerant.</li> <li>● If due to foreign particles, remove expansion valve and remove particles with dry, compressed air (not shop air).</li> <li>● If either of the above methods cannot correct the problem, replace expansion valve.</li> <li>● Replace liquid tank.</li> <li>● Check lubricant for contamination.</li> </ul>



# TROUBLE DIAGNOSES

## Trouble Diagnosis for Insufficient Heating

### INSPECTION FLOW




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# TROUBLE DIAGNOSES

## Trouble Diagnosis for Noise

### INSPECTION FLOW



## Checking Refrigerant Leaks


### PRELIMINARY CHECK

Perform a visual inspection of all refrigeration parts, fittings, hoses, and components for signs of A/C lubricant leakage, damage and corrosion. Take note of the areas with A/C lubricant leakage and allow for extra time in these areas with an electronic leak detector.

GI

MA

EM



AHA281A

### PRECAUTIONS FOR HANDLING LEAK DETECTOR

When performing a refrigerant leak check, use a J-41995 A/C leak detector or equivalent. Ensure that the instrument is calibrated and set properly per the operating instructions.

The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.

Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and lubricants, may falsely trigger the leak detector. Make sure the surfaces, to be checked, are clean. Clean with a dry cloth or blow off with shop air. Do not allow the sensor tip of the detector to come into contact with any substance. This can also cause false readings and may damage the detector.

LC

EC

FE

CL


MT

1. Position probe approximately 5 mm (3/16 in) away from point to be checked.

AT

FA

RA




AHA185A

2. When testing, circle each fitting completely with probe.

BR

ST

RS




SHA706E

BT

3. Move probe along component approximately 25-50 mm/sec. (1-2 in./sec).

HA

EL



AHA597

IDX

## SERVICE PROCEDURES

### Checking Refrigerant Leaks (Cont'd)

#### CHECKING PROCEDURE

To prevent inaccurate or false readings, make sure there is no refrigerant vapor, shop chemicals or smoke in the vicinity of the vehicle. Perform the leak test in a calm area (low air/wind movement) so that the leaking refrigerant is not dispersed.

1. Turn engine off.
2. Connect a suitable A/C manifold gauge set to the A/C service ports.
3. Check if the A/C refrigerant pressure is at least 345 kPa (50 psi) above 16°C (60°F). If less than specification, recover/evacuate and recharge the system with the specified amount of refrigerant.

NOTE: At temperatures below 16°C (60°F), leaks may not be detected since the system may not reach 345 kPa (50 psi).

4. Conduct the leak test from the high side (compressor discharge **a**) to evaporator inlet **i**) to the low side (evaporator drain hose **h**) to compressor suction **k**). Refer to HA-66. Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detector probe completely around the connection/component.

- **Compressor**

Check the fittings of high and low-pressure hoses, relief valve, and shaft seal.

- **Liquid tank**

Check the pressure switch, tube fitting, weld seams and the fusible plug mounts.

- **Service valves**

Check all around the service valves. Ensure service valve caps are secured on the service valves (to prevent leaks).

NOTE: After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any false readings by leak detector.

- **Cooling unit (Evaporator)**


With engine off, turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Wait a minimum of 10 minutes accumulation time (refer to the manufacturer's recommended procedure for actual wait time) before inserting the leak detector probe into the drain hose. (Keep the probe inserted for at least ten seconds.)

Use caution not to contaminate the probe tip with water or dirt that may be in the drain hose.

5. If the leak detector detects a leak, verify at least once by blowing compressed air into area of suspected leak, then repeat check as outlined above.
6. Do not stop when one leak is found. Continue to check for additional leaks at all system components.  
If no leaks are found, perform steps 7 through 10.
7. Start engine.
8. Set the heater A/C control as follows:
  - a. A/C switch ON
  - b. Face mode
  - c. Recirculation switch ON
  - d. Max cold temperature
  - e. Fan speed high
9. Run engine at 1500 rpm for at least 2 minutes.
10. Turn engine off and perform leak check again following steps 4 through 6 above.

# SERVICE PROCEDURES

## Checking Refrigerant Leaks (Cont'd)



Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector at the compressor. The pressure on the high pressure side will gradually drop after refrigerant circulation stops, and pressure in the low pressure side will gradually rise, as shown on the graph. Some leaks are more easily detected when pressure is high.

11. Before connecting ACR4 to vehicle, check ACR4 gauges. No refrigerant pressure should be displayed. If pressure is displayed, recover refrigerant from equipment lines and then check refrigerant purity.
12. Confirm refrigerant purity in supply tank using ACR4 and refrigerant identifier.
13. Confirm refrigerant purity in vehicle A/C system using ACR4 and refrigerant identifier.
14. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component as necessary.
15. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
16. Conduct A/C performance test to ensure system works properly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX


# SERVICE PROCEDURES

## R-134a Service Procedure


### DISCHARGING REFRIGERANT

#### WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment) or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.




### EVACUATING SYSTEM AND CHARGING REFRIGERANT



# SERVICE PROCEDURES

## R-134a Service Procedure (Cont'd)



Note: \*1 Before charging refrigerant, ensure engine is OFF.

\*2 Before checking for leaks, start engine to activate air conditioner system then turn engine OFF. Service valve caps must be installed to prevent leakage.

## Compressor Lubricant Quantity

The lubricant used to lubricate the compressor circulates through the system with the refrigerant. Whenever any A/C component is replaced or gas leakage occurs, lubricant must be added.

If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)


### LUBRICANT

**Name: Nissan A/C System Lubricant Type R**

**Part No.: KLH00-PAGR0**

### CHECKING AND ADJUSTING

Adjust the lubricant quantity according to the flowchart shown below.






# SERVICE PROCEDURES

## Compressor Lubricant Quantity (Cont'd)

A

1. Before connecting ACR4 to vehicle, check ACR4 gauges. No refrigerant pressure should be displayed. If pressure is displayed, recover refrigerant from equipment lines and then check refrigerant purity.
2. Confirm refrigerant purity in supply tank using ACR4 and refrigerant identifier.
3. Confirm refrigerant purity in vehicle A/C system using ACR4 and refrigerant identifier.
4. Discharge refrigerant into refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
5. Drain the lubricant from the old (removed) compressor into a graduated container and record the amount of lubricant drained.
6. Drain the lubricant from the new compressor into a separate, clean container.
7. Measure an amount of new lubricant equal to amount drained from old compressor. Add this lubricant to new compressor through the suction port opening.
8. Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to new compressor through the suction port opening.
9. If the liquid tank also needs to be replaced, add an additional 5 ml (0.2 US fl oz, 0.2 Imp fl oz) of lubricant at this time.  
**Do not add this 5 ml (0.2 US fl oz, 0.2 Imp fl oz) of lubricant if only replacing the compressor.**


### Lubricant adjusting procedure for compressor replacement




## Refrigerant Lines

- Refer to HA-4.

SEC. 214-271-274-276



**Compressor Mounting**



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
FA

**Belt Tension**

- Refer to MA section (“Checking Drive Belts”, “ENGINE MAINTENANCE”).

RA

**Fast Idle Control Device (FICD)**

- Refer to EC section (“IACV-FICD Solenoid Valve”, “TROUBLE DIAGNOSIS FOR NON-DETECTIVE ITEMS”).

BR

ST

RS

BT


**HA**

EL

IDX

## Compressor

SEC. 274




AHA471


## Compressor Clutch

### REMOVAL

- When removing center bolt, hold clutch disc with clutch disc wrench.



AHA389




RHA124F


- Remove the drive plate using the clutch disc puller. Insert holder's three pins into the drive plate. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the drive plate. While tightening the center bolt, insert a round bar (screwdriver, etc.) between two of the pins (as shown in the figure) to prevent drive plate rotation. After removing the drive plate, remove the shims from either the drive shaft or the drive plate.

# SERVICE PROCEDURES

## Compressor Clutch (Cont'd)



- Remove the snap ring using external snap ring pliers.





- Pulley removal  
Use a commercially available pulley puller. Position the center of the puller on the end of the drive shaft. Remove the pulley assembly with the puller.

### For Pressed Pulleys:

To prevent deformation of the pulley groove, the puller claws should be hooked under (not into) the pulley groove.

- Remove the field coil harness clip using a screwdriver.
- Remove the three field coil fixing screws and remove the field coil.



## INSPECTION

### Clutch disc

If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

### Pulley

Check the appearance of the pulley assembly. If contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

### Coil

Check coil for loose connection or cracked insulation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX


# SERVICE PROCEDURES

## Compressor Clutch (Cont'd)


### INSTALLATION




- Install the field coil.
- **Be sure to align the coil's pin with the hole in the compressor's front head.**
- Install the field coil harness clip using a screwdriver.



- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



- Install the drive plate on the drive shaft, together with the original shim(s). Press the drive plate down by hand.



- Using the holder to prevent drive plate rotation, tighten the bolt to 12 to 15 N·m (1.2 to 1.5 kg·m, 9 to 11 ft·lb) torque.
- **After tightening the bolt, check that the pulley rotates smoothly.**

# SERVICE PROCEDURES

## Compressor Clutch (Cont'd)

- Check clearance all the way around the clutch disc.



### Disc-to-pulley clearance:

**0.3 - 0.6 mm (0.012 - 0.024 in)**

If the specified clearance is not obtained, replace adjusting spacer and recheck.

## BREAK-IN OPERATION

When replacing compressor clutch assembly, always conduct the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.



## Thermal Protector

### INSPECTION

- When servicing, do not allow foreign matter to get into compressor.
- Check continuity between two terminals.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

## Heater Unit (Heater Core)



AHA033A

### REMOVAL

1. Drain the cooling system. Refer to MA section, ("Changing Engine Coolant").
2. Disconnect the two heater hoses from inside the engine compartment.
3. Remove the cooling unit. Refer to HA-73.
4. Remove the steering member assembly. Refer to BT section ("Instrument Panel").
5. Remove the heater unit.
6. Remove the heater core.


### INSTALLATION

Installation is basically the reverse order of removal.

**When filling radiator with coolant, refer to MA section ("Changing Engine Coolant").**



## Cooling Unit (A/C Evaporator)



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX




### REMOVAL

1. Discharge the A/C system. Refer to HA-62.
2. Disconnect the two refrigerant lines from the engine compartment.
  - Cap the A/C lines to prevent moisture from entering the system.
3. Remove the glove box and mating trim. Refer to BT section ("Instrument Panel").
4. Disconnect the thermal amp. connector.
5. Remove the cooling unit.
6. Separate the cooling unit case, and remove the evaporator.

### INSTALLATION

Installation is basically the reverse order of removal.  
**Recharge the A/C system. Refer to HA-62.**



## Blower Case and Motor

### REMOVAL


1. Remove the glove box and mating trim. Refer to BT section ("Instrument Panel").
2. Remove the cooling unit. Refer to HA-73.
3. Disconnect the fan motor resistor.
4. Disconnect the fan motor.
5. Remove the blower case and motor.
6. Remove the three bolts and remove the motor from the blower case.

### INSTALLATION


Installation is basically the reverse order of removal.

**Recharge the A/C system. Refer to HA-62.**

## Fan Switch and Illumination Bulbs



AHA037A




AHA038A

### REMOVAL


1. Remove A/C & Heat control. Refer to BT section ("Instrument Panel").
2. Remove fan control knob and temperature control knob.

**Wrap knobs with a cloth and pull in direction as shown at left. Be careful not to scratch knob during removal.**



AHA039A

3. Remove fan switch by lifting tabs with a small, flat-bladed screwdriver.



AHA040A

4. Twist illumination bulbs counterclockwise and lift out.

### INSTALLATION

Installation is the reverse order of removal.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

# SERVICE DATA AND SPECIFICATIONS (SDS)

## General Specifications

### COMPRESSOR

Model	DKV-14C
Type	Vane rotary
Displacement    cm <sup>3</sup> (cu in)/Rev	140 (8.54)
Direction of rotation	Clockwise (Viewed from drive end)
Drive belt	Poly V type

### LUBRICANT

Model	ZEXEL make DKV-14C
Name	Nissan A/C System Lubricant Type R
Part No.	KLH00-PAGR0
Capacity    ml (US fl oz, Imp fl oz)	
Total in system	200 (6.8, 7.0)
Compressor (Service part) charging amount	200 (6.8, 7.0)

### REFRIGERANT

Type	R-134a
Capacity	kg (lb)    0.70 - 0.80 (1.54 - 1.76) g (oz)    700 - 800 (24.69 - 28.22)

## Inspection and Adjustment

### ENGINE IDLING SPEED

When A/C is ON

- Refer to EC section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS").

### BELT TENSION

- Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").

### COMPRESSOR CLUTCH

Model	DKV-14C
Clutch disc-pulley clearance mm (in)	0.3 - 0.6 (0.012 - 0.024)