

LT
SECTION
LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
LT
L
M

CONTENTS

PRECAUTIONS 4	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 4	
General precautions for service operations 4	
Wiring Diagrams and Trouble Diagnosis 4	
HEADLAMP (FOR USA) 5	
Component Parts and Harness Connector Location... 5	
System Description 5	
OUTLINE 5	
BATTERY SAVER CONTROL 6	
AUTO LIGHT OPERATION 6	
VEHICLE SECURITY SYSTEM 6	
XENON HEADLAMP (IF EQUIPPED) 6	
CAN Communication System Description 7	
FOR TCS MODELS 7	
FOR A/T MODELS 8	
FOR M/T MODELS 10	
Wiring Diagram — H/LAMP — 12	
HALOGEN 12	
XENON 14	
Terminals and Reference Value for BCM 16	
CONSULT-II Function 16	
CONSULT-II BASIC OPERATION 16	
DATA MONITOR 17	
ACTIVE TEST 18	
Headlamp HI Does Not Illuminate (Both Sides) ... 18	
Headlamp HI Does Not Illuminate (One Side) 20	
High-Beam Indicator Lamp Does Not Illuminate ... 20	
Headlamp LO Does Not Illuminate (Both Sides) ... 20	
Headlamp LO Does Not Illuminate (One Side) 21	
Headlamps Do Not Turn OFF 22	
One Xenon Headlamp Does Not Illuminate At Full Brightness 23	
One Xenon Headlamp Flickers 23	
Aiming Adjustment 23	
LOW BEAM AND HIGH BEAM 24	
Bulb Replacement 24	
HEADLAMP (OUTER SIDE), FOR LOW BEAM (XENON) 24	
HEADLAMP (OUTER SIDE), FOR LOW BEAM (HALOGEN) 24	
HEADLAMP (INNER SIDE), FOR HIGH BEAM.. 25	
FRONT TURN SIGNAL LAMP 25	
Removal and Installation 25	
REMOVAL 25	
INSTALLATION 25	
Disassembly and Assembly 26	
DISASSEMBLY 26	
ASSEMBLY 27	
HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM - 28	
Component Parts and Harness Connector Location.. 28	
System Description 28	
HEADLAMP OPERATION 29	
BATTERY SAVER CONTROL 30	
AUTO LIGHT OPERATION 30	
DAYTIME LIGHT OPERATION 30	
XENON HEADLAMP (IF EQUIPPED) 30	
OPERATION 30	
CAN Communication System Description 31	
FOR TCS MODELS 31	
FOR A/T MODELS 32	
FOR M/T MODELS 34	
Schematic 36	
HALOGEN 36	
XENON 37	
Wiring Diagram — DTRL — 38	
HALOGEN 38	
XENON 41	
Terminals and Reference Value for Daytime Light Control Unit 44	
Aiming Adjustment 45	
Bulb Replacement 45	
Removal and Installation 45	
Disassembly and Assembly 45	
AUTO LIGHT SYSTEM 46	
Component Parts and Harness Connector Location.. 46	
System Description 46	
OUTLINE 46	

BATTERY SAVER CONTROL	47	Turn Signal Lamp Does Not Operate	92
SHUT OFF DELAY	47	Hazard Lamp Does Not Operate	93
CAN Communication System Description	47	Turn Signal Indicator Lamp Does Not Operate	95
FOR TCS MODELS	47	Bulb Replacement	95
FOR A/T MODELS	48	FRONT TURN SIGNAL LAMP	95
FOR M/T MODELS	50	REAR TURN SIGNAL LAMP	95
Major Components and Functions	51	Removal and Installation	95
Schematic	52	FRONT TURN SIGNAL LAMP	95
HALOGEN (WITH DAYTIME LIGHT SYSTEM)...	52	REAR TURN SIGNAL LAMP	95
XENON (WITH DAYTIME LIGHT SYSTEM)	53	LIGHTING AND TURN SIGNAL SWITCH	96
Wiring Diagram — AUTO/L —	54	Removal and Installation	96
HALOGEN (USA)	54	Switch Circuit Inspection	96
XENON (USA)	56	HAZARD SWITCH	97
HALOGEN (CANADA)	58	Removal and Installation	97
XENON (CANADA)	61	COMBINATION SWITCH	98
Terminals and Reference Value for BCM	64	Combination Switch Reading Function	98
How to Proceed With Trouble Diagnosis	64	CONSULT-II Function	98
Inspection Before Diagnosis	64	CONSULT-II BASIC OPERATION	98
SETTING CHANGE FUNCTIONS	64	DATA MONITOR	98
BCM POWER/GROUND CIRCUIT INSPEC-		Removal and Installation	99
TION	64	Switch Circuit Inspection	99
CONSULT-II Function	65	STOP LAMP	100
CONSULT-II BASIC OPERATION	65	Wiring Diagram — STOP/L —	100
WORK SUPPORT	66	Bulb Replacement for High-mounted Stop Lamp ..	102
DATA MONITOR	67	WITH REAR SPOILER	102
ACTIVE TEST	68	WITHOUT REAR SPOILER	102
Trouble Diagnosis Chart by Symptom	68	Bulb Replacement for Rear Combination Lamp ..	102
Light Switch Inspection	68	Removal and Installation for High-mounted Stop	
Auto Light Sensor System Inspection	69	Lamp	102
FRONT FOG LAMP	71	WITH REAR SPOILER	102
System Description	71	WITHOUT SPOILER	102
OUTLINE	71	Removal and Installation for Rear Combination	
BATTERY SAVER CONTROL	71	Lamp	102
CAN Communication System Description	71	STEP LAMP	103
FOR TCS MODELS	72	System Description	103
FOR A/T MODELS	73	Wiring Diagram — STEP/L —	104
FOR M/T MODELS	74	Terminals and Reference Value for BCM	105
Wiring Diagram — F/FOG —	76	Step Lamp Does Not Operate	105
Front Fog Lamps Do Not Illuminate (Both Sides) ...	77	Bulb Replacement	106
Front Fog Lamp Does Not Illuminate (One Side) ...	78	Removal and Installation	106
Aiming Adjustment	78	BACK-UP LAMP	107
Removal and Installation	79	Wiring Diagram — BACK/L —	107
TURN SIGNAL AND HAZARD WARNING LAMPS..	80	Bulb Replacement	108
System Description	80	Removal and Installation	108
TURN SIGNAL OPERATION	80	PARKING, LICENSE PLATE AND TAIL LAMPS ...	109
HAZARD LAMP OPERATION	80	System Description	109
REMOTE KEYLESS ENTRY SYSTEM OPERA-		OPERATION BY LIGHTING SWITCH	109
TION	81	BATTERY SAVER CONTROL	110
CAN Communication System Description	81	CAN Communication System Description	110
FOR TCS MODELS	82	FOR TCS MODELS	110
FOR A/T MODELS	83	FOR A/T MODELS	111
FOR M/T MODELS	84	FOR M/T MODELS	113
Schematic	86	Schematic	115
Wiring Diagram — TURN —	87	Wiring Diagram — TAIL/L —	116
Terminals and Reference Value for BCM	90	Parking, License Plate and Tail Lamps Do Not Illu-	
CONSULT-II Function	90	minate	119
CONSULT-II BASIC OPERATION	91	Parking, License Plate and Tail Lamps Do Not Turn	
DATA MONITOR	91	OFF (After Approx. 10 Minutes)	121
ACTIVE TEST	92	Bulb Replacement	121

LICENSE PLATE LAMP	121	ILLUMINATION	131	
FRONT TURN SIGNAL (PARKING) LAMP	121	System Description	131	A
TAIL LAMP	121	ILLUMINATION OPERATION BY LIGHTING		
Removal and Installation	122	SWITCH	131	
LICENSE PLATE LAMP	122	BATTERY SAVER CONTROL	132	B
FRONT TURN SIGNAL (PARKING) LAMP	122	CAN Communication System Description	132	
REAR COMBINATION LAMP	122	FOR TCS MODELS	133	
INTERIOR ROOM LAMP	123	FOR A/T MODELS	134	C
System Description	123	FOR M/T MODELS	135	
INTERIOR LAMP TIMER OPERATION	123	Schematic	137	
BATTERY SAVER	123	Wiring Diagram — ILL —	138	D
Component Parts and Harness Connector Location	124	Removal and Installation	142	
Wiring Diagram — ROOM/L —	125	ILLUMINATION CONTROL SWITCH	142	
Terminals and Reference Value for BCM	126	GLOVE BOX LAMP	142	E
CONSULT-II Function	126	VANITY MIRROR AND TRUNK ROOM LAMPS ...	143	
CONSULT-II BASIC OPERATION	126	Wiring Diagram — INT/L —	143	
WORK SUPPORT	127	Bulb Replacement for Vanity Mirror Lamp	145	F
DATA MONITOR	127	Bulb Replacement, Removal and Installation for		
ACTIVE TEST	128	Trunk Room Lamp	145	
Interior Lamp Control Does Not Operate	128	BULB SPECIFICATIONS	146	G
Bulb Replacement	129	Headlamp	146	
MAP LAMP AND CONSOLE LAMP	129	Exterior Lamp	146	
PERSONAL LAMP	129	Interior Lamp/Illumination	146	H
Removal and Installation	130			
ROOM LAMP	130			I
IGNITION KEY HOLE ILLUMINATION LAMP	130			J

LT

L

M

PRECAUTIONS

PRECAUTIONS

PF0:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00400

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.



WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

General precautions for service operations

EKS0040P

- Never work with wet hands.
- The xenon headlamp system includes a high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, never touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector, and housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. (If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.)
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.



Wiring Diagrams and Trouble Diagnosis

EKS0040Q

When you read wiring diagrams, refer to the following:

- [GI-12. "How to Read Wiring Diagrams"](#)
- [PG-3. "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-10. "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25. "How to Perform Efficient Diagnosis for an Electrical Incident"](#)


HEADLAMP (FOR USA)

HEADLAMP (FOR USA)

PFP:26010

Component Parts and Harness Connector Location

EKS0040R



WKIA0054E

EKS0040S

System Description

Control of the headlamp system operation is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the 2ND position, the BCM receives input requesting the headlamps (and tail lamps) illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the headlamp high and headlamp low relay coils. When energized, these relays direct power to the respective headlamps, which then illuminate.

OUTLINE

Power is supplied at all times

- to headlamp high relay, located in the IPDM E/R (intelligent power distribution module engine room), and
- to headlamp low relay, located in the IPDM E/R (intelligent power distribution module engine room), and
- to BCM (body control module) terminal 7
- through 50A fusible link [letter f, located in the fuse and fusible link box].

With the ignition switch in the ON or START position, power is supplied

- to BCM (body control module) terminal 35
- through 10A fuse [No. 12, located in the fuse block (J/B)].

With the ignition switch in the ACC or ON position, power is supplied

- to BCM (body control module) terminal 36
- through 10A fuse [No. 6, located in the fuse block (J/B)].

Ground is supplied

HEADLAMP (FOR USA)

- to BCM (body control module) terminals 8, 27, and 63
- through body grounds M57, M61, E15, and E24.

Low Beam Operation

With the lighting switch in 2ND position, the BCM (body control module) receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the headlamp low relay coil. When energized, this relay directs power

- to 15A fuse [No. 50, located in the IPDM E/R]
- through terminal 27 of the IPDM E/R
- to terminal 1 of headlamp RH, and
- to 15A fuse [No. 49, located in the IPDM E/R]
- through terminal 21 of the IPDM E/R
- to terminal 1 of headlamp LH.

Ground is supplied at all times

- to terminal 2 of headlamp RH
- through body grounds E15 and E24, and
- to terminal 2 of headlamp LH
- through body grounds E15 and E24.

With power and ground supplied, low beam headlamps illuminate.

High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM (body control module) receives input requesting the headlamp high beams to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the headlamp high relay coil. When energized, this relay directs power

- to 10A fuse [No. 47, located in the IPDM]
- through terminal 24 of the IPDM
- to terminal 1 of headlamp RH, and
- to 10A fuse [No. 48, located in the IPDM]
- through terminal 22 of the IPDM
- to terminal 1 of headlamp LH.

Ground is supplied

- to terminal 2 of headlamp RH
- through body grounds E15 and E24, and
- to terminal 2 of headlamp LH
- through body grounds E15 and E24.

With power and ground supplied, the high beam headlamps and the HIGH BEAM indicator illuminate.

BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the headlamps are turned off.

AUTO LIGHT OPERATION

Refer to [LT-46, "System Description"](#) for auto light operation.

VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-87, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#).

XENON HEADLAMP (IF EQUIPPED)

The low beam headlamps may be equipped with xenon type bulbs. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a

HEADLAMP (FOR USA)

mixture of xenon (an inert gas) and certain other metal halides. In addition to added lighting power, electronic control of the power supply gives the headlamps stable quality and tone color. Following are some of the advantages of the xenon type headlamp.

- The light produced by the headlamps is a white color comparable to sunlight that is easy on the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- The light features a high relative spectral distribution at wavelengths to which the human eye is most sensitive. This means that even in the rain, more light is reflected back from the road surface toward the vehicle, for added visibility.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.


CAN Communication System Description

EKS0040T

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System diagram



LKIA0015E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R (R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T

HEADLAMP (FOR USA)

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R


HEADLAMP (FOR USA)

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R	
Fuel consumption monitor signal	T		R			A
A/T warning lamp signal		T	R			B
A/T position indicator signal	R	T	R	R(R range only)		B
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R				T	C
A/C compressor request signal	T				R	
Blower fan switch signal	R(QR25DE)			T		D
Cooling fan motor operation signal	R			T		
Cooling fan speed request signal	T				R	
Position lights request			R	T	R	E
Position lights status				R	T	
Low beam request				T	R	
Low beam status	R			R	T	F
High beam request			R	T	R	
High beam status	R			R	T	G
Front fog lights request				T	R	
Front fog light status				R	T	
OD cancel switch signal		R	T		R	H
Brake switch signal		R	T			
Vehicle speed signal	R		T			I
	R		T	R		
Oil pressure switch			R		T	
Sleep request1			R	T		J
Sleep request2				T	R	
N range switch signal		R	T			LT
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T	R	L
Tail lamp request			R	T	R	
Turn indicator signal			R	T		M
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R	T	
Wiper stop position signal				R	T	
Rear window defogger switch signal				T	R	
Rear window defogger control signal	R			R	T	

HEADLAMP (FOR USA)

FOR M/T MODELS

System diagram



LKIA0018E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R ^(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T

HEADLAMP (FOR USA)

Signals	ECM	COMBINATION METER	BCM	IPDM E/R	
Rear window defogger switch signal			T	R	A
Rear window defogger control signal	R		R	T	B

C

D

E

F

G

H

I

J

LT

L





M

HEADLAMP (FOR USA)







EKS0040U

Wiring Diagram — H/LAMP — HALOGEN

LT-H/LAMP-01



REFER TO THE FOLLOWING.
 M16 - JOINT CONNECTOR (J/C)





LKWA0019E

HEADLAMP (FOR USA)

LT-H/LAMP-02

— : DATA LINE





REFER TO THE FOLLOWING.
 E130 - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0020E

HEADLAMP (FOR USA)

XENON


LT-H/LAMP-03




HEADLAMP (FOR USA)

LT-H/LAMP-04

— : DATA LINE



PRECEDING PAGE



REFER TO THE FOLLOWING.
E130 - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0022E

HEADLAMP (FOR USA)

Terminals and Reference Value for BCM

EKS0040V

Terminal No.	Wire color	Item	Measuring condition		Voltage (Approx.)
			Ignition switch	Operation or condition	
7	W/B	Battery power supply	OFF	—	Battery voltage
8	B	Ground	—	—	—
27	B	Ground	—	—	—
35	G	Ignition power supply	ON	—	Battery voltage
36	PU	Ignition power supply	ACC	—	Battery voltage
38	W/R	Auto light sensor input	ON	Headlamps illuminate by auto light control	0V → 3V
40	R/B	Combination switch output 2	—	—	2V → 10V
41	R/G	Combination switch output 3	—	—	2V → 10V
42	R/Y	Combination switch output 4	—	—	2V → 10V
43	L	Combination switch output 5	—	—	2V → 10V
45	R	Auto light sensor power	—	Ignition switch OFF → ON	0V → 5V
47	R/W	Combination switch output 1	—	—	2V → 10V
48	G/W	Combination switch input 1	—	—	1.5V → 10V
49	G/B	Combination switch input 2	—	—	1.5V → 10V
50	G/R	Combination switch input 3	—	—	1.5V → 10V
51	G/Y	Combination switch input 4	—	—	1.5V → 10V
52	L/W	Combination switch input 5	—	—	1.5V → 10V
53	P	Auto light sensor ground	—	—	—
63	B	Ground	—	—	—
70	L	Communication signal (CAN-H)	—	—	1V → 3V
71	Y	Communication signal (CAN-L)	—	—	1V → 3V

CONSULT-II Function


EKS0040W

CONSULT-II has a display function for work support, self-diagnosis, data monitor, and active test for each part by combining data receiving and sending via the communication line from BCM.

BCM diagnosis part	Check item, diagnosis mode	Description
Headlamp	Work support	Changes the setting for each function.
	Data monitor	Displays BCM input data in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.


CONSULT-II BASIC OPERATION

1. With the ignition switch OFF, connect CONSULT-II to the vehicle-side data link connector, then turn ignition switch ON.
2. Touch "START".




HEADLAMP (FOR USA)

3. Touch "BCM" on "SELECT SYSTEM" screen.



4. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.



DATA MONITOR

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

Display Item List

Monitor item name "OPERATION OR UNIT"	Contents
IGN ON SW "ON/OFF"	"IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal is displayed.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
AUTO LIGHT SW ^{Note} "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
TAIL LAMP SW "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of light switch judged from lighting switch signal.
HEAD LAMP SW "ON/OFF"	Displays status (headlamp switch: ON/Others: OFF) of headlamp switch judged from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.

HEADLAMP (FOR USA)

Monitor item name "OPERATION OR UNIT"	Contents
FR FOG SW "ON/OFF"	Displays status (front fog switch: ON/Others: OFF) of front fog switch judged from lighting switch signal.
DOOR SW - DR "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR "ON/OFF"	Displays status of the rear doors as judged from the rear door switch signal. (Door is open: ON/Door is closed: OFF)
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
OPTICAL SENSOR [0 - 5V]	Displays "ambient light (close to 5V when light/close to 0V when dark)" judged from auto light sensor signal.

NOTE:

Vehicles without auto light system display this item, but cannot monitor it.

ACTIVE TEST

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

Display Item List

Test item	Display on CONSULT-II screen	Description
Tail light relay output	TAIL LAMP	Allows tail light relay to operate by switching ON-OFF at your option.
Headlamp relay output	HEAD LAMP (LOW)	Allows headlamp relay to operate by switching ON-OFF at your option.
Headlamp relay output	HEAD LAMP (HI)	Allows headlamp relay to operate by switching ON-OFF at your option.
Front fog lamp relay output	FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF at your option.

Headlamp HI Does Not Illuminate (Both Sides)

EKS0040X

1. INSPECTION 1 BETWEEN IPDM E/R AND HEADLAMPS

1. Start active test. Refer to [LT-18. "ACTIVE TEST"](#).
2. Check operation of HI headlamps.

OK or NG


- OK >> GO TO 4.
 NG >> GO TO 2.

HEADLAMP (FOR USA)

2. INSPECTION 2 BETWEEN IPDM E/R AND HEADLAMPS

1. Disconnect IPDM E/R connector and left/right headlamp connectors.
2. Check continuity between harness connector terminals of IPDM E/R and connector terminals of left/right headlamps.

Terminals					Continuity
IPDM E/R		Headlamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E124	24 (L/W)	Right	E110	1 (L/W)	Yes
	22 (G)	Left	E11	1 (G)	



OK or NG


OK >> Connect electrical connectors. GO TO 3.

NG >> Check for short circuit or open circuit in harness between IPDM E/R and right/left headlamps. Repair as necessary.

3. IPDM E/R INSPECTION

Start active test. Refer to [LT-18, "ACTIVE TEST"](#). When headlamp HI is operating, check voltage between connector terminals left/right headlamps and body ground.

Terminals				Voltage (Approx.)
Headlamp			Body ground (-)	
Connector		Terminal (wire color)		12
Right	E110	1 (L/W)		
Left	E11	1 (G)		



OK or NG

OK >> Check headlamp bulbs and replace as necessary.

NG >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#).

4. INSPECTION 1 BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II. Carry out "BCM C/U" self-diagnosis.

Displayed results of self-diagnosis

No malfunction detected>> GO TO 5.

CAN communications or CAN system>> Inspect the BCM CAN communications system. Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

OPEN DETECT 1 - 5>> Combination switch system malfunction. Refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#).

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	

LKIA0073E

HEADLAMP (FOR USA)

5. INSPECTION 2 BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II. With "HEADLAMP" data monitor, check that "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

OK or NG

- OK >> Replace BCM.
- NG >> Replace lighting switch. Refer to [LT-96, "Removal and Installation"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
ACC ON SW	ON
AUTO LIGHT SW	OFF
TAIL LAMP SW	OFF
HEAD LAMP SW	OFF
HI BEAM SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF

LKIA0074E

Headlamp HI Does Not Illuminate (One Side)

EKS0040Y

1. BULB INSPECTION

Inspect inoperative lamp bulb.


OK or NG

- OK >> GO TO 2.
- NG >> Replace headlamp bulb. Refer to [LT-25, "HEADLAMP \(INNER SIDE\), FOR HIGH BEAM"](#).

2. INSPECTION BETWEEN IPDM E/R AND HEADLAMPS

- Disconnect IPDM E/R connector and headlamp connector.
- Check continuity between harness connector terminals of IPDM E/R and harness connector terminals of inoperative headlamp.

IPDM E/R		Headlamp		Continuity
Connector	Terminal (wire color)	Connector	Terminal (wire color)	
E124	24 (L/W)	Right	E110	Yes
	22 (G)	Left	E11	



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#).
- NG >> Check for short circuits and open circuits in harness between IPDM E/R and headlamps. Repair as necessary.

High-Beam Indicator Lamp Does Not Illuminate

EKS0040Z

1. BULB INSPECTION

Inspect high-beam indicator lamp bulb.

OK or NG

- OK >> Replace combination meter. Refer to [DI-21, "Removal and Installation"](#).
- NG >> Replace indicator bulb.

Headlamp LO Does Not Illuminate (Both Sides)

EKS00410

1. CHECK IPDM E/R OUTPUT TO HEADLAMPS

- Start active test. Refer to [LT-18, "ACTIVE TEST"](#).
- Check operation of low beam headlamps.

OK or NG

- OK >> GO TO 2.
- NG >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#).

HEADLAMP (FOR USA)

2. PERFORM BCM SELF-TEST

Select BCM on CONSULT-II. Carry out "BCM C/U" self-diagnosis.

Displayed results of self-diagnosis

No malfunction detected>> GO TO 3.

CAN communications or CAN system>> Inspect the BCM CAN communications system. Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

OPEN DETECT 1 - 5>> Combination Switch System malfunction. Refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#).

HEAD LAMP 1 SW or HEAD LAMP 2 SW>> Replace lighting switch. Refer to [LT-96, "Removal and Installation"](#).

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	

LKIA0073E

3. CHECK COMBINATION SWITCH INPUTS TO BCM

Select BCM on CONSULT-II. With "HEADLAMP" data monitor, check that "HEAD LAMP SW" and "HEAD LAMP SW 2" turn ON-OFF with operation of lighting switch.

OK or NG

OK >> Replace BCM.

NG >> Replace lighting switch. Refer to [LT-96, "Removal and Installation"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
ACC ON SW	ON
AUTO LIGHT SW	OFF
TAIL LAMP SW	ON
HEAD LAMP SW	ON
HI BEAM SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF

LKIA0078E

Headlamp LO Does Not Illuminate (One Side)

1. CHECK POWER TO HEADLAMP


1. Disconnect inoperative headlamp connector.
2. Turn the low beam headlamps ON.
3. Check voltage between inoperative headlamp connector terminal and ground.

Terminals			Voltage
(+)		(-)	
Connector	Terminal		
Right	E107	1 (R/Y)	Ground
Left	E13	1 (L)	
			Yes

OK or NG

OK >> GO TO 2.

NG >> GO TO 4.



WKIA0285E

HEADLAMP (FOR USA)

2. CHECK HEADLAMP GROUND


1. Turn the low beam headlamps OFF.
2. Check continuity between inoperative headlamp connector terminal and ground.

Terminals				Continuity
(+)		(-)		
Connector	Terminal	Connector	Terminal	
Right	E107	2 (B)	Ground	Yes
Left	E13	2 (B)		

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit in harness between inoperative headlamp and ground.



3. HEADLAMP SUBHARNASS INSPECTION

1. Check the inoperative headlamp subharness for open or short circuits.

OK or NG

OK (with halogen headlamps)>> Replace headlamp bulb. Refer to [LT-24, "Bulb Replacement"](#).

OK (with xenon headlamps)>> Replace headlamp bulb. Refer to [LT-24, "Bulb Replacement"](#). Check operation of headlamp. If headlamp is still inoperative, replace ballast and check operation. If headlamp is still inoperative, replace igniter.

NG (with halogen headlamps)>> Repair open or short circuit in headlamp subharness.

NG (with xenon headlamps)>> Replace headlamp subharness.

4. CHECK CIRCUIT BETWEEN IPDM E/R AND INOPERATIVE HEADLAMP


1. Turn the low beam headlamps OFF.
2. Check continuity between inoperative headlamp connector terminal and IPDM E/R connector terminal.

Headlamp	Terminals				Continuity
	(+)		(-)		
	Connector	Terminal	Connector	Terminal	
Right	E107	1 (R/Y)	E124	27 (R/Y)	Yes
Left	E13	1 (L)	E124	21 (L)	

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#).

NG >> Repair open or short circuit between IPDM E/R and inoperative headlamp.



Headlamps Do Not Turn OFF

1. CHECK CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

- IPDM E/R detects CAN communication malfunction and activates fail-safe operation. Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) and inspect CAN system.

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#).

NG >> Repair or replace malfunctioning part.

EKS00412

HEADLAMP (FOR USA)

One Xenon Headlamp Does Not Illuminate At Full Brightness

EKS00413

1. COMPONENT INSPECTION

1. Check the inoperative headlamp subharness for open or short circuits.

OK or NG

- OK >> Replace headlamp bulb. Refer to [LT-24, "Bulb Replacement"](#) . Check operation of headlamp. If headlamp still does not illuminate at full brightness, replace ballast and check operation. If headlamp still does not illuminate at full brightness, replace igniter.
- NG >> Replace headlamp subharness.

One Xenon Headlamp Flickers

EKS00414

1. CHECK SYSTEM OPERATION

1. Turn the low beam headlamps ON and check operation.

NOTE:

Xenon headlamps may flicker momentarily when the headlamps are turned ON. This is normal and does not indicate a fault. Diagnosis of flickering headlamps should only be performed if the headlamps continue to flicker for more than 3 seconds after turning headlamps ON.

OK or NG

- OK >> System is operating correctly.
- NG >> GO TO 2.

2. COMPONENT INSPECTION


1. Check the inoperative headlamp subharness for open or short circuits.

OK or NG

- OK >> Replace ballast. Check operation of headlamp. If headlamp still flickers, replace igniter and check operation. If headlamp still flickers, replace headlamp bulb. Refer to [LT-24, "Bulb Replacement"](#) .
- NG >> Replace headlamp subharness.

Aiming Adjustment

EKS00415



For details, refer to the regulations in your state.

Before performing aiming adjustment, check the following.


1. Ensure all tires are inflated to correct pressure.
2. Place vehicle on flat surface.

HEADLAMP (FOR USA)

3. Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant and engine oil filled to correct level, and fuel tank full.

LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam on.
2. Use adjusting screws to perform aiming adjustment.
 - **First loosen the adjusting screw all the way and then make adjustment by tightening the screw.**



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- **Basic illuminating area for adjustment should be within the range shown on the aiming chart. Adjust headlamps accordingly.**

Bulb Replacement HEADLAMP (OUTER SIDE), FOR LOW BEAM (XENON)

EKS00416

1. Disconnect negative battery cable.
2. Turn the plastic cap counterclockwise to unlock it from the headlamp.
3. Turn the bulb socket counterclockwise to unlock it.
4. Unlock the retaining spring and remove the bulb from the headlamp.
5. Install in reverse order of removal.

CAUTION:

After installing the bulb, be sure to install the plastic cap securely to ensure watertightness.

HEADLAMP (OUTER SIDE), FOR LOW BEAM (HALOGEN)

1. Disconnect negative battery cable.
2. Turn the plastic cap counterclockwise to unlock it from the headlamp.
3. Disconnect the electrical connectors from the bulb terminals.
4. Unlock the retaining spring and remove the bulb from the headlamp.
5. Install in reverse order of removal.

HEADLAMP (FOR USA)

CAUTION:

After installing the bulb, be sure to install the plastic cap securely to ensure watertightness.

HEADLAMP (INNER SIDE), FOR HIGH BEAM

1. Turn the bulb counterclockwise to remove it.
2. Installation is reverse order of removal.

FRONT TURN SIGNAL LAMP

1. Remove the headlamp. Refer to [LT-25, "Removal and Installation"](#).
2. Turn the bulb socket counterclockwise to unlock it.
3. Push and turn the bulb counterclockwise to remove it.
4. Installation is reverse order of removal.

Headlamp (outer side), for low beam (Halogen) : 12V 55W (H1)

Headlamp (outer side), for low beam (Xenon) : 12V 35W (D2R)

Headlamp (inner side), for high beam : 12V 60W (HB3)

Front turn signal lamp : 12V 27W/8W (amber)


CAUTION:

After installing the bulb, be sure to install the bulb socket securely to ensure watertightness.

Removal and Installation

REMOVAL

1. Remove the front fascia. Refer to [EI-13, "Removal and Installation"](#).
2. Ensure lighting switch is OFF.
3. Disconnect the negative battery cable.
4. Remove the headlamp mounting bolts.
5. Pull the headlamp toward the front of the vehicle, disconnect connectors, and remove from vehicle.



INSTALLATION

Install in the reverse order of removal.

Headlamp mounting bolts:

 : 4.4 - 6.4 N·m (0.45 - 0.65 kg·m, 39 - 56 in·lb)


HEADLAMP (FOR USA)

EKS00418

Disassembly and Assembly

DISASSEMBLY


Xenon



WKIA0283E

- | | | |
|--------------------------------|----------------------------------|-----------------------------|
| 1. Retaining springs | 2. Headlamp assembly | 3. Halogen bulb (high beam) |
| 4. Front turn signal lamp bulb | 5. Front turn signal bulb socket | 6. Ignitor |
| 7. Plastic cap | 8. Ballast | 9. Xenon bulb socket |
| 10. Xenon bulb (low beam) | 11. Aiming adjustment screw | |

Halogen



LKIA0052E

- | | | |
|--|----------------------------------|-----------------------------|
| 1. Retaining springs | 2. Headlamp assembly | 3. Halogen bulb (high beam) |
| 4. Front turn signal lamp bulb | 5. Front turn signal bulb socket | 6. Plastic cap |
| 7. Bulb terminal electrical connectors | 8. Halogen bulb (low beam) | 9. Aiming adjustment screw |

1. Turn the low beam plastic cap counterclockwise to unlock and remove it.
2. Turn the bulb socket counterclockwise to unlock and remove it (xenon).
3. Disconnect the electrical connectors from the bulb terminals (halogen).
4. Unlock the retaining springs and remove the low beam bulb.
5. Release the ignitor and remove from the plastic cap (xenon).

HEADLAMP (FOR USA)

6. Turn the high beam lamp socket counterclockwise to unlock and remove it.
7. Turn the front turn signal lamp bulb socket counterclockwise and unlock it.
8. Remove the front turn signal lamp bulb from its socket.

ASSEMBLY

Assemble in the reverse order of disassembly.

CAUTION:

- After installing the xenon bulb, be sure to install the bulb socket and plastic cap securely to ensure watertightness.

A

B

C

D

E

F

G

H

I

J

LT

L

M


HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

PF2:26010

Component Parts and Harness Connector Location

EKS00419



WKIA0079E

System Description

EKS0041A

The headlamp system for Canada vehicles is equipped with a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Battery saver system is controlled by the BCM.

Power is supplied at all times

- to headlamp high relay located in the IPDM E/R (intelligent power distribution module engine room).

Power is also supplied at all times

- to BCM (body control module) terminal 7
- through 50A fusible link [letter f , located in the fuse and fusible link box].

With the ignition switch in the ON or START position, power is supplied

- to daytime light control unit terminal 3
- through 10A fuse [No. 12, located in the fuse block (J/B)], and
- to BCM (body control module) terminal 35
- through 10A fuse [No. 12, located in the fuse block (J/B)].

With the ignition switch in the ACC or ON position, power is supplied

- to BCM (body control module) terminal 36
- through 10A fuse [No. 6, located in the fuse block (J/B)].

With the ignition switch in the START position, power is supplied

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

- to daytime light control unit terminal 2
- through 10A fuse [No. 9, located in the fuse block (J/B)].

Ground is supplied

- to daytime light control unit terminals 13, 14, and 16
- through body grounds E15 and E24, and
- to BCM (body control module) terminals 8, 27, and 63
- through body grounds M57, M61, E15, and E24.

HEADLAMP OPERATION

Low Beam Operation

With the lighting switch in 2ND position, the BCM (body control module) receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the headlamp low relay coil. When energized, this relay directs power

- to 15A fuse [No. 50, located in the IPDM E/R]
- through terminal 27 of the IPDM E/R
- to terminal 1 of headlamp RH, and
- to 15A fuse [No. 49, located in the IPDM E/R]
- through terminal 21 of the IPDM E/R
- to terminal 1 of headlamp LH.

Ground is supplied at all times

- to terminal 2 of headlamp RH
- through body grounds E15 and E24, and
- to terminal 2 of headlamp LH
- through body grounds E15 and E24.

With power and ground supplied, low beam headlamps illuminate.

High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM (body control module) receives input requesting the headlamp high beams to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the headlamp high relay coil. When energized, this relay directs power

- to 10A fuse [No. 47, located in the IPDM E/R]
- through terminal 24 of the IPDM E/R
- to terminal 4 of the daytime light control unit
- through terminal 7 of the daytime light control unit
- to terminal 1 of headlamp RH, and
- to 10A fuse [No. 48, located in the IPDM E/R]
- through terminal 22 of the IPDM E/R
- to terminal 5 of the daytime light control unit
- through terminal 6 of the daytime light control unit
- to terminal 1 of headlamp LH.

Ground is supplied

- to terminal 2 of headlamp RH
- to terminal 9 of the daytime light control unit
- through terminal 14 of the daytime light control unit
- through body grounds E15 and E24, and
- to terminal 2 of headlamp LH
- to terminal 10 of the daytime light control unit
- through terminals 13 of the daytime light control unit
- through body grounds E15 and E24.

A

B

C

D

E

F

G

H

I

J

LT

L

M

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

With power and ground supplied, the high beam headlamps and the HIGH BEAM indicator illuminate.

BATTERY SAVER CONTROL

With the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the headlamps are turned off.

AUTO LIGHT OPERATION

For auto light operation, refer to [LT-46, "System Description"](#).

DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal 7
- to terminal 1 of RH headlamp
- through terminal 2 of RH headlamp
- to daytime light control unit terminal 9
- through daytime light control unit terminal 6
- to terminal 1 of LH headlamp
- through terminal 2 of LH headlamp
- to daytime light control unit terminal 10.

Ground is supplied

- to daytime light control unit terminals 13, 14, and 16
- through body grounds E15 and E24.

Because the high beam headlamps are now wired in series, they operate at half illumination.

XENON HEADLAMP (IF EQUIPPED)

The low beam headlamps may be equipped with xenon type bulbs. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to added lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Following are some of the advantages of the xenon type headlamp.

- The light produced by the headlamps is a white color comparable to sunlight that is easy on the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- The light features a high relative spectral distribution at wavelengths to which the human eye is most sensitive. This means that even in the rain, more light is reflected back from the road surface toward the vehicle, for added visibility.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.

OPERATION

After starting the engine with the lighting switch in the "OFF" or 1ST position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		Hi	Lo	P	Hi	Lo	P	Hi	Lo	P	Hi	Lo	P	Hi	Lo	P	Hi	Lo	P
Headlamp	High beam	-	-	-	-	-	×	×	-	×	●*	●*	×	●*	●*	×	×	-	×
	Low beam	-	-	-	-	-	×	×	×	×	-	-	×	-	-	×	×	×	×
Tail lamp		-	-	-	×	×	×	×	×	×	-	-	-	×	×	×	×	×	×
License and instrument illumination lamp		-	-	-	×	×	×	×	×	×	-	-	-	×	×	×	×	×	×

- Hi: "HIGH BEAM" position
- Lo: "LOW BEAM" position

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

- P: "FLASH TO PASS" position
- x: Lamp "ON"
- -: Lamp "OFF"
- ●: Lamp dims. (Added functions)
- *: When starting the engine with the parking brake released, the daytime lights will operate.
When starting the engine with the parking brake pulled, the daytime lights will not operate.


CAN Communication System Description

EKS0041B

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R (R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



LKIA0017E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		


HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R	
A/T position indicator signal	R	T	R	R ^(R range only)		A
Air conditioner switch signal	R			T		B
Air conditioner compressor signal	R				T	
A/C compressor request signal	T				R	
Blower fan switch signal	R ^(QR25DE)			T		C
Cooling fan motor operation signal	R			T		
Cooling fan speed request signal	T				R	D
Position lights request			R	T	R	
Position lights status				R	T	
Low beam request				T	R	E
Low beam status	R			R	T	
High beam request			R	T	R	F
High beam status	R			R	T	
Front fog lights request				T	R	
Front fog light status				R	T	G
OD cancel switch signal		R	T		R	
Brake switch signal		R	T			
Vehicle speed signal	R		T			H
	R		T	R		
Oil pressure switch			R		T	I
Sleep request1			R	T		
Sleep request2				T	R	
N range switch signal		R	T			J
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		LT
Door switch signal			R	T	R	
Tail lamp request			R	T	R	
Turn indicator signal			R	T		L
Buzzer output signal			R	T		
Trunk switch signal			R	T		M
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R	T	
Wiper stop position signal				R	T	
Rear window defogger switch signal				T	R	
Rear window defogger control signal	R			R	T	

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

FOR M/T MODELS

System diagram



LKIA0018E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Signals	ECM	COMBINATION METER	BCM	IPDM E/R	A
Rear window defogger switch signal			T	R	
Rear window defogger control signal	R		R	T	B

C

D

E

F

G

H

I

J

LT


L

M

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

EKS0041C


Schematic HALOGEN



LKWA0023E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

XENON



A
B
C
D
E
F
G
H
I
J
LT
L
M





LKWA0024E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -





EKS0041D

Wiring Diagram — DTRL — HALOGEN

LT-DTRL-01



REFER TO THE FOLLOWING.
M16 - JOINT CONNECTOR (J/C)





LKWA0025E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-02

— : DATA LINE





REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0026E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-03





REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0027E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

XENON



LT-DTRL-04



HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-05

— : DATA LINE





REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0029E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-06



REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

LKWA0030E

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Terminals and Reference Value for Daytime Light Control Unit

EKS0041E

Terminal No.	Wire color	Item	Condition	Voltage (Approx.)
1	BR/Y	Generator	When turning ignition switch to "ON"	Less than 1V
			When engine is running	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
2	BR	Start signal	When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "ON" from "START"	Less than 1V
			When turning ignition switch to "OFF"	Less than 1V
3	G	Power source	When turning ignition switch to "ON"	Battery voltage
			When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
4	L/W	LH light fuse	When lighting switch is turned to the 2ND position with "HI BEAM" or "FLASH TO PASS" position	Battery voltage
			When lighting switch is turned to "FLASH TO PASS" position with ignition switch "ON" position	Battery voltage
5	G	RH light fuse	When lighting switch is turned to the 2ND position with "HI BEAM" or "FLASH TO PASS" position	Battery voltage
			When lighting switch is turned to "FLASH TO PASS" position with ignition switch "ON" position	Battery voltage
6	L	LH HI beam	When lighting switch is turned to the 2ND position with "HI BEAM" or "FLASH TO PASS" position	Battery voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Half battery voltage
7	Y	RH HI beam	When lighting switch is turned to the 2ND position with "HI BEAM" or "FLASH TO PASS" position	Battery voltage
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery voltage
9	G	RH HI beam (ground)	When turning lighting switch to the 2ND position with "HI BEAM" or "FLASH TO PASS" position	Less than 1V
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Half battery voltage
10	Y/G	LH HI beam (ground)	When turning lighting switch to the 2ND position with "HI BEAM" or "FLASH TO PASS" position	Less than 1V
			When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Less than 1V
13	B	Ground	—	—
14	B	Ground	—	—
16	B	Ground	—	—

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

Terminal No.	Wire color	Item	Condition	Voltage (Approx.)
17	G	Parking brake switch	When parking brake is released	Battery voltage
			When parking brake is set	Less than 1.7V

Aiming Adjustment

EKS0041F

Refer to [LT-23, "Aiming Adjustment"](#) .

Bulb Replacement

EKS0041G

Refer to [LT-24, "Bulb Replacement"](#) .

Removal and Installation

EKS0041H

Refer to [LT-25, "Removal and Installation"](#) .

Disassembly and Assembly

EKS0041I

Refer to [LT-26, "Disassembly and Assembly"](#) .

A
B
C
D
E
F
G
H
I
J
LT
L
M

LT


AUTO LIGHT SYSTEM

PFP:28491

AUTO LIGHT SYSTEM

Component Parts and Harness Connector Location

EKS0041J



WKIA0147E

System Description

EKS0041K

This system automatically turns the parking lamps and the headlamps on and off in accordance with ambient light.

Timing for when the lamps turn on/off can be selected using four modes.

OUTLINE

The auto light control system uses an optical sensor that detects the brightness of outside light. When the lighting switch is in AUTO position, it automatically turns on/off the parking lamps and the headlamps (and fog lamps, if equipped) in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, refer to [LT-64, "SETTING CHANGE FUNCTIONS"](#).

When the lighting switch is in "AUTO" position, power is supplied

- from BCM (body control module) terminal 45
- to auto light sensor terminal 1.

When lighting switch is in "AUTO" position, ground is supplied

- from BCM (body control module) terminal 53
- to auto light sensor terminal 3.

When ignition switch is turned to "ON" or "START" position, and when outside brightness is darker than prescribed level, input is supplied

- to BCM (body control module) terminal 38
- from auto light sensor terminal 2.

The headlamps will then illuminate. For a description of headlamp operation, refer to [LT-5, "System Description"](#) (USA), or [LT-28, "System Description"](#) (Canada).

AUTO LIGHT SYSTEM

BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the AUTO position, and the ignition switch is turned from ON or ACC to OFF, and one of the doors is opened, the battery saver feature is activated. Under this condition, the headlamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the headlamps are turned off.

SHUT OFF DELAY

When the ignition switch is turned from ON to OFF while the auto light system is activated and the headlamps are illuminated, the shut off delay feature is activated. Under this condition, the BCM no longer receives a voltage signal at terminal 35, and this starts the auto light shut off delay timer. The shut off delay timer is active until one of the doors is opened, or the combination switch (lighting switch) position is changed. If one of the doors is opened, the shut off delay feature is deactivated, and the battery saver control feature is activated. If the combinations switch (lighting switch) position is changed, the headlamps are turned off.


CAN Communication System Description

EKS0041L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System diagram



LKIA0015E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R

AUTO LIGHT SYSTEM

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



LKIA0017E

AUTO LIGHT SYSTEM

Input/output signal chart


T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R(R range only)	
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

AUTO LIGHT SYSTEM

FOR M/T MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T

AUTO LIGHT SYSTEM

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Rear window defogger switch signal			T	R
Rear window defogger control signal	R		R	T

Major Components and Functions

EKS0041M

Components	Functions
BCM	<ul style="list-style-type: none"> ● Turns on/off circuits of tail light and headlamp according to signals from light sensor, lighting switch (AUTO), driver door switch, and ignition switch (ON, OFF), and vehicle signal from combination meter.
Auto light sensor	<ul style="list-style-type: none"> ● Converts ambient light (lux) to voltage, and sends it to BCM. (Detects light from 50 to 1,300 lux)
Combination meter	<ul style="list-style-type: none"> ● Sends vehicle signal to BCM via CAN communication line.


A
B
C
D
E
F
G
H
I
J
LT
L
M

LT

AUTO LIGHT SYSTEM

Schematic HALOGEN (WITH DAYTIME LIGHT SYSTEM)


EKS0041N



WKWA0098E

AUTO LIGHT SYSTEM

XENON (WITH DAYTIME LIGHT SYSTEM)



A
B
C
D
E
F
G
H
I
J
LT
L
M

WKWA0099E


AUTO LIGHT SYSTEM

EKS00410

Wiring Diagram — AUTO/L — HALOGEN (USA)


LT-AUTO/L-01

— : DATA LINE




TO LT-ROOM/L

NEXT PAGE





REFER TO THE FOLLOWING.
M16 - JOINT CONNECTOR (J/C)



WKWA0100E

AUTO LIGHT SYSTEM

LT-AUTO/L-02



REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)




WKWA0101E

AUTO LIGHT SYSTEM


XENON (USA)

LT-AUTO/L-03

— : DATA LINE



REFER TO THE FOLLOWING.
 (M16) - JOINT CONNECTOR (J/C)




WKWA0102E


AUTO LIGHT SYSTEM

LT-AUTO/L-04

— : DATA LINE



PRECEDING PAGE



REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)





WKWA0103E

AUTO LIGHT SYSTEM





HALOGEN (CANADA)

LT-AUTO/L-05

— : DATA LINE





REFER TO THE FOLLOWING.
 (M16) - JOINT CONNECTOR (J/C)



AUTO LIGHT SYSTEM

LT-AUTO/L-06

— : DATA LINE





REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA0105E

AUTO LIGHT SYSTEM

LT-AUTO/L-07






REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)


WKWA0106E

AUTO LIGHT SYSTEM

XENON (CANADA)





REFER TO THE FOLLOWING.
 M16 - JOINT CONNECTOR (J/C)



AUTO LIGHT SYSTEM

LT-AUTO/L-09





REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA0108E

AUTO LIGHT SYSTEM

LT-AUTO/L-10



REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA0109E

AUTO LIGHT SYSTEM

Terminals and Reference Value for BCM

EKS0041P

Terminal No.	Wire color	Signal name	Measuring condition		Standard (V) (Approx.)
			Ignition switch	Operation or condition	
7	W/B	Battery power supply	OFF	—	12V
8	B	Ground	ON	—	0
14	SB	Driver door switch signal	OFF	Driver door switch ON (open)	0
				OFF (closed)	12V
27	B	Ground	ON	—	0
35	G	IGN power	ON	—	12V
36	PU	ACC power	ACC	—	12V
38	W/R	Auto light sensor signal	ON	When auto light sensor is illuminated	3.1V or more ^{Note} (Reference value)
				When auto light sensor is not illuminated	0.6 or less (Reference value)
45	R	Auto light sensor power source	ON	—	5
53	P	Sensor ground	ON	—	0
63	B	Ground	ON	—	0

NOTE:

If the auto light sensor is insufficiently illuminated, the measured value may not satisfy the standard.

How to Proceed With Trouble Diagnosis

EKS0041Q

1. Confirm the malfunction symptom or customer complaint.
2. Understand system description. Refer to [LT-46, "System Description"](#).
3. Conduct pre-inspection. Refer to [LT-64, "Inspection Before Diagnosis"](#).
4. Find cause of malfunction by following the symptoms in the trouble diagnosis chart and repair or replace as necessary. Refer to [LT-68, "Trouble Diagnosis Chart by Symptom"](#).
5. Does automatic light system operate normally? If it operates normally, go to 6. If it does not operate normally, go to 4.
6. End.

Inspection Before Diagnosis

EKS0041R

SETTING CHANGE FUNCTIONS

- Sensitivity of automatic light system can be adjusted using CONSULT-II. Refer to [LT-66, "WORK SUPPORT"](#).

BCM POWER/GROUND CIRCUIT INSPECTION

1. FUSE/FUSIBLE LINK INSPECTION

- Check the following BCM fuses and fusible links.

Terminal	Ignition switch position	Fuse/fusible link
7	Battery power	f
35	ON or START	12
36	ACC or ON	6

OK or NG

- OK >> GO TO 2.
 NG >> Replace fuse or fusible link.

AUTO LIGHT SYSTEM

2. POWER SUPPLY CIRCUIT INSPECTION

Disconnect BCM connector and measure voltage between each terminal in table below and ground.

Terminal No.	Signal name	Ignition switch	Standard voltage (V) (Approx.)
7	Battery power	OFF	12V
35	IGN power	ON	12V
36	ACC power	ACC	12V

OK or NG

OK >> GO TO 3.

NG >> Repair or replace BCM power circuit harness.

3. GROUND CIRCUIT INSPECTION

Check continuity between the following vehicle-side connector terminals and body ground.

Terminal No.	Signal name	Ignition switch	Continuity
8	Ground	OFF	Yes
27		OFF	Yes
63		OFF	Yes

OK or NG

OK >> Power and ground are OK.

NG >> Repair or replace BCM ground circuit harness.

CONSULT-II Function


EKS0041S

CONSULT-II has a display function for work support, self-diagnosis, data monitor, and active test for each part by combining data receiving and sending via the communication line from BCM.

BCM diagnosis part	Check item, diagnosis mode	Description
Headlamp	Work support	Changes the setting for each function.
	Data monitor	Displays BCM input data in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.


CONSULT-II BASIC OPERATION

1. With the ignition switch OFF, connect CONSULT-II to the vehicle-side data link connector, then turn ignition switch ON.
2. Touch "START".




AUTO LIGHT SYSTEM

3. Touch "BCM" on "SELECT SYSTEM" screen.



4. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.



WORK SUPPORT

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item setting to be changed on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch the item setting desired.
6. Touch "SETTING CHANGE".
7. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
8. Touch "END".

Work Support Setting Item

Work Support item	Description	Mode	Setting status
AUTO LIGHT SET	Sensitivity of auto light can be selected and set from four modes.	Normal	Factory setting
		Mode 2	More sensitive setting compared to factory setting (The time required for lamp light-up is shorter than "Normal".)
		Mode 3	Less sensitive setting compared to factory setting (The time required for lamp light-up is longer than "Normal".)
		Mode 4	Less sensitive setting compared to Mode 3 (The time required for lamp light-up is longer than Mode 3.)
BATTERY SAVER SET	Function is not enabled, battery saver operation cannot be changed.	On	Function is not enabled, battery saver operation cannot be changed.
		Off	

AUTO LIGHT SYSTEM

Work Support item	Description	Mode	Setting status
ILL DELAY SET	The timer that turns off the headlamps (and fog lamps, if turned on) after the last door is closed can be selected and set from 8 modes.	Mode 1	45 seconds (Factory setting)
		Mode 2	0 seconds (immediate shutoff)
		Mode 3	30 seconds
		Mode 4	60 seconds
		Mode 5	90 seconds
		Mode 6	120 seconds
		Mode 7	150 seconds
		Mode 8	180 seconds

DATA MONITOR

Operation Procedure

1. Touch "HEADLAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU".

All signals	Monitors all the signals.
Selection from menu	Selects and monitors individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the signals will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

Display Item List

Monitor item name "OPERATION OR UNIT"	Contents
IGN ON SW "ON/OFF"	"IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal is displayed.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
AUTO LIGHT SW "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
TAIL LAMP SW "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of light switch judged from lighting switch signal.
HEAD LAMP SW "ON/OFF"	Displays status (headlamp switch: ON/Others: OFF) of headlamp switch judged from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (front fog switch: ON/Others: OFF) of front fog switch judged from lighting switch signal.
DOOR SW - DR "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR "ON/OFF"	Displays status of the rear doors as judged from the rear door switch signal. (Door is open: ON/Door is closed: OFF)
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
OPTICAL SENSOR [0 - 5V]	Displays "ambient light (close to 5V when light/close to 0V when dark)" judged from auto light sensor signal.

AUTO LIGHT SYSTEM

ACTIVE TEST

Operation Procedure

1. Touch "HEADLAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

Display Item List

Test item	Display on CONSULT-II screen	Description
Tail light relay output	TAIL LAMP	Allows tail light relay to operate by switching ON-OFF at your option.
Headlamp relay output	HEAD LAMP (LOW)	Allows headlamp relay to operate by switching ON-OFF at your option.
Headlamp relay output	HEAD LAMP (HI)	Allows headlamp relay to operate by switching ON-OFF at your option.
Front fog lamp relay output	FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF at your option.

Trouble Diagnosis Chart by Symptom

EKS0041T

Trouble phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> ● Parking lamps and headlamps will not illuminate when outside of the vehicle becomes dark. (Lighting switch 1st position and 2nd position operate normally.) ● Parking lamps and headlamp will not go out when outside of the vehicle becomes light. (Lighting switch 1st position and 2nd position operate normally.) ● Headlamps go out when outside of the vehicle becomes light, but parking lamps stay on. 	<ul style="list-style-type: none"> ● Refer to LT-66, "WORK SUPPORT" . ● Refer to LT-68, "Light Switch Inspection" . ● Refer to LT-69, "Auto Light Sensor System Inspection" . If above systems are normal, replace BCM.
Parking lamps illuminate when outside of the vehicle becomes dark, but headlamps stay off. (Lighting switch 1st position and 2nd position operate normally.)	<ul style="list-style-type: none"> ● Refer to LT-66, "WORK SUPPORT" . ● Refer to LT-69, "Auto Light Sensor System Inspection" . If above systems are normal, replace BCM.
Auto light adjustment system will not operate. (Lighting switch AUTO, 1st position and 2nd position operate normally.)	<ul style="list-style-type: none"> ● Refer to LT-69, "Auto Light Sensor System Inspection" . If above system is normal, replace BCM.
Auto light adjustment system of combination meter will not operate.	<ul style="list-style-type: none"> ● CAN communication line inspection between BCM and combination meter. Refer to BCS-15, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)" .

Light Switch Inspection

EKS0041U

1. LIGHT SWITCH INSPECTION

Select "BCM" in CONSULT-II. Operate lighting switch via "AUTO LIGHT SW" on data monitor screen, and check that light turns on and off as commanded.

Lighting switch AUTO : ON

Lighting switch OFF : OFF

OK or NG

OK >> Normal.

NG >> Replace lighting switch. Refer to [LT-96, "Removal and Installation"](#) .

DATA MONITOR	
MONITOR	
IGN ON SW	ON
ACC ON SW	ON
AUTO LIGHT SW	ON
TAIL LAMP SW	OFF
HEAD LAMP SW	OFF
HI BEAM SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF

LKIA0077E

AUTO LIGHT SYSTEM

EKS0041V

Auto Light Sensor System Inspection

1. OUTPUT SIGNAL INSPECTION

Select "BCM" in CONSULT-II. Using "OPTICAL SENSOR" data from "DATA MONITOR", check difference in the voltage when the auto light sensor is illuminated and not illuminated.

Illuminated

Light sensor : 3.1V or more

Not illuminated

Light sensor : 0.6V or less

NOTE:

If the auto light sensor is insufficiently illuminated, the measured value may not satisfy the standard.

OK or NG

- OK >> Normal.
- NG >> GO TO 2.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
ACC ON SW	ON
AUTO LIGHT SW	OFF
TAIL LAMP SW	ON
HEAD LAMP SW	ON
HI BEAM SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF

LKIA0078E

2. POWER SUPPLY CIRCUIT CONTINUITY INSPECTION

1. Disconnect connectors of BCM and auto light sensor.
2. Check harness continuity between BCM vehicle-side connector terminal 45 (R) and vehicle-side connector terminal 1 (R) of auto light sensor.


Continuity should exist.

3. Check continuity between BCM vehicle-side connector terminal 45 (R) and body ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Malfunction in harness between BCM and auto light sensor. Repair or replace as required.



3. OUTPUT CIRCUIT CONTINUITY INSPECTION

1. Check harness continuity between BCM vehicle-side connector terminal 38 (W/R) and vehicle-side connector terminal 2 (W/R) of auto light sensor.


Continuity should exist.

2. Check continuity between BCM vehicle-side connector terminal 38 (W/R) and body ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 4.
- NG >> Malfunction in harness between BCM and auto light sensor. Repair or replace as required.



AUTO LIGHT SYSTEM

4. GROUND CIRCUIT CONTINUITY INSPECTION

1. Check harness continuity between BCM vehicle-side connector terminal 53 (P) and vehicle-side connector terminal 3 (P) of auto light sensor.

Continuity should not exist.


2. Check continuity between BCM vehicle-side connector terminal 53 (P) and body ground.

Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Malfunction in harness between BCM and auto light sensor. Repair or replace as required.



5. SENSOR VOLTAGE INSPECTION


1. Connect BCM connector.
2. Check voltage between BCM terminal 45 (R) and body ground.

Approx. 5V

OK or NG

OK >> Replace the auto light sensor.

NG >> Replace BCM.



FRONT FOG LAMP

System Description

EKS0041W

Control of the fog lamps is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the fog lamp position, the BCM receives input requesting the fog lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the front fog lamp relay coil. When energized, this relay directs power to the front fog lamps.

OUTLINE

Power is supplied at all times

- through 15A fuse [No. 41, located in the IPDM E/R (intelligent power distribution module engine/room)]
- to front fog lamp relay, located in the IPDM E/R, and

Power is also supplied at all times

- to terminal 7 of the BCM (body control module).

When the ignition switch is in ON or START position, power is supplied

- to terminal 35 of the BCM.

When the ignition switch is in ACC or ON position, power is supplied

- to terminal 36 of the BCM.

Ground is supplied

- to BCM terminals 8, 27, and 63
- through body grounds M57, M61, E15, and E24.

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch can be in any position (except pass or high beam) and the fog lamp switch must be ON for fog lamp operation.

With the fog lamp switch in the ON position, the central processing unit of the IPDM E/R (intelligent power distribution module engine room) grounds the coil side of the fog lamp relay. The fog lamp relay then directs power

- to front fog lamp LH terminal 1
- through IPDM E/R terminal 32, and
- to front fog lamp RH terminal 1
- through IPDM E/R terminal 29.

Ground is supplied

- to front fog lamp LH terminal 2
- through body grounds E15 and E24, and
- to front fog lamp RH terminal 2
- through body grounds E15 and E24.

With power and grounds supplied, the front fog lamps illuminate.

BATTERY SAVER CONTROL

When the fog lamp switch is ON and the ignition switch is turned from ON to ACC or OFF, or if the ignition switch is in the OFF position when the fog lamp switch is turned ON, the battery saver control feature is activated.

Under this condition, the fog lamps (and headlamps) remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the fog lamps (and headlamps) are turned off.

CAN Communication System Description

EKS0041X


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

A
B
C
D
E
F
G
H
I
J
LT
L
M

FRONT FOG LAMP

FOR TCS MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R ^(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		

FRONT FOG LAMP

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



LKIA0017E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R ^(R range only)	
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R ^(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R

FRONT FOG LAMP

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

FOR M/T MODELS

System diagram



LKIA0018E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R



FRONT FOG LAMP

Signals	ECM	COMBINATION METER	BCM	IPDM E/R	
Blower fan switch signal	R ^(QR25DE)		T		A
Cooling fan motor operation signal	R			T	B
Cooling fan speed request signal	T			R	
Position lights request		R	T	R	C
Position lights status			R	T	
Low beam request			T	R	
Low beam status	R		R	T	D
High beam request		R	T	R	E
High beam status	R		R	T	
Front fog lights request			T	R	F
Front fog light status			R	T	
Vehicle speed signal	R	T			G
Oil pressure switch		R		T	
Sleep request1		R	T		H
Sleep request2			T	R	
Seat belt buckle switch signal		T	R		I
Door switch signal		R	T	R	
Tail lamp request		R	T	R	J
Turn indicator signal		R	T		
Buzzer output signal		R	T		
Trunk switch signal		R	T		
ASCD main switch signal	T	R			
ASCD cruise signal	T	R			
Wiper operation			R	T	
Wiper stop position signal			R	T	LT
Rear window defogger switch signal			T	R	
Rear window defogger control signal	R		R	T	

FRONT FOG LAMP

Wiring Diagram — F/FOG —

EKS0041Y



LKWA0047E

FRONT FOG LAMP

EKS0041Z

Front Fog Lamps Do Not Illuminate (Both Sides)

1. INSPECTION 1 BETWEEN IPDM E/R AND FRONT FOG LAMPS

1. Start active test. Refer to [LT-18, "ACTIVE TEST"](#) .
2. Check operation of the front fog lamps.


OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. INSPECTION 2 BETWEEN IPDM E/R AND FRONT FOG LAMPS

1. Disconnect IPDM E/R connector and left/right front fog lamp connectors.
2. Check continuity between harness connector terminals of IPDM E/R and harness connector terminals of left/right front fog lamps.

Terminals					Continuity
IPDM E/R		Front fog lamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E122	29 (W/R)	Right	E101	1 (W/R)	Yes
	32 (W/R)	Left	E2	1 (W/R)	




OK or NG

- OK >> Connect electrical connectors. GO TO 3.
- NG >> Check for short circuits and open circuits in harness between IPDM E/R and headlamps and repair as necessary.

3. IPDM E/R INSPECTION

Start active test. Refer to [LT-18, "ACTIVE TEST"](#) . When front fog lamp relay is operating, check voltage between left/right front fog lamp connector terminals and body ground.

Terminals				Voltage (Approx.)
Front fog lamp			Body ground (-)	
Connector	Terminal (wire color)			
Right	E101	1 (W/R)		12
Left	E2	1 (W/R)		



OK or NG

- OK >> Check front fog lamp bulbs and replace as necessary.
- NG >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#) .

4. INSPECTION 1 BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II. Carry out "BCM C/U" self-diagnosis.

Displayed results of self-diagnosis

No malfunction detected>> GO TO 5.

CAN communications or CAN system>> Inspect the BCM CAN communications system. Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .

OPEN DETECT 1 - 5>> Combination switch system malfunction. Refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#) .

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	

LKIA0073E

FRONT FOG LAMP

5. INSPECTION 2 BETWEEN COMBINATION SWITCH AND BCM

Select "BCM" on CONSULT-II. Use "HEADLAMP" data monitor to check that "FR FOG SW" turns ON-OFF linked with operation of fog lamp switch.

OK or NG

- OK >> Replace BCM.
- NG >> Replace lighting switch. Refer to [LT-96, "Removal and Installation"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
ACC ON SW	ON
AUTO LIGHT SW	OFF
TAIL LAMP SW	OFF
HEAD LAMP SW	OFF
HI BEAM SW	OFF
PASSING SW	OFF
FR FOG SW	ON
DOOR SW-DR	OFF

LKIA0094E

Front Fog Lamp Does Not Illuminate (One Side)

EKS00420

1. BULB INSPECTION

Inspect bulbs of lamps which do not illuminate.


OK or NG

- OK >> GO TO 2.
- NG >> Replace lamp bulb.

2. INSPECTION BETWEEN IPDM E/R AND FRONT FOG LAMPS

1. Disconnect IPDM E/R connector and inoperative front fog lamp connector.
2. Check continuity between harness connector terminals of IPDM E/R and harness connector terminal of front fog lamps.

Terminals					Continuity
IPDM E/R		Front fog lamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E122	29 (W/R)	Right	E101	1 (W/R)	Yes
	32 (W/R)	Left	E2	1 (W/R)	



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#).
- NG >> Check for short circuits and open circuits in harness between IPDM E/R and front fog lamps.


Aiming Adjustment

EKS00421

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.


- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.

Adjust aiming in the vertical direction by turning the adjusting screw.




FRONT FOG LAMP

1. Set the distance between the screen and the center of the fog lamp lens as shown.
2. Turn front fog lamps ON.



3. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.




Removal and Installation

EKS00422

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb.

CAUTION:

- Do not leave fog lamp assembly without bulb for a long period of time. Dust, moisture, smoke, etc. entering the fog lamp body may affect the performance. Remove the bulb from the headlamp assembly just before replacement bulb is installed.
 - Grasp only the plastic base when handling the bulb. Never touch the glass envelope. Touching the glass could significantly affect the bulb life and/or fog lamp performance.
1. Remove the fender protector. Refer to [EI-20, "Removal and Installation"](#).
 2. Disconnect electrical connector.
 3. Remove bolt, and slide fog lamp out of front fascia.
- Install in the reverse order of removal.



TURN SIGNAL AND HAZARD WARNING LAMPS

TURN SIGNAL AND HAZARD WARNING LAMPS

PF2:26120

System Description

TURN SIGNAL OPERATION

EKS00423

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to BCM (body control module) terminal 35, and
- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to terminals 17 and 18 of the combination meter.

Ground is supplied

- to BCM (body control module) terminals 8, 27, and 63
- through body grounds M57, E15, and E24, and
- to combination meter terminals 6 and 39
- through body grounds M57 and M61.

LH Turn

When the turn signal switch (combination switch) is moved to the L position, the BCM (body control module) receives input requesting the left turn signals to flash. The BCM then supplies power

- to front turn signal lamp LH terminal 3
- to rear turn signal lamp LH (part of the rear combination lamp LH) terminal 3.

Ground is supplied to the front turn signal lamp LH terminal 2 through body grounds E15 and E24.

Ground is supplied to the rear turn signal lamp LH (part of the rear combination lamp) terminal 5 through body grounds B7 and B19.

The BCM also supplies ground to combination meter terminals 1 and 2 across the CAN communication lines. This input is processed by the central processing unit of the combination meter, which in turn supplies ground to the left turn signal indicator lamp.

With power and ground supplied, the BCM controls the flashing of the LH turn signal lamps.

RH Turn

When the turn signal switch (combination switch) is moved to the R position, the BCM (body control module) receives input requesting the right turn signals to flash. The BCM then supplies power

- to front turn signal lamp RH terminal 3
- to rear turn signal lamp RH (part of the rear combination lamp RH) terminal 3.

Ground is supplied to the front turn signal lamp RH terminal 2 through body grounds E15 and E24.

Ground is supplied to the rear turn signal lamp RH (part of the rear combination lamp RH) terminal 5 through body grounds B7 and B19.

The BCM also supplies ground to combination meter terminals 1 and 2 across the CAN communication lines. This input is processed by the central processing unit of the combination meter, which in turn supplies ground to the right turn signal indicator lamp.

With power and ground supplied, the BCM controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times

- to BCM (body control module) terminal 7
- through 50A fusible link [letter f, located in the fuse and fusible link box], and
- to combination meter terminal 5
- through 10A fuse [No. 19, located in the fuse block (J/B)].

Ground is supplied

- to hazard switch terminal 3
- through body grounds M57 and M61,
- to BCM terminals 8, 27, and 63,
- through body grounds M57, M61, E15, and E24, and
- to combination meter terminals 6 and 39
- through body grounds M57 and M61.

When the hazard switch is depressed, ground is supplied

TURN SIGNAL AND HAZARD WARNING LAMPS

- to BCM terminal 61
- through hazard lamp switch terminal 1.

The BCM then supplies power

- to front turn signal lamp LH terminal 3
- to front turn signal lamp RH terminal 3
- to rear turn signal lamp LH (part of the rear combination lamp LH) terminal 3
- to rear turn signal lamp RH (part of the rear combination lamp RH) terminal 5.

Ground is supplied

- to the front turn signal lamp LH terminal 2 through body grounds E15 and E24
- to the front turn signal lamp RH terminal 2 through body grounds E15 and E24
- to the rear turn signal lamp LH (part of the rear combination lamp) terminal 5 through body grounds B7 and B19
- to the rear turn signal lamp RH (part of the rear combination lamp RH) terminal 5 through body grounds B7 and B19.

The BCM also supplies input to combination meter terminals 1 and 2 across the CAN communication lines. This input is processed by the central processing unit of the combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and ground supplied, the BCM controls the flashing of the hazard warning lamps.

REMOTE KEYLESS ENTRY SYSTEM OPERATION

Power is supplied at all times

- to BCM (body control module) terminal 7
- through 50A fusible link [letter f , located in the fuse and fusible link box], and
- to combination meter terminal 5
- through 10A fuse [No. 19, located in the fuse block (J/B)].

Ground is supplied

- to BCM terminals 8, 27, and 63,
- through body grounds M57, M61, E15, and E24, and
- to combination meter terminals 6 and 39
- through body grounds M57 and M61.

When the remote keyless entry system is triggered by input from the keyfob, the BCM supplies power

- to front turn signal lamp LH terminal 3
- to front turn signal lamp RH terminal 3
- to rear turn signal lamp LH (part of the rear combination lamp LH) terminal 3
- to rear turn signal lamp RH (part of the rear combination lamp RH) terminal 3.

Ground is supplied

- to the front turn signal lamp LH terminal 2 through body grounds E15 and E24
- to the front turn signal lamp RH terminal 2 through body grounds E15 and E24
- to the rear turn signal lamp LH (part of the rear combination lamp) terminal 5 through body grounds B7 and B19
- to the rear turn signal lamp RH (part of the rear combination lamp RH) terminal 5 through body grounds B7 and B19.

The BCM also supplies input to combination meter terminals 1 and 2 across the CAN communication lines. This input is processed by the central processing unit of the combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and ground supplied, the BCM controls the flashing of the hazard warning lamps when keyfob is used to activate the remote keyless entry system.

CAN Communication System Description

EKS00424


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2

TURN SIGNAL AND HAZARD WARNING LAMPS

communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System diagram



LKIA0015E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R (R range only)	
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R ^(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R

TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Low beam status	R			R	T
High beam request			R	T	R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

FOR M/T MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	


TURN SIGNAL AND HAZARD WARNING LAMPS

Signals	ECM	COMBINATION METER	BCM	IPDM E/R	
Air conditioner compressor signal	R			T	A
A/C compressor request signal	T			R	
Blower fan switch signal	R ^(QR25DE)		T		B
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T			R	C
Position lights request		R	T	R	
Position lights status			R	T	D
Low beam request			T	R	
Low beam status	R		R	T	
High beam request		R	T	R	E
High beam status	R		R	T	
Front fog lights request			T	R	
Front fog light status			R	T	F
Vehicle speed signal	R	T			
Oil pressure switch		R		T	G
Sleep request1		R	T		
Sleep request2			T	R	
Seat belt buckle switch signal		T	R		H
Door switch signal		R	T	R	
Tail lamp request		R	T	R	I
Turn indicator signal		R	T		
Buzzer output signal		R	T		
Trunk switch signal		R	T		J
ASCD main switch signal	T	R			
ASCD cruise signal	T	R			LT
Wiper operation			R	T	
Wiper stop position signal			R	T	
Rear window defogger switch signal			T	R	L
Rear window defogger control signal	R		R	T	

TURN SIGNAL AND HAZARD WARNING LAMPS

Schematic

EKS00425




WKWA0399E

TURN SIGNAL AND HAZARD WARNING LAMPS


EKS00426

Wiring Diagram — TURN —

LT-TURN-01






REFER TO THE FOLLOWING.
(M16) - JOINT CONNECTOR-1 (J/C)



LKWA0031E

TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



REFER TO THE FOLLOWING.

(E130) - SUPER MULTIPLE




JUNCTION (SMJ)

(B37) - JOINT CONNECTOR (J/C)

WKWA0400E

TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03



REFER TO THE FOLLOWING.





- (M4) - FUSE BLOCK - JUNCTION BOX (J/B)
- (M16) - JOINT CONNECTOR (J/C)

LKWA0033E

TURN SIGNAL AND HAZARD WARNING LAMPS

Terminals and Reference Value for BCM

EKS00427

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (V) or waveform	
			Ignition switch	Operation or condition		
7	W/B	Battery power supply	OFF	—	Approx. 12V	
8	B	Ground	ON	—	Approx. 0V	
21	G/Y	Turn signal (right)	ON	Combination switch Turn right ON	 SKIA1120J	
22	G/B	Turn signal (left)	ON	Combination switch Turn left ON	 SKIA1120J	
35	G	IGN power	ON	—	Approx. 12V	
42	R/Y	Combination switch OUTPUT 4	ON	Lighting, turn, wiper OFF	 SKIA1119J	
43	L	Combination switch OUTPUT 5	ON	Lighting, turn, wiper OFF	 SKIA1119J	
48	G/W	Combination switch INPUT 1	ON	Lighting, turn, wiper OFF	Approx. 0V	
61	G/R	Hazard	OFF	Hazard switch	ON	Approx. 0V
				OFF	Approx. 5V	

CONSULT-II Function

EKS00428


CONSULT-II has a display function for work support, self-diagnosis, data monitor, and active test for each part by combining data receiving and sending via the communication line from BCM.

BCM diagnosis part	Check item, diagnosis mode	Description
Flasher	Data monitor	Displays BCM input data in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.


TURN SIGNAL AND HAZARD WARNING LAMPS

CONSULT-II BASIC OPERATION


1. With the ignition switch OFF, connect CONSULT-II to the vehicle-side data link connector, then turn ignition switch ON.
2. Touch "START".



3. Touch "BCM" on "SELECT SYSTEM" screen.



4. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.



DATA MONITOR

Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors the individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

TURN SIGNAL AND HAZARD WARNING LAMPS

Display Item List

Monitor item name "OPERATION OR UNIT"		Contents
IGN ON SW	"ON/OFF"	"IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal is displayed.
HAZARD SW	"ON/OFF"	Displays "Hazard ON (ON)/Hazard OFF (OFF)" status, determined from hazard switch signal.
TURN SIGNAL R	"ON/OFF"	Displays "Turn right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L	"ON/OFF"	Displays "Turn left (ON)/Other (OFF)" status, determined from lighting switch signal.

ACTIVE TEST

Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

Display Item List

Test item	Display on CONSULT-II screen	Description
Turn signal lamp (right) output	FLASHER (RIGHT)	Turn signal lamp (right) can be operated by any ON-OFF operations.
Turn signal lamp (left) output	FLASHER (LEFT)	Turn signal lamp (left) can be operated by any ON-OFF operations.
Turn signal lamp (right) indicator signal output	FLASHER (RIGHT) (CAN)	Turn signal lamp (right) indicator signal can be output by CAN communication line to gauges by any ON-OFF operations.
Turn signal lamp (left) indicator signal output	FLASHER (LEFT) (CAN)	Turn signal lamp (left) indicator signal can be output by CAN communication line to gauges by any ON-OFF operations.

Turn Signal Lamp Does Not Operate

EKS00429

1. BULB INSPECTION

Check each turn signal lamp bulb to make sure correct bulbs are installed.

OK or NG

- OK >> GO TO 2.
 NG >> Replace bulb.

2. INSPECTION 1 BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II. Carry out "BCM C/U" self-diagnosis.

Displayed results of self-diagnosis

Diagnosis system 1 - 5>> Combination switch system malfunction.
 Refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#).

No malfunction detected>> GO TO 3.

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	

LKIA0073E

TURN SIGNAL AND HAZARD WARNING LAMPS

3. INSPECTION 2 BETWEEN COMBINATION SWITCH AND BCM

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, check that "TURN SIGNAL R" and "TURN SIGNAL L" turn ON-OFF according to operation of turn signal switch.

OK or NG

- OK >> GO TO 4.
- NG >> Replace lighting switch. Refer to [LT-96, "Removal and Installation"](#).

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HAZARD SW	ON
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF

LKIA0083E

4. INSPECTION 1 BETWEEN BCM AND TURN SIGNAL LAMPS

- Select "BCM" on CONSULT-II. Select "FLASHER" active test.
- Check that "FLASHER RIGHT" and "FLASHER LEFT" operate.

OK or NG

- OK >> Replace BCM.
- NG >> GO TO 5.

ACTIVE TEST	
FLASHER RIGHT	ON
OFF	

LKIA0084E


5. INSPECTION 2 BETWEEN BCM AND TURN SIGNAL LAMPS

- Disconnect BCM connector and all turn signal lamp connectors.
- Check continuity between harness connectors of BCM and body ground.

Terminals			Continuity
BCM			Body ground
Connector		Terminal (wire color)	
Right	M20	21 (G/Y)	
Left	M20	22 (G/B)	
			No

OK or NG

- OK >> Replace BCM.
- NG >> Check for short circuit in harnesses between BCM and each turn signal and repair as necessary.



Hazard Lamp Does Not Operate

EKS0042A

1. BULB INSPECTION

Check each turn signal lamp bulb to make sure correct bulbs are installed.

OK or NG

- OK >> GO TO 2.
- NG >> Replace bulb.

TURN SIGNAL AND HAZARD WARNING LAMPS

2. INSPECTION 1 BETWEEN HAZARD SWITCH AND BCM

Select "BCM" on CONSULT-II. Use "FLASHER" data monitor to verify that "HAZARD SW" turns ON-OFF according to operation of hazard switch.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 3.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
HAZARD SW	ON
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF

LKIA0083E


3. INSPECTION 2 BETWEEN HAZARD SWITCH AND BCM

1. Disconnect BCM connector and hazard switch connector.
2. Check continuity between harness connector terminal of BCM and harness connector terminal of hazard switch.

Terminals				Continuity
BCM		Hazard switch		
Connector	Terminal (wire color)	Connector	Terminal (wire color)	
M18	61 (G/R)	M55	1 (G/R)	Yes

OK or NG

- OK >> Connect connectors. GO TO 4.
- NG >> Check for short circuit or open circuit in harness between BCM and hazard switch. Repair as necessary.




4. INSPECTION BCM

Check voltage between BCM terminal and body ground.

Terminals			Voltage
BCM (+)		Body ground (-)	1.6V or more
Connector	Terminal (wire color)		
M18	61 (G/R)		

OK or NG

- OK >> Replace hazard switch. Refer to [LT-97, "Removal and Installation"](#).
- NG >> Replace BCM.




TURN SIGNAL AND HAZARD WARNING LAMPS

5. INSPECTION 1 BETWEEN BCM AND TURN SIGNAL LAMPS

1. Select "BCM" on CONSULT-II. Select "FLASHER" active test.
2. Check that "FLASHER RIGHT" and "FLASHER LEFT" operate.

OK or NG

- OK >> Replace BCM.
 NG >> GO TO 6.




6. INSPECTION 2 BETWEEN BCM AND TURN SIGNAL LAMPS

1. Disconnect BCM connector and all turn signal lamp connectors.
2. Check continuity between harness connectors of BCM and body ground.

Terminals			Continuity
BCM			No
Connector		Terminal (wire color)	
Right	M20	21 (G/Y)	
Left	M20	22 (G/B)	

OK or NG

- OK >> Replace BCM.
 NG >> Check for short circuit in harnesses between BCM and each turn signal. Repair as necessary.



Turn Signal Indicator Lamp Does Not Operate

EKS0042B

1. BULB INSPECTION

Inspect turn signal indicator lamp bulb.

OK or NG

- OK >> Replace combination meter. Refer to [DI-21, "Removal and Installation"](#) .
 NG >> Replace indicator bulb.

Bulb Replacement FRONT TURN SIGNAL LAMP

EKS0042C

Refer to [LT-24, "Bulb Replacement"](#) .

REAR TURN SIGNAL LAMP

Refer to [LT-121, "TAIL LAMP"](#) .

Removal and Installation FRONT TURN SIGNAL LAMP

EKS0042D

Refer to [LT-25, "Removal and Installation"](#) .

REAR TURN SIGNAL LAMP

Refer to [LT-122, "REAR COMBINATION LAMP"](#) .

LIGHTING AND TURN SIGNAL SWITCH


LIGHTING AND TURN SIGNAL SWITCH

PFP:25540

Removal and Installation

EKS0042E

1. Remove the steering column cover. Refer to [PS-10, "Removal and installation"](#) .
2. Pinch tabs and slide out lighting and turn signal switch (combination switch).



LKIA0013E

Switch Circuit Inspection

EKS0042F

Refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#) .

HAZARD SWITCH


HAZARD SWITCH

PF2:25290

Removal and Installation

EKS0042G

1. Remove center console storage compartment. Refer to [IP-12, "Removal and Installation"](#).
2. Depress hazard switch tab, and remove hazard switch.



A
B
C
D
E
F
G
H
I
J
LT
L
M

COMBINATION SWITCH

COMBINATION SWITCH

PF25567

Combination Switch Reading Function

EKS0042H

Refer to [BCS-3, "Combination Switch Reading Function"](#) .

CONSULT-II Function


EKS0042I

CONSULT-II has a display function for work support, self-diagnosis, data monitor, and active test for each part by combining data receiving and sending via the communication line from BCM.


BCM diagnosis part	Check item, diagnosis mode	Description
Combination switch	Data monitor	Displays BCM input data in real time.

CONSULT-II BASIC OPERATION


1. With the ignition switch OFF, connect CONSULT-II to the vehicle-side data link connector, then turn ignition switch ON.
2. Touch "START".



3. Touch "BCM" on "SELECT SYSTEM" screen.



4. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.



DATA MONITOR

Operation Procedure

1. Touch "COMB SW" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

COMBINATION SWITCH

All signals	Monitors all the signals.
Selection from menu	Selects and monitors individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the signals will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

Display Item List

Monitor item name "OPERATION OR UNIT"		Contents
TAIL LAMP SW	"ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
HEAD LAMP SW 1	"ON/OFF"	Displays "Headlamp Switch 1 (ON)/Other (OFF)" status, determined from lighting switch signal.
HEAD LAMP SW 2	"ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
HI BEAM SW	"ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
PASSING SW	"ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
AUTO LIGHT SW ^{Note}	"ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
FR FOG SW	"ON/OFF"	Displays status (front fog switch: ON/Others: OFF) of front fog switch judged from lighting switch signal.
FR WIPER HI	"ON/OFF"	Displays "Front Wiper HI (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER LO	"ON/OFF"	Displays "Front Wiper LOW (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER INT	"ON/OFF"	Displays "Front Wiper INT (ON)/Other (OFF)" status, determined from wiper switch signal.
INT VOLUME	[1 - 7]	Displays intermittent operation knob setting (1 - 7), determined from wiper switch signal.
FR WASHER SW	"ON/OFF"	Displays "Front Washer Switch (ON)/Other (OFF)" status, determined from wiper switch signal.
TURN SIGNAL R	"ON/OFF"	Displays "Turn Right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L	"ON/OFF"	Displays "Turn Left (ON)/Other (OFF)" status, determined from lighting switch signal.

NOTE:

For vehicles without auto light, item will be displayed but monitoring is not possible.

Removal and Installation

EKS0042J

For details, refer to [LT-96, "Removal and Installation"](#).

Switch Circuit Inspection

EKS0042K

For details, refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#).

STOP LAMP



PF:26550

EKS0042L

STOP LAMP

Wiring Diagram — STOP/L —

LT-STOP/L-01




REFER TO THE FOLLOWING.

- (E30) - FUSE BLOCK-JUNCTION BOX (J/B)
- (B37) - JOINT CONNECTOR (J/C)


LKWA0034E

STOP LAMP

LT-STOP/L-02



A
B
C
D
E
F
G
H
I
J
LT
L
M



REFER TO THE FOLLOWING.
 (B37) - JOINT CONNECTOR (J/C)

LKWA0035E

STOP LAMP

Bulb Replacement for High-mounted Stop Lamp WITH REAR SPOILER

EKS0042M

When this vehicle is equipped with a rear spoiler, the high-mounted stop lamp uses an LED circuit board instead of a bulb. The LED circuit board is not serviceable, and must be replaced as an assembly.

WITHOUT REAR SPOILER

1. Remove high-mounted stop lamp assembly. Refer to [LT-102, "Removal and Installation for High-mounted Stop Lamp"](#).
2. Turn bulb socket counterclockwise to unlock and remove from lamp assembly.
3. Turn bulb counterclockwise to remove from socket.

Installation is the reverse order of removal.

Bulb Replacement for Rear Combination Lamp

EKS0042N

1. Remove rear combination lamp. Refer to [LT-102, "Removal and Installation for Rear Combination Lamp"](#).
2. Turn bulb socket counterclockwise to unlock, and remove from combination lamp assembly.
3. Turn bulb counterclockwise to remove from bulb socket.

Installation is the reverse order of removal.

Removal and Installation for High-mounted Stop Lamp WITH REAR SPOILER

EKS0042O

When this vehicle is equipped with a rear spoiler, the high-mounted stop lamp uses an LED circuit board instead of a bulb. The LED circuit board is not serviceable, and must be replaced as an assembly.


1. From trunk, disconnect electrical connector.
2. Remove screws, and high-mounted stop lamp assembly.

Installation is the reverse order of removal.

WITHOUT SPOILER

1. Slide high-mounted stop lamp assembly rearward on parcel shelf to give clearance to front tabs.
2. Lift front of lamp assembly up and bring forward to give clearance to rear tabs.
3. Disconnect connector, and remove from vehicle.

Installation is the reverse order of removal.



Removal and Installation for Rear Combination Lamp

EKS0042P

1. Displace trunk room trim as needed. Refer to [EI-35, "Removal and Installation"](#).
2. From trunk, remove nuts securing rear combination lamp assembly.
3. Disconnect connectors and remove assembly.

Installation is reverse order of removal.

Rear combination lamp mounting nut:

 : 2.5 - 3.7 N·m (0.25 - 0.38 kg·m, 22 - 33 in·lb)

STEP LAMP

STEP LAMP

PFP:26420

System Description

EKS0042Q

Step lamp turns ON at time when driver door, passenger door, RH rear door, or LH rear door is opened (door switch ON). Lamp turns OFF when all doors are closed (all door switches OFF).

A

B

C

D

E

F

G

H

I

J

LT

L



M

STEP LAMP

Wiring Diagram — STEP/L —

EKS0042R

LT-STEP/L-01



LKWA0036E

STEP LAMP

Terminals and Reference Value for BCM

EKS0042S

Terminal No.	Wire color	Signal name	Measuring condition		Standard (V) (Approx.)	
			Ignition switch	Operation or condition		
7	W/B	Battery power supply	OFF	—	12	
8	B	Ground	ON	—	0	
10	P/L	Front door switch RH signal	OFF	Front door switch RH	ON (open)	0
					OFF (closed)	12
11	R/B	Rear door switch (LH and RH) signal	OFF	Rear door switch (LH and RH)	ON (open)	0
					OFF (closed)	12
14	SB	Front door switch LH signal	OFF	Front door switch LH	ON (open)	0
					OFF (closed)	12V
24	P/B	Battery saver output signal	OFF	Any door switch	ON (open)	0 ^{Note}
					OFF (closed)	12V
33	R/W	Step lamp signal	OFF	Any door is open (ON)	0	
				All doors are closed (OFF)	12	

Note: Becomes battery voltage approximately 30 seconds after any door is opened.

Step Lamp Does Not Operate

EKS0042T

1. INSPECTION 1 BETWEEN EACH DOOR SWITCH AND BCM

Select BCM on CONSULT-II. Use "INT LAMP" data monitor to check that switches listed below turn ON-OFF according to switch operation.

Switch name	CONSULT screen
Driver door switch	DOOR SW - DR
Each door switch	DOOR SW - AS

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	OFF
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF
KEY CYL LK SW	OFF
KEY CYL UN SW	OFF
LK BUTTON/SIG	OFF

LKIA0085E


OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system. Repair as necessary.

2. INSPECTION 1 BETWEEN BCM AND STEP LAMP

1. Disconnect BCM connector and left/right step lamp connectors.
2. Check continuity between harness connector terminal of BCM and harness connector terminal of left/right step lamps.

Terminals				Continuity
BCM		Step lamp		
Connector	Terminal (wire color)	Connector	Terminal (wire color)	
M20	33 (R/W)	D109	- (R/W)	Yes
M20	33 (R/W)	D11	- (R/W)	Yes



OK or NG

- OK >> Connect step lamp electrical connector. GO TO 4.
- NG >> Check for short circuit or open circuit in harness between BCM and interior lamp. Repair as necessary.

STEP LAMP

3. INSPECTION 2 BETWEEN BCM AND STEP LAMP

Check voltage between harness connector terminal of BCM and body ground.

Terminals		Body ground (-)	Voltage (Approx.)
BCM (+)			
Connector	Terminal (wire color)		12
M20	33 (R/W)		

OK or NG


- OK >> Replace BCM.
- NG >> Replace step lamp.

Bulb Replacement

1. Pry lens cover from lamp assembly.
 2. Push and turn bulb to remove.
- Installation is reverse order of removal.

Removal and Installation

1. Carefully pry lens from door finisher.
 2. Disconnect electrical connector.
- Installation is reverse order of removal.



EKS0042U

EKS0042V

BACK-UP LAMP

PF:26550




EKS0042W

BACK-UP LAMP

Wiring Diagram — BACK/L —

LT-BACK/L-01

⬡ A : WITH A/T
 ⬡ M : WITH M/T



REFER TO THE FOLLOWING.

(M4) - FUSE BLOCK - JUNCTION BOX (J/B)
 (B37) - JOINT CONNECTOR (J/C)

LKWA0037E

BACK-UP LAMP

Bulb Replacement

EKS0042X

1. Remove rear combination lamp. Refer to [LT-102, "Removal and Installation for Rear Combination Lamp"](#) .
2. Turn bulb socket counterclockwise to unlock and remove.
3. Pull bulb from socket to remove.

Installation is reverse order of removal.

Removal and Installation

EKS0042Y

The back-up lamp is part of the rear combination lamp assembly. For removal and installation, refer to [LT-102, "Removal and Installation for Rear Combination Lamp"](#) .

PARKING, LICENSE PLATE AND TAIL LAMPS

PFP:26550

System Description

EKS0042Z

Control of the parking, license plate, and tail lamp operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST position, the BCM receives input requesting the parking, license plate, and tail lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking, license plate, and tail lamps, which then illuminate.

Power is supplied at all times

- to tail lamp relay, located in the IPDM E/R (intelligent power distribution module engine room)
- through 10A fuse [No. 38, located in the IPDM E/R (intelligent power distribution module engine room)].

Power is also supplied at all times

- to BCM (body control module) terminal 7
- through 50A fusible link (letter f , located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to BCM (body control module) terminal 35
- through 10A fuse [No. 12, located in the fuse block (J/B)].

With the ignition switch in the ACC or ON position, power is supplied

- to BCM (body control module) terminal 36
- through 10A fuse [No. 6, located in the fuse block (J/B)].

Ground is supplied

- to BCM (body control module) terminals 8, 27, and 63
- through body grounds M57, M61, E15, and E24.

OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1st or 2nd position (or if the auto light system is activated), the BCM (body control module) receives input requesting the parking, license plate, and tail lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power

- through terminal 37 of the IPDM E/R
- to front turn signal lamp LH terminal 1,
- to front turn signal lamp RH terminal 1,
- to rear combination lamp LH terminal 2,
- to rear combination lamp RH terminal 2,
- to license lamp LH terminal +, and
- to license lamp RH terminal +.

Ground is supplied at all times

- to front turn signal lamp LH terminal 2,
- through body grounds E15 and E24, and
- to front turn signal lamp RH terminal 2,
- through body grounds E15 and E24, and
- to rear combination lamp LH terminal 5
- through body grounds B7 and B19, and
- to rear combination lamp RH terminal 5
- through body grounds B7 and B19, and
- to license lamp LH terminal –,
- through body grounds B7 and B19, and
- to license lamp RH terminal –
- through body grounds B7 and B19.

With power and ground supplied, the parking, license and tail lamps illuminate.

A
B
C
D
E
F
G
H
I
J

LT

L
M

PARKING, LICENSE PLATE AND TAIL LAMPS

BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST (or 2ND) position, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the parking, license plate, and tail lamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the parking, license plate, and tail lamps are turned off.


CAN Communication System Description

EKS00430

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R ^(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R

PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R ^(R range only)	


PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R ^(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

PARKING, LICENSE PLATE AND TAIL LAMPS

FOR M/T MODELS

System diagram



LKIA0018E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R ^(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T


PARKING, LICENSE PLATE AND TAIL LAMPS

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Rear window defogger switch signal			T	R
Rear window defogger control signal	R		R	T

PARKING, LICENSE PLATE AND TAIL LAMPS

Schematic

EKS00431





A
B
C
D
E
F
G
H
I
J
LT
L
M

WKWA0411E

PARKING, LICENSE PLATE AND TAIL LAMPS

EKS00432


Wiring Diagram — TAIL/L —




LKWA0038E

PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02



A
B
C
D
E
F
G
H
I
J
LT
L
M







REFER TO THE FOLLOWING.
 (E130) - SUPER MULTIPLE JUNCTION (SMJ)

WKWA0412E

PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-03



REFER TO THE FOLLOWING.
 (M17), (B37) - JOINT CONNECTOR (J/C)

WKWA0413E

PARKING, LICENSE PLATE AND TAIL LAMPS

EKS00433

Parking, License Plate and Tail Lamps Do Not Illuminate

1. INSPECTION 1 BETWEEN IPDM E/R AND PARKING, LICENSE PLATE AND TAIL LAMPS

1. Start active test. Refer to [LT-18, "ACTIVE TEST"](#).
2. Check operation of the parking lamps, license plate lamps and tail lamps.


OK or NG

- OK >> GO TO 4.
 NG >> GO TO 2.


2. INSPECTION 2 BETWEEN IPDM E/R AND PARKING, LICENSE PLATE AND TAIL LAMP

1. Disconnect IPDM E/R connector, turn signal lamp connector, license plate lamp connector and combination lamp connectors.
2. Check continuity between harness connector terminal of IPDM E/R and harness connector terminals of turn signal lamp, license plate lamp and combination lamp.


Terminals				Continuity	
IPDM E/R		Turn signal lamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E122	37 (R/L)	Right	E109	1 (R/L)	Yes
		Left	E12	1 (R/L)	



Terminals				Continuity	
IPDM E/R		Rear combination lamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E122	37 (R/L)	Right	B36	2 (R/L)	Yes
		Left	B35	2 (R/L)	



Terminals				Continuity	
IPDM E/R		License lamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E122	37 (R/L)	Right	B33	+ (R/L)	Yes
		Left	B31	+ (R/L)	



OK or NG

- OK >> Connect electrical connectors. GO TO 3.
 NG >> Check for short circuit or open circuit in harnesses between IPDM E/R and turn signal lamp, between IPDM E/R and rear combination (tail and side marker) lamp, and between IPDM E/R and license lamp.


PARKING, LICENSE PLATE AND TAIL LAMPS

3. IPDM E/R INSPECTION

Start active test. Refer to [LT-18, "ACTIVE TEST"](#) .


- When tail lamp relay is operating, check voltage between turn signal connector terminal 1 and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector		Terminal (wire color)	12
Right	E109	1 (R/L)	
Left	E12		
		Ground	




- When tail lamp relay is operating, check voltage between rear combination (tail) lamp terminal 2 and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector		Terminal (wire color)	12
Right	B36	2 (R/L)	
Left	B35		
		Ground	



- When tail lamp relay is operating, check voltage between license lamp terminal + and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector		Terminal (wire color)	12
Right	B33	+ (R/L)	
Left	B31		
		Ground	



OK or NG

- OK >> Inspect turn signal harness, connectors, and rear combination lamp sub-harness.
- NG >> Replace IPDM E/R. Refer to [PG-24, "Removal and Installation of IPDM E/R"](#) .

4. INSPECTION 1 BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II. Carry out "BCM C/U" self-diagnosis.

Displayed results of self-diagnosis

No malfunction detected>> GO TO 5.

CAN communications or CAN system>> Inspect the BCM CAN communications system. Refer to [BCS-15, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .

OPEN DETECT 1 - 5>> Combination switch system malfunction. Refer to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#) .

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED	

LKIA0073E

PARKING, LICENSE PLATE AND TAIL LAMPS

5. INSPECTION 2 BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II. With "HEADLAMP" data monitor, check that "TAIL LAMP SW" turns ON-OFF linked with operation of lighting switch.

OK or NG

- OK >> Replace BCM.
- NG >> Replace lighting switch.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
ACC ON SW	ON
AUTO LIGHT SW	ON
TAIL LAMP SW	OFF
HEAD LAMP SW	OFF
HI BEAM SW	OFF
PASSING SW	OFF
FR FOG SW	OFF
DOOR SW-DR	OFF

LKIA0077E

Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

EKS00434

1. IPDM E/R INSPECTION

1. Turn the ignition switch ON. Place the combination switch (lighting switch) in the ON position. Turn the ignition switch OFF.
2. Verify that the parking, license plate, and tail lamps turn OFF after approximately 10 minutes.

OK or NG


- OK >> Normal.
- NG >> Ignition relay malfunction. Refer to [PG-19, "Function of Detecting Ignition Relay Malfunction"](#).

Bulb Replacement LICENSE PLATE LAMP

EKS00435

1. From trunk, turn bulb socket counterclockwise to unlock and remove.
2. Pull bulb to remove from socket.

License plate lamp : 12V 5W



FRONT TURN SIGNAL (PARKING) LAMP

For bulb replacement, refer to [LT-25, "FRONT TURN SIGNAL LAMP"](#).

TAIL LAMP

1. Remove rear combination lamp. Refer to [LT-102, "Removal and Installation for Rear Combination Lamp"](#).
2. Turn bulb socket counterclockwise to unlock and remove.
3. Pull bulb to remove from socket.

Tail lamp : 12V 8W

PARKING, LICENSE PLATE AND TAIL LAMPS


EKS00436

Removal and Installation

LICENSE PLATE LAMP

Removal


1. Remove the license lamp finisher. Refer to [EI-22, "Removal and Installation"](#).
2. Disconnect the license plate lamp connector.
3. Remove the license plate lamp mounting screw and remove the license plate lamp from the vehicle.



Installation

Install in the reverse order of removal.

License plate lamp mounting screw:

 : 1.3 - 1.8 N·m (0.13 - 0.18 kg-m, 11 - 16 in-lb)

FRONT TURN SIGNAL (PARKING) LAMP

For front turn signal (parking) lamp removal and installation procedures, refer to [LT-25, "Removal and Installation"](#).

REAR COMBINATION LAMP

Removal

For rear combination lamp removal and installation procedures, refer to [LT-102, "Removal and Installation for Rear Combination Lamp"](#).

INTERIOR ROOM LAMP

INTERIOR ROOM LAMP

PFP:26410

System Description

EKS00437

When room lamp switch is in DOOR position, room lamp ON/OFF is controlled by timer according to signals from switches including key detection switch, driver door switch, driver door lock switch.

When room lamp turns ON, there is a gradual brightening over 1 second. When room lamp turns OFF, there is a gradual dimming over 1 second

The interior room lamp timer is controlled by the BCM.

Interior room lamp timer control settings can be changed with CONSULT-II.

INTERIOR LAMP TIMER OPERATION

When room lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for interior lamp ON/OFF.

In addition, when lamp turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- to 10A fuse [No. 19 (located in the fuse block (J/B))]
- through joint connector -1 terminal 4
- to key switch and key lock solenoid terminal 3.

When all doors are closed (all door switches OFF) and key is removed from key cylinder (key detection switch OFF), power will not be supplied to BCM terminal 62.

When driver door lock switch is turned ON (unlocked),

Ground is supplied

- from BCM terminal 30
- to front door lock actuator LH terminal 1.

At this time, BCM detects that driver door is unlocked. It determines that interior lamp timer operation conditions are met, and turns the interior lamp ON for 30 seconds.

When all doors are closed (all door switches OFF) and key is in key cylinder (key detection switch ON),

Power is supplied

- through key switch and key lock solenoid terminal 4
- to BCM terminal 62.

When key is removed from key switch and key lock solenoid (key detection switch OFF), power supply to BCM terminal 62 is terminated. BCM detects that key has been removed, determines that interior lamp timer conditions are met, and turns the interior lamp ON for 30 seconds.

When driver door closes, and the key is not inserted in the key switch and key lock solenoid (key detection switch OFF), BCM terminal 14 or 54 changes from 0V (door open) to 12V (door closed). The BCM determines that conditions for interior lamp operation are met and turns the interior lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked (driver door lock switch turns OFF)
- Driver door is opened (driver door switch turns ON)
- Ignition switch ON.

BATTERY SAVER


If the interior room lamp remains illuminated by the door switch open signal, or if the room lamp switch is in the ON position for more than 30 minutes after the ignition switch is turned to the OFF position, the BCM will automatically turn off the interior room lamp(s).

A
B
C
D
E
F
G
H
I
J
LT
L
M

INTERIOR ROOM LAMP

Component Parts and Harness Connector Location

EKS00438




WKIA0288E

INTERIOR ROOM LAMP


EKS00439

Wiring Diagram — ROOM/L —

LT-ROOM/L-01



- ⬡OV : WITHOUT VEHICLE SECURITY SYSTEM
- ⬡VN : WITH ILLUMINATED VANITY MIRRORS
- ⬡XV : EXCEPT WITH ILLUMINATED VANITY MIRRORS



LKWA0041E

INTERIOR ROOM LAMP

Terminals and Reference Value for BCM

EKS0043A

Terminal No.	Wire color	Signal name	Measuring condition				Standard (V) (Approx.)	
			Ignition switch	Operation or condition				
7	W/B	Battery power supply	OFF	—			12	
8	B	Ground	ON	—			0	
10	P/L	Front door switch RH signal	OFF	Front door switch RH	ON (open)		0	
					OFF (closed)		12	
11	R/B	Rear door switch (LH and RH) signal	OFF	Rear door switch (LH and RH)	ON (open)		0	
					OFF (closed)		12	
14	SB	Front door switch LH signal	OFF	Front door switch LH	ON (open)		0	
					OFF (closed)		12	
32	R	Interior lamp signal	OFF	Interior lamp switch: DOOR position	Key is inserted.	Any door switch	ON (open)	0
						OFF (closed)	12	
				—	Interior lamp switch: DOOR position	All doors are closed.	Vehicle key is removed after being fully inserted.	
						Turn ignition switch to ON.	12	
30	Y/R	Driver door lock signal	OFF	Door is unlocked. (SW ON)			0	
				Door is locked. (SW OFF)			5	
62	B/R	Key detection switch signal	OFF	Vehicle key is removed.			0	
				Vehicle key is inserted.			12	

Note: Becomes approximately 12V approximately 30 seconds after key is removed.

CONSULT-II Function


EKS0043B

CONSULT-II has a display function for work support, self-diagnosis, data monitor, and active test for each part by combining data receiving and sending via the communication line from BCM.

BCM diagnosis part	Check item, diagnosis mode	Description
INTERIOR LAMP	Work support	Changes the setting for each function.
	Data monitor	Displays BCM input data in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.


CONSULT-II BASIC OPERATION

1. With the ignition switch OFF, connect CONSULT-II to the vehicle-side data link connector, then turn ignition switch ON.
2. Touch "START".




INTERIOR ROOM LAMP

3. Touch "BCM" on "SELECT SYSTEM" screen.



4. Select the desired part to be diagnosed on "SELECT TEST ITEM" screen.



WORK SUPPORT

Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "ROOM LAMP TIMER SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED " will be displayed.
7. Touch "END".

Display Item List

Item	Description	CONSULT-II	Factory setting
Room lamp timer setting	Interior lamp ON/OFF can be selected for when driver door lock is released (unlocked).	ON	○
		OFF	—

DATA MONITOR

Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors the individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

A
B
C
D
E
F
G
H
I
J
LT
L
M

INTERIOR ROOM LAMP

Display Item List

Monitor item name "OPERATION OR UNIT"		Contents
IG ON SW	"ON/OFF"	"IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal is displayed.
KEY ON SW	"ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from the key reminder detection switch signal.
DOOR SW - DR	"ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from passenger door switch signal.
LOCK SW DR/AS	"ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF) status, determined from locking detection switch in driver door.
KEY CYL LK SW	"ON/OFF"	Displays "Door locked (ON) status, determined from key cylinder lock switch in driver door.
KEY CYL UN SW	"ON/OFF"	Displays "Door unlocked (OFF) status, determined from key cylinder lock switch in driver door.
LK BUTTON/SIG	"ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
UN BUTTON/SIG	"ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.
DOOR SW - RR	"ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from rear door switch signals.

ACTIVE TEST

Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

Display Item List

Test item	Display on CONSULT-II screen	Description
Interior lamp output	INT LAMP	Interior lamp can be operated by any ON-OFF operations.

Interior Lamp Control Does Not Operate

EKS0043C

1. INSPECTION 1 BETWEEN EACH SWITCH AND BCM

Select BCM on CONSULT-II. Use "INT LAMP" data monitor to check that switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-128, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.
 NG >> Inspect malfunctioning switch system and repair as necessary.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	OFF
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF
KEY CYL LK SW	OFF
KEY CYL UN SW	OFF
LK BUTTON/SIG	OFF

LKIA0085E


INTERIOR ROOM LAMP

2. INSPECTION 1 BETWEEN BCM AND ROOM LAMP

1. Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
2. When room lamp switch is in DOOR position, use active test to verify that room lamp operates.

OK or NG

- OK >> Replace BCM.
- NG >> GO TO 3.




3. INSPECTION 2 BETWEEN BCM AND ROOM LAMP

1. Disconnect BCM connector and room lamp connector.
2. Check for continuity in wiring harness between BCM and room lamp.

Terminals				Continuity
(+)		(-)		
Connector	Terminal (wire color)	Connector	Terminal (wire color)	
M20	32 (R)	R8	2 (R)	Yes

OK or NG

- OK >> Connect room lamp connector. GO TO 4.
- NG >> Check for short circuit or open circuit in harness between BCM and room lamp. Repair as necessary.




4. INSPECTION 3 BETWEEN BCM AND ROOM LAMP

When room lamp switch is in "DOOR" position, check voltage between BCM harness connector and body ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (wire color)	Body ground	
M20	32 (R)		12

OK or NG

- OK >> Replace BCM.
- NG >> Replace room lamp. Refer to [LT-130, "ROOM LAMP"](#).



Bulb Replacement MAP LAMP AND CONSOLE LAMP

EKS0043D

Map Lamp

1. Insert a thin screwdriver in the notch and remove the lens.
2. Remove the screw and remove the shade.
3. Remove the bulb.

Map lamp : 12V 10W

PERSONAL LAMP

1. Insert a thin screwdriver in the notch and remove the lens.

INTERIOR ROOM LAMP

2. Remove the screw and cover plate.
3. Push and turn bulb counterclockwise to remove.

Personal lamp : 12V 8W

Removal and Installation ROOM LAMP

EKS0043E

1. Open the front interior lamp box and remove the screw.
2. Insert a clip driver or a suitable tool and disengage the metal clip fittings of the front interior lamp.
3. Disconnect the connector and remove the front interior lamp.


Room lamp mounting screw:

 : 2.5 - 3.4 N-m (0.25 - 0.35 kg-m, 22 - 30 in-lb)

IGNITION KEY HOLE ILLUMINATION LAMP

1. Remove the lower instrument panel (driver side). Refer to [IP-13, "Driver Lower Instrument Panel"](#).
2. Turn the bulb socket counterclockwise and unlock it.

Ignition key hole illumination lamp : 12V 1.4W



ILLUMINATION**System Description**

EKS0043F

Control of the illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM receives input requesting the illumination lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the illumination lamps, which then illuminate.

Power is supplied at all times

- to tail lamp relay, located in the IPDM E/R (intelligent power distribution module engine room)
- through 10A fuse [No. 38, located in the IPDM E/R (intelligent power distribution module engine room)].

Power is also supplied at all times

- to BCM (body control module) terminal 7
- through 50A fusible link (letter f , located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- to BCM (body control module) terminal 35
- through 10A fuse [No. 12, located in the fuse block (J/B)].

With the ignition switch in the ACC or ON position, power is supplied

- to BCM (body control module) terminal 36
- through 10A fuse [No. 6, located in the fuse block (J/B)].

Ground is supplied

- to BCM (body control module) terminals 8, 27, and 63
- through body grounds M57, M61, E15, and E24.

ILLUMINATION OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM (body control module) receives input requesting the illumination lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The central processing unit of the IPDM E/R controls the tail lamp relay coil, which when energized, directs power

- through terminal 37 of the IPDM E/R
- to illumination control switch terminal 1,
- to A/T device terminal 3,
- to TCS switch terminal 3,
- to audio unit terminal 8,
- to CD player terminal 23,
- to hazard switch terminal 5,
- to rear window defogger switch terminal 5,
- to heated seat switch LH terminal 2,
- to heated seat switch RH terminal 2,
- to A/C control unit terminal 7,
- to A/C auto amplifier terminal 24,
- to combination meter terminal 48, and
- to glove box lamp terminal +.

With the ignition switch in ON or START, power is supplied

- to auto anti-dazzling inside mirror terminal +,
- through 10A fuse [No. 14, located in the fuse block (J/B)], and
- to BCM (body control module) terminal 35,
- through 10A fuse [No. 12, located in the fuse block (J/B)].

With the ignition switch in ON or START, power is also supplied

- to main power window and door lock/unlock switch terminal 12 (with left front only power window anti-pinch system) or terminal 17 (with left and right front power window anti-pinch system),

A

B

C

D

E

F

G

H

I

J

LT

L

M

ILLUMINATION

- to front power window switch RH terminal 5 (with left front only power window anti-pinch system) or terminal 13 (with left and right front power window anti-pinch system),
- to rear power window switch RH terminal 5,
- to rear power window switch LH terminal 5,
- through BCM terminal 29.

Ground is supplied at all times

- to illumination control switch terminal 3,
- to glove box lamp terminal –, and
- to auto anti-dazzling inside mirror terminal –
- through body grounds M57 and M61, and
- to rear power window switch RH terminal 8,
- through body ground B117, and,
- to rear power window switch LH terminal 8,
- through body grounds B7 and B19.

The main power window and door lock/unlock switch and the front power window switch RH illumination circuits are case grounded.

Controlled ground is supplied

- to A/T device terminal 4,
- to TCS switch terminal 4,
- to audio unit terminal 7,
- to CD player terminal 25,
- to hazard switch terminal 4,
- to rear window defogger switch terminal 6,
- to heated seat switch LH terminal 1,
- to heated seat switch RH terminal 1,
- to A/C control unit terminal 8,
- to A/C auto amplifier terminal 25, and
- to combination meter terminal 47
- from illumination control switch terminal 2.

With power and ground supplied, illumination lamps illuminate.

BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST or 2ND position (or if auto light system is activated), and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 30 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the illumination lamps are turned off after a 30 second delay.

When the lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

CAN Communication System Description


EKS0043G

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

ILLUMINATION

FOR TCS MODELS

System diagram



LKIA0015E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R ^(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		

ILLUMINATION

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System diagram



LKIA0017E

Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R ^(R range only)	
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R ^(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R

ILLUMINATION

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

FOR M/T MODELS

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R


ILLUMINATION

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Blower fan switch signal	R ^(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T
Rear window defogger switch signal			T	R
Rear window defogger control signal	R		R	T

ILLUMINATION

EKS0043H

Schematic




A
B
C
D
E
F
G
H
I
J
LT
L
M

LKWA0063E

ILLUMINATION

Wiring Diagram — ILL —

EKS0043I



LT-ILL-01

— : DATA LINE

REFER TO "PG-POWER".



REFER TO THE FOLLOWING.

(E130) - SUPER MULTIPLE

JUNCTION (SMJ)

(M16) - JOINT



CONNECTOR (J/C)



LKWA0042E

ILLUMINATION

LT-ILL-02





REFER TO THE FOLLOWING.
 (M130) - SUPER MULTIPLE JUNCTION (SMJ)
 (M17), (M66) - JOINT CONNECTOR (J/C)

LKWA0075E

ILLUMINATION

LT-ILL-03


- ⬡MA : WITH MANUAL A/C
- ⬡AA : WITH AUTO A/C
- ⬡HS : WITH HEATED SEATS




LKWA0043E

ILLUMINATION

LT-ILL-04



- ⬡A1 : WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM
- ⬡A2 : WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM
- ⬡VN : WITH ILLUMINATED VANITY MIRRORS
- ⬡XV : EXCEPT WITH ILLUMINATED VANITY MIRRORS
- *1 ⬡A1 : 12
⬡A2 : 17
- *2 ⬡A1 : 5
⬡A2 : 13



REFER TO THE FOLLOWING.
 ⬡M16 - JOINT CONNECTOR (J/C)

LKWA0044E


ILLUMINATION

EKS0043J

Removal and Installation

ILLUMINATION CONTROL SWITCH

1. Remove driver lower instrument panel. Refer to [IP-13, "Driver Lower Instrument Panel"](#).
2. Press the illumination control switch retaining tabs and remove the unit from the driver lower instrument panel.



GLOVE BOX LAMP

1. Through the passenger air bag connector access in the top of the glove box, remove bulb socket by turning counterclockwise.
2. Pull the bulb from the socket to remove.

Glove box lamp : 12V 3.4W

VANITY MIRROR AND TRUNK ROOM LAMPS




PF26470

EKS0043K

VANITY MIRROR AND TRUNK ROOM LAMPS

Wiring Diagram — INT/L —







LT-INT/L-01



WKWA0198E

VANITY MIRROR AND TRUNK ROOM LAMPS

LT-INT/L-02



REFER TO THE FOLLOWING.
(M16) , (B37) - JOINT CONNECTOR (J/C)

WKWA0199E


VANITY MIRROR AND TRUNK ROOM LAMPS

Bulb Replacement for Vanity Mirror Lamp

EKS0043L

1. Insert a thin screwdriver in the notch and remove the lens.
2. Remove the bulb.

Vanity mirror lamp : 14V 1.8W




Bulb Replacement, Removal and Installation for Trunk Room Lamp

EKS0043M

1. Unfold tab A and remove the lens.
2. Remove the trunk room lamp while pressing tab B in the direction of the arrow.
3. Disconnect the trunk room lamp connector.
4. Pull bulb from socket to remove.

Trunk room lamp : 12V 3.4W



A

B

C

D

E

F

G

H

I

J

LT

L

M

BULB SPECIFICATIONS

BULB SPECIFICATIONS

PFP:26297

Headlamp

EKS0043N

Item	Wattage (W)
Low (halogen)	55 (H1)
Low (xenon)	35 (D2R)
High	60W (HB3)

Exterior Lamp

EKS0043O

Item	Wattage (W)
Front combination lamp	Turn signal lamp/parking lamp 27/8 (amber)
Rear combination lamp	Stop/Tail lamp 27/8
	Turn signal lamp 27
	Back-up lamp 13
	Side marker lamp 5
Fog lamp	51
License plate lamp	5
High-mounted stop lamp (parcel shelf mount)	18

Interior Lamp/Illumination

EKS0043P

Item	Wattage (W)
Glove box lamp	3.4
Ignition key hole illumination lamp	0.74
Map lamp	10
Room lamp	8
Spot lamp	8
Step lamp	3.4
Trunk room lamp	3.4
Vanity mirror lamp	1.4

*: Always check with the Parts Department for the latest parts information.