

SECTION **DI**

DRIVER INFORMATION SYSTEM


A
B
C

CONTENTS

D
E

<p>PRECAUTION 3</p> <p> Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 3</p> <p> Wiring Diagrams and Trouble Diagnosis 3</p> <p>COMBINATION METERS 4</p> <p> Component Parts and Harness Connector Location... 4</p> <p> System Description 4</p> <p> UNIFIED CONTROL METER 4</p> <p> HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER 4</p> <p> POWER SUPPLY AND GROUND CIRCUIT 5</p> <p> WATER TEMPERATURE GAUGE 5</p> <p> TACHOMETER 5</p> <p> FUEL GAUGE 5</p> <p> SPEEDOMETER 5</p> <p> CAN Communication System Description 6</p> <p> FOR TCS MODELS 6</p> <p> FOR A/T MODELS 7</p> <p> FOR M/T MODELS 8</p> <p> Combination Meter 10</p> <p> CHECK 10</p> <p> Schematic 11</p> <p> Wiring Diagram — METER — 12</p> <p> Terminals and Reference Value for Combination Meter 13</p> <p> Meter/Gauges Operation and Odo/Trip Meter 13</p> <p> SELF-DIAGNOSIS FUNCTION 13</p> <p> HOW TO ALTERNATE DIAGNOSIS MODE 13</p> <p> How to Proceed With Trouble Diagnosis 14</p> <p> Diagnosis Flow 14</p> <p> Power Supply and Ground Circuit Check 15</p> <p> Trouble Diagnosis Chart by Symptom 16</p> <p> DIAGNOSIS RESULTS 16</p> <p> Fuel System 16</p> <p> FUEL GAUGE 16</p> <p> LOW-FUEL WARNING LAMP 16</p> <p> Tachometer System 17</p> <p> Engine Coolant Temperature System 18</p> <p> Inspection/Water Temperature Gauge 18</p>	<p> Vehicle Speed System 19</p> <p> Position Indication System (Position Other Than P/N) 19</p> <p> The Fuel Gauge Pointer Fluctuates, Indicates Wrong Value or Varies 20</p> <p> The Fuel Gauge Does Not Move to F- position 20</p> <p> The Fuel Gauge Does Not Work 20</p> <p> Low Fuel Warning Lamp Illuminates at All Times or Does Not Illuminate 21</p> <p> Electrical Components Inspection 21</p> <p> FUEL LEVEL SENSOR UNIT CHECK 21</p> <p> Combination Meter 21</p> <p> REMOVAL AND INSTALLATION 21</p> <p>WARNING LAMPS 22</p> <p> System Description 22</p> <p> OUTLINE 22</p> <p> MALFUNCTION INDICATOR LAMP 22</p> <p> LOW WASHER FLUID LEVEL WARNING LAMP.. 22</p> <p> AIR BAG WARNING LAMP 22</p> <p> SEAT BELT WARNING LAMP 22</p> <p> LOW FUEL LEVEL WARNING LAMP 22</p> <p> LOW OIL PRESSURE WARNING LAMP 22</p> <p> CHARGE WARNING LAMP 23</p> <p> BRAKE WARNING LAMP 23</p> <p> TRUNK WARNING LAMP 23</p> <p> DOOR WARNING LAMP 23</p> <p> ASCD SET INDICATOR LAMP 23</p> <p> CRUISE INDICATOR LAMP 23</p> <p> ABS WARNING LAMP 23</p> <p> TCS OFF WARNING LAMP 23</p> <p> SLIP WARNING LAMP 24</p> <p> CAN Communication System Description 24</p> <p> FOR TCS MODELS 24</p> <p> FOR A/T MODELS 25</p> <p> FOR M/T MODELS 27</p> <p> Schematic 29</p> <p> Wiring Diagram — WARN — 30</p> <p> Terminals And Reference Value For BCM 34</p> <p> Work Flow 34</p> <p> Preliminary Check 34</p>
---	--

F
G
H
I
J
L
M



INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT	34	INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT	51
CONSULT-II Function	35	CONSULT-II Function	52
SELF-DIAGNOSIS PROCEDURE	35	DIAGNOSTIC ITEMS DESCRIPTION	52
DATA MONITOR	36	CONSULT-II BASIC OPERATION PROCEDURE	53
ACTIVE TEST	37	DATA MONITOR	53
Trouble Diagnosis For Door Warning Lamp	37	ACTIVE TEST	54
Oil Pressure Warning Lamp Stays Off (Ignition Switch ON)	37	SELF-DIAGNOSTIC RESULTS	54
Oil Pressure Warning Lamp Does Not Turn Off (Oil Pressure Is Normal)	38	All Warnings Are Not Operated	55
Component Inspection	39	Key Warning Chime Does Not Operate	57
OIL PRESSURE SWITCH	39	Light Warning Chime Does Not Operate	58
A/T INDICATOR	40	Seat Warning Chime Does Not Operate	59
Wiring Diagram — AT/IND —	40	BOARD COMPUTER	60
Trouble Diagnosis	41	System Description	60
SYMPTOM CHART	41	FUNCTION	60
A/T Indicator Does Not Illuminate	41	OUTSIDE AIR TEMPERATURE INDICATION	60
WARNING CHIME	42	DTE (DISTANCE TO EMPTY) INDICATION	60
Component Parts and Harness Connector Location	42	TRIP DISTANCE	60
System Description	42	TRIP TIME	60
FUNCTION	42	AVERAGE FUEL CONSUMPTION	60
IGNITION KEY WARNING CHIME	42	AVERAGE VEHICLE SPEED	60
LIGHT WARNING CHIME	43	HOW TO CHANGE/RESET INDICATION	60
SEAT BELT WARNING CHIME	43	CAN Communication System Description	61
CAN Communication System Description	43	FOR TCS MODELS	61
FOR TCS MODELS	43	FOR A/T MODELS	62
FOR A/T MODELS	45	FOR M/T MODELS	64
FOR M/T MODELS	46	Wiring Diagram — B/COMP —	66
Major Component Parts and Function	47	Trouble Diagnoses	68
Wiring Diagram — CHIME —	48	SEGMENT CHECK	68
Terminals and Reference Value for BCM	50	PRELIMINARY CHECK	68
How to Proceed With Trouble Diagnosis	51	DIAGNOSIS PROCEDURE	68
Preliminary Check	51	Electrical Components Inspection	69
		AMBIENT SENSOR	69

PRECAUTION

PRECAUTION

PF0:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00673

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiring Diagrams and Trouble Diagnosis

EKS003F0

When you read wiring diagrams, refer to the following:

- Refer to [GI-12, "How to Read Wiring Diagrams"](#) .
- Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution circuit.

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) .
- Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .

A
B
C
D
E
F
G
H
I
J
DI
L
M


COMBINATION METERS

COMBINATION METERS

PFP:24814

Component Parts and Harness Connector Location

EKS003F1



WKIA1642E

System Description UNIFIED CONTROL METER

EKS003F2


- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled by the unified meter control unit, which is built into the combination meter.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter and A/T indicator segments can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The vehicle speed signal and the memory signals from the meter memory circuit are processed by the combination meter and the mileage is displayed.

COMBINATION METERS

- Depressing the odometer/trip switch toggles the mode in the following order.



- The odo/trip meter display mode toggling and trip display resetting can be identified by the amount of time that elapses from pressing the odo/trip meter switch to releasing it.
- When resetting with trip A displayed, only trip A display is reset (Trip B operates the same way).

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 5.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminals 17 and 18.

Ground is supplied

- to combination meter terminals 6 and 39
- through body grounds M57 and M61.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature.

ECM provides a water temperature signal to combination meter for water temperature gauge with CAN communication line.

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

ECM provides an engine speed signal to combination meter for tachometer with CAN communication line.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 12 for the fuel level sensor
- from terminal G of the fuel level sensor unit
- through terminal E of the fuel level sensor unit and
- through body grounds M57 and M61.

SPEEDOMETER

The vehicle speed sensor provides a vehicle speed signal to the combination meter for speedometer indication.

COMBINATION METERS


EKS003F3

CAN Communication System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		

COMBINATION METERS

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R ^(R range only)	
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R ^(QR25DE)			T	
Cooling fan motor operation signal	R			T	

COMBINATION METERS

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

FOR M/T MODELS

System Diagram



COMBINATION METERS

Input/Output Signal Chart

T: Transmit R: Receive



Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R ^(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T
Rear window defogger switch signal			T	R
Rear window defogger control signal	R		R	T

A
B
C
D
E
F
G
H
I
J
DI
L
M

COMBINATION METERS

Combination Meter CHECK

EKS003F4



48	47	46	45	44	43	42	41	40	39	38	37	36
35	34	33	32	31	30	29	28	27	26	25		

(M23)

24	23	22	21	20	19	18	17	16	15	14	13	12
11	10	9	8	7	6	5	4	3	2	1		

(M24)

Bulb socket color	Bulb wattage
Black	3.0W

() : Bulb socket color

- AS : With ASCD
- BD : With board computer
- U : For USA
- C : For Canada
- TS : With TCS


WKIA1763E

COMBINATION METERS

Schematic

EKS003F5

AS : WITH ASCD
 IS : WITH TCS



A
 B
 C
 D
 E
 F
 G
 H
 I
 J
DI
 L
 M


WKWA0204E

COMBINATION METERS


EKS003F6

Wiring Diagram — METER —

DI-METER-01



- : DATALINE
- AT : WITH AT
- QR : WITH QR25DE
- VQ : WITH VQ35DE
- *1 QR : 33
- *1 VQ : 109
- *2 QR : 34
- *2 VQ : 113



COMBINATION METERS

Terminals and Reference Value for Combination Meter

EKS003F7

TERMI- NAL	WIRE COLOR	ITEM	CONDITION		Voltage (V) (Approx.)
			Ignition switch	Operation or condition	
1	L	CAN-H	—	—	—
2	Y	CAN-L	—	—	—
5	Y/R	Battery power supply	—	—	12
6	B	Ground	—	—	0
11	L/Y	Vehicle speed signal	ON	Speedometer operated [When vehicle speed is approx. 20 km/h (12 MPH)]	Approx. 240 Hz
12	G/B	Fuel level sensor signal	ON	—	Refer to DI-21. "FUEL LEVEL SENSOR UNIT CHECK" .
17	GY	Ignition switch ON or START	ON	—	12
18	GY	Ignition switch ON or START	ON	—	12
39	B	Ground	—	—	0

Meter/Gauges Operation and Odo/Trip Meter SELF-DIAGNOSIS FUNCTION

EKS003F8

- Odo/trip meter (board computer) segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn the ignition switch ON, and switch the odometer/trip meter to "trip A" or "trip B".


NOTE:

If the diagnosis function is activated with the trip meter A displayed, the mileage on the trip meter A will indicate 000.0 miles, but the actual trip mileage will be retained. (Trip B operates the same way.)

2. Turn the ignition switch OFF.
3. While pushing the odo/trip meter switch, turn the ignition switch ON again.
4. Check that the trip meter displays "000.0".
5. Push the odo/trip meter switch at least 7 times within 7 seconds.
6. All the segments on the odo/trip meter illuminate, and simultaneously the low-fuel warning lamp indicator illuminates. At this time, the unified meter control unit is turned to diagnosis mode.

NOTE:


If any of the segments is not displayed, replace the combination meter.



WKIA0057E

COMBINATION METERS

7. Push the odo/trip meter switch. Each meter/gauge should indicate as shown in the figure while pushing odo/trip meter switch. (At this time, the low-fuel warning lamp goes off).



EKS003F9

How to Proceed With Trouble Diagnosis

1. Confirm the trouble symptom or customer complaint.
2. Perform diagnosis according to diagnosis flow. Refer to [DI-14, "Diagnosis Flow"](#) .
3. According to the trouble diagnosis chart, repair or replace the cause of the trouble symptom. Refer to [DI-16, "Trouble Diagnosis Chart by Symptom"](#) .
4. Does the meter operate normally? Yes: Go to 5. No: Go to 2.
5. Inspection End

Diagnosis Flow

EKS003FA

1. WARNING LAMP ILLUMINATION INSPECTION

1. Turn the ignition switch ON.
2. Check that warning lamps (such as MIL and oil pressure warning lamp) illuminate.

Do warning lamps illuminate?

Yes >> GO TO 2.

No >> Check ignition power supply system of combination meter. Refer to [DI-15, "Power Supply and Ground Circuit Check"](#) .

2. SELF-DIAGNOSIS OPERATION CHECK

Perform combination meter self-diagnosis. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#) .

Does self-diagnosis function operate?

Yes >> GO TO 3.

No >> Check battery power supply of combination meter and ground system. Refer to [DI-15, "Power Supply and Ground Circuit Check"](#) .

3. ODO/TRIP METER OPERATION CHECK

Check segment display status of odo/trip meter. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#) .

Is the display normal?

Yes >> GO TO 4.

No >> Replace the combination meter.

4. FUEL WARNING LAMP ILLUMINATION CONFIRMATION

During fuel warning lamp check, confirm illumination of fuel warning lamp. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#) .

Does fuel warning lamp illuminate?

Yes >> GO TO 5.

No >> Replace the combination meter.

COMBINATION METERS

5. METER CIRCUIT CHECK

During meter circuit check, confirm meter illumination. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#).
Is the display normal?

- Yes >> Go to diagnosis results. Refer to [DI-16, "DIAGNOSIS RESULTS"](#).
- No >> Replace the combination meter.

Power Supply and Ground Circuit Check

EKS003FB

1. CHECK FUSES

- Check for blown combination meter fuses.

Unit	Power source	Fuse No.
Combination meter	Battery	19
	Ignition switch ON or START	14


OK or NG

- OK >> GO TO 2.
- NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect the combination meter connector.
2. Check voltage between combination meter harness connectors M24 terminal 5 (Y/R), 17 (GY), 18 (GY) and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ON	START
Connector	Terminal (Wire color)	Ground	Battery voltage	Battery voltage	Battery voltage
M24	5 (Y/R)		0V	Battery voltage	Battery voltage
M24	17 (GY)		0V	Battery voltage	Battery voltage
M24	18 (GY)			Battery voltage	Battery voltage



OK or NG

- OK >> GO TO 3.
- NG >> Check harness for open or short between combination meter and fuse.

3. GROUND CIRCUIT CHECK

Check continuity between combination meter harness connector terminal 6 (B) and 39 (B), and ground.

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)	Ground	Yes
M24	6 (B)		
M23	39 (B)		

OK or NG

- OK >> Inspection End
- NG >> Check ground harness.

COMBINATION METERS

Trouble Diagnosis Chart by Symptom DIAGNOSIS RESULTS

EKS003FC

Trouble phenomenon	Inspection contents		Possible cause
Fuel warning lamp indication is irregular.	Inspect the sensor system of the gauge (warning lamp) with the irregular indication.	NG	<ul style="list-style-type: none"> ● Refer to DI-16, "Fuel System". ● Refer to DI-17, "Tachometer System". ● Refer to DI-18, "Engine Coolant Temperature System".
Indication is not normal for one of the following: tachometer, fuel gauge, or water temperature gauge		OK	Combination meter
Indication is irregular for the speedometer and odo/trip meter.	Inspect the vehicle speed input signal.	NG	Refer to DI-19, "Vehicle Speed System" .
		OK	Combination meter
Indications are irregular for more than one gauge.	—		Combination meter
A/T position indication (other than P or N) is not normal.	—		Refer to DI-19, "Position Indication System (Position Other Than P/N)" .

Fuel System

EKS003FD

The following symptoms do not indicate a malfunction.

FUEL GAUGE

- Depending on vehicle position or driving circumstance, the fuel in the tank flows and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

LOW-FUEL WARNING LAMP

Depending on vehicle position or driving circumstance, the fuel in the tank flows and the warning lamp ON timing may change.

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Check meter, fuel level sensor unit and terminals (meter-side, unit-side, harness-side) for looseness or bent terminals.

OK or NG


- OK >> GO TO 2.
NG >> Repair terminal or connector.

COMBINATION METERS

2. CONTINUITY INSPECTION BETWEEN COMBINATION METER AND FUEL LEVEL SENSOR UNIT

1. Disconnect combination meter connector and fuel level sensor unit connector.
2. Check continuity (open circuit) between combination meter harness connector M24 terminal 12 (G/B) and fuel level sensor unit harness connector B16 terminal G (G/B).
3. Check continuity (short circuit) between combination meter harness connector M24 terminal 12 (G/B) and ground.

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M24	12 (G/B)	B16	G (G/B)	Yes
M24	12 (G/B)	—	Ground	No




OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

3. GROUND CIRCUIT INSPECTION OF FUEL LEVEL SENSOR

- Check continuity (open circuit) between fuel level sensor unit harness connector B16 terminal E (B) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
B16	E (B)	Ground	Yes



OK or NG

- OK >> GO TO 4.
- NG >> Repair harness or connector.

4. FUEL LEVEL SENSOR INSPECTION

Check components. Refer to [DI-21, "FUEL LEVEL SENSOR UNIT CHECK"](#).

OK or NG

- OK >> GO TO 5.
- NG >> Replace fuel level sensor unit.

5. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

OK or NG

- OK >> Replace the combination meter.
- NG >> Install the fuel level sensor unit properly.

Tachometer System

EKS003FE

1. VISUAL INSPECTION

Check if tachometer fluctuates when the engine starts.

Is the fluctuation acceptable?

- Yes >> GO TO 2.
- No >> GO TO 3.

COMBINATION METERS

2. ENGINE SPEED INSPECTION

Compare the values indicated in the engine speed and tachometer.

Does the engine speed correspond to the speed indicated?

- Yes >> Condition is normal.
- No >> Replace the combination meter.

3. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-106, "CONSULT-II Function"](#) (QR25DE) or [EC-736, "CONSULT-II Function"](#) (VQ35DE).

OK or NG

- OK >> GO TO 4.
- NG >> Go to ECM trouble diagnosis.

4. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#) .

OK or NG

- OK >> Condition is normal.
- NG >> Replace the combination meter.

Engine Coolant Temperature System

EKS003FF

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Check terminals (meter-side, control unit-side, and harness-side) on the meter and ECM for disconnection and bend.

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. ECM SYSTEM INSPECTION

- Perform ECM self-diagnosis. Refer to [EC-106, "CONSULT-II Function"](#) (QR25DE) or [EC-736, "CONSULT-II Function"](#) (VQ35DE).

OK or NG

- OK >> GO TO 3.
- NG >> Go to ECM trouble diagnosis.

3. SELF-DIAGNOSIS INSPECTION

- Perform combination meter self-diagnosis. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#) .

OK or NG

- OK >> Condition is normal.
- NG >> Replace the combination meter.

Inspection/Water Temperature Gauge

EKS003FG

1. ECM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-106, "CONSULT-II Function"](#) (QR25DE) or [EC-736, "CONSULT-II Function"](#) (VQ35DE).

OK or NG

- OK >> GO TO 2.
- NG >> Go to ECM trouble diagnosis.

COMBINATION METERS

2. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#).

OK or NG

- OK >> The combination meter is OK.
- NG >> Replace combination meter.


Vehicle Speed System

EKS003FH

1. CHECK VEHICLE SPEED SENSOR CIRCUITS

1. Remove vehicle speed sensor.
2. Check voltage between combination meter harness connector M24 terminal 11 (L/Y) and ECM harness connector F54 terminal 58 (B).

Terminals				Voltage value (Approx.)
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M24	11 (L/Y)	F54	58 (B)	0.5V




OK or NG

- OK >> Vehicle speed sensor is OK.
- NG >> GO TO 2.

2. CHECK VEHICLE SPEED SENSOR

Check resistance between vehicle speed sensor terminals + and -.

Terminals				Resistance value (Approx.)
(+)		(-)		
Component	Terminal	Component	Terminal	
Vehicle speed sensor	+	Vehicle speed sensor	-	250Ω



OK or NG

- OK >> Check harness or connector between combination meter, vehicle speed sensor and ECM.
- NG >> Replace vehicle speed sensor.

Position Indication System (Position Other Than P/N)

EKS003FI

1. TCM INSPECTION

Perform TCM self-diagnosis. Refer to [AT-41, "SELF-DIAGNOSTIC PROCEDURE \(WITH CONSULT-II\)"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Go to TCM trouble diagnosis.

2. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#).

OK or NG

- OK >> Condition is normal.
- NG >> Replace the combination meter.

COMBINATION METERS

The Fuel Gauge Pointer Fluctuates, Indicates Wrong Value or Varies

EKS003FJ

1. CHECK FUEL GAUGE FLUCTUATION

Test drive vehicle to see if gauge fluctuates only during driving or before or after stopping.

Does the indication value vary only during driving or before or after stopping?

- Yes >> The pointer fluctuation may be caused by fuel level change in the fuel tank. Condition is normal.
No >> Ask the customer about the situation when the symptom occurs in detail, and perform the trouble diagnosis.

The Fuel Gauge Does Not Move to F- position

EKS003FK

1. OBSERVE FUEL GAUGE

Does it take a long time for the pointer to move to F- position?

Yes or No

- Yes >> GO TO 2.
No >> GO TO 3.

2. IDENTIFY FUELING CONDITION

Was the vehicle fueled with the ignition switch ON?

Yes or No

- Yes >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise, it will take a long time to move to F- position because of the characteristic of the fuel gauge.
No >> GO TO 3.

3. OBSERVE VEHICLE POSITION

Is the vehicle parked on an incline?

Yes or No

- Yes >> Check the fuel level indication with vehicle on a level surface.
No >> GO TO 4.

4. OBSERVE FUEL GAUGE POINTER

During driving, does the fuel gauge pointer move gradually toward E - position?

Yes or No

- Yes >> Check the components. Refer to [DI-21, "FUEL LEVEL SENSOR UNIT CHECK"](#) .
No >> The float arm may interfere or bind with any of the components in the fuel tank.

The Fuel Gauge Does Not Work

EKS003FL

1. HARNESS CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Check combination meter, fuel level sensor unit, and terminals (meter-side, module-side, lead-side, and harness-side) for poor connection and bend.

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.

2. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation (refer to [FL-5, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#) , and check whether the float arm interferes or binds with any components inside the fuel tank.

OK or NG

- OK >> Fuel level sensor unit is OK.
NG >> Check fuel level sensor unit. Refer to [DI-21, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

COMBINATION METERS

Low Fuel Warning Lamp Illuminates at All Times or Does Not Illuminate

EKS003FM

1. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#).

OK or NG


- OK >> Check fuel level sensor unit. Refer to [DI-21, "FUEL LEVEL SENSOR UNIT CHECK"](#).
- NG >> Replace combination meter.

Electrical Components Inspection FUEL LEVEL SENSOR UNIT CHECK

EKS003FN

- For removal, refer to [FL-5, "Removal and Installation"](#).
- Check the resistance between terminals G and E.

Measurement terminal		Float position mm (in)		Resistance value (Approx.)
G	E	Full (1)	82.7 (3.3)	4.5 – 5.5Ω
		1/2 (2)	200.3 (7.9)	31.5 – 5.5Ω
		Empty (3)	325.0 (12.8)	80.0 – 83.0Ω



EKS003FO

Combination Meter REMOVAL AND INSTALLATION

For removal and installation procedure, refer to [IP-13, "Combination Meter"](#).

A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING LAMPS

System Description OUTLINE

With ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminals 17 and 18.

Ground is supplied

- to combination meter terminals 6 and 39
- through body grounds M57 and M61,
- to seat belt buckle switch LH terminal 2
- through body grounds B7 and B19,
- to brake fluid level switch terminal 2, and
- to washer fluid level sensor terminal –
- through body grounds E15 and E24.

MALFUNCTION INDICATOR LAMP

During prove out or when an engine control malfunction occurs, ground is supplied

- to combination meter terminal 23
- from ECM terminal 18 (QR25DE engines) or terminal 33 (VQ35DE engines).

When power and ground are supplied, the malfunction indicator lamp illuminates.

LOW WASHER FLUID LEVEL WARNING LAMP

When the washer fluid level is low, ground is supplied

- to combination meter terminal 22
- from washer fluid level sensor terminal +.

When power and ground are supplied, the low washer level warning lamp illuminates.

AIR BAG WARNING LAMP

During prove out or when an air bag malfunction occurs, the ground path is interrupted

- from the air bag diagnosis sensor unit terminal 15
- to combination meter terminal 38.

Ground is supplied

- to combination meter terminals 6 and 39
- through body grounds M57 and M61.

When power and ground are supplied, the air bag warning lamp illuminates.

SEAT BELT WARNING LAMP

When the driver's seat belt is unfastened, ground is supplied

- to combination meter terminal 28
- from seat belt buckle switch LH terminal 1.

When power and ground are supplied, the seat belt warning lamp illuminates.

LOW FUEL LEVEL WARNING LAMP

The amount of fuel in the fuel tank is determined by the fuel level sensor in the fuel tank. A signal is sent

- to combination meter terminal 12
- from fuel level sensor unit terminal G.

The fuel level sensor will illuminate the low fuel level warning lamp when the fuel level is low.

When power and ground are supplied, the low fuel level warning lamp illuminates.

LOW OIL PRESSURE WARNING LAMP

Low oil pressure warning lamp is controlled by the IPDM E/R (Intelligent Power Distribution Module Engine Room).

WARNING LAMPS

Low oil pressure causes oil pressure switch terminal + to provide ground to IPDM E/R terminal 50. The IPDM E/R then signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the low oil pressure warning lamp.

When power and ground are supplied, the low oil pressure warning lamp illuminates.

CHARGE WARNING LAMP

During prove out or when a generator malfunction occurs, ground is supplied

- to combination meter terminal 24
- from generator terminal L.

When power and ground are supplied, the charge warning lamp and brake lamp illuminate.

BRAKE WARNING LAMP

When the parking brake is applied, or if the brake fluid level is low, ground is supplied

- to combination meter terminal 36
- from parking brake switch terminal 1, or
- to combination meter terminal 37
- from brake fluid level switch terminal 1.

When power and ground are supplied, the brake warning lamp illuminates.

TRUNK WARNING LAMP

Trunk warning lamp is controlled by the BCM.

When the trunk is opened, ground is supplied

- to BCM terminal 19
- through body grounds B7 and B19.

The BCM then signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the trunk warning lamp.

When power and ground are supplied, the trunk warning lamp illuminates.

DOOR WARNING LAMP

Door warning lamp is controlled by the BCM.

When one of the doors is opened, ground is supplied to the BCM terminals 10, 11, 14 or 54. The BCM then signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the door warning lamp.

When power and ground are supplied, the door warning lamp illuminates.

ASCD SET INDICATOR LAMP

The ASCD set indicator lamp is controlled by the ECM.

When the ASCD system is turned on and the speed is set, the ECM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the set indicator lamp.

When power and ground are supplied, the set indicator lamp illuminates.

CRUISE INDICATOR LAMP

The cruise indicator lamp is controlled by the ECM.

When the ASCD system is turned on, the ECM signals the combination meter (unified meter control unit) via the CAN lines and ground is provided to the cruise indicator lamp.

When power and ground are supplied, the cruise indicator lamp illuminates.

ABS WARNING LAMP

When an ABS malfunction occurs, ground is supplied

- to combination meter terminal 25
- from ABS actuator and electric unit (control unit) terminal 21.

When power and ground are supplied, the ABS warning lamp illuminates.

TCS OFF WARNING LAMP

When TCS OFF switch is in OFF position, or an TCS malfunction occurs, ground is supplied

- to combination meter terminal 26
- from ABS actuator and electric unit (control unit) terminal 26.

When power and ground are supplied, the TCS OFF warning lamp illuminates.

A
B
C
D
E
F
G
H
I
J

DI

L
M

WARNING LAMPS

SLIP WARNING LAMP

When TCS is in operation, or a TCS malfunction occurs, ground is supplied

- to combination meter terminal 27
- from ABS actuator and electric unit (control unit) terminal 28.

When power and ground are supplied, the slip warning lamp illuminates.


CAN Communication System Description

EKS003FQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System Diagram



LKIA0015E

Input/Output Signal Chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R (R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R

WARNING LAMPS

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R ^(R range only)	


WARNING LAMPS

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R ^(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

WARNING LAMPS

FOR M/T MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R ^(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T


WARNING LAMPS

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Rear window defogger switch signal			T	R
Rear window defogger control signal	R		R	T

WARNING LAMPS

EKS003FR

Schematic





A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING LAMPS

Wiring Diagram — WARN —

EKS003FS



DI-WARN-01



WKWA0207E

WARNING LAMPS



DI-WARN-02



WKWA0208E

WARNING LAMPS



DI-WARN-03



WKWA0209E

WARNING LAMPS

DI-WARN-04



WARNING LAMPS

Terminals And Reference Value For BCM

EKS003FT

TERMINAL	WIRE COLOR	ITEM	CONDITION		Voltage (V) (Approx.)
			IGNITION SWITCH	OPERATION	
10	P/L	Passenger door switch	OFF	Passenger door switch	ON (open) 0
					OFF (closed) 12
11	R/B	Rear door switch(es)	OFF	Rear door switch LH or RH	ON (open) 0
					OFF (closed) 12
14	SB	Driver door switch	OFF	Driver door switch	ON (open) 0
					OFF (closed) 12
19	P	Trunk lamp switch and trunk release solenoid	OFF	Trunk lamp switch	ON (open) 0
					OFF (closed) 12
54	SB	Driver door switch (without vehicle security system)	OFF	Driver door switch	ON (open) 0
					OFF (closed) 12
70	L	CAN-H	—	—	—
71	Y	CAN-L	—	—	—

Work Flow

EKS003FU

1. Check the trouble symptom and customer's requests.
2. Understand the outline of system. Refer to [DI-22, "System Description"](#).
3. Perform the preliminary check. Refer to [DI-34, "Preliminary Check"](#).
4. Referring to Trouble diagnosis chart, repair or replace the cause of the incident. Refer to [DI-37, "Trouble Diagnosis For Door Warning Lamp"](#).
5. Does warning chime system operate normally? If it operates normally, go to step 6. If not, go to step 4.
6. INSPECTION END.

Preliminary Check

EKS003FV

INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check for blown BCM fuses.

UNIT	POWER SOURCE	FUSIBLE LINK
BCM	Battery	f

Refer to [DI-48, "Wiring Diagram — CHIME —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

WARNING LAMPS

2. POWER SUPPLY CIRCUIT CHECK


1. Disconnect BCM connector.
2. Check voltage between BCM connector E39 terminal 7 (W/B) and ground. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#)

Terminals		Ignition switch position	
(+)		OFF	
Connector	Terminal (Wire color)	(-)	
E39	7 (W/B)	Ground	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



3. GROUND CIRCUIT CHECK


Check continuity between BCM harness connector E39 terminal 8 (B) and body ground. Refer to [PG-26, "GROUND CIRCUIT"](#)

Terminals		Continuity	
(+)		(-)	
Connector	Terminal (Wire color)	(-)	
E39	8 (B)	Ground	Yes

OK or NG

OK >> INSPECTION END.

NG >> Check harness ground circuit.




EKS003FW

CONSULT-II Function

- CONSULT-II executes the following functions by combining data reception and command transmission via the communication line from BCM. CAN system inspection, self-diagnosis, data monitor, and active test display.


SELF-DIAGNOSIS PROCEDURE

1. With the ignition switch OFF, connect CONSULT-II to the data link connector, and turn the ignition switch ON.



WARNING LAMPS


2. Touch "START".



3. Select the desired part to be diagnosed on the "SELECT SYSTEM" screen.


NOTE:

If "BCM" is selected, a further selection of "BCM C/U" must be selected before proceeding with the following step.



4. Touch "SELF-DIAG RESULTS".

5. Make the necessary repairs following the diagnostic procedures.



6. After the malfunctions are repaired, erase the self-diagnostic results stored in the control unit by touching "ERASE".

DATA MONITOR

Operation Procedure

1. Touch "SEAT BELT ALM" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all selected test item related signals.
SELECTION FROM MENU	Selects and monitors the specified item.

4. Touch "START".

5. If "SELECTION FROM MENU" is selected, touch the item desired to monitor. If "ALL SIGNALS" is selected, all selected test item related signals are monitored.

6. During monitoring, touching "COPY" will print the monitored item status.

WARNING LAMPS

Data Monitor Item

Monitored item	Description
KEY ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of seat belt switch (driver side).

ACTIVE TEST

Operation Procedure

1. Touch "SEAT BELT ALM" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested ("CHIME"), and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

Active Test Item

Test item	Malfunction detecting condition
CHIME	This test is able to check chime operation.

Trouble Diagnosis For Door Warning Lamp

EKS003FY

Symptom	Diagnostic procedure and repair order
Door warning lamp does not illuminate with any of doors open.	<ul style="list-style-type: none"> ● Check combination meter circuit. Refer to DI-15, "Power Supply and Ground Circuit Check" . ● Check front door switches. Refer to DI-34, "Terminals And Reference Value For BCM" . ● Check rear door switches. Refer to DI-34, "Terminals And Reference Value For BCM" . <p>If the above systems work properly, replace the BCM.</p>
Door warning lamp illuminates constantly.	<ul style="list-style-type: none"> ● Check combination meter circuit. Refer to DI-15, "Power Supply and Ground Circuit Check" . ● Check front door switches. Refer to DI-34, "Terminals And Reference Value For BCM" . ● Check rear door switches. Refer to DI-34, "Terminals And Reference Value For BCM" . <p>If the above systems work properly, replace the BCM.</p>

Oil Pressure Warning Lamp Stays Off (Ignition Switch ON)

EKS003FZ

1. INSPECTION 1 BETWEEN IPDM E/R AND COMBINATION METER

1. Activate IPDM E/R auto active test. Refer to [PG-19, "Auto Active Test"](#) .

Does auto active test activate?


- Yes >> Replace combination meter.
 No >> GO TO 2.

WARNING LAMPS

2. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Disconnect IPDM E/R connector and oil pressure switch connector.
2. Check continuity between IPDM E/R harness connector E121 terminal 50 (P/L) and oil pressure switch connector terminal + (P/L).

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
E121	50 (P/L)	F19 (QR25DE) F106 (VQ35DE)	+ (P/L) + (R/L)	Yes



OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.

3. CHECK OIL PRESSURE SWITCH

1. Check oil pressure switch. Refer to [DI-39, "OIL PRESSURE SWITCH"](#)


OK or NG

- OK >> GO TO 4.
- NG >> Replace the oil pressure switch.

4. IPDM E/R VOLTAGE INSPECTION

1. Connect IPDM E/R connector.
2. Turn the ignition switch ON.
3. Check voltage between IPDM E/R harness connector E121 terminal 50 (P/L) and body ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (Wire color)		
E121	50 (P/L)	Ground	0V



OK or NG

- OK >> Perform BCM self-diagnosis.
- NG >> Replace IPDM E/R.

Oil Pressure Warning Lamp Does Not Turn Off (Oil Pressure Is Normal)

EKS003G0

NOTE:

For oil pressure inspection, refer to [LU-6, "OIL PRESSURE CHECK"](#) (QR25DE) or [LU-17, "OIL PRESSURE CHECK"](#) (VQ35DE).

WARNING LAMPS

1. HARNESS CONTINUITY INSPECTION


1. Disconnect IPDM E/R connector and oil pressure switch connector.
2. Check continuity between IPDM E/R harness connector E121 terminal 50 (P/L) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
E121	50 (P/L)	Ground	No

OK or NG

OK >> GO TO 2.

NG >> Repair harness or connector.



2. IPDM E/R VOLTAGE INSPECTION


1. Connect IPDM E/R connector.
2. Turn the ignition switch ON.
3. Check voltage between IPDM E/R harness connector E121 terminal 50 (P/L) and body ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (Wire color)		
E121	50 (P/L)	Ground	0V

OK or NG

OK >> Check oil pressure switch. Refer to [DI-39, "OIL PRESSURE SWITCH"](#).


NG >> Replace IPDM E/R.



Component Inspection OIL PRESSURE SWITCH

Check continuity between the oil pressure switch and body ground.

	Oil pressure kPa (kg/cm ²)	Continuity
Engine stopped	Less than 0.029 (0.3)	Yes
Engine running	More than 0.029 (0.3)	No



A/T INDICATOR





PF24814

A/T INDICATOR

Wiring Diagram — AT/IND —

EKS003G2

DI-AT/IND-01



REFER TO THE FOLLOWING.

(M4) - FUSE BLOCK (J/B)

WKWA0211E

A/T INDICATOR

Trouble Diagnosis SYMPTOM CHART

EKS003G3

Symptom		Possible cause
A/T indicator lamp is abnormal.	All the lamps are inactive	A/T indicator does not illuminate. Refer to DI-41, "A/T Indicator Does Not Illuminate" .
	One lamp is inactive	<ul style="list-style-type: none">● Perform combination meter self-diagnosis. Refer to DI-13, "Meter/Gauges Operation and Odo/Trip Meter" .● Check the combination meter connectors. If OK, replace combination meter.

A/T Indicator Does Not Illuminate

EKS003G4

1. TCM CONTROL UNIT SYSTEM INSPECTION

Perform TCM self-diagnosis. Refer to [AT-36, "HOW TO READ DTC AND 1ST TRIP DTC"](#) .

OK or NG

OK >> GO TO 2.

NG >> Go to TCM trouble diagnosis.

2. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis. Refer to [DI-13, "Meter/Gauges Operation and Odo/Trip Meter"](#) .

OK or NG

OK >> A/T indicator is OK.

NG >> Replace combination meter.

A
B
C
D
E
F
G
H
I
J
L
M

DI


WARNING CHIME

PF2:24814

WARNING CHIME

Component Parts and Harness Connector Location

EKS003G5



WKIA1644E

System Description

EKS003G6

Item	Description
Ignition key warning chime	Sounds warning chime when driver's door is opened with key in ignition key cylinder and ignition switch "OFF" or "ACC" position.
Light warning chime	Sounds warning chime when driver's door is opened with lighting switch in the 1st or 2nd position and ignition switch "OFF" or "ACC" position.
Seat belt warning chime	Sounds warning chime for approximately 6 seconds after ignition switch is turned "ON" when driver's seat belt is unfastened.

Power is supplied at all times

- through 50A fuse (letter f, located in the fuse and fusible link box)
- to BCM terminal 7, and
- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to key switch and key lock solenoid terminal 3.

Ground is supplied

- to BCM terminal 8
- through body grounds E15 and E24, and
- to combination meter terminals 6 and 39
- through body grounds M57 and M61.

When the proper signal, or combination of signals, is received by the combination meter, the warning chime will sound.

IGNITION KEY WARNING CHIME

Power is supplied

- through key switch and key lock solenoid terminal 4
- to BCM terminal 62.

Ground is supplied

- to BCM terminal 14
- through front door switch LH terminal 2
- through front door switch LH case ground.

With the key inserted in the ignition switch, and the driver's door open, the warning chime will sound.

WARNING CHIME

LIGHT WARNING CHIME

With the key removed from the ignition switch, the driver's door open, and the lighting switch in 1ST or 2ND position, the warning chime will sound. [Except when headlamp battery saver control operates (for 5 minutes after ignition switch is turned to OFF or ACC position) and headlamps do not illuminate.]

Signal is supplied

- from combination switch (lighting switch) terminals 1, 2, 3, 4, 5, 6, 7, 8, 9 and 10
- to BCM terminals 40, 41, 42, 43, 47, 48, 49, 50, 51 and 52.

Ground is supplied

- to BCM terminal 14
- through front door switch LH terminal 2
- through front door switch LH case ground.

With these conditions, when power and ground are supplied, the light warning chime sounds.

SEAT BELT WARNING CHIME

With the driver's seat belt unfastened (seat belt buckle switch LH ON), warning chime will sound for approximately 6 seconds after the ignition switch is turned ON.

Ground is supplied

- to combination meter terminal 28
- through seat belt buckle switch terminal 1
- through seat belt buckle switch terminal 2
- through body grounds B7 and B19.

With these conditions, when power and ground are supplied, the seat belt warning chime sounds.


CAN Communication System Description

EKS003G7

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R(R range only)	R	


WARNING CHIME

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

WARNING CHIME

FOR A/T MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R(R range only)	
Air conditioner switch signal	R			T	
Air conditioner compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R(QR25DE)			T	
Cooling fan motor operation signal	R			T	
Cooling fan speed request signal	T				R
Position lights request			R	T	R
Position lights status				R	T
Low beam request				T	R
Low beam status	R			R	T
High beam request			R	T	R
High beam status	R			R	T
Front fog lights request				T	R
Front fog light status				R	T
OD cancel switch signal		R	T		R
Brake switch signal		R	T		
Vehicle speed signal	R		T		
	R		T	R	
Oil pressure switch			R		T
Sleep request1			R	T	
Sleep request2				T	R
N range switch signal		R	T		
P range switch signal		R	T		
Seat belt buckle switch signal			T	R	
Door switch signal			R	T	R

WARNING CHIME

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Tail lamp request			R	T	R
Turn indicator signal			R	T	
Buzzer output signal			R	T	
Trunk switch signal			R	T	
ASCD main switch signal	T		R		
ASCD cruise signal	T		R		
Wiper operation				R	T
Wiper stop position signal				R	T
Rear window defogger switch signal				T	R
Rear window defogger control signal	R			R	T

FOR M/T MODELS

System Diagram



LKIA0018E

Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R ^(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T

WARNING CHIME

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T
Rear window defogger switch signal			T	R
Rear window defogger control signal	R		R	T

Major Component Parts and Function

EKS003G8



Components	Functions
BCM	Intermittently operates the warning chime by signals from the ignition switch, key switch and key lock solenoid, lighting switch, front door switch LH, and seat belt buckle switch LH.
Warning chime	Generates intermittent sounds by signals from the BCM.

WARNING CHIME

Wiring Diagram — CHIME —

EKS003G9

DI-CHIME-01





WKWA0212E

WARNING CHIME

DI-CHIME-02

▬ : DATALINE









LKWA0060E



WARNING CHIME

Terminals and Reference Value for BCM

EKS003GA

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)	
			Ignition switch	Measurement method		
7	W/B	Battery power supply	OFF	—	12	
8	B	Ground	ON	—	0	
14	SB	Front door switch signal	OFF	Driver door	ON (open)	0
					OFF (closed)	5
40	R/B	COMB SW OUTPUT 2	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
41	R/G	COMB SW OUTPUT 3	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
42	R/Y	COMB SW OUTPUT 4	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
43	L	COMB SW OUTPUT 5	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
47	R/W	COMB SW OUTPUT 1	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	
48	G/W	COMB SW INPUT 1	ON	—	 <p style="text-align: right; font-size: small;">SKIA1119J</p>	

WARNING CHIME

Terminal No.	Wire color	Item	Condition		Voltage (V) (Approx.)
			Ignition switch	Measurement method	
49	G/B	COMB SW INPUT 2	ON	—	 SKIA1119J
50	G/R	COMB SW INPUT 3	ON	—	 SKIA1119J
51	G/Y	Combination switch input 4	ON	Lighting switch and wiper switch are OFF.	5 or more
52	L/W	Combination switch input 5	ON	Lighting switch and wiper switch are OFF.	5 or more
62	B/R	Key switch signal	OFF	Key is removed.	0
				Key is inserted.	12
70	L	CAN H	—	—	—
71	Y	CAN L	—	—	—

How to Proceed With Trouble Diagnosis

EKS003GB

1. Confirm the trouble symptom or customer complaint.
2. Understand operation description and function description. Refer to [DI-42, "System Description"](#).
3. Carry out the Preliminary Check. Refer to [DI-51, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Does the warning chime operate normally? Yes: Go to 6. No: Go to 4.
6. INSPECTION END.

Preliminary Check

EKS003GC

INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

- Check for blown BCM fuses.

UNIT	POWER SOURCE	FUSIBLE LINK
BCM	Battery	f

Refer to [DI-48, "Wiring Diagram — CHIME —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

WARNING CHIME

2. POWER SUPPLY CIRCUIT CHECK


1. Disconnect BCM connector.
2. Check voltage between BCM connector E39 terminal 7 (W/B) and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (Wire color)		
E39	7 (W/B)	Ground	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



3. GROUND CIRCUIT CHECK


Check continuity between BCM harness connector E39 terminal 8 (B) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
E39	8 (B)	Ground	Yes

OK or NG

OK >> INSPECTION END.

NG >> Check harness ground circuit.



CONSULT-II Function

EKS003GD

- CONSULT-II executes the following functions by combining data reception and command transmission via the communication line from BCM: work support, self-diagnosis, data monitor, and active test display.


DIAGNOSTIC ITEMS DESCRIPTION

BCM diagnosis position	Diagnosis mode	Description
KEY WARN ALM	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
LIGHT WARN ALM	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
SEAT BELT ALM	Data monitor	The input data to the BCM control unit is displayed in real time.
	Active test	Operation of electrical loads can be checked by sending driving signal to them.
BCM	Self-diagnostic	BCM performs self-diagnosis of CAN communication and combination switch.


WARNING CHIME

CONSULT-II BASIC OPERATION PROCEDURE


1. With the ignition switch OFF, connect CONSULT-II to the data link connector, and turn the ignition switch ON.




2. Touch "START".



3. Touch "BCM".



4. Touch "KEY WARN ALM", "LIGHT WARN ALM", "SEAT BELT ALM" or "BCM C/U".
5. Select "DATA MONITOR" "ACTIVE TEST" or "SELF-DIAG RESULTS".



DATA MONITOR

Operation Procedure

1. Touch KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BELT ALM" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all selected test item related signals.
SELECTION FROM MENU	Selects and monitors the specified item.

4. Touch "START".

A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING CHIME

5. If "SELECTION FROM MENU" is selected, touch the item desired to monitor. If "ALL SIGNALS" is selected, all selected test item related signals are monitored.
6. During monitoring, touching "COPY" will print the monitored item status.

Data Monitor Item (KEY WARN ALM)

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

Data Monitor Item (LIGHT WARN ALM)

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
TAIL LAMP SW	Indicates [ON/OFF] condition of lighting switch.
FR FOG SW	Indicates [ON/OFF] condition of front fog lamp switch.

Data Monitor Item (SEAT BELT ALM)

Monitored item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of seat belt buckle switch.

ACTIVE TEST

Operation Procedure

1. Touch "KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BELT ALM" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

Active Test Item (KEY WARN ALM)

Test item	Malfunction detecting condition
CHIME	This test is able to check key warning chime operation. Key warning chime sounds after touching "ON" on CONSULT-II screen.

Active Test Item (LIGHT WARN ALM)

Test item	Malfunction detecting condition
CHIME	This test is able to check light warning chime operation. Light warning chime sounds after touching "ON" on CONSULT-II screen.

Active Test Item (SEAT BELT ALM)

Test item	Malfunction detecting condition
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds after touching "ON" on CONSULT-II screen.

SELF-DIAGNOSTIC RESULTS

Operation Procedure

1. Touch "BCM C/U" on "DIAGNOSIS ITEM SELECTION" screen.
2. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
3. Self-diagnostic results are displayed.

WARNING CHIME

Display Item List

Items to be displayed	CONSULT-II display	Description
CAN communication	CAN communication [U1000]	Malfunction is detected in CAN communication.
Combination switch	Diagnosis 1 - 5 systems open circuit	Malfunction is detected in combination switch system.

NOTE:

If "CAN communication [U1000]" is indicated, after printing the monitor item, go to "CAN system". Refer to [LAN-7, "CAN SYSTEM \(FOR TCS MODELS\)"](#) , [LAN-28, "CAN SYSTEM \(FOR A/T MODELS\)"](#) or [LAN-45, "CAN SYSTEM \(FOR M/T MODELS\)"](#) .

All Warnings Are Not Operated


EKS003GE

1. CHIME OPERATION INSPECTION

Select "KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BELT ALM" on CONSULT-II, and perform "CHIME" active test.

Does chime sound?

- OK >> GO TO 4.
- NG >> GO TO 2.



2. BCM SELF-DIAGNOSIS

Select BCM on CONSULT-II, and perform "BCM C/U" self-diagnosis.

Self-diagnostic results content

No malfunction detected>> GO TO 3.

CAN communication [U1000] >> After printing the monitor item, go to "CAN system". Refer to [LAN-7, "CAN SYSTEM \(FOR TCS MODELS\)"](#) , [LAN-28, "CAN SYSTEM \(FOR A/T MODELS\)"](#) or [LAN-45, "CAN SYSTEM \(FOR M/T MODELS\)"](#) .

Diagnosis 1 - 5 systems open circuit>> Malfunction in combination switch system. Go to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#) according to self-diagnostic results.

WARNING CHIME

3. DATA MONITOR INSPECTION

Select BCM on CONSULT-II. Operate each switch with data monitor of “KEY WARN ALM”, “LIGHT WARN ALM” or “SEAT BELT ALM” and check operation status of applicable switches.

Switch operation	CONSULT-II display	Operation status
Ignition switch (ON)	IGN ON SW	ON
Ignition switch (OFF)		OFF
Ignition switch (key in switch)	KEY ON SW	ON
Ignition switch (key out of switch)		OFF
Driver door (open)	DOOR SW-DR	ON
Driver door (closed)		OFF
Headlamp switch (1st position)	TAIL LAMP SW	ON
Headlamp switch (OFF)		OFF
Fog lamp switch (ON)	FR FOG SW	ON
Fog lamp switch (OFF)		OFF
Seat belt switch (closed)	SEAT BELT SW	ON
Seat belt switch (open)		OFF

OK or NG

OK >> Replace combination meter.

NG >> GO TO 4.

4. CONTINUITY INSPECTION OF DOOR SWITCH CIRCUIT

1. Disconnect BCM connector and driver door switch connector.
2. Check harness continuity (open circuit) between BCM harness connector M21 terminal 14 (SB) and driver door switch harness connector B8 terminal 2 (SB).

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M21	14 (SB)	B8	2 (SB)	Yes


3. Check continuity (short circuit) between BCM harness connector M21 terminal 14 (SB) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M21	14 (SB)	Ground	No

OK or NG

OK >> Replace driver door switch.

NG >> Repair harness or connector.



WARNING CHIME

EKS003GF

Key Warning Chime Does Not Operate

1. CHECK FUSE

Check if the key switch and key lock solenoid (key detection) switch fuse is blown. Refer to [DI-48, "Wiring Diagram — CHIME —"](#).

Is the fuse blown?

OK >> Replace fuse. Be sure to repair the cause of the problem before installing new fuse.

NG >> GO TO 2.

2. KEY SWITCH INSPECTION

With "KEY WARN ALM" on the data monitor, insert the key into the ignition cylinder to check ON/OFF operation.

Switch operation	CONSULT-II display	Operation status
Ignition switch (ON)	IGN ON SW	ON
Ignition switch (OFF)		OFF
Ignition switch (key in switch)	KEY ON SW	ON
Ignition switch (key out of switch)		OFF
Driver door (open)	DOOR SW-DR	ON
Driver door (closed)		OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	OFF

WKIA0151E

OK or NG

OK >> Replace BCM.

NG >> GO TO 3.

3. IGNITION SWITCH VOLTAGE INSPECTION

1. Remove key from ignition cylinder.
2. Disconnect key switch and key lock solenoid connector.
3. Check voltage between key switch harness connector M26 terminal 3 (Y/R) and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (Wire color)		
M26	3 (Y/R)	Ground	Battery voltage

OK or NG

OK >> GO TO 4.


NG >> Repair harness or connector.

WARNING CHIME

4. HARNESS CONTINUITY INSPECTION

1. Disconnect BCM connector.
2. Check harness continuity (open circuit) between BCM harness connector M18 terminal 62 (B/R) and key switch harness connector M26 terminal 4 (B/R).

Terminals				Continuity
(+)		(-)		
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)	
M18	62 (B/R)	M26	4 (B/R)	Yes



3. Check harness continuity (short circuit) between BCM harness connector M18 terminal 62 (B/R) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (Wire color)		
M18	62 (B/R)	Ground	No

OK or NG

- OK >> Replace key switch and key lock solenoid.
- NG >> Repair harness or connector.


Light Warning Chime Does Not Operate

EKS003GG

1. DATA MONITOR INSPECTION

With "LIGHT WARN ALM" on the data monitor, confirm "TAIL LAMP SW" and "FR FOG SW" turn ON/OFF when lighting switch and front fog switch are operated.

Switch operation	CONSULT-II display	Operation status
Headlamp switch (1st position)	TAIL LAMP SW	ON
Headlamp switch (OFF)		OFF
Fog lamp switch (ON)	FR FOG SW	ON
Fog lamp switch (OFF)		OFF



OK or NG

- OK >> GO TO 2.
- NG >> Replace lighting switch.

2. INSPECTION BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II, and perform "BCM C/U" self-diagnosis.

Self-diagnostic results content

No malfunction detected>> Replace BCM.

CAN communication or CAN communication system>> Check BCM CAN communication system. Go to [LAN-3, "CAN COMMUNICATION"](#).

Diagnosis 1 - 5 systems open circuit>> Malfunction in combination switch system. Go to [BCS-16, "Combination Switch Inspection According to Self-Diagnostic Results"](#) according to self-diagnostic results.

WARNING CHIME

EKS003GH

Seat Warning Chime Does Not Operate


1. DATA MONITOR INSPECTION

With "SEAT BELT ALM" on the data monitor, confirm "SEAT BELT SW" when the seat belt buckle switch is operated.

Switch operation	CONSULT-II display	Operation status
Seat belt switch (closed)	SEAT BELT SW	ON
Seat belt switch (open)		OFF

OK or NG

- OK >> GO TO 2.
- NG >> Replace seat belt buckle switch.



2. INSPECTION BETWEEN COMBINATION SWITCH AND BCM

Select BCM on CONSULT-II, and perform "BCM C/U" self-diagnosis.

Self-diagnostic results content

- No malfunction detected>> Replace BCM.
- CAN communication or CAN communication system>> Check BCM CAN communication system. Go to [LAN-3, "CAN COMMUNICATION"](#).
- Diagnosis 1 - 5 systems open circuit>> Malfunction in combination switch system. Go to [BCS-16, "Combina-tion Switch Inspection According to Self-Diagnostic Results"](#) according to self-diagnostic results.

A
B
C
D
E
F
G
H
I
J
DI
L
M

BOARD COMPUTER

System Description FUNCTION

The board computer can indicate the following items.

- Outside air temperature
- DTE (distance to empty)
- Trip distance
- Trip time
- Average fuel consumption
- Average vehicle speed

OUTSIDE AIR TEMPERATURE INDICATION

The outside air temperature indication is displayed while the ignition switch is in the ON position.

Signal is supplied

- through ambient sensor terminal 1
- to combination meter (board computer) terminal 13.

Indication range is between -30 and 55°C (-22 and 131°F). When outside temperature is less than -30°C (-22°F), display shows ICY. When outside temperature is more than 55°C (131°F), indication will be blank. When outside temperature is less than 3°C (37°F) continuously, display will blink as a warning. In this case, the display will change to the outside air temperature mode even though the display is showing a different mode. The indicated temperature is not affected by engine heat. It changes only when one of the following conditions exists.

- When vehicle speed is more than 20 km/h (12 MPH).
- The ignition switch has been turned OFF for more than 3.5 hours.
- When outside air temperature is less than the indicated temperature.

DTE (DISTANCE TO EMPTY) INDICATION

The range indication provides the driver with an estimation of the distance that can be driven before refueling. The range is calculated by signals from the fuel level sensor unit (fuel remaining), ECM (fuel consumption) and vehicle speed sensor. The indication will be refreshed every 30 seconds. When fuel remaining is less than approximately 10ℓ (10 5/8 US quarts, 8 3/4 Imp quarts), the indication will blink as a warning. If the fuel remaining is less than approximately 8ℓ (8 1/2 US quarts, 7 Imp quarts), the indication will show "---". In this case, the display will change to the DTE mode even though the display is showing a different mode. When the battery is disconnected and reconnected, DTE mode will display "---" until the vehicle is driven 500 miles (804.5 km).

TRIP DISTANCE

Trip distance is calculated by signal from the vehicle speed sensor. If trip distance is reset, trip time will be reset at the same time.

TRIP TIME

Trip time displays cumulative ignition switch ON time. If trip time is reset, trip distance will be reset at the same time.

AVERAGE FUEL CONSUMPTION

Average fuel consumption indication is calculated by signals from the vehicle speed sensor and the ECM (fuel consumption). The indication will be refreshed every 30 seconds.

AVERAGE VEHICLE SPEED

Average vehicle speed indication is calculated by running distance and running time. The indication will be refreshed every 30 seconds. If average vehicle speed is reset, average fuel consumption will be reset at the same time. After resetting, the display will show "---" for 30 seconds.

HOW TO CHANGE/RESET INDICATION

Indication can be changed in the following order by momentarily depressing the board computer switch or the board computer steering switch.

Outside air temperature → dte → Average fuel consumption → Average vehicle speed → Trip time → Trip distance.

BOARD COMPUTER

Holding the switch for more than 0.8 second will reset the indication of the currently displayed mode (trip distance, trip time, average vehicle speed or average fuel consumption).

NOTE:

After the display changes automatically, the indication can be changed to the last mode by pushing the board computer switch or the board computer steering switch.


CAN Communication System Description

EKS003GJ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

FOR TCS MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive


Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T		R			
Accelerator pedal position signal	T					
Fuel consumption monitor signal	T		R			
A/T warning lamp signal		T	R			
A/T position indicator signal	R	T	R	R(R range only)	R	
ABS operation signal	R				T	
TCS operation signal	R	R			T	
Air conditioner switch signal	R			T		
Air conditioner compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			R	T		R
Position lights status				R		T
Low beam request				T		R
Low beam status	R			R		T
High beam request			R	T		R
High beam status	R			R		T
Front fog lights request				T		R

BOARD COMPUTER

Signals	ECM	TCM	COMBINATION METER	BCM	ABS/TCS control unit	IPDM E/R
Front fog light status				R		T
OD cancel switch signal		R	T			R
Brake switch signal		R	T			
Vehicle speed signal	R		T			
	R		T	R		
Oil pressure switch			R			T
Sleep request1			R	T		
Sleep request2				T		R
N range switch signal		R	T			
P range switch signal		R	T			
Seat belt buckle switch signal			T	R		
Door switch signal			R	T		R
Tail lamp request			R	T		R
Turn indicator signal			R	T		
Buzzer output signal			R	T		
Trunk switch signal			R	T		
ASCD main switch signal	T		R			
ASCD cruise signal	T		R			
Wiper operation				R		T
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R			R		T

FOR A/T MODELS

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T		R		
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				R
Fuel consumption monitor signal	T		R		
A/T warning lamp signal		T	R		
A/T position indicator signal	R	T	R	R (R range only)	


BOARD COMPUTER

Signals	ECM	TCM	COMBINATION METER	BCM	IPDM E/R	
Air conditioner switch signal	R			T		A
Air conditioner compressor signal	R				T	B
A/C compressor request signal	T				R	B
Blower fan switch signal	R ^(QR25DE)			T		C
Cooling fan motor operation signal	R			T		C
Cooling fan speed request signal	T				R	
Position lights request			R	T	R	D
Position lights status				R	T	D
Low beam request				T	R	
Low beam status	R			R	T	E
High beam request			R	T	R	
High beam status	R			R	T	
Front fog lights request				T	R	F
Front fog light status				R	T	
OD cancel switch signal		R	T		R	G
Brake switch signal		R	T			
Vehicle speed signal	R		T			H
	R		T	R		H
Oil pressure switch			R		T	
Sleep request1			R	T		I
Sleep request2				T	R	
N range switch signal		R	T			J
P range switch signal		R	T			J
Seat belt buckle switch signal			T	R		
Door switch signal			R	T	R	DI
Tail lamp request			R	T	R	
Turn indicator signal			R	T		
Buzzer output signal			R	T		L
Trunk switch signal			R	T		
ASCD main switch signal	T		R			M
ASCD cruise signal	T		R			M
Wiper operation				R	T	
Wiper stop position signal				R	T	
Rear window defogger switch signal				T	R	
Rear window defogger control signal	R			R	T	

BOARD COMPUTER

FOR M/T MODELS

System Diagram



LKIA0018E

Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	COMBINATION METER	BCM	IPDM E/R
Engine speed signal	T			
Engine coolant temperature signal	T			
Fuel consumption monitor signal	T			
Air conditioner switch signal	R		T	
Air conditioner compressor signal	R			T
A/C compressor request signal	T			R
Blower fan switch signal	R(QR25DE)		T	
Cooling fan motor operation signal	R			T
Cooling fan speed request signal	T			R
Position lights request		R	T	R
Position lights status			R	T
Low beam request			T	R
Low beam status	R		R	T
High beam request		R	T	R
High beam status	R		R	T
Front fog lights request			T	R
Front fog light status			R	T
Vehicle speed signal	R	T		
Oil pressure switch		R		T
Sleep request1		R	T	
Sleep request2			T	R
Seat belt buckle switch signal		T	R	
Door switch signal		R	T	R
Tail lamp request		R	T	R
Turn indicator signal		R	T	
Buzzer output signal		R	T	
Trunk switch signal		R	T	
ASCD main switch signal	T	R		
ASCD cruise signal	T	R		
Wiper operation			R	T
Wiper stop position signal			R	T

BOARD COMPUTER

Signals	ECM	COMBINATION METER	BCM	IPDM E/R	
Rear window defogger switch signal			T	R	A
Rear window defogger control signal	R		R	T	B

C

D

E

F

G

H

I

J

DI

L



M

BOARD COMPUTER

EKS003GK

Wiring Diagram — B/COMP —

DI-B/COMP-01




REFER TO THE FOLLOWING.
 (F54), (F57) - ELECTRICAL UNITS





WKWA0213E

BOARD COMPUTER

DI-B/COMP-02



A
B
C
D
E
F
G
H
I
J
DI
L
M



* This connector is not shown in "HARNES LAYOUT" of PG section.

WKWA0214E


BOARD COMPUTER

EKS003GL

Trouble Diagnoses SEGMENT CHECK

The board computer segment display can be checked by entering combination meter self-diagnostic mode. Refer to [DI-13, "SELF-DIAGNOSIS FUNCTION"](#).

PRELIMINARY CHECK



LKIA0061E

*1 [DI-68, "DIAGNOSIS PROCEDURE"](#) *2 [DI-10, "CHECK"](#)

DIAGNOSIS PROCEDURE

Symptom	Possible cause	Repair order
Outside air temperature display is not displayed properly. (It may take a short time to steady the indication after ignition switch is turned ON.) NOTE: If the meter is powered up with the ambient sensor disconnected, outside air temperature display will show "---" even if the sensor is reconnected. In this case, with the sensor connected, disconnect and reconnect the battery, then the correct temperature will be displayed.	<ol style="list-style-type: none"> 1. Ambient sensor 2. Ambient sensor circuit 3. Vehicle speed sensor signal 	<ol style="list-style-type: none"> 1. Check ambient sensor. 2. Check harness for open or short between ambient sensor and board computer. 3. Check harness for open or short between combination meter terminal 11 and vehicle speed sensor.
DTE (distance to empty) is not displayed properly.)	<ol style="list-style-type: none"> 1. Average fuel consumption display 2. Fuel tank gauge signal circuit. 	<ol style="list-style-type: none"> 1. Make sure fuel consumption is displayed properly. If NG, check fuel consumption display. 2. Make sure fuel gauge operates properly. If NG, check fuel gauge.
Trip distance is not indicated properly.	<ol style="list-style-type: none"> 1. Vehicle speed sensor signal circuit 	<ol style="list-style-type: none"> 1. Check harness for open or short between combination meter terminal 11 and vehicle speed sensor.

BOARD COMPUTER

Symptom	Possible cause	Repair order
Trip time is not indicated properly.	1. Fuse	1. 10A fuse [No. 19 (located in fuse block (J/B))]. Verify battery voltage is present at combination meter terminal 5.
Average fuel consumption is not displayed properly.	1. Trip distance display 2. Fuel consumption signal	1. Check harness for open or short between combination meter terminal 11 and vehicle speed sensor. 2. Check CAN lines for open or short between ECM and combination meter.
Average vehicle speed is not indicated properly.	1. Trip distance display 2. Trip time display	1. Check harness for open or short between combination meter terminal 11 and vehicle speed sensor. 2. Make sure trip time is displayed properly. If NG, check trip time display.


Electrical Components Inspection AMBIENT SENSOR

EKS003GM

After disconnecting ambient sensor harness connector, measure resistance between terminals 2 and 1 at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace ambient sensor.



BOARD COMPUTER
