

# SECTION **BCS**

## BODY CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

### CONTENTS

|   |   |  |    |
|---|---|--|----|
| <b>PRECAUTIONS</b> .....  | 2 | CAN Communication System Description .....                           | 8  |
| Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 2 | Schematic .....  | 9  |
| <b>BCM (BODY CONTROL MODULE)</b> .....  | 3 | CONSULT-II Function (BCM) .....                                      | 11 |
| System Description .....  | 3 | CONSULT-II INSPECTION PROCEDURE .....                                | 11 |
| BCM FUNCTION .....  | 3 | ITEMS OF EACH PART .....   | 12 |
| COMBINATION SWITCH READING FUNCTION .....   | 3 | WORK SUPPORT .....   | 13 |
| CAN COMMUNICATION CONTROL .....   | 6 | CAN Communication Inspection Using CONSULT-II (Self-Diagnosis) ..... | 13 |
| BCM STATUS CONTROL .....  | 6 | Configuration .....  | 14 |
| SYSTEMS CONTROLLED BY BCM DIRECTLY .....  | 7 | DESCRIPTION .....  | 14 |
| SYSTEMS CONTROLLED BY BCM AND IPDM E/R .....  | 7 | READ CONFIGURATION PROCEDURE .....                                   | 14 |
| MAJOR COMPONENTS AND CONTROL SYSTEM .....   | 7 | WRITE CONFIGURATION PROCEDURE .....                                  | 16 |
|   |   | Removal and Installation of BCM .....                                | 21 |
|   |   | REMOVAL .....  | 21 |
|   |   | INSTALLATION .....   | 21 |

**BCS**

# PRECAUTIONS

---

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS006Q5

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# BCM (BODY CONTROL MODULE)

PFP:284B2

EKS006Q6

## BCM (BODY CONTROL MODULE)

### System Description

- BCM (Body Control Module) controls the operation of various electrical units installed on the vehicle.

### BCM FUNCTION

BCM has a combination switch reading function for reading the operation of combination switches (light, wiper washer, turn signal) in addition to the function for controlling the operation of various electrical components. Also, it functions as an interface that receives signals from the front air control, and sends signals to ECM using CAN communication.


### COMBINATION SWITCH READING FUNCTION

#### 1. Description

- BCM reads combination switch (light, wiper) status, and controls various electrical components according to the results.
- BCM reads information of a maximum of 20 switches by combining five output terminals (OUTPUT 1-5) and five input terminals (INPUT 1-5).

#### 2. Operation description

- BCM activates transistors of output terminals (OUTPUT 1-5) periodically and allows current to flow in turn.
- If any (1 or more) of the switches are turned ON, circuit of output terminals (OUTPUT 1-5) and input terminals (INPUT 1-5) becomes active.
- At this time, transistors of output terminals (OUTPUT 1-5) are activated to allow current to flow. When voltage of input terminals (INPUT 1-5) corresponding to that switch changes, interface in BCM detects voltage change and BCM determines that switch is ON.



#### 3. BCM - Operation table of combination switch

- BCM reads operation status of combination switch by the combination shown in the following table.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

BCS

## BCM (BODY CONTROL MODULE)

|                 | COMB SW OUTPUT 1 |                  | COMB SW OUTPUT 2 |                  | COMB SW OUTPUT 3 |                  | COMB SW OUTPUT 4     |                       | COMB SW OUTPUT 5 |                  |
|-----------------|------------------|------------------|------------------|------------------|------------------|------------------|----------------------|-----------------------|------------------|------------------|
|                 | ON               | OFF              | ON               | OFF              | ON               | OFF              | ON                   | OFF                   | ON               | OFF              |
| COMB SW INPUT 1 | —                | —                | FR WIPER HI ON   | FR WIPER HI OFF  | INT VOLUME 1 ON  | INT VOLUME 1 OFF | RR WIPER INT ON      | RR WIPER INT OFF      | INT VOLUME 2 ON  | INT VOLUME 2 OFF |
| COMB SW INPUT 2 | FR WASHER ON     | FR WASHER OFF    | —                | —                | RR WASHER ON     | RR WASHER OFF    | INT VOLUME 3 ON      | INT VOLUME 3 OFF      | RR WIPER ON      | RR WIPER OFF     |
| COMB SW INPUT 3 | FR WIPER LOW ON  | FR WIPER LOW OFF | FR WIPER INT ON  | FR WIPER INT OFF | —                | —                | AUTO LIGHT ON        | AUTO LIGHT OFF        | —                | —                |
| COMB SW INPUT 4 | TURN LH ON       | TURN LH OFF      | PASSING ON       | PASSING OFF      | HEAD-LAMP 2 ON   | HEAD-LAMP 2 OFF  | FR FOG ON            | FR FOG OFF            | —                | —                |
| COMB SW INPUT 5 | TURN RH ON       | TURN RH OFF      | HEAD-LAMP 1 ON   | HEAD-LAMP 1 OFF  | HI BEAM ON       | HI BEAM OFF      | LIGHTING SW (1st) ON | LIGHTING SW (1st) OFF | —                | —                |


LIIA0759E

**NOTE:**

Headlamp has a dual system switch.

4. Example operation: (When lighting switch 1st position turned ON)
- When lighting switch 1st position is turned ON, contact in combination switch turns ON. At this time if OUTPUT 4 transistor is activated, BCM detects that voltage changes in INPUT 5.
  - When OUTPUT 4 transistor is ON, BCM detects that voltage changes in INPUT 5, and judges lighting switch 1st position is ON. Then BCM sends tail lamp ON signal to IPDM E/R using CAN communication.
  - When OUTPUT 4 transistor is activated again, BCM detects that voltage changes in INPUT 5 and recognizes that lighting switch 1st position is continuously ON.

# BCM (BODY CONTROL MODULE)



## NOTE:

Each OUTPUT terminal transistor is activated at 10 ms intervals. Therefore, after a switch is turned ON, electrical loads are activated with a time delay. But this time delay is so short that it cannot be noticed.

### 5. Operation mode

- Combination switch reading function has operation modes as follows:

Normal status

- When BCM is not in sleep status, OUTPUT terminals (1-5) each turn ON-OFF every 10 ms.


Sleep status

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

BCS

# BCM (BODY CONTROL MODULE)

- When BCM is in sleep mode, transistors of OUTPUT 1 and 5 stop the output, and BCM enters low-current-consumption mode. OUTPUTS (2, 3, and 4) turn ON-OFF at 60ms intervals, and receives lighting switch input only.



## CAN COMMUNICATION CONTROL

CAN communication allows a high rate of information through the two communication lines (CAN-L, CAN-H) connecting the various control units in the system. Each control unit transmits/receives data, but selectively reads required data only.

## BCM STATUS CONTROL

BCM changes its status depending on the operation status in order to save power consumption.

- CAN communication status
  - With ignition switch ON, CAN communicates with other control units normally.
  - Control by BCM is being operated properly.
  - When ignition switch is OFF, switching to sleep mode is possible.
  - Even when ignition switch is OFF, if CAN communication with IPDM E/R and combination meter is active, CAN communication status is active.
- Sleep transient status
  - This status shuts down CAN communication when ignition switch is turned OFF.
  - It transmits sleep request signal to IPDM E/R and combination meter.
  - Two seconds after CAN communication of all control units stops, CAN communication switches to inactive status.
- CAN communication inactive status
  - With ignition switch OFF, CAN communication is not active.
  - With ignition switch OFF, control performed only by BCM is active.
  - Three seconds after CAN communication of all control units stops, CAN communication switches to inactive status.
- Sleep status

# BCM (BODY CONTROL MODULE)

- BCM is activated with low current consumption mode.
- CAN communication is not active.
- When CAN communication operation is detected, it switches to CAN communication status.
- When a state of the following switches changes, it switches to CAN communication state:
  - Key switch
  - Hazard switch
  - Door lock/unlock switch
  - Front door switch (LH, RH)
  - Rear door switch (LH, RH)
  - Back door switch
  - Combination switch (passing, lighting switch 1st position, front fog lamp)
  - Keyfob (lock/unlock signal)
  - Door lock assembly LH (key cylinder switch)
- When control performed only by BCM is required by switch, it shifts to CAN communication inactive mode.
- Status of combination switch reading function is changed.

## SYSTEMS CONTROLLED BY BCM DIRECTLY

- Power door lock system. Refer to [BL-16, "POWER DOOR LOCK SYSTEM"](#) .
- Remote keyless entry system. Refer to [BL-38, "REMOTE KEYLESS ENTRY SYSTEM"](#) .
- Power window system. Refer to [GW-15, "POWER WINDOW SYSTEM"](#) . <sup>NOTE</sup>
- Sunroof system. Refer to [RF-10, "SUNROOF"](#) . <sup>NOTE</sup>
- Room lamp timer. Refer to [LT-124, "INTERIOR ROOM LAMP"](#) .
- Warning chime system. Refer to [DI-42, "WARNING CHIME"](#) .
- Turn signal and hazard warning lamps system. Refer to [LT-75, "TURN SIGNAL AND HAZARD WARNING LAMPS"](#) .
- Rear wiper and washer system. Refer to [WW-33, "REAR WIPER AND WASHER SYSTEM"](#) .

### NOTE:

Power supply only. No system control.

## SYSTEMS CONTROLLED BY BCM AND IPDM E/R

- Vehicle security (theft warning) system. Refer to [BL-67, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .
- Panic system. Refer to [BL-38, "REMOTE KEYLESS ENTRY SYSTEM"](#) .
- NVIS (NATS) system. Refer to [BL-125, "NVIS\(NISSAN Vehicle Immobilizer System-NATS\)"](#) .
- Headlamp, tail lamp, auto light and battery saver control systems. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) or [LT-33, "HEADLAMP \(FOR CANADA\) - DAYTIME LIGHT SYSTEM -"](#) .
- Front wiper and washer system. Refer to [WW-4, "FRONT WIPER AND WASHER SYSTEM"](#) .
- Rear window defogger system. Refer to [GW-73, "REAR WINDOW DEFOGGER"](#) .

## MAJOR COMPONENTS AND CONTROL SYSTEM

| System   | Input  | Output  |
|--|--|---|
| Remote keyless entry system                    | Keyfob                                       | <ul style="list-style-type: none"> <li>● All-door locking actuator</li> <li>● Back door opener actuator</li> <li>● Turn signal lamp (LH, RH)</li> </ul> |
| Power door lock system                         | Front power door lock/unlock switch (LH, RH) | All-door locking actuator   |
| Power supply (IGN) to power window and sunroof | Ignition power supply                        | Power supply to power window and sunroof system   |
| Power supply (BAT) to power window and sunroof | Battery power supply                         | Power supply to power window and sunroof system   |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BCS

## BCM (BODY CONTROL MODULE)

| System                                   | Input   | Output  |
|--|---|---|
| Panic alarm                              | <ul style="list-style-type: none"> <li>● Key switch</li> <li>● Keyfob</li> </ul>  | IPDM E/R  |
| Auto light system                        | <ul style="list-style-type: none"> <li>● Auto light sensor</li> <li>● Combination switch</li> </ul>   | IPDM E/R  |
| Battery saver control                    | <ul style="list-style-type: none"> <li>● Ignition switch</li> <li>● Combination switch</li> </ul>   | IPDM E/R  |
| Headlamp                                 | Combination switch  | IPDM E/R  |
| Tail lamp                                | Combination switch  | IPDM E/R  |
| Fog lamp                                 | Combination switch  | IPDM E/R  |
| Turn signal lamp                         | Combination switch  | <ul style="list-style-type: none"> <li>● Turn signal lamp</li> <li>● Combination meter</li> </ul> |
| Hazard lamp                              | Hazard switch   | <ul style="list-style-type: none"> <li>● Turn signal lamp</li> <li>● Combination meter</li> </ul> |
| Room lamp timer                          | <ul style="list-style-type: none"> <li>● Key switch</li> <li>● Keyfob</li> <li>● Front door lock/unlock switch (LH)</li> <li>● Front door switch LH</li> <li>● All-door switch</li> </ul> | Interior room lamp  |
| Key warning chime                        | <ul style="list-style-type: none"> <li>● Key switch</li> <li>● Front door switch LH</li> </ul>  | Combination meter (warning buzzer)  |
| Light warning chime                      | <ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Key switch</li> <li>● Front door switch LH</li> </ul>  | Combination meter (warning buzzer)  |
| Vehicle-speed-sensing intermittent wiper | <ul style="list-style-type: none"> <li>● Combination switch</li> <li>● Combination meter</li> </ul>   | IPDM E/R  |
| Rear window defogger                     | Rear window defogger switch   | IPDM E/R  |
| Air conditioner switch signal            | Front air control   | ECM   |
| Blower fan switch signal                 | Front air control   | ECM   |

### CAN Communication System Description

EKS006Q7

Refer to [LAN-5, "CAN COMMUNICATION"](#) .




# BCM (BODY CONTROL MODULE)

EKS006Q8

## Schematic

- (PV) : WITH REAR POWER VENT WINDOWS
- (PB) : WITH POWER BACK DOOR
- (XB) : WITHOUT POWER BACK DOOR




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

BCS

WIWA0254E

# BCM (BODY CONTROL MODULE)

- (PB) : WITH POWER BACK DOOR
- (WP) : WITH PUDDLE LAMPS
- (FT) : WITH FOOT LAMPS
- (PV) : WITH REAR POWER VENT WINDOWS
- (TT) : TRAILER TOW / PIN
- (WL) : WITH LOW TIRE PRESSURE WARNING SYSTEM



WIWA0255E

# BCM (BODY CONTROL MODULE)

EKS00609

## CONSULT-II Function (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


| BCM diagnostic test item | Diagnostic mode       | Content   |
|--------------------------|-----------------------|---|
| Inspection by part       | WORK SUPPORT          | Changes setting of each function.   |
|                          | DATA MONITOR          | Displays BCM input/output data in real time.                                  |
|                          | ACTIVE TEST           | Operation of electrical loads can be checked by sending drive signal to them. |
|                          | SELF-DIAG RESULTS     | Displays BCM self-diagnosis results.  |
|                          | CAN DIAG SUPPORT MNTR | The results of transmit/receive diagnosis of CAN communication can be read.   |
|                          | ECU PART NUMBER       | BCM part number can be read.  |
|                          | CONFIGURATION         | Performs BCM configuration read/write functions.                              |

### CONSULT-II INSPECTION PROCEDURE


#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector and turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.



## BCM (BODY CONTROL MODULE)

4. Select item to be diagnosed on “SELECT TEST ITEM” screen.



### ITEMS OF EACH PART

**NOTE:**

CONSULT-II will only display systems the vehicle possesses.


| System and item   | CONSULT-II display   | Diagnostic test mode (Inspection by part) |                   |                       |              |                 |             |                |
|---|----------------------|---|-------------------|-----------------------|--------------|-----------------|-------------|----------------|
|   |                      | WORK SUPPORT                              | SELF-DIAG RESULTS | CAN DIAG SUPPORT MNTR | DATA MONITOR | ECU PART NUMBER | ACTIVE TEST | CON-FIGURATION |
| BCM   | BCM                  | ×   | ×                 | ×                     |              | ×               |             | ×              |
| Power door lock system                                    | DOOR LOCK            | ×   |                   |                       | ×            |                 | ×           |                |
| Rear defogger   | REAR DEFOGGER        |   |                   |                       | ×            |                 | ×           |                |
| Warning chime   | BUZZER               |   |                   |                       | ×            |                 | ×           |                |
| Room lamp timer   | INT LAMP             | ×   |                   |                       | ×            |                 | ×           |                |
| Remote keyless entry system                               | MULTI REMOTE ENT     | ×   |                   |                       | ×            |                 | ×           |                |
| Headlamp  | HEAD LAMP            | ×   |                   |                       | ×            |                 | ×           |                |
| Wiper   | WIPER                |   |                   |                       | ×            |                 | ×           |                |
| Turn signal lamp<br>Hazard lamp                           | FLASHER              |   |                   |                       | ×            |                 | ×           |                |
| Blower fan switch signal<br>Air conditioner switch signal | AIR CONDITIONER      |   |                   |                       | ×            |                 |             |                |
| Combination switch  | COMB SW              |   |                   |                       | ×            |                 |             |                |
| NVIS (NATS)   | IMMU                 |   |                   |                       | ×            |                 | ×           |                |
| Interior lamp battery saver                               | BATTERY SAVER        | ×   |                   |                       | ×            |                 | ×           |                |
| Back door   | TRUNK                |   |                   |                       | ×            |                 | ×           |                |
| Theft alarm   | THEFT ALARM          | ×   |                   |                       | ×            |                 | ×           |                |
| Retained power control                                    | RETAINED PWR         | ×   |                   |                       | ×            |                 | ×           |                |
| Oil pressure switch                                       | SIGNAL BUFFER        |   |                   |                       | ×            |                 | ×           |                |
| Air pressure monitor                                      | AIR PRESSURE MONITOR |   |                   |                       | ×            |                 | ×           |                |
| Panic alarm   | PANIC ALARM          | ×   |                   |                       | ×            |                 | ×           |                |

# BCM (BODY CONTROL MODULE)

## WORK SUPPORT

### Operation Procedure

1. Touch "BCM" on "SELECT TEST ITEM" screen.



2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.


3. Touch item on "SELECT WORK ITEM" screen.

4. Touch "START".

5. Touch "CHANGE SET".

6. The setting will be changed and "RESETTING COMPLETED" will be displayed.

7. Touch "END".



### Display Item List

| Item                | Description   |
|---------------------|---|
| RESET SETTING VALUE | Return a value set with WORK SUPPORT of each system to a default value in factory shipment. |

## CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)

EKS006QA

### 1. SELF-DIAGNOSTIC RESULT CHECK

#### NOTE:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Connect CONSULT-II and CONSULT-II CONVERTER, and select "BCM" on "SELECT SYSTEM" screen.
2. Select "BCM" on "SELECT TEST ITEM" screen, and select "SELF-DIAG RESULTS".
3. Check display content in self-diagnostic results.

| CONSULT-II display code | Diagnosis item |
|-------------------------|----------------|
| U1000                   | INITIAL DIAG   |
|                         | TRANSMIT DIAG  |
|                         | ECM            |
|                         | IPDM E/R       |
|                         | METER/M&A      |
|                         | I-KEY          |

#### Contents displayed

No malfunction>>Inspection End

Malfunction in CAN communication system>>After printing the monitor items, go to "CAN System". Refer to [LAN-5, "CAN COMMUNICATION"](#).

# BCM (BODY CONTROL MODULE)

EKS006QB

## Configuration DESCRIPTION

CONFIGURATION has two functions as follows:

- READ CONFIGURATION is the function to confirm vehicle configuration of current BCM.
- WRITE CONFIGURATION is the function to write vehicle configuration on BCM.

### CAUTION:


- When replacing BCM, you must perform WRITE CONFIGURATION with CONSULT-II.
- Complete the procedure of WRITE CONFIGURATION in order.
- If you set incorrect WRITE CONFIGURATION, incidents will occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

## READ CONFIGURATION PROCEDURE


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector and turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to General Information Section. Refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




# BCM (BODY CONTROL MODULE)

4. Touch "BCM" on "SELECT TEST ITEM" screen.



A  
B  
C

5. Touch "CONFIGURATION" on "SELECT DIAG MODE" screen.




D  
E  
F  
G

6. Touch "TA60" and "OK" on "VEHICLE SELECT" screen. For canceling, touch "CANCEL" on "VEHICLE SELECT" screen.

**NOTE:**


Confirm vehicle model on IDENTIFICATION PLATE. Refer to [GI-46, "Model Variation"](#) in GI section.



H  
I  
J

BCS


7. Touch "READ CONFIGURATION" on "SELECT CONFIG ITEM" screen.




L  
M

# BCM (BODY CONTROL MODULE)

8. Configuration of current BCM is printed out automatically. A listing of manual setting items and auto setting items will be displayed. Auto setting items are preset and cannot be changed. Manual setting items can be set by using WRITE CONFIGURATION PROCEDURE. Refer to [BCS-16, "WRITE CONFIGURATION PROCEDURE"](#) .



9. Touch "BACK" on "READ CONFIGURATION" screen.




## WRITE CONFIGURATION PROCEDURE

### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector and turn ignition switch ON.






# BCM (BODY CONTROL MODULE)

2. Touch "START (NISSAN BASED VHCL)".




A  
B  
C  
D

3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to LAN Section to check data link connector (DLC) circuit.




E  
F  
G

4. Touch "BCM" on "SELECT TEST ITEM" screen.



H  
I  
J

5. Touch "CONFIGURATION" on "SELECT DIAG MODE" screen.




BCS

L  
M

6. Touch "TA60" and "OK" on "VEHICLE SELECT" screen. For canceling, touch "CANCEL" on "VEHICLE SELECT" screen.


**NOTE:**

Confirm vehicle model on IDENTIFICATION PLATE. Refer to [GI-46, "Model Variation"](#) in GI section.




# BCM (BODY CONTROL MODULE)

7. Touch "WRITE CONFIGURATION" on "SELECT CONFIG ITEM" screen.



8. Touch "YES".  
For canceling, touch "NO".




# BCM (BODY CONTROL MODULE)

9. Using the following flow chart, identify the correct model and configuration list. Confirm and/or change setting value for each item according to the configuration list.  
Depending on CONSULT-II software version being used, some or all of the write configuration items shown in the following configuration lists may be displayed. If an item does not appear on the CONSULT-II "WRITE CONFIGURATION" screen(s), then it is an auto setting item and it cannot be manually set or changed.

**NOTE:**

Confirm vehicle model on IDENTIFICATION PLATE. Refer to [GI-46, "Model Variation"](#) in GI section.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M



# BCM (BODY CONTROL MODULE)


10. Touch "CHNG SETTING" on "WRITE CONFIGURATION" screen.

**CAUTION:**


**Make sure to touch "CHNG SETTING" even if the indicated configuration of brand-new BCM is same as the desirable configuration.**

**If not, configuration which is set automatically by selecting vehicle model cannot be memorized.**


11. Touch "OK" on "WRITE CONFIGURATION" screen.  
If "CANCEL" is touched, it will return to previous screen.



12. Wait until the next screen during setting.




13. WRITE CONFIGURATION results are printed out automatically. Confirm "WRITE CONFIGURATION" is correctly executed by comparing sheet automatically printed out with applicable configuration list shown in step 9.



# BCM (BODY CONTROL MODULE)

14. Touch "OK" on "WRITE CONFIGURATION" screen.  
WRITE CONFIGURATION is completed.




## Removal and Installation of BCM

### REMOVAL

#### NOTE:

If possible, before removing BCM, retrieve current BCM configuration to use for reference when configuring brand-new BCM after installation. Refer to [BCS-14, "Configuration"](#) .

1. Disconnect negative battery cable.
2. Remove lower knee protector. Refer to [IP-10, "Removal and Installation"](#) .
3. Remove screw and release BCM.
4. Disconnect connectors and then remove BCM.



### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

- When replacing BCM, it must be configured. Refer to [BCS-14, "Configuration"](#) .
- When replacing BCM, perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BL-125, "NVIS\(NISSAN Vehicle Immobilizer System-NATS\)"](#) .
- When replacing BCM, perform ID registration procedure of low tire pressure warning system. Refer to [WT-13, "ID Registration Procedure"](#) .

# BCM (BODY CONTROL MODULE)

---