

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

<p>PRECAUTIONS 3</p> <p>Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 3</p> <p>Precautions When Using CONSULT-II 3</p> <p style="padding-left: 20px;">CHECK POINTS FOR USING CONSULT-II 3</p> <p>Precautions For Trouble Diagnosis 3</p> <p style="padding-left: 20px;">CAN SYSTEM 3</p> <p>Precautions For Harness Repair 4</p> <p style="padding-left: 20px;">CAN SYSTEM 4</p> <p>CAN COMMUNICATION 5</p> <p>System Description 5</p> <p>CAN Communication Unit 5</p> <p style="padding-left: 20px;">TYPE 1/ TYPE 2 5</p> <p style="padding-left: 20px;">TYPE 3 8</p> <p style="padding-left: 20px;">TYPE 4/ TYPE 5 10</p> <p style="padding-left: 20px;">TYPE 6 12</p> <p>CAN SYSTEM (TYPE 1) 15</p> <p>System Description 15</p> <p>Component Parts and Harness Connector Location. 15</p> <p>Schematic 16</p> <p>Wiring Diagram - CAN - 17</p> <p>Work Flow 20</p> <p style="padding-left: 20px;">CHECK SHEET 21</p> <p style="padding-left: 20px;">CHECK SHEET RESULTS (EXAMPLE) 23</p> <p>Circuit Check Between TCM and Data Link Connector 34</p> <p>Circuit Check Between Data Link Connector and IPDM E/R 35</p> <p>ECM Circuit Check 36</p> <p>TCM Circuit Check 37</p> <p>Combination Meter Circuit Check 37</p> <p>BCM Circuit Check 38</p> <p>Data Link Connector Circuit Check 38</p> <p>Steering Angle Sensor Circuit Check 39</p> <p>ABS Actuator and Electric Unit (Control Unit) Circuit Check 39</p> <p>IPDM E/R Circuit Check 40</p> <p>CAN Communication Circuit Check 41</p>	<p>IPDM E/R Ignition Relay Circuit Check 41</p> <p>Component Inspection 42</p> <p style="padding-left: 20px;">ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION 42</p> <p>CAN SYSTEM (TYPE 2) 43</p> <p>System Description 43</p> <p>Component Parts and Harness Connector Location. 43</p> <p>Schematic 44</p> <p>Wiring Diagram - CAN - 45</p> <p>Work Flow 48</p> <p style="padding-left: 20px;">CHECK SHEET 49</p> <p style="padding-left: 20px;">CHECK SHEET RESULTS (EXAMPLE) 51</p> <p>Circuit Check Between TCM and Driver Seat Control Unit 64</p> <p>Circuit Check Between Driver Seat Control Unit and Data Link Connector 65</p> <p>Circuit Check Between Data Link Connector and IPDM E/R 66</p> <p>ECM Circuit Check 67</p> <p>TCM Circuit Check 67</p> <p>Driver Seat Control Unit Circuit Check 68</p> <p>Combination Meter Circuit Check 68</p> <p>BCM Circuit Check 69</p> <p>Data Link Connector Circuit Check 69</p> <p>Steering Angle Sensor Circuit Check 70</p> <p>ABS Actuator and Electric Unit (Control Unit) Circuit Check 70</p> <p>IPDM E/R Circuit Check 71</p> <p>CAN Communication Circuit Check 71</p> <p>IPDM E/R Ignition Relay Circuit Check 72</p> <p>Component Inspection 72</p> <p style="padding-left: 20px;">ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION 72</p> <p>CAN SYSTEM (TYPE 3) 73</p> <p>System Description 73</p> <p>Component Parts and Harness Connector Location. 73</p> <p>Schematic 74</p> <p>Wiring Diagram - CAN - 75</p> <p>Work Flow 78</p> <p style="padding-left: 20px;">CHECK SHEET 80</p>
--	--

F
G
H
I
J
L
M

LAN

CHECK SHEET RESULTS (EXAMPLE)	82	CHECK SHEET	142
Circuit Check Between TCM and Driver Seat Control Unit	97	CHECK SHEET RESULTS (EXAMPLE)	144
Circuit Check Between Driver Seat Control Unit and Data Link Connector	98	Circuit Check Between TCM and Driver Seat Control Unit	158
Circuit Check Between Data Link Connector and IPDM E/R	99	Circuit Check Between Driver Seat Control Unit and Data Link Connector	159
ECM Circuit Check	100	Circuit Check Between Data Link Connector and IPDM E/R	160
TCM Circuit Check	100	ECM Circuit Check	161
Driver Seat Control Unit Circuit Check	101	TCM Circuit Check	161
Combination Meter Circuit Check	101	Driver Seat Control Unit Circuit Check	162
Display Control Unit Circuit Check	102	Combination Meter Circuit Check	162
BCM Circuit Check	102	BCM Circuit Check	163
Data Link Connector Circuit Check	103	Data Link Connector Circuit Check	163
Steering Angle Sensor Circuit Check	103	Steering Angle Sensor Circuit Check	164
Front Air Control Circuit Check	104	Transfer Control Unit Circuit Check	164
ABS Actuator and Electric Unit (Control Unit) Circuit Check	104	ABS Actuator and Electric Unit (Control Unit) Circuit Check	165
IPDM E/R Circuit Check	105	IPDM E/R Circuit Check	165
CAN Communication Circuit Check	105	CAN Communication Circuit Check	166
IPDM E/R Ignition Relay Circuit Check	106	IPDM E/R Ignition Relay Circuit Check	166
Component Inspection	106	Component Inspection	167
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	106	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	167
CAN SYSTEM (TYPE 4)	107	CAN SYSTEM (TYPE 6)	168
System Description	107	System Description	168
Component Parts and Harness Connector Location	107	Component Parts and Harness Connector Location	168
Schematic	108	Schematic	169
Wiring Diagram - CAN -	109	Wiring Diagram - CAN -	170
Work Flow	112	Work Flow	173
CHECK SHEET	113	CHECK SHEET	175
CHECK SHEET RESULTS (EXAMPLE)	115	CHECK SHEET RESULTS (EXAMPLE)	177
Circuit Check Between TCM and Data Link Connector	127	Circuit Check Between TCM and Driver Seat Control Unit	193
Circuit Check Between Data Link Connector and IPDM E/R	128	Circuit Check Between Driver Seat Control Unit and Data Link Connector	194
ECM Circuit Check	129	Circuit Check Between Data Link Connector and IPDM E/R	195
TCM Circuit Check	130	ECM Circuit Check	196
Combination Meter Circuit Check	130	TCM Circuit Check	196
BCM Circuit Check	131	Driver Seat Control Unit Circuit Check	197
Data Link Connector Circuit Check	131	Combination Meter Circuit Check	197
Steering Angle Sensor Circuit Check	132	Display Control Unit Circuit Check	198
Transfer Control Unit Circuit Check	132	BCM Circuit Check	198
ABS Actuator and Electric Unit (Control Unit) Circuit Check	133	Data Link Connector Circuit Check	199
IPDM E/R Circuit Check	133	Steering Angle Sensor Circuit Check	199
CAN Communication Circuit Check	134	Front Air Control Circuit Check	200
IPDM E/R Ignition Relay Circuit Check	135	Transfer Control Unit Circuit Check	200
Component Inspection	135	ABS Actuator and Electric Unit (Control Unit) Circuit Check	201
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	135	IPDM E/R Circuit Check	201
CAN SYSTEM (TYPE 5)	136	CAN Communication Circuit Check	202
System Description	136	IPDM E/R Ignition Relay Circuit Check	202
Component Parts and Harness Connector Location	136	Component Inspection	203
Schematic	137	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	203
Wiring Diagram - CAN -	138		
Work Flow	141		

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

UKS0017I

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS0017J

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "CAN Communication Unit"](#) .

Precautions For Trouble Diagnosis CAN SYSTEM

UKS0017K


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J
L
M


LAN

Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



CAN COMMUNICATION

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Wagon					
Axle	2WD			4WD		
Engine	VK56DE					
Transmission	A/T					
Brake control	VDC					
Automatic drive positioner		×	×		×	×
Navigation system			×			×
Automatic air conditioner			×			×
CAN system type	1	2	3	4	5	6
CAN system trouble diagnosis	LAN-15	LAN-43	LAN-73	LAN-107	LAN-136	LAN-168

×: Applicable

TYPE 1/ TYPE 2

System diagram


- Type 1



CAN COMMUNICATION

[CAN]

● Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R				R	
Engine status signal	T				R		R		
Engine coolant temperature signal	T			R			R		
A/T self-diagnosis signal	R	T							
Accelerator pedal position signal	T	R						R	
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
Key switch signal			R		T				
Ignition switch signal			R		T				
P range signal		T	R	R					
Stop lamp switch signal		R		T					
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T							
A/C switch signal	R				T				
A/C compressor request signal	T						R		R
Blower fan motor switch signal	R				T		R		
Cooling fan speed request signal	T						R		R
Position light request signal				R	T				R
Low beam request signal					T				R
Low beam status signal	R								T
High beam request signal				R	T				R
High beam status signal	R								T
Front fog light request signal					T				R

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Frontair control	ABS actuator and electric unit (control unit)	IPDM E/R
Day time running light request signal				R	T				
Vehicle speed signal				R			R	T	
	R	R	R	T	R		R		
Sleep wake up signal			R	R	T				R
Door switch signal			R	R	T				R
Turn indicator signal				R	T				
Key fob ID signal			R		T				
Key fob door unlock signal			R		T				
Buzzer output signal				R	T				
Fuel level sensor signal	R			T					
ASCD SET lamp signal	T			R					
ASCD CRUISE lamp signal	T			R					
Malfunction indicator lamp signal	T			R					
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
Front wiper request signal					T				R
Front wiper stop position signal					R				T
Rear window defogger switch signal					T		R		R
Rear window defogger control signal	R								T
Theft warning horn request signal					T				R
Horn chirp signal					T				R
Steering angle sensor signal						T		R	
ABS warning lamp signal				R				T	
VDC OFF indicator lamp signal				R				T	
SLIP indicator lamp signal				R				T	
Brake warning lamp signal				R				T	
A/T CHECK indicator lamp signal		T		R					
System setting signal			T		R				
			R		T				
A/T position indicator lamp signal		T		R					
1st position switch signal		R		T					
4th position switch signal		R		T					
Tow mode switch signal		R		T					
A/T fluid temperature sensor signal		T		R					

A
B
C
D
E
F
G
H
I
J
LAN
L
M


CAN COMMUNICATION

[CAN]

TYPE 3

System diagram

- Type 3



PKIA9247E

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R				R	
Engine status signal	T					R		R		
Engine coolant temperature signal	T			R				R		
A/T self-diagnosis signal	R	T								
Accelerator pedal position signal	T	R							R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Battery voltage signal	T	R								
Key switch signal			R			T				
Ignition switch signal			R			T				
P range signal		T	R	R						
Stop lamp switch signal		R		T						
Fuel consumption monitor signal	T			R						
				T	R					
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R					T				
A/C compressor request signal	T							R		R
Blower fan motor switch signal	R					T		R		
A/C switch/indicator signal					T			R		
					R			T		
Cooling fan speed request signal	T							R		R

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Position light request signal				R		T				R
Low beam request signal						T				R
Low beam status signal	R									T
High beam request signal				R		T				R
High beam status signal	R									T
Front fog light request signal						T				R
Day time running light request signal				R		T				
Vehicle speed signal				R				R	T	
	R	R	R	T	R	R		R		
Sleep wake up signal			R	R		T				R
Door switch signal			R	R	R	T				R
Turn indicator signal				R		T				
Key fob ID signal			R			T				
Key fob door unlock signal			R			T				
Buzzer output signal				R		T				
Fuel level sensor signal	R			T						
Fuel level low warning signal				T	R					
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						
Malfunction indicator lamp signal	T			R						
Front wiper request signal						T				R
Front wiper stop position signal						R				T
Rear window defogger switch signal						T		R		R
Rear window defogger control signal	R				R					T
Theft warning horn request signal						T				R
Horn chirp signal						T				R
Steering angle sensor signal							T		R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	
Brake warning lamp signal				R					T	
System setting signal			R		T	R				
			T		R	T				
Distance to empty signal				T	R					
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R						
Tire pressure signal					R	T				
Tire pressure data signal					R	T				

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN


CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
1st position switch signal		R		T						
4th position switch signal		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						

TYPE 4/ TYPE 5 System diagram

- Type 4



- Type 5



CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T								
Stop lamp switch signal		R		T						
Battery voltage signal	T	R								
Key switch signal			R		T					
Ignition switch signal			R		T					
P range signal		T	R	R						
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Engine speed signal	T	R		R				R	R	
Engine status signal	T				R		R			
Engine coolant temperature signal	T			R			R			
Accelerator pedal position signal	T	R						R	R	
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T						R		
A/C switch signal	R				T					
A/C compressor request signal	T						R			R
Blower fan motor switch signal	R				T		R			
Cooling fan speed request signal	T						R			R
Position light request signal				R	T					R
Low beam request signal					T					R
Low beam status signal	R									T
High beam request signal				R	T					R
High beam status signal	R									T
Front fog light request signal					T					R
Day time running light request signal				R	T					
Vehicle speed signal	R	R	R	T	R		R	R	T	
Sleep wake up signal			R	R	T					R
Door switch signal			R	R	T					R
Turn indicator signal				R	T					
Key fob ID signal			R		T					
Key fob door unlock signal			R		T					
Buzzer output signal				R	T					
Fuel level sensor signal	R			T						
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						
Malfunction indicator lamp signal	T			R						
Front wiper request signal					T					R

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Front wiper stop position signal					R					T
Rear window defogger switch signal					T		R			R
Rear window defogger control signal	R									T
Theft warning horn request signal					T					R
Horn chirp signal					T					R
Steering angle sensor signal						T			R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	
Brake warning lamp signal				R					T	
System setting signal			R		R					
			T		T					
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R				R		
1st position switch signal		R		T						
4th position switch signal		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						

TYPE 6

System diagram

- Type 6



PKIA9250E

Input/output signal chart

T: Transmit R: Receive

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T									
Stop lamp switch signal		R		T							
Battery voltage signal	T	R									
Key switch signal			R			T					
Ignition switch signal			R			T					
P range signal		T	R	R							
Closed throttle position signal	T	R									
Wide open throttle position signal	T	R									
Engine speed signal	T	R		R	R				R	R	
Engine status signal	T					R		R			
Engine coolant temperature signal	T			R				R			
Accelerator pedal position signal	T	R							R	R	
Fuel consumption monitor signal	T			R							
				T	R						
Turbine revolution signal	R	T									
Output shaft revolution signal	R	T							R		
A/C switch signal	R					T					
A/C compressor request signal	T							R			R
Blower fan motor switch signal	R					T		R			
A/C switch/indicator signal					T			R			
					R			T			
Cooling fan speed request signal	T							R			R
Position light request signal				R		T					R
Low beam request signal						T					R
Low beam status signal	R										T
High beam request signal				R		T					R
High beam status signal	R										T
Front fog light request signal						T					R
Day time running light request signal				R		T					
Vehicle speed signal				R				R	R	T	
	R	R	R	T	R	R		R			
Sleep wake up signal			R	R		T					R
Door switch signal			R	R	R	T					R
Key fob ID signal			R			T					
Key fob door unlock signal			R			T					
Buzzer output signal				R		T					
Fuel level sensor signal	R			T							
ASCD SET lamp signal	T			R							

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
ASCD CRUISE lamp signal	T			R							
Malfunction indicator lamp signal	T			R							
Fuel level low warning signal				T	R						
Front wiper request signal						T					R
Front wiper stop position signal						R					T
Rear window defogger switch signal						T		R			R
Rear window defogger control signal	R				R						T
Theft warning horn request signal						T					R
Horn chirp signal						T					R
Steering angle sensor signal							T			R	
ABS warning lamp signal				R						T	
VDC OFF indicator lamp signal				R						T	
SLIP indicator lamp signal				R						T	
Brake warning lamp signal				R						T	
System setting signal			R		T	R					
			T		R	T					
Distance to empty signal				T	R						
ASCD operation signal	T	R									
ASCD OD cancel request	T	R									
A/T CHECK indicator lamp signal		T		R							
A/T position indicator lamp signal		T		R					R		
Tire pressure signal					R	T					
Tire pressure data signal					R	T					
1st position switch signal		R		T							
4th position switch signal		R		T							
Tow mode switch signal		R		T							
A/T fluid temperature sensor signal		T		R							

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

UKS000NW

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000NX



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 1)

[CAN]

Schematic

UKS000YS



BKWA0184E

CAN SYSTEM (TYPE 1)


[CAN]

Wiring Diagram - CAN -

UKS000NY




LAN-CAN-01

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M

LAN








REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0010E

CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-02




BKWA0185E

CAN SYSTEM (TYPE 1)



[CAN]

LAN-CAN-03

— — — — — : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0020E

Work Flow

- When there are no indications of "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)	NISSAN CONSULT-II ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY	➔	SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP BACK LIGHT COPY	PKIA2093E
-----------	---	---	---	-----------

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	➔	SELF-DIAG RESULTS DTC RESULTS TIME CAN COMM CIRCUIT (U1000) 0 F.F.DATA ERASE PRINT MODE BACK LIGHT COPY	PKIA8260E
-----------	--	---	---	-----------

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)	SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY	➔	CAN DIAG SUPPORT MNTR ENGINE PRSNT INITIAL DIAG OK TRANSMIT DIAG OK TCM OK VDC/TCS/ABS OK METER/M&A OK ICC UNKWN BCM/SEC OK IPDM E/R OK AWD/4WD/e4WD UNKWN PRINT Scroll Down MODE BACK LIGHT COPY	PKIA8343E
-----------	--	---	--	-----------

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-21, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-21, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-23, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA9135E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-34, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	—	✓	✓	
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	✓	—	
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	UNKWN	
ABS	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—	

PKIA9146E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-35, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	UNKW	—
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	UNKW
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	—	—	UNKW	—	—	—

PKIA9147E



PKIA9252E

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-36, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

PKIA9148E



PKIA9253E

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-37, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9149E



PKIA9254E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-37, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9150E



PKIA9255E

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-38, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—

PKIA9151E



PKIA9256E

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-38, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9152E



PKIA9257E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-39, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9153E



PKIA9258E

CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-39, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	UNKW	—
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	UNKW
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—

PKIA9154E



PKIA9259E

CAN SYSTEM (TYPE 1)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-40, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9155E



PKIA9260E

Case 11

Check CAN communication circuit. Refer to [LAN-41, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UN K W N	—	UN K W N	UN K W N	UN K W N	—	UN K W N	UN K W N
A/T	—	NG	UN K W N	UN K W N	—	UN K W N	—	—	UN K W N	—
BCM	No indication ✓	NG	UN K W N	UN K W N	—	UN K W N	—	—	—	UN K W N
ABS	—	NG ✓	UN K W N	UN K W N	UN K W N	—	—	UN K W N	—	—
IPDM E/R	No indication ✓	—	UN K W N	UN K W N	—	—	UN K W N	—	—	—

PKIA9156E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-41, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UN K W N	—	UN K W N ✓	UN K W N	UN K W N	—	UN K W N ✓	UN K W N
A/T	—	NG	UN K W N	UN K W N	—	UN K W N	—	—	UN K W N	—
BCM	No indication	NG	UN K W N	UN K W N	—	UN K W N	—	—	—	UN K W N
ABS	—	NG	UN K W N	UN K W N	UN K W N	—	—	UN K W N	—	—
IPDM E/R	No indication	—	UN K W N	UN K W N	—	—	UN K W N	—	—	—

PKIA9157E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-41, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9158E

Circuit Check Between TCM and Data Link Connector

UKS0017N

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).

3 (W) - 12 (W) : Continuity should exist.
8 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and harness connector B69 terminals 51J (W), 52J (R).

24 (W) - 51J (W) : Continuity should exist.
23 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 5.
 NG >> Repair harness.




5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.
52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-20, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS00170

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).


6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).


31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-20, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS0017P


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS0017Q

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS0017S

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS0017T

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-21, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



UKS0017R

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-20, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check

UKS0017U

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS0017V

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



UKS0017W

IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



PKIA8141E

CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR SHORT CIRCUIT


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.

**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.


6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-42, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	




CAN SYSTEM (TYPE 2)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 2)

[CAN]

Schematic

UKS000YT



BKWA0186E

CAN SYSTEM (TYPE 2)


[CAN]

Wiring Diagram - CAN -


UKS0000H

LAN-CAN-04

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M40) - SUPER MULTIPLE JUNCTION (SMJ)



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0584E


CAN SYSTEM (TYPE 2)

[CAN]


LAN-CAN-05




M18




M22



M24



M47




M50



BKWA0187E

LAN-CAN-06

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0021E

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-49, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-49, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
 - The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.
- According to the check sheet results (example), start inspection. Refer to [LAN-51, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA9137E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-64, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	—	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	UNKWN	—	—	—

PKIA9159E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)

[CAN]


Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-65, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

PKIA9160E

//// : Malfunctioning part



PKIA9262E

CAN SYSTEM (TYPE 2)

[CAN]


Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-66, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9161E

//// : Malfunctioning part



PKIA9263E

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-67, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9162E



PKIA9264E

CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-67, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	

PKIA9163E



PKIA9265E

CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-68, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9164E



PKIA9266E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-68, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9165E



PKIA9267E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-69, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—

PKIA9166E



PKIA9268E

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-69, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9167E



CAN SYSTEM (TYPE 2)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-70, "Steering Angle Sensor Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9168E



PKIA9270E

CAN SYSTEM (TYPE 2)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-70, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9169E



PKIA9271E

CAN SYSTEM (TYPE 2)


[CAN]

Case 12

Check IPDM E/R circuit. Refer to [LAN-71, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9170E



PKIA9272E

CAN SYSTEM (TYPE 2)

[CAN]

Case 13

Check CAN communication circuit. Refer to [LAN-71, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—
AUTO DRIVE POS.	No indication	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	UNKW ^N
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—	—

PKIA9171E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-72, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—
AUTO DRIVE POS.	No indication	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	UNKW ^N
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—	—

PKIA9172E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-72, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIA9173E

Circuit Check Between TCM and Driver Seat Control Unit

UKS0018E

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).


3 (W) - 12 (W) : Continuity should exist.

8 (R) - 11 (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and driver seat control unit harness connector P2 terminals 3 (W), 19 (R).

24 (W) - 3 (W) : Continuity should exist.
23 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-48, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS00181

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.
19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-48, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS00182

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-48, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



BCM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-21, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-48, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
NG >> Repair harness between steering angle sensor and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-72, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
- NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


UKS0018C

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

UKS0018D

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 3)

PFP:23710


System Description

UKS000P0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000P1



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

UKS000P2



BKWA0007E

CAN SYSTEM (TYPE 3)



[CAN]

Wiring Diagram - CAN -


UKS000P3

LAN-CAN-07


— : DATA LINE




E16
B




E34
W




F9
G



F33
W



B37
W



P2*
W

* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.



REFER TO THE FOLLOWING.
(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0585E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-08




BKWA0017E

CAN SYSTEM (TYPE 3)



[CAN]

LAN-CAN-09

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M




REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0022E

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-80, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-80, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-148, "CAN Communication Line Check"](#).
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-80, "CHECK SHEET"](#).

CAN SYSTEM (TYPE 3)

[CAN]

8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-80, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-148, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-82, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

CAN SYSTEM (TYPE 3)

[CAN]

A
B
C
D
E
F
G
H
I
J
LAN
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA9139E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-97, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UN KN ✓WN	UN KN ✓WN	—	—	UN KN ✓WN	UN KN ✓WN
A/T	—	NG	UNKWN	UNKWN	—	UN KN ✓WN	—	—	—	UN KN ✓WN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN KN ✓WN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC ✓3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UN KN ✓WN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UN KN ✓WN	UN KN ✓WN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UN KN ✓WN	—	—	UNKWN	—	—	—	—

PKIA9174E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-98, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—

PKIA9175E



CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-99, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9176E



CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-100, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	UNKW [✓] N	—
AUTO DRIVE POS.	No indication	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	UNKW [✓] N
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—

PKIA9177E



CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-100, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9178E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-101, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9179E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-101, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5 ✓	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9180E



CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check display control unit circuit. Refer to [LAN-102, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN DTC 1 ✓	CAN DTC 3 ✓	—	CAN DTC 5 ✓	CAN DTC 2 ✓	—	CAN DTC 4 ✓	—	CAN DTC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9181E



CAN SYSTEM (TYPE 3)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-102, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2 ✓	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—

PKIA9182E



CAN SYSTEM (TYPE 3)


[CAN]

Case 10

Check data link connector circuit. Refer to [LAN-103, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9183E



CAN SYSTEM (TYPE 3)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-103, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9184E



CAN SYSTEM (TYPE 3)


[CAN]

Case 12

Check front air control circuit. Refer to [LAN-104, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9185E



CAN SYSTEM (TYPE 3)


[CAN]

Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-104, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9186E



PKIA9285E

CAN SYSTEM (TYPE 3)


[CAN]

Case 14

Check IPDM E/R circuit. Refer to [LAN-105, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9187E



CAN SYSTEM (TYPE 3)

[CAN]

Case 15

Check CAN communication circuit. Refer to [LAN-105, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	—
AUTO DRIVE POS.	No ind ication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No ind ication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	—
IPDM E/R	No ind ication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

PKIA9188E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-106, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N	—
AUTO DRIVE POS.	No ind ication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No ind ication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—	—
IPDM E/R	No ind ication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

PKIA9189E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-106, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER /M&A	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	UNKWN	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ABS	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9190E

Circuit Check Between TCM and Driver Seat Control Unit

UKS0018I

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).


3 (W) - 12 (W) : Continuity should exist.

8 (R) - 11 (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and driver seat control unit harness connector P2 terminals 3 (W), 19 (R).

24 (W) - 3 (W) : Continuity should exist.
23 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-78, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0018J

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.
19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-78, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS0018K

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-78, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (W) and 26 (R).

25 (W) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
NG >> Repair harness between display control unit and data link connector.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-21, "Removal and Installation of BCM"](#) .
NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-78, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (W) and 35 (R).

34 (W) - 35 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace front air control.
NG >> Repair harness between front air control and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-106, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
- NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


UKS0018X

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

UKS0018Y

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 4)

PFP:23710


System Description

UKS000PQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000PR



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

UKS000PS



BKWA0188E

CAN SYSTEM (TYPE 4)


[CAN]

Wiring Diagram - CAN -




UKS000PT

LAN-CAN-10

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.







(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0013E

CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-11




BKWA0189E

CAN SYSTEM (TYPE 4)




[CAN]

LAN-CAN-12

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0023E

Work Flow

- When there are no indications of "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN CONSULT-II ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE LIGHT COPY		SELECT SYSTEM ENGINE A/T ABS AIR BAG BCM METER A/C AMP BACK LIGHT COPY
---	--	---

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY		SELF-DIAG RESULTS DTC RESULTS TIME <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 80%;">CAN COMM CIRCUIT (U1000)</td> <td style="width: 20%; text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table> F.F.DATA ERASE PRINT MODE BACK LIGHT COPY	CAN COMM CIRCUIT (U1000)	0				
CAN COMM CIRCUIT (U1000)	0							

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE WORK SUPPORT SELF-DIAG RESULTS DATA MONITOR DATA MONITOR (SPEC) CAN DIAG SUPPORT MNTR ACTIVE TEST Scroll Down BACK LIGHT COPY		CAN DIAG SUPPORT MNTR ENGINE <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;"></td> <td style="width: 40%; text-align: center;">PRSNT</td> </tr> <tr> <td>INITIAL DIAG</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>TRANSMIT DIAG</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>TCM</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>VDC/TCS/ABS</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>METER/M&A</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>ICC</td> <td style="text-align: center;">UNKWN</td> </tr> <tr> <td>BCM/SEC</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>IPDM E/R</td> <td style="text-align: center;">OK</td> </tr> <tr> <td>AWD/4WD/e4WD</td> <td style="text-align: center;">UNKWN</td> </tr> <tr> <td>PRINT</td> <td style="text-align: center;">Scroll Down</td> </tr> <tr> <td>MODE BACK LIGHT COPY</td> <td></td> </tr> </table>		PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE BACK LIGHT COPY	
	PRSNT																									
INITIAL DIAG	OK																									
TRANSMIT DIAG	OK																									
TCM	OK																									
VDC/TCS/ABS	OK																									
METER/M&A	OK																									
ICC	UNKWN																									
BCM/SEC	OK																									
IPDM E/R	OK																									
AWD/4WD/e4WD	UNKWN																									
PRINT	Scroll Down																									
MODE BACK LIGHT COPY																										

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-113, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-113, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-115, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIA9140E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIA9141E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-127, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	—

PKIA9191E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-128, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9192E



PKIA9288E

CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-129, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	UNKW [✓] N	
ALL MODE AWD/4WD	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	—	
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—	

PKIA9193E



CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-130, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9194E



PKIA9290E

CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-130, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	--	NG	UNKWN	--	UNKWN	UNKWN ✓	UNKWN	--	UNKWN	UNKWN	UNKWN	
A/T	--	NG	UNKWN	UNKWN	--	UNKWN ✓	--	--	UNKWN	UNKWN	--	
BCM	No indication	NG	UNKWN	UNKWN	--	UNKWN ✓	--	--	--	--	UNKWN	
ALL MODE AWD/4WD	--	NG	UNKWN	UNKWN	UNKWN	--	--	--	--	UNKWN	--	
ABS	--	NG	UNKWN	UNKWN	UNKWN	--	--	UNKWN	UNKWN	--	--	
IPDM E/R	No indication	--	UNKWN	UNKWN	--	--	UNKWN	--	--	--	--	

PKIA9195E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-131, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9196E



PKIA9292E

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-131, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9197E



CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-132, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9198E



PKIA9294E

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check transfer control unit circuit. Refer to [LAN-132, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9199E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-133, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9200E



PKIA9296E

CAN SYSTEM (TYPE 4)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-133, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9201E



CAN SYSTEM (TYPE 4)

[CAN]

Case 12

Check CAN communication circuit. Refer to [LAN-134, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UN KN W N	—	UN KN W N	UN KN W N	UN KN W N	—	—	UN KN W N	UN KN W N	UN KN W N
A/T	—	NG	UN KN W N	UN KN W N	—	UN KN W N	—	—	—	UN KN W N	UN KN W N	—
BCM	No indication ✓	NG	UN KN W N	UN KN W N	—	UN KN W N	—	—	—	—	—	UN KN W N
ALL MODE AWD/4WD	—	NG	UN KN W N	UN KN W N	UN KN W N	—	—	—	—	—	UN KN W N	—
ABS	—	NG ✓	UN KN W N	UN KN W N	UN KN W N	—	—	UN KN W N	UN KN W N	—	—	—
IPDM E/R	No indication ✓	—	UN KN W N	UN KN W N	—	—	UN KN W N	—	—	—	—	—

PKIA9202E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-135, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UN KN W N	—	UN KN W N	UN KN W N	UN KN W N	—	—	UN KN W N	UN KN W N	UN KN W N
A/T	—	NG	UN KN W N	UN KN W N	—	UN KN W N	—	—	—	UN KN W N	UN KN W N	—
BCM	No indication	NG	UN KN W N	UN KN W N	—	UN KN W N	—	—	—	—	—	UN KN W N
ALL MODE AWD/4WD	—	NG	UN KN W N	UN KN W N	UN KN W N	—	—	—	—	—	UN KN W N	—
ABS	—	NG	UN KN W N	UN KN W N	UN KN W N	—	—	UN KN W N	UN KN W N	—	—	—
IPDM E/R	No indication	—	UN KN W N	UN KN W N	—	—	UN KN W N	—	—	—	—	—

PKIA9203E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-135, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN ✓	UNKWN ✓	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9204E

Circuit Check Between TCM and Data Link Connector

UKS00190

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).

3 (W) - 12 (W) : Continuity should exist.
8 (R) - 11 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and harness connector B69 terminals 51J (W), 52J (R).

24 (W) - 51J (W) : Continuity should exist.
23 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 5.
 NG >> Repair harness.




5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.
52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-112, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS00191

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.
14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.
42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-112, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS00193

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



UKS00194

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS00195

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-21, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



UKS00196

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-112, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



UKS00197

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS00198

Transfer Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (W) and 8 (R).

7 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS00199

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



UKS0019B

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



PKIA2077E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.


6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-135, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

UKS0019C

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).


Component Inspection

UKS0019D

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

PF2:23710


System Description

UKS000QB

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000QC




BKIA0052E

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

UKS000QD



A
B
C
D
E
F
G
H
I
J
LAN
L
M

BKWA0190E

CAN SYSTEM (TYPE 5)



[CAN]

Wiring Diagram - CAN -






UKS000QE

LAN-CAN-13

— : DATA LINE



E16 B




* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.


REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0586E

LAN-CAN-14



A
B
C
D
E
F
G
H
I
J
LAN
L
M




BKWA0191E

CAN SYSTEM (TYPE 5)




[CAN]

LAN-CAN-15

— : DATA LINE



PRECEDING PAGE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0024E

CAN SYSTEM (TYPE 5)

[CAN]

UKS0019E

Work Flow

- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN	
CONSULT-II	
ENGINE	
START (NISSAN BASED VHCL)	
START (RENAULT BASED VHCL)	
SUB MODE	
LIGHT	COPY

SELECT SYSTEM		
ENGINE		
A/T		
ABS		
AIR BAG		
BCM		
METER A/C AMP		
BACK	LIGHT	COPY

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
BACK	LIGHT COPY

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT (U1000)	0
F.F.DATA	
ERASE	PRINT
MODE	BACK LIGHT COPY

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
BACK	LIGHT COPY

CAN DIAG SUPPORT MNTR	
ENGINE	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	OK
IPDM E/R	OK
AWD/4WD/e4WD	UNKWN
PRINT	Scroll Down
MODE	BACK LIGHT COPY

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-142, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-142, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-144, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 5)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIA9143E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-158, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	

PKIA9205E



CAN SYSTEM (TYPE 5)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-159, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	

PKIA9206E



CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-160, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	UNKW	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	UNKW	UNKW	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	—	UNKW
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	—	UNKW	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	UNKW	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—

PKIA9207E



PKIA9300E

CAN SYSTEM (TYPE 5)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-161, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	
AUTO DRIVE POS.	No indication	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	—	
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	UNKW [✓] N	
ALL MODE AWD/4WD	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	—	UNKW [✓] N	—	
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	—	
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—	

PKIA9208E



CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-161, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9209E



CAN SYSTEM (TYPE 5)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-162, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9210E



CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-162, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9211E



CAN SYSTEM (TYPE 5)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-163, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—

PKIA9212E



CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-163, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9213E



PKIA9306E

CAN SYSTEM (TYPE 5)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-164, "Steering Angle Sensor Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9214E



CAN SYSTEM (TYPE 5)


[CAN]

Case 11

Check transfer control unit circuit. Refer to [LAN-164, "Transfer Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

PKIA9215E



PKIA9308E

CAN SYSTEM (TYPE 5)


[CAN]

Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-165, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9216E



CAN SYSTEM (TYPE 5)


[CAN]

Case 13

Check IPDM E/R circuit. Refer to [LAN-165, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9217E



PKIA9310E

Case 14

Check CAN communication circuit. Refer to [LAN-166, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

PKIA9218E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-166, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

PKIA9219E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-166, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	✓	—	—	✓	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	✓	✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

PKIA9220E

Circuit Check Between TCM and Driver Seat Control Unit

UKS0019F

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).


3 (W) - 12 (W) : Continuity should exist.

8 (R) - 11 (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).

12 (W) - 24 (W) : Continuity should exist.
11 (R) - 23 (R) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and driver seat control unit harness connector P2 terminals 3 (W), 19 (R).

24 (W) - 3 (W) : Continuity should exist.
23 (R) - 19 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-141, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0019G

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).

3 (W) - 51J (W) : Continuity should exist.
19 (R) - 52J (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-141, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS0019H

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-141, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
NG >> Repair harness between driver seat control unit and harness connector B40.



Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
NG >> Repair harness between combination meter and data link connector.



BCM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-21, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-141, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
NG >> Repair harness between steering angle sensor and data link connector.



Transfer Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (W) and 8 (R).

7 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace transfer control unit.
NG >> Repair harness between transfer control unit and harness connector E152.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-167, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).
 NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 6)


System Description

UKS000QY

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS000QZ




CAN SYSTEM (TYPE 6)

[CAN]

Schematic

UKS000R0



A
B
C
D
E
F
G
H
I
J
LAN
L
M

BKWA0001E

CAN SYSTEM (TYPE 6)



[CAN]

UKS000R1

Wiring Diagram - CAN -

LAN-CAN-16

— : DATA LINE



REFER TO THE FOLLOWING.
(M40) - SUPER MULTIPLE JUNCTION (SMJ)



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0587E

CAN SYSTEM (TYPE 6)

[CAN]

LAN-CAN-17







BKWA0003E

CAN SYSTEM (TYPE 6)

[CAN]

LAN-CAN-18

— : DATA LINE



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0004E


CAN SYSTEM (TYPE 6)

[CAN]


UKS0019V

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-175, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-175, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual. So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-148, "CAN Communication Line Check"](#).
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-175, "CHECK SHEET"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)

[CAN]

-
8. Mark the “NG” or “UNKWN” item of the check sheet table with “v” from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-175, "CHECK SHEET"](#) .

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MONITOR” for the diagnosed control unit, replace the control unit. Refer to [AV-148, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-177, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 6)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

PKIA9145E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-193, "Circuit Check Between TCM and Driver Seat Control Unit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UN ✓ KN	UN ✓ KN	—	—	—	UN ✓ KN	UN ✓ KN	UN ✓ KN
A/T	—	NG	UNKWN	UNKWN	—	UN ✓ KN	—	—	—	—	UN ✓ KN	UN ✓ KN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN ✓ KN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UN ✓ KN	—	UNKWN	—	—	—	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UN ✓ KN	UN ✓ KN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UN ✓ KN	UN ✓ KN	—	—	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UN ✓ KN	—	—	UNKWN	—	—	—	—	—	—

PKIA9221E



CAN SYSTEM (TYPE 6)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-194, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	—	—

PKIA9222E




PKIA9312E

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-195, "Circuit Check Between Data Link Connector and IPDM E/R"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—

PKIA9223E



CAN SYSTEM (TYPE 6)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-196, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	—	UNKWN	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	—	—

PKIA9224E



PKIA9314E

CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-196, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9225E



CAN SYSTEM (TYPE 6)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-197, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9226E



CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-197, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA9227E



CAN SYSTEM (TYPE 6)


[CAN]

Case 8

Check display control unit circuit. Refer to [LAN-198, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN ✓CRC 1	CAN ✓CRC 3	—	CAN ✓CRC 5	CAN ✓CRC 2	—	CAN ✓CRC 4	—	—	CAN ✓CRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9228E



CAN SYSTEM (TYPE 6)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-198, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9229E



CAN SYSTEM (TYPE 6)


[CAN]

Case 10

Check data link connector circuit. Refer to [LAN-199, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9230E



CAN SYSTEM (TYPE 6)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-199, "Steering Angle Sensor Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA9321E




Case 12

Check front air control circuit. Refer to [LAN-200, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4 ✓	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9232E



CAN SYSTEM (TYPE 6)


[CAN]

Case 13

Check transfer control unit circuit. Refer to [LAN-200, "Transfer Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA9233E




Case 14

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-201, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA9234E



CAN SYSTEM (TYPE 6)


[CAN]

Case 15

Check IPDM E/R circuit. Refer to [LAN-201, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	

PKIA9235E



CAN SYSTEM (TYPE 6)

[CAN]

Case 16

Check CAN communication circuit. Refer to [LAN-202, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	—	—

PKIA9236E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-202, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS		
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	—	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	—	—

PKIA9237E

Case 18

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-202. "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—

PKIA9238E

Circuit Check Between TCM and Driver Seat Control Unit

UKS0019W

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (W), 8 (R) and harness connector F33 terminals 12 (W), 11 (R).


3 (W) - 12 (W) : Continuity should exist.

8 (R) - 11 (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (W), 11 (R) and harness connector E34 terminals 24 (W), 23 (R).


12 (W) - 24 (W) : Continuity should exist.

11 (R) - 23 (R) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (W), 23 (R) and driver seat control unit harness connector P2 terminals 3 (W), 19 (R).


24 (W) - 3 (W) : Continuity should exist.

23 (R) - 19 (R) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-173, "Work Flow"](#).

NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

UKS0019X

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (W), 19 (R) and harness connector B69 terminals 51J (W), 52J (R).


3 (W) - 51J (W) : Continuity should exist.

19 (R) - 52J (R) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (W), 52J (R) and data link connector M22 terminals 6 (W), 14 (R).

51J (W) - 6 (W) : Continuity should exist.

52J (R) - 14 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-173, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

UKS0019Y

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (W), 14 (R) and harness connector M31 terminals 31G (W), 42G (R).

6 (W) - 31G (W) : Continuity should exist.

14 (R) - 42G (R) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (W), 42G (R) and IPDM E/R harness connector E122 terminals 39 (W), 40 (R).

31G (W) - 39 (W) : Continuity should exist.

42G (R) - 40 (R) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-173, "Work Flow"](#).
- NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J
L
M

LAN

ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (W) and 86 (R).

94 (W) - 86 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (W) and 8 (R).

3 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (W) and 19 (R).

3 (W) - 19 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (W) and 12 (R).

11 (W) - 12 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (W) and 26 (R).

25 (W) - 26 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace display control unit.
NG >> Repair harness between display control unit and data link connector.



BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-21, "Removal and Installation of BCM"](#) .
NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-173, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (W) and 4 (R).

3 (W) - 4 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (W) and 35 (R).

34 (W) - 35 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.

**Transfer Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (W) and 8 (R).

7 (W) - 8 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (W) and 15 (R).

11 (W) - 15 (R) : Approx. 54 - 66Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (W) and 40 (R).

39 (W) - 40 (R) : Approx. 108 - 132Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (W) and 14 (R).

6 (W) - 14 (R) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (W), 14 (R) and ground.

6 (W) - Ground : Continuity should not exist.

14 (R) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-203, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
 NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



A
B
C
D
E
F
G
H
I
J
L
M

LAN

