

PG

SECTION

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTIONS	3
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3
Wiring Diagrams and Trouble Diagnosis	3
POWER SUPPLY ROUTING CIRCUIT	4
Schematic	4
Wiring Diagram — POWER —	6
BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION	6
ACCESSORY POWER SUPPLY — IGNITION SW. IN ACC OR ON	11
IGNITION POWER SUPPLY — IGNITION SW. IN ON	12
IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START	13
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	17
System Description	17
SYSTEMS CONTROLLED BY IPDM E/R	17
CAN COMMUNICATION LINE CONTROL	17
IPDM E/R STATUS CONTROL	18
CAN Communication System Description	18
Function of Detecting Ignition Relay Malfunction ...	18
CONSULT-II Function (IPDM E/R)	19
CONSULT-II BASIC OPERATION	19
SELF-DIAGNOSTIC RESULTS	20
DATA MONITOR	20
ACTIVE TEST	21
Auto Active Test	22
DESCRIPTION	22
OPERATION PROCEDURE	22
INSPECTION IN AUTO ACTIVE TEST MODE... <td style="text-align: right;">22</td>	22
Schematic	24
IPDM E/R Terminal Arrangement	25
IPDM E/R Power/Ground Circuit Inspection	26
Inspection with CONSULT-II (Self-Diagnosis)	27
Removal and Installation of IPDM E/R	28
REMOVAL	28
INSTALLATION	28
GROUND CIRCUIT	29
Ground Distribution	29
MAIN HARNESS	29
ENGINE ROOM HARNESS	32
ENGINE CONTROL HARNESS	35
BODY HARNESS	36
BODY NO. 2 HARNESS	37
BACK DOOR NO. 2 RH HARNESS	38
HARNESS	39
Harness Layout	39
HOW TO READ HARNESS LAYOUT	39
OUTLINE	40
MAIN HARNESS	41
ENGINE ROOM HARNESS (LH VIEW)	43
ENGINE ROOM HARNESS (RH VIEW)	46
ENGINE CONTROL HARNESS	48
CHASSIS HARNESS	50
BODY HARNESS	52
BODY NO. 2 HARNESS	54
ROOM LAMP HARNESS	56
FRONT DOOR LH HARNESS	57
FRONT DOOR RH HARNESS	57
REAR DOOR LH HARNESS	58
REAR DOOR RH HARNESS	58
BACK DOOR HARNESS	59
Wiring Diagram Codes (Cell Codes)	60
ELECTRICAL UNITS LOCATION	62
Electrical Units Location	62
ENGINE COMPARTMENT	62
PASSENGER COMPARTMENT	63
Fuse	65
Fusible Link	65
Circuit Breaker (Built Into BCM)	65
HARNESS CONNECTOR	66
Description	66
HARNESS CONNECTOR (TAB-LOCKING TYPE)	66
HARNESS CONNECTOR (SLIDE-LOCKING TYPE)	67
HARNESS CONNECTOR (DIRECT-CONNECT	67

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
PG

SRS COMPONENT TYPE)	68	SUPER MULTIPLE JUNCTION (SMJ)	72
ELECTRICAL UNITS	69	Terminal Arrangement	72
Terminal Arrangement	69	FUSE BLOCK-JUNCTION BOX(J/B)	74
STANDARDIZED RELAY	70	Terminal Arrangement	74
Description	70	FUSE AND FUSIBLE LINK BOX	75
NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS	70	Terminal Arrangement	75
TYPE OF STANDARDIZED RELAYS	70	FUSE AND RELAY BOX	76
		Terminal Arrangement	76

PRECAUTIONS

PFP:00011

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS006RO

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiring Diagrams and Trouble Diagnosis

EKS006RP

When you read wiring diagrams, refer to the following:

- Refer to [GI-15, "How to Read Wiring Diagrams"](#) in GI section.
- Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution.

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section.
- Refer to [GI-27, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section.

A

B

C

D

E

F

G

H

I

J

PG

L

M

POWER SUPPLY ROUTING CIRCUIT


POWER SUPPLY ROUTING CIRCUIT

PFP:24110


Schematic

For detailed ground distribution, refer to [PG-29, "Ground Distribution"](#).

EKS006RQ



POWER SUPPLY ROUTING CIRCUIT







WKWA1577E

POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram — POWER — BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION



EKS006RR



WKWA2806E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-02





WKWA2807E


POWER SUPPLY ROUTING CIRCUIT

: WITH FRONT FOG LAMPS
 : CANADA
 : USA

PG-POWER-03





REFER TO THE FOLLOWING.




WKWA1580E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-04





REFER TO THE FOLLOWING.



WKWA1581E

POWER SUPPLY ROUTING CIRCUIT


PG-POWER-05



WKWA1582E

POWER SUPPLY ROUTING CIRCUIT

ACCESSORY POWER SUPPLY — IGNITION SW. IN ACC OR ON



IG1	ST	B	M26
IG2	ACC	R	W

J-2 *

* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

M31 - SUPER MULTIPLE JUNCTION (SMJ)



The diagram illustrates the layout of the FUSE BLOCK - JUNCTION BOX (J/B). It features several rectangular boxes labeled M4, M39, and M60 at the top left. Below these are two vertical columns of boxes. The left column contains numbered fuses 1 through 8. The right column contains numbered fuses 19 through 22. An upward-pointing arrow is positioned next to the top-right fuse box, labeled 'UP'.

WKWA1583E

POWER SUPPLY ROUTING CIRCUIT

IGNITION POWER SUPPLY — IGNITION SW. IN ON

PG-POWER-07



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.


(M3) , (M39)	- FUSE BLOCK - JUNCTION BOX (J/B)
	11 10 9 8
	22 21 20
	19
	18 17 16 15
	14 13 12

WKWA1584E

POWER SUPPLY ROUTING CIRCUIT

IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START

PG-POWER-08



IG1	ST	B
IG2	ACC	R

(M26)

W


REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE
JUNCTION (SMJ)

WKWA1585E

POWER SUPPLY ROUTING CIRCUIT



PG-POWER-09




WKWA1586E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10




REFER TO THE FOLLOWING.



WKWA1587E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-11




IG1	ST	B
IG2	ACC	R

(M26)

W

REFER TO THE FOLLOWING.

(M4, M39)
- FUSE BLOCK - JUNCTION BOX (J/B)



WKWA1588E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**System Description**

EKS006RS

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relays via IPDM E/R control circuits.
- IPDM E/R-integrated control circuits perform ON-OFF operation of relays, CAN communication control, etc.
- It controls operation of each electrical component via ECM, BCM and CAN communication lines.

CAUTION:**None of the IPDM E/R integrated relays can be removed.****SYSTEMS CONTROLLED BY IPDM E/R**

1. Lamp control

Using CAN communication lines, it receives signals from the BCM and controls the following lamps:

- Headlamps (Hi, Lo)
- Parking lamps
- Tail lamps
- Front fog lamps

2. Wiper control

Using CAN communication lines, it receives signals from the BCM and controls the front wipers.

3. Rear window defogger relay control

Using CAN communication lines, it receives signals from the BCM and controls the rear window defogger relay.

4. A/C compressor control

Using CAN communication lines, it receives signals from the ECM and controls the A/C compressor (magnetic clutch).

5. Starter control

Using CAN communication lines, it receives signals from the ECM and controls the starter relay.

6. Cooling fan control

Using CAN communication lines, it receives signals from the ECM and controls the cooling fan relays.

7. Horn control

Using CAN communication lines, it receives signals from the BCM and controls the horn relay.

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L-line, CAN H-line), it is possible to transmit a maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

1. Fail-safe control

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication returns to normal operation, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none"> ● With the ignition switch ON, the headlamp (low) is ON. ● With the ignition switch OFF, the headlamp (low) is OFF.
Tail and parking lamps	<ul style="list-style-type: none"> ● With the ignition switch ON, the tail and parking lamps are ON. ● With the ignition switch OFF, the tail and parking lamps are OFF.
Cooling fan	<ul style="list-style-type: none"> ● With the ignition switch ON, the cooling fan HI operates. ● With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay OFF

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Controlled system	Fail-safe mode
A/C compressor	A/C compressor OFF
Front fog lamps	Front fog lamp relay OFF

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status

- CAN communication is normally performed with other control units.
- Individual unit control by IPDM E/R is normally performed.
- When sleep request signal is received from BCM, mode is switched to sleep waiting status.

2. Sleep waiting status

- Process to stop CAN communication is activated.
- All systems controlled by IPDM E/R are stopped. When 1 second has elapsed after CAN communication with other control units is stopped, mode switches to sleep status.

3. Sleep status

- IPDM E/R operates in low current-consumption mode.
- CAN communication is stopped.
- When a change in CAN communication signal is detected, mode switches to CAN communication status.
- When a change in ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

EKS006RT

Refer to [LAN-5, "CAN COMMUNICATION"](#).

Function of Detecting Ignition Relay Malfunction

EKS006RU

- When the integrated ignition relay is stuck in a "closed contact" position and cannot be turned OFF, IPDM E/R turns ON tail and parking lamps for 10 minutes to indicate IPDM E/R malfunction.
- When the state of the integrated ignition relay does not agree with the state of the ignition switch signal received via CAN communication, the IPDM E/R activates the tail lamp relay.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

When the ignition switch is turned ON, the tail lamps are OFF.

CONSULT-II Function (IPDM E/R)


CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.


CONSULT-II BASIC OPERATION**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

- With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.




- Touch "START (NISSAN BASED VHCL)".




- Touch "IPDM E/R" on "SELECT SYSTEM" screen.

- If "IPDM E/R" is not displayed, print "SELECT SYSTEM" screen, then refer to [LAN-3, "PRECAUTIONS"](#).



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


4. Select the desired part to be diagnosed on the "SELECT DIAG MODE" screen.



SELF-DIAGNOSTIC RESULTS

Operation Procedure

1. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
2. Self-diagnosis results are displayed.



Display Item List

Display items	CONSULT-II display code	Malfunction detection	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	—	—
CAN COMM CIRC	U1000	<ul style="list-style-type: none"> If CAN communication reception/transmission data has a malfunction, or if any of the control units fail, data reception/transmission cannot be confirmed. When the data in CAN communication is not received before the specified time. 	X	X	Any of items listed below have errors: <ul style="list-style-type: none"> TRANSMIT DIAG ECM BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and placed in IPDM E/R memory.

DATA MONITOR

Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECT FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All signals will be monitored.
MAIN SIGNALS	Monitors the predetermined item(s).
SELECT FROM MENU	Selects and monitors individual signal(s).

3. Touch "START".
4. Touch the required monitoring item on "SELECT ITEM MENU".

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

All Signals, Main Signals, Select From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECT FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	X	X	X	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	X	X	X	Signal status input from ECM
Tail & clear request	TAIL & CLR REQ	ON/OFF	X	X	X	Signal status input from BCM
H/L LO request	HL LO REQ	ON/OFF	X	X	X	Signal status input from BCM
H/L HI request	HL HI REQ	ON/OFF	X	X	X	Signal status input from BCM
FR fog request	FR FOG REQ	ON/OFF	X	X	X	Signal status input from BCM
FR wiper request	FR WIP REQ	STOP/1LOW/LOW/HI	X	X	X	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	X	X	X	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/Block	X	X	X	Control status of IPDM E/R
Starter request	ST RLY REQ	ON/OFF	X		X	Status of input signal <small>NOTE</small>
Ignition relay status	IGN RLY	ON/OFF	X	X	X	Ignition relay status monitored with IPDM E/R
Rear defogger request	RR DEF REQ	ON/OFF	X	X	X	Signal status input from BCM
Oil pressure switch	OIL P SW	OPEN/CLOSE	X		X	Signal status input from IPDM E/R (function is not enabled)
Hood switch	HOOD SW	OFF	X			Signal status input from IPDM E/R (function is not enabled)
Theft warning horn request	THFT HRN REQ	ON/OFF	X		X	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	X		X	Output status of IPDM E/R
Daytime running lamp request	DTRL REQ	ON/OFF	X		X	Signal status input from BCM

NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is in ACC position, display may not be correct.

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG-MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "STOP" while testing to stop the operation.

Test name	CONSULT-II screen display	Description
Rear defogger output	REAR DEFOGGER	With a certain ON-OFF operation, the rear defogger relay can be operated.
Front wiper (HI, LO) output	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan output	MOTOR FAN	With a certain operation (1, 2, 3, 4), the cooling fan can be operated.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Test name	CONSULT-II screen display	Description
Lamp (HI, LO, TAIL, FOG) output	EXTERNAL LAMPS	With a certain operation (OFF, HI ON, LO ON, TAIL ON, FOG ON), the lamp relay (Low, High, Tail, Fog) can be operated.
Cornering lamp output	CORNERING LAMP	—
Horn output	HORN	With a certain ON-OFF operation, the horn relay can be operated.

Auto Active Test

DESCRIPTION

EKS006RW

- In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:
 - Rear window defogger
 - Front wipers
 - Tail and parking lamps
 - Front fog lamps
 - Headlamps (Hi, Lo)
 - A/C compressor (magnetic clutch)
 - Cooling fan

OPERATION PROCEDURE

- Close hood and front door RH, and lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

- Turn ignition switch OFF.
- Turn ignition switch ON and, within 20 seconds, press front door switch LH 10 times. Then turn ignition switch OFF.
- Turn ignition switch ON within 10 seconds after ignition switch OFF.
- When auto active test mode is actuated, horn chirps once.
- After a series of operations is repeated three times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to perform BL-28, "Door Switch Check" when the auto active test cannot be performed.

INSPECTION IN AUTO ACTIVE TEST MODE

- When auto active test mode is actuated, the following seven steps are repeated three times.



WKIA1452E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of the systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.


Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit
		NO	<ul style="list-style-type: none"> Rear window defogger relay Open circuit of rear window defogger IPDM E/R malfunction Harness or connector malfunction between IPDM E/R and rear window defogger
Any of front wipers, tail and parking lamps, front fog lamps, and headlamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	<ul style="list-style-type: none"> BCM signal input system
		NO	<ul style="list-style-type: none"> Lamp/wiper motor malfunction Lamp/wiper motor ground circuit malfunction Harness/connector malfunction between IPDM E/R and system in question IPDM E/R (integrated relay) malfunction
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit CAN communication signal between BCM and ECM CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Magnetic clutch malfunction Harness/connector malfunction between IPDM E/R and magnetic clutch IPDM E/R (integrated relay) malfunction
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	<ul style="list-style-type: none"> ECM signal input circuit CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Cooling fan motor malfunction Harness/connector malfunction between IPDM E/R and cooling fan motor IPDM E/R (integrated relay) malfunction

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic

EKS006RX




WKWA2809E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Terminal Arrangement

EKS006RY



WKIA3923E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Power/Ground Circuit Inspection

EKS006RZ

1. FUSE AND FUSIBLE LINK INSPECTION

- Check that the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Signal name	Fuse, fusible link No.
1, 2, 22	Battery power	a, c, d, e, l

OK or NG

OK >> GO TO 2.

NG >> Replace fuse or fusible link.

2. POWER CIRCUIT INSPECTION


- Disconnect IPDM E/R harness connector E118.
- Check voltage between IPDM E/R harness connector E118 terminals 1 (B/Y), 2 (R) and ground.

Battery voltage should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace IPDM E/R power circuit harness.



3. GROUND CIRCUIT INSPECTION


- Disconnect IPDM E/R harness connectors E122 and E124.
- Check continuity between IPDM E/R harness connector E122 terminal 38 (B), and E124 terminal 59 (B) and ground.

Continuity should exist.

OK or NG

OK >> Inspection End.

NG >> Repair or replace ground circuit harness of IPDM E/R.



Inspection with CONSULT-II (Self-Diagnosis)

EKS006S0

CAUTION:

If a CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on which control unit(s) carry out CAN communication.

1. SELF-DIAGNOSIS RESULT CHECK

1. Connect CONSULT-II and select "IPDM E/R" on the Diagnosis System Selection screen.
2. Select "SELF-DIAG RESULTS" on the diagnosis mode selection screen.
3. Check display content in self-diagnosis results.

CONSULT-II Display	CONSULT-II display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	No malfunction
CAN COMM CIRC	U1000	X	X	Any of items listed below have errors: <ul style="list-style-type: none"> TRANSMIT DIAG ECM BCM/SEC

NOTE:

The Details for Display for the Period are as follows:

- CRNT: Error currently detected by IPDM E/R.
- PAST: Error detected in the past and stored in IPDM E/R memory.

Contents displayed

NO DTC DETECTED. FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END.

CAN COMM CIRC>>Print out the self-diagnosis result and refer to [LAN-5, "CAN COMMUNICATION"](#).

A

B

C

D

E

F

G

H

I

J

PG

L


M

Removal and Installation of IPDM E/R


EKS006S1

REMOVAL

1. Disconnect negative battery cable.
2. Remove IPDM E/R upper cover.



3. Release 2 clips and pull IPDM E/R up from case.
4. Disconnect IPDM E/R connectors and remove the IPDM E/R.



INSTALLATION

Installation is in the reverse order of removal.



GROUND CIRCUIT

GROUND CIRCUIT

PFP:24080

Ground Distribution MAIN HARNESS

EKS006S2



CONNECTOR NUMBER	CONNECT TO
(M5)	Illumination control switch
(M20)	BCM (Terminal 67)
(M21)	NATS antenna amp
(M22)	Data link connector (Terminal 4)
(M22)	Data link connector (Terminal 5)
(M24)	Combination meter (Terminal 17)
(M28)	Combination switch (Terminal 12)
(M35)	Air bag diagnosis sensor
(M47)	Steering angle sensor
(M51)	Front blower switch
(M87)	Rear power vent window relay (open)
(M89)	Rear power vent window relay (close)
(M97)	Heated seat relay
(M112)	BOSE speaker amp (Terminal 17)
(M122)	Variable blower control
(M139)	Diode-1
(D107)	Door mirror RH (door mirror defogger)
(M203)	A/T device (Terminal 2)
(M203)	A/T device (Terminal 8)

A

B

C

D

E

F

G

H

I

J


PG

L

M

WKIA2808E


GROUND CIRCUIT



Preceding page

A

Body ground




Next page

B


CONNECTOR NUMBER	CONNECT TO
(M14)	Pedal adjusting control unit
(M34)	Automatic drive positioner (Terminal 40)
(M34)	Automatic drive positioner (Terminal 48)
(M76)	Electric brake (pre-wire)
(M92)	Power liftgate switch
(M93)	Display unit (Terminal 1)
(M94)	Display control unit (Terminal 3)
(M96)	Pedal adjusting switch
(M116)	Rear sonar system off switch (Terminal 3)
(M118)	Rear sonar system off switch (Terminal 2)
(R7)	Auto anti-dazzling inside mirror
(D4)	Door mirror LH (door mirror defogger)
(D5)	Seat memory switch
(D8)	Main power window and door lock/unlock switch (Terminal 17)
(D10)	Door mirror switch
(D14)	Front door lock assembly LH

WKIA3849E

GROUND CIRCUIT



Preceding page



CONNECTOR NUMBER	CONNECT TO
(M3)	Fuse block J/B
(M13)	Front passenger air bag off indicator
(M49)	Front air control (Terminal 1)
(M52)	Rear blower switch (front)
(M53)	Front power socket LH
(M54)	Front power socket RH (for cigarette lighter)
(M55)	Hazard switch
(M59)	Glove box lamp
(M81)	Shift lock control unit
(M98)	AV switch
(M107)	Front blower motor relay
(R3)	Vanity lamp LH
(R7)	Auto anti-dazzling inside mirror
(R8)	Vanity lamp RH
(R4)	Sunroof motor
(R102)	Front room/map lamp assembly
(R103)	Rear power vent window switch
(D105)	Power window and door lock/unlock switch RH
(M206)	DVD player (Terminal 22)
(M207)	Console power socket
(M252)	Front heated seat switch RH
(M253)	VDC OFF switch
(M254)	Tow mode switch (Terminal 2)
(M255)	Tow mode switch (Terminal 6)
(M255)	Front heated seat switch LH

A
B
C
D
E
F
G
H
I
J


PG

L
M

WKIA2810E

GROUND CIRCUIT

ENGINE ROOM HARNESS




CONNECTOR NUMBER	CONNECT TO
(E16)	ECM (Terminal 115)
(E16)	ECM (Terminal 116)
(F12)	Heated oxygen sensor 2 (bank 2)
(F13)	Heated oxygen sensor 2 (bank 1)
(F102)	Knock sensor (bank 1) shield
(F104)	Knock sensor (bank 2) shield
(F9)	A/T assembly (TCM) (Terminal 10)
(F9)	A/T assembly (TCM) (Terminal 5)
(F11)	Crankshaft position sensor (POS)
(F23)	Camshaft position sensor (PHASE)
(F50)	Electric throttle control actuator (throttle position sensor shield)
(F54)	ECM (Terminal 1)

CONNECTOR NUMBER	CONNECT TO
(E3)	Horn
(E11)	Front combination lamp LH (headlamp) (Terminal 3)
(E11)	Front combination lamp LH (headlamp) (Terminal 4)
(E21)	Brake fluid level switch
(E102)	Front fog lamp RH
(E103)	Daytime light relay
(E106)	Washer fluid level switch
(E113)	Cooling fan motor
(E116)	Condenser 2
(E148)	Trailer tow relay 1
(F68)	Water valve
(C5)	Fuel level sensor unit and fuel pump (fuel pump)
(C9)	Suspension air compressor
(C12)	License plate lamp

Next page

WKIA3898E

GROUND CIRCUIT



Preceding page

B

CONNECTOR NUMBER	CONNECT TO
(E46)	Transfer shift high relay (Terminal 1)
(E46)	Transfer shift high relay (Terminal 4)
(E47)	Transfer shift low relay (Terminal 1)
(E47)	Transfer shift low relay (Terminal 4)
(E130)	Compressor motor relay
(E140)	Trailer tow relay 2
(E148)	Trailer tow relay 1
(E142)	Transfer control unit (Terminal 3)
(F55)	ATP switch
(F57)	Transfer motor
(F58)	Transfer control device (actuator position switch) (Terminal 22)
(F59)	Wait detection switch
(F60)	Neutral-4LO switch
(C2)	Trailer
(C9)	Suspension air compressor

CONNECTOR NUMBER	CONNECT TO
(E107)	Front combination lamp RH (headlamp) (Terminal 3)
(E107)	Front combination lamp RH (headlamp) (Terminal 4)
(E23)	Front wiper motor
(E101)	Front fog lamp LH
(E122)	IPDM E/R (Terminal 38)
(E124)	IPDM E/R (Terminal 59)






A
B
C
D
E
F
G
H
I
J

PG

L
M

WKIA2812E



GROUND CIRCUIT



WKIA1459E

GROUND CIRCUIT

ENGINE CONTROL HARNESS



CONNECTOR NUMBER	CONNECT TO
(F6)	Ignition coil No. 2 (with power transistor)
(F7)	Ignition coil No. 4 (with power transistor)
(F8)	Ignition coil No. 6 (with power transistor)
(F21)	Condenser-1
(F47)	Ignition coil No. 1 (with power transistor)
(F48)	Ignition coil No. 3 (with power transistor)
(F49)	Ignition coil No. 5 (with power transistor)
(F51)	Ignition coil No. 7 (with power transistor)
(F52)	Ignition coil No. 8 (with power transistor)

A
B
C
D

E
F
G
H

I
J

PG


L

M



WKIA1460E

GROUND CIRCUIT

BODY HARNESS





CONNECTOR NUMBER	CONNECT TO
(B15)	LH side air bag satellite sensor (shield wire)




WKIA2813E

GROUND CIRCUIT

BODY NO. 2 HARNESS



CONNECTOR NUMBER	CONNECT TO
(B114)	RH side air bag satellite sensor (shield wire)



CONNECTOR NUMBER	CONNECT TO
(B105)	Rear combination lamp RH (turn signal)
(B110)	Seat belt buckle switch RH
(B118)	Front seat heater RH
(B119)	Condenser-3
(B120)	Condenser-4
(B130)	Rear combination lamp RH (stop/tail lamp)
(B135)	Back-up lamp RH
(B138)	Rear cargo power socket
(B151)	NAVI control unit (Terminal 1)
(B151)	NAVI control unit (Terminal 4)
(B152)	NAVI control unit (Terminal 30)
(R201)	Video monitor
(R202)	Personal lamp 2nd row
(R203)	Rear audio remote control unit (Terminal 15)
(R204)	Personal lamp 3rd row
(R205)	Rear air control switch
(D605)	Rear wiper motor (Terminal 3)
(D702)	Rear wiper motor (Terminal 5)
(D704)	Back door handle switch
(P103)	Power seat switch RH
(D301)	Rear power window switch RH


CONNECTOR NUMBER	CONNECT TO
(P152)	Occupant classification system control unit

WKIA2814E


A
B
C
D
E
F
G
H
I
J
PG
L
M

GROUND CIRCUIT

BACK DOOR NO. 2 RH HARNESS



CONNECTOR NUMBER	CONNECT TO
(D604)	Rear window defogger



WKIA1461E

HARNESS

PFP:24010

EKS006S3

HARNESS

Harness Layout

HOW TO READ HARNESS LAYOUT


The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness LH View (Engine Compartment)
- Engine Room Harness RH View (Engine Compartment)
- Engine Control Harness
- Chassis Harness
- Body Harness
- Body No. 2 Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

Example:



SEL252V

CONNECTOR SYMBOL


Main symbols of connector (in Harness Layout) are indicated below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
● Cavity: Less than 4				
● Relay connector				
● Cavity: From 5 to 8				
● Cavity: 9 or More				
● Ground terminal etc.	—			

PG


HARNESS

OUTLINE



Harness

MAIN HARNESS



- * Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

LKIA0423E

HARNESS


E2	<u>M109</u>	B/26	: Front air control	O/2	: Front passenger air bag module
	<u>M10</u>	D3	: Front air control	E3	: Front blower motor relay
	<u>M12</u>	D3	: Rear blower switch (front)	F5	: Yaw rate/side decel G-sensor
E3	<u>M3</u>	E3	: Fuse block (J/B)	A2	: Front tweeter LH
E3	<u>M4</u>	E3	: Fuse block (J/B)	D2	: Center speaker (with BOSE E)
C3	<u>M5</u>	C3	: Illumination control switch		
B4	<u>M6</u>	B4	: To <u>E10</u>	BR/2	: Front tweeter RH
B4	<u>M7</u>	B4	: Water valve relay	E2	: Rear sonar system OFF switch
A4	<u>M8</u>	A4	: To <u>D2</u>	C2	: BOSE speaker amp.
A4	<u>M9</u>	A4	: BR/24 : To <u>D1</u>	C2	: BOSE speaker amp.
A4	<u>M10</u>	A4	: To <u>E28</u>	B4	: Rear sonar system OFF switch
B3	<u>M11</u>	B3	: Parking brake switch	B3	: Sonar buzzer
E3	<u>M13</u>	E3	: Front passenger air bag off indicator	E2	: Remote keyless entry receiver
C3	<u>M18</u>	C3	: BCM (body control module)	E3	: Variable blower control (ATC)
C4	<u>M19</u>	C4	: BCM (body control module)	E3	: Front blower motor resistor (MTC)
C4	<u>M20</u>	C4	: BCM (body control module)	E3	: Tire pressure warning check connector
C3	<u>M21</u>	C3	: NATS antenna amplifier	C2	: Diode-1
C4	<u>M22</u>	C4	: W/16 : Data link connector	C2	: Diode-2
C2	<u>M24</u>	C2	: W/40 : Combination meter	D3	: 4WD shift switch
C3	<u>M26</u>	C3	: W/6 : Ignition switch	C4	: Mode door motor
C3	<u>M27</u>	C3	: W/4 : Key switch and key lock solenoid	E3	: Air mix door motor (passenger)
C3	<u>M28</u>	C3	: W/16 : Combination switch	C2	: Defroster door motor
C3	<u>M29</u>	C3	: Y/6 : Combination switch (spiral cable)	E2	: Intake sensor
C3	<u>M30</u>	C3	: GR/8 : Combination switch (spiral cable)	D2	: Air mix door motor (driver) (with ATC)
F4	<u>M31</u>	F4	: SMJ : To <u>E152</u>	D2	: Air mix door motor (front) (with MTC)
D4	<u>M32</u>	D4	: W/4 : In-vehicle sensor	Console sub-harness	
B4	<u>M33</u>	B4	: W/32 : Automatic drive positioner control unit	D4	<u>M201</u> : To <u>M56</u>
B4	<u>M34</u>	B4	: W/16 : Automatic drive positioner control unit	E4	<u>M202</u> : To <u>M64</u>
F5	<u>M35</u>	F5	: Y/28 : Air bag diagnosis sensor unit	D4	<u>M233</u> : AT device
E4	<u>M36</u>	E4	: SMJ : To <u>B149</u>	E5	<u>M205</u> : DVD player
E2	<u>M37</u>	E2	: B/1 : Fuse block (J/B)	E5	<u>M206</u> : L/16 : DVD player
E3	<u>M38</u>	E3	: B/2 : Fuse block (J/B)	E5	<u>M207</u> : Console power socket
E3	<u>M39</u>	E3	: W/8 : Fuse block (J/B)	Console switch sub-harness	
A4	<u>M40</u>	A4	: SMJ : To <u>B69</u>	E4	<u>M251</u> : BR/20 : To <u>M63</u>
C4	<u>M41</u>	C4	: W/16 : Satellite radio tuner (pre-wiring)	E4	<u>M252</u> : BR/6 : Heated seat switch (passenger)
D3	<u>M42</u>	D3	: W/12 : Audio unit	E4	<u>M253</u> : GR/6 : VDC OFF switch
D3	<u>M43</u>	D3	: W/10 : Audio unit	D4	<u>M254</u> : GR/8 : Tow mode switch
D3	<u>M44</u>	D3	: W/6 : Audio unit	D4	<u>M255</u> : BR/6 : Heated seat switch (driver)
D3	<u>M45</u>	D3	: W/16 : Audio unit	D5	<u>M256</u> : B/2 : AT device illumination
D3	<u>M46</u>	D3	: W/20 : Audio unit	Optical sensor sub-harness	
C3	<u>M47</u>	C3	: Steering angle sensor	D2	<u>M401</u> : W/4 : To <u>M65</u>
	<u>M48</u>			E2	<u>M402</u> : B/4 : Optical sensor
	<u>M49</u>				*

* : Refer to previous page

HARNESS

ENGINE ROOM HARNESS (LH VIEW)

Engine Compartment



Refer to PG-46, "ENGINE ROOM HARNESS (RH VIEW)" for continuation of engine room harness.

HARNESS


F4 E1	B/2	: Ambient sensor
E4 E4	Y/2	: Crash zone sensor
G4 E11	GR/2	: Front combination lamp LH
F4 E13	GR/2	: Ambient sensor 2
F3 E14	-	: Body ground
D3 E18	GR/2	: Front wheel sensor LH
E2 E21	GR/2	: Brake fluid level switch
D2 E23	GR/6	: Front wiper motor
F3 * E24	-	: Body ground
D3 E31	B/3	: Front pressure sensor
E3 E32	B/3	: Rear pressure sensor
D3 E49	B/6	: Active booster
G5 E101	B/2	: Front fog lamp LH
F3 E105	GR/2	: Washer motor
G3 E106	BR/2	: Washer fluid level switch
E2 E114	B/6	: Delta S sensor
E2 E125	B/47	: ABS actuator and electric unit (control unit)
F2 E126	-	: Body ground

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of WORK FLOW or TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

Passenger Compartment

* (E20)	B/8	: Accelerator pedal position (APP) sensor
(E26)	W/16	: To (M9)
(E29)	Y/4	: To (M10)
* (E34)	W/24	: To (B40)
(E35)	W/12	: To (B41)
(E36)	W/2	: To (B42)
* (E37)	BR/2	: ASCD brake switch
* (E38)	B/2	: Stop lamp switch
(E109)	W/2	: Pedal adjusting motor
(E110)	W/3	: Pedal adjusting motor



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


A
B
C
D
M
T
H
G
I
—
—
PG

WKIA3925E

Harness

ENGINE ROOM HARNESS (RH VIEW)

Engine Compartment



Refer to PG-43, "ENGINE ROOM HARNESS (LH VIEW)" for continuation of engine room harness.

HARNESS


E3 (E2) W/16	: To (F32)	D3 (E28) GR/2	: Fuse link box (battery)
C3 (E3) B/2	: Horn	D2 (E128) BR/2	: Fuse link box (battery)
E2 * (E5) W/24	: To (F14)	C2 (E30) W/2	: Compressor motor relay
F2 (E7) GR/2	: Fuse and fusible link box	C2 (E31) W/2	: Compressor motor relay
C3 (E9) -	: Body ground	D2 (E33) GR/2	: Transfer dropping resistor
D3 (E12) B/5	: Stop lamp relay	F5 (E138) W/8	: To (E107)
C2 * (E15) -	: Body ground	E2 (E40) BR/6	: Trailer tow relay 2
D2 * (E16) B/32	: ECM	F5 (E142) L/24	: Transfer control unit
F3 * (E19) W/16	: To (F33)	F5 (E143) G/24	: Transfer control unit
G5 * (E33) B/1	: To (M66)	E3 (E148) L/4	: Trailer tow relay 1
E2 * (E38) W/2	: To (F34)	D3 (E151) -	: Battery ground
F3 * (E40) GR/2	: To (E201)	G5 (E162) SMJ	: To (M31)
F3 * (E41) SMJ	: To (C1) (located RH rear of engine compartment)	C2 (E153) GR/2	: Transfer motor relay
E2 (E45) BR/6	: Back-up lamp relay	C2 (E154) GR/2	: Transfer motor relay
E3 (E46) B/5	: Transfer shift high relay	(H-1) -	: Horn relay
E3 (E47) B/5	: Transfer shift low relay		
C4 (E48) B/3	: Refrigerant pressure sensor	F3 (E201) GR/2	: To (E40)
C5 (E102) B/2	: Front fog lamp RH	D2 (E202) B/1	: To fuse and fusible link box
E3 (E103) B/5	: Daytime light relay	D3 (E203) -	: Body ground
C2 (E107) B/6	: Front combination lamp RH	D4 (E204) -	: Generator
C4 (E113) GR/2	: Cooling fan motor	D4 (E205) GR/2	: Generator
F2 (E116) W/2	: Condenser-2	D4 (E206) -	: Generator
E3 (E117) GR/2	: Front wheel sensor RH		
F2 * (E118) B/2	: IPDM E/R (intelligent power distribution module engine room)		
E2 * (E119) W/16	: IPDM E/R (intelligent power distribution module engine room)		
E2 (E120) W/6	: IPDM E/R (intelligent power distribution module engine room)		
F3 * (E121) BR/12	: IPDM E/R (intelligent power distribution module engine room)		
E2 * (E122) W/12	: IPDM E/R (intelligent power distribution module engine room)		
F2 (E123) BR/8	: IPDM E/R (intelligent power distribution module engine room)		
E2 * (E124) B/6	: IPDM E/R (intelligent power distribution module engine room)		
D2 (E127) -	: Fuse link box (battery)		

* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

WKIA3961E

HARNESS

ENGINE CONTROL HARNESS



WKIA3927E

HARNESS

B4	(F3) B/1	: A/C Compressor	C3 * (F48) GR/3	: Ignition coil No. 3 (with power transistor)
B4	(F4) B/3	: Oil pressure sensor	D3 * (F49) GR/3	: Ignition coil No. 5 (with power transistor)
C2 *	(F5) B/6	: Air/fuel ratio (A/F) sensor 1 (bank 2)	B3 * (F50) B/6	: Electric throttle control actuator
A3 *	(F6) GR/3	: Ignition coil No. 2 (with power transistor)	D3 * (F51) GR/3	: Ignition coil No. 7 (with power transistor)
B2 *	(F7) GR/3	: Ignition coil No. 4 (with power transistor)	B1 * (F52) GR/3	: Ignition coil No. 8 (with power transistor)
B3 *	(F8) GR/3	: Ignition coil No. 6 (with power transistor)	C3 * (F53) B/6	: Mass air flow sensor
E3 *	(F9) G/10	: A/T assembly	A2 * (F54) B/81	: ECM
E3 *	(F11) B/3	: Crankshaft position sensor (POS)	G3 (F55) B/2	: ATP switch (4WD only)
F2 *	(F12) G/4	: Heated oxygen sensor 2 (bank 2)	G3 (F56) B/8	: Terminal cord assembly (4WD only)
F3 *	(F13) G/4	: Heated oxygen sensor 2 (bank 1)	G3 (F57) B/2	: Transfer motor (4WD only)
A2	(F14) W/24	: To (E5)	F3 (F58) GR/6	: Transfer control device (4WD only)
C3 *	(F15) L/2	: EVAP canister purge volume control solenoid valve	G2 (F59) B/2	: Wait detection switch (4WD only)
C4 *	(F16) -	: Engine ground	G2 (F60) GR/2	: Neutral-4LO switch (4WD only)
A3 *	(F18) GR/2	: Injector No. 2	D2 * (F65) B/6	: Air/fuel ratio (A/F) sensor 1 (bank 1)
B2 *	(F20) GR/2	: Injector No. 4	D1 (F68) B/2	: Water valve
D3 *	(F21) GR/2	: Condenser-1	Knock sensor sub-harness	
C2 *	(F22) GR/2	: Injector No. 6	B3 * (F101) B/6	: To (E26)
D2 *	(F23) B/3	: Camshaft position sensor (PHASE)	C3 * (F102) GR/2	: Knock sensor (bank 1)
F2	(F25) W/2	: Diode No. 2	B3 * (F103) GR/2	: Engine coolant temperature sensor
C3 *	(F26) B/6	: To (F101)	C2 (F104) GR/2	: Knock sensor (bank 2)
C2	(F27) B/1	: Starter motor		
D2	(F28) GR/1	: Starter motor		
C3 *	(F30) GR/2	: Injector No. 1		
C2 *	(F31) GR/2	: Injector No. 8		
A2 *	(F32) W/16	: To (E2)		
B1 *	(F33) W/16	: To (E19)		
B1 *	(F34) W/2	: To (E39)		
A3	(F40) -	: Fusible link box (battery)		
C3 *	(F41) GR/2	: Injector No. 3		
C2 *	(F42) GR/2	: Injector No. 5		
D2 *	(F45) GR/2	: Injector No. 7		
A3 *	(F46) B/3	: Power steering pressure sensor		
C3 *	(F47) GR/3	: Ignition coil No. 1 (with power transistor)		

* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A

B

C

D

M

G

U

M

T


I

PG

WKIA3928E

HARNESS

CHASSIS HARNESS



LKIA0432E

HARNESS

F3 * (C1)	SMJ	: To (E41) (located RH rear of engine compartment)
A4 (C2)	B/7	: Trailer
B3 (C3)	GR/6	: To (C10)
D3 * (C4)	GR/3	: EVAP control system pressure sensor
D4 * (C5)	GR/5	: Fuel level sensor unit and fuel pump
C3 * (C6)	B/2	: EVAP canister vent control valve
C4 (C8)	B/3	: Height sensor
C4 (C9)	B/4	: Suspension air compressor
D4 (C10)	BR/2	: Rear wheel sensor RH
B3 (C11)	BR/2	: Rear wheel sensor LH
A3 (C12)	GR/2	: License plate lamps

Rear sonar sensor sub-harness


A3 (C13)	GR/6	: To (C3)
A3 (C12)	B/3	: Rear sonar sensor LH outer
A4 (C13)	B/3	: Rear sonar sensor LH inner
B4 (C14)	B/3	: Rear sonar sensor RH inner
B4 (C15)	B/3	: Rear sonar sensor RH outer

* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT
sections.

WKIA3940E

HARNESS

BODY HARNESS



HARNESS

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O


P

F2	(B3)	W/16	: Suspension control unit
D4	(B5)	-	: Body ground
E3	(B6)	W/18	: To (B20)
D4	(B7)	-	: Body ground
F3	(B8)	W/3	: Front door switch LH
E3	(B9)	Y/12	: Air bag diagnosis sensor unit
E4	(B10)	Y/2	: Front LH side air bag module
E3	(B12)	W/3	: Seat belt buckle switch LH
E4	(B14)	Y/2	: Front LH seat belt pre-tensioner
E4	(B15)	Y/2	: LH side air bag (satellite) sensor
F3	(B18)	W/3	: Rear door switch LH
G1	(B19)	-	: Body ground
G2	(B35)	B/3	: Rear combination lamp LH (turn signal)
D4	(B37)	W/16	: To (P1)
C2	(B38)	Y/2	: LH side curtain air bag module
C4	(B40)	W/24	: To (E34)
C4	(B41)	W/12	: To (E35)
C4	(B42)	W/2	: To (E36)
C3	(B43)	W/12	: To (B11)
F1	(B48)	W/16	: To (B40)
F1	(B49)	W/2	: To (D402)
F2	(B52)	W/2	: Rear power vent window motor LH
F2	(B54)	Y/2	: LH side curtain air bag module
G2	(B55)	W/26	: Back door control unit
F3	(B56)	W/16	: Sonar control unit
G2	(B63)	W/6	: Back door close switch
D3	(B64)	W/4	: To (B15)
D4	(B69)	SMJ	: To (M40)
G3	(B70)	B/3	: Rear combination lamp LH (stop/tail)
G2	(B71)	B/2	: Back-up lamp LH
D4	(B72)	BR/6	: Subwoofer (with BOSE audio system)

WKIA2822E

Harness

BODY NO. 2 HARNESS



For detailed ground distribution information, refer to "GROUND DISTRIBUTION".

HARNESS

G4	<u>(B101)</u> W/16	: To <u>(B88)</u>	G4	<u>(B149)</u> SMJ	: To <u>(N36)</u>
B2	<u>(B105)</u> B/3	: Rear combination lamp RH (turn signal)	C2	<u>(B150)</u> W/2	: Rear power vent window motor RH
D3	<u>(B106)</u> W/18	: To <u>(D301)</u>	F5	<u>(B151)</u> W/24	: NAVI control unit
F5	<u>(B107)</u> W/8	: To <u>(E139)</u>	F5	<u>(B152)</u> GR/24	: NAVI control unit
E3	<u>(B108)</u> W/3	: Front door switch RH	D1	<u>(B153)</u> W/2	: Cargo lamp
E4	<u>(B110)</u> W/3	: Seat belt buckle switch RH	E4	<u>(B154)</u> W/2	: To <u>(P103)</u>
G3	<u>(B111)</u> W/12	: To <u>(B3)</u>	C3	<u>(B155)</u> B/6	: Air mix door motor (rear)
F4	<u>(B112)</u> -	: Body ground (RH satellite sensor)	G3	<u>(B156)</u> W/4	: To <u>(B64)</u>
F3	<u>(B113)</u> Y/12	: Air bag diagnosis sensor unit			
D5	<u>(B114)</u> Y/2	: RH side air bag (satellite) sensor			
D3	<u>(B116)</u> W/3	: Rear door switch RH			
F4	<u>(B117)</u> -	: Body ground			
E4	<u>(B118)</u> W/3	: Front seat heater RH			
C2	<u>(B119)</u> W/2	: Condensor-3			
C3	<u>(B120)</u> W/2	: Condensor-4			
E5	<u>(B126)</u> Y/2	: Front RH side air bag module			
D5	<u>(B127)</u> Y/2	: Front RH seat belt pre-tensioner			
F2	<u>(B128)</u> Y/2	: RH side curtain air bag module			
C2	<u>(B129)</u> Y/2	: RH side curtain air bag module			
B3	<u>(B130)</u> B/3	: Rear combination lamp RH (stop/tail)			
B2	<u>(B132)</u> -	: Body ground			
C4	<u>(B133)</u> W/4	: Rear blower motor resistor			
C3	<u>(B134)</u> W/2	: Rear blower motor			
B2	<u>(B135)</u> B/2	: Back-up lamp RH			
E3	<u>(B136)</u> W/8	: To <u>(P15)</u>			
D4	<u>(B137)</u> B/3	: Belt tension sensor			
C2	<u>(B138)</u> B/2	: Rear cargo power socket			
C1	<u>(B139)</u> W/20	: To <u>(P002)</u>			
C1	<u>(B140)</u> W/6	: To <u>(P011)</u>			
D1	<u>(B145)</u> BR/24	: To <u>(P200)</u>			
D1	<u>(B146)</u> W/16	: To <u>(P201)</u>			
D1	<u>(B147)</u> W/4	: To <u>(P207)</u>			

A

B

C

D

M

T

G

H

—

U

PG


—

M

WKIA2823E

HARNESS

ROOM LAMP HARNESS




WKIA2824E

HARNESS

FRONT DOOR LH HARNESS


(D1) W/24	: To (M9)	(D9) GR/6	: Front power window motor LH
(D2) W/16	: To (M8)	(D10) W/10	: Door mirror switch
(D4) W/16	: Door mirror LH	(D11) W/2	: Front step lamp LH
(D5) W/8	: Seat memory switch	(D12) W/2	: Front door speaker LH
(D7) W/16	: Main power window and door lock/unlock switch	(D14) B/6	: Front door lock assembly LH (key cylinder switch)
(D8) W/3	: Main power window and door lock/unlock switch		



WKIA2840E

FRONT DOOR RH HARNESS

(D101) W/8	: To (M75)	(D107) W/16	: Door mirror RH
(D102) W/20	: To (M74)	(D108) W/2	: Front step lamp RH
(D104) GR/6	: Front power window motor RH	(D112) W/2	: Front door speaker RH
(D105) W/16	: Power window and door lock/unlock switch RH	(D114) B/6	: Front door lock actuator RH



LKIA0440E


A
B
C
D
E
F
G
H
I
J

PG

L
M


HARNESS

REAR DOOR LH HARNESS



LKIA0441E

REAR DOOR RH HARNESS




LKIA0442E

HARNESS

BACK DOOR HARNESS

A
B
C
D
E
F
G
H
I
J

PG



Back door No. 2 LH harness

- (D401) W/16 : To (B48)
- (D402) W/2 : To (B49)
- (D403) GR/2 : High-mounted stop lamp
- (D405) W/16 : To (D501)
- (D406) B/1 : Rear window defogger

Back door LH harness

- (D501) W/16 : To (D405)
- (D502) W/3 : Back door switch
- (D503) W/8 : Back door latch
- (D514) BR/2 : Back door warning chime
- (D517) BR/2 : Pinch strip LH


Back door No. 2 RH harness

- (D601) W/6 : To (B140)
- (D602) W/20 : To (B139)
- (D603) - : Body ground
- (D604) B/1 : Rear defogger ground
- (D605) W/8 : To (D702)
- (D606) W/20 : To (D701)

Back door RH harness

- (D701) W/20 : To (D606)
- (D702) W/8 : To (D605)
- (D704) W/6 : Rear wiper motor
- (D706) GR/2 : Back door handle switch
- (D707) B/1 : Glass hatch ajar switch
- (D708) W/4 : Back door lock actuator
- (D715) BR/2 : Pinch strip RH

Body ground



For detailed ground distribution information, refer to "Ground Distribution".

WKIA3929E

HARNESS

Wiring Diagram Codes (Cell Codes)

EKS006S4

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C,A	ATC	Auto Air Conditioner
A/C,M	MTC	Manual Air Conditioner
A/SUSP	RSU	Rear Air Suspension
AF1B1	EC	Air Fuel Ratio Sensor 1 Bank 1
AF1B2	EC	Air Fuel Ratio Sensor 1 Bank 2
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	ASCD Brake Switch
ASC/SW	EC	ASCD Steering Switch
ASCBOF	EC	ASCD Brake Switch
ASCIND	EC	ASCD Indicator
A/T	AT	A/T Assembly
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
AUTO/DP	SE	Automatic Drive Positioner
AUTO/L	LT	Auto Light Control
B/CLOS	BL	Back Door Auto Closure System
BACK/L	LT	Back-up Lamp
BRK/SW	EC	Brake Switch
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
COOL/F	EC	Cooling Fan Control
COMBSW	LT	Combination Switch
COMM	AV	Audio Visual Communication System
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
DVD	AV	DVD Entertainment System
ECM/PW	EC	ECM Power Supply for Back-Up
ECTS	EC	Engine Coolant Temperature Sensor
ETC1	EC	Electric Throttle Control Function
ETC2	EC	Throttle Control Motor Relay
ETC3	EC	Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/PUMP	EC	Fuel Pump
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Bank 1
FUELB2	EC	Fuel Injection System Bank 2
H/LAMP	LT	Headlamp
HORN	WW	Horn
HSEAT	SE	Heated Seat
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
IATS	EC	Intake Air Temperature Sensor
IGNSYS	EC	Ignition System

HARNESS

ILL	LT	Illumination
INJECT	EC	Injectors
INT/L	LT	Room/Map, Vanity, Cargo, Personal, Foot, Step, and Puddle Lamps
KEYLES	BL	Remote Keyless Entry System
KS	EC	Knock Sensor
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply and Ground Circuit
METER	DI	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	Malfunction Indicator Lamp
MIRROR	GW	Door Mirror
NATS	BL	Nissan Anti-Theft System
NAVI	AV	Navigation System
O2H2B1	EC	Rear Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Rear Heated Oxygen Sensor 2 Heater Bank 2
O2S2B1	EC	Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Heated Oxygen Sensor 2 Bank 2
P/SCKT	WW	Power Socket
PEDAL	AP	Adjustable Pedal System
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE) (Bank 1)
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (POS)
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Pressure Sensor
RP/SEN	EC	Refrigerant Pressure Sensor
SEAT	SE	Power Seat
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SONAR	DI	Rear Sonar System
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
START	SC	Starting System
STOP/L	LT	Stop Lamp
T/TOW	LT	Trailer Tow
T/WARN	WT	Low Tire Pressure Warning System
TAIL/L	LT	Parking, License and Tail Lamps
T/F	TF	Transfer Case
TPS1	EC	Throttle Position Sensor
TPS2	EC	Throttle Position Sensor
TPS3	EC	Throttle Position Sensor
TRNSCV	BL	HOMELINK® Universal Transceiver
TURN	LT	Turn Signal and Hazard Warning Lamps
VDC	BRC	Vehicle Dynamic Control System
VEHSEC	BL	Vehicle security (theft warning) system
VENT/V	EC	EVAP Canister Vent Control Valve
W/ANT	AV	Audio Antenna
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer
WIPER	WW	Front Wiper and Washer

A
B
C
D
E
F
G
H
I
J

PG

L
M
M


ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT


EKS006S5



LKIA0444E

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT




A
B
C
D
E
F
G
H
I
J

PG

A Instrument panel side RH










Fuse block (J/B) rear view



WKIA3930E

ELECTRICAL UNITS LOCATION




WKIA1536E

ELECTRICAL UNITS LOCATION

Fuse

EKS006S6

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.



Fusible Link

EKS006S7

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape.
- Never let fusible link touch any other wiring harness, vinyl or rubber parts.


Circuit Breaker (Built Into BCM)

EKS006S8

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

A circuit breaker is used for the following systems:

- Power windows
- Power door locks
- Remote keyless entry system
- Power sunroof
- Rear window wiper



HARNESS CONNECTOR

PFP:B4341

HARNESS CONNECTOR

EKS006S9

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]




HARNESS CONNECTOR

HARNESS CONNECTOR (DIRECT-CONNECT SRS COMPONENT TYPE)

- SRS direct-connect type harness connectors are used on certain SRS components such as air bag modules and seat belt pre-tensioners.
- Always pull up to release black locking tab prior to removing connector from SRS component.
- Always push down to lock black locking tab after installing connector to SRS component. When locked, the black locking tab is level with the connector housing.

CAUTION:

- **Do not pull the harness or wires when removing connectors from SRS components.**




ELECTRICAL UNITS

ELECTRICAL UNITS


PFP:23710

Terminal Arrangement



EKS006TW




ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



ECM



TRANSFER CONTROL UNIT



WKIA1251E

STANDARDIZED RELAY


STANDARDIZED RELAY

PFP:25230

Description


NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H
















TYPE OF STANDARDIZED RELAYS



SEL882H

1M	1 Make	2M	2 Make
1T	1 Transfer	1M+1B	1 Make 1 Break

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector Symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLACK
				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

WKIA0253E

A
B
C
D
E
F
G
H
I
J

PG

L
M

SUPER MULTIPLE JUNCTION (SMJ)

SUPER MULTIPLE JUNCTION (SMJ)

Terminal Arrangement

PFP:84341

EKS006TY







MAIN HARNESS



(M31) (White)

(M36) (White)

(M40) (White)



ENGINE ROOM HARNESS

BODY HARNESS NO.2

BODY HARNESS


LKIA0385E

SUPER MULTIPLE JUNCTION (SMJ)

CHASSIS HARNESS



(C1) (Gray)



A
B
C
D
E
F
G
H

J
PG
L
M

ENGINE ROOM HARNESS

WKIA1845E


FUSE BLOCK-JUNCTION BOX(J/B)

FUSE BLOCK-JUNCTION BOX(J/B)

PFP:24350

Terminal Arrangement

EKS006TZ



WKIA2016E


FUSE AND FUSIBLE LINK BOX

FUSE AND FUSIBLE LINK BOX

PFP:24381

Terminal Arrangement

EKS006U0



A

B

C

D

E

F

G

H

I

J

PG

L

M

WKIA3896E


FUSE AND RELAY BOX

FUSE AND RELAY BOX

PFP:24012

Terminal Arrangement

EKS006U1



WKIA2017E