

ST SECTION STEERING SYSTEM

CONTENTS

PRECAUTION	3	On-Vehicle Inspection and Service	14
PRECAUTIONS	3	STEERING WHEEL	15
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	On-Vehicle Inspection and Service	15
Precaution for Steering System	3	REMOVAL AND INSTALLATION	17
PREPARATION	4	HYDRAULIC LINE	17
PREPARATION	4	Removal and Installation	17
Special Service Tool	4	POWER STEERING OIL PUMP	19
Commercial Service Tool	5	Removal and Installation	19
FUNCTION DIAGNOSIS	6	POWER STEERING GEAR AND LINKAGE	20
HEATED STEERING WHEEL	6	Removal and Installation	20
System Diagram	6	STEERING COLUMN	23
System Description	6	Removal and Installation	23
Component Parts Location	6	STEERING WHEEL	26
Component Description	7	Removal and Installation	26
COMPONENT DIAGNOSIS	8	DISASSEMBLY AND ASSEMBLY	27
HEATED STEERING WHEEL	8	POWER STEERING OIL PUMP	27
Wiring Diagram	8	Disassembly and Assembly	27
SYMPTOM DIAGNOSIS	11	POWER STEERING GEAR AND LINKAGE	28
NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING	11	Disassembly and Assembly	28
NVH Troubleshooting Chart	11	STEERING COLUMN	31
ON-VEHICLE MAINTENANCE	12	Disassembly and Assembly	31
POWER STEERING FLUID	12	SERVICE DATA AND SPECIFICATIONS (SDS)	33
Checking Fluid Level	12	SERVICE DATA AND SPECIFICATIONS (SDS)	33
Checking Fluid Leakage	12	Steering Wheel	33
Air Bleeding Hydraulic System	12	Steering Column	33
ON-VEHICLE REPAIR	14	Steering Outer Socket and Inner Socket	34
POWER STEERING OIL PUMP	14	Tie-rod	34
		Steering Gear	35

Oil Pump	35	Steering Fluid	35
----------------	----	----------------------	----

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000001534378

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Steering System

INFOID:0000000001534379

- Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- For easier and proper assembly, place disassembled parts in order on a parts rack.
- Use nylon cloth or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended Genuine NISSAN PSF or equivalent to hydraulic parts. Petroleum jelly may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.

PREPARATION

< PREPARATION >






PREPARATION

PREPARATION

Special Service Tool



INFOID:0000000001534380

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST3127 S000 (See J-25765-A) Preload gauge 1. GG9103000 (J-25765-A) Torque wrench 2. HT62940000 (—) Socket adapter 3. HT62900000 (—) Socket adapter	Inspecting of pinion rotating torque and rotational torque for ball joint  S-NT541
HT72520000 (J-25730-A) Ball joint remover	Removing steering outer socket  NT146
1. KV48105300-4 and 5295262U10 (—) Connector A and O-ring 2. KV48105300-3 and 5295262U00 (—) Eye-bolt and O-ring 3. KV48103500 (J-26357 and J-26357-10) Pressure gauge and shut-off valve 4. KV48105300-1 and 5295262U00 (—) Connector B and O-ring 5. KV48105300-2 (—) Nut	Measuring oil pump relief pressure 
KV481J0010 (J-1859-A) Steering wheel puller	Removing steering wheel  LHIA0043E
KV481J0020 (J-42578) Steering wheel puller legs	Removing steering wheel  LHIA0044E

PREPARATION

< PREPARATION >


Tool number (Kent-Moore No.) Tool name	Description
KV40107300 (—)	Crimping boot bands
	 ZZA1229D
— (J-44372) Spring gauge	Measuring steering wheel turning force
	 LST024

Commercial Service Tool

INFOID:0000000001534381

ST

Tool name	Description
Power tool	Removing nuts and bolts



PBIC0190E

H

I

J

K

L

M

N

O

P


HEATED STEERING WHEEL

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS HEATED STEERING WHEEL

System Diagram

INFOID:0000000001586888



AWGIA0022GB

System Description

INFOID:0000000001586889


The heated steering wheel switch controls the heated steering relay. When the switch is turned on, the relay is energized and the heated steering system will operate. The heated steering system will turn off when the steering wheel temperature reaches approximately 30° C (86° F). Heated steering system operation can also be canceled by pressing the heated steering wheel switch again.

NOTE:

The heated steering system will operate ONLY when the steering wheel surface is below approximately 20° C (68° F). If the weather is warm enough, the heated steering system may not turn on, giving the appearance that the system does not operate.

Component Parts Location

INFOID:0000000001586890



AWGIA0023ZZ

1. Heated steering relay M71
2. Combination switch (spiral cable) M52
3. Heated steering wheel M114
4. Heated steering wheel switch M260

HEATED STEERING WHEEL

< FUNCTION DIAGNOSIS >

Component Description

INFOID:000000001586891

Heated steering wheel switch	<ul style="list-style-type: none">Controls the heated steering relay and operates the heated steering system.Turns the indicator lamp ON when the system is activated.
Heated steering relay	<ul style="list-style-type: none">Operates the heated steering system with the control signal from the heated steering wheel switch.
Heated steering wheel	<ul style="list-style-type: none">Heats the heating element with the power supplied from the heated steering relay.

A

B

C

D

E

F

ST

H

I

J

K

L

M

N

O

P

HEATED STEERING WHEEL


< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

HEATED STEERING WHEEL

Wiring Diagram

INFOID:0000000001586892




ALGWA0007GE

HEATED STEERING WHEEL

< COMPONENT DIAGNOSIS >

HEATED STEERING WHEEL CONNECTORS

Connector No.	M52
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	WHITE



H.S.

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name
1	BR	—
2	B	—

Terminal No.	Color of Wire	Signal Name
1Q	G/R	—
2	—	—

Terminal No.	Color of Wire	Signal Name
9	BR	—
16	B	—
19	BR	—
20	B/R	—

Terminal No.	Color of Wire	Signal Name
1	Y	—
2	L	—

Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—

Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—

Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—


Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z


HEATED STEERING WHEEL

< COMPONENT DIAGNOSIS >


Connector No.	M260
Connector Name	HEATED STEERING WHEEL SWITCH
Connector Color	WHITE




Connector No.	M260
Connector Name	HEATED STEERING WHEEL SWITCH
Connector Color	WHITE



Connector No.	M251
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	Gr/R	—	16	B/W	—
2	B/R	—			
5	BR	—			
6	B	—			

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000001534382

Use chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		Fluid level	Air in hydraulic system	Outer socket ball joint swinging force	Outer socket ball joint rotating torque	Outer socket ball joint end play	Steering fluid leakage	Steering wheel play	Steering gear rack sliding force	Drive belt looseness	EM-12, "Checking Drive Belts"	ST-12	ST-12	ST-34	ST-34	ST-34	ST-12	ST-15	ST-15	ST-15	ST-15	ST-15	DLN-180, "NVH Troubleshooting Chart" (2F1310), DLN-188, "NVH Troubleshooting Chart" (2S1410)	DLN-201, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	ESU-4, "NVH Troubleshooting Chart"	WT-31, "NVH Troubleshooting Chart"	WT-31, "NVH Troubleshooting Chart"	FAX-4, "NVH Troubleshooting Chart"	BR-5, "NVH Troubleshooting Chart"
Symptom	Noise	x	x																											
	Shake											x																		
	Vibration											x	x	x	x	x														
	Shimmy											x																		
	Shudder											x																		

x: Applicable

A
B
C
D
M
T
H
I
—
M
Z
O
P

ST

POWER STEERING FLUID

< ON-VEHICLE MAINTENANCE >

ON-VEHICLE MAINTENANCE

POWER STEERING FLUID

Checking Fluid Level

INFOID:000000001534383

Check the power steering fluid level with the engine off.


Check fluid level, referring to the scale on reservoir tank.

Use HOT range for fluid temperatures of 50° – 80°C (122° – 176°F).

Use COLD range for fluid temperatures of 0° – 30°C (32° – 86°F).

CAUTION:

- Do not overfill.
- Do not reuse any power steering fluid.
- Use the recommended power steering fluid or equivalent.
Refer to [MA-10, "Fluids and Lubricants"](#).



LGIA0021E

Checking Fluid Leakage


INFOID:000000001534384

Check the hydraulic piping lines for improper attachment and for leaks, cracks, damage, loose connections, chafing or deterioration.

1. Run engine until fluid temperature reaches 50° – 80°C (122° – 176°F) in reservoir tank. Keep engine speed idle.
2. Turn steering wheel right-to-left several times.
3. Hold steering wheel at each “lock” position for five seconds to check fluid leakage.

CAUTION:

Do not hold steering wheel in a locked position for more than 10 seconds. (There is the possibility that oil pump may be damaged.)



SGIA0506E

4. If fluid leakage at connections is noticed, then loosen flare nut and then retighten. Do not over tighten connector as this can damage O-ring, washer and connector.
5. If fluid leakage from oil pump is noticed, check oil pump. Refer to [ST-14](#).
6. Check steering gear boots for accumulation of fluid indicating a leak from the steering gear.

Air Bleeding Hydraulic System

INFOID:000000001534385

Incomplete air bleeding causes the following. When this happens, bleed air again.

- Air bubbles in reservoir tank.
- Clicking noise in oil pump.
- Excessive buzzing in oil pump.

NOTE:

When vehicle is stationary or while steering wheel is being turned slowly, some noise may be heard from oil pump or gear. This noise is normal and does not affect any system.

1. Stop engine, and then turn steering wheel fully to right and left several times.

CAUTION:

Do not allow steering fluid reservoir tank to go below the MIN level line. Check tank frequently and add fluid as needed.

2. Run engine at idle speed. Turn steering wheel fully right and then fully left, hold for about three seconds. Then check for fluid leakage.

3. Repeat step 2 several times at about three second intervals.

CAUTION:

Do not hold steering wheel in the locked position for more than 10 seconds. (There is the possibility that oil pump may be damaged.)

4. Check for air bubbles or cloudy fluid.

POWER STEERING FLUID

< ON-VEHICLE MAINTENANCE >

5. If air bubbles or cloudiness still exists, stop engine, perform steps 2 and 3 again until air bubbles or cloudiness does not exist.
6. Stop engine, check fluid level.

A

B

C

D

E

F

ST

H

I

J

K

L

M

N

O

P

POWER STEERING OIL PUMP

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

POWER STEERING OIL PUMP

On-Vehicle Inspection and Service

INFOID:000000001534388

CHECKING RELIEF OIL PRESSURE


CAUTION:

Before starting work, confirm belt tension is correct. Refer to [EM-12, "Checking Drive Belts".](#)

1. Connect Tool between oil pump discharge connector and high pressure hose and then bleed air from the hydraulic circuit.

Tool number:

Pressure gauge and shut-off valve		KV48103500 (J26357 and J26357-10)
Oil pump side	Connector A and O-ring	KV48105300-4 and 5295262U10 (—)
	Eye-bolt and O-ring	KV48105300-3 and 5295262U00 (—)
High pressure piping side	Connector B and O-ring	KV48105300-1 and 5295262U00 (—)
	Nut	KV48105300-2 (—)



2. Start engine. Allow engine to run until tank temperature reaches 50 – 80°C (122 – 176°F).

CAUTION:

- Warm up engine with shut-off valve fully opened. If engine is started with shut-off valve closed, fluid pressure in power steering pump increases to maximum. This will raise fluid temperature excessively.
- Be careful not to contact hose with belt when engine is started.

3. With engine at idle, close shut-off valve and read the relief oil pressure.

Relief oil pressure : 9.0 – 9.8 mPa (91.77 – 99.93 kg/cm², 1305.34 – 1421.37 psi)

CAUTION:

Do not close shut-off valve of pressure gauge for more than 10 seconds.

4. After measurement, open shut-off valve slowly.
 - If relief oil pressure is outside the specification, disassemble and repair oil pump. Refer to [ST-27, "Disassembly and Assembly"](#).
5. After inspection, disconnect oil pressure gauge and oil pressure gauge adapter from hydraulic circuit, connect oil pump discharge connector and high pressure hose. Add fluid and bleed air from hydraulic circuit thoroughly. Refer to [ST-12, "Air Bleeding Hydraulic System"](#).

STEERING WHEEL

< ON-VEHICLE REPAIR >

STEERING WHEEL

On-Vehicle Inspection and Service


INFOID:0000000001534386

CHECKING CONDITION OF INSTALLATION

- Check installation condition of steering gear assembly, front suspension, axle and steering column.
- Check if movement exists when steering wheel is moved up and down, to the left and right and to the axial direction.

**End play of the axle direction : 0 mm (0 in)
for steering wheel**

- Check if the nuts for steering gear assembly are loose. Refer to [ST-20](#).



CHECKING STEERING WHEEL PLAY

1. Turn tires straight ahead, start engine, then turn steering wheel to the left and right lightly, and measure steering wheel movement on the outer circumference when steering wheel is turned up to the point where tires start moving.

Steering wheel play on the outer circumference : 0 – 35 mm (0 – 1.38 in)

CHECKING NEUTRAL POSITION ON STEERING WHEEL

- Check neutral position on steering wheel after confirming that front wheel alignment is correct. Refer to [FSU-5, "Front Wheel Alignment"](#).
1. Turn tires straight ahead, check if steering wheel is in the neutral position.
 2. If it is not in the neutral position, remove steering wheel and reinstall it correctly.
 3. If the neutral position cannot be attained by repositioning the steering wheel two teeth or less on steering stem, loosen tie-rod lock nuts of steering outer sockets, then adjust tie-rods by the same amount in the opposite direction.


CHECKING STEERING WHEEL TURNING FORCE

1. Park vehicle on a level, dry surface and set parking brake.
2. Start engine.
3. Bring power steering fluid up to an operating temperature of approximately 60° – 80°C (140° – 176°F). Make sure the tires are inflated to specified pressure. Refer to [WT-39, "Tire"](#).
4. Check steering wheel turning force using Tool when steering wheel has been turned 360° from the neutral position.

Tool number : J-44372

**Steering wheel : 39 N (4 kg-f, 9 lb-f) or less
turning force**

5. If steering wheel turning force is out of specification, inspect steering column. Refer to [ST-31, "Disassembly and Assembly"](#).
6. If steering column meets specification, repair steering gear. Refer to [ST-28, "Disassembly and Assembly"](#).



STEERING WHEEL

< ON-VEHICLE REPAIR >

CHECKING FRONT WHEEL TURNING ANGLE

When checking front wheel turning angle, refer to "CHECKING FRONT WHEEL TURNING ANGLE " .

HYDRAULIC LINE

< REMOVAL AND INSTALLATION >



REMOVAL AND INSTALLATION HYDRAULIC LINE

Removal and Installation

INFOID:000000001534414

Refer to the following illustration for hydraulic line removal.

SEC. 490 • 492 • 497



: Lubricate with engine oil

: N m (kg-m, ft-lb)

: N m (kg-m, in-lb)

: Always replace after every disassembly.

WGIA0096E


1. Reservoir tank
2. Suction hose
3. High pressure hose
4. Oil cooler
5. Steering gear assembly
6. Reservoir tank bracket
7. Eye bolt

Installation is in the reverse order of removal.

HYDRAULIC LINE


< REMOVAL AND INSTALLATION >

- Confirm mating marks are aligned with hose and clamp, then correct if needed.



SGIA0563E

- To install eye joint, align projection of eye joint with notch of power steering pump, and attach eye joint to power steering pump properly. Tighten eye bolt by hand fully, then torque to specification.



WGIA0089E

POWER STEERING OIL PUMP

< REMOVAL AND INSTALLATION >

POWER STEERING OIL PUMP

Removal and Installation

INFOID:0000000001534409

REMOVAL

1. Drain power steering fluid from reservoir tank.
2. Remove engine room cover. Refer to [EM-22, "Removal and Installation"](#) .
3. Remove air duct assembly. Refer to [EM-23, "Removal and Installation"](#) .
4. Remove power steering reservoir tank.
5. Remove serpentine drive belt belt from auto tensioner and power steering pump. Refer to [EM-12, "Removal and Installation"](#) .
6. Disconnect pressure sensor electrical connector.
7. Remove high pressure and low pressure piping from power steering oil pump. Refer to [ST-17](#) .
8. Remove mounting bolts, then remove power steering pump.

INSTALLATION

Installation is in the reverse order of removal. Refer to [ST-17](#) for tightening torque.

- After installation, bleed air. Refer to [ST-12, "Air Bleeding Hydraulic System"](#).

NOTE:

Belt tension is automatic and requires no adjustment.

A

B

C

D

E

F

ST

H

I

J

K

L

M

N

O

P


POWER STEERING GEAR AND LINKAGE

< REMOVAL AND INSTALLATION >

POWER STEERING GEAR AND LINKAGE

Removal and Installation

INFOID:0000000001534404




1. Cotter pin
2. Mounting bracket
3. Mounting insulator
4. Steering gear assembly
5. Washer

CAUTION:

Spiral cable may snap due to steering operation if steering column is separated from steering gear assembly. Therefore secure steering wheel to avoid turning.

REMOVAL

1. Turn wheels to the straight-ahead position.
2. Remove tires from vehicle using power tool.
3. Remove undercover using power tool.
4. On 4WD model, remove front final drive, then support drive shafts with wire. Refer to [DLN-207. "Removal and Installation"](#).
5. Make sure slit of lower joint fits with the projection on rear cover cap, while checking that mark on steering gear assembly aligns with mark on rear cover cap.



6. Remove cotter pin at steering outer socket and discard, then loosen nut.

POWER STEERING GEAR AND LINKAGE


< REMOVAL AND INSTALLATION >

7. Remove steering outer socket from steering knuckle using Tool. Be careful not to damage ball joint boot.

CAUTION:

Temporarily tighten mounting nut to prevent damage to threads and to prevent Tool from coming off.

Tool number : HT72520000 (J-25730-A)




SDIA1434E

A
B
C
D
E
F
ST
H

8. On 2WD model, remove stabilizer bar bracket bolts and reposition stabilizer bar. Refer to [FSU-14, "Removal and Installation"](#).


9. Disconnect oil piping (high pressure side and low pressure side) from steering gear assembly, then drain fluid from piping.



LGIA0032E


I
J
K
L
M
N
O
P

10. Remove lower joint bolt of lower joint shaft.



LGIA0029E

11. Remove nuts of steering gear assembly using power tool, then remove bolts and steering gear assembly.



LGIA0024E

P

INSTALLATION


Installation is in the reverse order of removal.

- After removing/installing or replacing steering components, check wheel alignment. Refer to [FSU-5, "Front Wheel Alignment"](#).
- After adjusting wheel alignment, adjust neutral position of steering angle sensor. Refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

POWER STEERING GEAR AND LINKAGE

< REMOVAL AND INSTALLATION >

- With steering wheel in straight ahead position, make sure slit of lower joint fits with the projection on rear cover cap, while checking that mark on steering gear assembly aligns with mark on rear cover cap. Insert the joint until surface "A" contacts surface "B".



- After installation, bleed the air from the steering hydraulic system. Refer to [ST-12. "Air Bleeding Hydraulic System"](#).

INSPECTION AFTER INSTALLATION

Check if steering wheel turns smoothly when it is turned several times fully to the left and right lock positions.


STEERING COLUMN

< REMOVAL AND INSTALLATION >

STEERING COLUMN

Removal and Installation

INFOID:0000000001534400




- | | | |
|----------------------------------------|-----------------------------|------------------------------|
| 1. Driver air bag module | 2. Steering wheel | 3. Steering wheel side cover |
| 4. Combination switch and spiral cable | 5. Steering column assembly | 6. Collar |
| 7. Hole cover seal | 8. Clamp | 9. Hole cover mounting plate |
| 10. Hole cover | 11. Upper joint | 12. Upper shaft |
| 13. Boot clamp | 14. Lower joint shaft | 15. Boot and clips (plastic) |

CAUTION:

- Care must be taken not to give axial impact to steering column assembly during removal and installation.
- Care must be taken not to move steering gear during removal of steering column assembly.

REMOVAL


- Remove the combination switch and spiral cable from steering column assembly with combination switches attached. Refer to [SR-6, "Removal and Installation"](#).
- Remove tilt lever knob from tilt lever by inserting a suitable tool into slot of tilt lever knob, then depress tab and withdraw tilt lever knob.




STEERING COLUMN

< REMOVAL AND INSTALLATION >


3. Remove lower instrument panel LH. Refer to [IP-13, "Removal and Installation"](#).
4. Remove steering column cover and ignition key finisher. Refer to "Removal and Installation".
5. Remove knee protector screws, then knee protector.




6. Remove lock nut and bolt, then separate upper joint from upper shaft.



7. Remove the steering column assembly nuts and bolts, then remove steering column assembly from steering member.



8. Remove hole cover seal and clamp.
9. Remove nuts and hole cover mounting plate and hole cover from dash panel.
10. Raise vehicle, then remove lower joint shaft bolt and remove lower joint shaft and upper shaft from vehicle.
 - During lower joint detachment, insert a tool into the yoke groove to prevent gouging damage.



INSPECTION AFTER REMOVAL

- Check for damage to steering column assembly jacket tube. If damage is found, replace steering column assembly with new one.

STEERING COLUMN


< REMOVAL AND INSTALLATION >

- If vehicle has been in a collision, check column length "L1" or "L2" as shown. If out of specification, replace steering column assembly with a new one.

Column length

L1 : 158 mm (6.22 in)

L2 : 262 mm (10.31 in)



SGIA0475E

- Check for proper lubrication, apply multi-purpose grease as necessary to external joints and levers. Refer to [MA-10, "Fluids and Lubricants"](#).

INSTALLATION

Installation is in the reverse order of removal.


CAUTION:

When installing the steering column, finger-tighten all of the lower bracket and joint bolts; then tighten them to specification. Do not apply undue stress to the steering column.

NOTE:

Align slit of the coupling joint with projection on dust cover. Insert the joint until surface "A" contacts surface "B".

- After installation, turn steering wheel to make sure it moves smoothly. Make sure the number of turns are the same from the straight-forward position to left and right locks. Make sure that the steering wheel is in a neutral position when driving straight ahead.
- When installing steering column to steering member, install nut from front side of vehicle.
- The lower nut on the upper joint may not be reused.




SST491C

INSPECTION AFTER INSTALLATION

- After installing steering column to vehicle, check tilt device operation range is within specification.

Range "A" : 61.3 mm (2.41 in)

- Check if steering wheel operation can turn to the end of the left and right stops smoothly.



WGIA0083E

STEERING WHEEL

< REMOVAL AND INSTALLATION >

STEERING WHEEL

Removal and Installation

INFOID:0000000001534399

REMOVAL


1. Set the front wheels in the straight-ahead position.
2. Remove the driver air bag module. Refer to [SR-4, "Removal and Installation"](#) .
3. Disconnect steering wheel switches.
4. Remove the steering wheel center nut.
5. Remove the steering wheel using Tools.

Tool number A: KV481J0010 (J-1859-A)
 B: KV481J0020 (J-42578)

CAUTION:

Place a piece of tape across the spiral cable so it will not be rotated out of position.

6. Inspect the steering wheel near the puller holes for damage. If damaged, replace the steering wheel.
 - Remove steering wheel rear cover and steering wheel switches, if required.




WHIA0124E

INSTALLATION

Installation is in the reverse order of removal.


- Align spiral cable correctly when installing steering wheel. Make sure that the spiral cable is in the neutral position. The neutral position is detected by turning left 2.6 revolutions from the right end position and ending with the knob at the top.
- If equipped with VDC, refer to [BRC-8, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#) for steering angle sensor adjustment.
- After the work is completed, perform self-diagnosis to make sure no malfunction is detected. Refer to [SRC-5, "Trouble Diagnosis with CONSULT-III"](#) .
- Tighten steering wheel center nut to specification. Refer to "Removal and Installation".



WGIA0038E

CAUTION:

- The spiral cable may snap due to steering operation if the cable is not installed in the correct position.
- With the steering linkage disconnected, the cable may snap by turning the steering wheel beyond the limited number of turns. The spiral cable can be turned counterclockwise about 2.5 turns from the neutral position.



PHIA0275E

POWER STEERING OIL PUMP


< DISASSEMBLY AND ASSEMBLY >

DISASSEMBLY AND ASSEMBLY

POWER STEERING OIL PUMP

Disassembly and Assembly

INFOID:000000001534413



- | | | |
|------------------------|-------------------------------|-----------|
| 1. Bracket | 2. Spring washer | 3. Pulley |
| 4. Power steering pump | 5. High pressure hose bracket | 6. O-ring |
| 7. Suction pipe | ← Front | |

INSPECTION BEFORE DISASSEMBLY

Disassemble the power steering oil pump only if the following items are found.

- Deformed or damaged pulley, bracket, connector or suction pipe.
- Oil leakage from the suction pipe or connector.

DISASSEMBLY

NOTE:

Mount the power steering oil pump in a vise as needed.

1. Remove the connector bolt, connector and copper washers.

CAUTION:

Do not reuse the copper washers.

2. Remove the suction pipe and O-ring.

CAUTION:

Do not reuse the O-ring.

3. Remove the pulley nut and pulley.

4. Remove the bracket bolts and bracket.

INSPECTION AFTER DISASSEMBLY

Body Assembly Inspection

Check the power steering oil pump body assembly for damage. If any damage is found, replace with a new power steering oil pump assembly.

ASSEMBLY

Assembly is in the reverse order of disassembly.

CAUTION:

- **Do not reuse the copper gaskets**
- **Do not reuse the O-ring. Apply a coat of Genuine Nissan PSF or equivalent to the O-ring.**


POWER STEERING GEAR AND LINKAGE

< DISASSEMBLY AND ASSEMBLY >

POWER STEERING GEAR AND LINKAGE

Disassembly and Assembly

INFOID:0000000001534407



- | | | |
|--------------------------|-----------------|-------------------|
| 1. Boot clamp | 2. Inner socket | 3. Boot |
| 4. Boot clamp | 5. Outer socket | 6. Cylinder tubes |
| 7. Gear housing assembly | 8. Connector | |

CAUTION:

- Secure steering gear assembly with a vise, using copper plates or something similar to prevent it from being damaged. Do not grip cylinder with a vise.
- Before performing disassembly, clean steering gear assembly with kerosene. Be careful not to bring any kerosene into contact with the discharge and return port connectors.

DISASSEMBLY

- Remove cylinder tubes from gear housing assembly.
- Loosen lock nuts of outer sockets, and remove outer sockets.
- Remove boot clamps of the small diameter side and the large diameter side, then remove boot.

CAUTION:

When removing boots, be careful not to damage inner socket and gear housing assembly. If they are damaged, change them to avoid oil leaks.

- Remove inner sockets.

INSPECTION AFTER DISASSEMBLY

Boot

Check boot for tears, cracks and deformation. Replace if necessary.

POWER STEERING GEAR AND LINKAGE

< DISASSEMBLY AND ASSEMBLY >

Gear Housing Assembly


Check gear housing assembly for dents, cracks or damage. Replace as an assembly if necessary.

Outer Socket and Inner Socket

SWING TORQUE

- Measure the swing torque, using Tool. When ball stud and inner socket start moving the measured value must be within the specification. If the reading is outside the specification, replace the socket.

Tool number : — (J-44372)




Item	Outer socket	Inner socket
Measuring point	Cotter pin hole of stud	Shown as L: 83.2 mm (3.276 in)
Swing torque	0.3 – 2.9 N·m (0.03 – 0.29 kg-m, 3 – 25 in-lb)	1.0 – 7.8 N·m (0.11 – 0.79 kg-m, 9 – 69 in-lb)
Measuring value (F)	4.84 – 46.7 N (0.50 – 4.7 kg-f, 4 - 34 lb-f)	12.1 – 93.7 N (1.3 – 9.5 kg, 9 – 69 lb)

ROTATING TORQUE

- Measure the rotating torque, using Tool. If the value is outside the specification, replace the outer sockets.

Tool number : ST3127S000 (J-25765-A)

Rotating torque : 0.3 – 2.9 N·m (0.03 – 0.29 kg-m, 3 – 25 in-lb)




AXIAL END PLAY

- Apply a load of 490 N (50 kg-f, 110 lb-f) to the ball stud axially. Use a dial gauge to measure the amount of the movement that the stud makes. If the value is outside the specification, replace the sockets.

Outer socket : 0.5 mm (0.020 in) or less

Inner socket : 0.2 mm (0.008 in) or less




ASSEMBLY

- Install the inner sockets.

POWER STEERING GEAR AND LINKAGE

< DISASSEMBLY AND ASSEMBLY >


2. Install the large-diameter side of the boots to the gear housing assembly.
3. Install the small-diameter side of the boots to the groove of the inner sockets.



4. Install the boot clamps to the boots, as shown.

CAUTION:


Do not reuse the large-diameter boot clamps.



5. Crimp the large-diameter boot clamps, using Tool.


Tool number : KV40107300 (—)

6. Install the cylinder tubes to the gear housing assembly.
7. Install the lock nuts and outer sockets to the inner sockets.



8. Thread the outer sockets onto the inner sockets to the specified length "L", then tighten the lock nuts to the specification. Refer to "Disassembly and Assembly". Reconfirm that the tie-rod length "L" is within specification.

Maximum inner socket length "L" : 115.2 mm (4.54 in)




STEERING COLUMN

< DISASSEMBLY AND ASSEMBLY >

STEERING COLUMN

Disassembly and Assembly

INFOID:0000000001534403



- | | | |
|-----------------------------|--------------------|---------------------|
| 1. Steering column assembly | 2. Ignition switch | 3. Upper joint |
| 4. Spring | 5. Tilt lever knob | 6. Self-shear screw |


DISASSEMBLY

1. Remove spring from steering column assembly and tilt lever.
2. Remove bolt from upper joint, then remove upper joint from steering column assembly.
3. Remove ignition switch tamper resistant self-shear type screws with a drill or other appropriate tool.

ASSEMBLY

Assembly is in the reverse order of disassembly.

- Install new tamper resistant self-shear type screws.



INSPECTION AFTER ASSEMBLY


When the steering wheel does not turn smoothly, check the steering column as follows:

STEERING COLUMN

< DISASSEMBLY AND ASSEMBLY >

1. Check the column bearings for damage or unevenness. Replace the steering column as an assembly, if necessary.
2. Check the column tube for deformation or breakage. Replace the steering column as an assembly, if necessary.
3. If the vehicle has been involved in a collision, or if noise and rattles are heard during a turn, check the length (L) of the column. If out of specification, replace the steering column as an assembly.


Steering column length (L) : 610 mm (24.02 in)



WGIA0080E

4. Check for proper lubrication of joints and levers, apply multi-purpose grease as necessary. Refer to [MA-10, "Fluids and Lubricants"](#).
5. Check for wear around the seal edges, replace steering column assembly as necessary.
6. Check for corrosion or pitting around the seal sliding area.
7. After installing the steering column, check the tilt mechanism for proper operation.

Tilt mechanism range : 3° per notch at 5 steps



WGIA0026E

CAUTION:

- Do not exert any load or impact in the axial direction immediately before or after column removal.
- After installation, check for smooth steering wheel rotation, without any catches or noise.
- Replace the column if it is depleted of grease, worn, damaged, or if any scratches or coating separation is present on the shaft seal area causing grease to leak out of sealed steering column assembly.

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Steering Wheel


INFOID:000000001534391

End play of the axle direction for steering wheel	0 mm (0 in)
Steering wheel play on the outer circumference	0 – 35 mm (0 – 1.38 in)

Steering Column


INFOID:000000001534392

Unit: mm (in)




WGIA0080E

Steering column assembly length "L"	610 (24.02)
-------------------------------------	-------------



SGIA0475E

Steering column length "L1"	158 (6.22)
Steering column length "L2"	262 (10.31)



WGIA0083E

Tilt range "A"	61.3 (2.41)
Tilt mechanism range	3° per notch at 5 steps


SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

Steering Outer Socket and Inner Socket

INFOID:0000000001534393

Steering gear type	PR26AM
--------------------	--------




SGIA0547E

Tie-rod ball joint outer socket	Swinging torque	0.3 – 2.9 N·m (0.03 – 0.29 kg-m, 3 – 25 in-lb)
	Measurement on spring balance • Measuring point: cotter pin hole of stud	4.84 – 46.7 N (0.50 – 4.7 kg-f, 4 – 34 lb-f)
	Rotating torque	0.3 – 2.9 N·m (0.03 – 0.29 kg-m, 3 – 25 in-lb)
	Axial end play	0.5 mm (0.020 in) or less
Tie-rod ball joint inner socket	Swinging torque	1.0 – 7.8 N·m (0.11 – 0.79 kg-m, 9 – 69 in-lb)
	Measurement on spring balance • Measuring point: L mark see above, L=83.2 mm (3.276 in).	12.1 – 93.7 N (1.3 – 9.5 kg-f, 9 – 69 lb-f)
	Axial end play	0.2 mm (0.008 in) or less

Tie-rod

INFOID:0000000001534394



SGIA0167E

Tie-rod maximum length "L"	115.2 mm (4.54 in)
----------------------------	--------------------


SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

Steering Gear

INFOID:000000001534395

Steering gear model	PR26AM
---------------------	--------



STC0034D

Rack neutral position, dimension "L" (rack stroke)	85.5 mm (3.36 in)		
Rack sliding force	At the neutral point: Range within ± 11.5 mm (± 0.453 in) from the neutral position (in power ON)	Area average value	147 – 211 N (14.99 – 21.52 kg, 33.1 – 47.52 lb)
		Allowable variation	98 N (10 kg-f, 22 lb-f) or less
	Whole area (in power OFF)	Peak value	294 N (30.0 kg-f, 66 lb-f) or less
		Allowable variation	147 N (16 kg-f, 35 lb-f) or less

Oil Pump

INFOID:000000001534396

Oil pump relief oil pressure	9.0 – 9.8 mPa (91.77 – 99.93 kg/cm ² , 1305.34 – 1421.37 psi)
------------------------------	--------------------------------------------------------------------------

Steering Fluid

INFOID:000000001534397

Fluid capacity	Approx. 1.0 ℥ (2 1/8 US pt, 1 3/4 Imp pt)
----------------	-------------------------------------------