

PROPELLER SHAFT & DIFFERENTIAL CARRIER

SECTION PD

CONTENTS

PREPARATION	2
Special Service Tools	2

Propeller shaft

PROPELLER SHAFT	7
On-vehicle Service.....	9
Removal and Installation	9
Inspection.....	9
Disassembly.....	10
Assembly	11

Final drive

ON-VEHICLE SERVICE	13
Front Oil Seal Replacement (Front final drive)	13
Front Oil Seal Replacement (Rear final drive: Model H233B).....	13
Rear Cover Gasket Replacement (Rear final drive: Model C200)	14

REMOVAL AND INSTALLATION (Front final drive)	15
---	----

REMOVAL AND INSTALLATION (Rear final drive)	16
--	----

R180A

FRONT FINAL DRIVE	17
DISASSEMBLY	18
Pre-inspection	18
Final Drive Housing	18
Differential Case	20
Extension Tube and Differential Side Shaft	21
INSPECTION	23
Ring Gear and Drive Pinion	23
Differential Case Assembly.....	23
Bearing.....	23
ADJUSTMENT	24

Side Bearing Preload.....	24
Pinion Gear Height and Pinion Bearing Preload.....	25
Pinion Bearing Preload Washer Selection.....	26
Pinion Height Adjusting Washer Selection.....	27
Tooth Contact.....	29
ASSEMBLY	30
Extension Tube and Differential Side Shaft	30
Differential Case	30
Final Drive Housing	31

H190A

REAR FINAL DRIVE	35
DISASSEMBLY	36
Pre-inspection	36
Differential Carrier.....	36
Differential Case	38
INSPECTION	40
Ring Gear and Drive Pinion	40
Differential Case Assembly.....	40
Bearing.....	40
LIMITED SLIP DIFFERENTIAL	41
Preparation for Disassembly	41
Checking Differential Torque.....	41
Disassembly.....	42
Inspection.....	42
Contact Surfaces.....	42
Disc And Plate.....	42
Assembly	43
ADJUSTMENT	46
Side Bearing Preload.....	46
Pinion Gear Height	47
Pinion Height Adjusting Washer Selection.....	49
Tooth Contact.....	51
ASSEMBLY	52
Differential Case	52
Differential Carrier.....	53

CONTENTS (Cont'd.)

	C200		
REAR FINAL DRIVE			57
DISASSEMBLY			58
Pre-inspection			58
Differential Carrier			58
Differential Case			60
INSPECTION			62
Ring Gear and Drive Pinion			62
Differential Case Assembly			62
Bearing			62
LIMITED SLIP DIFFERENTIAL			63
Preparation for Disassembly			63
Checking Differential Torque			63
Disassembly			63
Inspection			64
Contact Surfaces			64
Disc And Plate			64
Adjustment			65
Friction Disc And Friction Plate End Play			65
Assembly			67
ADJUSTMENT			69
Side Bearing Preload			69
Pinion Gear Height			70
Pinion Height Adjusting Washer			
Selection			72
Tooth Contact			74
ASSEMBLY			75
Differential Case			75
Differential Carrier			76

	H233B		
REAR FINAL DRIVE			80
DISASSEMBLY			81
Pre-inspection			81







Differential Carrier		81
Differential Case		83
INSPECTION		85
Ring Gear and Drive Pinion		85
Differential Case Assembly		85
Bearing		85
LIMITED SLIP DIFFERENTIAL		86
Preparation for Disassembly		86
Checking Differential Torque		86
Disassembly		86
Inspection		87
Contact Surfaces		87
Disc And Plate		87
Adjustment		88
Friction Disc And Friction Plate End Play		88
Assembly		89
ADJUSTMENT		92
Pinion Gear Height		92
Pinion Height Adjusting Washer Selection		93
Tooth Contact		95
ASSEMBLY		96
Differential Case		96
Differential Carrier		97
SERVICE DATA AND SPECIFICATIONS (SDS)		100
Propeller Shaft		100
General Specifications		100
Service Data		101
Final Drive		102
General Specifications		102
Inspection And Adjustment (R180A)		103
Inspection And Adjustment (H190A)		104
Inspection And Adjustment (C200)		105
Inspection And Adjustment (H233B)		106

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PREPARATION







Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	Unit application			
		R180A	H190A	C200	H233B
ST3127S000 (See J25765-A) Preload gauge ① GG91030000 (J25765) Torque wrench ② HT62940000 (—) Socket adapter ③ HT62900000 (—) Socket adapter	 <p>Measuring pinion bearing preload and total preload</p> <p>NT124</p>	X	X	X	X
KV38100800 (J25604-01), (J34310) Differential attachment	 <p>Mounting final drive (To use, make a new hole.)</p> <p>NT119</p> <p>a: 152 mm (5.98 in)</p>	X	—	—	—
ST06310000 (J25602-01) Differential attachment	 <p>Mounting final drive</p> <p>NT140</p>	—	X	—	—
ST06340000 (J24310) Differential attachment	 <p>Mounting final drive</p> <p>NT140</p>	—	—	—	X
ST32580000 (J34312) Differential side bearing adjusting nut wrench	 <p>Adjusting side bearing pre- load and backlash (ring gear- drive pinion)</p> <p>NT141</p>	—	—	—	X
ST33290001 (J25810-A) Side bearing outer race puller	 <p>Removing side bearing outer race and side oil seal</p> <p>NT076</p>	X	—	—	—
ST38060002 (J34311) Drive pinion flange wrench	 <p>Removing and installing propeller shaft lock nut and drive pinion lock nut</p> <p>NT113</p>	X	X	X	—

PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Unit application				
		R180A	H190A	C200	H233B	
KV38104700 (J34311) Drive pinion flange wrench	 NT113	Removing and installing pro- peller shaft lock nut, and drive pinion lock nut	—	—	—	X
ST3090S000 (—) Drive pinion rear inner race puller set ① ST30031000 (J22912-01) Puller ② ST30901000 (J26010-01) Base	 NT527	Removing and installing drive pinion rear inner cone	X	X	X	X
ST3306S001 Differential side bearing puller set ① ST33051001 (J22888-20) Body ② ST33061000 (J8107-2) Adapter	 NT072	Removing and installing dif- ferential side bearing inner cone	X	X	X	X
ST33230000 (J25805-01) Differential side bearing drift	 NT085	Installing side bearing inner cone	X	X	X	—
ST33190000 (J25523) Differential side bearing drift	 NT085	Installing side bearing inner cone	—	—	—	X
ST33081000 (—) Side bearing puller adapter	 NT431	Installing side bearing inner cone	—	—	X	X

CI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT








HA

EL

IDX






PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Unit application				
		R180A	H190A	C200	H233B	
KV38100600 (J25267) Side bearing spacer drift	 <p>NT528</p> <p>a: 8 mm (0.31 in) b: R42.5 mm (1.673 in)</p>	Installing side bearing spacer	—	—	X	—
ST30611000 (J25742-1) Drift	 <p>NT090</p>	Installing pinion rear bearing outer race	X	X	X	X
ST30621000 (J25742-5) Drift	 <p>NT073</p> <p>a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.</p>	Installing pinion rear bearing outer race	X	X	X	X
ST30701000 (J25742-2) Drift	 <p>NT073</p> <p>a: 61.5 mm (2.421 in) dia. b: 41 mm (1.61 in) dia.</p>	Installing pinion front bearing outer race	X	—	—	—
ST30613000 (J25742-3) Drift	 <p>NT073</p> <p>a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.</p>	Installing pinion front bearing outer race	—	X	X	X
KV381025S0 (—) Oil seal fitting tool ① ST30720000 (J25405) Drift bar ② KV38102510 (—) Drift	 <p>NT525</p> <p>a: 77 mm (3.03 in) dia. b: 55 mm (2.17 in) dia. c: 71 mm (2.80 in) dia. d: 65 mm (2.56 in) dia.</p>	Installing front oil seal	X	X	—	X
KV38100500 (J25273) Gear carrier front oil seal drift	 <p>NT115</p> <p>a: 85 mm (3.35 in) dia. b: 60 mm (2.36 in) dia.</p>	Installing front oil seal	—	—	X	X

PREPARATION



Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Unit application				
		R180A	H190A	C200	H233B	
ST33720000 (J25817) Differential side retainer guide	 NT138	Installing side retainer	X	—	—	—
ST33270000 (J25809) Side oil seal drift	 NT526	Installing side oil seal	X	—	—	—
(J34309) Differential shim selector	 NT134	Adjusting bearing pre-load and gear height	X	X	X	X
(J25269-4) Side bearing discs (2 Req'd)	 NT136	Selecting pinion height adjusting washer	X	—	X	—
(J25269-18) Side bearing discs (2 Req'd)	 NT135	Selecting pinion height adjusting washer	—	X	—	X
(J8129) Spring gauge	 NT127	Measuring carrier turning torque	X	X	X	X
(J35764) Gear carrier side oil seal drift	 NT120	Installing side oil seal	X	—	—	—

GI
MA
EW
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	Unit application				
		R180A	H190A	C200	H233B	
KV381051S0 (—) Rear axle shaft dummy ① KV38105110 (—) Torque wrench side ② KV38105120 (—) Vice side	 NT142	Checking differential torque on limited slip differential	—	X	X	—
KV381052S0 (—) Rear axle shaft dummy ① KV38105210 (—) Torque wrench side ② KV38105220 (—) Vice side	 NT142	Checking differential torque on limited slip differential	—	—	—	X


PROPELLER SHAFT

Front propeller shaft (Model 2F71H)




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Rear propeller shaft (Model 2S80B)




PROPELLER SHAFT

Rear propeller shaft (Model 3S80B)




Rear propeller shaft (Model 3S71A)



PROPELLER SHAFT

GI



On-vehicle Service

PROPELLER SHAFT VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. Raise rear end of vehicle until wheels are clear of the ground.
2. Measure propeller shaft runout at several points along propeller shaft by rotating final drive companion flange using hands.
3. If runout exceeds specifications, disconnect propeller shaft at final drive companion flange. Rotate companion flange 180 degrees, then reconnect propeller shaft.

Runout limit: 0.6 mm (0.024 in)

4. Check runout again. If runout still exceeds the limit, replace propeller shaft assembly.
5. Perform road test.

MA

EM

LC

EC

FE

APPEARANCE CHECKING

- Inspect propeller shaft tube surface for dents or cracks and replace as necessary.
- Check center bearing for noise or damage and replace as necessary.

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX




Removal and Installation

1. Place matching marks on flanges, then separate propeller shaft from final drive.



2. Remove propeller shaft.


- **Insert plug into rear oil seal after removing rear propeller shaft.**



Inspection


- Inspect propeller shaft runout. If runout exceeds the limit, replace propeller shaft assembly.

Runout limit: 0.6 mm (0.024 in)



PROPELLER SHAFT


Inspection (Cont'd)




- Inspect journal axial play.
If play exceeds the limit, replace propeller shaft assembly.
Journal axial play:
0.02 mm (0.0008 in) or less

Disassembly


CENTER BEARING



1. Place matching marks on flanges, then separate 2nd tube from 1st tube.



2. Place matching marks on the flange and shaft.



3. Remove locking nut using Tool.

Tool numbers:


R180A, H190A, C200

ST38060002 (J34311)

H233B

KV38104700 (J34311)

4. Remove companion flange using puller.



5. Remove center bearing using Tool and press.
Tool number: ST30031000 (J22912-01)






PROPELLER SHAFT

Disassembly (Cont'd)

JOURNAL

NOTE:

1. Place matching marks on propeller shaft and flange or yoke.



2. Remove snap ring.

3. Remove pushed out journal bearing by lightly tapping yoke with a hammer, taking care not to damage journal and yoke hole.

4. Remove bearing at opposite side in above operation.
Put marks on disassembled parts so that they can be reinstalled in their original positions.

Assembly

CENTER BEARING

- When installing center bearing, position the "F" mark on center bearing toward front of vehicle.
- **Apply a coat of multi-purpose lithium grease containing molybdenum disulfide to the end face of the center bearing and both sides of the washer.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

PROPELLER SHAFT

Assembly (Cont'd)


- Stake the nut. Always use new one.
- Align match marks when assembling tubes.



JOURNAL


1. Assemble journal bearing. Apply recommended multi-purpose grease on bearing inner surface.

When assembling, be careful that needle bearing does not fall down.




2. Select snap ring that will provide specified play in axial direction of journal, and install them. Refer to SDS, PD-101.

Select snap rings with a difference in thickness at both sides within 0.06 mm (0.0024 in).



3. Adjust thrust clearance between bearing and snap ring to zero by tapping yoke.




4. Check to see that journal moves smoothly and check for axial play.

Axial play: 0.02 mm (0.0008 in) or less


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Front Oil Seal Replacement (Front final drive)


1. Remove front propeller shaft.
2. Loosen drive pinion nut.
Tool number: ST38060002 (J34311)



3. Remove companion flange using puller.




4. Remove front oil seal.



5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Press front oil seal into carrier.

**Tool number:
ST30720000 (J25405)**

6. Install companion flange and drive pinion nut.
7. Install propeller shaft.




Front Oil Seal Replacement (Rear final drive: Model H233B)


CAUTION:

For final drive models using collapsible spacer (H190A, C200), bearing preload must be adjusted whenever companion flange is removed. Therefore, final drive overhaul is required.


1. Remove propeller shaft.
2. Loosen drive pinion nut.
Tool number: KV38104700 (J34311)




**Front Oil Seal Replacement
(Rear final drive: Model H233B) (Cont'd)**



3. Remove companion flange.



4. Remove front oil seal.




5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Press front oil seal into carrier.




Tool number: KV38100500 (J25273)

6. Install companion flange and drive pinion nut.
7. Install rear propeller shaft.

**Rear Cover Gasket Replacement
(Rear final drive: Model C200)**



1. Drain gear oil.
2. Remove rear cover and rear cover gasket.
3. Install new rear cover gasket and rear cover.
4. Fill final drive with recommended gear oil.



Removal

1. Remove front propeller shaft.
2. Remove drive shaft. Refer to FA section ["Drive Shaft", "FRONT AXLE (4WD)"].
3. Remove engine mounting bolts and raise up engine.
4. Remove front final drive together with differential mounting member.

Installation

1. Install front final drive assembly together with differential mounting member.

2. Tighten front final drive securing bolts and nuts by following the procedure to prevent drive train vibration.

- a. Temporarily tighten nut (A).
- b. Temporarily tighten nut (B).
- c. Tighten bolt (C) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
- d. Tighten bolt (D) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
- e. Tighten nut (A) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
- f. Tighten nut (B) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
- g. Tighten nut (E) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).

3. Install drive shaft. Refer to FA section ["Drive Shaft", "FRONT AXLE (4WD)"].
4. Install front propeller shaft.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
FDX

Removal


- Remove propeller shaft.

Plug front end of transfer.

- Remove axle shaft.
Refer to RA section ("REAR AXLE").


CAUTION:

- Be careful not to damage spline, sleeve yoke and front oil seal when removing propeller shaft.
- Before removing the final drive assembly or rear axle assembly, disconnect the ABS sensor harness connector from the assembly and move it away from the final drive/rear axle assembly area. Failure to do so may result in the sensor wires being damaged and the sensor becoming inoperative.




Installation

- Fill final drive with recommended gear oil.



- Pay attention to the direction of gasket (H233B only).



Pre-inspection

Before disassembling final drive, perform the following inspection.


- Total preload
 - a. Turn drive pinion in both directions several times to set bearing rollers.
 - b. Check total preload with Tool.

Tool number: ST3127S000 (J25765-A)

Total preload:

1.2 - 2.3 N·m


(12 - 23 kg·cm, 10 - 20 in·lb)




- Ring gear-to-drive pinion backlash
Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)



- Ring gear runout
Check runout of ring gear with a dial indicator.
Runout limit:
0.05 mm (0.0020 in)
- Tooth contact
Check tooth contact. Refer to "ADJUSTMENT", PD-29.




Final Drive Housing

1. Using three spacers [20 mm (0.79 in)], mount final drive assembly on Tool.


Tool number:

KV38100800 (J34310), (J25604-01)




2. Remove extension tube and differential side shaft assembly.


Final Drive Housing (Cont'd)




3. Remove differential side flange.



4. Mark side retainers for identification. Remove side retainers. **Be careful not to confuse right and left side retainers and shims.**



5. Extract differential case from final drive housing.




6. Remove side outer races.

Tool number: ST33290001 (J25810-A)

Keep the side bearing outer races together with their respective inner cones — do not mix them up.

7. Remove side oil seal.



8. Loosen drive pinion nut.

Tool number: ST38060002 (J34311)

9. Remove companion flange with puller.

GL

WA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA


EL

IDX


Final Drive Housing (Cont'd)



10. Take out drive pinion together with pinion rear bearing inner cone, drive pinion bearing spacer and pinion bearing adjusting washer.
11. Remove front oil seal and pinion front bearing inner cone.




12. Remove pinion front and rear bearing outer races with brass drift.



13. Remove pinion rear bearing inner cone and drive pinion adjusting washer.
Tool number: ST30031000 (J22912-01)



Differential Case




1. Remove side bearing inner cones.
To prevent damage to bearing, engage puller jaws in grooves.
Tool numbers:
(A) ST33051001 (J22888-20)
(B) ST33061000 (J8107-2)

Differential Case (Cont'd)


Be careful not to confuse the right and left hand parts.



2. Loosen ring gear bolts in a criss-cross fashion.
3. Tap ring gear off differential case with a soft hammer.
Tap evenly all around to keep ring gear from binding.




4. Separate differential case LH and RH.
Put match marks on both differential case LH and RH sides prior to separating them.



Extension Tube and Differential Side Shaft

1. Remove differential side shaft assembly from extension tube.



2. Cut rear axle bearing collar with cold chisel. Be careful not to damage differential side shaft.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX

**Extension Tube and Differential Side Shaft
(Cont'd)**

3. Reinstall differential side shaft into extension tube and secure with bolts. Remove rear axle bearing by drawing out differential side shaft from rear axle bearing with puller.



4. Remove grease seal.

Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping.
If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).

CI

WA

EM

LC

EC

FE

CL

WT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX



Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft and thrust washers.



Bearing

1. Thoroughly clean bearing.
2. Check bearing for wear, scratches, pitting or flaking.
Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



For quiet and reliable final drive operation, the following five adjustments must be made correctly:

1. Side bearing preload
2. Pinion gear height
3. Pinion bearing preload
4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-33.
5. Ring and pinion gear tooth contact pattern.


Side Bearing Preload

A selection of carrier side retainer adjusting shims is required for successful completion of this procedure.

1. Make sure all parts are clean. Also make sure the bearings are well lubricated with light oil or type "DEXRON™" automatic transmission fluid.
2. Install differential carrier and side bearing assembly into the final drive housing.




3. Place all of the original side retainer adjusting shims onto the side bearing retainer that goes at the ring gear end of the carrier.



4. Install both bearing retainers onto the final drive housing and torque the retainer bolts.

Bolt torque specification:

☛: 9 - 12 N·m (0.9 - 1.2 kg·m, 78 - 104 in·lb)



5. Turn the carrier several times to seat the bearings.
6. Measure the carrier turning torque with a spring gauge, J8129, at the ring gear retainer bolt.

Turning torque specification:

34.3 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb)

of pulling force at the ring gear bolt

Side Bearing Preload (Cont'd)

7. If the turning torque measured is incorrect, establish the correct bearing preload by adding to or subtracting from the total amount of shim thickness.
 - Increase shim thickness to decrease turning torque on the carrier.
 - Decrease shim thickness to increase turning torque on the carrier.

GI
MA
EM

LC

EG


8. Record the correct, selected total thickness of the side retainer adjusting shims, and remove the carrier and bearings from the final drive housing. Save all shims for later re-use.

FE


CL

MT

AT



SPD195A



SPD769


Pinion Gear Height and Pinion Bearing Preload

1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the pinion gear bearings into the pinion pre-load shim selector tool, J34309.
 - **Front Pinion Bearing** — make sure the J34309-3 front pinion bearing seat is secured tightly against the J34309-2 gauge anvil. Then turn the front pinion bearing pilot, J34309-7, to secure the bearing in its proper position.

TF

PD

FA



SPD196A


- **Rear Pinion Bearing** — the rear pinion bearing pilot, J34309-8, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4, is used to lock the bearing to the assembly.

RA

BR

ST

RS



SPD197A


BT

HA


EL

IDX


Pinion Gear Height and Pinion Bearing Preload (Cont'd)




- Place the pinion preload shim selector tool gauge screw, J34309-1, with the pinion rear bearing inner cone installed, into the final drive housing.



- Install the J34309-2 gauge anvil with the front pinion bearing into the final drive housing and assemble it to the J34309-1 gauge screw. Make sure that the J34309-16 gauge plate will turn a full 360 degrees, and tighten the two sections by hand.



- Turn the assembly several times to seat the bearings.



- Measure the turning torque at the end of the J34309-2 shaft using Tool.

Tool number: ST3127S000 (J25765-A)

Turning torque specification:


0.6 - 1.0 N-m (6 - 10 kg-cm, 5.2 - 8.7 in-lb)

- Place the J34309-10 "R180A" pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:


Make sure all machined surfaces are clean.

PINION BEARING PRELOAD WASHER SELECTION



- Place the solid pinion bearing adjusting spacer squarely into the recessed portion of the J34309-2 gauge anvil.

Pinion Gear Height and Pinion Bearing Preload (Cont'd)




9. Select the correct thickness of pinion bearing preload adjusting washer using a standard gauge of 6 mm (0.24 in) and J34309-101 feeler gauge. The exact total measure you get with the gauges is the thickness of the adjusting washer required. Select the correct washer.

Drive pinion bearing adjusting washer:

Refer to SDS, PD-103.

10. Set the selected pinion bearing preload adjusting washer aside for use when assembling the pinion and bearings into the final drive housing.


PINION HEIGHT ADJUSTING WASHER SELECTION




11. Place the J34309-10 pinion height adapter onto the gauge plate and tighten by hand.

CAUTION:


Make sure all machined surfaces are clean.



12. Position firmly the side bearing discs, J25269-4, and arbor into the side bearing bores.



13. Select the correct standard pinion height adjusting washer thickness using a standard gauge of 3 mm (0.12 in) and J34309-101 feeler gauge. Measure the distance between the J34309-10 "R180A" pinion height adapter and the arbor.



14. Write down your exact total measurement.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Pinion Gear Height and Pinion Bearing Preload (Cont'd)




15. Correct the pinion height washer size by referring to the “pinion head number”.

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set and should be the same as the number on the ring gear. The second number is the “pinion head height number”, and it refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.

Pinion Head Height Number	Add or Remove from the Standard Pinion Height Washer Thickness Measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

16. Select the correct pinion height washer.

**Drive pinion height adjusting washer:
Refer to SDS, PD-103.**





17. Remove the J34309 pinion preload shim selector tool from the final drive housing and disassemble to retrieve the pinion bearings.

Tooth Contact


Gear tooth contact pattern check is necessary to verify correct relationship between ring gear and drive pinion. Hypoid gear sets which are not positioned properly may be noisy, or have short life, or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.

CI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX




1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.
3. Hold companion flange steady and rotate the ring gear in both directions.

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.




SPD007




Extension Tube and Differential Side Shaft


1. Measure rear axle bearing end play.
Rear axle bearing end play (A - B):
0.1 mm (0.0039 in) or less
 The end play can be adjusted with bearing adjusting shim.
Available bearing adjusting shims:
Refer to SDS, PD-103.



2. Install grease seal.
Tool number: (J35764)







3. Install extension tube retainer, rear axle bearing and rear axle shaft bearing collar on differential side shaft.
4. Install differential side shaft assembly into extension tube.



Differential Case

1. Measure clearance between side gear thrust washer and differential case.
Clearance between side gear thrust washer and differential case (A - B):
Less than 0.15 mm (0.0059 in)
 The clearance can be adjusted with side gear thrust washer.
Available side gear thrust washers:
Refer to SDS, PD-103.
2. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.

Differential Case (Cont'd)



3. Install differential case LH and RH.

4. Place differential case on ring gear.

5. Apply locking agent [Locktite (stud lock) or equivalent] to ring gear bolts, and install them.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

6. Press-fit side bearing inner cones on differential case with Tools.

Tool numbers:

(A) ST33230000 (J25805-01)

(B) ST33061000 (J8107-2)

Final Drive Housing

1. Press-fit front and rear bearing outer races with Tools.

Tool numbers:

(A) ST30611000 (J25742-1)

(B) ST30621000 (J25742-5)

(C) ST30701000 (J25742-2)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

Final Drive Housing (Cont'd)




2. Select pinion bearing adjusting washer and drive pinion bearing spacer. Refer to "ADJUSTMENT", PD-25.
3. Install drive pinion height adjusting washer in drive pinion, and press-fit pinion rear bearing inner cone in it, using press and Tool.

Tool number: ST30901000 (J26010-01)




4. Place pinion front bearing inner cone in final drive housing.
5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.


Tool number: ST30720000 (J25405)



6. Place drive pinion bearing spacer, pinion bearing adjusting washer and drive pinion in final drive housing.




7. Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.



8. Tighten pinion nut to the specified torque. **The threaded portion of drive pinion and pinion nut should be free from oil or grease.**

Tool number: ST38060002 (J34311)

Final Drive Housing (Cont'd)



9. Turn drive pinion in both directions several revolutions and measure pinion bearing preload.

Tool number: ST3127S000 (J25765-A)

Pinion bearing preload:

1.1 - 1.7 N·m (11 - 17 kg-cm, 9.5 - 14.8 in-lb)

When pinion bearing preload is outside the specifications, replace pinion bearing adjusting washer and spacer with a different thickness.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



10. Select side retainer adjusting shim.


Refer to "ADJUSTMENT", PD-24.

11. Press-fit side bearing outer race into side retainer.

Tool numbers:

(A) ST30611000 (J25742-1)

(B) ST30621000 (J25742-5)




12. Install side oil seal to side retainer.

Tool number: ST33270000 (J25809)


13. Install differential case assembly.

14. Place side retainer adjusting shims (refer to "ADJUSTMENT", PD-24), and O-ring on side retainer, and install them in final drive housing.

Tool number: ST33720000 (J25817)



- Align arrows stamped on side retainer and final drive housing.



15. Measure ring gear-to-drive pinion backlash with a dial indicator.

Ring gear-to-drive pinion backlash:


0.13 - 0.18 mm (0.0051 - 0.0071 in)

- If backlash is too small, decrease thickness of right shim and increase thickness of left shim by the same amount.

If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.

Final Drive Housing (Cont'd)



16. Check total preload with Tool.


When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number: ST3127S000 (J25765-A)

Total preload:

1.2 - 2.3 N-m


(12 - 23 kg-cm, 10 - 20 in-lb)



- If preload is too great, add the same amount of shim to each side.
- If preload is too small, remove the same amount of shim from each side.

Never add or remove a different number of shims for each side as it will change ring gear-to-drive pinion backlash.

17. Recheck ring gear-to-drive pinion backlash because increase or decrease in thickness of shims will cause change of ring gear to pinion backlash.



18. Check runout of ring gear with a dial indicator.


Runout limit:

0.05 mm (0.0020 in)

- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
- If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.

19. Check tooth contact. Refer to "ADJUSTMENT", PD-29.


20. Install rear cover and gasket.



21. Install extension tube and differential side shaft assembly.

REAR FINAL DRIVE

H190A



□ : N · m (kg-m, ft-lb)
 ☆ : Adjustment is required
 ★ : Using locking agent [Locktite (stud lock) or equivalent]


SEC. 380

PD-35

APD006

675

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Pre-inspection

Before disassembling final drive, perform the following inspection.


- Total preload
 - a. Turn drive pinion in both directions several revolutions to seat bearing rollers correctly.
 - b. Check total preload with Tool.

Tool number: ST3127S000 (J25765-A)

Total preload:

1.2 - 2.2 N-m


(12 - 22 kg-cm, 10 - 19 in-lb)



- Ring gear-to-drive pinion backlash
Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:


0.13 - 0.18 mm (0.0051 - 0.0071 in)



- Ring gear runout
Check runout of ring gear with a dial indicator.

Runout limit:


0.08 mm (0.0031 in)



- Tooth contact
Check tooth contact. Refer to "ADJUSTMENT", PD-51.
- Side gear-to-pinion mate gear backlash
Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:

Less than 0.15 mm (0.0059 in)



Differential Carrier


1. Mount differential carrier on Tools.

Tool numbers:

(A) ST0501S000 (—)


(B) ST06310000 (J25602-01)

Differential Carrier (Cont'd)




2. Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.


Bearing caps are line-bored during manufacture and should be put back in their original places.




3. Remove side bearing caps.



4. Remove differential case assembly with a pry bar.



Keep the side bearing outer races together with their respective inner cones — do not mix them up.



5. Remove drive pinion nut with Tool.
Tool number: ST38060002 (J34311)
6. Remove companion flange with puller.

GI

MA

EM

LC

EC

FE

CL

MT

AT

YF

PD

FA

RA

BR

ST

RS


BT

HA


EL

IDX


Differential Carrier (Cont'd)




7. Remove drive pinion with soft hammer.
8. Remove oil seal.



9. Remove pinion bearing outer races with a brass drift.



10. Pull out rear bearing inner cone with a press and Tool.
Tool number: ST30031000 (J22912-01)




Differential Case


1. Remove side bearing inner cones.
To prevent damage to bearing, engage puller jaws in groove.

Tool numbers:

- (A) ST33051001 (J22888-20)
- (B) ST33061000 (J8107-2)



Be careful not to confuse the left and right hand parts.

Differential Case (Cont'd)


2. Spread out lock straps and loosen ring gear bolts in a criss-cross fashion.
3. Tap ring gear off differential case with a soft hammer.
Tap evenly all around to keep ring gear from binding.

GI

MA

EM

LC



4. Drive out pinion mate shaft lock pin, with Tool from ring gear side.

Lock pin is calked at pin hole mouth on differential case.

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Ring Gear and Drive Pinion


Check gear teeth for scoring, cracking or chipping.
If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).



SPD239A

Differential Case Assembly


Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, and thrust washers.



SPD715


Bearing

1. Thoroughly clean bearing.
2. Check bearings for wear, scratches, pitting or flaking.
Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



CAUTION:

Do not run engine when only one wheel (rear) is off the ground.



Preparation for Disassembly

CHECKING DIFFERENTIAL TORQUE

Measure differential torque with Tools. If it is not within the specifications, inspect components of limited slip differential.

Differential torque:

New parts


69 - 118 N·m (7 - 12 kg-m, 51 - 87 ft-lb)

Used parts

39 - 74 N·m (4 - 7.5 kg-m, 29 - 54 ft-lb)


Tool number:

- Ⓐ KV38105110 (—)
- Ⓑ KV38105120 (—)



Disassembly

1. Remove couple screws.
2. Separate differential cases A and B. Draw out component parts (disc and plates etc.).




Inspection

CONTACT SURFACES

1. Clean the disassembled parts in suitable solvent and blow dry with compressed air.
2. If the following surfaces are found with burrs or scratches, smooth with oil stone.

- ① Differential case A
- ② Differential case B
- ③ Side gear
- ④ Pinion mate gear
- ⑤ Pinion mate shaft
- ⑥ Thrust block
- ⑦ Pressure ring



DISC AND PLATE

1. Clean the discs and plates in suitable solvent and blow dry with compressed air.
2. Inspect discs and plates for wear, nicks and burrs.
3. Check friction discs or plates for warpage.

**Maximum allowable warpage:
0.08 mm (0.0031 in)**


If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.

Inspection (Cont'd)

4. Measure frictional surfaces and projected portions of friction discs, plates, spring disc and plate. If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:


0.1 mm (0.004 in) or less




Assembly

Prior to assembling discs and plates, properly lubricate them with limited slip differential oil.


1. Alternately position specified number of friction plates and friction discs on rear of side gear.



2. Install spring disc.




3. Install spring plate.




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


Assembly (Cont'd)




4. Install side gear thrust washer to differential case A.



5. Install differential case A over side gear, discs and plates assembly.




6. Install pinion mate gears, pinion shaft and thrust block to differential case A.




7. Install side gear to pinion mate gears.
8. Install pressure ring to side gear.
9. Install each disc and plate.

Use same procedures as outlined in steps 1. through 3.



10. Install side gear thrust washer to differential case B.

Assembly (Cont'd)



11. Install differential case B.

Position differential cases B and A by correctly aligning marks stamped on cases.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX




12. Tighten differential case couple screws.



13. Check if there is a clearance between differential cases B and A.

If there is a clearance, use a thinner side gear thrust washer on both sides.

**Available side gear thrust washers:
Refer to SDS, PD-104.**



14. Check differential torque:

Differential torque:

New parts

69 - 118 N·m (7 - 12 kg-m, 51 - 87 ft-lb)

Used parts

39 - 74 N·m (4 - 7.5 kg-m, 29 - 54 ft-lb)

Tool numbers:

Ⓐ KV38105110 (—)

Ⓑ KV38105120 (—)

If greater than specification, use a thinner friction disc. If less than specification, use a thicker friction disc.

Available friction discs:


Refer to SDS, PD-104.

For quiet and reliable final drive operation, the following five adjustments must be made correctly:

1. Side bearing preload
2. Pinion gear height
3. Pinion bearing preload. Refer to "ASSEMBLY", PD-55.
4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-55.
5. Ring and pinion gear tooth contact pattern

Side Bearing Preload

A selection of carrier side bearing preload shims is required for successful completion of this procedure.




1. Make sure all parts are clean and that the bearings are well lubricated with light oil or type "DEXRON™" automatic transmission fluid.
2. Remove side bearing inner cones.


To prevent damage to bearing, engage puller jaws in grooves.

Tool numbers:

- (A) ST33051001 (J22888-20)
- (B) ST33061000 (J8107-2)




3. Reinstall all of the original side bearing adjusting shims on the carrier side, away from the ring gear.




4. Reinstall the carrier side bearing using Tools J25805-01 and J8107-2. Press on the bearings.

Side Bearing Preload (Cont'd)




5. Install carrier and bearings into the final drive housing. Install side bearing caps. Torque the bolts and tap on the caps with a soft hammer to seat the bearings.

Side bearing cap bolt torque specification:
 49 - 59 N·m (5 - 6 kg-m, 36 - 43 ft-lb)




6. After turning the carrier several times to seat the bearings, measure carrier turning force with spring gauge J8129.

Turning force specification:
 34.3 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb)
 of pulling force at the ring gear bolt




7. If necessary, correct the carrier bearing preload by adding to or subtracting from the total amount of shim thickness. Add shim thickness to increase turning force on the carrier. Subtract shim thickness to decrease turning force on the carrier.




Pinion Gear Height

1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the pinion gear bearings into the pinion pre-load shim selector Tool, J34309.




- **Front Pinion Bearing** — make sure the J34309-3 front pinion bearing is secured tightly against the J34309 gauge anvil. Then turn the front pinion bearing pilot J34309-5 to secure the bearing in its proper position.
- **Rear Pinion Bearing** — the rear pinion bearing pilot, J34309-15, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4 is used to lock the bearing to the assembly.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Pinion Gear Height (Cont'd)


- Place the pinion pre-load shim selector Tool J34309-1 gauge screw assembly with the pinion rear bearing inner cone installed into the final drive housing.



- Assemble the front pinion bearing inner cone and the J34309-2 gauge anvil together with the J34309-1 gauge screw in the final drive housing. Make sure that the pinion height gauge plate, J34309-16, will turn a full 360 degrees, and tighten the two sections together by hand.



- Turn the assembly several times to seat the bearings.




- Measure the turning torque at the end of the J34309-2 gauge anvil using Tool.

Tool number: ST3127S000 (J25765-A)

Turning torque specification:

1.0 - 1.3 N·m

(10 - 13 kg·cm, 8.7 - 11.3 in·lb)




- Place the J34309-14 pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:


Make sure all machined surfaces are clean.

Pinion Gear Height (Cont'd)

PINION HEIGHT ADJUSTING WASHER SELECTION




8. Now, position the side bearing discs, J25269-18, and arbor firmly into the side bearing bores.




9. Install the side bearing caps and torque the cap bolts.

Specification:


49 - 59 N·m (5 - 6 kg·m, 36 - 43 ft·lb)



10. Select the correct standard pinion height adjusting washer thickness by using J34309-101 feeler gauge. Measure the gap between the J34309-14 pinion height adapter and the arbor.



11. Write down your exact total measurement.



12. Correct the pinion height washer size by referring to the "pinion head number".

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set and should be the same as the number on the ring gear. The second number is the "pinion head height number," and it refers to the ideal pinion height from standard for quietest operation.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Pinion Gear Height (Cont'd)

Use the following chart to determine the correct pinion height washer.

Pinion Head Height Number	Add or Remove from the Standard Pinion Height Washer Thickness Measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

13. Select the correct pinion height washer.

**Drive pinion height adjusting washer:
Refer to SDS, PD-104.**




14. Remove the J34309 pinion preload shim selector Tool from the final drive housing and disassemble to retrieve the pinion bearings.

Tooth Contact


Checking of gear tooth contact pattern is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear sets which are not positioned properly may be noisy, or have short life, or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.




3. Hold companion flange steady and rotate the ring gear in both directions.

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.




When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.

SPD007



Differential Case


1. Install side gears, pinion mate gears and thrust washers into differential case.




2. Fit pinion mate shaft to differential case so that it meets lock pin holes.
3. Adjust backlash between side gear and pinion mate gear by selecting side gear thrust washer. Refer to SDS, PD-104.

Backlash between side gear and pinion mate gear (Clearance between side gear thrust washer and differential case):


Less than 0.15 mm (0.0059 in)



4. Install pinion mate shaft lock pin with a punch. **Make sure lock pin is flush with case.**




5. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




6. Apply locking agent [Locktite (stud lock) or equivalent] to contacting surfaces of ring gear and differential case, then place differential case on ring gear.

Differential Case (Cont'd)



SPD032

7. Apply a small amount of locking agent (described on previous page) to ring gear bolts.
8. Install new lock straps and ring gear bolts.
 - Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.
 - Then bend up lock straps to lock the bolts in place.




PD353

9. Select side bearing adjusting shims. Refer to "ADJUSTMENT", PD-46.
10. Install the shims behind each bearing and press on side bearing inner cones with Tools.

Tool numbers:

- (A) ST33230000 (J25805-01)
- (B) ST33061000 (J8107-2)

Differential Carrier




SPD580

1. Press-fit front and rear bearing outer races with Tools.

Tool numbers:

- (A) ST30611000 (J25742-1)
- (B) ST30621000 (J25742-5)
- (C) ST30613000 (J25742-3)



SPD377


2. Select pinion height adjusting washer. Refer to "ADJUSTMENT", PD-47.
3. Install pinion height adjusting washer in drive pinion, and press-fit rear bearing inner cone with press and Tool.

Tool number: ST30901000 (J26010-01)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Differential Carrier (Cont'd)

- Place pinion front bearing inner cone in gear carrier.




- Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.


Tool numbers:

(A) ST30720000 (J25405)


(B) KV38102510 (—)



- Install drive pinion washer, collapsible spacer and drive pinion in gear carrier.




- Install companion flange and hold it firmly. Insert pinion into companion flange by tapping its head with a soft hammer.




- Temporarily tighten pinion nut until there is no axial play. **The threaded portion of drive pinion and pinion nut should be free from oil or grease.**

Tool number: ST38060002 (J34311)



Differential Carrier (Cont'd)



SPD149

9. Tighten pinion nut by degrees to the specified preload while checking the preload with Tools.

When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.


Pinion bearing preload:

1.1 - 1.6 N·m (11 - 16 kg·cm, 9.5 - 13.9 in·lb)

Tool number: ST3127S000 (J25765-A)


CAUTION:

The preload is achieved by the permanent setting of the collapsible spacer. So, if an overpreload results from turning of the pinion nut excessively, the spacer should be replaced by new one.




SPD011

10. Install differential case assembly with side bearing outer races into gear carrier.



SPD043

11. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.



SPD140


12. Measure ring gear-to-drive pinion backlash with a dial indicator.

Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)

- If backlash is too small, decrease thickness of left shim and increase thickness of right shim by the same amount.
- If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.



SPD149

13. Check total preload with Tool.


When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number: ST3127S000 (J25765-A)

Total preload:

1.2 - 2.2 N·m (12 - 22 kg·cm, 10 - 19 in·lb)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Differential Carrier (Cont'd)

- If preload is too great, remove the same amount of shims from each side.
- If preload is too small, add the same amount of shims to each side.

Never add or remove a different number of shims for each side as it will change ring gear-to-drive pinion backlash.

14. Recheck ring gear-to-drive pinion backlash because an increase or decrease in thickness of shims will cause change of ring gear-to-pinion backlash.




15. Check runout of ring gear with a dial indicator.

Runout limit: 0.08 mm (0.0031 in)


- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
 - If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.
16. Check tooth contact.
Refer to "ADJUSTMENT", PD-51.

SEC. 380



- : N·m (kg-m, ft-lb)
- : Always replace when disassembled.
- : Adjustment is required.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



PD245

Pre-inspection

Before disassembling final drive, perform the following inspection.


- Total preload
 - a. Turn drive pinion in both directions several times to set bearing rollers.
 - b. Check total preload with Tool.

Tool number: ST3127S000 (J25765-A)

Total preload:

1.2 - 2.3 N·m

(12 - 23 kg-cm, 10 - 20 in-lb)




SPD196

- Ring gear-to-drive pinion backlash.
Check backlash of ring gear with a dial indicator at several points.


Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)



SPD702

- Ring gear runout
Check runout of ring gear with a dial indicator.
Runout limit: 0.05 mm (0.0020 in)




SPD198

- Tooth contact
Check tooth contact. Refer to "ADJUSTMENT", PD-74.
- Side gear-to-pinion mate gear backlash
Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:

Less than 0.15 mm (0.0059 in)




SPD714

Differential Carrier


1. Remove rear cover and rear cover gasket.
2. Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.

Bearing caps are line-bored during manufacture and should be put back in their original places.


Differential Carrier (Cont'd)




3. Remove side bearing caps.




4. Remove differential case assembly with pry bar.



Keep the side bearing outer races together with their respective inner cones — do not mix them up.




5. Remove pinion nut with Tool.
Tool number: ST38060002 (J34311)




6. Remove companion flange with puller.

CI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Differential Carrier (Cont'd)



7. Remove drive pinion with soft hammer.
8. Remove front oil seal and pinion front bearing inner cone.




9. Remove pinion bearing outer races with a brass drift.



10. Remove pinion rear bearing inner cone and pinion height adjusting washer.
Tool number: ST30031000 (J22912-01)

Differential Case





1. Remove side bearing inner cones.
To prevent damage to bearing, engage puller jaws in grooves.

Tool numbers:


- (A) ST33051001 (J22888-20)
- (B) ST33061000 (J8107-2)

Differential Case (Cont'd)

Be careful not to confuse the right and left hand parts.



2. Loosen ring gear bolts in a criss-cross fashion.
3. Tap ring gear off the differential case with a soft hammer.
Tap evenly all around to keep ring gear from binding.



4. Punch off pinion mate shaft lock pin from ring gear side.
Lock pin is calked at pin hole mouth on differential case.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping. If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).




Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, thrust block and thrust washers.




Bearing

1. Thoroughly clean bearing.
2. Check bearings for wear, scratches, pitting or flaking. Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



CAUTION:

Do not run engine when only one wheel (rear) is off the ground.



Preparation for Disassembly

CHECKING DIFFERENTIAL TORQUE

Measure differential torque with Tools.


If it is not within the specifications, inspect components of limited slip differential.

Differential torque:

88 - 108 N·m
 (9.0 - 11.0 kg-m, 65 - 80 ft-lb)

Tool numbers:


- Ⓐ KV38105110 (—)
- Ⓑ KV38105120 (—)



Disassembly

1. Spread out lock straps.
2. Remove couple bolts using a press.
Tool number: ST33081000 (—)
3. Separate differential cases A and B.
 Draw out component parts (discs and plates, etc.).

Put marks on gears and pressure rings so that they can be reinstalled in their original positions.



SPD291

Inspection

CONTACT SURFACES

1. Clean the disassembled parts in suitable solvent and blow dry with compressed air.
2. If the following surfaces are found with burrs or scratches, smooth with oil stone.
 - ① Differential case B
 - ② Differential case A
 - ③ Side gear
 - ④ Pinion mate gear
 - ⑤ Pinion mate shaft
 - ⑥ Thrust block
 - ⑦ Friction plate guide


DISC AND PLATE

1. Clean the discs and plates in suitable solvent and blow dry with compressed air.
2. Inspect discs and plates for wear, nicks and burrs.

3. Check friction discs or plates for warpage.


**Maximum allowable warpage:
0.08 mm (0.0031 in)**

If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.



SPD279

Inspection (Cont'd)




4. Measure frictional surfaces and projected portions of friction discs, plates and spring plate. If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:

0.1 mm (0.004 in) or less

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



Adjustment

FRICION DISC AND FRICTION PLATE END PLAY

End play of friction disc and friction plate can be calculated by using the following equation and should be adjusted within the following range.


Adjustment can be made by selecting friction disc having two different thicknesses.

End play E:

0.05 - 0.15 mm (0.0020 - 0.0059 in)

$$E = A - (B + C)$$

- A: Length of differential case contact surface to differential case inner bottom.
- B: Total thickness of friction discs, friction plates and spring plate in differential case on one side.
- C: Length of differential case contact surface to back side of side gear.




1. Measure values of "A".


Standard length A:

49.50 - 49.55 mm (1.9488 - 1.9508 in)

Adjustment (Cont'd)




2. Measure thickness of each disc and plate.
 - Total thickness "B":**
19.24 - 20.26 mm (0.7575 - 0.7976 in)
 - No. of discs and plates (One side):**
Friction disc 6
Friction plate 6
Spring plate 1



3. Measure values of "C".
 - a. Attach a dial indicator to the base plate.
 - b. Place differential case B on the base plate, and install a master gauge on case B.

Then adjust the dial indicator scale to zero with its tip on the master gauge.



- c. Install pinion mate gears, side gears and pinion mate shaft in differential case B.
 - d. Set dial indicator's tip on the side gear, and read the indication.


Example:






$$\begin{aligned}
 E &= A - D \\
 &= A - (B + C) \\
 &= 0.05 \text{ to } 0.15 \text{ mm} \\
 A &= 49.52 \text{ mm} \\
 B &= 19.45 \text{ mm} \\
 C &= 29.7 \text{ mm} \\
 D &= B + C \\
 &\quad B \dots 19.45 \\
 &\quad + C \dots 29.7 \\
 &\quad \hline
 &\quad 49.15
 \end{aligned}$$

$$\begin{aligned}
 E &= A - D \\
 A &\dots 49.52 \\
 -D &\dots 49.15 \\
 \hline
 &0.37
 \end{aligned}$$

From the above equation, end play of 0.37 mm exceeds the specified range of 0.05 to 0.15 mm.

Select suitable discs and plates to adjust correctly.





Assembly

Prior to assembling discs and plates, properly lubricate them by dipping them in limited slip differential oil.

1. Alternately position specified number of friction plates and friction discs on rear of side gear.

Always position a friction plate first on rear of side gear.

2. Install spring plate.

3. Install friction plate guides.

Correctly align the raised portions of friction plates, and apply grease to inner surfaces of friction plate guides to prevent them from falling.


4. Install differential case B over side gear, discs, plates and friction plate guide assembly.

- Install differential case B while supporting friction plate guides with your middle finger by inserting through oil hole in differential case.
- Be careful not to detach spring plate from the hexagonal part of the side gear.


5. Install pinion mate gears and pinion shaft to differential case B.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Assembly (Cont'd)




6. Install thrust block.



7. Install side gear to pinion mate gears.


8. Install each disc and plate.

Use same procedures as outlined in steps 1. through 3.



9. Install differential case A.

Position differential cases A and B by correctly aligning marks stamped on cases.



10. Tighten differential case bolts.

11. Place ring gear on differential case and install new lock straps and bolts.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

Then bend up lock straps to lock the bolts in place.

12. Install side bearing inner cone.




13. Check differential torque.

For quiet and reliable final drive operation, the following five adjustments must be made correctly.

1. Side bearing preload
2. Pinion gear height
3. Pinion bearing preload. Refer to "ASSEMBLY", PD-77.
4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-78.
5. Ring and pinion gear tooth contact pattern

Side Bearing Preload

A selection of carrier side bearing preload shims is required for successful completion of this procedure.



1. Make sure all parts are clean. Make sure, also, the bearings are well lubricated with light oil or type "DEXRON™" automatic transmission fluid.
2. Place the differential carrier, with side bearings and bearing races installed, into the final drive housing.

3. Put the side bearing spacer in place.

CAUTION:


Side bearing spacer is placed on either the right or left depending upon final drive gear ratio. Be sure to replace it on the correct side.

4. Use Tool to place original carrier side bearing preload shims on the carrier end, opposite the ring gear.

Tool number: KV38100600 (J25267)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Side Bearing Preload (Cont'd)




5. Install the side bearing caps in their correct locations and torque the bearing cap retaining bolts.

Specification:

88 - 98 N·m

(9.0 - 10.0 kg·m, 65 - 72 ft·lb)

6. Turn the carrier several times to seat the bearings.




7. Measure the turning torque of the carrier at the ring gear retaining bolts with a spring gauge, J8129.

Specification:

34.3 - 39.2 N


(3.5 - 4.0 kg, 7.7 - 8.8 lb)

of pulling force at the ring gear bolt




8. If the turning torque is not within the specifications, correct the torque as follows:

- If the turning torque is less than the specified range, install washers of greater thickness.
 - If the turning torque is greater than the specification, install thinner washers.
 - See the SDS section for washer dimensions and part numbers.
9. Record the total amount of washer thickness required for the correct carrier side bearing preload.




10. Remove the carrier from the final drive housing. Save the selected preload washers for later use during the assembly of the final drive unit.




Pinion Gear Height

1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the pinion gear bearings into the pinion preload shim selector Tool, J34309.


Pinion Gear Height (Cont'd)




- **Front pinion bearing** — make sure the J34309-3 front pinion bearing seat is secured tightly against the J34309-2 gauge anvil. Then turn the front pinion bearing pilot, J34309-5, to secure the bearing in its proper position.
- **Rear pinion bearing** — the rear pinion bearing pilot, J34309-8, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4, is used to lock the bearing to the assembly.




3. Install the pinion rear bearing inner cone into the final drive housing. Then place the pinion preload shim selector Tool, J34309-1, gauge screw assembly.



4. Assemble the front pinion bearing inner cone and the J34309-2 gauge anvil. Assemble them together with the J34309-1 gauge screw in the final drive housing. Make sure that the pinion height gauge plate, J34309-16, will turn a full 360 degrees. Tighten the two sections together by hand.



5. Turn the assembly several times to seat the bearings.



6. Measure the turning torque at the end of the J34309-2 gauge anvil using Tool.

Tool number: ST3127S000 (J25765-A)

Turning torque specification:

1.0 - 1.3 N·m

(10 - 13 kg-cm, 8.7 - 11.3 in-lb)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
ET
HA
EL
IDX

Pinion Gear Height (Cont'd)


7. Place the J34309-11 pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:


Make sure all machined surfaces are clean.

**PINION HEIGHT ADJUSTING WASHER SELECTION**

8. Now, position the side bearing discs, J25269-4, and arbor firmly into the side bearing bores. Install the side bearing caps and tighten the cap bolts to proper torque.




9. Select the correct standard pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and J34309-101 feeler gauge. Measure the distance between the J34309-11 pinion height adapter including the standard gauge and the arbor.



10. Write down your exact measurement (the value of feeler gauge).

Pinion Gear Height (Cont'd)



11. Correct the pinion height washer size by referring to the “pinion head number”.


There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set. This number should be the same as the number on the ring gear. The second number is the “pinion head height number”. It refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.

Use the following chart to determine the correct pinion height washer:

Pinion head height number	Add or remove from the standard pinion height washer thickness measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

12. Select the correct pinion height washer.

**Drive pinion height adjusting washer:
Refer to SDS, PD-105.**




13. Remove the J34309 pinion preload shim selector Tool from the final drive housing. Then disassemble to retrieve the pinion bearings.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Tooth Contact


Checking gear tooth contact pattern is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear set which is not positioned properly may be noisy, or have short life or both. With the checking of gear tooth contact pattern, the most desirable contact for low noise level and long life can be assured.



SPD199


1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.



SPD200


3. Hold companion flange steady and rotate the ring gear in both directions.

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.



When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.

SPD007



SPD656

Differential Case


1. Measure clearance between side gear thrust washer and differential case.

Clearance between side gear thrust washer and differential case (A - B):

Less than 0.15 mm (0.0059 in)


The clearance can be adjusted with side gear thrust washer. Refer to SDS, PD-105.

2. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.



SPD643


3. Install differential case LH and RH.



SPD746

4. Place differential case on ring gear.
5. Apply locking agent [Locktite (stud lock) or equivalent] to ring gear bolts, and install them.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.



PD353

6. Press-fit side bearing inner cones on differential case with Tool.

Tool numbers:

(A) ST33230000 (J25805-01)

(B) ST33061000 (J8107-2)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Differential Carrier

1. Press-fit front and rear bearing outer races with Tools.


Tool numbers:

- (A) ST30611000 (J25742-1)
- (B) ST30621000 (J25742-5)
- (C) ST30613000 (J25742-3)




2. Select pinion height adjusting washer. Refer to "ADJUSTMENT", PD-70.
3. Install pinion height adjusting washer in drive pinion, and press-fit rear bearing inner cone in it, with press and Tool.

Tool number: ST30901000 (J26010-01)




4. Place pinion front bearing inner cone in gear carrier.








5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.

Tool number: KV38100500 (J25273)



Differential Carrier (Cont'd)



6. Place drive pinion bearing spacer, drive pinion bearing adjusting washer and drive pinion in gear carrier.

7. Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.

8. Tighten pinion nut to 127 N·m (13 kg·m, 94 ft·lb).
The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number: ST38060002 (J34311)

9. Tighten the pinion nut by very small degrees until the specified preload is achieved. When checking the preload, turn the drive pinion in both directions several times to set the bearing rollers.

Tool number: ST3127S000 (J25765-A)

Pinion bearing preload:

1.1 - 1.7 N·m

(11 - 17 kg·cm, 9.5 - 14.8 in·lb)

This procedure will have to be repeated if:


- **Maximum preload is achieved before the minimum pinion nut torque is reached.**
- **Minimum preload is not achieved before maximum pinion nut torque is reached.**

10. Select side bearing adjusting washer. Refer to Adjustment.


11. Install differential case assembly with side bearing outer races into gear carrier.

GJ
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


Differential Carrier (Cont'd)




12. Insert left and right side bearing adjusting washers in place between side bearing and carrier.



13. Drive in side bearing spacer with Tool.
Tool number: KV38100600 (J25267)



14. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.




15. Measure ring gear-to-drive pinion backlash with a dial indicator.

Ring gear-to-drive pinion backlash:
0.13 - 0.18 mm
(0.0051 - 0.0071 in)

- If backlash is too small, decrease thickness of right shim and increase thickness of left shim by the same amount. If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.




16. Check total preload with Tool.

When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.

Total preload:
1.2 - 2.3 N·m
(12 - 23 kg·cm, 10 - 20 in·lb)

Tool number: ST3127S000 (J25765-A)


Differential Carrier (Cont'd)



- If preload is too great, remove the same amount of shim from each side.
- If preload is too small, add the same amount of shim to each side.

Never add or remove a different number of shims for each side as it will change ring gear-to-drive pinion backlash.

17. Recheck ring gear-to-drive pinion backlash because increase or decrease in thickness of shims will cause change of ring gear-to-pinion backlash.




18. Check runout of ring gear with a dial indicator.


**Runout limit:
0.05 mm (0.0020 in)**

- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
 - If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.
19. Check tooth contact.
Refer to "ADJUSTMENT", PD-74.
 20. Install rear cover and gasket.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



: N·m (kg-m, in-lb)
 : N·m (kg-m, ft-lb)
 ☆ : Adjustment is required.
 ★ : Applied to models equipped with rear drum brake



SPD149

Pre-inspection

Before disassembling final drive, perform the following inspection.


- Total preload
 - a. Turn drive pinion in both directions several times to seat bearing rollers correctly.
 - b. Check total preload with Tool.

Total preload:

1.7 - 2.5 N·m

(17 - 25 kg·cm, 15 - 22 in·lb)

Tool number: ST3127S000 (J25765-A)




SPD246

- Ring gear-to-drive pinion backlash
Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:

0.15 - 0.20 mm (0.0059 - 0.0079 in)




SPD247

- Ring gear runout
Check runout of ring gear with a dial indicator.

Runout limit:

0.08 mm (0.0031 in)




SPD004

- Tooth contact
Check tooth contact, referring to "ADJUSTMENT", PD-95.
- Side gear-to-pinion mate gear backlash
Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:

Less than 0.15 mm (0.0059 in)



SPD139


Differential Carrier

1. Mount final drive assembly on Tool.

Tool numbers: (A) ST0501S000 (—)


(B) ST06340000 (J24310)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Differential Carrier (Cont'd)

- Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.


Bearing caps are line-bored during manufacture and should be put back in their original places.




- Remove side lock fingers and side bearing caps.



- Remove side bearing adjuster with Tool.
Tool number: ST32580000 (J34312)




- Remove differential case assembly with a pry bar.




Keep the side bearing outer races together with their respective inner cones — do not mix them up.


Differential Carrier (Cont'd)




6. Remove drive pinion nut with Tool.
Tool number: KV38104700 (J34311)
7. Remove companion flange with puller.
8. Remove ABS sensor.




9. Take out drive pinion together with pinion rear bearing inner cone, drive pinion bearing spacer and pinion bearing adjusting shim.



10. Remove front oil seal and pinion front bearing inner cone.
11. Remove pinion bearing outer races with a brass drift.



12. Remove pinion rear bearing inner cone and drive pinion adjusting washer.
Tool number: ST30031000 (J22912-01)



Differential Case

1. Remove side bearing inner cones.
To prevent damage to bearing, engage puller jaws in groove.

Tool numbers:

- (A) ST33051001 (J22888-20)
- (B) ST33061000 (J8107-2)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT



HA

EL


IDX

Differential Case (Cont'd)


Be careful not to confuse the left and right hand parts.



2. Spread out lock straps and loosen ring gear bolts in a criss-cross fashion.



3. Tap ring gear off differential case with a soft hammer. Tap evenly all around to keep ring gear from binding.



4. Separate differential case LH and RH. Put match marks on both differential case LH and RH sides prior to separating them.

Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping.
If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).

CI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA


EL

IDX





Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, and thrust washers.



Bearing

1. Thoroughly clean bearing.
2. Check bearings for wear, scratches, pitting or flaking.
Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



CAUTION:

Do not run engine when only one wheel (rear) is off the ground.

Preparation for Disassembly

CHECKING DIFFERENTIAL TORQUE


Measure differential torque with Tools. If it is not within the specifications, inspect components of limited slip differential.

Differential torque:

201 - 240 N·m
 (20.5 - 24.5 kg-m, 148 - 177 ft-lb)

Tool numbers:


- (A) KV38105210 (—)
- (B) KV38105220 (—)



Disassembly

1. Remove side bearing inner cone with Tool.
 2. Remove ring gear by spreading out lock straps.
 3. Loosen ring gear bolts in a criss-cross fashion.
 4. Tap ring gear off gear case with a soft hammer.
- Tap evenly all around to keep ring gear from binding.

Disassembly (Cont'd)



- 5. Remove differential case by spreading out lock straps.
- 6. Remove couple bolts on differential cases A and B with a press.

Tool number: ST33081000 (—)

- 7. Separate differential cases A and B.
Draw out component parts (discs and plates, etc.).


Put marks on gears and pressure rings so that they can be reinstalled in their original positions.

Inspection

CONTACT SURFACES

- 1. Clean the disassembled parts in suitable solvent and blow dry with compressed air.
- 2. If the following surfaces are found with burrs or scratches, smooth with oil stone.

- ① Differential case B
- ② Differential case A
- ③ Side gear
- ④ Pinion mate gear
- ⑤ Pinion mate shaft
- ⑥ Thrust block
- ⑦ Friction plate guide



DISC AND PLATE


- 1. Clean the discs and plates in suitable solvent and blow dry with compressed air.
- 2. Inspect discs and plates for wear, nicks and burrs.

- 3. Check friction discs or plates for warpage.

Allowable warpage:

0.08 mm (0.0031 in)

If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


Inspection (Cont'd)

4. Measure frictional surfaces and projected portions of friction discs, plates, spring disc and plate.

If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:

0.1 mm (0.004 in) or less



SPD403

Adjustment

FRICION DISC AND FRICTION PLATE END PLAY

End play of friction disc and friction plate can be calculated by using the following equation and should be adjusted within the following range.

Adjustment can be made by selecting friction disc having two different thicknesses.

End play E:


0.05 - 0.15 mm (0.0020 - 0.0059 in)

$E = A - (B + C)$


A: Length of differential case contact surface to differential case inner bottom.

B: Total thickness of friction discs, friction plates, spring disc and spring plate in differential case on one side.

C: Length of differential case contact surface to back side of side gear.



SPD761




SPD417

1. Measure values of "A".


Standard length A:

49.50 - 49.55 mm (1.9488 - 1.9508 in)

Adjustment (Cont'd)




2. Measure thickness of each disc and plate.
 - Total thickness "B":**
19.24 - 20.26 mm (0.7575 - 0.7976 in)
 - No. of discs and plates (One side):**
 - Friction disc 5
 - Friction plate 6
 - Spring disc 1
 - Spring plate 1



3. Measure values of "C".
 - a. Attach a dial indicator to the base plate.
 - b. Place differential case B on the base plate, and install a master gauge on case B.

Then adjust the dial indicator scale to zero with its tip on the master gauge.



- c. Install pinion mate gears, side gears and pinion mate shaft in differential case B.
 - d. Set dial indicator's tip on the side gear, and read the indication.

Example:

$$E = A - D = A - (B + C) = 0.05 \text{ to } 0.15 \text{ mm}$$

$$A = 49.52 \text{ mm}$$

$$B = 19.45 \text{ mm}$$

$$C = 29.7 \text{ mm}$$

$$D = B + C$$

$$B \dots 19.45$$

$$+C \dots 29.7$$

$$49.15$$

$$E = A - D$$


$$A \dots 49.52$$

$$-D \dots 49.15$$

$$0.37$$

From the above equation, end play of 0.37 mm exceeds the specified range of 0.05 to 0.15 mm.

Select suitable discs and plates to adjust correctly.




Assembly

Prior to assembling discs and plates, properly lubricate them by dipping them in limited slip differential oil.

1. Alternately position specified number of friction plates and friction discs on rear of side gear.


Always position a friction plate first on rear of side gear.

Assembly (Cont'd)




2. Install spring disc.

Align the twelve angular holes in spring disc with the hexagonal area of the side gear.




3. Install spring plate.




4. Install friction plate guides.

Correctly align the raised portions of friction plates, and apply grease to inner surfaces of friction plate guides to prevent them from falling.




5. Install differential case B over side gear, discs, plates and friction plate guide assembly.

- **Install differential case B while supporting friction plate guides with your middle finger by inserting through oil hole in differential case.**
- **Be careful not to detach spring disc from the hexagonal part of the side gear.**




6. Install pinion mate gears and pinion shaft to differential case B.

Assembly (Cont'd)




7. Install thrust block.



8. Install side gear to pinion mate gears.


9. Install each disc and plate.

Use same procedures as outlined in steps 1. through 4.



10. Install differential case A.

Position differential cases A and B by correctly aligning marks stamped on cases.



11. Tighten differential case bolts.

12. Place ring gear on differential case and install new lock straps and bolts.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

Then bend up lock straps to lock the bolts in place.


13. Install side bearing inner cone.

14. Check differential torque.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX


For quiet and reliable final drive operation, the following five adjustments must be made correctly:

1. Side bearing preload
2. Pinion gear height
3. Pinion bearing preload. Refer to "ASSEMBLY", PD-98.
4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-99.
5. Ring and pinion gear tooth contact pattern




Pinion Gear Height


1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the pinion gear bearings into the pinion pre-load shim selector Tool, J34309.



- **Rear Pinion Bearing** — the rear pinion bearing pilot, J34309-8, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4, is used to lock the bearing to the assembly.
- **Front Pinion Bearing** — make sure the J34309-3, front pinion bearing seat is secured tightly against the J34309-2 gauge anvil. Then turn the front pinion bearing pilot, J34309-5, to secure the bearing in its proper position.




3. Place the pinion preload shim selector Tool gauge screw assembly, J34309-1, with the pinion rear bearing inner cone installed, into the final drive housing.



4. Install the J34309-2 gauge anvil with the front pinion bearing into the final drive housing and assemble it to the J34309-1 gauge screw. Make sure that the J34309-16 gauge plate will turn a full 360 degrees, and tighten the two sections by hand to set bearing pre-load.
5. Turn the assembly several times to seat the bearings.

Pinion Gear Height (Cont'd)



SPD234A


6. Measure the turning torque at the end of the J34309-2 gauge anvil using Tool.

Tool number: ST3127S000 (J25765-A)

Turning torque specification:

0.4 - 0.9 N-m (4 - 9 kg-cm, 3.5 - 7.8 in-lb)

GI
MA
EM
LC



SPD208A


7. Place the J34309-12 "H233B" pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:

Make sure all machined surfaces are clean.

EC
FE
CL

PINION HEIGHT ADJUSTING WASHER SELECTION



SPD286A

8. Position the J25269-18 side bearing discs and the arbor into the side bearing bores.

MT
AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




SPD237A

9. Install the bearing caps and torque the bolts.

Specification:


☐: 93 - 103 N-m (9.5 - 10.5 kg-m, 69 - 76 ft-lb)




SPD204A

10. Select the correct standard pinion height adjusting washer thickness using a standard gauge of 2.5, 3.0, or 3.5 mm (0.098, 0.118, or 0.138 in) and J34309-101 feeler gauge. Measure the distance between the J34309-12 "H233B" pinion height adapter and the arbor.

Pinion Gear Height (Cont'd)



11. Write down your exact total measurement.




12. Correct the pinion height washer size by referring to the “pinion head height number”.

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set and should be the same as the number on the ring gear. The second number is the “pinion head height number,” and it refers to the ideal pinion height from standard for the quietest operation. Use the following chart to determine the correct pinion height washer.

Pinion Head Height Number	Add or Remove from the Selected Standard Pinion Height Washer Thickness Measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

13. Select the correct pinion height washer.

**Drive pinion height adjusting washer:
Refer to SDS, PD-106.**




14. Remove the J34309 pinion preload shim selector tool from the final drive housing and disassemble to retrieve the pinion bearings.

Tooth Contact


Gear tooth contact pattern check is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear sets which are not positioned properly may be noisy, or have short life or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.





3. Hold companion flange steady and rotate the ring gear in both directions.

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.




To correct, increase thickness of pinion height adjusting washer in order to bring drive pinion close to ring gear.

To correct, reduce thickness of pinion height adjusting washer in order to make drive pinion go away from ring gear.




Correct tooth contact



When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.

SPD007

Differential Case



SPD656


1. Measure clearance between side gear thrust washer and differential case.

Clearance between side gear thrust washer and differential case (A — B):

Less than 0.15 mm (0.0059 in)


The clearance can be adjusted with side gear thrust washer. Refer to SDS, PD-106.

2. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.



SPD643


3. Install differential case LH and RH.
4. Install differential case on ring gear.



SPD746

5. Place differential case on ring gear.
6. Apply locking agent [Loctite (stud lock) or equivalent] to ring gear bolts, and install them.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.



PD353

7. Press-fit side bearing inner cones on differential case with Tool.

Tool numbers:

 - (A) ST33190000 (J25523)
 - (B) ST33081000 (—)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Differential Carrier

1. Press-fit front and rear bearing outer races with Tools.

Tool numbers:


- Ⓐ ST30611000 (J25742-1)
- Ⓑ ST30621000 (J25742-5)
- Ⓒ ST30613000 (J25742-3)




2. Select drive pinion adjusting washer. Refer to "ADJUSTMENT", PD-92.

3. Install drive pinion adjusting washer in drive pinion, and press-fit pinion rear bearing inner cone in it, with press and Tool.

Tool number: ST30901000 (J26010-01)



4. Place pinion front bearing inner cone in gear carrier.




5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.


Tool numbers:

- Ⓐ ST30720000 (J25405)
- Ⓑ KV38102510 (—)


Differential Carrier (Cont'd)



6. Install drive pinion bearing spacer, pinion bearing adjusting shim and drive pinion in gear carrier.




7. Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.



8. Tighten pinion nut to the specified torque.
The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number: KV38104700 (J34311)



9. Turn drive pinion in both directions several times, and measure pinion bearing preload.


Tool number: ST3127S000 (J25765-A)

Pinion bearing preload (Without front oil seal):

1.2 - 1.5 N·m (12 - 15 kg-cm, 10 - 13 in-lb)

If preload is out of specification, adjust the thickness of spacer and shim combination by replacing shim and spacer with thinner one.

- Start from the combination of thickest spacer and shim.
- Combine each spacer and shim thickness one by one until the correct specification is achieved.




10. Install differential case assembly with side bearing outer races into gear carrier.


11. Position side bearing adjusters on gear carrier with threads properly engaged; screw in adjusters lightly at this stage of assembly.

Tool number: ST32580000 (J34312)

Differential Carrier (Cont'd)




12. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.
 - Do not tighten at this point to allow further tightening of side bearing adjusters.




13. Tighten both right and left side bearing adjusters alternately and measure ring gear backlash and total preload at the same time. Adjust right and left side bearing adjusters by tightening them alternately so that proper ring gear backlash and total preload can be obtained.


Ring gear-to-drive pinion backlash:
 0.15 - 0.20 mm (0.0059 - 0.0079 in)



- When checking preload, turn drive pinion in both directions several times to set bearing rollers.
Tool number: ST3127S000 (J25765-A)
Total preload:
 1.7 - 2.5 N·m (17 - 25 kg·cm, 15 - 22 in·lb)



14. Tighten side bearing cap bolts.
15. Install side lock finger in place to prevent rotation during operation.



16. Check runout of ring gear with a dial indicator.
 - **Runout limit: 0.08 mm (0.0031 in)**
 - If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
 - If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.
17. Check tooth contact. Refer to "ADJUSTMENT", PD-95.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Propeller Shaft

GENERAL SPECIFICATIONS

2WD models

Wheelbase	Standard		Long	
Transmission	M/T	A/T	M/T	A/T
Propeller shaft model	3S71A			
Number of joints	3			
Coupling method with transmission	Sleeve type			
Type of journal bearings	Solid type (disassembly type)			
Distance between yokes	88.1 (3.47)			
Shaft length (Spider to spider)	mm (in)			
1st	651.5 (25.65)	549.9 (21.65)	651.5 (25.65)	549.9 (21.65)
2nd	675.2 (26.58)		975.2 (38.39)	
Shaft outer diameter	mm (in)			
1st	63.5 (2.50)			
2nd	63.5 (2.50)			

4WD models

Location	Front	Rear	
Wheelbase	—	Standard	Long
Propeller shaft model	2F71H	2S80B	3S80B
Number of joints	2		3
Coupling method with transmission	Flange type	Sleeve type	
Type of journal bearings	Solid type (disassembly type)		
Distance between yokes	88.1 (3.47)		
Shaft length (Spider to spider)	mm (in)		
1st	514.1 (20.24)	938.1 (36.93)	398.0 (15.67)
2nd	—		840.3 (33.08)
Shaft outer diameter	mm (in)		
1st	63.5 (2.50)	63.5 (2.50)	63.5 (2.50)
2nd	—		63.5 (2.50)

SERVICE DATA AND SPECIFICATIONS (SDS)

Propeller Shaft (Cont'd)

SERVICE DATA

Unit: mm (in)

Propeller shaft runout limit	0.6 (0.024)
Journal axial play	0.02 (0.0008) or less

Snap ring

Unit: mm (in)

Thickness	Color	Part number
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light brown	37151-C9400
2.17 (0.0854)	Black	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive

GENERAL SPECIFICATIONS

2WD models

Transmission	M/T						A/T	
Body type	—		—		King cab		—	
Vehicle type	Except SE		SE		XE		—	
Final drive model	Standard	Optional	Standard	Optional	Standard	Optional	Standard	Optional
	H190A		C200				H190A	
	2-pinion	LSD	2-pinion	LSD	2-pinion	LSD	2-pinion	LSD
Gear ratio	3.545		3.900				4.111	
Number of teeth (Ring gear/drive pinion)	39/11		39/10				37/9	
Oil capacity (Approx.) l (US pt, Imp pt)	1.5 (3-1/8, 2-5/8)		1.3 (2-3/4, 2-1/4)				1.5 (3-1/8, 2-5/8)	

4WD models

Front final drive	R180A	
	4-pinion	
	4.625	
Oil capacity (Approx.) l (US pt, Imp pt)	1.3 (2-3/4, 2-1/4)	
Rear final drive	Standard	Optional
	H233B	
	4-pinion	LSD
Gear ratio	4.625	
Number of teeth (Ring gear/drive pinion)	37/8	
Oil capacity (Approx.) l (US pt, Imp pt)	2.8 (5-7/8, 4-7/8)	

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (R180A)

Ring gear runout

Ring gear runout limit	mm (in)	0.05 (0.0020)
------------------------	---------	---------------

Axle bearing adjustment

Axle bearing end play	mm (in)	0 - 0.1 (0 - 0.004)
-----------------------	---------	---------------------

Available axle bearing adjusting shims

Thickness mm (in)	Part number
0.10 (0.0039)	38233-01G11
0.20 (0.0079)	38233-01G12
0.30 (0.0118)	38233-01G13
0.40 (0.0157)	38233-01G14
0.50 (0.0197)	38233-01G10

Side gear adjustment

Side gear backlash (Clearance between side gear and differential case)	mm (in)	Less than 0.15 (0.0059)
---	---------	-------------------------

Available side gear thrust washers

Thickness mm (in)	Part number
0.75 - 0.78 (0.0295 - 0.0307)	38424-W2010
0.78 - 0.81 (0.0307 - 0.0319)	38424-W2011
0.81 - 0.84 (0.0319 - 0.0331)	38424-W2012
0.84 - 0.87 (0.0331 - 0.0343)	38424-W2013
0.87 - 0.90 (0.0343 - 0.0354)	38424-W2014
0.90 - 0.93 (0.0354 - 0.0366)	38424-W2015
0.93 - 0.96 (0.0366 - 0.0378)	38424-W2016
0.96 - 0.99 (0.0378 - 0.0390)	38424-W2017

Side bearing adjustment

Differential carrier assembly turning resistance	N (kg, lb)	34.3 - 39.2 (3.5 - 4.0, 7.7 - 8.8)
--	------------	---------------------------------------

Side bearing adjusting method	Adjusting shim
-------------------------------	----------------

Available side retainer shims

Thickness mm (in)	Part number
0.20 (0.0079)	38453-01G00
0.25 (0.0098)	38453-01G01
0.30 (0.0118)	38453-01G02
0.40 (0.0157)	38453-01G03
0.50 (0.0197)	38453-01G04

Total preload adjustment

Total preload	N-m (kg-cm, in-lb)	1.2 - 2.3 (12 - 23, 10 - 20)
---------------	--------------------	---------------------------------

Ring gear backlash	mm (in)	0.13 - 0.18 (0.0051 - 0.0071)
--------------------	---------	----------------------------------

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number
3.09 (0.1217)	38154-P6017
3.12 (0.1228)	38154-P6018
3.15 (0.1240)	38154-P6019
3.18 (0.1252)	38154-P6020
3.21 (0.1264)	38154-P6021
3.24 (0.1276)	38154-P6022
3.27 (0.1287)	38154-P6023
3.30 (0.1299)	38154-P6024
3.33 (0.1311)	38154-P6025
3.36 (0.1323)	38154-P6026
3.39 (0.1335)	38154-P6027
3.42 (0.1346)	38154-P6028
3.45 (0.1358)	38154-P6029
3.48 (0.1370)	38154-P6030
3.51 (0.1382)	38154-P6031
3.54 (0.1394)	38154-P6032
3.57 (0.1406)	38154-P6033
3.60 (0.1417)	38154-P6034
3.63 (0.1429)	38154-P6035
3.66 (0.1441)	38154-P6036

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Adjusting washer and spacer
---	-----------------------------

Drive pinion preload	N-m (kg-cm, in-lb)	1.1 - 1.7 (11 - 17, 9.5 - 14.8)
With front oil seal		

Available drive pinion bearing preload adjusting washers

Thickness mm (in)	Part number
6.59 (0.2594)	38127-01G00
6.57 (0.2587)	38127-01G01
6.55 (0.2579)	38127-01G02
6.53 (0.2571)	38127-01G03
6.51 (0.2563)	38127-01G04
6.49 (0.2555)	38127-01G05
6.47 (0.2547)	38127-01G06
6.45 (0.2539)	38127-01G07
6.43 (0.2531)	38127-01G08
6.41 (0.2524)	38127-01G09
6.39 (0.2516)	38127-01G10
6.37 (0.2508)	38127-01G11
6.35 (0.2500)	38127-01G12
6.33 (0.2492)	38127-01G13
6.31 (0.2484)	38127-01G14

Available drive pinion bearing preload adjusting spacers

Length mm (in)	Part number
52.20 (2.0551)	38130-78500
52.40 (2.0630)	38131-78500
52.60 (2.0709)	38132-78500
52.80 (2.0787)	38133-78500
53.00 (2.0866)	38134-78500
53.20 (2.0945)	38135-78500

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (H190A)

Ring gear runout

Ring gear runout limit	mm (in)	0.08 (0.0031)
------------------------	---------	---------------

Side gear adjustment

Side gear backlash (Clearance between side gear to differential case)	mm (in)	Less than 0.15 (0.0059)
--	---------	-------------------------

Available side gear thrust washers

Conventional models

Thickness mm (in)	Part number
0.75 (0.0295)	38424-E3000
0.80 (0.0315)	38424-E3001
0.85 (0.0335)	38424-E3002
0.90 (0.0354)	38424-E3003

LSD models

Thickness mm (in)	ID color	Part number
1.50 (0.0591)	None	38424-41W00
1.60 (0.0630)	White	38424-41W01
1.70 (0.0669)	Yellow	38424-41W02

— Additional service for LSD model —

Differential torque adjustment

Differential torque	N·m (kg·m, ft·lb)	
New parts		69 - 118 (7 - 12, 51 - 87)
Used parts		39 - 74 (4 - 7.5, 29 - 54)

Number of discs and plates	
Friction disc	4
Friction plate	4
Spring disc	2
Spring plate	2

Wear limit of plate and disc	mm (in)	0.1 (0.004)
------------------------------	---------	-------------

Allowable warpage	mm (in)	
Friction disc and plate		0.08 (0.0031)

Available discs and plates

Part name	Thickness mm (in)	Part number
Friction disc	1.75 (0.0689)	38433-41W00
	1.85 (0.0728)	38433-41W01
Friction plate	1.75 (0.0689)	38432-41W00
Spring disc	1.75 (0.0689)	38436-N3210
Spring plate	1.75 (0.0689)	38435-N3210

Drive pinion height adjustment

Available drive pinion height adjusting washers

Thickness mm (in)	Part number
2.58 (0.1016)	38154-P6000
2.61 (0.1028)	38154-P6001
2.64 (0.1039)	38154-P6002
2.67 (0.1051)	38154-P6003
2.70 (0.1063)	38154-P6004
2.73 (0.1075)	38154-P6005
2.76 (0.1087)	38154-P6006
2.79 (0.1098)	38154-P6007
2.82 (0.1110)	38154-P6008
2.85 (0.1122)	38154-P6009
2.88 (0.1134)	38154-P6010
2.91 (0.1146)	38154-P6011
2.94 (0.1157)	38154-P6012
2.97 (0.1169)	38154-P6013
3.00 (0.1181)	38154-P6014
3.03 (0.1193)	38154-P6015
3.06 (0.1205)	38154-P6016
3.09 (0.1217)	38154-P6017
3.12 (0.1228)	38154-P6018
3.15 (0.1240)	38154-P6019
3.18 (0.1252)	38154-P6020

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Collapsible spacer
Drive pinion preload	
N·m (kg·cm, in·lb)	1.1 - 1.6 (11 - 16, 9.5 - 13.9)
With front oil seal	

Side bearing adjustment

Differential carrier assembly turning resistance	N (kg, lb)	34.3 - 39.2 (3.5 - 4.0, 7.7 - 8.8)
Side bearing adjusting method		Adjusting shim

Available side bearing adjusting shims

Thickness mm (in)	Part number
0.10 (0.0039)	38455-61200
0.12 (0.0047)	38453-61201
0.15 (0.0059)	38453-61202
0.17 (0.0067)	38453-61203
0.20 (0.0079)	38456-61200
0.25 (0.0098)	38453-61204
0.30 (0.0118)	38453-61205
0.40 (0.0157)	38453-61206
0.50 (0.0197)	38457-61200

Total preload adjustment

Total preload	N·m (kg·cm, in·lb)	1.2 - 2.2 (12 - 22, 10 - 19)
Ring gear backlash	mm (in)	0.13 - 0.18 (0.0051 - 0.0071)

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (C200)

Ring gear runout

Ring gear runout limit	mm (in)	0.05 (0.0020)
------------------------	---------	---------------

Side gear adjustment

Side gear backlash (Clearance between side gear and differential case)	mm (in)	Less than 0.15 (0.0059)
---	---------	-------------------------

Available side gear thrust washers

Thickness mm (in)	Part number
0.75 (0.0295)	38424-N3110
0.78 (0.0307)	38424-N3111
0.81 (0.0319)	38424-N3112
0.84 (0.0331)	38424-N3113
0.87 (0.0343)	38424-N3114
0.90 (0.0354)	38424-N3115
0.93 (0.0366)	38424-N3116

Side bearing adjustment

Differential carrier assembly turning resistance	N (kg, lb)	34.3 - 39.2 (3.5 - 4.0, 7.7 - 8.8)
--	------------	---------------------------------------

Available side bearing adjusting washers

Thickness mm (in)	Part number
2.00 (0.0787)	38453-N3100
2.05 (0.0807)	38453-N3101
2.10 (0.0827)	38453-N3102
2.15 (0.0846)	38453-N3103
2.20 (0.0866)	38453-N3104
2.25 (0.0886)	38453-N3105
2.30 (0.0906)	38453-N3106
2.35 (0.0925)	38453-N3107
2.40 (0.0945)	38453-N3108
2.45 (0.0965)	38453-N3109
2.50 (0.0984)	38453-N3110
2.55 (0.1004)	38453-N3111
2.60 (0.1024)	38453-N3112

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number
3.09 (0.1217)	38154-P6017
3.12 (0.1228)	38154-P6018
3.15 (0.1240)	38154-P6019
3.18 (0.1252)	38154-P6020
3.21 (0.1264)	38154-P6021
3.24 (0.1276)	38154-P6022
3.27 (0.1287)	38154-P6023
3.30 (0.1299)	38154-P6024
3.33 (0.1311)	38154-P6025
3.36 (0.1323)	38154-P6026
3.39 (0.1335)	38154-P6027
3.42 (0.1346)	38154-P6028
3.45 (0.1358)	38154-P6029
3.48 (0.1370)	38154-P6030
3.51 (0.1382)	38154-P6031
3.54 (0.1394)	38154-P6032
3.57 (0.1406)	38154-P6033
3.60 (0.1417)	38154-P6034
3.63 (0.1429)	38154-P6035
3.66 (0.1441)	38154-P6036

Total preload adjustment

Total preload	N·m (kg-cm, in-lb)	1.2 - 2.3 (12 - 23, 10 - 20)
Ring gear backlash	mm (in)	0.13 - 0.18 (0.0051 - 0.0071)

— Additional service for LSD model — (C200)

Differential torque adjustment

Differential torque	N·m (kg-m, ft-lb)	88 - 108 (9.0 - 11.0, 65 - 80)
Number of discs and plates		
Friction disc		12
Friction plate		12
Spring plate		2
Wear limit of plate and disc	mm (in)	0.1 (0.004)
Allowable warpage of friction disc and plate	mm (in)	0.08 (0.0031)

Available discs and plates

Part name	Thickness mm (in)	Part number
Friction disc	1.5 (0.059)	38433-C6002 (Standard type)
	1.6 (0.063)	38433-C6003 (Adjusting type)
Friction plate	1.5 (0.059)	38432-C6001
Spring plate	1.5 (0.059)	38435-C6011

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (H233B)

Ring gear runout

Ring gear runout limit	mm (in)	0.08 (0.0031)
------------------------	---------	---------------

Side gear adjustment

Side gear backlash (Clearance between side gear to differential case)	mm (in)	Less than 0.15 (0.0059)
--	---------	-------------------------

Available side gear thrust washers

Thickness mm (in)	Part number
1.75 (0.0689)	38424-T5000
1.80 (0.0709)	38424-T5001
1.85 (0.0728)	38424-T5002

— Additional service for LSD model —

Differential torque adjustment

Differential torque	N-m (kg-m, ft-lb)	201 - 240 (20.5 - 24.5, 148 - 177)
---------------------	-------------------	---------------------------------------

Number of discs and plates	
Friction disc	10
Friction plate	12
Spring disc	2
Spring plate	2

Wear limit of plate and disc	mm (in)	0.1 (0.004)
------------------------------	---------	-------------

Allowable warpage of friction disc and plate	mm (in)	0.08 (0.0031)
--	---------	---------------

Available discs and plates

Part name	Thickness mm (in)	Part number
Friction disc	1.48 - 1.52 (0.0583 - 0.0598)	38433-C6000 (Standard type)
	1.58 - 1.62 (0.0622 - 0.0638)	38433-C6001 (Adjusting type)
Friction plate	1.48 - 1.52 (0.0583 - 0.0598)	38432-C6000
Spring disc	1.48 - 1.52 (0.0583 - 0.0598)	38436-C6000
Spring plate	1.48 - 1.52 (0.0583 - 0.0598)	38435-C6010

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number
2.58 (0.1016)	38151-01J00
2.61 (0.1028)	38151-01J01
2.64 (0.1039)	38151-01J02
2.67 (0.1051)	38151-01J03
2.70 (0.1063)	38151-01J04
2.73 (0.1075)	38151-01J05
2.76 (0.1087)	38151-01J06
2.79 (0.1098)	38151-01J07
2.82 (0.1110)	38151-01J08
2.85 (0.1122)	38151-01J09
2.88 (0.1134)	38151-01J10
2.91 (0.1146)	38151-01J11
2.94 (0.1157)	38151-01J12
2.97 (0.1169)	38151-01J13
3.00 (0.1181)	38151-01J14
3.03 (0.1193)	38151-01J15
3.06 (0.1205)	38151-01J16
3.09 (0.1217)	38151-01J17
3.12 (0.1228)	38151-01J18
3.15 (0.1240)	38151-01J19
3.18 (0.1252)	38151-01J60
3.21 (0.1264)	38151-01J61
3.24 (0.1276)	38151-01J62
3.27 (0.1287)	38151-01J63
3.30 (0.1299)	38151-01J64
3.33 (0.1311)	38151-01J65
3.36 (0.1323)	38151-01J66
3.39 (0.1335)	38151-01J67
3.42 (0.1346)	38151-01J68
3.45 (0.1358)	38151-01J69
3.48 (0.1370)	38151-01J70
3.51 (0.1382)	38151-01J71
3.54 (0.1394)	38151-01J72
3.57 (0.1406)	38151-01J73
3.60 (0.1417)	38151-01J74
3.63 (0.1429)	38151-01J75
3.66 (0.1441)	38151-01J76

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive (Cont'd)

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Adjusting shim and spacer
Drive pinion preload N-m (kg-cm, in-lb)	
Without front oil seal	1.2 - 1.5 (12 - 15, 10 - 13)

Available drive pinion preload adjusting shims

Thickness mm (in)	Part number
2.31 (0.0909)	38125-82100
2.33 (0.0917)	38126-82100
2.35 (0.0925)	38127-82100
2.37 (0.0933)	38128-82100
2.39 (0.0941)	38129-82100
2.41 (0.0949)	38130-82100
2.43 (0.0957)	38131-82100
2.45 (0.0965)	38132-82100
2.47 (0.0972)	38133-82100
2.49 (0.0980)	38134-82100
2.51 (0.0988)	38135-82100
2.53 (0.0996)	38136-82100
2.55 (0.1004)	38137-82100
2.57 (0.1012)	38138-82100
2.59 (0.1020)	38139-82100

Available drive pinion preload adjusting spacers

Length mm (in)	Part number
4.50 (0.1772)	38165-76000
4.75 (0.1870)	38166-76000
5.00 (0.1969)	38167-76000
5.25 (0.2067)	38166-01J00
5.50 (0.2165)	38166-01J10

Total preload adjustment

Total preload N-m (kg-cm, in-lb)	1.7 - 2.5 (17 - 25, 15 - 22)
Ring gear backlash mm (in)	0.15 - 0.20 (0.0059 - 0.0079)
Side bearing adjusting method	Side adjuster

CI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX