

SECTION **INL**

INTERIOR LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

CONTENTS

<p>WITH POWER DOOR LOCKS</p> <p>BASIC INSPECTION 3</p> <p>DIAGNOSIS AND REPAIR WORKFLOW 3 Work Flow3</p> <p>FUNCTION DIAGNOSIS 6</p> <p>INTERIOR ROOM LAMP CONTROL SYSTEM 6</p> <p> System Diagram6</p> <p> System Description6</p> <p> Component Parts Location7</p> <p> Component Description8</p> <p>ILLUMINATION CONTROL SYSTEM 9</p> <p> System Diagram9</p> <p> System Description9</p> <p> Component Parts Location10</p> <p> Component Description10</p> <p>DIAGNOSIS SYSTEM (BCM)11</p> <p>COMMON ITEM11</p> <p> COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) 11</p> <p>INT LAMP11</p> <p> INT LAMP : CONSULT-III Function (BCM - INT LAMP) 12</p> <p>BATTERY SAVER13</p> <p> BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER) 13</p> <p>COMPONENT DIAGNOSIS15</p> <p>POWER SUPPLY AND GROUND CIRCUIT15</p> <p>BCM15</p> <p> BCM : Diagnosis Procedure 15</p>	<p>BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT16</p> <p> Description16</p> <p> Component Function Check16</p> <p> Diagnosis Procedure16</p> <p>INTERIOR ROOM LAMP CONTROL CIRCUIT ...18</p> <p> Description18</p> <p> Component Function Check18</p> <p> Diagnosis Procedure18</p> <p>CARGO LAMP CONTROL CIRCUIT20</p> <p> Description20</p> <p> Diagnosis Procedure20</p> <p> Component Inspection22</p> <p>IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT23</p> <p> Description23</p> <p> Component Function Check23</p> <p> Diagnosis Procedure23</p> <p>INTERIOR ROOM LAMP CONTROL SYSTEM ...25</p> <p> Wiring Diagram25</p> <p>ILLUMINATION37</p> <p> Wiring Diagram37</p> <p>ECU DIAGNOSIS47</p> <p>BCM (BODY CONTROL MODULE)47</p> <p> Reference Value47</p> <p> Terminal Layout50</p> <p> Physical Values51</p> <p> Wiring Diagram56</p> <p> DTC Inspection Priority Chart59</p> <p> DTC Index60</p> <p>SYMPTOM DIAGNOSIS62</p>
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

INTERIOR LIGHTING SYSTEM SYMPTOMS	62	COMPONENT DIAGNOSIS	79
Symptom Table	62	INTERIOR ROOM LAMP	79
PRECAUTION	63	Diagnosis Procedure	79
PRECAUTIONS	63	Component Inspection (Door Switch)	80
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	63	CARGO LAMP CONTROL CIRCUIT	81
General precautions for service operations	63	Description	81
ON-VEHICLE REPAIR	64	Diagnosis Procedure	81
INTERIOR ROOM LAMP	64	Component Inspection	83
Removal and Installation	64	INTERIOR ROOM LAMP	84
ILLUMINATION	67	Wiring Diagram	84
Removal and Installation	67	ILLUMINATION	92
SERVICE DATA AND SPECIFICATIONS (SDS)	68	Wiring Diagram	92
BULB SPECIFICATIONS	68	ECU DIAGNOSIS	102
Interior Lamp/Illumination	68	BCM (BODY CONTROL MODULE)	102
WITHOUT POWER DOOR LOCKS		Reference Value	102
BASIC INSPECTION	69	Terminal Layout	105
DIAGNOSIS AND REPAIR WORKFLOW	69	Physical Values	106
Work Flow	69	Wiring Diagram	111
FUNCTION DIAGNOSIS	72	DTC Inspection Priority Chart	114
INTERIOR ROOM LAMP	72	DTC Index	115
System Diagram	72	SYMPTOM DIAGNOSIS	117
System Description	72	INTERIOR LIGHTING SYSTEM SYMPTOMS ..	117
Component Parts Location	73	Symptom Table	117
Component Description	73	PRECAUTION	118
ILLUMINATION CONTROL SYSTEM	75	PRECAUTIONS	118
System Diagram	75	Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	118
System Description	75	General precautions for service operations	118
Component Parts Location	76	ON-VEHICLE REPAIR	119
Component Description	76	INTERIOR ROOM LAMP	119
DIAGNOSIS SYSTEM (BCM)	77	Removal and Installation	119
COMMON ITEM	77	ILLUMINATION	122
COMMON ITEM : CONSULT-III Function	77	Removal and Installation	122
INT LAMP	77	SERVICE DATA AND SPECIFICATIONS (SDS)	123
INT LAMP : CONSULT-III Function	77	BULB SPECIFICATIONS	123
		Interior Lamp/Illumination	123

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH POWER DOOR LOCKS]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004056533

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

JPLIA0089GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH POWER DOOR LOCKS]

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITH POWER DOOR LOCKS]

NO >> GO TO 11

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End

NO >> GO TO 3

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP CONTROL SYSTEM


< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

FUNCTION DIAGNOSIS

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram



System Description

INFOID:000000004056535

OUTLINE

- Front room/map lamp and room lamp 2nd row are controlled by the interior room lamp timer control function of the BCM.

- Cargo lamp is controlled by the cargo lamp control function of the BCM.

The timer control functions of the BCM activate based on inputs from the remote keyless entry receiver, the key cylinder lock/unlock switch, the door switches, the key switch and the power window and door lock/unlock switches.

ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in the DOOR position and when all conditions below are met, the BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF.

- When the front door LH is unlocked [with main power window and door lock/unlock switch, or front door lock assembly (key cylinder switch)].
- When a door opens → closes.

Timer control is cancelled under the following conditions.

- When the front door LH is locked [with main power window and door lock/unlock switch, or front door lock assembly (key cylinder switch)].
- A door is opened (door switch turns ON).

Interior lamp operational settings can be changed with the function setting of CONSULT-III.

INTERIOR LAMP BATTERY SAVER CONTROL

INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 30 minutes after the ignition switch is turned OFF. The BCM controls power and ground to all interior lamps.


After the battery saver system turns the lamps OFF, the lamps will illuminate again when

- a signal is received from a main power window and door lock/unlock switch, or when the front door LH lock assembly (key cylinder switch) is locked or unlocked
- a door is opened or closed

The interior lamp battery saver control time period can be changed with the function setting of CONSULT-III.

Component Parts Location

INFOID:000000004056536



- | | | |
|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| 1. BCM M18, M19, M20 (view with lower instrument panel LH removed) | 2. Key switch M27 | 3. Steering column assembly |
| 4. Front door switch LH B8 (crew cab)
Front door switch RH B108 (crew cab) | 5. Rear door switch LH B18 (crew cab)
Rear door switch RH B116 (crew cab) | 6. Front door switch LH D213 (king cab)
Front door switch RH D316 (king cab) |
| 7. Rear door switch upper LH D211 (king cab)
Rear door switch upper LH D312 (king cab) | 8. Rear door switch lower LH D212 (king cab)
Rear door switch lower LH D313 (king cab) | 9. Cargo lamp B161 |

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

INTERIOR ROOM LAMP CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

10. Room lamp 2nd row R10 11. Front room/map lamp assembly R9 12. Vanity lamp LH B80
Vanity lamp RH B81
13. Ignition keyhole illumination M150

Component Description

INFOID:000000004056537

Part name	Description
BCM	Provides power and ground and controls timer functions for the interior room lamps and cargo lamp.
Key switch	Provides key in ignition status to the BCM.
Door switches	Provides door OPEN/CLOSED status to the BCM.
Back door switch	Provides back door OPEN/CLOSED status to the BCM.
Main power window and door lock/unlock switch	Provides door lock/unlock position switch status to the BCM.
Power window and door lock/unlock switch RH	
Front door lock assembly LH (key cylinder switch)	Provides door lock/unlock status to the BCM.


ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

ILLUMINATION CONTROL SYSTEM

System Diagram



System Description

INFOID:000000004056539

The illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST or 2ND position the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate.

BATTERY SAVER CONTROL

When the lighting switch (combination switch) is in the 1ST or 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 30 minutes unless the lighting switch position is changed. If the lighting switch position is changed, then the illumination lamps are turned off after a 30 second delay. When the lighting switch is turned from OFF to 1ST or 2ND position after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL


ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Component Parts Location

INFOID:000000004056540



WKIA5029E

1. IPDM E/R E122, E124
2. Combination switch M28
3. Combination meter M24
4. Illumination control switch (built into combination meter)
5. BCM M18, M20 (view with lower instrument panel LH removed)

Component Description

INFOID:000000004056541

Part name	Description
BCM	The BCM monitors the lighting switch position with the combination switch reading function. The BCM requests, via CAN communication, that the IPDM E/R activate the tail lamp relay.
IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication network.
Combination meter (illumination control switch)	The illumination control switch is a part of the combination meter. The combination meter controls illumination intensity by varying ground to the illumination lamps based on the illumination control switch position.
Combination switch	The combination switch provides input to the BCM about the lighting switch position.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000004436189

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to INL-60, "DTC Index" .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none"> Enables to read and save the vehicle specification. Enables to write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
BCM	BCM	×		
Door lock	DOOR LOCK	×	×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER		×	×
Air conditioner	AIR CONDITONER		×	
Combination switch	COMB SW		×	
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Vehicle security system	THEFT ALM	×	×	×
RAP (retained accessory power)	RETAINED PWR	×	×	×
Signal buffer system	SIGNAL BUFFER		×	×
TPMS (tire pressure monitoring system)	AIR PRESSURE MONITOR	×	×	×
Panic alarm system	PANIC ALARM			×

INT LAMP

DIAGNOSIS SYSTEM (BCM)


< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

INT LAMP : CONSULT-III Function (BCM - INT LAMP)

INFOID:000000004436190

WORK SUPPORT



Work Item	Setting item	Setting	
SET I/L D-UNLCK INTCON	ON*	With the interior room lamp timer function	
	OFF	Without the interior room lamp timer function	
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual brightening time.
	MODE 2*	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	0 sec.	
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual dimming time.
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4*	3 sec.	
	MODE 5	0 sec.	

* : Initial setting

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch (ON) status judges from IGN signal (ignition power supply)
KEY ON SW [ON/OFF]	The switch status input from key switch
DOOR SW-DR [ON/OFF]	Indicates condition of front door switch (all) and rear door switch upper and lower (king cab) LH
DOOR SW-AS [ON/OFF]	Indicates condition of front door switch (all) and rear door switch upper and lower (king cab) RH
DOOR SW-RR [ON/OFF]	Indicates condition of rear door switch RH (crew cab)
DOOR SW- RL [ON/OFF]	Indicates condition of rear door switch LH (crew cab)
KEY CYL LK-SW [ON/OFF]	Lock switch status input from door lock and unlock switch
KEY CYL UN-SW [ON/OFF]	Lock switch status input from door lock and unlock switch
CDL LOCK SW [ON/OFF]	Lock switch status input from door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Unlock switch status input from door lock and unlock switch

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Monitor Item [Unit]	Description
KEYLESS LOCK [ON/OFF]	Lock signal status received from remote keyless entry receiver (integrated in the BCM)
KEYLESS UNLOCK [ON/OFF]	Unlock signal status received from remote keyless entry receiver (integrated in the BCM)

ACTIVE TEST

Test Item	Operation	Description
IGN ILLUM	ON	Outputs the ignition keyhole illumination control signal to turn the ignition keyhole illumination lamp ON.
	OFF	Stops the ignition keyhole illumination control signal to turn the ignition keyhole illumination lamp OFF.
INT LAMP	ON	Outputs the interior room lamp control signal to turn the interior room lamps ON.
	OFF	Stops the interior room lamp control signal to turn the interior room lamps OFF.
STEP LAMP TEST	—	This test is shown, not supported.
LUGGAGE LAMP TEST	—	This test is shown, not supported.

BATTERY SAVER

BATTERY SAVER : CONSULT-III Function (BCM - BATTERY SAVER)

INFOID:000000004436191

WORK SUPPORT

Work Item	Setting Item	Setting	
ROOM LAMP TIMER SET	MODE 1*	15 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	30 min.	

*: Initial setting

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch (ON) status judges from IGN signal (ignition power supply)
KEY ON SW [ON/OFF]	The switch status input from key switch
DOOR SW-DR [ON/OFF]	The switch status input from front door switch (driver side)
DOOR SW-AS [ON/OFF]	The switch status input from front door switch (passenger side)
DOOR SW-RR [ON/OFF]	The switch status input from rear door switch RH
DOOR SW- RL [ON/OFF]	The switch status input from rear door switch LH
BACK DOOR SW	NOTE: This is displayed even when it is not equipped
KEY CYL LK-SW [ON/OFF]	Lock switch status input from door key cylinder switch
KEY CYL UN-SW [ON/OFF]	Unlock switch status input from door key cylinder switch
CDL LOCK SW [ON/OFF]	Lock switch status input from door lock and unlock switch
CDL UNLOCK SW [ON/OFF]	Unlock switch status input from door lock and unlock switch
KEYLESS LOCK [ON/OFF]	Lock signal status received from remote keyless entry receiver (integrated in the BCM)
KEYLESS UNLOCK [ON/OFF]	Unlock signal status received from remote keyless entry receiver (integrated in the BCM)

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Test Item	Operation	Description
BATTERY SAVER	OFF	Cuts the interior room lamp power supply to turn interior room lamps OFF.
	ON	Outputs the interior room lamp power supply to turn interior room lamps ON.*

*: Each lamp switch is in ON position.

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000004436402

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	18 (10A)
70		G (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	1 (10A)

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM.
- Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Approx.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair or replace harness.



BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

Description

INFOID:000000004056546

Provides the battery saver output/power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

Component Function Check

INFOID:000000004056547

1.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY FUNCTION

CONSULT-III

1. Turn ignition switch ON.
2. Turn each interior room lamp ON.
 - Front room/map lamp assembly (if equipped)
 - Vanity lamps (if equipped)
 - Room lamp 2nd row
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. While operating the test item, check that each interior room lamp turns ON/OFF.

OFF : Interior room lamp OFF

ON : Interior room lamp ON

Is the inspection result normal?

YES >> Battery saver output/power supply circuit is normal.

NO >> Refer to [INL-16, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000004056548

1.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OUTPUT

CONSULT-III

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM connector M20 terminal 56 and ground.

(+)		(-)	Test item	Voltage
Connector	Terminal		BATTERY SAVER	
M20	56	Ground	OFF	0V
			ON	Battery voltage



Is the inspection result normal?

YES >> GO TO 2

NO >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).

2.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - BCM M20
 - Ignition keyhole illumination (if equipped)
 - Front room/map lamp assembly (if equipped)
 - Vanity lamp LH (if equipped)
 - Vanity lamp RH (if equipped)
 - Room lamp 2nd row
3. Check continuity between BCM connector and each interior room lamp connector.

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

BCM		Each interior room lamp			Continuity
Connector	Terminal	Connector	Terminal	Terminal	
M20	56	Ignition keyhole illumination (if equipped)	M150	1	Yes
		Front room/map lamp assembly (if equipped)	R9	1	
		Vanity lamp LH (if equipped)	B80	1	
		Vanity lamp RH (if equipped)	B81	1	
		Room lamp 2nd row	R10	2	

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair the harness or connectors.

3.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY SHORT CIRCUIT


Check continuity between BCM connector M20 terminal 56 and ground.

Connector	Terminal	—	Continuity
M20	56	Ground	No

Is the inspection result normal?

YES >> Replace the interior room lamp. Refer to [INL-64](#).
"Removal and Installation".

NO >> Repair the harness or connectors.



A
B
C
D
E
F
G
H
I
J
K

INL

M
N
O
P

INTERIOR ROOM LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:000000004056549

Controls the following interior room lamps (ground side) by PWM signal

- Front room/map lamp assembly (if equipped)
- Room lamp 2nd row

NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

Component Function Check

INFOID:000000004056550

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Front room/map lamp bulbs (if equipped)
- Room lamp 2nd row bulb

1. CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

CONSULT-III

1. Switch the front room/map lamp assembly (if equipped) and room lamp 2nd row switches to DOOR.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. While operating the test item, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

ON : Interior room lamp gradual brightening

OFF : Interior room lamp gradual dimming

Is the inspection result normal?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-18. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004056551

1. CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

CONSULT-III

1. Turn ignition switch ON.
2. Select "INT LAMP" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M20 terminal 63 and ground.

(+)		(-)	INT LAMP	Voltage
Connector	Terminal			
M20	63	Ground	ON	0V
			OFF	Battery voltage


Is the inspection result normal?

YES >> Interior room lamp control circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>> GO TO 2

2. CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT



ALLIA0410GB

INTERIOR ROOM LAMP CONTROL CIRCUIT

[WITH POWER DOOR LOCKS]


< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, room lamp 2nd row connector and front room/map lamp connector (if equipped).
3. Check continuity between BCM connector M20 terminal 63 and interior room lamp connectors.

Terminal		Terminal			Continuity
Connector	Terminal	Component	Connector	Terminal	
A: M20	63	Room lamp 2nd row	B: R10	1	Yes
		Front room/map lamp (if equipped)	C: R9	2	

Is the inspection result normal?

- YES** >> Check interior room lamp for an open. If OK, replace the BCM. Refer to [BCS-56, "Removal and Installation"](#). If NG, replace the interior room lamp. Refer to [INL-64, "Removal and Installation"](#).
- NO** >> Repair the harness or connectors.




3. CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M20, room lamp 2nd row connector and front room/map lamp connector (if equipped).
3. Check continuity between BCM connector M20 terminal 63 and ground.

Connector	Terminal	—	Continuity
M20	63	Ground	No

Is the inspection result normal?

- YES** >> Check interior room lamp for a short circuit. If OK, replace the BCM. Refer to [BCS-56, "Removal and Installation"](#). If NG, replace the interior room lamp. Refer to [INL-64, "Removal and Installation"](#).
- NO** >> Repair the harness or connectors.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

CARGO LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

CARGO LAMP CONTROL CIRCUIT

Description

INFOID:000000004056552

Controls the cargo lamp relay coil (ground side) to turn the cargo lamp ON and OFF.

Diagnosis Procedure

INFOID:000000004056553

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Fuse
- Cargo lamp bulb

1. CHECK CARGO LAMP OPERATION

Check the cargo lamp operation from the cargo lamp switch, the door switches, and a keyfob (if equipped).

Is the cargo lamp inoperative from all of the above switches and the keyfob (if equipped)?

YES >> GO TO 4

NO >> • Inoperative from cargo lamp switch only, GO TO 2

- Inoperative from door switches only, refer to [DLK-27, "KING CAB : Description"](#) (king cab), [DLK-29, "CREW CAB : Description"](#) (crew cab).
- Inoperative from keyfob only, refer to [DLK-50, "Description"](#).

2. CHECK CARGO LAMP SWITCH

Check the cargo lamp switch. Refer to [INL-22, "Component Inspection"](#).

Is the inspection result normal?


YES >> GO TO 3

NO >> Replace the cargo lamp switch.

3. CHECK CARGO LAMP SWITCH CIRCUIT

1. Disconnect BCM connector M18 and cargo lamp switch connector.
2. Check continuity between BCM connector M18 (A) terminal 31 and cargo lamp switch connector M71 (B) terminal 1.

BCM		Cargo lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
M18 (A)	31	M71 (B)	1	Yes



3. Check continuity between BCM connector M18 terminal 31 and ground.

Connector	Terminal	—	Continuity
M18 (A)	31	Ground	No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).

NO >> Repair harness or connectors.

4. CHECK CARGO LAMP RELAY

Check the cargo lamp relay. Refer to [INL-22, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace the cargo lamp relay.

5. CHECK CARGO LAMP RELAY CONTROL

CARGO LAMP CONTROL CIRCUIT

[WITH POWER DOOR LOCKS]

< COMPONENT DIAGNOSIS >


While operating the cargo lamp switch, check voltage between BCM connector M19 terminal 50 and ground.

Connector	Terminal	—	Cargo lamp switch	Voltage
M19	50	Ground	ON	0V
			OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 8



6.CHECK CARGO LAMP VOLTAGE


1. Disconnect the cargo lamp connector.
2. While operating the cargo lamp switch, check voltage between cargo lamp connector B161 terminal 3 and ground.

Connector	Terminal	—	Cargo lamp switch	Voltage
B161	3	Ground	ON	Battery voltage

Is the inspection result normal?

YES >> Replace cargo lamp.

NO >> GO TO 7



7.CHECK CARGO LAMP RELAY VOLTAGE PART 1


Check voltage between cargo lamp relay connector M165 terminal 5 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		
M165	5		Battery voltage

Is the inspection result normal?

YES >> Repair harness or connectors between cargo lamp relay and cargo lamp.

NO >> Repair harness or connector between splice and cargo lamp relay.



8.CHECK CARGO LAMP RELAY VOLTAGE PART 2


Check voltage between cargo lamp relay connector M165 terminal 2 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		
M165	2		Battery voltage

Is the inspection result normal?

YES >> GO TO 9

NO >> Repair harness or connectors.



9.CHECK CARGO LAMP RELAY CONTROL CIRCUIT


CARGO LAMP CONTROL CIRCUIT

[WITH POWER DOOR LOCKS]

< COMPONENT DIAGNOSIS >

1. Disconnect BCM connector M19 and cargo lamp relay connector.
2. Check continuity between BCM connector M19 (A) terminal 50 and cargo lamp relay connector M165 (B) terminal 1.

BCM		Cargo lamp relay		Continuity
Connector	Terminal	Connector	Terminal	
M19 (A)	50	M165 (B)	1	Yes



3. Check continuity between BCM connector M19 terminal 50 and ground.

Connector	Terminal	—	Continuity
M19 (A)	50	Ground	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).
 NO >> Repair harness or connectors.

Component Inspection

INFOID:000000004056554

CARGO LAMP SWITCH


1.CHECK CARGO LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect cargo lamp switch connector.
3. Check continuity between cargo lamp switch terminals.

Cargo lamp switch	Condition	Continuity
Terminal		
1 - 3	ON	Yes
	OFF	No

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace cargo lamp switch.



CARGO LAMP RELAY


1.CHECK CARGO LAMP RELAY

1. Turn ignition switch OFF.
2. Disconnect cargo lamp relay connector.
3. Supply power to terminal 2 and ground to terminal 1 of the cargo lamp relay.
4. Check continuity between cargo lamp relay terminals 3 and 5.

Terminal	Condition	Continuity
3 5		
3 5	Power and ground supplied to terminals 1 and 2	Yes
	No power and ground supplied	No

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace cargo lamp relay.



IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

Description

INFOID:000000004056555

Controls the ignition keyhole illumination (ground side) to turn the ignition keyhole illumination ON and OFF.

Component Function Check

INFOID:000000004056556

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply circuit
- Ignition keyhole illumination bulb

1. CHECK IGNITION KEYHOLE ILLUMINATION OPERATION

CONSULT-III

1. Turn the ignition switch ON.
2. Select "IGN ILLUM" of BCM (INT LAMP) active test item.
3. While operating the test item, check that the ignition keyhole illumination turns ON/OFF

ON : Ignition keyhole illumination ON

OFF : Ignition keyhole illumination OFF

Is the inspection result normal?

- YES >> Ignition keyhole illumination circuit is normal.
 NO >> Refer to [INL-23, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000004056557

1. CHECK IGNITION KEYHOLE OUTPUT

CONSULT-III

1. Turn ignition switch ON.
2. Select "IGN ILLUM" of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM connector M18 terminal 1 and ground.

Connector	Terminal	—	IGN ILLUM	Voltage
M18	1	Ground	ON	0V
			OFF	Battery voltage

Is the inspection result normal?


- YES >> Ignition keyhole illumination control circuit is operating normally.
 Fixed ON>>GO TO 3.
 Fixed OFF>> GO TO 2.

2. CHECK IGNITION KEYHOLE ILLUMINATION OPEN CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and ignition keyhole illumination connector.
3. Check continuity between BCM connector M18 (A) terminal 1 and ignition keyhole illumination connector M150 (B) terminal 2.

BCM		Ignition keyhole illumination		Continuity
Connector	Terminal	Connector	Terminal	
M18 (A)	1	M150 (B)	2	Yes

Is the inspection result normal?



ALLIA0420GB



WKIA5803E

IGNITION KEYHOLE ILLUMINATION CONTROL CIRCUIT

[WITH POWER DOOR LOCKS]

< COMPONENT DIAGNOSIS >

- YES >> Check the ignition keyhole illumination for an open. If OK, replace the BCM. Refer to [BCS-56. "Removal and Installation"](#). If NG, replace ignition keyhole illumination.
- NO >> Repair harness or connectors.


3. CHECK IGNITION KEYHOLE ILLUMINATION SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and ignition keyhole illumination connector.
3. Check continuity between BCM connector M18 terminal 1 and ground.

Connector	Terminal	—	Continuity
M18	1	Ground	No

Is the inspection result normal?

- YES >> Check the ignition keyhole illumination for a short circuit. If OK, replace the BCM. Refer to [BCS-56. "Removal and Installation"](#). If NG, replace ignition keyhole illumination.
- NO >> Repair harness or connectors.



INTERIOR ROOM LAMP CONTROL SYSTEM


< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:000000004056558




ABLWA0164GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]




ABLWA0165GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

-  : WITH FRONT MAP LAMPS
-  : WITH IGNITION KEY-HOLE ILLUMINATION
-  : WITH VANITY LAMPS



ABLWA0166GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P


INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]


INTERIOR ROOM LAMP CONNECTORS - WITH POWER DOOR LOCK SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	R/Y	-
20	B	-
21	BR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4N	R/Y	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
9	B	-

Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	GR	-
10	SB	-
11	LG	-
12	V	-


ABLIA0683GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	L	-
8	LG	-
12	G	-


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	KEY RING OUTPUT
7	GR	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)

Terminal No.	Color of Wire	Signal Name
18	BR	KEYLESS & AUTO LIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY OUTPUT
20	G	KEYLESS TUNER SIGNAL
31	GR	CARGO LAMP SW
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
45	V	CDL LOCK SW
46	LG	CDL UNLOCK SW
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
50	P	CARGO LAMP OUTPUT

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
56	V	BATTERY SAVER OUTPUT
57	R/Y	BAT (FUSE)
63	BR	ROOM LAMP OUTPUT
67	B	GND (POWER)
70	W	BAT (F/L)

Connector No.	M27
Connector Name	KEY SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	Y	-

ABLIA0621GB

A B C D E F G H I J K L M N O P




INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
55G	Y	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
60J	P	-
61J	GR	-
69J	R/Y	-

Connector No.	M71
Connector Name	CARGO LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
3	B	-

Connector No.	M74
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	LG	-
5	P	-

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	B	-


ABLIA0578GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Connector No.	M120
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	GND
2	G	SIGNAL
4	V	PWR

Connector No.	M150
Connector Name	IGNITION KEYHOLE ILLUMINATION
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	BR	-

Connector No.	M165
Connector Name	CARGO LAMP RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	R/Y	-
3	G	-
5	R/Y	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
55G	Y	-

ABLIA0579GB


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	-

Connector No.	B16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	-
8	GR	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-


Connector No.	B80
Connector Name	VANITY LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	B	-

Terminal No.	Color of Wire	Signal Name
60J	P	-
61J	GR	-
69J	R/Y	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA0580GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LG	-

Connector No.	B107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Connector No.	B81
Connector Name	VANITY LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	B	-

Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	L	-
8	LG	-
12	G	-

Connector No.	B161
Connector Name	HIGH MOUNTED STOP LAMP ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	G	-

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	-

ABLIA0622GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Connector No.	R10
Connector Name	ROOM LAMP 2ND ROW
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	-
2	R/Y	-

Connector No.	R9
Connector Name	FRONT ROOM/MP LAMP ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	Y	-
3	B	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/Y	-
20	B	-
21	BR	-

Connector No.	D7
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	LG	-
11	W	-
14	B	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
9	B	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/W	-
10	SB	-
11	W	-
12	LG	-


ABLIA0581GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	W	-
5	LG	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	B	-

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	R/W	-
4	B	-
5	SB	-

Connector No.	D212
Connector Name	REAR DOOR SWITCH LOWER LH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Connector No.	D211
Connector Name	REAR DOOR SWITCH UPPER LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

Connector No.	D105
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	W	-
3	B	-

ABLIA0582GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	D302
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Connector No.	D216
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	B	-
8	LG	-

Connector No.	D213
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LG	-
3	B	-

Connector No.	D314
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LG	-
3	B	-

Connector No.	D313
Connector Name	REAR DOOR SWITCH LOWER RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Connector No.	D312
Connector Name	REAR DOOR SWITCH UPPER RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

ABLIA0807GB

ILLUMINATION


< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

ILLUMINATION

Wiring Diagram

INFOID:000000004056559



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL


ABLWA0169GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

- <AC> : WITH A/C
- <BA> : WITH BASE AUDIO SYSTEM
- <CI> : WITH CLUTCH INTERLOCK CANCEL SWITCH
- <CC> : CREW CAB
- <DL> : WITH ELECTRONIC LOCKING REAR DIFFERENTIAL
- <FK> : WITH VBC
- <FN> : WITHOUT VBC
- <KC> : KING CAB
- <PA> : WITH PREMIUM AUDIO SYSTEM
- <PM> : WITH POWER OUTSIDE MIRRORS
- <4W> : WITH 4-WHEEL DRIVE



* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.


ABLWA0170GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

(A) : WITH A/T
 (HS) : WITH HEATED SEATS
 (WV) : WITH VDC




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ABLWA0171GB


ILLUMINATION CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8P	R/Y	-
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3

Terminal No.	Color of Wire	Signal Name
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
26	R	ILL+
27	G	ILL-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
22	BR	ILLUMINATION CONTROL
23	B	POWER GND


Connector No.	M43
Connector Name	AUDIO UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	GR	ILL CONT
9	R	LIGHT SW

Terminal No.	Color of Wire	Signal Name
62G	R	

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA0584GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	M55
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-
4	BR	-

Connector No.	M50
Connector Name	FRONT AIR CONTROL (WITH VBC)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	G	-
9	BR	-

Connector No.	M49
Connector Name	FRONT AIR CONTROL (WITHOUT VBC)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
8	G	-
9	BR	-

Connector No.	M65
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM, WITH CREW CAB)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	GR	ILL CONT
8	G	LIGHT SW

Connector No.	M64
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM, WITH KING CAB)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	GR	ILL CONT
8	G	LIGHT SW

Connector No.	M59
Connector Name	GLOVE BOX LAMP
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

ABLIA0585GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Connector No.	M71
Connector Name	CARGO LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	BR	-
4	R/Y	-

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GROUND
4	R	ILL (TAIL)

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	M102
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
18	R	-
21	G	-

Connector No.	M141
Connector Name	4WD SHIFT SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
7	R	LIGHT_SW
8	BR	GND

Connector No.	M149
Connector Name	DIFFERENTIAL LOCK MODE SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
5	BR	-

ABLIA0586GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


INL

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	M156
Connector Name	A/T DEVICE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-
5	BR	-

Connector No.	M155
Connector Name	HILL DESCENT CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	M154
Connector Name	VDC OFF SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	R	-
4	BR	-

Connector No.	M161
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	M160
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
5	SB	-
6	O	-

Connector No.	M159
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
15	BR	-
16	R	-


ABLIA0587GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M163
Connector Name	CLUTCH INTERLOCK CANCEL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
62G	R	-

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

ABLIA0588GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


INL

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITH POWER DOOR LOCKS]

Connector No.	R6
Connector Name	BLUETOOTH ON INDICATOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	DAY/NIGHT_ILL_SIG

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R	-

ABLIA0589GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000004436192

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
KEY ON SW	Mechanical key is removed from key cylinder	OFF
	Mechanical key is inserted to key cylinder	ON
CDL LOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the lock side	ON
CDL UNLOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the unlock side	ON
DOOR SW-DR	Driver's door closed	OFF
	Driver's door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear RH door closed	OFF
	Rear RH door opened	ON
DOOR SW-RL	Rear LH door closed	OFF
	Rear LH door opened	ON
BACK DOOR SW	NOTE: The item is indicated, but not monitored.	—
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF
	Driver door key cylinder LOCK position	ON
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF
	Driver door key cylinder UNLOCK position	ON
KEYLESS LOCK	"LOCK" button of key fob is not pressed	OFF
	"LOCK" button of key fob is pressed	ON
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	OFF
	"UNLOCK" button of key fob is pressed	ON
ACC ON SW	Ignition switch OFF	OFF
	Ignition switch ACC or ON	ON
REAR DEF SW	Rear window defogger switch OFF	OFF
	Rear window defogger switch ON	ON
LIGHT SW 1ST	Lighting switch OFF	OFF
	Lighting switch 1ST	ON
BUCKLE SW	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF]	OFF
	The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]	ON
KEYLESS PANIC	PANIC button of key fob is not pressed	OFF
	PANIC button of key fob is pressed	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
KEYLESS TRUNK	NOTE: The item is indicated, but not monitored.	OFF
TRNK OPN MNTR	NOTE: The item is indicated, but not monitored.	OFF
RKE LCK-UNLCK	LOCK/UNLOCK button of key fob is not pressed and held simultaneously	OFF
	LOCK/UNLOCK button of key fob is pressed and held simultaneously	ON
RKE KEEP UNLK	UNLOCK button of key fob is not pressed	OFF
	UNLOCK button of key fob is pressed and held	ON
HI BEAM SW	Lighting switch OFF	OFF
	Lighting switch HI	ON
HEAD LAMP SW 1	Lighting switch OFF	OFF
	Lighting switch 2ND	ON
HEAD LAMP SW 2	Lighting switch OFF	OFF
	Lighting switch 2ND	ON
AUTO LIGHT SW	Lighting switch OFF	OFF
	Lighting switch AUTO	ON
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
RR FOG SW	NOTE: The item is indicated, but not monitored.	OFF
TURN SIGNAL R	Turn signal switch OFF	OFF
	Turn signal switch RH	ON
TURN SIGNAL L	Turn signal switch OFF	OFF
	Turn signal switch LH	ON
CARGO LAMP SW	Cargo lamp switch OFF	OFF
	Cargo lamp switch ON	ON
OPTICAL SENSOR	Bright outside vehicle	5V
	Dark outside vehicle	0V
IGN SW CAN	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
FR WIPER HI	Front wiper switch OFF	OFF
	Front wiper switch HI	ON
FR WIPER LOW	Front wiper switch OFF	OFF
	Front wiper switch LO	ON
FR WIPER INT	Front wiper switch OFF	OFF
	Front wiper switch INT	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
FR WIPER STOP	Any position other than front wiper stop position	OFF
	Front wiper stop position	ON
VEHICLE SPEED	While driving	Equivalent to speedometer reading

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status	
RR WIPER ON	NOTE: The item is indicated, but not monitored.	OFF	A
RR WIPER INT	NOTE: The item is indicated, but not monitored.	OFF	B
RR WASHER SW	NOTE: The item is indicated, but not monitored.	OFF	C
RR WIPER STOP	NOTE: The item is indicated, but not monitored.	OFF	D
RR WIPER STP2	NOTE: The item is indicated, but not monitored.	OFF	D
H/L WASH SW	NOTE: The item is indicated, but not monitored.	OFF	E
HAZARD SW	Hazard switch OFF	OFF	E
	Hazard switch ON	ON	E
BRAKE SW	Brake pedal is not depressed	OFF	F
	Brake pedal is depressed	ON	F
FAN ON SIG	Blower fan motor switch OFF	OFF	G
	Blower fan motor switch ON (other than OFF)	ON	G
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	OFF	H
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	ON	H
TRNK OPNR SW	NOTE: The item is indicated, but not monitored.	OFF	I
TRUNK CYL SW	NOTE: The item is indicated, but not monitored.	OFF	J
HOOD SW	NOTE: The item is indicated, but not monitored.	OFF	J
OIL PRESS SW	<ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running 	OFF	K
	Ignition switch ON	ON	K
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	INL
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	INL
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	M
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	N
ID REGST FL1	ID of front LH tire transmitter is registered	DONE	O
	ID of front LH tire transmitter is not registered	YET	O
ID REGST FR1	ID of front RH tire transmitter is registered	DONE	O
	ID of front RH tire transmitter is not registered	YET	O
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE	P
	ID of rear RH tire transmitter is not registered	YET	P
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE	P
	ID of rear LH tire transmitter is not registered	YET	P
WARNING LAMP	Tire pressure indicator OFF	OFF	P
	Tire pressure indicator ON	ON	P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
BUZZER	Tire pressure warning alarm is not sounding	OFF
	Tire pressure warning alarm is sounding	ON

Terminal Layout

INFOID:000000004436193



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Physical Values

INFOID:000000004436194

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">SKIA5291E</p>
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">SKIA5292E</p>
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">SKIA5291E</p>
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	<p style="text-align: right;">SKIA5292E</p>
6	R	Combination switch input 1				
7	GR	Front door lock assembly LH (key cylinder switch) unlock	Input	OFF	ON (open, 2nd turn)	Momentary 1.5V
8	SB	Front door lock assembly LH (key cylinder switch) lock			On (open)	Momentary 1.5V
			OFF (closed)	0V		
9	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
12	LG	Front door switch RH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper RH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower RH (King Cab)				
13	L	Rear door switch RH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver (Ground)	Output	OFF	—	0V
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 <p style="text-align: right; font-size: small;">LIIA1893E</p>
20	G	Remote keyless entry receiver signal (Signal)	Input	OFF	Stand-by (keyfob buttons released)	 <p style="text-align: right; font-size: small;">LIIA1894E</p>
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 <p style="text-align: right; font-size: small;">LIIA1895E</p>
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
31	GR	Cargo lamp switch	Input	OFF	ON	0V
				OFF	OFF	Battery voltage
32	O	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
36	LG	Combination switch output 1				
37	B	Key switch	Input	OFF	Key inserted	Battery voltage
				OFF	Key removed	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
45	V	Lock switch	Input	OFF	ON (lock)	0V
				OFF	OFF	Battery voltage
46	LG	Unlock switch	Input	OFF	ON (unlock)	0V
				OFF	OFF	Battery voltage
47	GR	Front door switch LH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper LH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower LH (King Cab)				
48	P	Rear door switch LH (Crew Cab)	Input	OFF	ON (open)	0V
				OFF	OFF (closed)	Battery voltage





A
B
C
D
E
F
G
H
I
J
K
N
O
P

INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)	
				Ignition switch	Operation or condition		
50	P	Cargo lamp	Output	OFF	Any door open (ON)	0V	
					All doors closed (OFF)	Battery voltage	
51	G	Trailer turn signal (right)	Output	ON	Turn right ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
52	V	Trailer turn signal (left)	Output	ON	Turn left ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
56	V	Battery saver output	Output	OFF	30 minutes after ignition switch is turned OFF	0V	
				ON	—	Battery voltage	
57	R/Y	Battery power supply	Input	—	—	Battery voltage	
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more	
					When optical sensor is not illuminated	0.6V or less	
59	GR	Front door lock assembly LH (unlock)	Output	OFF	OFF (neutral)	0V	
					ON (unlock)	Battery voltage	
60	LG	Turn signal (left)	Output	ON	Turn left ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
61	G	Turn signal (right)	Output	ON	Turn right ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
63	BR	Interior room/map lamp	Output	OFF	Any door switch	ON (open)	0V
					OFF (closed)	Battery voltage	
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V	
					ON (lock)	Battery voltage	
66	L	Front door lock actuator RH, rear door lock actuators LH/RH (unlock)	Output	OFF	OFF (neutral)	0V	
					ON (unlock)	Battery voltage	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
67	B	Ground	Input	ON	—	0V
68	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	P	Power window power supply (BAT)	Output	OFF	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL


BCM (BODY CONTROL MODULE)

[WITH POWER DOOR LOCKS]

< ECU DIAGNOSIS >

Wiring Diagram

INFOID:000000004436195




ABMWA0116GI

BCM (BODY CONTROL MODULE)

[WITH POWER DOOR LOCKS]

< ECU DIAGNOSIS >



ABMWA0117GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

BCM (BODY CONTROL MODULE)

[WITH POWER DOOR LOCKS]

< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE) CONNECTORS

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
1	BR	KEY RING OUTPUT
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
7	GR	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
9	Y	RR DEFOGGER SW
10	-	-
11	G/B	ACC. SW
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
14	-	-
15	W	TPMS MODE TRIGGER SW
16	-	-
17	-	-
18	BR	KEYLESS & AUTO LIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY OUTPUT

Terminal No.	Color of Wire	Signal Name
20	G	KEYLESS TUNER SIGNAL
21	GR	IMMOBILIZER ANTENNA SIGNAL (CLOCK)
22	-	-
23	G	SECURITY INDICATOR OUTPUT
24	-	-
25	BR	IMMOBILIZER ANTENNA SIGNAL (RX, TX)
26	-	-
27	W	AIRCON SW
28	R	BLOWER FAN SW
29	G	HAZARD SW
30	-	-
31	GR	CARGO LAMP SW
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	V	CDL LOCK SW
46	LG	CDL UNLOCK SW
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
49	-	-
50	P	CARGO LAMP OUTPUT
51	G	TRAILER FLASHER OUTPUT (RIGHT)
52	V	TRAILER FLASHER OUTPUT (LEFT)
53	-	-
54	-	-
55	-	-

ABMIA0315GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3
11	O	WASH FR (-) RR (+)
12	B	GND
13	L	WASH FR (-) RR (-)
14	W	IGN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
56	V	BATTERY SAVER OUTPUT
57	R/Y	BAT (FUSE)
58	W	AUTO LIGHT SENSOR INPUT 2
59	GR	DOOR UNLOCK OUTPUT (DR)
60	LG	FLASHER OUTPUT (LEFT)
61	G	FLASHER OUTPUT (RIGHT)
62	-	-
63	BR	ROOM LAMP OUTPUT
64	-	-
65	V	DOOR LOCK OUTPUT (ALL)
66	L	DOOR UNLOCK OUTPUT (OTHER)
67	B	GND (POWER)
68	O	POWER WINDOW POWER SUPPLY OUTPUT (LINKED TO RAP)
69	P	POWER WINDOW POWER SUPPLY OUTPUT (BAT)
70	W	BAT (F/L)



ABMLA0316GB

INFOID:000000004436196

DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

Priority	DTC
1	<ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> B2190: NATS ANTENNA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM
3	<ul style="list-style-type: none"> C1729: VHCL SPEED SIG ERR C1735: IGNITION SIGNAL
4	<ul style="list-style-type: none"> C1704: LOW PRESSURE FL C1705: LOW PRESSURE FR C1706: LOW PRESSURE RR C1707: LOW PRESSURE RL C1708: [NO DATA] FL C1709: [NO DATA] FR C1710: [NO DATA] RR C1711: [NO DATA] RL C1712: [CHECKSUM ERR] FL C1713: [CHECKSUM ERR] FR C1714: [CHECKSUM ERR] RR C1715: [CHECKSUM ERR] RL C1716: [PRESSDATA ERR] FL C1717: [PRESSDATA ERR] FR C1718: [PRESSDATA ERR] RR C1719: [PRESSDATA ERR] RL C1720: [CODE ERR] FL C1721: [CODE ERR] FR C1722: [CODE ERR] RR C1723: [CODE ERR] RL C1724: [BATT VOLT LOW] FL C1725: [BATT VOLT LOW] FR C1726: [BATT VOLT LOW] RR C1727: [BATT VOLT LOW] RL

DTC Index

INFOID:000000004436197

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	BCS-30
U1010: CONTROL UNIT (CAN)	—	—	BCS-31
B2190: NATS ANTENNA AMP	—	—	SEC-18
B2191: DIFFERENCE OF KEY	—	—	SEC-21
B2192: ID DISCORD BCM-ECM	—	—	SEC-22
B2193: CHAIN OF BCM-ECM	—	—	SEC-24
C1708: [NO DATA] FL	—	—	WT-14

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITH POWER DOOR LOCKS]

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
C1709: [NO DATA] FR	—	—	WT-14
C1710: [NO DATA] RR	—	—	WT-14
C1711: [NO DATA] RL	—	—	WT-14
C1712: [CHECKSUM ERR] FL	—	—	WT-16
C1713: [CHECKSUM ERR] FR	—	—	WT-16
C1714: [CHECKSUM ERR] RR	—	—	WT-16
C1715: [CHECKSUM ERR] RL	—	—	WT-16
C1716: [PRESSDATA ERR] FL	—	—	WT-18
C1717: [PRESSDATA ERR] FR	—	—	WT-18
C1718: [PRESSDATA ERR] RR	—	—	WT-18
C1719: [PRESSDATA ERR] RL	—	—	WT-18
C1720: [CODE ERR] FL	—	—	WT-16
C1721: [CODE ERR] FR	—	—	WT-16
C1722: [CODE ERR] RR	—	—	WT-16
C1723: [CODE ERR] RL	—	—	WT-16
C1724: [BATT VOLT LOW] FL	—	—	WT-16
C1725: [BATT VOLT LOW] FR	—	—	WT-16
C1726: [BATT VOLT LOW] RR	—	—	WT-16
C1727: [BATT VOLT LOW] RL	—	—	WT-16
C1729: VHCL SPEED SIG ERR	—	—	WT-19
C1735: IGNITION SIGNAL	—	—	—

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

INL

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[WITH POWER DOOR LOCKS]

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000004056566

CAUTION:

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All of the following lamps do not turn ON <ul style="list-style-type: none"> • Front room/map lamp assembly (if equipped) • Room lamp 2nd row • Vanity mirror lamps (if equipped) • Ignition keyhole illumination (if equipped) 	<ul style="list-style-type: none"> • Harness between BCM and each interior room lamp • Harness between BCM and each door switch • BCM 	Battery saver output/power supply circuit Refer to INL-16 .
Some or all of the following interior room lamps do not turn ON/OFF <ul style="list-style-type: none"> • Front room/map lamp assembly (if equipped) • Room lamp 2nd row 	<ul style="list-style-type: none"> • Harness between BCM and each interior room lamp • BCM 	Interior room lamp control circuit Refer to INL-18 .
Cargo lamp does not turn ON/OFF	<ul style="list-style-type: none"> • Harness between fuse block (J/B) and cargo lamp relay • Harness between cargo lamp relay and cargo lamp • Harness between BCM and cargo lamp relay • BCM 	Cargo lamp control circuit Refer to INL-20 .
Ignition keyhole illumination does not turn ON/OFF	<ul style="list-style-type: none"> • Harness between BCM and ignition keyhole illumination • BCM 	Ignition keyhole illumination circuit Refer to INL-23
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-12 .
Interior room lamp battery saver does not activate.	—	Check the interior room lamp battery saver setting. Refer to INL-13 .

PRECAUTION

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004056567

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

General precautions for service operations

INFOID:000000004056568

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts which may get in the way with cloth.
- When removing parts with a screw driver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If a non-reuseable part is removed, replace it with a new one.
- After re-assembly has been completed, make sure each part functions correctly.
- Never work with wet hands.
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps or remove sealant residue.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

INL

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

[WITH POWER DOOR LOCKS]

ON-VEHICLE REPAIR

INTERIOR ROOM LAMP

Removal and Installation

INFOID:000000004056569


MAP LAMP

Removal

The map lamp is replaced as part of the overhead console assembly. Refer to [INT-23, "Removal and Installation"](#).

⇐: Vehicle front

[]: Metal clip



Installation

Installation is in the reverse order of removal.

Bulb Replacement


1. Disconnect the negative battery terminal.
2. Using a suitable tool (A), remove map lamp lens (1).
⇐: Vehicle front

CAUTION:

Wrap a cloth around tool to protect the housing and lens.

3. Release one side of the bulb (2) from the tab, then pull straight downward to remove.

Map lamp bulb : 12V - 8W



VANITY MIRROR LAMP


Removal

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

[WITH POWER DOOR LOCKS]

The vanity mirror lamp is replaced as part of the sunvisor assembly. Refer to [INT-23, "Removal and Installation"](#).



Installation

Installation is in the reverse order of removal.

Bulb Replacement


The vanity mirror lamp bulb is replaced as part of the sunvisor assembly. Refer to [INT-23, "Removal and Installation"](#).

GLOVE BOX LAMP

Removal

1. Remove lower instrument panel RH and glove box. Refer to [IP-11, "Removal and Installation"](#).
2. Rotate glove box lamp socket (3) with bulb (1) counterclockwise, then pull away from lamp shield (2) on steering member to remove.

⇐: Vehicle front




Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery terminal.
2. Remove glove box lamp.
3. Pull bulb (2) straight out from glove box lamp socket (1) to remove.

Glove box lamp bulb : 12V - 3.4W



ROOM LAMP

Removal


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

[WITH POWER DOOR LOCKS]

1. Disconnect the negative battery terminal.
2. Using a suitable tool (A), release the pawls and remove the room lamp lens (1).
- CAUTION:**
Wrap a cloth around tool to protect the housing and lens.
3. Remove room lamp screws (2).
4. Disconnect the connector, then remove room lamp.



Installation


Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery terminal.
2. Using a suitable tool, release the pawls and remove the room lamp lens.
3. Release the room lamp bulb retainers (1), then pull bulb (2) straight out to remove.

Room lamp bulb

: 12V - 8W



ILLUMINATION


Removal and Installation

INFOID:000000004056570

ILLUMINATION CONTROL SWITCH

Removal

The illumination control switch is replaced as a part of the combination meter assembly. Refer to [MWI-93, "Removal and Installation"](#).




Installation

Installation is in the reverse order of removal.

A/T FINISHER LAMP

Removal

1. Remove A/T finisher from center console. Refer to [IP-17, "Exploded View"](#).
2. Rotate A/T finisher lamp socket (2) with bulb (3) counterclockwise, then pull away from finisher (1).




Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Remove A/T finisher from center console. Refer to [IP-17, "Exploded View"](#).
2. Remove A/T finisher lamp socket (1), then pull bulb (2) straight out away from socket.

AT finisher lamp bulb : 12V - 3W



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

[WITH POWER DOOR LOCKS]

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Interior Lamp/Illumination

INFOID:000000004056571

Item	Wattage (W)*
Map lamp	8
Vanity lamp	*
Glove box lamp	3.4
Room lamp	8
A/T finisher lamp	3

*: Always check with the Parts Department for the latest parts information.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT POWER DOOR LOCKS]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004056572

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT POWER DOOR LOCKS]

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Verified that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT POWER DOOR LOCKS]

NO >> GO TO 11

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End

NO >> GO TO 3

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

FUNCTION DIAGNOSIS

INTERIOR ROOM LAMP

System Diagram

INFOID:000000004056573



AWLIA0817GB

System Description

INFOID:000000004056574

OUTLINE

- Front room/map lamp (if equipped) and room lamp 2nd row are powered by fuse block (J/B) fuse number 18 (10A). When the lamps are set to the DOOR position, ground is provided through the door switches.
- Cargo lamp is controlled by the cargo lamp control function of the BCM.


INTERIOR ROOM LAMP

< FUNCTION DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Component Parts Location

INFOID:000000004056575



- | | | |
|-------------------------------------------------------------------------------|------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| 1. BCM M18, M19, M20 (view with lower instrument panel LH removed) | 2. Key switch M27 | 3. Steering column assembly |
| 4. Front door switch LH B8 (crew cab)
Front door switch RH B108 (crew cab) | 5. Rear door switch LH B18 (crew cab)
Rear door switch RH B116 (crew cab) | 6. Front door switch LH D213 (king cab)
Front door switch RH D314 (king cab) |
| 7. Cargo lamp B161 | 8. Room lamp 2nd row R10 | 9. Front room/map lamp assembly (with front map lamps) R9 |

Component Description

INFOID:000000004056576

Part name	Description
BCM	Provides ground for the cargo lamp relay.

INTERIOR ROOM LAMP

< FUNCTION DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Key switch	Provides key in ignition status to the BCM.
Door switches	Provides door OPEN/CLOSED status to the BCM. Provides ground for the room lamp 2nd row and front room/map lamp assembly (with front map lamps).


ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

ILLUMINATION CONTROL SYSTEM

System Diagram



System Description

INFOID:000000004056578

The illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST or 2ND position the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate.

BATTERY SAVER CONTROL

When the lighting switch (combination switch) is in the 1ST or 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 30 minutes unless the lighting switch position is changed. If the lighting switch position is changed, then the illumination lamps are turned off after a 30 second delay. When the lighting switch is turned from OFF to 1ST or 2ND position after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL


ILLUMINATION CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Component Parts Location

INFOID:000000004056579



WKIA5029E

1. IPDM E/R E122, E124
2. Combination switch M28
3. Combination meter M24
4. Illumination control switch (built into combination meter)
5. BCM M18, M20 (view with lower instrument panel LH removed)

Component Description

INFOID:000000004056580

Part name	Description
BCM	The BCM monitors the lighting switch position with the combination switch reading function. The BCM requests, via CAN communication, that the IPDM E/R activate the tail lamp relay.
IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication network.
Combination meter (illumination control switch)	The illumination control switch is a part of the combination meter. The combination meter controls illumination intensity by varying ground to the illumination lamps based on the illumination control switch position.
Combination switch	The combination switch provides input to the BCM about the lighting switch position.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function

INFOID:000000004056581

CONSULT-III can display each diagnostic item using the following diagnostic test modes.


Diagnostic mode	Description
Work Support	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
Data Monitor	Displays BCM input/output data in real time.
Active Test	Operation of electrical loads can be checked by sending drive signal to them.
Self-Diagnostic Results	Displays BCM self-diagnosis results.
CAN Diag Support Monitor	The result of transmit/receive diagnosis of CAN communication can be read.
ECU Identification	BCM part number can be read.
Configuration	Performs BCM configuration read/write functions.

INT LAMP

INT LAMP : CONSULT-III Function

INFOID:000000004056582

WORK SUPPORT



Service item	Setting item	Setting	
SET I/L D-UNLCK INTCON	ON	This item is not used for this model	
	OFF		
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.	
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	This item is not used for this model
	MODE 5	4 sec.	
	MODE 6	5 sec.	
	MODE 7	0 sec.	

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Service item	Setting item	Setting	
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.	This item is not used for this model
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	4 sec.	
	MODE 6	5 sec.	
	MODE 7	0 sec.	

DATA MONITOR

Monitor item [Unit]	Description
IGN ON SW [ON/OFF]	The switch status input from ignition switch
KEY ON SW [ON/OFF]	Key switch status input from key slot
DOOR SW-DR [ON/OFF]	The switch status input from front door switch LH
DOOR SW-AS [ON/OFF]	The switch status input from front door switch RH
DOOR SW-RR [ON/OFF]	The switch status input from rear door switch RH
DOOR SW- RL [ON/OFF]	The switch status input from rear door switch LH
BACK DOOR SW [ON/OFF]	This item is not used for this model
KEY CYL LK-SW [ON/OFF]	This item is not used for this model
KEY CYL UN-SW [ON/OFF]	This item is not used for this model
CDL LOCK SW [ON/OFF]	This item is not used for this model
CDL UNLOCK SW [ON/OFF]	This item is not used for this model
KEYLESS LOCK [ON/OFF]	This item is not used for this model
KEYLESS UNLOCK [ON/OFF]	This item is not used for this model

ACTIVE TEST

Test item	Operation	Description
INT LAMP	ON	This item is not used for this model
	OFF	
IGN ILLUM	ON	This item is not used for this model
	OFF	
LUGGAGE LAMP TEST	ON	This item is not used for this model
	OFF	

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

COMPONENT DIAGNOSIS

INTERIOR ROOM LAMP

Diagnosis Procedure

INFOID:000000004056583

CAUTION:


Before performing the diagnosis, check that the following is normal.

- Fuse
- Interior room lamp bulbs

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY

Check voltage between interior room lamp connectors and ground.

Component	(+)		(-)	Voltage
	Connector	Terminal		
Front room/map lamp (if equipped)	R9 (A)	1	Ground	Battery voltage
Room lamp 2nd row	R10 (B)	2		




Is the inspection result normal?

- YES >> GO TO 2
- NO >> Repair the harness or connectors.

2. CHECK INTERIOR ROOM LAMP GROUND

1. Disconnect interior room lamp connectors.
2. Check continuity between interior room lamp connectors and ground while operating the door switches.

Component	(+)		(-)	Door switches	Continuity
	Connector	Terminal			
Front room/map lamp (if equipped)	R9 (A)	2	Ground	Open	Yes
				Closed	No
Room lamp 2nd row	R10 (B)	1		Open	Yes
				Closed	No



Is the inspection result normal?

- YES >> Replace the interior room lamp. Refer to [INL-119, "Removal and Installation"](#).
- NO >> GO TO 3

3. CHECK DOOR SWITCHES

Check the door switches. Refer to [INL-80, "Component Inspection \(Door Switch\)"](#).

Is the inspection result normal?

- YES >>
 - Crew cab models, repair the harness or connectors between the interior room lamp and the door switches.
 - King cab models, GO TO 4
- NO >> Replace the door switch.

4. CHECK DOOR SWITCH GROUND (KING CAB)

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Check continuity between door switch connectors and ground.

Component	(+)		(-)	Continuity
	Connector	Terminal		
Front door switch LH	D213	3	Ground	Yes
Front door switch RH	D314	3		

Is the inspection result normal?

- YES >> Repair the harness or connectors between the interior room lamp and the door switches.
 NO >> Repair the harness or connectors between the door switch and ground.



Component Inspection (Door Switch)

INFOID:000000004437741

CREW CAB


1. CHECK DOOR SWITCHES

1. Disconnect door switch.
2. Check continuity between door switch terminals.

	Terminal	Condition	Continuity
Door switch	1 – Ground	Open	Yes
		Closed	No

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace door switch.



KING CAB


1. CHECK DOOR SWITCHES

1. Disconnect door switch.
2. Check continuity between door switch terminals.

Item	Terminal	Condition	Continuity
Door switches	1 – 3	Open	Yes
		Closed	No

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace door switch.



CARGO LAMP CONTROL CIRCUIT

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

CARGO LAMP CONTROL CIRCUIT

Description

INFOID:000000004437738

Controls the cargo lamp relay coil (ground side) to turn the cargo lamp ON and OFF.

Diagnosis Procedure

INFOID:000000004437739

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Fuse
- Cargo lamp bulb

1. CHECK CARGO LAMP OPERATION

Check the cargo lamp operation from the cargo lamp switch and the door switches.

Is the cargo lamp inoperative from all of the above switches?

YES >> GO TO 4

NO >> • Inoperative from cargo lamp switch only, GO TO 2

- Inoperative from door switches only, refer to [DLK-27, "KING CAB : Description"](#) (king cab), [DLK-29, "CREW CAB : Description"](#) (crew cab).

2. CHECK CARGO LAMP SWITCH

Check the cargo lamp switch. Refer to [INL-83, "Component Inspection"](#).


Is the inspection result normal?

YES >> GO TO 3

NO >> Replace the cargo lamp switch.

3. CHECK CARGO LAMP SWITCH CIRCUIT

1. Disconnect BCM connector M18 and cargo lamp switch connector.
2. Check continuity between BCM connector M18 (A) terminal 31 and cargo lamp switch connector M71 (B) terminal 1.



BCM		Cargo lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
M18 (A)	31	M71 (B)	1	Yes

3. Check continuity between BCM connector M18 terminal 31 and ground.

Connector	Terminal	—	Continuity
M18 (A)	31	Ground	No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).

NO >> Repair harness or connectors.

4. CHECK CARGO LAMP RELAY

Check the cargo lamp relay. Refer to [INL-83, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace the cargo lamp relay.

5. CHECK CARGO LAMP RELAY CONTROL

CARGO LAMP CONTROL CIRCUIT

[WITHOUT POWER DOOR LOCKS]

< COMPONENT DIAGNOSIS >

While operating the cargo lamp switch, check voltage between BCM connector M19 terminal 50 and ground.

Connector	Terminal	—	Cargo lamp switch	Voltage
M19	50	Ground	ON	0V
			OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 8

6.CHECK CARGO LAMP VOLTAGE

1. Disconnect the cargo lamp connector.
2. While operating the cargo lamp switch, check voltage between cargo lamp connector B161 terminal 3 and ground.

Connector	Terminal	—	Cargo lamp switch	Voltage
B161	3	Ground	ON	Battery voltage

Is the inspection result normal?

YES >> Replace cargo lamp.

NO >> GO TO 7

7.CHECK CARGO LAMP RELAY VOLTAGE PART 1

Check voltage between cargo lamp relay connector M165 terminal 5 and ground.

Cargo lamp relay		Ground	Voltage
Connector	Terminal		Battery voltage
M165	5		

Is the inspection result normal?

YES >> Repair harness or connectors between cargo lamp relay and cargo lamp.

NO >> Repair harness or connector between splice and cargo lamp relay.

8.CHECK CARGO LAMP RELAY VOLTAGE PART 2

Check voltage between cargo lamp relay connector M165 terminal 2 and ground.





Cargo lamp relay		Ground	Voltage
Connector	Terminal		Battery voltage
M165	2		

Is the inspection result normal?

YES >> GO TO 9

NO >> Repair harness or connectors.

9.CHECK CARGO LAMP RELAY CONTROL CIRCUIT




CARGO LAMP CONTROL CIRCUIT

[WITHOUT POWER DOOR LOCKS]

< COMPONENT DIAGNOSIS >

1. Disconnect BCM connector M19 and cargo lamp relay connector.
2. Check continuity between BCM connector M19 (A) terminal 50 and cargo lamp relay connector M165 (B) terminal 1.

BCM		Cargo lamp relay		Continuity
Connector	Terminal	Connector	Terminal	
M19 (A)	50	M165 (B)	1	Yes



3. Check continuity between BCM connector M19 terminal 50 and ground.

Connector	Terminal	—	Continuity
M19 (A)	50	Ground	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).
 NO >> Repair harness or connectors.

Component Inspection

INFOID:000000004437740

CARGO LAMP SWITCH


1.CHECK CARGO LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect cargo lamp switch connector.
3. Check continuity between cargo lamp switch terminals.

Cargo lamp switch	Condition	Continuity
Terminal		
1 – 3	ON	Yes
	OFF	No

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace cargo lamp switch.



CARGO LAMP RELAY


1.CHECK CARGO LAMP RELAY

1. Turn ignition switch OFF.
2. Disconnect cargo lamp relay connector.
3. Supply power to terminal 2 and ground to terminal 1 of the cargo lamp relay.
4. Check continuity between cargo lamp relay terminals 3 and 5.

Terminal	Condition	Continuity
3 5	Power and ground supplied to terminals 1 and 2	Yes
	No power and ground supplied	No

Is the inspection result normal?

- YES >> Inspection End
 NO >> Replace cargo lamp relay.



INTERIOR ROOM LAMP


< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

INTERIOR ROOM LAMP

Wiring Diagram

INFOID:000000004056590




ABLWA0167GB

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

◊ CC : CREW CAB
 ◊ FM : WITH FRONT MAP LAMPS
 ◊ KC : KING CAB



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ABLWA0168GB


INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]


INTERIOR ROOM LAMP CONNECTORS - WITHOUT POWER DOOR LOCK SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/Y	-
20	B	-
21	BR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4N	R/Y	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-
7	L	-
8	LG	-
12	G	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
31	GR	CARGO LAMP SW
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

ABLIA0684GB

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
50	P	CARGO LAMP OUTPUT

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
57	R/Y	BAT (FUSE)
67	B	GND (POWER)
70	W	BAT (F/L)

Connector No.	M27
Connector Name	KEY SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	Y	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
55G	Y	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
54J	V	-
55J	R	-
60J	P	-
61J	GR	-

Connector No.	M71
Connector Name	CARGO LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	B	-

ABLIA0645GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M165
Connector Name	CARGO LAMP RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	R/Y	-
3	G	-
5	R/Y	-

Connector No.	M139
Connector Name	DIODE-6
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	BR	-


Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	GR	-

Terminal No.	55G	Color of Wire	Y	Signal Name	-
--------------	-----	---------------	---	-------------	---

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA0646GB

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL



ABLIA0647GB

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >



[WITHOUT POWER DOOR LOCKS]

Connector No.	B161
Connector Name	HIGH MOUNTED STOP LAMP ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	G	-

Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-
7	L	-
8	LG	-
12	G	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	R/Y	-
20	B	-
21	BR	-

Connector No.	R9
Connector Name	FRONT ROOM/MP LAMP ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	-
2	Y	-
3	B	-

Connector No.	R10
Connector Name	ROOM LAMP 2ND ROW
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	BR	-
2	R/Y	-

Connector No.	D213
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-
3	B	-


ABLIA0576GB

INTERIOR ROOM LAMP

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Connector No.	D314
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	LG	-
3	B	-

Connector No.	D302
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-
7	B	-
8	LG	-

Connector No.	D216
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	L	-
7	B	-
8	LG	-

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ABLIA0577GB

ILLUMINATION


< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

ILLUMINATION

Wiring Diagram

INFOID:000000004056591




ABLWA0169GB

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

- <AC> : WITH AC
- <BA> : WITH BASE AUDIO SYSTEM
- <CI> : WITH CLUTCH INTERLOCK CANCEL SWITCH
- <CC> : CREW CAB
- <DL> : WITH ELECTRONIC LOCKING REAR DIFFERENTIAL
- <FK> : WITH VBC
- <FN> : WITHOUT VBC
- <KC> : KING CAB
- <PA> : WITH PREMIUM AUDIO SYSTEM
- <PM> : WITH POWER OUTSIDE MIRRORS
- <4W> : WITH 4-WHEEL DRIVE



* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABLWA0170GB


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]


A : WITH A/T
 HS : WITH HEATED SEATS
 WV : WITH VDC



ABLWA0171GB


ILLUMINATION CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8P	R/Y	-
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3

Terminal No.	Color of Wire	Signal Name
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)


ABLIA0583GB

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
26	R	ILL+
27	G	ILL-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
22	BR	ILLUMINATION CONTROL
23	B	POWER GND


Connector No.	M43
Connector Name	AUDIO UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	GR	ILL CONT
9	R	LIGHT SW

Terminal No.	62G	Color of Wire	R	Signal Name
--------------	-----	---------------	---	-------------

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA0584GB

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Connector No.	M55
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-
4	BR	-

Connector No.	M50
Connector Name	FRONT AIR CONTROL (WITH VBC)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	G	-
9	BR	-

Connector No.	M49
Connector Name	FRONT AIR CONTROL (WITHOUT VBC)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
8	G	-
9	BR	-

Connector No.	M65
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM, WITH CREW CAB)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	GR	ILL CONT
8	G	LIGHT SW

Connector No.	M64
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM, WITH KING CAB)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	GR	ILL CONT
8	G	LIGHT SW

Connector No.	M59
Connector Name	GLOVE BOX LAMP
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

ABLIA0585GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M71
Connector Name	CARGO LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	BR	-
4	R/Y	-

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GROUND
4	R	ILL (TAIL)

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	M102
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
18	R	-
21	G	-

Connector No.	M141
Connector Name	4WD SHIFT SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
7	R	LIGHT_SW
8	BR	GND

Connector No.	M149
Connector Name	DIFFERENTIAL LOCK MODE SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
5	BR	-


ABLIA0586GB

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Connector No.	M156
Connector Name	A/T DEVICE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-
5	BR	-

Connector No.	M155
Connector Name	HILL DESCENT CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	M154
Connector Name	VDC OFF SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	R	-
4	BR	-

Connector No.	M161
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	M160
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
5	SB	-
6	O	-

Connector No.	M159
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
15	BR	-
16	R	-

ABLIA0587GB


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< COMPONENT DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M163
Connector Name	CLUTCH INTERLOCK CANCEL SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	BR	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
62G	R	-


ABLIA0588GB

ILLUMINATION

< COMPONENT DIAGNOSIS >


[WITHOUT POWER DOOR LOCKS]

Connector No.	R6
Connector Name	BLUETOOTH ON INDICATOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	DAY/NIGHT_ILL_SIG

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R	-

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ABLIA0589GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000004448843

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
KEY ON SW	Mechanical key is removed from key cylinder	OFF
	Mechanical key is inserted to key cylinder	ON
CDL LOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the lock side	ON
CDL UNLOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the unlock side	ON
DOOR SW-DR	Driver's door closed	OFF
	Driver's door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear RH door closed	OFF
	Rear RH door opened	ON
DOOR SW-RL	Rear LH door closed	OFF
	Rear LH door opened	ON
BACK DOOR SW	NOTE: The item is indicated, but not monitored.	—
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF
	Driver door key cylinder LOCK position	ON
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF
	Driver door key cylinder UNLOCK position	ON
KEYLESS LOCK	"LOCK" button of key fob is not pressed	OFF
	"LOCK" button of key fob is pressed	ON
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	OFF
	"UNLOCK" button of key fob is pressed	ON
ACC ON SW	Ignition switch OFF	OFF
	Ignition switch ACC or ON	ON
REAR DEF SW	Rear window defogger switch OFF	OFF
	Rear window defogger switch ON	ON
LIGHT SW 1ST	Lighting switch OFF	OFF
	Lighting switch 1ST	ON
BUCKLE SW	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF]	OFF
	The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]	ON
KEYLESS PANIC	PANIC button of key fob is not pressed	OFF
	PANIC button of key fob is pressed	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status	
KEYLESS TRUNK	NOTE: The item is indicated, but not monitored.	OFF	A
TRNK OPN MNTR	NOTE: The item is indicated, but not monitored.	OFF	B
RKE LCK-UNLCK	LOCK/UNLOCK button of key fob is not pressed and held simultaneously	OFF	C
	LOCK/UNLOCK button of key fob is pressed and held simultaneously	ON	
RKE KEEP UNLK	UNLOCK button of key fob is not pressed	OFF	D
	UNLOCK button of key fob is pressed and held	ON	
HI BEAM SW	Lighting switch OFF	OFF	E
	Lighting switch HI	ON	
HEAD LAMP SW 1	Lighting switch OFF	OFF	F
	Lighting switch 2ND	ON	
HEAD LAMP SW 2	Lighting switch OFF	OFF	F
	Lighting switch 2ND	ON	
AUTO LIGHT SW	Lighting switch OFF	OFF	G
	Lighting switch AUTO	ON	
PASSING SW	Other than lighting switch PASS	OFF	H
	Lighting switch PASS	ON	
FR FOG SW	Front fog lamp switch OFF	OFF	I
	Front fog lamp switch ON	ON	
RR FOG SW	NOTE: The item is indicated, but not monitored.	OFF	I
TURN SIGNAL R	Turn signal switch OFF	OFF	J
	Turn signal switch RH	ON	
TURN SIGNAL L	Turn signal switch OFF	OFF	K
	Turn signal switch LH	ON	
CARGO LAMP SW	Cargo lamp switch OFF	OFF	INL
	Cargo lamp switch ON	ON	
OPTICAL SENSOR	Bright outside vehicle	5V	INL
	Dark outside vehicle	0V	
IGN SW CAN	Ignition switch OFF or ACC	OFF	M
	Ignition switch ON	ON	
FR WIPER HI	Front wiper switch OFF	OFF	N
	Front wiper switch HI	ON	
FR WIPER LOW	Front wiper switch OFF	OFF	O
	Front wiper switch LO	ON	
FR WIPER INT	Front wiper switch OFF	OFF	P
	Front wiper switch INT	ON	
FR WASHER SW	Front washer switch OFF	OFF	P
	Front washer switch ON	ON	
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	
FR WIPER STOP	Any position other than front wiper stop position	OFF	
	Front wiper stop position	ON	
VEHICLE SPEED	While driving	Equivalent to speedometer reading	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
RR WIPER ON	NOTE: The item is indicated, but not monitored.	OFF
RR WIPER INT	NOTE: The item is indicated, but not monitored.	OFF
RR WASHER SW	NOTE: The item is indicated, but not monitored.	OFF
RR WIPER STOP	NOTE: The item is indicated, but not monitored.	OFF
RR WIPER STP2	NOTE: The item is indicated, but not monitored.	OFF
H/L WASH SW	NOTE: The item is indicated, but not monitored.	OFF
HAZARD SW	Hazard switch OFF	OFF
	Hazard switch ON	ON
BRAKE SW	Brake pedal is not depressed	OFF
	Brake pedal is depressed	ON
FAN ON SIG	Blower fan motor switch OFF	OFF
	Blower fan motor switch ON (other than OFF)	ON
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	OFF
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	ON
TRNK OPNR SW	NOTE: The item is indicated, but not monitored.	OFF
TRUNK CYL SW	NOTE: The item is indicated, but not monitored.	OFF
HOOD SW	NOTE: The item is indicated, but not monitored.	OFF
OIL PRESS SW	<ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running 	OFF
	Ignition switch ON	ON
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	DONE
	ID of front LH tire transmitter is not registered	YET
ID REGST FR1	ID of front RH tire transmitter is registered	DONE
	ID of front RH tire transmitter is not registered	YET
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE
	ID of rear RH tire transmitter is not registered	YET
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE
	ID of rear LH tire transmitter is not registered	YET
WARNING LAMP	Tire pressure indicator OFF	OFF
	Tire pressure indicator ON	ON

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Monitor Item	Condition	Value/Status
BUZZER	Tire pressure warning alarm is not sounding	OFF
	Tire pressure warning alarm is sounding	ON

Terminal Layout

INFOID:000000004448844



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Physical Values




INFOID:000000004448845

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
6	R	Combination switch input 1				
7	GR	Front door lock assembly LH (key cylinder switch) unlock	Input	OFF	ON (open, 2nd turn)	Momentary 1.5V
8	SB	Front door lock assembly LH (key cylinder switch) lock			On (open)	Momentary 1.5V
			OFF (closed)	0V		
9	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
12	LG	Front door switch RH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper RH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower RH (King Cab)				
13	L	Rear door switch RH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver (Ground)	Output	OFF	—	0V
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 <p style="text-align: right; font-size: small;">L1IA1893E</p>
20	G	Remote keyless entry receiver signal (Signal)	Input	OFF	Stand-by (keyfob buttons released)	 <p style="text-align: right; font-size: small;">L1IA1894E</p>
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 <p style="text-align: right; font-size: small;">L1IA1895E</p>
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V





A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
31	GR	Cargo lamp switch	Input	OFF	ON	0V
				OFF	OFF	Battery voltage
32	O	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
36	LG	Combination switch output 1				
37	B	Key switch	Input	OFF	Key inserted	Battery voltage
					Key removed	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
45	V	Lock switch	Input	OFF	ON (lock)	0V
					OFF	Battery voltage
46	LG	Unlock switch	Input	OFF	ON (unlock)	0V
					OFF	Battery voltage
47	GR	Front door switch LH (All)	Input	OFF	ON (open)	0V
		Rear door switch upper LH (King Cab)			OFF (closed)	Battery voltage
		Rear door switch lower LH (King Cab)				
48	P	Rear door switch LH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)	
				Ignition switch	Operation or condition		
50	P	Cargo lamp	Output	OFF	Any door open (ON)	0V	
					All doors closed (OFF)	Battery voltage	
51	G	Trailer turn signal (right)	Output	ON	Turn right ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
52	V	Trailer turn signal (left)	Output	ON	Turn left ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
56	V	Battery saver output	Output	OFF	30 minutes after ignition switch is turned OFF	0V	
				ON	—	Battery voltage	
57	R/Y	Battery power supply	Input	—	—	Battery voltage	
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more	
					When optical sensor is not illuminated	0.6V or less	
59	GR	Front door lock assembly LH (unlock)	Output	OFF	OFF (neutral)	0V	
					ON (unlock)	Battery voltage	
60	LG	Turn signal (left)	Output	ON	Turn left ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
61	G	Turn signal (right)	Output	ON	Turn right ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>	
63	BR	Interior room/map lamp	Output	OFF	Any door switch	ON (open)	0V
					OFF (closed)	Battery voltage	
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V	
					ON (lock)	Battery voltage	
66	L	Front door lock actuator RH, rear door lock actuators LH/RH (unlock)	Output	OFF	OFF (neutral)	0V	
					ON (unlock)	Battery voltage	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Terminal	Wire color	Item	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
67	B	Ground	Input	ON	—	0V
68	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	P	Power window power supply (BAT)	Output	OFF	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage


BCM (BODY CONTROL MODULE)

[WITHOUT POWER DOOR LOCKS]

< ECU DIAGNOSIS >

Wiring Diagram

INFOID:00000000448846



ABMWA0116GI


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

BCM (BODY CONTROL MODULE)

[WITHOUT POWER DOOR LOCKS]

< ECU DIAGNOSIS >



ABMWA0117GI

BCM (BODY CONTROL MODULE)

[WITHOUT POWER DOOR LOCKS]

< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE) CONNECTORS

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
1	BR	KEY RING OUTPUT
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
7	GR	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
9	Y	RR DEFOGGER SW
10	-	-
11	G/B	ACC_SW
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
14	-	-
15	W	TPMS MODE TRIGGER SW
16	-	-
17	-	-
18	BR	KEYLESS & AUTO LIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY OUTPUT

Terminal No.	Color of Wire	Signal Name
20	G	KEYLESS TUNER SIGNAL
21	GR	IMMOBILIZER ANTENNA SIGNAL (CLOCK)
22	-	-
23	G	SECURITY INDICATOR OUTPUT
24	-	-
25	BR	IMMOBILIZER ANTENNA SIGNAL (RX, TX)
26	-	-
27	W	AIRCON SW
28	R	BLOWER FAN SW
29	G	HAZARD SW
30	-	-
31	GR	CARGO LAMP SW
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



41	42	43	44	45	46	47	48	49	50	51	52	53	54	55
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	V	CDL LOCK SW
46	LG	CDL UNLOCK SW
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
49	-	-
50	P	CARGO LAMP OUTPUT
51	G	TRAILER FLASHER OUTPUT (RIGHT)
52	V	TRAILER FLASHER OUTPUT (LEFT)
53	-	-
54	-	-
55	-	-

ABMIA0315GB

A B C D E F G H I J K L M N O P


INL

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3
11	O	WASH FR (-) RR (+)
12	B	GND
13	L	WASH FR (-) RR (-)
14	W	IGN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
56	V	BATTERY SAVER OUTPUT
57	R/Y	BAT (FUSE)
58	W	AUTO LIGHT SENSOR INPUT 2
59	GR	DOOR UNLOCK OUTPUT (DR)
60	LG	FLASHER OUTPUT (LEFT)
61	G	FLASHER OUTPUT (RIGHT)
62	-	-
63	BR	ROOM LAMP OUTPUT
64	-	-
65	V	DOOR LOCK OUTPUT (ALL)
66	L	DOOR UNLOCK OUTPUT (OTHER)
67	B	GND (POWER)
68	O	POWER WINDOW POWER SUPPLY OUTPUT (LINKED TO RAP)
69	P	POWER WINDOW POWER SUPPLY OUTPUT (BAT)
70	W	BAT (F/L)

ABMIA0316GB

INFOID:000000004448847

DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

Priority	DTC	
1	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) 	A
2	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM 	B
3	<ul style="list-style-type: none"> • C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL 	C
4	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL 	D E F G H I J

DTC Index

INFOID:000000004448848

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	BCS-30
U1010: CONTROL UNIT (CAN)	—	—	BCS-31
B2190: NATS ANTENNA AMP	—	—	SEC-18
B2191: DIFFERENCE OF KEY	—	—	SEC-21
B2192: ID DISCORD BCM-ECM	—	—	SEC-22
B2193: CHAIN OF BCM-ECM	—	—	SEC-24
C1708: [NO DATA] FL	—	—	WT-14

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
C1709: [NO DATA] FR	—	—	WT-14
C1710: [NO DATA] RR	—	—	WT-14
C1711: [NO DATA] RL	—	—	WT-14
C1712: [CHECKSUM ERR] FL	—	—	WT-16
C1713: [CHECKSUM ERR] FR	—	—	WT-16
C1714: [CHECKSUM ERR] RR	—	—	WT-16
C1715: [CHECKSUM ERR] RL	—	—	WT-16
C1716: [PRESSDATA ERR] FL	—	—	WT-18
C1717: [PRESSDATA ERR] FR	—	—	WT-18
C1718: [PRESSDATA ERR] RR	—	—	WT-18
C1719: [PRESSDATA ERR] RL	—	—	WT-18
C1720: [CODE ERR] FL	—	—	WT-16
C1721: [CODE ERR] FR	—	—	WT-16
C1722: [CODE ERR] RR	—	—	WT-16
C1723: [CODE ERR] RL	—	—	WT-16
C1724: [BATT VOLT LOW] FL	—	—	WT-16
C1725: [BATT VOLT LOW] FR	—	—	WT-16
C1726: [BATT VOLT LOW] RR	—	—	WT-16
C1727: [BATT VOLT LOW] RL	—	—	WT-16
C1729: VHCL SPEED SIG ERR	—	—	WT-19
C1735: IGNITION SIGNAL	—	—	—

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[WITHOUT POWER DOOR LOCKS]

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000004056598

CAUTION:

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
interior room lamps do not turn ON/OFF <ul style="list-style-type: none">• Front room/map lamp assembly (if equipped)• Room lamp 2nd row	<ul style="list-style-type: none">• Harness between fuse block (J/B) and each interior room lamp• Harness between each interior room lamp and door switches• Door switches	Interior room lamp Refer to INL-79 .
Cargo lamp does not turn ON/OFF	<ul style="list-style-type: none">• Harness between fuse block (J/B) and cargo lamp relay• Harness between cargo lamp relay and cargo lamp• Harness between BCM and cargo lamp relay• BCM	Cargo lamp control circuit Refer to INL-81 .

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

PRECAUTION

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004056599

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

General precautions for service operations

INFOID:000000004056600

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts which may get in the way with cloth.
- When removing parts with a screw driver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If a non-reuseable part is removed, replace it with a new one.
- After re-assembly has been completed, make sure each part functions correctly.
- Never work with wet hands.
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps or remove sealant residue.

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

[WITHOUT POWER DOOR LOCKS]

ON-VEHICLE REPAIR

INTERIOR ROOM LAMP

Removal and Installation

INFOID:000000004056601


MAP LAMP

Removal

The map lamp is replaced as part of the overhead console assembly. Refer to [INT-23, "Removal and Installation"](#).

⇐: Vehicle front

[]: Metal clip



Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery terminal.
2. Using a suitable tool (A), remove map lamp lens (1).


⇐: Vehicle front

CAUTION:

Wrap a cloth around tool to protect the housing and lens.

3. Release one side of the bulb (2) from the tab, then pull straight downward to remove.

Map lamp bulb : 12V - 8W



VANITY MIRROR LAMP

Removal


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

[WITHOUT POWER DOOR LOCKS]

The vanity mirror lamp is replaced as part of the sunvisor assembly. Refer to [INT-23, "Removal and Installation"](#).



Installation

Installation is in the reverse order of removal.

Bulb Replacement


The vanity mirror lamp bulb is replaced as part of the sunvisor assembly. Refer to [INT-23, "Removal and Installation"](#).

GLOVE BOX LAMP

Removal

1. Remove lower instrument panel RH and glove box. Refer to [IP-11, "Removal and Installation"](#).
2. Rotate glove box lamp socket (3) with bulb (1) counterclockwise, then pull away from lamp shield (2) on steering member to remove.

⇐: Vehicle front




Installation

Installation is in the reverse order of removal.

Bulb Replacement

1. Disconnect the negative battery terminal.
2. Remove glove box lamp.
3. Pull bulb (2) straight out from glove box lamp socket (1) to remove.

Glove box lamp bulb : 12V - 3.4W



ROOM LAMP

Removal


1. Disconnect the negative battery terminal.

INTERIOR ROOM LAMP

< ON-VEHICLE REPAIR >

[WITHOUT POWER DOOR LOCKS]

- Using a suitable tool (A), release the pawls and remove the room lamp lens (1).
- CAUTION:**
Wrap a cloth around tool to protect the housing and lens.
- Remove room lamp screws (2).
 - Disconnect the connector, then remove room lamp.



Installation


Installation is in the reverse order of removal.

Bulb Replacement

- Disconnect the negative battery terminal.
- Using a suitable tool, release the pawls and remove the room lamp lens.
- Release the room lamp bulb retainers (1), then pull bulb (2) straight out to remove.

Room lamp bulb

: 12V - 8W



A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION


Removal and Installation

INFOID:000000004056602

ILLUMINATION CONTROL SWITCH

Removal

The illumination control switch is replaced as a part of the combination meter assembly. Refer to [MWI-93, "Removal and Installation"](#).




Installation

Installation is in the reverse order of removal.

A/T FINISHER LAMP

Removal

1. Remove A/T finisher from center console. Refer to [TM-297, "Exploded view"](#).
2. Rotate A/T finisher lamp socket (2) with bulb (3) counterclockwise, then pull away from finisher (1).



Installation


Installation is in the reverse order of removal.

Bulb Replacement

1. Remove A/T finisher from center console. Refer to [TM-297, "Exploded view"](#).
2. Remove A/T finisher lamp socket (1), then pull bulb (2) straight out away from socket.

AT finisher lamp bulb

: 12V - 3W



BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

[WITHOUT POWER DOOR LOCKS]

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Interior Lamp/Illumination

INFOID:000000004056603

Item	Wattage (W)*
Map lamp	8
Vanity lamp	*
Glove box lamp	3.4
Room lamp	8
A/T finisher lamp	3

*: Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P