

ELECTRICAL SYSTEM

SECTION **EL**

When you read wiring diagrams:

● Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

CONTENTS

PRECAUTIONS	4	System Description (For Canada).....	43	CL
Supplemental Restraint System "AIR BAG".....	4	Wiring Diagram — DTRL —.....	44	
HARNESS CONNECTOR	5	Operation (Daytime light system for Canada).....	47	MT
Description.....	5	Schematic.....	47	
STANDARDIZED RELAY	6	Trouble Diagnoses (For USA).....	48	AT
Description.....	6	Trouble Diagnoses (For Canada).....	49	
POWER SUPPLY ROUTING	8	Bulb Replacement.....	51	FA
Wiring Diagram — POWER —.....	8	Aiming Adjustment.....	51	
Schematic.....	18	EXTERIOR LAMP	53	RA
Fuse.....	19	Back-up Lamp/Wiring Diagram — BACK/L —.....	53	
Fusible Link.....	19	Clearance, License, Tail and Stop		
BATTERY	20	Lamps/Wiring Diagram — TAIL/L —.....	54	BR
How to Handle Battery.....	20	Front Fog Lamp/System Description.....	57	
Service Data and Specifications (SDS).....	23	Front Fog Lamp/Wiring Diagram — F/FOG —.....	58	
STARTING SYSTEM	24	Turn Signal and Hazard Warning		
System Description.....	24	Lamps/System Description.....	60	ST
Wiring Diagram — START —.....	26	Turn Signal and Hazard Warning		
Construction.....	30	Lamps/Wiring Diagram — TURN —.....	61	BF
Removal and Installation.....	30	Turn Signal and Hazard Warning		
Pinion/Clutch Check.....	31	Lamps/Trouble Diagnoses.....	64	HA
Service Data and Specifications (SDS).....	31	Cornering Lamp/System Description.....	65	
CHARGING SYSTEM	32	Cornering Lamp/Wiring Diagram		
System Description.....	32	— CORNER —.....	66	EL
Wiring Diagram — CHARGE —.....	33	Combination Flasher Unit Check.....	68	
Construction.....	34	Bulb Specifications.....	68	
Removal and Installation.....	34	INTERIOR LAMP	69	IDX
Trouble Diagnoses.....	35	Illumination/System Description.....	69	
Service Data and Specifications (SDS).....	36	Spot and Trunk Room Lamps/System		
COMBINATION SWITCH	37	Description.....	70	
Combination Switch/Check.....	37	Illumination/Wiring Diagram — ILL —.....	71	
Combination Switch/Replacement.....	38	Spot and Trunk Room Lamp/Wiring Diagram		
Steering Switch/Check.....	39	— INT/L —.....	74	
HEADLAMP	40	METERS AND GAUGES	75	
System Description (For USA).....	40	System Description.....	75	
Wiring Diagram — H/LAMP —.....	41	Combination Meter.....	76	1065

CONTENTS (Cont'd.)

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram — METER —	77	Work Flow	145
Inspection/Fuel Gauge and Water Temperature Gauge	79	Consult	146
Fuel Tank Gauge Unit Check	80	On-board Diagnosis	154
Fuel Warning Lamp Sensor Check	80	On-board Diagnosis — Mode I (IVMS communication diagnosis)	155
Thermal Transmitter Check	80	On-board Diagnosis — Mode II (Switch monitor)	157
Oil Pressure Switch Check	80	On-board Diagnosis — Mode III (Power door lock operation)	159
Vehicle Speed Sensor Signal Check	81	On-board Diagnosis — Mode IV (Power window monitor)	161
WARNING LAMPS	82	IVMS (LAN) — TROUBLE DIAGNOSES	163
Wiring Diagram — WARN —	82	Body Control Module (BCM)	163
Schematic	85	Local Control Units (LCU's)	166
Diode Check	86	Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM —	174
WIPER AND WASHER	87	Power Supply and Ground Circuit Check	177
System Description	87	POWER WINDOW — IVMS	179
Front Wiper and Washer/Wiring Diagram — WIPER —	89	Component Parts and Harness Connector Location	179
Installation	91	System Description	180
Wiper Linkage	92	Wiring Diagram — WINDOW —	181
Washer Nozzle Adjustment	93	Schematic	185
Check Valve	93	Trouble Diagnoses	186
HORN, CIGARETTE LIGHTER, CLOCK	94	POWER DOOR LOCK — IVMS	190
Wiring Diagram — HORN —	94	Component Parts and Harness Connector Location	190
REAR WINDOW DEFOGGER	96	System Description	191
Wiring Diagram — DEF —	96	Wiring Diagram — D/LOCK —	192
Filament Check	97	Schematic	196
Filament Repair	98	Trouble Diagnoses	197
AUDIO AND POWER ANTENNA	99	MULTI-REMOTE CONTROL SYSTEM — IVMS	203
Audio/System Description	99	System Description	203
Audio/Wiring Diagram — AUDIO —	100	Wiring Diagram — MULTI —	205
Power Antenna/System Description	105	Schematic	212
Power Antenna/Wiring Diagram — P/ANT —	106	Trouble Diagnoses	213
Trouble Diagnoses	107	Replacing Remote Controller or Multi-Remote Control Unit (LCU05)	217
Location of Antenna	109	TIME CONTROL SYSTEM — IVMS	218
Antenna Rod Replacement	110	System Description	218
Window Antenna Repair	111	Wiring Diagram — TIME —	221
AUTOMATIC SPEED CONTROL DEVICE (ASCD)	112	Trouble Diagnoses	228
Component Parts and Harness Connector Location	112	THEFT WARNING SYSTEM — IVMS	242
System Description	113	Component Parts and Harness Connector Location	242
Wiring Diagram — ASCD —	115	Description	243
Schematic	120	System Description	244
Trouble Diagnoses	121	Wiring Diagram — THEFT —	247
IVMS (LAN) — SYSTEM DESCRIPTION	139	Schematic	254
Overall Description	139		
Component Parts Location	141		
System Diagram	142		
Sleep/Wake-up Control	143		
Fail-safe System	144		
IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM	145		

CONTENTS (Cont'd.)

Trouble Diagnoses.....	256	HARNESS LAYOUT	286	
ILLUMINATION — IVMS	273	Outline	286	
System Description	273	Engine Room Harness	287	GI
Wiring Diagram — SW/ILL —	274	Main Harness	290	
Trouble Diagnoses.....	275	Engine Control Harness	292	
INTERIOR LAMP ON-OFF CONTROL — IVMS	276	Body Harness.....	294	MA
System Description	276	Body No. 2 Harness and Tail Harness	296	
Wiring Diagram — ROOM/L —	277	Room Lamp Harness	297	EM
Trouble Diagnoses.....	278	Air Bag Harness	298	
STEP LAMP — IVMS	279	Door Harness (LH side).....	299	
System Description	279	Door Harness (RH side)	300	LC
Wiring Diagram — STEP/L —	280	SUPER MULTIPLE JUNCTION (SMJ)	Foldout	
Trouble Diagnoses.....	282	Terminal Arrangement	Foldout	EC
LOCATION OF ELECTRICAL UNITS	283	HYBRID ELECTRIC CONTROL UNIT (HEC)	Foldout	
Engine Compartment.....	283	Construction and Terminal Arrangement	Foldout	FE
Passenger Compartment.....	284	JOINT CONNECTOR (J/C)	Foldout	
Luggage Compartment	285	Terminal Arrangement	Foldout	CL

WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system).....		EC SECTION	
AUTOMATIC TRANSMISSION CONTROL SYSTEM, SHIFT LOCK SYSTEM		AT SECTION	
ANTI-LOCK BRAKE SYSTEM		BR SECTION	
TRUNK LID OPENER, HEATED SEAT, SUN ROOF, SRS "AIR BAG", DOOR MIRROR, DOOR MIRROR DEFOGGER.....		BF SECTION	MT
HEATER AND AIR CONDITIONER.....		HA SECTION	AT

MT

AT

FA

RA

BR

ST


BF

HA

EL

DX

PRECAUTIONS



Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which could result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS air bag electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS "Air bag".

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental loosening or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA
















EL

IDX

MEL343D

STANDARDIZED RELAY

Description




Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE or GREEN
2M				BROWN
1M•1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL871SA

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER —


EL-POWER-01




Refer to last page (Foldout page).
E101, M3

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)





GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF



HA
 EL
 IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)






POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

To EL-POWER-02

EL-POWER-04



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



EL

IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05






MEL445D

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-06



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

IDX

POWER SUPPLY ROUTING


Wiring Diagram — POWER — (Cont'd)




POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-08



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF





HA
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-09




MEL449D


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-10




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA




EL
IDX

POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.



Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link is melted, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause.
 - Never wrap outside of fusible link with vinyl tape.
- Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

IDX

BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)
- Check the condition of the battery by checking the specific gravity of the electrolyte.

CHECKING ELECTROLYTE LEVEL

WARNING:



Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.

BATTERY

How to Handle Battery (Cont'd)


- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX. level.



SULPHATION


A battery will be completely discharged if it is left unattended for a long time and the specific gravity becomes less than 1.100. This may result in sulphation on the cell plates.

To find if a battery has been "sulphated", pay attention to its voltage and current when charging it. As shown in the figure at left, if the battery has been "sulphated", less current and higher voltage may be observed in the initial stages of charging.



SPECIFIC GRAVITY CHECK

- Read hydrometer and thermometer indications at eye level.



- When the electrolyte level is too low, tilt battery case for easier measurement.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

BATTERY

How to Handle Battery (Cont'd)

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

BATTERY

How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.

MEMORY RESET

If the battery is disconnected or goes dead, the following items must be reset:

- Radio AM and FM preset
- Clock
- AUTO temperature setting trimmer

Service Data and Specifications (SDS)

Applied area	USA non-California	California	Canada and optional for USA
Type	55D23L	65D26R	80D26L
Capacity V-AH	12-60	12-65	12-65
Cold cranking current (For reference) A	356	413	582

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

STARTING SYSTEM

System Description

M/T models for USA

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **d**), located in the fuse and fusible link box).

With the ignition switch in the START position, power is supplied

- through terminal ③ of the ignition switch
- to clutch interlock relay terminal ③.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **17**), located in the fuse block in the HEC)
- to theft warning relay terminal ①

With the ignition switch in the START position, power is supplied

- through 7.5A fuse (No. **33**), located in the fuse block in the HEC)
- to theft warning relay terminal ③

If the theft warning system is not triggered, power is supplied

- through theft warning relay terminal ④
- to clutch interlock relay terminal ①.

When the clutch pedal is depressed, ground is supplied to clutch interlock relay terminal ② through the clutch interlock switch and body grounds **M13** and **M73**.

The clutch interlock relay is energized and power is supplied

- from terminal ⑤ of the clutch interlock relay
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the clutch interlock relay is interrupted.

M/T models for CANADA

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **d**), located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **17**), located in the fuse block in the HEC)
- to theft warning relay terminal ①

With the ignition switch in the START position, power is supplied

- through 30A fusible link (letter **d**), located in the fuse and fusible link box)
- to theft warning relay terminal ③

If the theft warning system is not triggered, power is supplied

- through theft warning relay terminal ④
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded.

A/T models

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **d**), located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **17**), located in the fuse block in the HEC)
- to theft warning relay terminal ①.

Also, with the ignition switch in the START position, power is supplied

- from ignition switch terminal ③
- to inhibitor relay terminal ⑥

If the theft warning system is not triggered, power is supplied

STARTING SYSTEM

System Description (Cont'd)

- through theft warning relay terminal ④
- to inhibitor switch terminal ①
- through inhibitor relay terminal ①, with the selector lever in the P or N position
- to body grounds (F18) and (F19).

The inhibitor relay is energized and power is supplied

- from ignition switch terminal ③
- to terminal ① of the starter motor windings
- through inhibitor relay terminals ⑥ and ⑦

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the inhibitor switch is interrupted.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL






IDX

STARTING SYSTEM

Wiring Diagram — START —

M/T MODEL

EL-START-01



Refer to last page (Foldout page).


(M3), (E101)

(E106)

STARTING SYSTEM

Wiring Diagram — START — (Cont'd)

EL-START-02



US : For U.S.A.
N : For Canada

1 E15
GY

1 2 M16
L

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

STARTING SYSTEM

Wiring Diagram — START — (Cont'd)





A/T MODEL

EL-START-03

Refer to "EL-POWER".

WTW : With theft warning system

OTW : Without theft warning system



Refer to last page (Foldout page).


M3, E101

E106

STARTING SYSTEM

Wiring Diagram — START — (Cont'd)

EL-START-04



1 (E15)
GY

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

IDX

STARTING SYSTEM


Construction



Removal and Installation

REMOVAL

1. Remove air duct assembly.
2. Disconnect starter harness.
3. Remove starter bolts (two).
4. Remove starter.



INSTALLATION

To install, reverse the removal procedure.

STARTING SYSTEM

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

GI

MA

EM

Service Data and Specifications (SDS)

LC

STARTER

Type	S114-801A	
	HITACHI make	
	Reduction gear type	
System voltage	V	12
No-load		
Terminal voltage	V	11.0
Current	A	Less than 90
Revolution	rpm	More than 2,700
Minimum diameter of commutator	mm (in)	28 (1.10)
Minimum length of brush	mm (in)	10.5 (0.413)
Brush spring tension	N (kg, lb)	12.7 - 17.7 (1.3 - 1.8, 2.9 - 4.0)
Clearance of bearing metal and armature shaft	mm (in)	Less than 0.2 (0.008)
Clearance between pinion front edge and pinion stopper	mm (in)	0.3 - 2.5 (0.012 - 0.098)

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IOX

System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. AC voltage is converted into DC voltage by the diode assembly in the alternator.

Power is supplied at all times to alternator terminal **(S)** through:

- 140A fusible link (letter **(a)**, located in the fuse and fusible link box), and
- 7.5A fuse (No. **(57)**, located in the fuse and fusible link box).

Voltage output through alternator terminal **(B)**, is controlled by the IC regulator at terminal **(S)**. The charging circuit is protected by the 140A fusible link.

Terminal **(E)** of the alternator supplies ground through body ground **(E35)**.

With the ignition switch in the ON or START position, power is supplied


- through 10A fuse (No. **(13)**, located in the fuse block in the HEC)
- to combination meter terminal **(41)** for the charge warning indicator.

Ground is supplied to terminal **(42)** of the combination meter through terminal **(L)** of the alternator. With power and ground supplied, the charge warning indicator will illuminate. When the alternator is providing sufficient voltage, the ground is opened and the charge warning indicator will go off.

If the charge warning indicator illuminates with the engine running, a malfunction is indicated. Refer to "Trouble Diagnoses" (EL-35).

CHARGING SYSTEM

Wiring Diagram — CHARGE —



EL-CHARGE-01

Refer to "EL-POWER".

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).


M3, E101
M1

EL


IDX

Construction

SEC. 231
LR1125-702



SEL459T




Removal and Installation

REMOVAL

1. Remove engine undercover RH.
2. Remove side inspection cover RH.
3. Loosen belt idler pulley.
4. Remove drive belt.
5. Remove A/C compressor mounting bolts (four).
6. Remove cooling fan and fan shroud.
7. Slide A/C compressor forward.
8. Disconnect alternator harness connector.
9. Remove alternator upper bolt and lower bolt.

INSTALLATION

To install, reverse the removal procedure.




CHARGING SYSTEM

Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

Before starting, inspect the fusible link.


WITH IC REGULATOR



- 1) Use fully charged battery.
- 2) Light : Charge warning light
ACG : Alternator parts except IC regulator
IC-RG : IC regulator
OK : IC-alternator is in good condition.
- 3) When reaching "Damaged ACG", remove alternator from vehicle and disassembly, inspect and correct or replace faulty parts.
- 4) *Method of grounding F terminal (HITACHI make only)

Gasoline engine model

Contact tip of wire with brush and attach wire to alternator body.



SEL030Z

- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of alternator.

CHARGING SYSTEM



Service Data and Specifications (SDS)

ALTERNATOR

Type		LR1125-702
		HITACHI make
Nominal rating		12-125
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,100
Hot output current (When 13.5 volts is applied)	A/rpm	More than 36/1,300 More than 94/2,500 More than 123/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	More than 6.00 (0.2362)
Brush spring pressure	N (g, oz)	1.000 - 3.432 (102 - 350, 3.60 - 12.34)
Slip ring minimum diameter	mm (in)	More than 26.0 (1.024)
Rotor (field coil) resistance	Ω	2.35

COMBINATION SWITCH

Combination Switch/Check




LIGHTING SWITCH

	OFF			1			2		
	A	B	C	A	B	C	A	B	C
5			○			○			○
6			○			○			○
7						○			○
8			○			○			○
9			○			○			○
10						○			○
11						○			○
12						○			○

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	○	○			
14	○	○	○		
15		○			
16		○		○	
17			○		○
18					○

INTERMITTENT WIPER VOLUME



FRONT FOG LAMP SWITCH


	OFF	ON
31		○
32		○

CORNERING LAMP SWITCH

	L	N	R
1	○		○
2	○		○
3	○		○


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

COMBINATION SWITCH





Combination Switch/Replacement

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.



COMBINATION SWITCH

Steering Switch/Check



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HEADLAMP

System Description (For USA)

Power is supplied at all times

- through 15A fuse (No. 61), located in the fuse and fusible link box
- to lighting switch terminal 5, and
- through 15A fuse (No. 62), located in the fuse and fusible link box
- to lighting switch terminal 8.

When the lighting switch is turned to the 2ND and LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to terminal 2 of the RH headlamp, and
- from lighting switch terminal 7
- to terminal 2 of the LH headlamp.

Terminal 3 of each headlamp supplies ground through body grounds E5 and E30.

With power and ground supplied, the headlamps will illuminate.

When the lighting switch is placed in the 2ND and HIGH ("A") or PASS ("C") position, power is supplied

- from lighting switch terminal 6
- to terminal 1 of the LH headlamp, and
- from lighting switch terminal 9
- to terminal 1 of the RH headlamp, and
- to combination meter terminal 21 for the HIGH BEAM indicator.

Ground is supplied to terminal 31 of the combination meter through body grounds M13 and M73.

With power and ground supplied, the high beams and the HIGH BEAM indicator illuminate.


With theft warning system

The theft warning system will flash the high beams if the system is triggered. Refer to "THEFT WARNING SYSTEM — IVMS" (EL-242).

HEADLAMP

Wiring Diagram — H/LAMP —

FOR U.S.A.




EL-H/LAMP-01

Refer to 'EL-POWER'.

Next page

Next page



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

HEADLAMP

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-02



Refer to last page (Foldout page).

(M3), (E101)
(E49)

HEADLAMP

System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control unit. It activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started, the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. After that, the daytime lights will continue to operate even when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 62, located in the fuse and fusible link box)
- to daytime light control unit terminal ③ and
- to lighting switch terminal ⑧.

Power is also supplied at all times

- through 15A fuse (No. 61, located in the fuse and fusible link box)
- to daytime light control unit terminal ②,
- to lighting switch terminal ⑤ and
- to theft warning relay terminal ③.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 12, located in the fuse block in the HEC)
- to daytime light control unit terminal 12.

Ground is supplied to daytime light control unit terminal ⑤ through body grounds M13 and M73.

HEADLAMP OPERATION

Low beam operation

When the lighting switch is moved to the 2ND and LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to LH headlamp terminal ②.

Ground is supplied to LH headlamp terminal ③ through body grounds E5 and E30.

Also, when the lighting switch is moved to the 2ND and LOW ("B") position, power is supplied

- from lighting switch terminal 7
- to RH headlamp terminal ②.

Ground is supplied to headlamp terminal ③ through body grounds E5 and E30 (through daytime light control unit).

With power and ground supplied, the low beam headlamps illuminate.

High beam operation

When the lighting switch is moved to the 2ND and HIGH ("A") or PASS ("C") position, power is supplied

- from lighting switch terminal 9
- to LH headlamp terminal ①.

Also, when the lighting switch is moved to the 2ND and HIGH ("A") or PASS ("C") position, power is supplied

- from lighting switch terminal 9
- to daytime light control unit terminal ⑧
- through daytime light control unit terminal ⑥
- to RH headlamp terminal ①.

Ground is supplied in the same manner as low beam operation.

With power and ground supplied, the high beam headlamps illuminate.

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position, power is supplied

- to daytime light control unit terminal ③
- through daytime light control unit terminal ⑥
- to headlamp RH terminal ①
- through headlamp RH terminal ③
- to daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑧
- to headlamp LH terminal ①.

Ground is supplied to headlamp LH terminal ③ through body grounds E5 and E30.

Because the high beam headlamps are now connected in series, they operate at half illumination.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



IDX

HEADLAMP

Wiring Diagram — DTRL —

FOR CANADA

EL-DTRL-01



Refer to last page (Foldout page).

(M3) (E101)
(M4) (B1)
(M1)
(E49)
(M67)

HEADLAMP



Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL





IDX



HEADLAMP

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



Refer to last page (Foldout page).

M3, E101
E49

HEADLAMP

Operation (Daytime light system for Canada)

After starting the engine with the lighting switch in the "OFF" position or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
Lighting switch		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	O	X	X	O	O	X	O	Δ*	Δ*	O	Δ*	Δ*	O	O	X	O
	Low beam	X	X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

O : Lamp "ON"


X : Lamp "OFF"

Δ : Lamp dims.

* : When starting the engine with the parking brake released, the daytime lamp will come ON.
When starting the engine with the parking brake pulled, the daytime lamp won't come ON.

Schematic

FOR CANADA



HEADLAMP

Trouble Diagnoses (For USA)











Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E5) and (E30) 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E5) and (E30). 3. Check 15A fuse (No. 62), located in fusible link and fuse box). Verify battery positive voltage is present at terminal 8 of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E5) and (E30) 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E5) and (E30). 3. Check 15A fuse (No. 61), located in fusible link and fuse box). Verify battery positive voltage is present at terminal 5 of lighting switch. 4. Check lighting switch.
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check Y wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check G/Y wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb. 2. Open in RH high beam circuit 3. Lighting switch. 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check LG/B wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check L/B wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (M13) and (M73) 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds (M13) and (M73). 3. Check Y wire between lighting switch and combination meter for an open circuit.

HEADLAMP

Trouble Diagnoses (For Canada)

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE









(Data are reference values.)

Terminal No.	Item	Condition	Judgement standard
1	—	—	—
2	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "OFF".	Battery positive voltage
3	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "OFF".	Battery positive voltage
4	Lighting switch (Lo beam)	When turning lighting switch to "2ND" ("B").	Battery positive voltage
5	Lighting switch (Hi beam)	When turning lighting switch to "HIGH" ("A").	Battery positive voltage
		When turning lighting switch to "PASS" ("C").	Battery positive voltage
6	LH hi beam	When turning lighting switch to "HIGH" ("A").	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation). CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery positive voltage
7	LH headlamp control (ground)	When lighting switch is turned to "2ND" ("B").	1V or less
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation). CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
8	RH hi beam	When turning lighting switch to "HIGH" ("A").	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation). CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
9	Ground	—	—


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HEADLAMP

Trouble Diagnoses (For Canada) (Cont'd)

Terminal No.	Item	Condition	Judgement standard
10	Parking brake switch	 When turning ignition switch to "ON" with parking brake set.	1V or less
		 When releasing parking brake with ignition switch "ON".	Battery positive voltage
11	Alternator	 When turning ignition switch to "ON".	1V or less
		 When engine is running.	Battery positive voltage
		 When turning ignition switch to "OFF".	1V or less
12	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "ST".	Battery positive voltage
		 When turning ignition switch to "OFF".	1V or less

HEADLAMP



Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

- **Do not leave the bulb out of the headlamp reflector for a long period of time. Dust, moisture, smoke, etc. entering headlamp may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**


Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**



AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Adjustment value for mechanical aimer

	Mechanical aimer level
Horizontal side	-4 to 4
Vertical side	-4 to 4

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



EL
IDX

HEADLAMP

Aiming Adjustment (Cont'd)

LOW BEAM

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**






- **Upper edge and left edge of high intensity zone should be within the range shown at left. Adjust headlamps accordingly.**
 - **Dotted lines in illustration show center of headlamp.**
- "H": Horizontal center line of headlamps
 "W_L": Distance between each headlamp center

EXTERIOR LAMP

Back-up Lamp/Wiring Diagram — BACK/L —

EL-BACK/L-01



Refer to last page (Foldout page).

(M4) , (B1)
(M1)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram — TAIL/L —

EL-TAIL/L-01




Next page

Next page

To EL-CORNER

To EL-CORNER

Refer to last page (Foldout page).





- (M1)
- (E50)
- (M21)
- (M25)

EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).
M4, B1





EL

IDX

EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-03



EXTERIOR LAMP

Front Fog Lamp/System Description

Power is supplied at all times to front fog lamp relay terminal ③ through

- 15A fuse (No. 54, located in the fuse and fusible link box).

With the lighting switch in the 2ND and LOW ("B") position, power is supplied

- through 15A fuse (No. 62, located in the fuse and fusible link box)
- to lighting switch terminal ⑧
- through terminal ⑩ of the lighting switch
- to front fog lamp relay terminal ②.

Front fog lamp operation

The lighting switch must be in the 2ND and LOW ("B") position for front fog lamp operation.

With the front fog lamp switch in the ON position

- ground is supplied to front fog lamp relay terminal ① through the front fog lamp switch and body grounds E5 and E30.

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal ⑤
- to terminal ① of each front fog lamp.

Ground is supplied to terminal ② of each front fog lamp through body grounds E5 and E30.

With power and ground supplied, the front fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG —





EL-F/FOG-01



EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG — (Cont'd)

EL-F/FOG-02



Refer to last page (Foldout page).

E48

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

IDX

Turn Signal and Hazard Warning Lamps/System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 14), located in the fuse block in the HEC)
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ⑧
- through terminal ① of the combination flasher unit and terminal ④ of the multi-remote control relay-2
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ⑤ through body grounds (M13) and (M73).

LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to

- front turn signal lamp LH terminal ① (through fuse block (HEC) terminals (5S) and (6S))
- rear combination lamp LH terminal ② (through fuse block (HEC) terminals (5S) and (40)) and
- combination meter terminal ⑫.

Ground is supplied to the front turn signal lamp LH terminal ② through body grounds (E5) and (E30).

Ground is supplied to the rear combination lamp LH terminal ④ through body grounds (T6) and (T9).

Ground is supplied to combination meter terminal ⑪ through body grounds (M13) and (M73).

With power and grounds supplied, the combination flasher unit controls the flashing interval of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to

- front turn signal lamp RH terminal ① (through fuse block (HEC) terminals (15S) and (10S))
- rear combination lamp RH terminal ② (through fuse block (HEC) terminals (15S) and (130)) and
- combination meter terminal ⑱.

Ground is supplied to the front turn signal lamp RH terminal ② through body grounds (E5) and (E30).

Ground is supplied to the rear combination lamp RH terminal ④ through body grounds (T6) and (T9).

Ground is supplied to combination meter terminal ⑳ through body grounds (M13) and (M73).

With power and ground supplied, the combination flasher unit controls the flashing interval of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through

- 10A fuse (No. 11), located in the fuse block in the HEC).

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ⑧
- through terminal ① of the combination flasher unit
- to hazard switch terminal ④ (through terminal ⑥ of the joint connector-17).

Ground is supplied to the combination flasher unit terminal ⑤ through body grounds (M13) and (M73).

Power is supplied through terminal ⑤ of the hazard switch to

- front turn signal lamp LH terminal ① (through fuse block (HEC) terminals (2J) and (5S))
- rear combination lamp LH terminal ② (through fuse block (HEC) terminals (2J) and (40)) and
- combination meter terminal ⑫.

Power is also supplied through terminal ⑥ of the hazard switch to

- front turn signal lamp RH terminal ① (through fuse block (HEC) terminals (11J) and (10S))
- rear combination lamp RH terminal ② (through fuse block (HEC) terminals (11J) and (130)) and
- combination meter terminal ⑱ (through fuse block (HEC) terminals (11J) and (5H)).

Ground is supplied to terminal ② of the front turn signal lamps through body grounds (E5) and (E30).

Ground is supplied to terminal ④ of the rear combination lamps through body grounds (T6) and (T9).


Ground is supplied to combination meter terminal ⑳ through body grounds (M13) and (M73).

With power and ground supplied, the combination flasher unit controls the flashing interval of the hazard warning lamps.

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN —

EL-TURN-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).

- M1
- M4
- M25
- B1



EL

IDX

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)

EL-TURN-02




Refer to last page (Foldout page).

- (M3), (E101)
- (M4), (B1)
- (M67)

EXTERIOR LAMP


Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)

EL-TURN-03



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

Refer to last page (Foldout page).



EL
IDX

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 14), located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check LG/B wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 11), located in fuse block). Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check LG/B wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E5 and E30 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E5 and E30.
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds T6 and T9 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds T6 and T9.
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Ground 	<ol style="list-style-type: none"> 1. Check grounds M13 and M73.
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 	<ol style="list-style-type: none"> 1. Check bulb in combination meter.

EXTERIOR LAMP

Cornering Lamp/System Description

The lighting switch must be in the 2ND and LOW ("B") or HIGH ("A") position for the cornering lamps to operate.

Power is supplied at all times to terminal ⑧ of the lighting switch through

- 15A fuse (No. 62, located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied to cornering lamp relay terminal ③ through:

- 7.5A fuse (No. 14, located in the fuse block in the HEC).

Power is supplied to cornering lamp relay terminal ①

- through terminal ⑩ of the lighting switch in the LOW ("B") position or
- through terminal ⑨ of the lighting switch in the HIGH ("A") position.

Ground is supplied to cornering lamp relay terminal ② through body grounds E5 and E30.

With power and ground supplied, the cornering lamp relay is energized.

Power is supplied

- from terminal ⑤ of the cornering lamp relay
- to cornering lamp switch terminal ⑥.

RH turn

When the turn signal lever is moved to the RH position, power is supplied

- from terminal ⑦ of the cornering lamp switch
- through terminal ② of the cornering lamp switch
- to cornering lamp RH terminal ③.

Ground is supplied to terminal ② of cornering lamp RH through body grounds E5 and E30.

The RH cornering lamp illuminates until the turn signal lever returns to NEUTRAL position.

LH turn

When the turn signal lever is moved to the LH position, power is supplied

- from terminal ⑧ of the cornering lamp switch
- through terminal ③ of the cornering lamp switch
- to cornering lamp LH terminal ④.

Ground is supplied to terminal ② of cornering lamp LH through body grounds E5 and E30.

The LH cornering lamp illuminates until the turn signal lever returns to NEUTRAL position.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

EXTERIOR LAMP

Cornering Lamp/Wiring Diagram — CORNER —





EL-CORNER-01



EXTERIOR LAMP

Cornering Lamp/Wiring Diagram — CORNER — (Cont'd)

EL-CORNER-02




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

IDX

EXTERIOR LAMP



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

Bulb Specifications

	Wattage (12 volt)
Headlamp (Semi-sealed beam)	
High/low	65/45 (HB1)
Front turn signal lamp	27
Front combination lamp	
Cornering/Front clearance	27/8
Front side marker	3.8
Front fog lamp	55 (H3)
Rear combination lamp	
Turn signal	27
Stop/Tail	27/8
Back-up	27
Rear side marker lamp	3.8
License plate lamp	5
High-mounted stop lamp	27
Interior lamp	10
Spot lamp	10
Step lamp	3.4
Trunk room lamp	3.4

INTERIOR LAMP

Illumination/System Description

Power is supplied at all times

- through 15A fuse (No. 51, located in the fuse and fusible link box)
- to lighting switch terminal ①.

The lighting switch must be in the 1ST or 2ND position for illumination.

Power is also supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to vanity mirror illumination terminal ①.

A variable resistor is built in the illumination control switch to control the amount of current to the illumination system.

The ashtray illumination, vanity mirror illumination and the glove box lamp are not controlled by the illumination control switch. The brightness of these lamps does not change.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Power terminal	Ground terminal
Audio	⑧	⑦
CD player	⑳	㉒
Push control unit	①	②
PTC (Potentio Temperature Control)*	㉗**	㉕
A/T control device	⑥	③
Hazard switch	⑦	⑧
Power window switch (Front LH/RH)	⑦ / ⑭	⑩ / ⑩
Cigarette lighter	①	②
Ashtray	①	②
Combination meter	㉖	⑤ and ④⑩
Clock	②	④
ASCD main switch	⑤	⑥
Rear window defogger switch	⑤	⑥
Glove box lamp	②	①
Illumination control switch	①	② and ③
Vanity mirror	①	②

*: If equipped.

** : Power supplied to PTC terminal ㉗ is supplied through the push control unit.

With the exception of the glove box lamp, vanity mirror illumination and the ashtray illumination, the ground for all of the components are controlled through terminals ② and ③ of the illumination control switch and body grounds M13 and M73.

When the glove box is open, glove box lamp terminal ① is grounded through the glove box lamp switch and body grounds M13 and M73.

The ashtray illumination terminal ② and vanity mirror illumination terminal ② are grounded directly through body grounds M13 and M73.

Vanity mirror will illuminate when cover of the vanity mirror is opened.

INTERIOR LAMP

Spot and Trunk Room Lamps/System Description

Power is supplied at all times

- through 7.5A fuse (No. 26), located in the fuse block in the HEC)
- to spot lamp terminal ①, and
- to trunk room lamp terminal ①.

Ground is supplied when switch is ON

- to spot lamp terminal ②
- through body grounds M13 and M73.


Ground is supplied when trunk room lamp switch is ON

- to trunk room lamp terminal ②
- through body grounds B16 and B19.


INTERIOR LAMP

Illumination/Wiring Diagram — ILL —

EL-ILL-01



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA




Refer to last page (Foldout page).
 M1
 M65


EL
 IDX

INTERIOR LAMP Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-02



⬡ AA : AUTO A/C models
 ⬡ MA : MANUAL A/C models





Refer to last page (Foldout page).
 (M19)

MEL403D

INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)



Refer to last page (Foldout page).

M1



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL
IDX

INTERIOR LAMP

Spot and Trunk Room Lamp/Wiring Diagram — INT/L —

EL-INT/L-01



Refer to last page (Foldout page).

(M1)

System Description

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 13, located in the fuse block in the HEC)
- to combination meter terminal 41
- for the tachometer and
- for the fuel gauge and water temperature gauge.

GI

Ground is supplied

- to combination meter terminals 31, 10 and 38
- through body grounds M13 and M73.

MA

The reading on the water temperature gauge is based on the resistance change of the thermal transmitter.

EM

A variable ground is supplied to terminal 37 of the combination meter for the water temperature gauge.

The tachometer is regulated by a signal

LC

- from terminal 5 of the ECM (ECCS control module)
- to combination meter terminal 17 for the tachometer.

The fuel gauge is regulated by a variable ground signal supplied

EC

- to combination meter terminal 13 for the fuel gauge
- from terminal 3 of the fuel tank gauge unit
- through terminal 2 of the fuel tank gauge unit and
- through body grounds F18 and F19.

FE

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer and the voltage is converted into the vehicle speed.

CL

The voltage is supplied

- to combination meter terminals 11 and 28 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

WT

AT

FA

RA

BR

ST

BF



HA

EL

IDX

METERS AND GAUGES


Combination Meter



8	9	10	11	13	14		
1	2	3	4	5			

		28	29	31	32
17	19	21	22	23	

	40	41	42	43	44	45	46
		35	36	37	38		





MEL350D

METERS AND GAUGES

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram — METER —

EL-METER-01

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).



(M1)
(M18)

EL
IDX

METERS AND GAUGES

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram — METER — (Cont'd)





EL-METER-02




Refer to last page (Foldout page).

M4, B1
M36

Inspection/Fuel Gauge and Water Temperature Gauge



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX




Fuel Tank Gauge Unit Check

- For removal, refer to FE section "FUEL SYSTEM". Check the resistance between terminals **G** and **E**.

Ohmmeter		Float position		Resistance value (Ω)
(+)	(-)	mm (in)		
G	E	*3	Full	33 (1.30)
		*2	1/2	91 (3.58)
		*1	Empty	159 (6.26)

*1 and *3: When float rod is in contact with stopper.




Fuel Warning Lamp Sensor Check

- Raise the float with fingers more than the distance shown in the figure at left. Make sure that continuity does not exist.

CAUTION:


Do not move the float beyond its mobile range.



Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 Ω
100°C (212°F)	Approx. 21 - 24 Ω




Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES

Check the continuity between the terminals of oil pressure switch and body ground.

Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly with fingers and measure voltage across **a** and **b**.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

IDX

WARNING LAMPS

Wiring Diagram — WARN —

EL-WARN-01




Refer to last page (Foldout page).

M1
M19


WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).

M4, B1
M36



EL

IDX

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-03




Refer to last page (Foldout page).

- (M3) . (E101)
- (M4) . (B1)
- (E114)
- (F101)


WARNING LAMPS

Schematic



- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL**
- IDX


WARNING LAMPS



Diode Check

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual of your tester.



- Diodes for warning lamps are built into the combination meter printed circuit.

Refer to "Combination Meter" (EL-76).

System Description

WIPER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 20, located in the fuse block in the HEC)
- to front wiper motor terminal 4.

Low and high speed wiper operation

Ground is supplied to front wiper switch terminal 17 through body grounds E5 and E30.

When the front wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the front wiper switch
- to front wiper motor terminal 2.

With power and ground supplied, the front wiper motor operates at low speed.

When the front wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the front wiper switch
- to front wiper motor terminal 3.

With power and ground supplied, the front wiper motor operates at high speed.

Auto stop operation

When the front wiper switch is placed in the OFF position, the front wiper motor will continue to operate until the wiper arms reach the base of the windshield (Auto stop).

When the front wiper switch is placed in the OFF position, ground is supplied

- from terminal 14 of the front wiper switch
- to front wiper motor terminal 2, in order to continue front wiper motor operation at low speed.

Ground is also supplied until the wiper arms reaches the base of the windshield

- through terminal 13 of the front wiper switch
- to wiper relay terminal 3
- through terminal 4 of the wiper relay
- to front wiper motor terminal 5
- through terminal 6 of the front wiper motor, and
- through body grounds M13 and M73.

When the wiper arms reach the base of the windshield, the switch in the front wiper motor moves to the "STOP" position. The ground path is interrupted and the front wiper motor stops.

Intermittent operation

Intermittent operation is controlled by the BCM.

When the front wiper switch is placed in the INT position, ground is supplied

- to BCM terminal 25
- from front wiper switch terminal 15
- through body grounds E5 and E30.

The desired interval time is input

- to BCM terminal 17
- from front wiper switch terminal 19.

Based on these two inputs, an intermittent ground is supplied

- to front wiper relay terminal 3
- from BCM terminal 10.

With power and ground supplied, the front wiper relay is activated.

When activated, an intermittent ground is supplied

- to front wiper motor terminal 2
- through the front wiper switch terminal 14
- to front wiper switch terminal 13
- through front wiper relay terminal 3
- to front wiper relay terminal 5
- through body grounds E5 and E30.

Front wiper motor operates at desired low speeds with BCM terminal 25 grounded.

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 20, located in the fuse block in the HEC)
- to front washer motor terminal 1.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

WIPER AND WASHER

System Description (Cont'd)

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal ②, and
- to BCM terminal ②⑥
- from terminal ①⑧ of the front wiper switch
- through terminal ①⑦ of the front wiper switch, and
- through body grounds ⑤⑤ and ⑤③①.

With power and ground supplied, the washer motor operates.






The front wiper motor operates at low speed for about 3 seconds. This feature is controlled by the BCM in the same manner as the intermittent operation.

For further information, refer to "TIME CONTROL SYSTEM" (EL-218).

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram — WIPER —

EL-WIPER-01



Refer to last page (Foldout page).

(M3) (E101)
(M1)






IDX

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram — WIPER — (Cont'd)

EL-WIPER-02



Refer to last page (Foldout page).

(M3) . (E101)

WIPER AND WASHER

Installation

1. Turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface. Set the blade center to clearance "L₁" or "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" & "L₂".



Clearance "L₁": 32 - 48 mm (1.26 - 1.89 in)

Clearance "L₂": 47 - 57 mm (1.85 - 2.24 in)

- Tighten windshield wiper arm nuts to specified torque.

Windshield wiper:


21 - 26 N·m (2.1 - 2.7 kg-m, 15 - 20 ft-lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER AND WASHER

Wiper Linkage




REMOVAL

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.


INSTALLATION

- Grease ball joint portion before installation. Installation is in reverse order of removal.




Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.
Adjustable range: $\pm 10^\circ$



Check Valve

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

Wiring Diagram — HORN —

EL-HORN-01




Refer to last page (Foldout page).
(M1)

HORN, CIGARETTE LIGHTER, CLOCK


Wiring Diagram — HORN — (Cont'd)

EL-HORN-02



Refer to 'EL-POWER'.

W : Models equipped with theft warning system
 O : Models without theft warning system



Refer to last page (Foldout page).

- (M3), (E101)
- (E12)
- (E51)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA



EL

IDX

REAR WINDOW DEFOGGER

Wiring Diagram — DEF —





EL-DEF-01



Refer to last page (Foldout page).

- (M3) (E101)
- (M4) (B1)
- (M18)
- (M36)

REAR WINDOW DEFOGGER



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe along filament. Tester needle will swing abruptly when probe passes the point.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth




REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

Audio/System Description

Refer to Owner's Manual for audio system operating instructions.

WITH BOSE SYSTEM

Power is supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to radio and CD player terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 21, located in the fuse block in the HEC)
- to radio and CD player terminal 10.

Ground is supplied through the case of the radio.

Also, radio and CD player terminal 12 is grounded to body grounds M13 and M73 through audio amp. relay terminals 1 and 2.

Power is supplied at all times

- through 15A fuse (No. 22, located in the fuse block in the HEC)
- to front door speaker LH terminal 5
- to front door speaker RH terminal 5 and
- to rear speaker LH terminal 3 and RH terminal 3.

When the radio POWER button is pressed, audio signals are supplied

- through radio and CD player terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 3 and 6 of the LH and RH front speakers and terminals 2 and 4 of the LH and RH rear speakers
- to LH and RH tweeters through terminals 1 and 2 of the front and rear speakers.

EXCEPT BOSE SYSTEM

Power is supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to radio and cassette player terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 21, located in the fuse block in the HEC)
- to radio and cassette player terminal 10.

Ground is supplied through the case of the radio.

When the radio power knob is pushed to the ON position, audio signals are supplied

- through radio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the front and rear speakers.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL





IDX

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO —

BOSE SYSTEM

EL-AUDIO-01




Refer to last page (Foldout page).


(M1)

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA



Refer to last page (Foldout page).
 (M43)


EL

IDX

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-03



Refer to last page (Foldout page).

B1, M4



M43

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

EXCEPT FOR BOSE SYSTEM

EL-AUDIO-04



Refer to last page (Foldout page).





(M1)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-05



Refer to last page (Foldout page).

(M4) , (B1)

Power Antenna/System Description

Power is supplied at all times

- through 7.5A fuse (No. [40], located in the fuse block in the HEC)
- to power antenna timer and motor terminal ③.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. [21], located in the fuse block in the HEC)
- to radio and CD player terminal ⑩.

Ground is supplied to the power antenna timer and motor through body grounds T8 and T9.

When the radio is turned to the ON position, battery voltage is supplied

- through radio and CD player terminal ⑤
- to power antenna timer and motor terminal ④.

When battery voltage is supplied to the power antenna timer and motor terminal ④, power supplied to the power antenna timer and motor terminal ③ drives the motor.

The antenna rises and is held in the extended position.

When the radio is turned to the OFF position, battery voltage is interrupted

- from radio and CD player terminal ⑤
- to power antenna terminal ④.

The antenna retracts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA





EL

IDX

AUDIO AND POWER ANTENNA

Power Antenna/Wiring Diagram — P/ANT —

EL-P/ANT-01



Refer to last page (Foldout page).

M4, B1
M1

AUDIO AND POWER ANTENNA

Trouble Diagnoses

6-SPEAKER TYPE (BOSE SYSTEM)

Symptom	Possible causes	Repair order	
Radio is inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 10A fuse Poor radio case ground Radio 	<ol style="list-style-type: none"> Check 10A fuse (No. 21, located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 19 of radio. Check radio case ground. Remove radio for repair. 	GI MA
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 7.5A fuse Radio 	<ol style="list-style-type: none"> Check 7.5A fuse (No. 40, located in fuse block). Verify battery positive voltage is present at terminal 6 of radio. Remove radio for repair. 	EM LC
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> 15A fuse Audio switching relay Grounds M13 and M73. Radio output Radio 	<ol style="list-style-type: none"> Check 15A fuse (No. 22, located in fuse block). Verify battery positive voltage is present at terminal 3 of audio switching relay. Check audio switching relay. Check grounds M13 and M73. Check radio output voltage. Remove radio for repair. 	EC FE
Rear speakers are inoperative.	<ol style="list-style-type: none"> Grounds B16 and B19 Radio 	<ol style="list-style-type: none"> Check grounds B16 and B19. Remove radio for repair. 	CL
Front speakers are inoperative.	<ol style="list-style-type: none"> Front speaker ground circuits Radio 	<ol style="list-style-type: none"> Check front speaker ground circuits. Remove radio for repair. 	MT
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker Radio output Speaker circuit Radio 	<ol style="list-style-type: none"> Check speaker. Check radio output voltages. Check wires for open or short between radio and speaker. Remove radio for repair. 	AT FA
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> Antenna Poor radio ground Radio 	<ol style="list-style-type: none"> Check antenna. Check radio ground. Remove radio for repair. 	RA
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> Window antenna Radio 	<ol style="list-style-type: none"> Check window antenna. Remove radio for repair. 	BR
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> Poor radio ground Loose or missing ground bonding straps Ignition condenser or rear window defogger noise suppressor condenser Alternator Ignition coil or secondary wiring Radio 	<ol style="list-style-type: none"> Check radio ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check alternator. Check ignition coil and secondary wiring. Remove radio for repair. 	ST BF HA
Radio generates noise in AM and FM stations with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> Poor radio ground Antenna Accessory ground Malfunctioning accessory 	<ol style="list-style-type: none"> Check radio ground. Check antenna. Check accessory ground. Replace accessory. 	EL IX

AUDIO AND POWER ANTENNA

Trouble Diagnoses (Cont'd)

4-SPEAKER TYPE

Symptom	Possible causes	Repair order
Radio is inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 1. 10A fuse 2. Poor radio case ground 3. Radio 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 21), located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 10 of radio. 2. Check radio case ground. 3. Remove radio for repair.
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Radio 	<ol style="list-style-type: none"> 1. Check 7.5A fuse (No. 40), located in fuse block). Verify battery positive voltage is present at terminal 6 of radio. 2. Remove radio for repair.
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> 1. Speaker 2. Radio output 3. Speaker circuit 4. Radio 	<ol style="list-style-type: none"> 1. Check speaker. 2. Check radio output voltages. 3. Check wires for open or short between radio and speaker. 4. Remove radio for repair.
All speakers are inoperative.	<ol style="list-style-type: none"> 1. Radio 	<ol style="list-style-type: none"> 1. Remove radio for repair.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> 1. Antenna 2. Poor radio ground 3. Radio 	<ol style="list-style-type: none"> 1. Check antenna. 2. Check radio ground. 3. Remove radio for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> 1. Window antenna 2. Radio 	<ol style="list-style-type: none"> 1. Check antenna. 2. Remove radio for repair.
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> 1. Poor radio ground 2. Loose or missing ground bonding straps 3. Ignition condenser or rear window defogger noise suppressor condenser 4. Alternator 5. Ignition coil or secondary wiring 6. Radio 	<ol style="list-style-type: none"> 1. Check radio ground. 2. Check ground bonding straps. 3. Replace ignition condenser or rear window defogger noise suppressor condenser. 4. Check alternator. 5. Check ignition coil and secondary wiring. 6. Remove radio for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> 1. Poor radio ground 2. Antenna 3. Accessory ground 4. Faulty accessory 	<ol style="list-style-type: none"> 1. Check radio ground. 2. Check antenna. 3. Check accessory ground. 4. Replace accessory.

POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. 10A fuse 3. Radio signal 4. Grounds T6 and T9 5. Power antenna timer and motor 	<ol style="list-style-type: none"> 1. Check 7.5A fuse (No. 40), located in fuse block). Verify that battery positive voltage is present at terminal 1 of power antenna timer and motor. 2. Check 10A fuse (No. 21), located in fuse block). Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of radio. 3. Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal 4 of power antenna timer and motor. 4. Check grounds T6 and T9. 5. Check power antenna timer and motor.

AUDIO AND POWER ANTENNA

Trouble Diagnoses (Cont'd)

SPEAKER INSPECTION

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ② (for 4-speaker) or ① and ② of tweeter, ③ and ⑥ of front speaker or ② and ④ of rear speaker (for 6-speaker).
 - The resistance should be 2-4 Ω .
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ② (for 4-speaker) or ① and ② of tweeter, ③ and ⑥ of front speaker or ② and ④ of rear speaker (for 6-speaker).
 - A momentary hum or pop should be heard.

GI
MA

ANTENNA INSPECTION

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
 - If reception improves, check antenna ground (at body surface).
 - If reception does not improve, check main feeder cable for short circuit or open circuit.

EM
LC


RADIO INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and speakers connected (If radio or speaker is removed for inspection, supply a ground to the case using a jumper wire.)

EC
FE
CL

Location of Antenna



MEL360D

MT
AT
FA
RA
BR
ST
BF
HA

EL




IDX

AUDIO AND POWER ANTENNA

Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.
2. Withdraw antenna rod while raising it by operating antenna motor.




INSTALLATION

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.


Window Antenna Repair

ELEMENT CHECK


1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.



2. If an element is broken, no continuity will exist.



3. To locate broken point, move probe along element. Tester needle will swing abruptly when probe passes the point.




ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-98).

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location



MEL365D

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse (No. **12**, located in the fuse block in the HEC)
- to ASCD main switch terminal **1** and
- to ASCD hold relay terminal **5** and ASCD clutch switch relay terminal **1** (M/T models).

GI

When ASCD main switch is in the ON position, power is supplied

- from terminal **2** of the ASCD main switch
- to ASCD control unit terminal **4** and
- from terminal **3** of the ASCD main switch
- to ASCD hold relay terminal **1**.

MA

Ground is supplied

- to ASCD hold relay terminal **2**
- through body grounds **E5** and **E30**.

EM

LC

With power and ground supplied, the ASCD hold relay is activated, and power is supplied

- from terminal **3** of the ASCD hold relay
- to ASCD clutch switch relay terminal **6** (M/T models) or
- to inhibitor relay terminal **3** (A/T models).

EC

Power remains supplied also to ASCD control unit terminal **4** when the ASCD main switch is released to the N (neutral) position.

FE

Ground is supplied

- to ASCD control unit terminal **3**
- through body grounds **M13** and **M73**.

CL

Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- inhibitor relay (A/T models)
- ASCD clutch switch (M/T models) and
- ASCD cancel switch.

MT

AT

FA

A vehicle speed input is supplied

- from terminal **14** of the combination meter
- to ASCD control unit terminal **7**

RA

Power is supplied at all times

- to stop lamp switch terminal **1**
- through 15A fuse (No. **10**, located in the fuse block in the HEC).

BR

When the brake pedal is depressed, power is supplied

- from terminal **2** of the stop lamp switch
- to ASCD control unit terminal **11**.

ST

Power is supplied at all times

- through 10A fuse (No. **53**, located in the fuse and fusible link box)
- to horn relay terminal **2**
- through terminal **1** of the horn relay
- to ASCD steering switch terminal **12**.

BF

HA

When the SET/COAST switch is depressed, power is supplied

- from terminal **14** of the ASCD steering switch
- to ASCD control unit terminal **2**.

EL

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal **13** of the ASCD steering switch
- to ASCD control unit terminal **1**.

IDX

When the ASCD CANCEL switch is depressed, power is supplied

- to ASCD control unit terminals **1** and **2**.

When the system is activated, power is supplied

- to ASCD control unit terminal **1**.

Power is interrupted when

- the shift lever is placed in P or N (A/T models)
- the clutch pedal is depressed (M/T models) or

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

- the brake pedal is depressed.

Outputs

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD actuator consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal ⑧ of the ASCD control unit
- to ASCD pump terminal ①.

Ground is supplied to the vacuum motor

- from terminal ⑨ of the ASCD control unit
- to ASCD pump terminal ④.

Ground is supplied to the air valve

- from terminal ⑩ of the ASCD control unit
- to ASCD pump terminal ②.

Ground is supplied to the release valve

- from terminal ⑭ of the ASCD control unit
- to ASCD pump terminal ③.

When the system is activated, power is supplied

- from terminal ⑬ of the ASCD control unit
- to combination meter terminal ⑧ and
- to A/T control unit terminal ⑳ (A/T models).

Ground is supplied

- to combination meter terminal ㉑
- through body grounds ㉒ and ㉓.

With power and ground supplied, the CRUISE indicator illuminates.

When the RESUME/ACCEL button is depressed on A/T models, a signal is sent


- from terminal ⑫ of the ASCD control unit
- to A/T control unit terminal ㉔.

When this occurs, the A/T control unit cancels overdrive.



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —

EL-ASCD-01



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX




Refer to last page (Foldout page).

(M3, E101)
(M1)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-02



⬠ AT : AT models
⬠ MT : MT models

Refer to "EL-POWER".

Preceding page


Preceding page

Preceding page

To EL-START


Refer to last page (Foldout page).

M3, E101




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).

- (M3), (E101)
- (M1)
- (M25)
- (M21)





IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-04





Refer to last page (Foldout page).

M3, E101
M36

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-05



Refer to last page (Foldout page).

(M1)
(M22)

(2) (1) (F43) (GY)


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL


IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic



AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Trouble Diagnoses

CONSULT

1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA


EL

IDX




3. Turn on ignition switch.
4. Turn on ASCD main switch.
5. Touch START (on CONSULT display).
6. Touch ASCD.
7. Touch SELF-DIAG RESULTS.

- Self-diagnostic results are shown on display. Refer to table on the next page.




8. Touch DATA MONITOR.



- Touch START.
- Data monitor results are shown on display. Refer to table on the next page.

For further information, read the CONSULT Operation Manual.



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Self-diagnostic results

Diagnostic item	Description
* NO SELF DIAGNOSTIC FAILURE INDICATED. FURTHER TESTING MAY BE REQUIRED.**	<ul style="list-style-type: none">● Even if no self diagnostic failure is indicated, further testing may be required as far as the customer complains.
POWER SUPPLY-VALVE	<ul style="list-style-type: none">● The power supply circuit for the valves is open. (An abnormally high voltage is entered.)
VACUUM PUMP	<ul style="list-style-type: none">● The vacuum pump circuit is open or shorted. (An abnormally high or low voltage is entered.)
AIR VALVE	<ul style="list-style-type: none">● The air valve circuit is open or shorted. (An abnormally high or low voltage is entered.)
VHCL SP-S/FAILSAFE	<ul style="list-style-type: none">● The vehicle speed sensor or the fail-safe circuit is malfunctioning.
CONTROL UNIT	<ul style="list-style-type: none">● The ASCD control unit is malfunctioning.
RELEASE VALVE	<ul style="list-style-type: none">● The release valve circuit is open or shorted. (An abnormally high or low voltage is entered.)
BRAKE SW/STOP/L SW	<ul style="list-style-type: none">● The brake switch or stop lamp switch is malfunctioning.

Data monitor

Monitored item	Description
BRAKE SW	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the brake switch circuit.
STOP LAMP SW	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the stop lamp switch circuit.
SET SW	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the set switch circuit.
RESUME/ACC SW	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the resume/accelerate switch circuit.
CANCEL SW	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the cancel circuit.
VHCL SPEED SE	<ul style="list-style-type: none">● The present vehicle speed computed from the vehicle speed sensor signal is displayed.
SET VHCL SPD	<ul style="list-style-type: none">● The preset vehicle speed is displayed.
VACUUM PUMP	<ul style="list-style-type: none">● The operation time of the vacuum pump is displayed.
AIR VALVE	<ul style="list-style-type: none">● The operation time of the air valve is displayed.
PW SUP-VALVE	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the circuit for the air valve and the release valve.
CRUISE LAMP	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the cruise lamp circuit.
A/T-OD CANCEL	<ul style="list-style-type: none">● Indicates [ON/OFF] condition of the OD cancel circuit.
FAIL SAFE-LOW	<ul style="list-style-type: none">● The fail-safe (LOW) circuit function is displayed.
FAIL SAFE-SPD	<ul style="list-style-type: none">● The fail-safe (SPEED) circuit function is displayed.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	Diagnostic Procedure								Electrical Components Inspection							
	EL-124	EL-128	EL-128	EL-129	EL-129	EL-131	EL-132	EL-134	EL-135	EL-136	EL-136	EL-137	EL-137	EL-137	EL-137	
REFERENCE PAGE	EL-124	EL-128	EL-128	EL-129	EL-129	EL-131	EL-132	EL-134	EL-135	EL-136	EL-136	EL-137	EL-137	EL-137	EL-137	
SYMPTOM	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	ASCD wire adjustment	ASCD actuator/ASCD pump	ASCD main switch	ASCD steering switch	ASCD cancel switch and stop lamp switch	ASCD clutch switch	Inhibitor switch	Vehicle speed sensor
ASCD control unit cannot be set properly.	○									○	○	○	○	○	○	○
Engine hunts		○							○	○						
Large difference between set speed and actual vehicle speed.			○						○	○						
Deceleration is greatest immediately after ASCD has been set.				○					○	○						
ACCEL switch will not operate.	○					○						○				
RESUME switch will not operate.	○						○					○	○			
Set speed cannot be canceled.					○				○	○			○	○		
"CRUISE" indicator lamp blinks.								○		○		○	○			


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)







Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1




SYMPTOM: ASCD control cannot be set.



1. Turn ignition switch ON.
2. Turn ASCD main switch "ON" to make sure indicators illuminate.








- CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT.**
1. Disconnect ASCD control unit connector.
 2. Turn ignition switch ON.
 3. Turn ASCD main switch "ON".
 4. Check voltage between control unit connector terminals ④ and ③. **Battery voltage should exist.**



Ⓐ
(Next page)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




(Next page)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

E



☆ MONITOR ☆ NO FAIL

VHCL SPEED SE 45mph


RECORD

SEL084T


B

E

CHECK VEHICLE SPEED SENSOR CIRCUIT.

 See "VHCL SPEED SE" in "Data monitor" mode while driving.

OR

 1. Apply wheel chocks and jack up rear of vehicle.
2. Disconnect control unit connector.
3. Connect voltmeter between control unit harness terminals ⑦ and ③.
4. Slowly turn rear wheel.
5. Check deflection of voltmeter pointer.

OK

NG

CHECK VEHICLE SPEED SENSOR.
Refer to "Electrical Components Inspection" (EL-138).

OK


NG

Replace.

Check and repair harness.

E

ASCD control unit connector (M30)



SEL525T

OK

CHECK ASCD ACTUATOR/ASCD PUMP.
Refer to "Electrical Components Inspection" (EL-136).

OK

NG


Replace.

(Next page)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

F



☆ MONITOR ☆ NO FAIL


PW SUP-VALVE ON

RECORD

SEL860R

F


ASCSD control unit connector (M30)



SEL526T

G

ASCSD control unit connector (M30)



SEL527T

Ⓢ

F

CHECK OUTPUT FOR ASCD ACTUATOR/ASCSD PUMP.

1. Read out "PW SUP- VALVE" in "Data monitor" mode while driving.

PW SUP-VALVE:
ON (When ASCD is operating.)
OFF (When ASCD is not operating.)

OR

1. Turn ignition switch ON.
2. Check voltage between control unit harness terminals ⑧ and ⑨.

Voltage is 0V.

NG → Replace ASCD control unit.

OK

G

1. Disconnect ASCD control unit connector.

2. Measure resistance between control unit harness terminals ⑧ and ⑨, ⑩, ⑭.

Terminals	Resistance [Ω]	
⑧	⑨	Approx. 8 - 45
	⑩	Approx. 65
	⑭	Approx. 65

OK → Replace ASCD control unit.

NG

Repair short or open circuit in ASCD pump.


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 2

SYMPTOM: Engine hunts.



DIAGNOSTIC PROCEDURE 3

SYMPTOM: Large difference between set vehicle speed and actual speed.




AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Deceleration is greatest immediately after ASCD has been set.




GI
MA
EM
LC
EC
FE
CL



DIAGNOSTIC PROCEDURE 5

SYMPTOM: Set speed cannot be cancelled.






MT
AT
FA
RA
BR
ST
BF
HA

OK
ⓐ
(Next page)

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: ACCEL switch will not operate.

A



☆ MONITOR ☆ NO FAIL


RESUME/ACC SW ON

RECORD

SEL861R

A


ASCD control unit connector (M30)




SEL530T

B

RESUME/ACCEL switch "ON"



SEL862R



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: RESUME switch will not operate.

A



☆ MONITOR ☆ NO FAIL


RESUME/ACC SW ON

RECORD

SEL863R

A


ASCD control unit connector (M30)



SEL530T


B

SET/COAST switch "ON"




SEL864R


C



Brake pedal





SEL865R



(Next page)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL



IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: "CRUISE" indicator lamp blinks.




Terminals	Resistance [Ω]	
⑧	⑨	Approx. 8 - 45
	⑩	Approx. 65
	⑭	Approx. 65

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD WIRE ADJUSTMENT



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

1. Loosen lock nut and adjusting nut.
2. Make sure that accelerator wire is properly adjusted. (Refer to FE section, "ACCELERATOR CONTROL SYSTEM".)
3. Tighten adjusting nut until throttle drum just starts to move.
4. Loosen adjusting nut again 1/2 to 1 turn.
5. Tighten lock nut.

GI
MA
EM
LC
EC
FE
CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX







AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

ASCD actuator/ASCD pump

1. Disconnect ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.



ASCD main switch

Check continuity between terminals by pushing switch to each position.


Switch position	Terminals					
	1	2	3	4	5	6
ON	○	○	○	○		
N		○	○	○		ILL.
OFF						

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD steering switch

Check continuity between terminals by pushing each button.



Button	Terminal		
	12	13	14
SET/COAST	○	○	○
RESUME/ACCEL	○	○	○
CANCEL	○	▶	○
	○	▶	○

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

IDX


ASCD cancel switch and stop lamp switch



Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No


Check each switch after adjusting brake pedal — refer to BR section.

Clutch switch (For M/T models)



Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

Inhibitor switch (For A/T models)




Condition	Continuity
When shift lever position is "N" or "P"	Yes
When shift lever position is not "N" or "P"	No

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Vehicle speed sensor

1. Remove vehicle speed sensor from transaxle.
2. Turn vehicle speed sensor pinion quickly and measure voltage across **(a)** and **(b)**.



Overall Description


OUTLINE

The In-Vehicle Multiplexing System, IVMS (LAN system), consists of a BCM (Body Control Module) and five LCU's (Local Control Units). Some switches and electrical loads are connected to each LCU. Some electrical systems are directly connected to the BCM. Control of each LCU, (which is provided by a switch and electrical load), is accomplished by the BCM, via two multiplex data lines (A and B) connected between the two. Refer to the System Diagram (EL-142).

BCM (Body Control Module)


The BCM, which is a master unit of the IVMS (LAN), consists of microprocessor, memory and communication LSI sections and has communication and control functions. It receives data signals from the LCUs and sends electrical load data signals to them.

The BCM is described as a "control assembly (for IVMS)" in the Parts Catalog.



The auto amp. for auto air conditioner, if equipped, is built into the BCM. The BCM connectors are located on the front side of the BCM. Do not be confused with the auto amp. connectors on the rear side of the BCM.

NOTE: The auto amp. function has nothing to do with the IVMS.



LCU (Local Control Unit)

The LCU's, which are slave units of the BCM, have only a communication function and consist of communication LSI and input-output interface circuits. They receive data signals from the BCM, control the ON/OFF operations of electrical loads and the sleep operation, as well as send switch signals to the BCM.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

Overall Description (Cont'd)


CONTROLLED SYSTEMS

The IVMS controls several body-electrical systems. The systems included in the IVMS are as follows:

- Power window
- Power door lock
- Time control system
 - Intermittent wiper
 - Rear window defogger timer
 - Ignition key warning
 - Light warning
 - Interior lamp and ignition keyhole illumination timer
 - Seat belt warning
 - Battery saver
- Step lamps
- Multi-remote control system
- Illumination
- Theft warning system
- Interior lamp (ON-OFF control)
- Trouble-diagnosing system
 - with CONSULT
 - ON-BOARD


Also, IVMS has the "sleep/wake-up control" function. IVMS puts itself (the whole IVMS system) to sleep under certain conditions to prevent unnecessary power consumption. Then, when a certain input is detected, the system wakes itself up. For more detailed information, refer to "Sleep/Wake-up Control" (EL-143).

Component Parts Location




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

System Diagram



Sleep/Wake-up Control


SLEEP CONTROL



"Sleep" control prevents unnecessary power consumption. About 30 seconds after the following conditions are met, the BCM suspends the communication between itself and all LCU's. The whole IVMS system is set in the "sleep" mode.

- Ignition switch "OFF"
- All electrical loads (in the IVMS) "OFF" (except the security indicator lamp)
- Timer "OFF"

WAKE-UP CONTROL



As shown above, when the BCM detects a "wake-up" signal, it wakes up the whole system and starts communicating again. The "sleep" mode of all LCU's is now canceled, and the BCM returns to the normal control mode. When any one of the following switches are turned ON, the "sleep" mode is canceled:

- Ignition key switch (Insert)*
- Ignition switch "ACC" or "ON"
- Lighting switch (1st)
- Door switches (all doors)
- Trunk lid unlock switch
- Trunk lid key cylinder tamper switch
- Trunk room lamp switch
- Hood switch
- Door unlock sensors (all doors)
- Door key cylinder tamper switches (front doors)
- Door key cylinder lock switches and unlock switches (front doors)

* Also, when key is pulled out of ignition (ignition key switch is turned from ON to OFF), the "sleep" mode is canceled.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Fail-safe System


SYSTEM DESCRIPTION

Fail-safe system operates when the computing function of the BCM is judged to be malfunctioning. If BCM sends no signal or an abnormal signal to an LCU 15 times in succession, the LCU is set in a fail-safe condition. During the fail-safe condition, operation of each electrical load is as indicated in the table below.

Control system	Electrical load	Operation	Remarks
Power window control	Front power window motor LH (UP/DOWN)	Does not operate.	
	Front power window motor RH (UP/DOWN)	Does not operate.	
	Rear power window motor LH (UP/DOWN)	Does not operate.	
	Rear power window motor RH (UP/DOWN)	Does not operate.	
Power door lock control	Door lock motor (driver side) (LOCK/UNLOCK)	Does not operate.	
	Door lock motor (passenger side) (LOCK/UNLOCK)	Does not operate.	
	Door lock motor (rear LH) (LOCK/UNLOCK)	Does not operate.	
	Door lock motor (rear RH) (LOCK/UNLOCK)	Does not operate.	
Rear window defogger timer control (Door mirror defogger is synchronized)	<ul style="list-style-type: none"> ● Rear window defogger ● Door mirror defogger 	Operates.	
Ignition key warning control	Chime	Operates.	
Light warning control	Chime	Operates.	
Interior lamp timer control	Interior lamp	Operates.	
	Ignition keyhole illumination	Operates.	
Seat belt timer control	Chime	Operates.	
Wiper control	<ul style="list-style-type: none"> ● Intermittent wiper ● Washer and wiper combination 	Operates.	
Theft warning control	Theft warning horn relay-1 and -2	Operates.	
	Theft warning relay-1 and -2	Operates.	
	Security indicator lamp	Operates.	
Step lamp control	Step lamp (driver side)	Goes off.	
	Step lamp (passenger side)	Goes off.	
	Step lamp (rear LH)	Goes off.	
	Step lamp (rear RH)	Goes off.	
Illumination control	Power window switch illumination (All doors)	Goes off.	
Multi-remote control	Trunk lid opener actuator	Does not operate.	Cannot be operated by multi-remote controller
	Hazard warning lamps	Does not operate.	
Interior lamp ON-OFF control	Interior lamp	Operates.	

Work Flow


- The IVMS may be diagnosed with the CONSULT or by the on-board diagnosis system.



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX

NOTICE:


When LCU connectors are disconnected for more than one minute as in trouble diagnoses, the "disconnected" data will be memorized by the BCM. "IVMS communication diagnosis" with CONSULT will indicate "PAST NO RESPONSE" after the LCU connectors are connected.




Consult

CONSULT INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.
(The data link connector is located in left dash side panel.)



3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "LAN".



6. Perform each diagnostic item according to the function chart as follows:

For further information, read the CONSULT Operation Manual.

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Consult (Cont'd)

DIAGNOSTIC ITEMS APPLICATION

Test item	Diagnosed system	MODE				
		LAN COMM DIAGNOSIS	WAKE-UP DIAGNOSIS	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST
LAN-COMM CHECK	IVMS (LAN) communication and wake-up function	X	X			
POWER WINDOW	Power window				X	X
DOOR LOCK	Power door lock			X	X	X
WIPER	Wiper and washer				X	X
REAR DEFOGGER	Rear window defogger				X	X
IGN KEY WARN ALM	Ignition key warning chime				X	X
LIGHT WARN ALM	Light warning chime				X	X
ROOM LAMP TIMER	Interior lamp timer				X	X
SEAT BELT TIMER	Seat belt timer				X	X
THEFT WARNING SYSTEM	Theft warning system				X	X
STEP LAMP	Step lamps				X	X
ILLUM LAMP	Interior lamp				X	X
MULTI-REMOTE CONT SYS	Multi-remote control				X	X

X: Applicable

For diagnostic item in each control system, read the CONSULT Operation Manual.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Consult (Cont'd)

IVMS COMMUNICATION DIAGNOSIS



Consult (Cont'd)

DIAGNOSTIC CHART

Diagnostic item	Diagnostic explanation	Number of malfunctioning LCU's	Expected cause	Service procedure
[COMM FAIL] (Communication malfunctioning)	A communication signal is sent from the BCM to all LCU's. LCU's return a signal to the BCM as they receive the signal above. The signals sent from the BCM and returned from LCU's should be the same. If they are different, LCU(s) and/or communication between the BCM and LCU's are malfunctioning.	One	1. Poor connection at LCU connector 2. Open or short circuit in the data lines A and/or B 3. Ground circuit of the LCU open 4. Malfunctioning LCU	1. Check for connector looseness. 2. Check continuity of the data line circuits between the LCU in question and harness-to-harness connector. 3. Check ground circuit of the LCU in question. 4. Replace the LCU in question.
[A-LINE NO RESPONSE]* (Communication via data line A not responded)	A communication signal is sent from the BCM to LCU's via data lines A and B. LCU's return the signal via the data line A. If the signal does not return, the data line A is malfunctioning.	All	1. Open or short circuit in the data lines. 2. Malfunctioning BCM	1. Check continuity of the data line circuits between the BCM and harness-to-harness connector. 2. Replace the BCM.
[B-LINE NO RESPONSE]* (Communication via data line B not responded)	A communication signal is sent from the BCM to LCU's via data lines A and B. LCU's return the signal via the data line B. If the signal does not return, the data line B is malfunctioning.	One	1. Poor connection in the data line A at the LCU connector 2. Open circuit in the data line A 3. Malfunctioning LCU	1. Check for connector looseness. 2. Check continuity of the data line A circuit between the LCU in question and harness-to-harness connector. 3. Replace the LCU in question.
		Two or more	1. Poor connections at LCU connectors or harness-to-harness connectors 2. Open circuit in the data line A 3. Malfunctioning LCU	1. Check for connector looseness. 2. Check continuity of the data line A circuit for the LCU's in question. 3. Replace the LCU in question.
		All	1. Short circuit in the data line A with ground 2. Poor connection in the data line A at the BCM connectors 3. Open circuit in the data line A between the BCM and harness-to-harness connector 4. Malfunctioning BCM	1. Check continuity between data line A terminal of BCM connectors and ground. 2. Check for connector looseness. 3. Check continuity of the data line A circuit for the BCM. 4. Replace BCM.
		One	1. Poor connection in the data line B at the LCU connector 2. Open circuit in the data line B 3. Malfunctioning LCU	1. Check for connector looseness. 2. Check continuity of the data line B circuit between the LCU in question and harness-to-harness connector. 3. Replace the LCU in question.
		Two or more	1. Poor connection at LCU connectors or harness-to-harness connectors 2. Open circuit in the data line B 3. Malfunctioning LCU	1. Check for connector looseness. 2. Check continuity of the data line B circuit for the LCU's in question. 3. Replace the LCU in question.
		All	1. Short circuit in the data line B with ground 2. Poor connection in the data line B at the BCM connectors 3. Open circuit in the data line B between the BCM and harness-to-harness connector 4. Malfunctioning BCM	1. Check continuity between data line B terminal of the BCM connectors and ground. 2. Check for connector looseness. 3. Check continuity of the data line B circuit for the BCM. 4. Replace BCM.

*: There may be cases that a malfunction is detected in one of the two data lines but all systems in the IVMS (such as power window or power door lock) are functioning correctly. In such cases, it is not essential to repair the malfunctioning data line. This is because communication is still accomplished via the other data line that is functioning.

EL
IDX
HA
BF
ST
BR
RA
FA
AT
MT
CL
FE
EC
LC
EM
MA
GI


Consult (Cont'd)

Diagnostic item	Diagnostic explanation	Number of malfunctioning LCU's	Expected cause	Service procedure
<p>[A-LINE NO RESPONSE] [B-LINE NO RESPONSE] (Communication via data lines A and B not responded)</p>	<p>A communication signal is sent from the BCM to LCU's via data lines A and B. LCU's return the signal via the data lines A and B. If the signal does not return, the data lines A and B are malfunctioning.</p>	<p>One</p> <p>Two or more</p> <p>All</p>	<p>1. Open circuit in the power source for the LCU in question. 2. Poor connection at LCU connector 3. Open circuit in the data lines A and B 4. Open circuit in LCU ground 5. Malfunctioning LCU</p> <p>1. Open circuit in the power source for the LCU's in question 2. Poor connection at LCU connectors or harness-to-harness connectors 3. Open circuit in the data lines A and B 4. Malfunctioning LCU's</p> <p>1. Short circuit between data lines A and B 2. Short circuits in the data lines A and B with ground 3. Poor connection at the BCM connectors 4. Open circuit in the data lines A and B between the BCM and harness-to-harness connectors 5. Malfunctioning BCM</p>	<p>1. Check fuse, fusible link, circuit breaker or harness. 2. Check for connector looseness. 3. Check continuity of each data line between the LCU in question and harness-to-harness connectors. 4. Check ground circuit of the LCU in question. 5. Replace the LCU in question.</p> <p>1. Check fuse, fusible link, circuit breaker or harness. 2. Check for connector looseness. 3. Check continuity of each data line between the LCU's in question and harness-to-harness connectors. 4. Replace the LCU's in question.</p> <p>1. Check continuity between data lines A and B. 2. Check continuity between data line terminals of the BCM connectors and ground. 3. Check for connector looseness. 4. Check continuity of each data line between the BCM and harness-to-harness connectors. 5. Replace the BCM.</p>
<p>[COMM FAIL] [A-LINE NO RESPONSE] [B-LINE NO RESPONSE]</p>	<p>All malfunctions indicated above are evident.</p>	<p>One</p> <p>Two or more</p> <p>All</p>	<p>1. Open circuit in LCU ground 1. Open circuits in LCU grounds 1. Malfunctioning BCM</p>	<p>1. Check ground circuit of the LCU in question. 1. Check ground circuits of the LCU's in question. 1. Replace BCM.</p>

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Consult (Cont'd)

WAKE-UP DIAGNOSIS



*: LCU may be the cause of a problem, but this is rarely the case.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA


EL

IDX


Consult (Cont'd)

POWER DOOR LOCK — Self-diagnostic results

Diagnostic procedure




- A**
- 1) Choose "**DOOR LOCK**" in SELECT TEST ITEM.
 - 2) Touch "**SELF-DIAG RESULTS**" of SELECT DIAG mode.
 - 3) Touch "**START**".



B

Start self-diagnosis on all door motors. Lock and unlock all doors by operating door motors automatically.




C D

Diagnostic contents are as shown in the figure at left.

C : When no malfunction is detected

D : When malfunction is detected

A summary of diagnostic results is given in the following chart.



IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Consult (Cont'd)

Power door lock result list

Diagnostic item	Explanation	Repair order
*NO SELF DIAGNOSTIC FAILURE INDICATED/FURTHER TESTING MAY BE REQUIRED.**	Normal The door lock system is in good order.	—
DOOR LOCK MOTOR-DR	The circuit for the driver side door lock motor is malfunctioning.	1. Visually check the wiring harness connections. 2. Diagnose the door lock motor circuit referring to the DIAGNOSTIC PROCEDURES of "POWER DOOR LOCK — IVMS" (EL-197).
DOOR LOCK MOTOR-AS	The circuit for the passenger side door lock motor is malfunctioning.	
DOOR LOCK MOTOR-RR/RH	The circuit for the rear RH side door lock motor is malfunctioning.	
DOOR LOCK MOTOR-RR/LH	The circuit for the rear LH side door lock motor is malfunctioning.	

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL

IDX



On-board Diagnosis


SELF-DIAGNOSTIC RESULTS INDICATOR LAMP

The interior lamp and step lamps (front seats) act as the indicators for the on-board diagnosis. These lamps blink simultaneously in response to self-diagnostic results.

SELF-DIAGNOSTIC FUNCTION

Mode	Function	Self-diagnostic results indicator lamp	
		Interior lamp	Step lamps (front seats)
Mode I	IVMS communication diagnosis	X	X
Mode II	Switch monitor	X	X
Mode III	Power door lock operation	X	X
Mode IV	Power window monitor	X	X


X : applicable



On-board Diagnosis — Mode I (IVMS communication diagnosis)

HOW TO PERFORM MODE I

- Condition
- Ignition switch: OFF
 - Headlamp switch: OFF
 - Rear window defogger switch: OFF
 - Doors: Closed
 - Interior lamp: Center "O" position



*: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL


IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

On-board Diagnosis — Mode I (IVMS communication diagnosis) (Cont'd)

DESCRIPTION

In this mode, a malfunction code is indicated by the number of flashes from the interior lamp and front step lamps as shown below:




After indicator lamp turns on for 2 seconds then off for 2 seconds, it flashes [cycling ON (0.5 sec.)/OFF (0.5 sec.)] to indicate a malfunction code of the 10th digit. Then, 1 second after indicator lamp turns off, it again flashes [cycling ON (0.5 sec.)/OFF (0.5 sec.)] to indicate a malfunction code of the 1st digit.

For example, the indicator lamp goes on and off for 0.5 seconds twice and after 1.0 seconds, it goes on and off for 0.5 seconds four times. This indicates malfunction code "24". The self-diagnostic results will remain in the BCM memory.

Malfunction code table

Code No.	Malfunctioning LCU	Detected items	Diagnostic procedure
24	Driver door control unit (LCU01)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-149).
25		No response from data line A	Refer to Consult DIAGNOSTIC CHART, "A-LINE NO RESPONSE" (EL-149).
26		No response from data line B	Refer to Consult DIAGNOSTIC CHART, "B-LINE NO RESPONSE" (EL-149).
34	Passenger door control unit (LCU02)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-149).
35		No response from data line A	Refer to Consult DIAGNOSTIC CHART, "A-LINE NO RESPONSE" (EL-149).
36		No response from data line B	Refer to Consult DIAGNOSTIC CHART, "B-LINE NO RESPONSE" (EL-149).
41	Rear LH door control unit (LCU03)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-149).
42		No response from data line A	Refer to Consult DIAGNOSTIC CHART, "A-LINE NO RESPONSE" (EL-149).
43		No response from data line B	Refer to Consult DIAGNOSTIC CHART, "B-LINE NO RESPONSE" (EL-149).
44	Rear RH door control unit (LCU04)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-149).
45		No response from data line A	Refer to Consult DIAGNOSTIC CHART, "A-LINE NO RESPONSE" (EL-149).
46		No response from data line B	Refer to Consult DIAGNOSTIC CHART, "B-LINE NO RESPONSE" (EL-149).
54	Multi-remote control unit (LCU05)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-149).
55		No response from data line A	Refer to Consult DIAGNOSTIC CHART, "A-LINE NO RESPONSE" (EL-149).
56		No response from data line B	Refer to Consult DIAGNOSTIC CHART, "B-LINE NO RESPONSE" (EL-149).



On-board Diagnosis — Mode II (Switch monitor)

HOW TO PERFORM MODE II

- Condition
- Ignition switch: OFF
 - Headlamp switch: OFF
 - Rear window defogger switch: OFF
 - Doors: Closed
 - Interior lamp: Center "○" position

Turn ignition switch "ON".

Return ignition switch to "OFF" and press rear window defogger switch more than 10 times during 10 seconds.

Self-diagnostic results indicator lamps should turn on.

Turn ignition switch "ON" within 5 seconds after the indicator lamps turn on.

Indicator lamps turn off.

After a second

Mode II is performed.

Turn ignition switch "OFF".

DIAGNOSIS END

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL


IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

On-board Diagnosis — Mode II (Switch monitor) (Cont'd)

DESCRIPTION


In this mode, when BCM detects the input signal from a switch in IVMS as shown below, the detection is indicated by the interior lamp and front step lamps with buzzer.



SEL396SA

Switch monitor item

BCM	<ul style="list-style-type: none"> ● Hood switch ● Trunk room lamp switch ● Trunk lid key cylinder tamper switch ● Trunk lid unlock switch ● Door switches ● Headlamp switch (1st) ● Wiper switch (INT) ● Wiper switch (WASH) ● Door switch (driver's side) ● Door switch (passenger side) ● Seat belt buckle switch 	LCU 02	<ul style="list-style-type: none"> ● Door key cylinder switch ● Key cylinder tamper switch ● Door unlock sensor ● Passenger power window sub-switch (UP/DOWN) 	
		LCU 03	<ul style="list-style-type: none"> ● Power window sub-switch (Rear RH) (UP/DOWN) 	
		LCU 04	<ul style="list-style-type: none"> ● Power window sub-switch (Rear LH) (UP/DOWN) 	
LCU 01	<ul style="list-style-type: none"> ● Power window lock switch ● Power window main switches (UP/DOWN) ● Power window automatic switch ● Illumination control switch ● Door lock & unlock switch (LOCK/UNLOCK) ● Door key cylinder switch ● Key cylinder tamper switch 	LCU 05	<ul style="list-style-type: none"> ● Door lock button ● Door unlock button ● Interior lamp button ● Trunk lid opener button 	Operated by multi-remote controller




On-board Diagnosis — Mode III (Power door lock operation)

HOW TO PERFORM MODE III

Condition

- Ignition switch: OFF
- Headlamp switch 1st: ON
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp: Center "O" position



*: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL


IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

On-board Diagnosis — Mode III (Power door lock operation) (Cont'd)

DESCRIPTION

In this mode, a malfunction code is indicated by the number of flashes from the interior lamp and front step lamps as shown below:




After indicator lamp turns ON for 2 seconds and then turns OFF, it flashes to indicate a malfunction code. For example, the indicator lamp goes on and off for 0.5 seconds three times. This indicates malfunction code "3".

The self-diagnostic results will remain in the BCM memory.

Malfunction code table


Code No.	Detected items	Repair order
1	Front LH door lock motor circuit	1. Visually check the wiring harness connections. 2. Diagnose the door lock motor circuit referring to the DIAGNOSTIC PROCEDURES of "POWER DOOR LOCK — IVMS" (EL-197).
2	Front RH door lock motor circuit	
3	Rear RH door lock motor circuit	
4	Rear LH door lock motor circuit	
9	No malfunction in the above circuit	—



On-board Diagnosis — Mode IV (Power window monitor)

HOW TO PERFORM MODE IV

- Condition
- Ignition switch: OFF
 - Headlamp switch 1st: ON
 - Rear window defogger switch: OFF
 - Front LH window: Closed
 - Doors: Closed
 - Interior lamp: Center "O" position



*: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

GI
MA
EM
LC
EC
FE
CL
MT
AT
EA
RA
BR
ST
BF
HA

EL


IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

On-board Diagnosis — Mode IV (Power window monitor) (Cont'd)

DESCRIPTION

In mode IV, front LH window is automatically operated. In conjunction with power window motor (DOWN) "ON", indicator lamps (interior lamp and front step lamps) turn on. When power window "lock" is detected, power window motor will stop and the indicator lamps will turn off.




NOTE: As soon as manual switches (each seat's power window switch) turn ON, front LH power window motor (DOWN) stops and diagnosis ends.

* While power window motor is being operated, electrical ripple occurs.

Body Control Module (BCM)

CIRCUIT DIAGRAM



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

IVMS (LAN) — TROUBLE DIAGNOSES

Body Control Module (BCM) (Cont'd)

INPUT/OUTPUT OPERATION SIGNAL

Terminal No.	Connections	INPUT (I)/ OUTPUT (O)	Operated condition	Voltage (V) (Approximate values)	
1	Power source	—	—	12	
2	Theft warning indicator	O	Theft warning control	Illuminated	0
				Turned off	12
3	Ground	—	—	—	
4	—	—	—	—	
5	Interior lamp	O	ON (Illuminated)	0	
			OFF	12	
6	Ground	—	—	—	
7	—	—	—	—	
8	—	—	—	—	
9	Seat belt switch	I	When the seat belt is fastened	12	
			When the seat belt is not fastened	0	
10	Wiper amplifier (ON signal)	O	Wiper switch	ON	0
				OFF	12
11	Hazard	O	Flasher lamp	ON	0
				OFF	12
12	Ignition keyhole illumination	O	ON	0	
			OFF	12	
13	Theft warning horn relays and theft warning lamp relay	O	ON	0	
			OFF	12	
14	Theft warning relay	O	Theft warning control	ON	0
				OFF	12
15	Defogger relay	O	Time control	ON	0
				OFF	12
16	Buzzer	O	ON	0	
			OFF	12	
17	Intermittent wiper volume switch	I	Intermittent time	Max. (20 sec)	3.6
				Min. (2 sec)	0
18	Trunk lid unlock switch	I	Unlocked	0	
			Locked	5	
19	Passenger's door switch	I	ON (Open)	0	
			OFF (Closed)	5	
20	Trunk lid tamper switch	I	ON	0	
			OFF	12	
21	Door switches (All doors)	I	Door switch	ON (Open)	0
				OFF (Closed)	12
22	Rear window defogger switch	I	ON	0	
			OFF	5	

IVMS (LAN) — TROUBLE DIAGNOSES

Body Control Module (BCM) (Cont'd)

Terminal No.	Connections	INPUT (I)/ OUTPUT (O)	Operated condition	Voltage (V) (Approximate values)	
23	Ignition key switch (Insert)	I	IGN key removed from ignition key cylinder (OFF)	0	GI
			IGN key inserted into ignition key cylinder (ON)	12	MA
24	Headlamp switch (1ST)	I	1ST, 2ND positions: ON	12	
			OFF	0	EM
25	Wiper switch (Intermittent)	I	ON	0	
			OFF	12	LC
26	Wiper switch (Wash)	I	ON	0	
			OFF	12	EC
27	Vehicle speed pulse	I	Pulse	0 - 5	
28	Ignition switch (ACC)	I	Ignition key in "ACC" position	12	
29	Ignition switch (ON)	I	Ignition key in "ON" position	12	FE
30	Hood switch	I	Open (ON)	0	
			Closed (OFF)	5	CL
31	Driver's door switch	I	Open (ON)	0	
			Closed (OFF)	12	MT
32	Trunk lid open signal	I	Open (ON)	0	
			Closed (OFF)	12	AT
33	Data line (B)	I/O	—	—	
34	CONSULT	On-board diag- nostic results	—	—	FA
35		TX signal	—	—	RA
36		RX signal	—	—	
37		CLK signal	—	—	BR
38	Data line (A)	I/O	—	—	

ST

BF

HA


EL

IDX

Local Control Units (LCU's)

CIRCUIT DIAGRAM


Driver door control unit (LCU01)



IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

Passenger door control unit (LCU02)




GI
MA
EM
LC
ES
FE
CL
VT
AT
FA
RA
BR
ST
BE
HA
EL
FDX


IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

Rear RH door control unit (LCU03)




Rear LH door control unit (LCU04)



IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

Multi-remote control unit (LCU05)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

INPUT/OUTPUT OPERATION SIGNAL

Driver door control unit (LCU01)

Terminal No.	Connections	INPUT (I)/ OUTPUT (O)	Operated condition		Voltage (V) (Approximate values)
1	Data line (A)	I/O	—		—
2	Data line (B)	I/O	—		—
3	Door key cylinder tamper switch	I	ON (Key cylinder removed)		0
			OFF (Key cylinder installed)		12
4	Door unlock sensor	I	Unlocked (ON)		0
			Locked (OFF)		5
5	Door key cylinder unlock switch	I	Unlocked (ON)		0
			Locked (OFF)		12
6	Door key cylinder lock switch	I	Locked (ON)		0
			Unlocked (OFF)		12
7	Headlamp switch (1st)	I	1st, 2nd: ON		12
			OFF		0
8	Step lamp	O	ON		0
			OFF		12
9	—	—	—		—
10	Illumination control sig- nal	I	Brightened - Darkened		0 - 12
11	Power window motor (P/W) — Up	O	Driver's P/W switch	Up	12
				Free	0
12	Power window motor (P/W) — Down	O	Driver's P/W switch	Down	12
				Free	0
13	Power source (C/B)	—	—		12
14	—	—	—		—
15	—	—	—		—
16	Ground	—	—		—
17	Door lock motor — Lock	O	Door lock & unlock switch	Locked	12
				Free	0
18	Door lock motor — Unlock	O	Door lock & unlock switch	Unlocked	12
				Free	0

IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

Passenger door control unit (LCU02)

Terminal No.	Connections	INPUT (I)/ OUTPUT (O)	Operated condition	Voltage (V) (Approximate values)		
1	Data line (A)	I/O	—	—	GI	
2	Data line (B)	I/O	—	—		
3	Door key cylinder tamper switch	I	ON	0	MA	
			OFF	12		
4	Door unlock sensor	I	Unlocked (ON)	0	EM	
			Locked (OFF)	5		
5	Door key cylinder unlock switch	I	Unlocked (ON)	0	LC	
			Locked (OFF)	12		
6	Door key cylinder lock switch	I	Locked (ON)	0	EC	
			Unlocked (OFF)	12		
7	Power source (FUSE)	—	—	12	FE	
8	Step lamp	O	ON	0		
			OFF	12	CL	
9	—	—	—	—		
10	Illumination control sig- nal	I	Brightened - Darkened	0 - 12	MT	
11	Power window motor (P/W) — Up	O	Passenger's P/W switch	Up	12	
				Free	0	AT
12	Power window motor (P/W) — Down	O	Passenger's P/W switch	Down	12	
				Free	0	FA
13	Power source (C/B)	—	—	12		
14	Headlamp switch (1st)	I	1st, 2nd: ON	12	RA	
			OFF	0		
15	—	—	—	—	BR	
16	Ground	—	—	—		
17	Door lock motor — Lock	O	Door lock & unlock switch	Locked	12	ST
				Free	0	
18	Door lock motor — Unlock	O	Door lock & unlock switch	Unlocked	12	BF
				Free	0	

HA

EL

IDX

IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

Rear RH door control unit (LCU03) and rear LH door control unit (LCU04)

Terminal No.	Connections	INPUT (I)/ OUTPUT (O)	Operated condition	Voltage (V) (Approximate values)	
1	Data line (A)	I/O	—	—	
2	Data line (B)	I/O	—	—	
3	—	—	—	—	
4	Door unlock sensor	I	Unlocked (ON)	0	
			Locked (OFF)	5	
5	—	—	—	—	
6	—	—	—	—	
7	Power source (FUSE)	—	—	12	
8	—	—	—	—	
9	—	—	—	—	
10	—	—	—	—	
11	—	—	—	—	
12	Ground	—	—	—	
13	Door lock motor — Lock	O	Door lock & unlock switch	Locked	12
				Free	0
14	Door lock motor — Unlock	O	Door lock & unlock switch	Unlocked	12
				Free	0
15	Power window motor (P/W) — Up	O	Rear P/W switch	Up	12
				Free	0
16	Power window motor (P/W) — Down	O	Rear P/W switch	Down	12
				Free	0
17	Power source (C/B)	—	—	12	
18	—	—	—	—	

IVMS (LAN) — TROUBLE DIAGNOSES

Local Control Units (LCU's) (Cont'd)

Multi-remote control unit (LCU05)

Terminal No.	Connections	INPUT (I)/ OUTPUT (O)	Operated condition	Voltage (V) (Approximate values)	
1	Data line (A)	I/O	—	—	GI
2	Power source	—	—	12	
3	Data line (B)	I/O	—	—	MA
4	Ground	—	—	—	
5	Trunk lid opener actuator	O	Open	0	EM
			OFF	12	
6	—	—	—	—	LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

IDX

Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM —

EL-COMM-01





Refer to last page (Foldout page).

(M3) (E101)

(M36)

IVMS (LAN) — TROUBLE DIAGNOSES

Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM — (Cont'd)



Refer to last page (Foldout page).
 (M3), (E101)
 (M12)
 (M23)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA


EL
 IDX

IVMS (LAN) — TROUBLE DIAGNOSES

Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM — (Cont'd)


EL-COMM-03

▬ : DATA LINE




Refer to last page (Foldout page).

M4, B1






Power Supply and Ground Circuit Check

GROUND CIRCUIT CHECK



Control unit	Terminals	Continuity
BCM	③ - Ground	Yes
	⑥ - Ground	
LCU01	⑩ - Ground	
LCU02	⑫ - Ground	
LCU03	⑫ - Ground	
LCU04	⑫ - Ground	
LCU05	④ - Ground	



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA





EL

IDX

IVMS (LAN) — TROUBLE DIAGNOSES

Power Supply and Ground Circuit Check (Cont'd)








POWER SUPPLY CIRCUIT CHECK



Control unit	Terminals	Ignition switch position			
		OFF	ACC	ON	START
BCM*	① - ③, ⑥	Battery voltage			
	②⑧ - ③, ⑥	Approx. 0V	Battery voltage		Approx. 0V
	②⑨ - ③, ⑥	Approx. 0V		Battery voltage	
LCU01	⑬ - ⑮	Battery voltage			
LCU02	⑬ - ⑮	Battery voltage			
	⑦ - ⑮	Battery voltage			
LCU03 and LCU04	⑦ - ⑫	Battery voltage			
	⑰ - ⑫	Battery voltage			
LCU05	② - ④	Battery voltage			

* CONSULT (data monitor) may be used to check for the ignition switch input (ACC, ON).

Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

System Description

With the ignition switch in the ON or START position, power is supplied

- from 7.5A fuse (No. 12), located in the fuse block in the HEC)
- to BCM terminal 29.

Driver door control unit (LCU01) terminals ① and ② are connected to BCM terminals ④⑧ and ④③ by DATA LINES A and B. Also, driver door control unit terminals ① and ② are connected to front power window regulator LH terminals ② and ① respectively.

Rear LH door control unit (LCU04) and rear RH door control unit (LCU03) terminals ① and ② are connected to BCM terminals ④⑧ and ④③ by DATA LINES A and B. Also, rear LH and RH door control unit terminals ①⑤ and ①⑥ are connected to rear power window regulator LH and RH terminals ② and ① respectively.

Passenger door control unit (LCU02) terminals ① and ② are connected to BCM terminals ④⑧ and ④③ by DATA LINES A and B. Also, passenger door control unit terminals ① and ② are connected to front power window regulator RH terminals ② and ① respectively.

BCM terminals ④⑧ and ④③ connected to multi-remote control unit (LCU05) terminals ① and ③ by DATA LINES A and B.


When a power window switch is pushed, a signal is sent to BCM by DATA LINES. BCM sends a signal to all door control units and all door control units supply power and ground to all power window regulators.

Control by remote controller


When multi-remote control unit receives DOWN signal from remote controller, the signal is sent to all door control units through BCM by DATA LINES. When door control units receive the signal, power and ground are supplied to all power window regulators.

Wiring Diagram — WINDOW —

EL-WINDOW-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF



Refer to last page (Foldout page).

- (M4) (B1)
- (M1)
- (M23)




HA
EL
HX

POWER WINDOW — IVMS

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02


▬ : DATA LINE



POWER WINDOW — IVMS

Wiring Diagram — WINDOW — (Cont'd)


EL-WINDOW-04



Refer to last page (Foldout page).



Schematic



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

Trouble Diagnoses

OPERATIVE CONDITION

- Power windows can be raised or lowered with each sub-switch or the power window main switch located on the driver's door trim when ignition key is in the "ON" position and power window lock switch on the driver's door trim is unlocked.
- When power window lock switch is locked, no windows can be raised or lowered except for driver side window.
- When ignition key is in the "ON" position, to fully open the driver side window, press down completely on the automatic switch (main switch) and release it; it needs not be held. The window will automatically open all the way. To stop the window, press then release the "UP" side of the switch.

TROUBLE SYMPTOM

Perform "IVMS Communication Diagnosis" (EL-148), "Power Supply and Ground Circuit Check" (EL-177) before starting with the following items.

Trouble symptom	Power window lock switch	Power window main switch	Power window sub-switch	Power window regulator
	Procedure 1 (EL-187)	Procedure 2 (EL-187)	Procedure 3 (EL-188)	Procedure 4 (EL-188)
One or more of the sub-switches do not function.			X	X
One or more of the main switches on driver's door trim do not function (including automatic switch).		X		X
Power window lock switch on main switch does not lock and/or unlock all windows.	X			
All power window main switches and sub-switches do not function.	X	X	X	X



The following ABBREVIATIONS are used in this Trouble Diagnoses.

- (FL): Front LH
- (FR): Front RH
- (RL): Rear LH
- (RR): Rear RH

POWER WINDOW — IVMS



Trouble Diagnoses (Cont'd)

PROCEDURE 1 — Power window lock switch



GI
MA
EM
LC
EC
FE
CL

PROCEDURE 2 — Power window main switch (Front LH, RH, Rear LH, RH)



MT
AT
FA
RA
BR
ST
BF
HA

EL

IDX

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

PROCEDURE 3 — Power window sub-switch (Front RH, Rear LH, RH)

A

☆ MONITOR		<input type="checkbox"/>
P/W SW AS-UP	OFF	
P/W SW AS-DWN	OFF	
P/W SW RR-UP	OFF	
P/W SW RR-DWN	OFF	
P/W SW RL-UP	OFF	
P/W SW RL-DWN	OFF	
RECORD		


SEL455T

CHECK POWER WINDOW SUB-SWITCH CIRCUIT FOR MALFUNCTIONING PORTION.

A  CONSULT

See "P/W SW UP or DOWN" in DATA MONITOR mode.
"P/W SW UP or DOWN" should change from "OFF" to "ON" when each sub-switch is turned ON.

OR

 ON-BOARD

Check power window sub-switch operation in Switch monitor (Mode II) mode. (Refer to On-board Diagnoses, EL-157.)

OK

Check IVMS communication (EL-148) and system operation again.

NG

Replace LCU for malfunctioning portion.

- Front RH: LCU02
- Rear LH: LCU04
- Rear RH: LCU03


A

■ ACTIVE TEST ■	
P/W MOTOR-DRIVER	OFF
or	
(P/W MOTOR-ASSIST	OFF)
(P/W MOTOR-RR-RH	OFF)
(P/W MOTOR-RR-LH	OFF)
<input type="button" value="UP"/> <input type="button" value="DWN"/> <input type="button" value="STOP"/>	

SEL480S

PROCEDURE 4 — Power window regulator

A CHECK POWER WINDOW REGULATOR CIRCUIT.

 CONSULT

See "P/W MOTOR" in ACTIVE TEST mode.
 Perform operation shown on display.
Power window motor should operate.

NOTE:
If CONSULT is not available, start with the diagnostic procedure **B.**

OK







Check IVMS communication again (EL-148).

NG

A








(Go to next page.)

Trouble Diagnoses (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Component Parts and Harness Connector Location



SEL549T

System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 7.5A fuse (No. 40), located in the fuse block in the HEC
- to key switch terminal 1.

Power is supplied to BCM terminal 23 through key switch terminal 2 when key switch is in ON position (ignition key is inserted in the key cylinder).

With the ignition switch in ON or START position, power is also supplied

- through 7.5A fuse (No. 12), located in the fuse block in the HEC
- to BCM terminal 29.

BCM terminal 30 is connected to driver door control unit (LCU01) terminal 1, passenger door control unit (LCU02) terminal 1, rear LH door control unit (LCU04) terminal 1, rear RH door control unit (LCU03) terminal 1 and multi-remote control unit (LCU05) terminal 1 by DATA LINE A.

Also, BCM terminal 33 is connected to driver door control unit (LCU01) terminal 2, passenger door control unit (LCU02) terminal 2, rear LH door control unit (LCU04) terminal 2, rear RH door control unit (LCU03) terminal 2 and multi-remote control unit (LCU05) terminal 3 by DATA LINE B.

Ground is supplied

- to BCM terminal 31 or 19
- from front LH or RH door switch terminal 2
- through front LH or RH door switch terminal 3 when door switch is in OPEN position and
- through body grounds B16 and B19.

Ground is supplied

- to driver door control unit (LCU01) terminals 6, 5 or 4
- from front LH door key cylinder switch terminals 1 or 2, or door unlock sensor (in the front LH door lock actuator) terminal 2 when door key cylinder is in BETWEEN FULL STROKE AND N position
- through front LH door key cylinder switch terminal 4 or front LH door lock actuator terminal 4 and
- through body grounds M13 and M73.

Ground is supplied

- to rear LH door control unit (LCU04) or RH (LCU03) terminals 4, 13 or 14
- from door unlock sensor (in the rear LH or RH door lock actuator) terminal 2 when door lock is in UNLOCKED position
- through rear LH or RH door lock actuator terminal 4 and
- through body grounds B16 and B19.

Ground is supplied

- to passenger door control unit (LCU02) terminals 6, 5 or 4
- from front RH door key cylinder switch terminals 1 or 2, or door unlock sensor (in the front RH door lock actuator) terminal 2 when door key cylinder is in BETWEEN FULL STROKE AND N position
- through front RH door key cylinder switch terminal 4 or front RH door lock actuator terminal 4 and
- through body grounds M13 and M73.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL


DX

POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK —


EL-D/LOCK-01

— ■ — ■ — ■ : DATA LINE



Refer to last page (Foldout page).


- (M3) , (E101)
- (M4) , (B1)
- (M36)
- (M1)




POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF





Refer to last page (Foldout page).
M23

HA
EL
IDX

POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-03




Refer to last page (Foldout page).

(M23)

POWER DOOR LOCK — IVMS


Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-04



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA


EL
IDX



Refer to last page (Foldout page).
M4, B1

POWER DOOR LOCK — IVMS

Schematic



MEL423D

Trouble Diagnoses

OPERATIVE CONDITION

- The lock & unlock switch (SW) on driver's door trim can lock and unlock all doors.
- With the lock knob on front LH or RH door set to "LOCK", all doors are locked.
- With the door key inserted in the key cylinder on front LH or RH door, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors.

However, if the ignition key is in the steering key cylinder and one or more of the front doors are open, setting the lock & unlock switch, lock knob, or the door key to "LOCK" locks the doors once but then immediately unlocks them. — (KEY REMINDER DOOR SYSTEM)

If any of the following symptoms occur, key reminder door system is malfunctioning.

- With ignition key removed from the steering key cylinder and all doors closed, operating the lock & unlock switch or lock knob on the front LH or RH door trim unlocks all doors the instant they are locked.
- With ignition key inserted into the steering key cylinder and front LH or RH door opened, operating the lock & unlock switch or lock knob on the front LH or RH door trim to "Lock" does not unlock all doors.

TROUBLE SYMPTOM

Perform "IVMS Communication Diagnoses" (EL-148), "Power Supply and Ground Circuit Check" (EL-177), and "SELF DIAG RESULTS" mode in DOOR LOCK with CONSULT or On-board Diagnosis-Mode III (refer to EL-159) before starting with the following items:

Trouble symptom	Door switch	IGN key switch	Lock & unlock switch	Door key cylinder switch	Lock knob switch (Unlock sensor)	Door lock actuator
	Procedure 1 (EL-198)	Procedure 2 (EL-199)	Procedure 3 (EL-199)	Procedure 4 (EL-200)	Procedure 5 (EL-201)	Procedure 6 (EL-202)
Key reminder door system does not operate properly.	X	X	X	X	X	X
All doors are not locked and/or unlocked when operating lock & unlock switch.			X		X	X
All doors are not locked and/or unlocked when operating front LH or RH door key cylinder switch.				X	X	X
One or more doors are not locked and/or unlocked when operating front door lock knobs, lock & unlock switch and/or door key cylinder switch.					X	X


The following ABBREVIATIONS are used in this Trouble Diagnoses.

- Ⓛ: Front LH
- Ⓡ: Front RH
- Ⓛ: Rear LH
- Ⓡ: Rear RH


POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

PROCEDURE 1 — Door switch



CHECK DOOR SWITCH CIRCUIT.


A  CONSULT

See "DOOR SW DR" and "DOOR SW AS" in DATA MONITOR mode.

Front LH, RH door	"DOOR SW" display
Open	"ON"
Closed	"OFF"

OK → Go to PROCEDURE 2 (EL-199).

OR

 ON-BOARD


Check front LH and RH door switches in Switch monitor (Mode II) mode. (Refer to On-board Diagnoses, EL-157.)

NG

B

- 1) Disconnect BCM 20-pin connector, and front door switch connector.
- 2) Check continuity.

NG → Repair harness.




	Terminals	Continuity
FL	① - ②	Yes
FR	③ - ②	

OK

C

Check harness continuity between front door switch connector terminal ③ and body ground. Continuity should exist.

NG → Repair ground harness.




OK

D

Check continuity of door switch circuit with door open. Continuity should exist.

NG → Replace door switch.




Check door switch circuit and IVMS communication again.

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

PROCEDURE 2 — Ignition key switch



CHECK KEY SWITCH CIRCUIT.

A CONSULT

See "IGN KEY SW" in DATA MONITOR mode.

"IGN KEY SW" should be "ON" when IGN key is inserted in steering key cylinder.

OR


B TESTER

Check voltage when key is inserted in steering key cylinder.

Battery voltage should exist.

OK

Go to PROCEDURE 6 (EL-202).



C

Check voltage of key switch connector terminal ② when key is inserted in steering key cylinder.

Battery voltage should exist.



OK

Repair harness between key switch and BCM connector.

NG

NG

Check key switch unit and fuse circuit.



PROCEDURE 3 — Lock & unlock switch

CHECK DOOR LOCK & UNLOCK SWITCH CIRCUIT.

A CONSULT

See "DOOR LK SW-LK or UN" in DATA MONITOR mode.

These signals should be "ON" when door lock switch was operated.

OR

ON-BOARD

Check door lock & unlock switch operation in Switch monitor (Mode II) mode. (Refer to On-board Diagnoses, EL-157.)

OK

Go to PROCEDURE 5 (EL-201).

NG

Replace driver door control unit (LCU01).

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

PROCEDURE 4 — Door key cylinder switch



CHECK DOOR KEY CYLINDER SIGNAL.

A  CONSULT

See "KEY CYL DR or AS" in DATA MONITOR mode.


These signals should be "ON" when ignition key inserted in the door key cylinder was turned to lock or unlock. **If signals turn from "OFF" to "ON" too quickly on CONSULT display when key cylinder is turned, check these signals in the graphic mode.**

(Refer to CONSULT OPERATION MANUAL.)

OK


Go to PROCEDURE 5 (EL-201).

OR

 ON-BOARD

Check front LH or RH door lock key cylinder lock and unlock switch in Switch monitor (Mode II) mode.

(Refer to On-board Diagnoses, EL-157.)



B

- 1) Disconnect LCU connector, and connector from key cylinder switch.
- 2) Check continuity.

Terminals	Continuity
⑥ - ①	Yes
⑥ - ②	
GND - ④	

NG

Repair harness.


OK

Check door lock key cylinder switch circuit.

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

PROCEDURE 5 — Door unlock sensor



CHECK DOOR LOCK KNOB SWITCH CIRCUITS.

OK → Go to PROCEDURE 6 (EL-202).


A CONSULT

See "LOCK SIG SW" in DATA MONITOR mode.
 "LOCK SIG SW" should be "LOCK" when lock knob was locked.

OR

ON-BOARD

Check front door lock knob operation in Switch monitor (Mode II) mode. (Refer to On-board Diagnoses, EL-157.)




NG

B

- 1) Disconnect LCU connector and door lock actuator connector.
- 2) Check harness continuity between LCU connector terminal ④ and door lock actuator connector terminal ②. Continuity should exist.

NG → Repair harness.



OK

C

CHECK GROUND CIRCUIT FOR FRONT LH OR RH LOCK KNOB SWITCH. Check harness continuity between door lock actuator connector harness terminal ④ and body ground. Continuity should exist.

NG → Repair ground harness.

OK

Replace front door lock actuator.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA





EL

IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

PROCEDURE 6 — Door lock actuator



A

CHECK DOOR LOCK MOTOR OPERATION.

CONSULT

See "DR LOCK MTR" in ACTIVE TEST mode.

Perform operation shown on display.

Door lock motor should operate.

NOTE:

If CONSULT is not available, start with the diagnostic procedure B .

OK → Check IVMS Communication again. Refer to EL-148.

NG

B

Check voltage between LCU connector terminals ⑰ and ⑱, or/and ⑬ and ⑭ .

Door lock operation	Terminals		Voltage	
	⊕	⊖		
Front (FL, FR)	Lock	⑰	⑱	Battery voltage
	Unlock	⑱	⑰	
Rear (RL, RR)	Lock	⑬	⑭	
	Unlock	⑭	⑬	

NG → Replace LCU for malfunctioning portion.

OK

C

1) Disconnect LCU connector and door lock actuator connector.

2) Check continuity.

	Terminals	Continuity
Front (FL, FR)	⑰ - ③	Yes
	⑱ - ①	
Rear (RL, RR)	⑬ - ③	
	⑭ - ①	

NG → Repair harness.

OK

D

Check door lock motor operation.

Door lock operation	Terminals	
	⊕	⊖
Lock	③	①
Unlock	①	③

NG → Replace door lock motor.

OK

Check IVMS communication again. Refer to EL-148.

System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 10A fuse (No. 11), located in the fuse block in the HEC
 - to multi-remote control relay-1 terminal ① and multi-remote control relay-2 terminal ①.
- Terminals ② of multi-remote control relay-1 and relay-2 are connected to BCM terminal ①.

GI

Power is supplied at all times

- through 7.5A fuse (No. 52), located in the fuse and fusible link box)
- to theft warning relay terminal ①.

MA

Theft warning relay terminal ② is connected to BCM terminal 13.

EM

Power is supplied at all times

- through 15A fuse (No. 37), located in the fuse block in the HEC)
- to trunk lid opener actuator terminal ②.

LC

Trunk lid opener actuator terminal ① is connected to multi-remote control unit terminal ⑤

BCM is connected to Multi-remote control unit, driver door control unit, passenger door control unit, rear LH door control unit and rear RH door control unit by DATA LINES A and B.

EC

Power is supplied at all times

- through 7.5A fuse (No. 40), located in the fuse block in the HEC)
- to key switch terminal ①.

FE

When the key switch is in ON position (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal ②
- to BCM terminal 23.

CL

When ignition switch is in ACC or ON position, power is supplied

- through 7.5A fuse (No. 19), located in the fuse block in the HEC)
- to BCM terminal 28.

MT

Power is supplied at all times

- through 7.5A fuse (No. 26), located in the fuse block in the HEC)
- to interior lamp terminal ①.

AT

When interior lamp is in DOOR position, ground is supplied

- to interior lamp terminal ②
- through BCM terminal 5.

FA

When any of the four door switches is in OPEN position, ground is supplied

- to BCM terminal 21
- through door switches body grounds.

RA

When the front door lock actuator LH (door unlock sensor) is in UNLOCKED position, ground is supplied

- to driver door control unit (LCU01) terminal ④
- through front door lock actuator LH (door unlock sensor) terminal ②
- to front door lock actuator LH (door unlock sensor) terminal ④
- through body grounds M13 and M73.

BR

ST

When the front door lock actuator RH (door unlock sensor) is in UNLOCKED position, ground is supplied

- to passenger door control unit (LCU02) terminal ④
- through front door lock actuator RH (door unlock sensor) terminal ②
- to front door lock actuator RH (door unlock sensor) terminal ④
- through body grounds M13 and M73.

BF

HA

When the rear door lock actuator LH and/or RH (door unlock sensor) is in UNLOCKED position, ground is supplied

- to rear LH and/or RH door control unit terminal ④
- through rear door lock actuator LH (door unlock sensor) terminal ② and/or
- through rear door lock actuator RH (door unlock sensor) terminal ②
- to rear door lock actuator LH (door unlock sensor) terminal ④ and/or
- to rear door lock actuator RH (door unlock sensor) terminal ④
- through body grounds 816 and 819.

EL

IDX

Remote controller signal input

- through window antenna
- to multi-remote control unit (LCU05) terminal ⑦.

System Description (Cont'd)

The multi-remote control system controls operation of the

- power door lock
- trunk lid opener
- interior lamp
- panic alarm.

OPERATING PROCEDURE

Multi-remote control unit can receive signals from remote controller when key switch is in OFF position (key not in cylinder).

Power door lock operation

Multi-remote control unit is connected to BCM, driver door control unit, passenger door control unit and rear LH/RH door control units by DATA LINES A and B.

- Key switch OFF signal (ignition key is not in key cylinder)
- Door switch CLOSE signal (all doors closed)

The two above signals are already input into BCM. At this point, multi-remote control unit receives a LOCK signal from remote controller. Multi-remote control unit will then send a LOCK signal

- from its terminals ① and ③ (DATA LINES A and B)
- to each door control unit terminal ① and ②

When multi-remote control unit (LCU05) receives a LOCK signal, ground is supplied

- to multi-remote control relays-1 and -2 terminal ②
- through BCM terminal ⑪.

Multi-remote control relays are now energized and door lock actuators lock all doors. (Hazard warning lamps flash twice as a reminder.)

When an UNLOCK signal is sent from remote controller, door lock actuators unlock all doors.

Refer to "POWER DOOR LOCK — IVMS" (EL-190).

Trunk lid opener operation

Ground is supplied

- to trunk lid opener actuator terminal ①
- through multi-remote control unit.

When power and ground are supplied, trunk lid opener actuator opens trunk lid.

Interior lamp operation

Multi-remote control system turns interior lamp ON or OFF when door switch is in CLOSED position (all doors closed).

For detailed description, refer to "INTERIOR LAMP" (EL-69).


Panic alarm operation

Multi-remote control system activates horn and headlamps intermittently when an alarm signal is sent from remote controller to multi-remote control system.

For detailed description, refer to "THEFT WARNING SYSTEM — IVMS" (EL-242).

Wiring Diagram — MULTI —



EL-MULTI-01




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

IDX





Refer to last page (Foldout page).
 M3, E101
 M4, B2
 M67
 M1



MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)




Refer to last page (Foldout page).

- (M3) , (E101)
- (E12)
- (E49)
- (E50)
- (E51)

MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-03



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF

Refer to last page (Foldout page).

(M1)

HA

EL



IDX



MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-04



Refer to last page (Foldout page).

(M4) . (B2)


(M36)

MULTI-REMOTE CONTROL SYSTEM — IVMS


Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-05

DATA LINE



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF



Refer to last page (Foldout page).

(M23)



HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-06

— DATA LINE




Refer to last page (Foldout page).

(M23)

MULTI-REMOTE CONTROL SYSTEM — IVMS


Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-07




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL
IDX



Refer to last page (Foldout page).
M4, B1

Schematic




Trouble Diagnoses


TROUBLE SYMPTOM

Perform "IVMS Communication Diagnosis" (refer to EL-148), "Power Supply and Ground Circuit Check" (EL-177), before starting with the following items.

- All functions of remote control system do not function.



- Multi-remote controller does not operate a part of the functions.




Note: The multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.

MULTI-REMOTE CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1



A

CHECK REMOTE CONTROLLER BATTERY.

Remove battery and measure voltage across battery positive and negative terminals, ⊕ and ⊖.


Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal ⊕	Battery negative terminal ⊖	3V or more

Note:

Remote controller does not function if battery is not set correctly.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2




A

CHECK ANTENNA CIRCUIT.

- 1) Disconnect 1-pin connector from LCU05.
- 2) Remove rear pillar finisher.
- 3) Check continuity between the terminal center and filament on the rear window.

Continuity should exist.

NG → Repair antenna circuit. Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-98).



OK ↓


CHECK IGNITION KEY SWITCH CIRCUIT.

B CONSULT

See "IGN KEY SW" in DATA MONITOR mode.

"IGN KEY SW" should be "ON" when IGN key is inserted in steering key cylinder.

NG → Check and repair ignition key switch circuit.



OR


C TESTER

Check voltage when key is inserted in steering key cylinder.

Battery voltage should exist.

Condition	Voltage
Key inserted	Battery voltage
Key not inserted	0V

NG → Check and repair door switch circuit.



OK ↓

CHECK DOOR SWITCH CIRCUIT.

D CONSULT

See "DOOR SWITCH" in DATA MONITOR mode.

If all doors are closed, "DOOR SWITCH" should be "OFF".

OR

ON-BOARD

Check all doors switches in Switch monitor (Mode II) mode. (Refer to On-board Diagnoses, EL-157.)


OK ↓

Perform "WAKE-UP DIAGNOSIS" (EL-151) and IVMS communication diagnosis (EL-148) again.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3




CHECK MULTI-REMOTE CONTROLLER OPERATION.

A CONSULT

See "TRUNK BTN-CON" in DATA MONITOR mode.

"TRUNK BTN-CON" should be "ON" when trunk lid opener button on multi-remote controller is continuously pressed for more than 1 second.

NG → Replace multi-remote controller.



OR
ON-BOARD

See Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-157).

OK


CHECK TRUNK LID OPENER CIRCUIT.

B CONSULT

See "TRUNK OPEN S/V" in ACTIVE TEST mode.

Perform operation shown on display. Trunk lid opener should operate.

OK → Check IVMS communication again. Refer to EL-148.



OR
TESTER


Check voltage between LCU05 6-pin connector terminal ⑤ and ground. **Battery voltage should exist.**

OK → Replace LCU05.

NG

Repair harness between LCU05 and trunk lid opener actuator.

DIAGNOSTIC PROCEDURE 4



A CONSULT

Check to see if trunk lid opens when 12V DC is applied across trunk lid opener actuator connector terminals ① and ②.

NG → Replace trunk lid opener actuator.

OK

Check and repair harness.

Replacing Remote Controller or Multi-Remote Control Unit (LCU05)

Enter the Identity (ID) code manually when:

- remote controller or multi-remote control unit LCU05 is replaced.
- an additional remote controller is activated.

GI

ID Code Entry Procedure

To enter the ID code, follow this procedure.

MA

“Setting mode”:

- (1) Close and lock all doors.
- (2) Insert and remove the key from the ignition more than six times within 10 seconds. (The hazard warning lamp will then flash twice.)

EM

- **At this time, the original ID codes are eliminated.**

LC

ID code entry:

- (3) Turn ignition key to “ACC” position.
- (4) Push lock button on the new remote controller once (for example, if door is locked using the remote controller during this ID code entry enable state, a new ID code can be entered).

EC

- **At this time, the new ID code is entered. (The hazard warning lamp will then flash twice.)**

FE

Additional ID code entry

- (5) If you need to activate additional remote controllers, unlock the driver’s door, then lock again with door lock knob.
- (6) Push lock button on the additional new remote controller once.
- (7) This ID code entry enable state and setting mode remain until the driver’s door is opened.

CL

NOTE

MT

- If you need to activate more than two additional new remote controllers, repeat the procedure “Additional ID code entry” for each new remote controller.
- If the same ID code that exists in the memory is input, the hazard warning lamps will flash twice but the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.
- Any ID codes entered after termination of the “setting mode” will not be accepted. Additionally remote control signals will be inhibited when an ID code has not been entered during the “setting” mode.

AT

FA

RA

BR

ST

BF

HA

EL

IDX

System Description

FUNCTION

- The IVMS has the following time control functions.

Item	Details of control
Intermittent wiper control	Regulates intermittent time approximately from 2 to 21 seconds depending on the intermittent wiping time setting.
Washer and wiper combination control	Operates wiper when washer switch is turned "ON" for at least 0.3 seconds.
Light warning buzzer timer	Sounds warning buzzer when driver's door is opened with light switch in the 1st or 2nd position and ignition switch "OFF".
Ignition key warning buzzer timer	Sounds warning buzzer when driver's door is opened with key in ignition.
Seat belt warning buzzer timer	Sounds warning buzzer for about 6 seconds if ignition switch is turned "ON" when driver's seat belt is unfastened.
Rear window defogger timer	Turn off rear window defogger and door mirror heater, if equipped, about 15 minutes after the rear window defogger switch is turned "ON".
Battery saver	Shuts off interior lamp, step lamps and ignition keyhole illumination in 30 minutes if any door is left open when ignition switch is "OFF". The battery saver will reset if ignition switch is cycled or any door is opened or closed.
Interior lamp timer	Keeps interior lamp and ignition keyhole illuminated for about 30 seconds when: <ul style="list-style-type: none"> ● driver's door is unlocked while key is out of ignition, ● key is pulled out of ignition while driver's door is closed, and ● key is pulled out of ignition and driver's door is opened and then closed. The timer is cancelled, and interior lamp and ignition keyhole illumination turn off when <ul style="list-style-type: none"> ● driver's door is locked, or ● ignition switch is turned "ON".

INTERMITTENT WIPER CONTROL

Intermittent operation

Intermittent operation can be set variable by turning the intermittent wiper volume knob. The wiper motor then operates the wiper at low speed at a set interval of about 1 to 20 seconds. This feature is controlled by the BCM.

When the wiper switch is placed in the INT position, ground is supplied

- to BCM terminal ②⑤
- from wiper switch terminal ①⑤
- to wiper switch terminal ①⑦
- through body grounds ②⑤ and ②⑩.

The desired interval time is input

- to BCM terminal ①⑦
- from wiper switch terminal ①⑨.

For further information, refer to "WIPER AND WASHER" (EL-87).

System Description (Cont'd)

REAR WINDOW DEFOGGER TIMER

The rear window defogger and door mirror defogger system are controlled by the BCM.

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ① and
- to the door mirror defogger relay terminal ① and
- to BCM terminal 29
- through 7.5A fuse (No. 12, located in the fuse block in the HEC).

Ground is supplied to terminal ② of the rear window defogger switch through body grounds M13 and M73.

When the rear window defogger switch is ON, ground is supplied

- through terminal ① of the rear window defogger switch
- to BCM terminal 22.

Terminal 15 of the BCM then supplies ground to the rear window defogger relay terminal ② and door mirror defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay and door mirror defogger relay are energized.

Power is supplied

- through terminals 5 and 7 of the rear window defogger relay
- to the rear window defogger and
- through terminal 5 of the door mirror defogger relay
- to the door mirror defogger.

The rear window defogger and door mirror defogger have an independent ground.

With power and ground supplied, the rear window defogger and door mirror defogger hot wires heat and defog the rear window and door mirror. When the system is operated, the indicator illuminates.

For power supply and ground to the rear window defogger, refer to "REAR WINDOW DEFOGGER" (EL-96). Also, for power supply and ground to the door mirror defogger, refer to "DOOR MIRROR" in BF section.

IGNITION KEY WARNING BUZZER TIMER

Power is supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to warning buzzer terminal ①, and
- key switch terminal ②.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 12, located in the fuse block in the HEC)
- to BCM terminal 29.

Ground is supplied to BCM terminal 31 through front door switch LH terminals ② and ③ when switch is in OPEN position from body grounds B16 and B19.

With the key in the ignition switch in the OFF position, and the driver's door OPEN, the warning buzzer will sound.

LIGHT WARNING BUZZER TIMER

Power is supplied at all times

- through 15A fuse (No. 51, located in the fuse and fusible link box)
- to lighting switch terminal ①.

Power is supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to warning buzzer terminal ①.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 12, located in the fuse block in the HEC)
- to BCM terminal 29.

Ground is supplied to BCM terminal 31 through front door switch LH terminals ② and ③ when switch is in OPEN position from body grounds B16 and B19.

With the ignition switch in the OFF position, the driver's door OPEN, and the lighting switch in the 1ST or 2ND position, the warning buzzer will sound.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

System Description (Cont'd)**INTERIOR LAMP AND IGNITION KEY ILLUMINATION TIMER**

Power is supplied at all times

- through 7.5A fuse (No. 26, located in the fuse block in the HEC)
- to interior lamp terminal ①,
- to ignition keyhole illumination terminal ①.

Power is also supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to key switch terminal ②.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 12, located in the fuse block in the HEC)
- to BCM terminal ⑨.

Driver door control unit (LCU01) terminal ① is connected to BCM terminal ⑩ by DATA LINE A. Also, driver door control unit terminal ② is connected to BCM terminal ⑩ by DATA LINE B.

Ground is supplied to driver door control unit terminal ④

- through front door lock actuator LH (unlock sensor) terminals ② and ④ when front door lock actuator is in UNLOCK position
- through body grounds M13 and M73.

Switch operation

With interior lamp switch ON, ground is continuously supplied to turn interior lamp on.

When a door switch is set to OPEN position with interior lamp switch in DOOR position, ground is supplied

- to interior lamp terminal ②
- through BCM terminal ⑤,
- to ignition keyhole illumination terminal ②
- through BCM terminal ⑫ and
- to BCM terminal ⑪
- through front door switch LH terminal ②
- to front door switch LH terminal ③
- through body grounds B16 and B19.

SEAT BELT WARNING BUZZER TIMER

Power is supplied at all times

- through 7.5A fuse (No. 40, located in the fuse block in the HEC)
- to warning buzzer terminal ①.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 12, located in the fuse block in the HEC)
- to BCM terminal ⑨.

Ground is supplied to BCM terminal ⑨ through seat belt buckle switch terminals ① and ③, when seat belt buckle switch is in UNFASTENED position, and body grounds B16 and B19.


This warning buzzer sounds for about 6 seconds

- when ignition switch is turned from OFF to ON and seat belt is unfastened (seat belt buckle switch ON).


Wiring Diagram — TIME —

INTERMITTENT WIPER CONTROL

EL-TIME-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).

(M3) (E101)
(M1)

EL




IDX

TIME CONTROL SYSTEM — IVMS

Wiring Diagram — TIME — (Cont'd)

REAR WINDOW DEFOGGER TIMER CONTROL

EL-TIME-02



Refer to last page (Foldout page).


M3 E101
M1
M18

TIME CONTROL SYSTEM — IVMS


Wiring Diagram — TIME — (Cont'd)

IGNITION KEY WARNING CONTROL

EL-TIME-03



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF



Refer to last page (Foldout page).
 M3 , E101
 M4 , B1
 M1
 M36



HA
EL
IDX

TIME CONTROL SYSTEM — IVMS

Wiring Diagram — TIME — (Cont'd)

LIGHT WARNING CONTROL

EL-TIME-04



Refer to last page (Foldout page).


- (M4), (B1)
- (M1)
- (M36)

TIME CONTROL SYSTEM — IVMS


Wiring Diagram — TIME — (Cont'd)

INTERIOR LAMP, IGNITION KEYHOLE ILLUMINATION TIMER CONTROL

EL-TIME-05



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF



Refer to last page (Foldout page).


- (M3) (E101)
- (M4) (B1)
- (M1)
- (M36)

HA
EL
IDX

TIME CONTROL SYSTEM — IVMS

Wiring Diagram — TIME — (Cont'd)

EL-TIME-06



Refer to last page (Foldout page).

(M23)



(M8)
W



(M23)
L



(M48)
GY



(D9)
W





(D12)
GY

TIME CONTROL SYSTEM — IVMS

Wiring Diagram — TIME — (Cont'd)

SEAT BELT TIMER CONTROL

EL-TIME-07



Refer to last page (Foldout page).

- (M4) (B1)
- (M1)
- (M36)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

Trouble Diagnoses

- Perform "IVMS Communication Diagnosis" and "Power Supply and Ground Circuit Check" as necessary before starting Diagnostic Procedures.


SYMPTOM CHART

PROCEDURE		IVMS Communication diagnosis	Power supply and ground circuit check		Diagnostic Procedure							
REFERENCE PAGE		EL-148	EL-177	EL-178	EL-229	EL-231	EL-232	EL-233	EL-235	EL-237	EL-238	EL-239
SYMPTOM		IVMS Communication diagnosis	Ground circuit check	Power supply circuit check	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8
Wiper & washer	Intermittent wiper does not operate.		BCM	BCM	○							
	Intermittent time of wiper cannot be adjusted.		BCM	BCM		○						
	Wiper and washer activate individually but not in combination.		BCM	BCM			○					
Warning	Light warning chime does not activate.		BCM	BCM				○				
	Ignition key warning chime does not activate.		BCM	BCM					○			
	Seat belt warning chime does not activate.		BCM	BCM						○		
Rear defogger	Rear defogger does not activate, or go off after activating.		BCM	BCM							○	
Interior lamp	Interior lamp timer does not operate or interior lamp timer does not cancel when driver's door is locked or ignition switch is turned "ON".	○	BCM, LCU01	BCM, LCU01								○

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.




A

See "INT SW" in "Data monitor" mode.
When wiper switch is in INT position:
INT SW ON
When wiper switch is in OFF position:
INT SW OFF

OR

Perform On-board diagnosis — Mode II (switch monitor) for wiper switch (INT). Refer to EL-157.

OK → Go to **C** below.



B

INTERMITTENT SWITCH INPUT SIGNAL CHECK
Measure voltage between BCM terminals ⑤ and ③ or ⑥.

Condition of wiper switch	Voltage [V]
OFF	Approx. 12
ON	0

Check wiper switch. Refer to "COMBINATION SWITCH" (EL-37).

Replace wiper switch.

Check harness continuity between BCM and wiper switch.

Repair harness or connectors.

Replace BCM.

C

WIPER OPERATION CIRCUIT CHECK

1. Perform "WIPER AMP" in "Active test" mode.
2. Check wiper operation.


If CONSULT is not available, skip this procedure and go to the next procedure below.

OK → Go to **E** next page.

Check wiper relay.

Replace wiper relay.




(Go to next page.)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TIME CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)






TIME CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.




A

See "WASH SW" in "Data monitor" mode.
When washer switch is ON:
WASH SW ON
When washer switch is OFF:
WASH SW OFF
OR

Perform On-board diagnosis — Mode II (switch monitor) for wiper switch (WASH). Refer to EL-157.

OK → Go to **C** below.




B

WASHER SWITCH INPUT SIGNAL CHECK

1. Disconnect BCM connectors.
2. Turn ignition switch to "ON".
3. Measure voltage between BCM terminals ②⑥ and ③ or ⑥.

Condition of washer switch	Voltage [V]
OFF	Approx. 12
ON	0

NG → Check harness continuity between BCM and washer switch.



C

WIPER RELAY OUTPUT SIGNAL CHECK

1. Connect BCM connectors.
2. Turn ignition switch to "ON".
3. Measure voltage between BCM terminals ⑩ and ③ or ⑥ right after turning washer switch ON and OFF. **0V for approx. 3 seconds after washer has operated.**

NG → Replace BCM.

OK → Check wiper relay and wiper relay circuit.

NG → Repair or replace.








OK → System is OK.

TIME CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Light warning buzzer does not activate.




Ⓐ
(Go to next page.)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TIME CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)





A

D

LIGHTING SWITCH INPUT SIGNAL CHECK

1. Disconnect BCM connectors.
2. Measure voltage between BCM terminals ②④ and ③ or ⑥.

Condition of lighting switch	Voltage [V]
1ST or 2ND	Approx. 12
OFF	0





E

BUZZER OUTPUT SIGNAL CHECK

Perform "LIGHT WARN ALM" in "Active Test" mode. Check buzzer operation.


If CONSULT is not available, skip this procedure and go to the next procedure below.



F

BUZZER OPERATION CHECK

1. Disconnect buzzer connector.
2. Connect battery to buzzer and check buzzer operation.




OK → Replace BCM.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Ignition key warning buzzer does not activate.




A

See "DOOR SW-DR" in "Data monitor" mode.
 When driver's door is open:
DOOR SW-DR ON
 When driver's door is closed:
DOOR SW-DR OFF

OR

Perform On-board diagnosis — Mode II (switch monitor) for door switch (driver side). Refer to EL-157.

OK → Go to **C** below.



Check driver's door switch.

NG → Replace door switch.

OK →

B

DOOR SWITCH INPUT SIGNAL CHECK
 Measure voltage between BCM terminals ③ and ⑥.


Condition of driver's door	Voltage [V]
Closed	Approx. 12
Open	0

NG → Check harness between BCM and driver's door switch and door switch ground circuit.

OK →

NG → Repair harness.

OK → Replace BCM.




C

See "IGN KEY SW" in "Data Monitor" mode.
 When key is in ignition:
IGN KEY SW ON
 When key is out of ignition:
IGN KEY SW OFF

If CONSULT is not available, skip this procedure and go to the next procedure below.

OK → Go to **E** next page.



D

IGNITION KEY SWITCH INPUT SIGNAL CHECK
 1. Disconnect BCM connectors.
 2. Measure voltage between BCM terminals ② and ③ or ⑥.

Condition of key switch	Voltage [V]
Key in ignition	Approx. 12
Key out of ignition	0

NG → Check ignition key switch.

OK →




NG → Replace ignition key switch.

OK → Check harness.

OK → **A**
 (Go to next page.)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
 EL
 IDX






Trouble Diagnoses (Cont'd)



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: Seat belt warning buzzer does not activate.




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7


SYMPTOM: Rear window defogger (and door mirror heater) do not activate or do not turn off after activating.



A

See "DEFOGGER SW" in "Data Monitor" mode.
When defogger switch is pushed (turned ON):
DEFOGGER SW ON
When defogger switch is pushed again (turned OFF):
DEFOGGER SW OFF
If CONSULT is not available, skip this procedure and go to the next procedure below.

OK → Go to **C** below.



B

REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK
1. Turn ignition switch ON.
2. Measure voltage between BCM terminals ② and ③ or ⑥.

Condition of defogger switch	Voltage [V]
ON	0
OFF	Approx. 5

NG → Check rear window defogger switch.


OK →
NG → Replace rear window defogger switch.

Check harness continuity between BCM and rear window defogger switch and rear window defogger switch ground circuit.

OK →
NG → Repair harness.

Replace BCM.

OK → Replace BCM.



C

REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK
1. Disconnect BCM connectors.
2. Measure voltage between BCM terminals ⑮ and ③ or ⑥.

Condition of ignition switch	Voltage [V]
ON	Approx. 12
OFF	0


NG → Check rear window defogger relay (and door mirror defogger) relay.
NG → Replace relay(s).

OK → Check rear window defogger circuit. (Refer to "REAR WINDOW DEFOGGER" EL-96.) And/or check door mirror defogger circuit. (Refer to BF section "MIRROR".)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: Interior lamp timer does not operate or does not cancel when driver's door is locked or ignition switch is turned ON.



A

See "DOOR SW-DR" in "Data Monitor" mode.

When driver's door is open:
DOOR SW-DR ON

When driver's door is closed:
DOOR SW-DR OFF

OR

Perform On-board diagnosis — Mode II (switch monitor) for door switch (driver side). Refer to EL-157.


OK → Go to **C** below.

NG

Check driver's door switch.

NG → Replace door switch.

OK



B

DOOR SWITCH INPUT SIGNAL CHECK


Measure voltage between BCM terminals 31 and 3 or 6.

Condition of driver's door	Voltage [V]
Open	0
Closed	Approx. 12

NG → Check harness continuity between BCM and driver's door switch and door switch ground circuit.

OK → Replace BCM.

NG → Repair harness.



C

See "LOCK SIG-DR" in "Data Monitor" mode.

When driver's door is locked:
LOCK SIG-DR LOCK

When driver's door is unlocked:
LOCK SIG-DR UNLK

OR

Perform On-board diagnosis — Mode II (switch monitor) for door lock switch (driver side). Refer to EL-157.

OK → Go to **E** on next page.

NG


Ⓐ

(Go to next page.)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

TIME CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)





D

①

DOOR LOCK SWITCH INPUT SIGNAL CHECK
Measure voltage between LCU01 terminals ④ and ⑯.

Condition of driver's door	Voltage [V]
Locked	Approx. 5
Unlocked	0




E

IGNITION KEY SWITCH INPUT SIGNAL CHECK
1. Disconnect BCM connectors.
2. Measure voltage between BCM terminals ⑬ and ③ or ⑥.

Condition of key switch	Voltage [V]
Key in ignition	Approx. 12
Key out of ignition	0

OK

Replace BCM.



NOTE

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST








BF

HA

EL


IDX

Component Parts and Harness Connector Location



Description

1. OPERATION FLOW



GI
MA
EM
LC
EC
FE
CL

2. SETTING THE THEFT WARNING SYSTEM

Initial condition

- (1) Close all doors.
- (2) Close hood and trunk lid.
- (3) Pull key out of ignition.

Disarmed phase

When any door(s), hood or trunk lid is opened, the theft warning system turns into the "disarmed" phase. (The security indicator lamp blinks every second.)

Pre-armed phase and armed phase

The theft warning system turns into the "pre-armed" phase when hood, trunk lid and all doors are closed and locked. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.4 seconds.)

3. CANCELING THE SET THEFT WARNING SYSTEM

When any of the following operations (a), (b) and (c) is performed, the armed phase is canceled.

- (a) Unlock at least one door using either the key or the multi remote controller.
- (b) Unlock the trunk lid with the key or the multi remote controller.
- (c) Insert the key in ignition and turn ignition to "ACC" or "ON".

4. ACTIVATING THE ALARM OPERATION OF THE THEFT WARNING SYSTEM

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.4 seconds.)

When any of the following operations (a), (b) and (c) is performed, the system sounds the horns and flashes the headlamps for about 2.5 minutes. At the same time, the system disconnects the starting system circuit. The starting system is kept dead even after the alarm turns off.

- (a) Open the engine hood or trunk lid using the hood or trunk lid opener.
- (b) Unlock any door without key or multi remote controller.
- (c) Pull out the key cylinder from either front door or the trunk lid.

5. CANCELING THE ALARM OPERATION OF THE THEFT WARNING SYSTEM

The alarm operation can be canceled when the trunk lid or either front door is unlocked with key or multi remote controller.

MT
AT
FA
RA
BR
ST
BF
HA

EL
IDX

System Description

Power is supplied at all times

- through 30A fusible link (letter **Q**), located in the fuse and fusible link box)
- to ignition switch terminal **1**.

With the ignition switch in the START position, power is supplied

- from terminal **5** of the ignition switch
- to theft warning relay terminal **3** (M/T models for Canada).

With the ignition switch in the START position, power is supplied

- through 7.5A fuse (No. **33**), located in the fuse block in the HEC)
- to theft warning relay terminal **3** (M/T models for U.S.A.).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. **17**), located in the fuse block in the HEC)
- to theft warning relay terminal **3** (A/T models).

Power is supplied at all times

- through 7.5A fuse (No. **40**), located in the fuse block in the HEC)
- to security indicator lamp terminal **2**.

BCM terminal **48** is connected to terminal **1** of all door control units and to multi-remote control unit terminal **1**.

BCM terminal **43** is connected to terminal **1** of all door control units and to multi-remote control unit terminal **1**.

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse (No. **19**), located in the fuse block in the HEC)
- to BCM terminal **28**.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. **12**), located in the fuse block in the HEC)
- to BCM terminal **29**.

Power is supplied at all times

- through 15A fuse (No. **61**), located in the fuse and fusible link box)
- to theft warning lamp relay terminal **3**.

Power is supplied at all times

- through 15A fuse (No. **62**), located in the fuse and fusible link box)
- to theft warning lamp relay terminal **6**.

Power is supplied at all times

- through 7.5A fuse (No. **52**), located in the fuse and fusible link box)
- to theft warning horn relay-1 terminal **3** and **1**
- to theft warning horn relay-2 terminal **1**
- to theft warning lamp relay terminal **1**.

Power is supplied at all times

- through 10A fuse (No. **53**), located in the fuse and fusible link box)
- to horn relay terminal **2**.

THEFT WARNING SYSTEM ARMING (Without key or remote controller used to lock front doors)

When a door is open, BCM terminal **21** receives a ground signal from the door switch that is in the OPEN position.

When a door is unlocked, terminal **4** of the respective door control unit receives a ground signal

- from terminal **2** of the respective door unlock sensor in door lock actuator
- through body grounds **M13** and **M73** (for the front doors) or
- through body grounds **B16** and **B19** (for the rear doors).

When the hood is open, BCM terminal **40** receives a ground signal

- from terminal **1** of the hood switch
- through body grounds **E5** and **E30**.

When the trunk lid is open, BCM terminal **42** receives a ground signal

- from terminal **1** of the trunk room lamp switch
- through body grounds **B16** and **B19**

When none of the above conditions exists, the theft warning system is armed.

THEFT WARNING SYSTEM — IVMS

System Description (Cont'd)

THEFT WARNING SYSTEM ARMING (With key or remote controller used to lock doors)

If the rear doors are locked and the key or remote controller is used to lock either front door, driver side and passenger door control unit terminal ⑥ receives a ground signal

- from terminal ① of the front door key cylinder switch LH or RH
- from body grounds (M13) and (M73).

If this signal is received by the BCM, the theft warning system will be armed automatically.

Once the theft warning system has been armed, BCM terminal ② supplies ground to security indicator lamp terminal ①.

GI

MA

THEFT WARNING SYSTEM OPERATION

The theft warning system is triggered by

- opening a door or the trunk lid without using the key or remote controller
- opening the hood
- tampering with (punching out etc.) the key cylinder in the door or trunk lid.

Once the theft warning system has been armed, and if the BCM receives a ground signal at terminal ⑫, terminal ⑪ or terminal ⑩ (as described under THEFT WARNING SYSTEM ARMING), the theft warning system will be triggered. Also, when one of the following signals is received at the BCM, the system will be triggered.

When a door key cylinder switch has been tampered with, driver side and passenger side door control unit terminal ③ receives a ground signal

- from terminal ③ of the front door key cylinder switch LH or RH
- to terminal ④ of the front door key cylinder switch LH or RH
- from body grounds (M13) and (M73).

When the trunk lid key cylinder switch has been tampered with, BCM terminal ⑩ receives a ground signal

- from terminal ② of the trunk lid key cylinder switch
- to terminal ③ of the trunk lid key cylinder switch
- from body grounds (B16) and (B19).

If the theft warning system is triggered, ground is supplied

- from terminal ⑭ of the BCM
- to theft warning relay terminal ②.

With power and ground supplied, power to the clutch interlock relay (M/T models) or inhibitor switch (A/T models) is interrupted. So the starter motor will not operate. Refer to "STARTING SYSTEM" (EL-24).

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ⑬ of the BCM
- to theft warning horn relay-2 terminal ② and
- to theft warning lamp relay terminal ②.

When the theft warning lamp relay is energized, power is supplied

- from theft warning lamp relay terminal ⑦
- to headlamp LH terminal ① and
- from theft warning lamp relay terminal ⑤
- to headlamp RH terminal ①.

Ground is supplied

- to headlamp LH or RH terminal ③
- from body grounds (E5) and (E30).

When the theft warning horn relay-2 is energized, ground is supplied

- to theft warning horn relay-1 terminal ②
- through theft warning horn relay-2 terminal ⑤
- through body grounds (E5) and (E30) and
- to horn relay terminal ①
- through theft warning relay terminal ③.

When the theft warning horn relay-1 and horn relay are energized, power is supplied

- to theft warning horn terminal ① and
- to horn terminal ①.

The headlamp flash and the horn sounds intermittently and the starting system is kept dead.

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

THEFT WARNING SYSTEM — IVMS

System Description (Cont'd)

THEFT WARNING SYSTEM DISARMING

When the key or remote controller is used to unlock a door, driver or passenger door control unit terminal ⑤ receives a ground signal from terminal ② of the front door key cylinder switch LH or RH.

When the key or remote controller is used to unlock the trunk lid, BCM terminal ⑩ receives a ground signal from terminal ① of the trunk lid key cylinder switch.

When the BCM receives any one of these signals, the theft warning system is disarmed.

PANIC ALARM OPERATION

Multi-remote control system may operate the alarm (horn and headlamps) as required.


When the multi-remote control system receives a signal from remote controller, ground is supplied intermittently from BCM terminal ⑬ and BCM outputs alarm.

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT —

EL-THEFT-01

▬ : DATA LINE



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA


BR

ST

BF

HA

Refer to last page (Foldout page).



M3, E101

M4, B2

M1

M36





EL

IDX


THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-02




Refer to last page (Foldout page).



THEFT WARNING SYSTEM — IVMS


Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-03



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA

EL
 IDX




Refer to last page (Foldout page).
 E49
 E51

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-04



Refer to last page (Foldout page).

M3, E101

E12

E50



M48
W




E12
GY

E50
W



E20
W

E36
B




E43
L

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)


EL-THEFT-05

— : DATA LINE



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF

Refer to last page (Foldout page).
(M23)




HA
EL
IDX

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)


EL-THEFT-06

DATA LINE



Refer to last page (Foldout page).


(M23)




THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-07



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA



Refer to last page (Foldout page).


(M4) (B1)

EL

IDX


THEFT WARNING SYSTEM — IVMS

Schematic



THEFT WARNING SYSTEM — IVMS

Schematic (Cont'd)




GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses

Before starting with the following "SYSTEM OPERATION CHECK", be sure to perform "IVMS Communication Diagnosis" (EL-148) and "Power Supply and Ground Circuit Check" (EL-177).

SYSTEM OPERATION CHECK

If ignition switch is turned to "ACC" at a step between START and ARMED or in the ARMED phase shown in this flow chart, the system operation is canceled.



THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

IDX

THEFT WARNING SYSTEM — IVMS
Trouble Diagnoses (Cont'd)






THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

Diagnostic procedure 1-(1)



GF

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA




EL

IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)






Diagnostic procedure 1-(2)



THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(3)



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL

IDX

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)



A

See "TAMPER SW" in "Data Monitor" mode.

When driver side key cylinder is removed,

TAMPER SW-DR ON

When driver side key cylinder is installed,

TAMPER SW-DR OFF

When passenger side key cylinder is removed,

TAMPER SW-AS ON

When passenger side key cylinder is installed,

TAMPER SW-AS OFF

When trunk lid key cylinder is removed,

TAMPER SW-TRK ON

When trunk lid key cylinder is installed,

TAMPER SW-TRK OFF

OR

Perform On-board diagnosis — Mode II (switch monitor) for each tamper switch. Refer to EL-157.

OK → Go to DIAGNOSTIC PROCEDURE 2 (EL-264).

NG ↓

B

KEY CYLINDER TAMPER SWITCH INPUT SIGNAL CHECK

Measure voltage between BCM terminals ⑳ and ③ or ⑥ (trunk lid), LCU01 terminals ③ and ⑩ (driver side), and LCU02 terminals ③ and ⑩ (passenger side).

Condition		Voltage [V]
Key cylinder removed		0
Key cylinder installed	Front doors	Approx. 12
	Trunk lid	Approx. 5

OK → Go to DIAGNOSTIC PROCEDURE 2 (EL-264).

NG ↓

Check key cylinder tamper switch in question. Refer to "Electrical Components Inspection" (EL-272).

NG → Replace.



OK ↓

A

(Go to next page.)

THEFT WARNING SYSTEM — IVMS





Trouble Diagnoses (Cont'd)



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IDX





Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2



Trouble Diagnoses (Cont'd)





DIAGNOSTIC PROCEDURE 3



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 4



THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5



Check theft warning horn relay-1 and -2 and theft warning lamp relay.

NG → Replace.

OK

A

ALARM OUTPUT CIRCUIT CHECK
 1. Disconnect BCM connectors.
 2. Measure voltage between BCM terminals ⑬ and ③ or ⑥.
Positive battery voltage should exist.

NG → Check and repair harness.

OK

Do horn and theft warning horn sound when horn button is pressed?

Yes → Go to **C** on next page.

No

Check horn and theft warning horn.

NG → Replace.

OK

B

THEFT WARNING HORN CIRCUIT CHECK
 1. Disconnect theft warning horn relay-1 connector.
 2. Measure voltage between terminals ① and ②.
Positive battery voltage should exist.
 3. Measure voltage between terminals ③ and ⑤.
Positive battery voltage should exist.
 4. Connect theft warning horn relay-1 and disconnect theft warning horn relay-2 connector.
 5. Measure voltage between terminals ① and ②.
Positive battery voltage should exist.
 6. Measure voltage between terminals ③ and ⑤.
Positive battery voltage should exist.

NG → Check and repair harness.

OK

Check theft warning horn relay-2 ground circuit and harness between theft warning horn relay-1 and theft warning horn.

NG → Repair harness.

OK


Check horn circuit. Refer to "HORN, CIGARETTE LIGHTER AND CLOCK" (EL-94).

NG → Repair or replace.

OK





A

(Go to next page)







THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)



Trouble Diagnoses (Cont'd)





DIAGNOSTIC PROCEDURE 7



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8




THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches

Check continuity between terminal and switch body.



	Terminals	Condition	Continuity
Front door switches	② - switch body	Pressed	No
		Released	Yes
Rear door switches	① - switch body	Pressed	No
		Released	Yes

GI
MA
EM

LC


EC

FE

CL

Hood switch

Check continuity between terminals.



Terminals	Condition	Continuity
① - ②	Pressed	No
	Released	Yes

MT


AT

FA

RA

Trunk room lamp switch

Check continuity between terminals.



Terminals	Condition	Continuity
① - ②	Pressed	Yes
	Released	No

BR

ST

BF

HA

EL

IDX

Trouble Diagnoses (Cont'd)


Key cylinder tamper switch, door lock switch and door unlock switch

● Door

	Terminals	Condition	Continuity
Tamper switch	③ - ④	Key cylinder installed	No
		Key cylinder removed	Yes
Door lock switch	① - ④	Lock (full stroke)	No
		Between lock and neutral	Yes
		Neutral	No
Door unlock switch	② - ④	Unlock	Yes
		Neutral	No


● Trunk lid

	Terminals	Condition	Continuity
Tamper switch	② - ③	Key cylinder installed	No
		Key cylinder removed	Yes
Trunk lid unlock switch	① - ③	Unlock (full stroke)	No
		Between unlock and neutral	Yes
		Neutral	No



Door unlock sensor

Terminals	Condition	Continuity
② - ④	Lock	No
	Unlock	Yes



System Description

Power is supplied at all times

- to lighting switch terminal ①
- through 15A fuse (No. ⑤①, located in the fuse and fusible link box).

With the lighting switch in the 1ST or 2ND position, power is supplied

- to BCM terminal ②④
- through lighting switch terminal ② and
- 7.5A fuse (No. ⑤, located in the fuse block in the HEC).

Terminals ① and ② of the power window switch illumination (located in the rear LH and RH door control units) are connected to BCM terminals ③② and ③③ by DATA LINES A and B respectively.

When power is supplied to BCM, BCM sends a signal to rear LH and RH door control units to turn on power window switch illumination. Power and ground are supplied to power window switch illumination, then power window switch illumination turns on.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF



HA

EL


IDX

Wiring Diagram — SW/ILL —

EL-SW/ILL-01



Refer to last page (Foldout page).



Trouble Diagnoses

Perform "IVMS Communication Diagnoses" (EL-148) and "Power Supply and Ground Circuit Check" (EL-177) before starting with the following chart.

Symptom	Possible cause	Repair order
Power window switch illumination does not illuminate when lighting switch is turned to 1st or 2nd.*	1. 7.5A fuse 2. Open in lighting switch circuit 3. LCU 4. BCM	1. Check 7.5A fuse (No. 5), located in fuse block). 2. Check R/L wire between 7.5A fuse and BCM. 3. Replace LCU. 4. Replace BCM.

* CONSULT (data monitor and/or active test) may also be used to confirm the cause of malfunction.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

System Description

Power is supplied at all times

- through 7.5A fuse (No. 26), located in the fuse block in the HEC)
- to interior lamp terminal ①.



BCM terminal ② is grounded when any door switch is in OPEN position.

When the front RH door switch, rear LH door switch or rear RH door switch is in OPEN position, interior lamp turns on.

Multi-remote control unit (LCU05) terminal ① and BCM terminal ④ are connected by DATA LINE A. Multi-remote control unit terminal ③ and BCM terminal ⑤ are connected by DATA LINE B. When multi-remote control unit receives a signal to turn on interior lamp from remote controller, multi-remote controller transmits its signal to BCM. Interior lamp turns on when all door switches are in CLOSED position.

Wiring Diagram — ROOM/L —

EL-ROOM/L-01



Refer to last page (Foldout page).

- (M4), (B1)
- (M1)
- (M23)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA

EL

IDX

INTERIOR LAMP ON-OFF CONTROL — IVMS

Trouble Diagnoses

Perform "IVMS Communication Diagnoses" (EL-148) and "Power Supply and Ground Circuit Check" (EL-177) before starting with the following chart.

Symptom	Possible cause	Repair order
Interior lamp does not illuminate when any door is opened.*	<ol style="list-style-type: none"> 1. Bulb 2. 7.5A fuse 3. Interior lamp switch 4. Open in interior lamp circuit 5. BCM 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check 7.5A fuse (No. 26, located in fuse block). 3. Check interior lamp switch. 4. Check R/W wire between interior lamp and BCM. 5. Replace BCM.
Interior lamp does not illuminate when a certain door is opened. (It illuminates when other doors are opened.)	<ol style="list-style-type: none"> 1. Door switch of the door in question 2. Open in door switch circuit 	<ol style="list-style-type: none"> 1. Check door switch in question. 2. Check R/W wire between BCM and door switch in question.
Interior lamp does not turn off when all doors are closed	<ol style="list-style-type: none"> 1. Short in interior lamp circuit 2. Door switch 3. Short in door switch circuit 4. BCM 	<ol style="list-style-type: none"> 1. Check R/W wire between interior lamp and BCM. 2. Check all door switches. 3. Check R/W wire between BCM and all door switches. 4. Replace BCM.

* CONSULT (data monitor and/or active test) may also be used to confirm the cause of malfunction.

System Description

Power is supplied at all times

- to BCM terminal ①
- through 7.5A fuse (No. 60, located in the fuse and fusible link box).

BCM terminal ② is connected to terminal ① of each door switch.

Power is supplied at all times

- to front step lamp LH and RH terminals ①
- through 7.5A fuse (No. 26, located in the fuse block in the HEC).

Ground is supplied to BCM terminal ② when one door switch is in the OPEN position.

Ground is supplied to terminal 16 of LCU01 and LCU02 through body grounds M13 and M73.

Terminal ① of LCU01 and LCU02 and terminal 38 of BCM are connected by DATA LINE A. Terminal ② of LCU01 and LCU02 and terminal 33 of BCM are connected by DATA LINE B.

When ground is supplied to BCM terminal ②, BCM sends a signal to driver and passenger door control units to turn on front LH and RH step lamps.

With power and ground supplied, front step lamps turn on.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF




HA

EL

IDX

Wiring Diagram — STEP/L —

EL-STEP/L-01




Refer to last page (Foldout page).


- M3, E101
- M4, B1
- M23

STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA



Refer to last page (Foldout page).
M1

EL

IDX

STEP LAMP — IVMS

Trouble Diagnoses



Perform "IVMS Communication Diagnoses" (EL-148) and "Power Supply and Ground Circuit Check" (EL-177) before starting with the following chart.

Symptom	Possible cause	Repair order
Step lamps on both sides do not illuminate when any door is opened.*	<ol style="list-style-type: none"> 1. Bulbs 2. 7.5A fuse 3. Open in door switch circuit 4. BCM 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check 7.5A fuse (No. 26), located in fuse block). 3. Check R/W wire between BCM and all door switches. 4. Replace BCM.
Step lamps on both sides do not illuminate when a certain door is opened. (They illuminate when other doors are opened.)	<ol style="list-style-type: none"> 1. Door switch of the door in question 2. Open in door switch circuit 	<ol style="list-style-type: none"> 1. Check door switch in question. 2. Check R/W wire between BCM and door switch in question.
Step lamp on one side does not illuminate.	<ol style="list-style-type: none"> 1. Bulb 2. Open in step lamp circuit 3. LCU 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/L wire between step lamp and LCU or R wire between step lamp and fuse. 3. Replace LCU.
Step lamp on one side does not turn off when all doors are closed.	<ol style="list-style-type: none"> 1. Short in step lamp circuit 2. LCU 	<ol style="list-style-type: none"> 1. Check R/L wire between step lamp and LCU. 2. Replace LCU.
Step lamps on both sides do not turn off when all doors are closed.	<ol style="list-style-type: none"> 1. Door switches 2. Short in door switch circuit 3. BCM 	<ol style="list-style-type: none"> 1. Check all door switches. 2. Check R/W wire between BCM and all door switches. 3. Replace BCM.

* CONSULT (data monitor and/or active test) may also be used to confirm the cause of malfunction.

LOCATION OF ELECTRICAL UNITS


Engine Compartment



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX


LOCATION OF ELECTRICAL UNITS

Passenger Compartment



LOCATION OF ELECTRICAL UNITS

Luggage Compartment



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

HARNESS LAYOUT

Outline



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Engine Room Harness (Engine Compartment)
- Main Harness
- Body Harness

The grid reference is placed on the page where connectors are listed in number order.

To the left of the connector number code there is a grid reference.

Example:

G2 (E1): ASCD actuator


└ grid reference

To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

HARNESS LAYOUT

Engine Room Harness



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNES LAYOUT


Engine Room Harness (Cont'd)

F3	(E1)	: Brake fluid level switch	B4	(E41)	: Compressor (Air conditioner)
F2	(E4)	: ASCD pump	A2	(E42)	: Daytime light control unit
E5	(E5)	: Body ground	C2	(E43)	: Relay box-2
E5	(E6)	: Clearance lamp and cornering lamp LH	A2	(E44)	: Clearance lamp and cornering lamp RH
D5	(E7)	: To front fog lamp harness (For optional)	A4	(E45)	: Washer level switch
F3	(E8)	: Fuse and fusible link box	B4	(E46)	: Front washer motor
E4	(E9)	: Joint connector-1 (White)	B4	(E47)	: Alternator
E4	(E10)	: Joint connector-2 (White)	A1	(E48)	: Joint connector-5 (White)
F4	(E11)	: Joint connector-3 (Gray)	A1	(E49)	: Joint connector-6 (White)
F3	(E12)	: Joint connector-4 (White)	A1	(E50)	: Joint connector-7 (White)
E3	(E13)	: To (E36)	A1	(E51)	: Joint connector-8 (Gray)
F3	(E14)	: To (E27)			
D3	(E15)	: Starter motor			
D3	(E16)	: Battery			
E3	(E17)	: Front wheel sensor LH (Anti-lock brake system)			
E2	(E18)	: Actuator (Anti-lock brake system)			
D3	(E19)	: Hood switch (Theft warning system)			
D3	(E20)	: Relay box-1			
D5	(E21)	: Front fog lamp LH			
D5	(E22)	: Front turn signal lamp LH			
D5	(E23)	: Front side marker lamp LH			
C4	(E24)	: Headlamp LH			
C4	(E25)	: Triple-pressure switch			
C4	(E26)	: Cooling fan motor-1			
C3	(E27)	: Cooling fan motor-2			
C3	(E28)	: Ambient sensor			
B4	(E29)	: Horn			
A3	(E30)	: Body ground			
A3	(E31)	: Headlamp RH			
A4	(E32)	: Front turn signal lamp RH			
A3	(E33)	: Front side marker lamp RH			
A4	(E34)	: Front fog lamp RH			
B4	(E35)	: Body ground			
B2	(E36)	: Theft warning horn (Theft warning system)			
C2	(E37)	: Alternator			
B2	(E38)	: To (E38)			
C2	(E39)	: To (E38)			
C3	(E40)	: Alternator			

*: Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

HARNESS LAYOUT

Engine Room Harness (Cont'd)




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 BF
 HA
EL
 IDX

- E101 : To (MS) (SM/J)
- E102 : Circuit breaker-1
- E103 : Circuit breaker-2 (With yellow tape)
- E104 : Joint connector-9 (Sky blue-Diode)
- E105 : Ignition switch
- E106 : To fuse block (HEC)
- E107 : Ignition key hole illumination
- E108 : Turn signal and cornering lamp switch
- E109 : Key switch
- E110 : Lighting switch
- E111 : Front wiper switch
- E112 : Front fog lamp switch
- E113 : ABS control unit
- E114 : Body ground (Anti-lock brake system)
- E115 : Diode
- E116 : Diode

HARNESS LAYOUT

Main Harness



HARNES LAYOUT

Main Harness (Cont'd)


B4 (M1)	: Fuse block (HEC)
C4 (M2)	: Data link connector for CONSULT
A3 (M3)	: To (F101)
B4 (M4)	: To (B1)
B4 (M5)	: To (B2)
A5 (M6)	: Fuel pump relay
A5 (M7)	: Sun roof relay (With red tape)
A4 (M8)	: To (D1)
A4 (M9)	: To (D2)
C2 (M10)	: To (R1)
C1 (M11)	: Tweeter LH (BOSE system)
C2 (M12)	: Joint connector-23 (Gray)
C2 (M13)	: Body ground
C3 (M14)	: ASCD cancel switch
C4 (M15)	: Stop lamp switch
C3 (M16)	: Clutch interlock switch (M/T models for USA)
C4 (M17)	: ASCD clutch switch
C1 (M18)	: Joint connector-10 (Green)
C1 (M19)	: Joint connector-11 (White)
C1 (M20)	: Joint connector-12 (White)
D1 (M21)	: Joint connector-13 (Gray)
D1 (M22)	: Joint connector-14 (White)
D1 (M23)	: Joint connector-15 (Blue)
D1 (M24)	: Joint connector-16 (Sky blue-Diode)
E1 (M25)	: Joint connector-17 (White)
B3 (M26)	: Door mirror remote control switch
C3 (M27)	: ASCD main switch
B3 (M28)	: Security indicator lamp
C3 (M29)	: Combination meter
D3 (M30)	: ASCD control unit
D3 (M31)	: Shift lock control unit
D3 (M32)	: Illumination control switch
D3 (M34)	: Combination flasher unit
D4 (M35)	: Warning buzzer
D3 (M36)	: Junction box (Joint connectors)
D2 (M37)	: Resistor
D2 (M38)	: Mode door motor
E3 (M39)	: Fan switch (Manual A/C)
E3 (M40)	: Push control unit (Auto A/C)
D3 (M41)	: In-vehicle sensor
F3 (M42)	: Push control unit (Auto A/C)
E4 (M43)	: Joint connector-18 (White)
E4 (M44)	: Audio
E5 (M45)	: Cigarette lighter
F5 (M46)	: Ashtray illumination

F4 (M47)	: A/C auto amp. (In BCM)
F4 (M48)	: BCM
D4 (M49)	: Air mix door motor
D4 (M50)	: To (F105)
D4 (M51)	: To (F104)
E1 (M52)	: To (Z1)
E2 (M53)	: BI-level actuator
F2 (M54)	: Intake sensor
F3 (M55)	: Glove box lamp switch
F2 (M56)	: Thermo control amp.
G2 (M57)	: Fan control amp.
F3 (M58)	: To (F102)
E2 (M59)	: Clock
E2 (M60)	: Rear window defogger switch
D2 (M61)	: Hazard switch
F5 (M62)	: A/T control device
F4 (M63)	: Data link connector for GST
E1 (M64)	: Sunload sensor
F1 (M65)	: Joint connector-19 (Blue)
F1 (M66)	: Joint connector-20 (White)
F1 (M67)	: Joint connector-21 (White)
F3 (M68)	: Glove box lamp
F2 (M69)	: Intake door motor
G2 (M70)	: To (B101)
G3 (M71)	: To (B102)
G1 (M72)	: Tweeter RH (BOSE system)
G2 (M73)	: Body ground
G2 (M74)	: To (B31)
G3 (M75)	: To (B32)
F3 (M76)	: Blower motor
F3 (M77)	: Fan resistor (Manual A/C)
F3 (M78)	: Door mirror defogger relay (With blue tape)
G3 (M79)	: Audio amp. relay
D1 (M80)	: Joint connector-22 (Sky blue-Diode)
C5 (M101)	: Front wiper motor
B5 (M102)	: Front wheel sensor RH (Anti-lock brake system)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNESS LAYOUT

Engine Control Harness



*: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the system to light up the MIL as an open circuit detection.

HARNESS LAYOUT

Engine Control Harness (Cont'd)

E1	(F1)	: Power steering oil pressure switch
E1	(F2)	: Front heated oxygen sensor (RH)
E2	(F3)	: Ignition coil No. 1
E2	(F4)	: Ignition coil No. 3
F2	(F5)	: Canister purge control valve
F2	(F6)	: Ignition coil No. 5
F3	(F7)	: Throttle position switch
F3	(F8)	: Throttle position sensor
G2	(F9)	: IACV-FICD solenoid valve-2
F2	(F10)	: IACV-AAC valve (Step motor type)
G3	(F11)	: EGR temperature sensor
G2	(F12)	: IACV-FICD solenoid valve-1
D1	(F13)	: Check connector
C2	(F14)	: To (F131)
C2	(F15)	: Camshaft position sensor (PHASE)
C2	(F17)	: Injector No. 2
C2	(F16)	: Engine ground
D2	(F19)	: Engine ground
D3	(F20)	: Injector No. 4
D3	(F21)	: Injector No. 6
E3	(F22)	: Condenser
F2	(F23)	: To (F121)
F3	(F24)	: EGRC-solenoid valve
E4	(F25)	: Thermal transmitter
E4	(F26)	: Engine coolant temperature sensor
D4	(F27)	: To (F111)
C3	(F28)	: Front heated oxygen sensor (LH)
D4	(F29)	: Ignition coil No. 6
C3	(F30)	: Ignition coil No. 4


C3	(F31)	: Ignition coil No. 2
F3	(F32)	: Neutral and reverse position switch
G4	(F33)	: Mass air flow sensor
G4	(F34)	: Intake air temperature sensor
G3	(F35)	: Dropping resistor
G4	(F36)	: To (E13)
G4	(F37)	: To (E14)
E4	(F38)	: Front engine mounting
E4	(F39)	: Inhibitor switch (A/T models)
E3	(F40)	: Canister control solenoid valve
F4	(F41)	: Revolution sensor (A/T models)
F4	(F42)	: Terminal cord assembly (A/T models)
F4	(F43)	: Vehicle speed sensor
B4	(F101)	: ECM (ECCS control module)
C4	(F102)	: To (M50)
B5	(F103)	: A/T control unit (A/T models)
A5	(F104)	: To (M51)
A5	(F105)	: To (M50)
A4	(F106)	: Joint connector-24 (Gray)
A4	(F107)	: Joint connector-25 (Blue)
C4	(F111)	: To (F27)
D4	(F112)	: Crankshaft position sensor (POS)
F3	(F121)	: To (F23)
D4	(F122)	: Knock sensor
D2	(F131)	: To (F131)
D2	(F132)	: Injector No. 1
E2	(F133)	: Injector No. 3
E2	(F134)	: Injector No. 5
D4	(F135)	: Oil pressure switch
C4	(F136)	: Crankshaft position sensor (REF)

*: Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the system to light up the MIL as an open circuit detection.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNES LAYOUT

Body Harness



HARNES LAYOUT



Body Harness (Cont'd)

B2	B1	To	MA
B2	B2	To	MS
B3	B3	Fuse block (HEC)	
A3	M	Fuse block (HEC)	
B3	M5	To power seat harness LH	
C3	B7	Seat belt buckle switch	
B3	B6	Heated seat LH	
C3	B9	Rear heated oxygen sensor	
C2	B10	Parking brake switch	
C3	B11	Heated seat switch LH	
C3	B12	Heated seat switch RH	
D3	B13	Heated seat RH	
D2	B14	To power seat harness	
E2	B15	Front door switch RH	
D2	B16	Body ground	
E2	B17	To	B71
B3	B18	Front door switch LH	
B2	B19	Body ground	
B3	B20	To	B51
E3	B21	Fuel pump	
E4	B22	Fuel tank gauge unit	
E3	B23	To	B110
D4	B25	Fuel pump control modulator (For California models)	
D4	B26	Dropping resistor	
E4	B27	To	T1
E4	B28	To	T2
C2	B29	To high-mounted stop lamp sub-harness (Models equipped with rear air spoiler)	
F4	B30	Trunk lid combination lamp LH	
F3	B31	Trunk room lamp switch	
G3	B32	Trunk lid key cylinder switch and tamper switch	
G3	B33	Trunk lid combination lamp RH	
D3	B34	Rear door switch LH	
D2	B35	Rear window defogger	
E3	B37	Rear speaker LH (BOSE system)	
E2	B38	Rear speaker LH (Except for BOSE system)	
E3	B39	Trunk room lamp	
F3	B40	High-mounted stop lamp (Models without rear air spoiler)	
F3	B41	Rear speaker RH (BOSE system)	
F3	B42	Rear speaker RH (Except for BOSE system)	
F2	B43	Rear door switch RH	

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNES LAYOUT

Body No. 2 Harness and Tail Harness




- B101** : To **M70**
- B102** : To **M71**
- B105** : Rear wheel sensor RH (Anti-lock brake system)
- B109** : Rear wheel sensor LH (Anti-lock brake system)
- B110** : To **B23**

- T1** : To **B27**
- T2** : To **B28**
- T3** : Rear side marker lamp LH
- T4** : Rear combination lamp LH
- T5** : Multi-remote control relay-1
- T6** : Body ground
- T7** : Trunk lid opener actuator
- T8** : License lamp
- T9** : Body ground
- T10** : Rear combination lamp RH
- T11** : Rear side marker lamp RH
- T12** : Multi-remote control unit (LCU05)
- T13** : Power antenna

HARNESS LAYOUT

Room Lamp Harness




- (R1)** : To **(MT10)**
- (R2)** : Vanity mirror illumination LH
- (R3)** : Sun roof motor
- (R4)** : Spot lamp
- (R5)** : Vanity mirror illumination RH
- (R6)** : Interior lamp

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNES LAYOUT

Air Bag Harness




HARNESS LAYOUT

FRONT

Door Harness (LH side)


- | | |
|--|--|
| D1 : To M8 | D8 : Power window regulator |
| D2 : To M9 | D9 : Driver door control unit (LCU01) |
| D3 : Front door speaker LH (Except for BOSE system) | D10 : Trunk lid opener switch |
| D4 : Door mirror LH | D11 : Front door step lamp LH |
| D5 : Door mirror defogger LH | D12 : Front door lock actuator LH |
| D6 : Front door speaker LH (BOSE system) | |
| D7 : Key cylinder switch LH | |



MEL378D

REAR

- | |
|--|
| D51 : To B20 |
| D52 : Rear door step lamp LH |
| D53 : Rear LH door control unit (LCU04) |
| D54 : Rear door power window regulator LH |
| D55 : Rear door lock actuator LH |




MEL379D

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

HARNESS LAYOUT

FRONT

Door Harness (RH side)



REAR

