ELECTRICAL SYSTEM

SECTION

MA

EM

LC

EC

FE

GI

CONTENTS

PRECAUTIONS	4
Supplemental Restraint System (SRS) "AIR	
BAG" and "SEAT BELT PRE-TENSIONER"	4
Precautions for Trouble Diagnosis	4
Precautions for Harness Repair	
Wiring Diagrams and Trouble Diagnosis	
HARNESS CONNECTOR	
Description	6
STANDARDIZED RELAY	8
Description	8
POWER SUPPLY ROUTING	10
Schematic	10
Wiring Diagram - POWER	11
Inspection	
GROUND	
Ground Distribution	19
COMBINATION SWITCH	31
Check	31
Replacement	32
STEERING SWITCH	33
Check	33
HEATED STEERING	34
Component Parts and Harness Connector	
Location	34
System Description	34
Wiring Diagram - H/STRG	36
HEADLAMP (FOR USA)	37
Component Parts and Harness Connector	
Location	
System Description	
Schematic	
Wiring Diagram - H/LAMP	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses	
Bulb Replacement	
Aiming Adjustment	50
HEADLAMP (FOR CANADA) - DAYTIME LIGHT	
SYSTEM -	51

	CL
Component Parts and Harness Connector	
Location51	
System Description51	MT
Schematic54	
Wiring Diagram - DTRL55	. —
Trouble Diagnoses60	AT
Bulb Replacement63	
Aiming Adjustment64	$\wedge \nabla$
PARKING, LICENSE AND TAIL LAMPS	AX
System Description65	
Schematic	SU
Wiring Diagram - TAIL/L68	00
Trouble Diagnoses72	
STOP LAMP	BR
Wiring Diagram - STOP/L73	
BACK-UP LAMP74	
Wiring Diagram - BACK/L74	ST
FRONT FOG LAMP	
System Description	6
Wiring Diagram - F/FOG	RS
Aiming Adjustment	
TURN SIGNAL AND HAZARD WARNING LAMPS80	BT
System Description80	
Wiring Diagram - TURN82	
Trouble Diagnoses	HA
Electrical Components Inspection	
ILLUMINATION	00
System Description	SC
Schematic	
Wiring Diagram - ILL87	EL
INTERIOR, STEP, SPOT, VANITY MIRROR AND	
TRUNK ROOM LAMPS	
System Description	IDX
Schematic	
Wiring Diagram - INT/L96	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses for Interior Lamp Timer104	
METERS AND GAUGES	

CONTENTS (Cont'd)

Component Parts and Harness Connector	
Location	117
System Description	117
Combination Meter	119
Schematic	120
Wiring Diagram - METER	121
Meter/Gauge Operation and Odo/Trip Meter	
Segment Check in Diagnosis Mode	122
Trouble Diagnoses	123
Electrical Components Inspection	129
BOARD COMPUTER	
System Description	130
Wiring Diagram - B/COMP	
Trouble Diagnoses	
Electrical Components Inspection	
WARNING LAMPS	
Schematic	
Wiring Diagram - WARN	137
Electrical Components Inspection	
A/T INDICATOR	
Wiring Diagram - AT/IND	
WARNING CHIME	
Component Parts and Harness Connector	
Location	144
System Description	
Wiring Diagram - CHIME	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses	
FRONT WIPER AND WASHER	
System Description	159
Wiring Diagram - WIPER	
Removal and Installation	
Washer Nozzle Adjustment	
Washer Tube Layout	
HORN	
Wiring Diagram - HORN	
CIGARETTE LIGHTER	
Wiring Diagram - CIGAR	
CLOCK	
Wiring Diagram - CLOCK	
REAR WINDOW DEFOGGER	
Component Parts and Harness Connector	
Location	167
System Description	
Wiring Diagram - DEF	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses	
Electrical Components Inspection	
Filament Check	
Filament Repair	

AUDIO	.180
System Description	.180
Schematic	.182
Wiring Diagram - AUDIO	.183
Trouble Diagnoses	.190
Inspection	.191
Wiring Diagram - REMOTE	.192
AUDIO ANTENNA	.193
Wiring Diagram - W/ANT	.193
Location of Antenna	.194
Window Antenna Repair	
POWER SUNROOF	
System Description	
Wiring Diagram - SROOF	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses	
DOOR MIRROR	
Wiring Diagram - MIRROR	
AUTO ANTI-DAZZLING INSIDE MIRROR	
Wiring Diagram - I/MIRR	
TRUNK LID AND FUEL FILLER LID OPENER	
Wiring Diagram - T&FLID	
TELEPHONE (PRE WIRE)	
Wiring Diagram - PHONE	
POWER SEAT	
Wiring Diagram - SEAT	
HEATED SEAT	
Wiring Diagram - HSEAT	
Seatback Heating Unit	
Component Parts and Harness Connector	.210
	210
System Description	
Schematic	
Wiring Diagram - AUT/DP	
On Board Diagnosis	
Trouble Diagnoses	
AUTOMATIC SPEED CONTROL DEVICE (ASCD)	
System Description	
POWER WINDOW	
System Description	
Schematic	
Wiring Diagram - WINDOW	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses	
POWER DOOR LOCK	.261
Component Parts and Harness Connector	
Location	
System Description	
Schematic	.262

CONTENTS (Cont'd)

Wiring Diagram - D/LOCK	263
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	268
Trouble Diagnoses	269
REMOTE KEYLESS ENTRY SYSTEM	277
Component Parts and Harness Connector	
Location	277
System Description	277
Schematic	
Wiring Diagram - KEYLES	
CONSULT-II Inspection Procedure	
CONSULT-II Application Items	
Trouble Diagnoses	
ID Code Entry Procedure	
Keyfob Battery Replacement	307
VEHICLE SECURITY (THEFT WARNING)	
SYSTEM	308
Component Parts and Harness Connector	
Location	
System Description	
Schematic	
Wiring Diagram - VEHSEC	
CONSULT-II Inspection Procedure	
CONSULT-II Application Item	
Trouble Diagnoses	
SMART ENTRANCE CONTROL UNIT	
Description	
CONSULT-II	
Schematic	
Smart Entrance Control Unit Inspection Table	
HOMELINK UNIVERSAL TRANSCEIVER	
Wiring Diagram - TRNSCV	
Trouble Diagnoses	354
NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM	
- NATS)	356
Component Parts and Harness Connetor	050
Location	
System Description	
System Composition	
Wiring Diagram - NATS	
CONSULT-II	
Trouble Diagnoses	
How to Replace NVIS (NATS) IMMU	
NAVIGATION SYSTEM	
System Description	376

Schematic	383	G
Wiring Diagram - NAVI3	384	
Self-diagnosis Mode	387	
Confirmation/Adjustment Mode	390	N
Setting Mode4	100	
Trouble diagnoses4	804	E
This Condition is Not Abnormal4	14	G
Program Loading4	25	
Initialization4	26	L
CAN COMMUNICATION4	29	
System Description4	29	
CAN SYSTEM (FOR A/T MODELS)4		
Component Parts and Harness Connector		
Location4	130	_
System Description4		
Wiring Diagram - CAN4		
Trouble Diagnoses4		C
Component Inspection4		C
CAN SYSTEM (FOR TCS MODELS)4		
Component Parts and Harness Connector		R
Location4	136	п.
System Description4		
Wiring Diagram - CAN4		A
Trouble Diagnoses4		
Component Inspection4		
ELECTRICAL UNITS LOCATION	140	A
Engine Compartment4		
Passenger Compartment4		90
HARNESS LAYOUT		9
How to Read Harness Layout4		
Outline4		
Main Harness4		2
Engine Room Harness4		GD
Engine Control Harness4		
Body Harness		_
Body No. 2 Harness4		
Tail Harness		
Room Lamp Harness4		6
Front Door Harness4		
Rear Door Harness4		
BULB SPECIFICATIONS		ŀ
Headlamp4		Ц
Exterior Lamp4		
Interior Lamp4		S
WIRING DIAGRAM CODES (CELL CODES)4	77	

EL

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL A33 is as follows:

• For a frontal collision

The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, crash zone sensor, warning lamp, wiring harness and spiral cable.

For a side collision
 The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow harness connector.

Precautions for Trouble Diagnosis CAN SYSTEM

NFEL0265

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.




Precautions for Harness Repair CAN SYSTEM

NFEL0266

Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]

PRECAUTIONS



When you read wiring diagrams, refer to the following:

GI-11, "HOW TO READ WIRING DIAGRAMS" •

•	EL-10, "POWER SUPPLY ROUTING" for power distribution circuit
Wh	nen you perform trouble diagnosis, refer to the following:

- GI-35, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES" •
- GI-24, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"
- Check for any Service bulletins before servicing the vehicle.

AT

GI

MA

EM

LC

EC

FE

CL

MT

NFEL0002

AX

SU

BR

ST

BT

HA

SC

EL

IDX

Description


HARNESS CONNECTOR (TAB-LOCKING TYPE)

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector. **CAUTION:**

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

NFEL0003 NFEL0003S01

HARNESS CONNECTOR

EM

LC


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



HA


STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NFEL0004 NFEL0004S01




TYPE OF STANDARDIZED RELAYS

 Image: Image:



SEL882H

STANDARDIZED RELAY




EL-9


Schematic

For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-19.


NFEL0005





Wiring Diagram — POWER –




EL-POWER-02










ACCESSORY POWER SUPPLY - IGNITION SW. IN "ACC" OR "ON"





12

2

22

13 14 15 16

23 24 25

17 18 19 20


MEL086O


26 27 28 29 30 3


UP


MEL087O

IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"










CEL083



Inspection

FUSE

•

If fuse is blown, be sure to eliminate cause of problem before installing new fuse.

NFEL0007


- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.

FUSIBLE LINK

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



CIRCUIT BREAKER (PTC THERMISTOR TYPE)

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current.

Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.

Ground Distribution

MAIN HARNESS

(M9)

Body ground

View with instrument panel removed

	CON- NECTOR NUMBER	CONNECT TO	FE
•	M20	Power window relay	CL
•	M24	Door mirror remote control switch (Illumination)	MT
•	M28	Data link connector (Terminal No. 4)	0/00
•	M45	TCS ON/OFF switch (With TCS)	AT
•	M154	Memory seat cancel switch (With memory seat)	0.07
•	M155	Heated steering switch (With heated steering) (Terminal No. 2)	AX
•	M155	Heated steering switch (With heated steering) (Terminal No. 5)	
•	M156	Combination switch (With heated steering) (Terminal No. 2)	SU
•	M160	Rear window defogger switch (With navigation system) (Terminal No. 2)	BR
•	M160	Rear window defogger switch (With navigation system) (Terminal No. 5)	
•	M165	A/T device (With A/T) (Terminal No. 2)	ST
Room lamp harness	R4	Vanity mirror LH (Illumination)	
· · · · · · · · · · · · · · · · ·	R4	Homelink universal transceiver	RS
•	R5	Sunroof motor (With sunroof)	
•		Spot lamp	BT
•	R8	Vanity mirror RH (Illumination)	
	R15	Auto anti-dazzling inside mirror	HA

A B Next page MA

EM


LC

EC

NFEL0008

SC

EL



Next page


MEL062O


eding page	CON-		
	NECTOR NUMBER	CONNECT TO	
	M72	Ashtray illumination	
•	M78	Power socket	
-	M144	Smart entrance control unit (Terminal No. 43)	
•	(M146)	Air bag diagnosis sensor unit (Terminal No. 2)	
Main sub-harness-1	(M152)	Clock	
	 	Shift lock control unit (With A/T)	
		Display and NAVI control unit (Terminal No. 3)	
		Display and NAVI control unit (Terminal No. 4)	
	M169	Display and NAVI control unit (Terminal No. 33)	
View with instrument panel remove	ed	[
Intake unit bar	F 0		
M87			
Body ground	B		
	CON- NECTOR NUMBER	CONNECT TO	
	M31	Fan control amp. (With auto A/C)	
	- <u>M58</u>	Fan switch (With manual A/C)	
	M34	Combination meter (Terminal No. 59) • Board computer	
	- M44	In-vehicle sensor (With auto A/C)	
	- <u>M48</u>	Mode door motor (With manual A/C)	
	M49	Mode door motor (With auto A/C)	
		Air mix door motor (With manual A/C)	
	- <u>(M51)</u>	Air mix door motor (With auto A/C)	
	- <u>(M56)</u>	A/C control unit (With manual A/C) A/C auto amp. (With auto A/C)	
	- <u>M60</u>	(Without navigation system)	
	- <u>M74</u>	Heated seat switch LH	
	- <u>M75</u>	Heated seat switch RH	
	- <u>M80</u>	Intake sensor (With auto A/C)	
	- <u>M82</u>	Glove box lamp Intake door motor (With manual A/C)	
	- <u>(M83)</u> - (M84)		
		Intake door motor (With auto A/C)	
	- <u>(M85)</u>	Sunload sensor (With auto A/C)	
	- <u>M145</u>	Smart entrance control unit (Terminal No. 64)	
	(M171)	A/C auto amp. (With auto A/C)	
		(with havigation system)	
M15 E81 Engine room harness	E55	(With navigation system) Ambient sensor (With auto A/C)	I

EL-21

ENGINE ROOM HARNESS


NFEL0008S02
NI LL0000002






Next page

MEL064O



1D)X

MEL065O



MEL066O

ENGINE CONTROL HARNESS

NFEL0008S03

F39, F40 F41, F42			GI MA
Engine ground	CON- NECTOR NUMBER	CONNECT TO	EM
J/C-19 F49 M81 Main harness	M28	Data link connector (Terminal No. 5)	LC
F54	F 64	Shield wire (Electric throttle control actuator) (Throttle control motor)	EC
J/C-18	F62	Heated oxygen sensor 2 (Bank 2)	
(F46)	F63	Heated oxygen sensor 2 (Bank 1)	FE
F8 F131 Engine control sub-harness-3	F132	Shield wire (Knock sensor)	
			GL
F41			MT AT
Engine ground	CON- NECTOR NUMBER	CONNECT TO	
•	F48	ECM (Terminal No. 106)	AX
↓	F 48	ECM (Terminal No. 107)	வா
	(E4P)	ECM (Terminal No. 108)	SU

(F48)

(F152)

(F213)

Engine control sub-harness-4

Engine control sub-harness-7

F10 F151

F66 F211

ECM (Terminal No. 108)

Park/Neutral position switch (With A/T)

Park/Neutral position switch (With M/T)

RS

BT

HA

SC

EL


IDX

F39, F40 (F41, F42) (F41, F42) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C		
Engine ground	CON- NECTOR NUMBER	CONNECT TO
	F30	Ignition coil No. 6
•	F 31	Ignition coil No. 4
•	(F35)	Ignition coil No. 2
Engine control	(F34)	Condenser
Engine control sub-harness-8	(F222)	Ignition coil No. 1
•	(F223)	Ignition coil No. 3
	(F224)	Ignition coil No. 5

Engine ground	CON- NECTOR	CONNECT TO
	NUMBER	
F49 M81 Main namess	(M42)	NVIS (NATS) IMMU
•	(F48)	ECM (Terminal No. 48)
•	(F48)	ECM (Terminal No. 57)
•	(F50)	TCM (Transmission control module) (Terminal No. 25)
	(F50)	TCM (Transmission control module) (Terminal No. 48)
Engine control sub-harness-5 Engine control F70 F231	(F65)	Camshaft position sensor (PHASE) (Bank 2)
	(F173)	Crankshaft position sensor (POS)
	(F232)	Camshaft position sensor (PHASE) (Bank 1)

BODY HARNESS NFEL0008S04 View with GI * 1: With CD auto changer (B44) (B59) B60 center pillar * 2: Without CD auto changer 0 or lower garnish *2 B59 **B**7 LH removed MA O **B**7 Body ground B60 CON-NECTOR CONNECT TO ୭ *1 NUMBER Body ground LC Seat control unit LH_sub-harness *2 (B53)(B511) (B512) Seat control unit LH (Terminal No. 33) (B513) Seat control unit LH (Terminal No. 16) EC (B515) Power seat switch LH Power seat switch LH sub-harness* B35) (B521) (B550) Power seat switch LH FE High-mounted stop lamp (B14) (Without rear air spoiler) CL (B29) Front door switch LH (B34) Seat belt buckle switch LH MT (B57) CD auto changer Seat cushion heater Seatback heater LH sub-harness* LH sub-harness* B32 B561 (B562) (B581) Seatback heater LH Rear door harness LH AT B31) [D81 (D85) Rear power window switch LH AX (B12) Body ground M SU (B13) B12 B13 // ST View with seatback Side finisher LH removed Body ground CON-NECTOR NUMBER 11 1 <u>\\a.</u> CONNECT TO Engine control Main harness harness (M161) (F68) B3 M6 (F48) ECM (Terminal No. 78) BT Fuel level sensor unit and fuel pump (Terminal No. 5) (B19) Fuel level sensor unit and fuel pump (B19) HA (Terminal No. 3) (B27) Condenser SC B44 CON-NECTOR NUMBER E CONNECT TO Body ground Shield wire (Air bag diagnosis sensor unit) (B42) (With side air bag system) (Terminal No. 44)


*: This sub-harness is not shown in "Harness layout", EL section.



MEL347K

BODY NO. 2 HARNESS

Ground Distribution (Cont'd)



*: This sub-harness is not shown in "Harness layout", EL section.

MEL070O

TAIL HARNESS


Body ground	CON- NECTOR NUMBER	CONNECT TO
	- []	Rear combination lamp LH • Turn signal lamp • Tail/Stop lamp • Back-up lamp
•	T2	Rear side marker lamp LH
	T5	Rear combination lamp RH • Turn signal lamp • Tail/Stop lamp • Back-up lamp
•	- 17	Rear side marker lamp RH
•	Т9	Trunk room lamp switch
•	T11	Stop and tail lamp unit

Body ground

MEL203O

NFEL0008S06


COMBINATION SWITCH




MEL078O

Replacement

COMBINATION SWITCH






Replacement

For removal and installation of spiral cable, refer to RS-20, "Installation — Air Bag Module and Spiral Cable".


- Each switch can be replaced without removing spiral cable.
- 1. Remove the instrument lower panel on driver side.
- 2. Remove the steering column cover.
- 3. Remove lighting switch or wiper and washer switch mounting screw.
- 4. Remove lighting switch or wiper and washer switch from the spiral cable.
- 5. Disconnect lighting switch or wiper and washer switch connector.

STEERING SWITCH



HEATED STEERING

Component Parts and Harness Connector Location



System Description

The heated steering system is controlled by the smart entrance control unit. The heated steering system operates only for approximately 30 minutes after heated steering switch is turned "ON".

Then the heated steering system is turned "OFF" when the heated steering switch is turned "ON" again or ignition switch "OFF" within 30 minutes after heated steering system "ON".

Power is supplied at all times

- to smart entrance control unit terminal 49
- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to heated steering relay terminal 3
- through 10A fuse (No. 72, located in the fuse and fusible link box)

With the ignition switch in the ON or START position, power is supplied.

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to the heated steering relay terminal 1 and
- to smart entrance control unit terminal 27.

Ground is supplied

- to terminal 2 and 5 of heated steering switch and
- to combination switch (heated steering switch) terminal 2
- through body grounds M9, M25 and M87.

When the heated steering switch is turned ON, ground is supplied

- through terminal 1 of heated steering switch
- to smart entrance control unit terminal 4.

Terminal 40 of the smart entrance control unit then supplies ground to the heated steering relay terminal 2. With power and ground supplied, the heated steering relay is energized. Power is supplied


- through terminal 5 of heated steering relay
- to heated steering switch terminal 4 and
- to combination switch (heated steering switch) terminal 1.
- through terminal 3 of combination switch (heated steering switch)
- to the heated steering (thermostat).


Ground is supplied for heated steering

through heated steering

EL-34

 to combination switch (heated steering switch) terminal 4. With power and ground supplied, the heated steering heats. 	GI
When the system is activated, the heated steering indicator lamp illuminates in the heated steering switch.	
	MA
	EM
	LC
	EC
	FE
	GL
	MT
	AT
	AX
	SU
	BR
	ST
	RS
	BŢ
	HA
	SC
	EL
	IDX





* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.


MEL133O

SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
4	G	HEATED STEERING SWITCH	OFF \rightarrow ON (ONLY WHEN PUSHED)	$5V \rightarrow 0V$
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN "ON" POSITION	12V
40	B/R	HEATED STEERING RELAY	OFF \rightarrow ON (IGNITION KEY IS IN "ON" POSITION)	$12V \rightarrow 0V$
49	R/B	POWER SOURCE (FUSE)	-	12V

HEADLAMP (FOR USA)

Component Parts and Harness Connector Location



System Description

The headlamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. And the headlamp battery saver system is controlled by the smart entrance control unit.

OUTLINE	NFEL0198S01	AX
Power is supplied at all times	INFELUI90301	
 to headlamp LH relay terminals 1 and 6 		രസ
 through 20A fuse (No. 54, located in the fuse and fusible link box), and 		SU
 to headlamp LH relay terminal 3 		
 through 15A fuse (No. 68, located in the fuse and fusible link box), and 		BR
 to headlamp RH relay terminals 1 and 6 		
 through 20A fuse (No. 55, located in the fuse and fusible link box), and 		ST
 to headlamp RH relay terminal 3 		91
 through 15A fuse (No. 69, located in the fuse and fusible link box), and 		
 to smart entrance control unit terminal 49 		RS
 through 10A fuse [No. 13, located in the fuse block (J/B)]. 		
When the ignition switch is in the ON or START position, power is supplied		BT
 to smart entrance control unit terminal 27 		DI
 through 10A fuse [No. 10, located in the fuse block (J/B)]. 		
When the ignition switch is in the ACC or ON position, power is supplied		HA
 to smart entrance control unit terminal 26 		
 through 10A fuse [No. 1, located in the fuse block (J/B)] 		SC
Ground is supplied		00
 to smart entrance control unit terminals 43 and 64 		
 through body grounds M9, M25 and M87. 		EL
POWER SUPPLY TO LOW BEAM AND HIGH BEAM		
When lighting switch is in 2ND or PASS position, ground is supplied	NFEL0198S07	IDX
• to headlamp LH relay terminal 2 from smart entrance control unit terminal 21		
through smart entrance control unit terminal 22,		

- from lighting switch terminal 12, and
- to headlamp RH relay terminal 2 from smart entrance control unit terminal 59

System Description (Cont'd)

- through smart entrance control unit terminal 60,
- from lighting switch terminal 12.

Headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from terminal 7 of each headlamp relay
- to terminal 1 of each headlamp

Ground is supplied

- to headlamp LH terminal 2
- through body grounds E11, E22 and E53, and
- to headlamp RH terminal 2
- through body grounds E11, E22 and E53.

With power and ground supplied, the headlamp(s) will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from terminal 5 of each headlamp relay
- to terminal 4 of each headlamp, and
- to combination meter terminal 26 for the HIGH BEAM indicator.

Ground is supplied

- to headlamp LH terminal 5
- through lighting switch terminals 6 and 5
- through body grounds E11, E22 and E53, and
- to headlamp RH terminal 5
- to combination meter terminal 27 for the HIGH BEAM indicator
- through lighting switch terminals 9 and 8
- through body grounds E11, E22 and E53.

With power and ground supplied, the high beams and the high beam indicator illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

While the headlamp is turned ON by "2ND" of light switch, the 5 minute timer is activated when the ignition switch is turned from ON (or START) to OFF (ACC OFF).

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.

While the headlamp is turned ON by "AUTO" of light switch, the 5 minutes timer is activated when the ignition switch signal changes from ON (or START) to OFF (ACC OFF), and either one of LH or RH front door switch ON signal is input.

The auto light delay off timer is activated as the following:

- When the door switch signal changes from ON to OFF while the timer is activated, the timer in operation is discontinued and the 45 second timer is reset.
- When the door switch signal changes from OFF to ON while the timer is activated, the timer is discontinued and the 45 second timer is reset.
- When the one of four door switch signals changes from OFF to ON while the timer is activated, the timer is discontinued and the 5 minute timer is reset.
- When all the door switch ON signals are input while the timer is activated, the timer is discontinued and the 45 second timer is reset.

Exterior lamp battery saver control mode and auto light delay off timer period can be changed by the function setting of CONSULT-II (EL-46).

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.


EL-38

HEADLAMP (FOR USA)

	Oystern Description (Contra)			
Then headlamps illuminate again.				
AUTO LIGHT OPERATION	NFEL0198506	GI		
The auto light control system has an auto light sensor inside it that detects outside brightness. When lighting switch is in "AUTO" position, ground is supplied				
to smart entrance control unit terminal 23 from lighting quiteb terminal 42		MA		
 from lighting switch terminal 42. When ignition switch is turn to "ON" or "START" position and 				
Outside brightness is darker than prescribed level. Ground is supplied		EM		
• to headlamp relay LH and RH terminals 2		LC		
• through smart entrance control unit terminal 21, 59 and 43, 64.				
Then both headlamp relays and tail lamp relay are energized, headlamp minate according to switch position.	os (low or high) and tall lamps are lilu-	EC		
Auto light operation allows headlamps and tail lamps to go off when or	utside brightness is brighter than pre-			
scribed level.		FE		
NOTE: The delay time changes (maximum of 20 seconds) as the outside	brightness changes.			
For parking license and tail lamp auto operation, refer to "PARKING, LI		CL		
VEHICLE SECURITY SYSTEM		05		
The vehicle security system will flash the low beams if the system is trigg (THEFT WARNING) SYSTEM" (EL-311).	gered. Refer to "VEHICLE SECURITY	MT		
XENON HEADLAMP		<u> </u>		
Xenon type headlamp is adopted to the low beam headlamps. Xenon		AT		
they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to added lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.				
 Following are some of the many advantage of the xenon type headlam The light produced by the headlamps is white color approximating s Light output is nearly double that of halogen headlamps, affording i 	sunlight that is easy on the eyes.	SU		
 The light features a high relative spectral distribution at wavelength which means that even in the rain, more light is reflected back from for added visibility. 	s to the human eye is most sensitive,	BR		
 Power consumption is approximately 25 percent less than halogen 	headlamps, reducing battery load.	ST		
		91		
Shade Reflector XENON TYPE	CONVENTIONAL TYPE	RS		
Bulb 5 lx 60 (197)	100 (328) 80 (262) 60 (197)	BT		
socket 20 lx 40 (5 lx			
	20 lx	HA		
		SC		
HID control unit		EL		
Transforms battery United Strength Illuminating	Area (Example) Unit: m (ft)	IDX		
Structure of the new xenon headlamp	lx = Lux			
HID: High Intensity Discharge	SEL477Y			


Schematic






MEL714P


HEADLAMP (FOR USA)






MEL092O

EL-H/LAMP-03




SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM		CONDITIO	N	DATA (DC)
1	LG	DRIVER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$		$12V \rightarrow 0V$	
2	R/L	PASSENGER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$		$5V \rightarrow 0V$	
3	R/W	REAR DOOR SWITCH	OFF (CLOSED) \rightarrow ON	(OPEN)		$5V \rightarrow 0V$
7	W/R	AUTO LIGHT SENSOR	IGNITION SWITCH		D TO AUTO LIGHT SENSOR	1 TO 5V
'	VV/L	(SIGNAL)	"ON" POSITION	LIGHT IS NOT AF	PLIED TO AUTO LIGHT SENSOR	LESS THAN 1V
8	P/B	AUTO LIGHT SENSOR (GND)		-		-
	R	AUTO LIGHT SENSOR	IGNITION SWITCH (OF			$0V \rightarrow 5V$
9	п	(POWER)	IGMITION SWITCH (OF			$0V \rightarrow 5V$
20	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (OF	F or auto \rightarrow 1	ST OR 2ND POSITION)	$12V \rightarrow 0V$
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
21	OR	HEADLAMP LH RELAY	(WITH LIGHTING	\rightarrow OFF	WITHIN 5 MINUTES	0V
21	On		SWITCH 2ND)	ON OR START		0V
			HEADLAMPS ILLUMINA	ATE BY AUTO LIGH	HT CONTROL	0V
			LIGHTING SWITCH	EXCEPT PASS O	R 2ND POSITION	12V
				PASS OR 2ND PO	DSITION	0V
22	L/OR		HEADLAMPS ILLUMINATE BY AUTO LIGHT CONTROL		10V → 12V	
			$(OPERATE \rightarrow NOT OPERATE)$			
23	L/Y	HEADLAMP SWITCH	IGNITION SWITCH	LIGHTING SWITC	CH (EXCEPT AUTO →	
23	L/ f	HEADLAIMF SWITCH	"ON" POSITION	AUTO POSITION)	$12V \rightarrow 0V$
26	PU	IGNITION SWITCH (ACC)	"ACC" POSITION 1		12V	
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN	N "ON" POSITION		12V
43	В	GROUND		-		-
49	R/B	POWER SOURCE (FUSE)		-		12V
58	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (OF	F or auto \rightarrow 18	ST OR 2ND POSITION)	12V → 0V
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
			(WITH LIGHTING	\rightarrow OFF	WITHIN 5 MINUTES	0V
59	Р	HEADLAMP RH RELAY	SWITCH 2ND)	ON OR START		0V
			HEADLAMPS ILLUMINA	ATE BY AUTO LIGH	HT CONTROL	LESS THAN
			$(OPERATE \rightarrow NOT OPERATE)$		1V → 12V	
				EXCEPT PASS C	R 2ND POSITION	12V
60				PASS OR 2ND P	OSITION	0V
00	LG/R		HEADLAMPS ILLUMINATE BY AUTO LIGHT CONTROL		$10V \rightarrow 12V$	
			$(OPERATE \rightarrow NOT OPERATE)$		100 - 120	
64	В	GROUND		-		-

HEADLAMP (FOR USA)



EL-45

CONSULT-II Application Items

"HEAD LAMP" Data Monitor

NFEL0201

NFEL0201S02

NFEL0201S0201

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
AUTO LIGT SW	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
AUTO LIGT SENS	Displays "Illumination outside of the vehicle (close to 5V when light/close to 0V when dark)" as judged from the optical sensor signal.
LIGHT SW 1ST	Displays status of the lighting switch as judged from the lighting switch signal. (1ST or 2ND position: ON/Other than 1ST and 2ND position: OFF)
LIGHT SW 2ND	Displays status of the lighting switch as judged from the lighting switch signal. (2ND position: ON/Other than 2ND position: OFF)
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.

Active Test

Active lest	NFEL0201S0202
Test Item	Description
TAIL LAMP	Tail lamp relay can be operated by on-off operation of the tail lamp.
HEAD LAMP	Headlamp relay can be operated by on-off operation of the headlamp.
AUTO LIGHT	Night time dimming signal can be operated by on-off operation.

Work Support

	NFEL0201S0203
Work Item	Description
AUTO LIGHT SET	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. • MODE 1 (Normal)/MODE 2 (Sensitive)/MODE 3 (Desensitized)/MODE 4 (Insensitive)
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two modes. • MODE 1 (ON)/MODE 2 (OFF)
ILL DELAY SET	 Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/ MODE 5 (90 sec.)/ MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

Trouble Diagnoses

NFEL0268

WARNING:

- The xenon headlamp has a high-tension current generating area. Be extremely careful when removing and installing. Be certain to disconnect the battery negative cable prior to removing or installing.
- When the xenon headlamp is lit, do not touch the harness (covered with red or amber insulation), bulb itself or the bulb socket with your bare hands.
- Never service a xenon headlamp with wet hands.
- When checking body side harness with a circuit tester, be certain to disconnect the harness connector from the xenon headlamp.
- When the xenon headlamp is lit, the xenon bulb must be installed in the headlamp housing. (Never turn on xenon headlamp, if the bulb is out of the headlamp housing.)

GI

CAUTION:

Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.

Symptom	Possible cause	Repair order
Neither headlamp operates.	 10A fuse Lighting switch Smart entrance control unit 	 Check 10A fuse [No. 13, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit. Check Lighting switch. Check smart entrance control unit. (EL-350)
LH headlamp (low and high beam) does not operate, but RH head- lamp (low and high beam) does operate.	 20A fuse Headlamp LH relay Headlamp LH relay circuit Lighting switch circuit Smart entrance control unit 	 Check 20A fuse (No. 54, located in fuse and fusible link box). Verify battery positive voltage is present at terminals 1 and 6 of headlamp LH relay. Check headlamp LH relay. Check harness between headlamp LH relay and smart entrance control unit. Check harness between smart entrance control unit and lighting switch. Check smart entrance control unit. (EL-350)
RH headlamp (low and high beam) does not operate, but LH headlamp (low and high beam) does operate.	 20A fuse Headlamp RH relay Headlamp RH relay circuit Lighting switch circuit Smart entrance control unit 	 Check 20A fuse (No. 55, located in fuse and fusible link box). Verify battery positive voltage is present at terminals 1 and 6 of headlamp RH relay. Check headlamp RH relay. Check harness between headlamp RH relay and smart entrance control unit. Check harness between smart entrance control unit and lighting switch. Check smart entrance control unit. (EL-350)
LH high beam does not operate, but LH low beam operates.	 Bulb 15A fuse Headlamp LH relay Open in the LH high beams circuit Lighting switch Lighting switch ground circuit 	 Check bulb. Check 15A fuse (No. 68, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 3 of headlamp LH relay. Check headlamp LH relay. Check the following. Harness between headlamp relay LH terminal 5 and LH headlamp for open circuit Harness between LH headlamp and lighting switch for open circuit Check lighting switch. Check harness between lighting switch and ground.
LH low beam does not operate, but LH high beam operates.	 Headlamp relay LH Open in the LH low beam circuit LH low beam ground circuit Xenon bulb HID control unit 	 Check headlamp relay LH Check harness between headlamp relay LH terminal 7 and LH headlamp for open circuit. Check harness between LH headlamp and ground. Replace the xenon bulb with other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) Replace the HID control unit with other side control unit or new one. (If headlamps illuminate correctly, replace the control unit.)
RH high beam does not operate, but RH low beam operates.	 Bulb 15A fuse Headlamp RH relay Open in the RH high beams circuit Lighting switch Lighting switch ground circuit 	 Check bulb. Check 15A fuse (No. 69, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 3 of headlamp RH relay. Check headlamp RH relay. Check the following. Harness between headlamp relay RH terminal 5 and RH headlamp for open circuit Harness between RH headlamp and lighting switch for open circuit Check lighting switch. Check harness between lighting switch and ground.

HEADLAMP (FOR USA)

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
RH low beam does not operate, but RH high beam operates.	 Headlamp relay RH Open in the RH low beam circuit RH low beam ground circuit Xenon bulb HID control unit 	 Check headlamp relay RH Check harness between headlamp relay RH terminal 7 and RH headlamp for open circuit. Check harness between RH headlamp and ground. Replace the xenon bulb with other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) Replace the HID control unit with other side control unit or new one. (If headlamps illuminate correctly, replace the control unit.)
High beam indicator does not work.	 Bulb Open in high beam circuit 	 Check bulb in combination meter. Check the following. Harness between headlamp RH relay and combination meter for an open circuit Harness between high beam indicator and lighting switch
Exterior lamp battery saver control does not operate properly.	 Door switch LH or RH circuit Smart entrance control unit 	 Check the following. a. Harness between smart entrance control unit and LH or RH door switch for open or short circuit b. LH or RH door switch ground circuit c. LH or RH door switch 2. Check smart entrance control unit. (EL-350)

Bulb Replacement

CAUTION:

NFEL0269

- After replacing a new xenon bulb, be sure to make aiming adjustments.
- Hold only the plastic base when handling the bulb. Never touch the glass envelope.
- Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.
- 1. Disconnect negative battery cable.
- 2. Disconnect headlamp connector.

WARNING:

Never service a xenon headlamp without disconnecting negative battery cable and with wet hands.

Seal cover
MEL471C

XENON BULB (LOW BEAM)

1. Remove headlamp seal cover by turning it counterclockwise.

HEADLAMP (FOR USA)

Bulb socket SEL678W	2. Turn bulb socket counterclockwise with keep pushing, then remove it.	gi Ma Em Lc
	 Release retaining pin. Remove the xenon bulb. Install in the reverse order of removal. CAUTION: 	EC
Retaining pin	 When disposing of the xenon bulb, do not break it; always dispose of it as is. Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket. 	FE CL MT
RH high beam	 HIGH BEAM 1. Turn the bulb clockwise (LH high beam) or counterclockwise (RH high beam). 2. Remove the bulb. 3. Install in the reverse order of removal. 	AT AX SU
Bulb SEL680W		BR ST
		RS BT
		HA


SC

EL

IDX

Aiming Adjustment


HEADLAMP (FOR USA)




Aiming Adjustment



- 1. Turn headlamp low beam on.
- 2. Use adjusting screw to perform aiming adjustment.
- First tighten the adjusting screw all the way and then make adjustment by loosening the screw.



Component Parts and Harness Connector Location



System Description

headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied	AT
before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.	AX
And battery saver system is controlled by the smart entrance control unit.	SU
r ower is supplied at all times	90
to headlamp LH relay terminals 1 and 6	
	BR
• to headlamp RH relay terminals 1 and 6	
 through 20A fuse (No. 55, located in the fuse and fusible link box), and 	ST
• to smart entrance control unit terminal 49	01
• through 10A fuse [No. 13, located in the fuse block (J/B)].	
	RS
 to daytime light control unit terminal 16 	
 through body grounds E11, E22 and E53, and 	BT
• to smart entrance control unit terminals 43 and 64	U
 through body grounds M9, M25 and M87. 	
When the ignition switch is in the ON or START position, power is also supplied	HA
 to daytime light control unit terminal 3 	
 through 10A fuse [No. 28, located in the fuse block (J/B)], and 	SC
 to smart entrance control unit terminal 27 	96
 through 10A fuse [No. 10, located in the fuse block (J/B)]. 	
When the ignition switch is in the ACC or ON position, power is supplied	EL
 to smart entrance control unit terminal 26 	
 through 10A fuse [No. 1, located in the fuse block (J/B)]. 	IDX
When the ignition switch is in the START position, power is supplied	uum
 to daytime light control unit terminal 2 	

• through 10A fuse [No. 21, located in the fuse block (J/B)].

EL-51

System Description (Cont'd)

HEADLAMP OPERATION

Power Supply to Low Beam and High Beam

When lighting switch is in 2ND or PASS position, ground is supplied

- to headlamp LH relay terminal 2 from smart entrance control unit terminal 21
- through smart entrance control unit terminal 22
- from lighting switch terminal 12, and
- to headlamp RH relay terminal 2 from smart entrance control unit terminal 59
- through smart entrnace control unit terminal 60
- from lighting switch terminal 12.

Headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

Low Beam Operation

When the lighting switch is turned to 2ND and LOW ("B") positions, ground is supplied

- to terminal 2 of the headlamp LH
- through body grounds E11, E22 and E53.

Ground is also supplied

- to terminal 2 of the headlamp RH
- through body grounds E11, E22 and E53.

With power and ground supplied, the low beam headlamps illuminate.

High Beam Operation/Flash-to-pass Operation

NFEL0204S0104 When the lighting switch is turned to 2ND and HIGH ("A") or PASS ("C") positions, ground is supplied

- to terminal 5 of LH headlamp
- through daytime light control unit terminals 10 and 14, and
- to combination meter terminal 27 for the HIGH BEAM indicator
- through lighting switch terminals 9 and 8
- through body grounds E11, E22 and E53.

Ground is also supplied

- to terminal 5 of RH headlamp
- through daytime light control unit terminals 9 and 13
- through lighting switch terminals 6 and 5
- through body grounds E11, E22 and E53.

With power and ground supplied, the high beam headlamps and HIGH BEAM indicator illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

While the headlamp is turned ON by "2ND" of light switch, the 5 minute timer is activated when the ignition switch is turned from ON (or START) to OFF (ACC OFF).

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.

While the headlamp is turned ON by "AUTO" of light switch, the 5 minute timer is activated when the ignition switch signal changes from ON (or START) to OFF (ACC OFF), and either one of LH or RH front door switch ON signal is input.

The auto light delay off timer is activated as the following:

- When the door switch signal changes from ON to OFF while the timer is activated, the timer in operation is discontinued and the 45 second timer is reset.
- When the door switch signal changes from OFF to ON while the timer is activated, the timer is discontin-ued and the 45 second timer is reset.
- When the one of four door switch signals changes from OFF to ON while the timer is activated, the timer is discontinued and the 5 minute timer is reset.
- When all the door switch ON signals are input while the timer is activated, the timer is discontinued and the 45 second timer is reset.

Exterior lamp battery saver control mode and auto light delay off timer period can be changed by the function setting of CONSULT-II (EL-46).

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the battery saver control, ground is supply

NFEL0204S0103

NFEL0204S01

NFEL0204S0107

System Description (Cont'd)

 to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then to headlamp LH and RH relays terminal 2 from headlamp battery saver control unit terminals 21 and 59 through smart entrance control unit terminals 22 and 60, and through lighting switch terminal 12. 	GI
Then headlamps illuminate again.	MA
AUTO LIGHT OPERATION For auto light operation, refer to "HEADLAMP" (EL-39).	EM
DAYTIME LIGHT OPERATION With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied	LC
 through daytime light control unit terminal 7 to terminal 4 of RH headlamp through terminal 5 of RH headlamp 	EC
 to daytime light control unit terminal 9 through daytime light control unit terminal 6 to terminal 4 of LH headlamp. 	FE
 Ground is supplied to terminal 5 of LH headlamp. through daytime light control unit terminal 16 	GL
 through body grounds E11, E22 and E53. Because the high beam headlamps are now wired in series, they operate at half illumination. 	MT
OPERATION	

OPERATION

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Eng			W	/ith er	igine	stoppe	ed					V	Vith er	ngine	runnir	ng				
			OFF 1ST		2ND		OFF		1ST		2ND		SU							
Lighting switch		A	В	С	Α	В	С	А	В	С	Α	В	С	A	В	С	А	В	С	
Lloodlown	High beam	Х	Х	Х	Х	Х	0	0	Х	0	_∆*	∆*	0	_∆*	∆*	0	0	Х	0	BR
Headlamp	Low beam	Х	Х	Х	Х	Х	0	0	0	0	Х	Х	Х	Х	Х	0	0	0	0	
Clearance and tail lamp		Х	Х	Х	0	0	0	0	0	0	Х	Х	Х	0	0	0	0	0	0	ST
License and instrument illu- mination lamp		x	x	х	0	0	0	0	0	0	x	х	x	0	0	0	0	0	0	RS

A: "HIGH BEAM" position

B: "LOW BEAM" position
C: "FLASH TO PASS" position
O : Lamp "ON"
X : Lamp "OFF"
△ : Lamp dims. (Added functions)
*: When starting the engine with the parking brake released, the daytime light will come ON.
When starting the engine with the parking brake pulled, the daytime light won't come ON.

EL

BT


HA

SC


IDX


Schematic


NFEL0205




Wiring Diagram — DTRL -











Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-04



Wiring Diagram — DTRL — (Cont'd)



Trouble Diagnoses

Trouble Diagnoses

NFEL0206

WARNING:

- The xenon headlamp has a high-tension current generating area. Be extremely careful when removing and installing. Be certain to disconnect the battery negative cable prior to removing or installing.
- When the xenon headlamp is lit, do not touch the harness (covered with red or amber insulation), bulb itself or the bulb socket with your bare hands.
- Never service a xenon headlamp with wet hands.
- When checking body side harness with a circuit tester, be certain to disconnect the harness connector from the xenon headlamp.
- When the xenon headlamp is lit, the xenon bulb must be installed in the headlamp housing. (Never turn on xenon headlamp, if the bulb is out of the headlamp housing.)

CAUTION:

Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.

Symptom	Possible cause	Repair order
Neither headlamp operates.	 10A fuse Lighting switch Smart entrance control unit 	 Check 10A fuse [No. 13, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit. Check Lighting switch. Check smart entrance control unit. (EL-350)
LH headlamp (low and high beam) does not operate, but RH head- lamp (low and high beam) does operate.	 20A fuse Headlamp LH relay Headlamp LH relay circuit Lighting switch circuit Smart entrance control unit 	 Check 20A fuse (No. 54, located in fuse and fusible link box). Verify battery positive voltage is present at terminals 1 and 6 of headlamp LH relay. Check headlamp LH relay. Check harness between headlamp LH relay and smart entrance control unit. Check harness between smart entrance control unit and lighting switch. Check smart entrance control unit. (EL-350)
RH headlamp (low and high beam) does not operate, but LH headlamp (low and high beam) does operate.	 20A fuse Headlamp RH relay Headlamp RH relay circuit Lighting switch circuit Smart entrance control unit 	 Check 20A fuse (No. 55, located in fuse and fusible link box). Verify battery positive voltage is present at terminals 1 and 6 of headlamp RH relay. Check headlamp RH relay. Check harness between headlamp RH relay and smart entrance control unit. Check harness between smart entrance control unit and lighting switch. Check smart entrance control unit. (EL-350)
LH high beam does not operate, but LH low beam operates.	 Bulb 15A fuse Headlamp LH relay Headlamp LH relay circuit Headlamp LH high beams circuit Lighting switch Lighting switch circuit Daytime light control unit 	 Check bulb. Check 15A fuse (No. 68, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 3 of headlamp LH relay. Check headlamp LH relay. Check harness between headlamp LH relay and daytime light control unit. Check harness between LH headlamp and lighting switch. Check the following. Harness between daytime light control unit and light- ing switch Harness between lighting switch and ground Check daytime light control unit.

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
LH low beam does not operate, but LH high beam operates.	 Headlamp relay LH Open in the LH low beam circuit LH low beam ground circuit Xenon bulb HID control unit 	 Check headlamp relay LH. Check harness between headlamp relay LH terminal 7 and LH headlamp for open circuit. Check harness between LH headlamp and ground. Replace the xenon bulb with other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) Replace the HID control unit with other side control unit or new one. (If headlamps illuminate correctly, replace the control unit.)
RH high beam does not operate, but RH low beam operates.	 Bulb 15A fuse Headlamp RH relay Headlamp RH relay circuit Open in the RH high beams circuit Lighting switch Lighting switch circuit Daytime light control unit 	 Check bulb. Check 15A fuse (No. 69, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 3 of headlamp RH relay. Check headlamp RH relay. Check harness between headlamp RH relay and daytime light control unit. Check harness between RH headlamp and lighting switch. Check the following. Harness between daytime control unit and lighting switch Harness between lighting switch and ground Check daytime light control unit.
RH low beam does not operate, but RH high beam operates.	 Headlamp relay RH Open in the RH low beam circuit RH low beam ground circuit Xenon bulb HID control unit 	 Check headlamp relay RH. Check harness between headlamp relay RH terminal 7 and RH headlamp for open circuit. Check harness between RH headlamp and ground. Replace the xenon bulb with other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) Replace the HID control unit with other side control unit or new one. (If headlamps illuminate correctly, replace the control unit.)
High beam indicator does not work.	 Bulb Open in high beam circuit 	 Check bulb in combination meter. Check the following. Harness between daytime light control unit and combination meter for an open circuit Harness between high beam indicator and lighting switch
Exterior lamp battery saver control does not operate properly.	 Door switch LH or RH circuit Smart entrance control unit 	 Check the following. Harness between smart entrance control unit and LH or RH door switch for open or short circuit LH or RH door switch ground circuit LH or RH door switch Check smart entrance control unit. (EL-350)
Daytime light control does not operate properly.	 Bulb Fuse check Parking brake switch Parking brake switch circuit Daytime control unit 	 Check bulb. Check the following. a. 10A fuse [No. 28, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of daytime light control unit. b. 10A fuse [No. 21, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 2 of daytime light control unit. Check parking brake switch. Check harness between parking brake switch and daytime light control unit. Check daytime light control unit. (EL-62)

Trouble Diagnoses (Cont'd)

DAYTIME LIGHT CONTROL UNIT CONNEC $ \begin{array}{c} 3 \\ 4 \\ 7 \\ \hline GY \end{array} \begin{array}{c} 14 \\ 5 \\ 6 \\ \hline GY \end{array} \begin{array}{c} 10 \\ 13 \\ \hline GY \end{array} \begin{array}{c} 10 \\ 13 \\ \hline GY \end{array} \begin{array}{c} 10 \\ 13 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline 10 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline 10 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline 10 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline 10 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline 10 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline 10 \\ \hline GY \end{array} \begin{array}{c} 10 \\ \hline GY \end{array} $	
	SEL584Y

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

Terminal No.	Wire color	Item		Condition	Voltage (Approximate values
1	BR	Alternator	Con	When turning ignition switch to "ON"	Less than 1V
				When engine is running	Battery voltage
			COFF	When turning ignition switch to "OFF"	Less than 1V
2	BR/W	Start signal	(CsT)	When turning ignition switch to "ST"	Battery voltage
			Con	When turning ignition switch to "ON" from "ST"	Less than 1V
			COFF	When turning ignition switch to "OFF"	Less than 1V
3	G	Power source		When turning ignition switch to "ON"	Battery voltage
			(CsT)	When turning ignition switch to "ST"	Battery voltage
			COFF	When turning ignition switch to "OFF"	Less than 1V
4	OR	Power source	(Con)	When turning ignition switch to "ON"	Battery voltage
			COFF	When turning ignition switch to "OFF"	Battery voltage
5	R	Power source	Con	When turning ignition switch to "ON"	Battery voltage
			COFF	When turning ignition switch to "OFF"	Battery voltage

Trouble Diagnoses (Cont'd)

Terminal No.	Wire color	Item		Condition	Voltage (Approximate values)	
6	Р	LH hi beam		When lighting switch is turned to the 2ND position with "HI BEAM" position	Battery voltage	-
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage	_
7	B/OR	RH hi beam		When lighting switch is turned to the 2ND position with "HI BEAM" position	Battery voltage	-
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage	
9	LG	RH hi beam (ground)		When lighting switch is turned to the 2ND position with "HI BEAM" position	Less than 1V	_
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage	_
10	L/Y	LH hi beam (ground)		When lighting switch is turned to the 2ND position with "HI BEAM" position	Less than 1V	-
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage	_
13	R/B	Lighting switch		When turning lighting switch to "HI BEAM"	Battery voltage	-
14	L/W	(Hi beam)		When turning lighting switch to "FLASH TO PASS"	Battery voltage	-
16	В	Ground			_	_
17	Y	Parking brake	P	When parking brake is released	Battery voltage	_
		switch		When parking brake is set	Less than 1.5V	

HA

Bulb Replacement

Refer to "HEADLAMP (FOR USA)" (EL-48).

NFEL0022

EL

Aiming Adjustment

Aiming Adjustment

Refer to "HEADLAMP (FOR USA)" (EL-50).

NFEL0023

System Description

System Description	
The parking, license and tail lamp operation is controlled by the lighting switch which is built into the combi- nation switch and smart entrance control unit. The battery saver system is controlled by the smart entrance control unit.	G]
Power is supplied at all times	MA
 to tail lamp relay terminals 1 and 3 	0/00-4
 through 10A fuse (No. 60, located in the fuse and fusible link box), and 	
• to smart entrance control unit terminal 49	EM
 through 10A fuse [No. 13, located in the fuse block (J/B)]. When ignition quitab is in ON or START position, never is supplied. 	
 When ignition switch is in ON or START position, power is supplied to smart entrance control unit terminal 27 	LC
 through 10A fuse [No. 10, located in the fuse block (J/B)]. 	
When the ignition switch is in the ACC or ON position, power is supplied	EC
 to smart entrance control unit terminal 26 	
 through 10A fuse [No. 1, located in the fuse block (J/B)]. 	FE
Ground is supplied to smart entrance control unit terminals 43 and 64	ГG
through body grounds M9, M25 and M87.	
LIGHTING OPERATION BY LIGHTING SWITCH	CL
When lighting switch is in 1ST (or 2ND) position, ground is supplied	
 to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57 	MT
 through smart entrance control unit terminals 20 and 58, and 	
 through lighting switch and body grounds E11, E22 and E53. 	AT
 to stop and tail lamp unit terminal 6 	1-11
 through body grounds T6 and T8. 	0.57
Tail lamp relay is energized and power is supplied	AX
to stop and tail lamp unit terminal 4	
through tail lamp relay terminal 5 to each root combination lamp terminals 1	SU
 to each rear combination lamp terminals 1 through stop and tail lamp unit terminal 3. 	
When the tail lamp illuminates, ground is supplied	BR
 through body grounds T6 and T8 	200
 to each rear combination lamp terminal 6. 	QT
Tail lamp relay is then energized and the parking, license, side marker and tail lamps illuminate.	ST
LIGHTING OPERATION BY AUTO LIGHT CONTROL SYSTEM	
When lighting switch is in AUTO position, ground is supplied	RS
 to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57 	
 through smart entrance control unit terminals 43 and 64, and 	BT
 to body grounds M9, M25 and M87. 	
Tail lamp relay is then energized and the parking, license, side marker and tail lamps illuminate.	HA
EXTERIOR LAMP BATTERY SAVER CONTROL	0 06-7
While parking, license, side maker and tail lamps are turned ON by "1ST" or "2ND" of lighting switch, the 5 minutes timer is activated when the ignition switch is turned from ON (or START) to OFF (ACC OFF). Continuity between terminals 19 and 20, and between terminals 57 and 58 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.	SC
Then the parking, license, side marker and tail lamps are turned off.	
While the headlamp is turned ON by "AUTO" of lighting switch, the 5 minute timer is activated when the igni- tion switch signal changes from ON (or START) to OFF (ACC OFF), and either one of LH or RH front door switch ON signal is input.	IDX

The auto light delay off timer is activated as the following:

• When the door switch signal changes from ON to OFF while the timer is activated, the timer in operation is discontinued and the 45 second timer is reset.

EL-65

System Description (Cont'd)

- When the door switch signal changes from OFF to ON while the timer is activated, the timer is discontinued and the 45 second timer is reset.
- When the one of four door switch signals changes from OFF to ON while the timer is activated, the timer is discontinued and the 5 minute timer is reset.
- When all the door switch ON signals are input while the timer is activated, the timer is discontinued and the 45 second timer is reset.

Exterior lamp battery saver control mode and auto light delay off timer period can be changed by the function setting of CONSULT-II (EL-46).


When the lighting switch is turned from OFF to 1ST (or 2ND) after the parking, license, side marker and tail lamps are turned off by the battery saver control, ground is supplied.


- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and
- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57.

Then the parking, license, side marker and tail lamps illuminate again.

PARKING, LICENSE AND TAIL LAMPS


Schematic






MEL722P

PARKING, LICENSE AND TAIL LAMPS




PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)



MEL103O

SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

ERMINAL	WIRE COLOR	ITEM		DATA (DC)			
1	LG	DRIVER DOOR SWITCH	OFF (CLOSED) \rightarrow ON	(OPEN)		$12V \rightarrow 0V$	
2	R/L	PASSENGER DOOR SWITCH	OFF (CLOSED) → ON				
3	R/W		OFF (CLOSED) → ON			$5V \rightarrow 0V$	
7	W/R	AUTO LIGHT SENSOR	IGNITION SWITCH	GNITION SWITCH LIGHT IS APPLIED TO AUTO LIGHT SENSOR			
7	•••/11	(SIGNAL)	"ON" POSITION	LIGHT IS NOT AP	PLIED TO AUTO LIGHT SENSO	R LESS THAN 1V	
8	P/B	AUTO LIGHT SENSOR (GND)		-		-	
9	R	AUTO LIGHT SENSOR (POWER)	IGNITION SWITCH (OF	=→ON)		$0V \rightarrow 5V$	
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V	
			(WITH LIGHTING	→ OFF	WITHIN 5 MINUTES	0V	
19	Y/B		SWITCH 1ST OR 2ND)	0V			
			HEADLAMPS ILLUMINA	LESS THAN			
			$(OPERATE \rightarrow NOT OPI$	ERATE)		1V → 12V	
20	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (OF	F OR AUTO $\rightarrow 1S^{-1}$	T OR 2ND POSITION)	$12V \rightarrow 0V$	
23	L/Y	HEADLAMP SWITCH	IGNITION SWITCH "ON" POSITION	LIGHTING SWITC	$H (EXCEPT AUTO \rightarrow$	12V → 0V	
26	PU	IGNITION SWITCH (ACC)	"ACC" POSITION			12V	
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN	I "ON" POSITION		12V	
43	В	GROUND		-		-	
49	R/B	POWER SOURCE (FUSE)		-		12V	
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V	
			(WITH LIGHTING	→ OFF	WITHIN 5 MINUTES	0V	
57	Y/B	Y/B TAIL LAMP RELAY	SWITCH 1ST OR 2ND)	0V			
			HEADLAMPS ILLUMINA		IT CONTROL	LESS THAN	
			(OPERATE \rightarrow NOT OP	/		1V → 12V	
58	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (OF	F OR AUTO \rightarrow 1S	T OR 2ND POSITION)	$12V \rightarrow 0V$	
64	В	GROUND		-		-	

SEL585Y

NOTE:

For CONSULT-II Inspection Procedure, refer to "HEADLAMP (FOR USA)" (EL-45). For CONSULT-II Application Items, refer to "HEADLAMP (FOR USA)" (EL-46).

ST

SU

BR

GI

MA

RS

BT

HA

SC

EL


IDX

PARKING, LICENSE AND TAIL LAMPS

Trouble Diagnoses

Trouble Diagnoses


	Trouble Diag	IIUSES =NFEL0257
Symptom	Possible cause	Repair order
No lamps operate (including head- lamps).	 10A fuse Lighting switch Smart entrance control unit 	 Check 10A fuse [No. 13, lacated in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit. Check lighting switch. Check smart entrance control unit. (EL-350)
No parking, side marker, license and tail lamps operate, but head- lamps do operate.	 10A fuse Tail lamp relay Tail lamp relay circuit Lighting switch Lighting switch circuit Smart entrance control unit 	 Check 10A fuse (No. 60, located in fuse and fusible link box). Verify battery positive voltage is present at terminals 1 and 3 of tail lamp relay. Check tail lamp relay. Check harness between smart entrance control unit terminals 19 and 57 and tail lamp relay terminal 2. Check harness between tail lamp relay terminal 5 and ground. Check lighting switch. Check harness between lighting switch terminal 11 and smart entrance control unit terminals 20 and 58. Check harness between lighting switch terminal 5 and ground. Check smart entrance control unit. (EL-350)
Tail lamp only does not operate.	 Tail lamp relay circuit Rear combination lamp circuit Stop and tail lamp unit 	 Check harness between tail lamp relay terminal 5 and stop and tail lamp unit terminal 4. Check harness between each rear combination lamp terminal 1 and stop and tail lamp unit terminal 3. Check stop and tail lamp unit.
Exterior lamp battery saver control does not operate properly.	 Door switch LH or RH circuit Smart entrance control unit 	 Check the following. a. Harness between smart entrance control unit and LH or RH door switch for open or short circuit b. LH or RH door switch ground circuit c. LH or RH door switch 2. Check smart entrance control unit. (EL-350)



MEL104O

BACK-UP LAMP







System Description	
OUTLINE NFEL0164	A I
Power is supplied at all times	GI
 to headlamp LH relay terminals 1 and 6 	
 through 20A fuse (No. 54, located in the fuse and fusible link box) and 	MA
 to smart entrance control unit terminal 49 	
 through 10A fuse [No. 13, located in the fuse block (J/B)], and 	EM
to front fog lamp relay terminal 3	
 through 15A fuse [No. 6, located in the fuse block (J/B)]. 	
When ignition switch is in ON or START position, power is supplied	LC
to smart entrance control unit terminal 27	
 through 10A fuse [No. 10, located in the fuse block (J/B)]. 	EC
When the ignition switch is in the ACC or ON position, power is supplied	
to smart entrance control unit terminal 26	PC
 through 10A fuse [No. 1, located in the fuse block (J/B)]. 	FE
Ground is supplied to smart entrance control unit terminals 43 and 64. When lighting switch is in 2ND position, ground is supplied	CL
 to headlamp LH relay terminal 2 from smart entrance control unit terminal 21. 	ØĽ
 through smart entrance control unit terminals 22 and 60, and 	
 through lighting switch, and body grounds E11, E22 and E53. 	MT
Headlamp LH relay is then energized.	
FOG LAMP OPERATION	AT
The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position for	
fog lamp operation.	$\Lambda \nabla Z$
With the fog lamp switch in the ON position, ground is supplied	AX
to fog lamp relay terminal 2	
 through the fog lamp switch and body grounds E11, E22 and E53. 	SU
The fog lamp relay is energized and power is supplied	
from fog lamp relay terminal 5	BR
• to terminal 2 of each fog lamp.	BN
Ground is supplied to terminal 1 of each fog lamp through body grounds E11, E22 and E53.	
With power and ground supplied, the fog lamps illuminate.	ST
EXTERIOR LAMP BATTERY SAVER CONTROL	
Fog lamps will remain on for a short while after the ignition switch is turned OFF (ACC OFF) from ON (or	RS
START).	
Continuity between terminals 21 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.	
Then fog lamps are turned to off.	BT
Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II (EL-46).	
When the lighting switch is turned from OFF to 2ND after fog lamps are turned off by the battery saver control,	HA
ground is supplied	
• to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then	<u>a</u> a
 to headlamp LH relay terminal 2 from smart entrance control unit terminal 21 through emert entrance control unit terminals 22 and 20 from lighting quiteb terminal 42 	SC
• through smart entrance control unit terminals 22 and 60 from lighting switch terminal 12.	
Then the fog lamps illuminate again.	EL


IDX

Wiring Diagram — F/FOG —










SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM		CONDITIO	N	DATA (DC)			
1	LG	DRIVER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$		$12V \rightarrow 0V$				
2	R/L	PASSENGER DOOR SWITCH	OFF (CLOSED) \rightarrow ON	(OPEN)		$5V \rightarrow 0V$			
20	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (O	FF OR AUTO→1S	T OR 2ND POSITION)	$12V \rightarrow 0V$			
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V			
21	OR	HEADLAMP LH RELAY	(WITH LIGHTING	→ OFF	WITHIN 5 MINUTES	0V			
21	Un		SWITCH OFF OR 1ST)	ON OR START		0V			
			HEADLAMPS ILLUMIN	ATE BY AUTO LIGI	HT CONTROL	OV			
			LIGHTING SWITCH	EXCEPT PASS C	R 2ND POSITION	12V			
	1/05			PASS OR 2ND P	DSITION	0V			
22	L/OR	HEADLAMP SWITCH	HEADLAMP SWITCH	HEADLAMP SWITCH	HEADLAMP SWITCH	OR HEADLAMP SWITCH HEADLAMPS ILLUMINA	ATE BY AUTO LIGI	HT CONTROL	10V → 12V
			(OPERATE → NOT OPERATE)		100 - 120				
26	PU	IGNITION SWITCH (ACC)	"ACC" POSITION			12V			
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS I	N "ON" POSITION		12V			
43	В	GROUND		-		-			
49	R/B	POWER SOURCE (FUSE)		-		12V			
58	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (O	FF OR AUTO \rightarrow 1	ST OR 2ND POSITION)	$12V \rightarrow 0V$			
			LIGHTING SWITCH	EXCEPT PASS C	R 2ND POSITION	12V			
60	LG/R	HEADLAMP SWITCH		PASS OR 2ND P	OSITION	0V			
50	Lant		HEADLAMPS ILLUMIN	ATE BY AUTO LIGI	HT CONTROL	$10V \rightarrow 12V$			
			(OPERATE \rightarrow NOT OP	ERATE)					
64	В	GROUND		_		-			

SEL586Y

NOTE:

For CONSULT-II Inspection Procedure, refer to "HEADLAMP (FOR USA)" (EL-45). For CONSULT-II Application Items, refer to "HEADLAMP (FOR USA)" (EL-46). Trouble Diagnoses for exterior lamp battery saver control, refer to "HEADLAMP (FOR USA)" (EL-46).



ID):

System Description

System Description

TURN SIGNAL OPERATION

NFEL0030

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 26, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal 2 through body grounds M9, M25 and M87.

LH Turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal 3 to

- front turn signal lamp LH terminal 1
- combination meter terminal 25
- rear combination lamp LH terminal 5.

Ground is supplied to the front turn signal lamp LH terminal 2 through body grounds E11, E22 and E53. Ground is supplied to the rear combination lamp LH terminal 6 through body grounds T6 and T8. Ground is supplied to combination meter terminal 30 through body grounds M9, M25 and M87.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH Turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal 2 to

- front turn signal lamp RH terminal 1
- combination meter terminal 29
- rear combination lamp RH terminal 5.

Ground is supplied to the front turn signal lamp RH terminal 2 through body grounds E11, E22 and E53. Ground is supplied to the rear combination lamp RH terminal 6 through body grounds T6 and T8. Ground is supplied to combination meter terminal 30 through body grounds M9, M25 and M87. With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal 3 through:

NFEL0030S02

With the hazard switch in the ON position, power is supplied

15A fuse [No. 5, located in the fuse block (J/B)].

- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal 2 through body grounds M9, M25 and M87. Power is supplied through terminal 5 of the hazard switch to

- front turn signal lamp LH terminal 1
- combination meter terminal 25
- rear combination lamp LH terminal 5.

Power is supplied through terminal 6 of the hazard switch to


- front turn signal lamp RH terminal 1
- combination meter terminal 29
- rear combination lamp RH terminal 5.

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)	
Ground is supplied to terminal 2 of each front turn signal lamp through body grounds E11, E22 and E53. Ground is supplied to terminal 6 of each rear combination lamp through body grounds T6 and T8. Ground is supplied to combination meter terminal 30 through body grounds M9, M25 and M87. With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.	ĢI
REMOTE KEYLESS ENTRY SYSTEM OPERATION	MA
Power is supplied at all times.	
to smart entrance control unit terminal 49	EM
 through 10A fuse [No. 13, located in the fuse block (J/B)]. 	
Ground is supplied to smart entrance control unit terminal 43 and 64. Refer to "REMOTE KEYLESS ENTRY SYSTEM", EL-277. When smart entrance control unit receives LOCK or UNLOCK siganl from keyfob with all doors closed, power	LC
is supplied	EA
through smart entrance control unit terminal 47	EC
 to front turn signal lamp LH terminal 1 and 	
to combination meter terminal 25 and	FE
to rear combination lamp LH terminal 5, and through amort antrongo control unit terminal 48	
 through smart entrance control unit terminal 48 to front turn signal lamp RH terminal 1 and 	CL
 to combination meter terminal 29 and 	
 to rear combination lamp RH terminal 5 	MT
Ground is supplied to terminal 2 of each front turn signal lamp through body grounds E11, E22 and E53.	
Ground is supplied to terminal 6 of each rear combination lamp through body grounds T6 and T8.	AT
Ground is supplied to combination meter terminal 30 through body grounds M9, M25 and M87. With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning	5 65
lamps.	AX
	ଜା ।
	SU
	BR
	ST
	RS
	BT
	HA
	0 00-0
	@@
	SC
	EL
	IDX

Wiring Diagram - TURN -

Wiring Diagram — TURN — NFEL0032 EL-TURN-01 IGNITION SWITCH ON OR START BATTERY FUSE BLOCK (J/B) REFER TO EL-POWER. Ś Ć 10A 13 15A 5 10A 26 (M17) • 2K LG/B R/W 📥 TO EL-ILL OR/L LG/B R/W ON ON ON HAZARD SWITCH OFF OFF () ILLUMINATION 6 5 <u>∎</u> R/Y G/R G/W G/Y G/B 🛾 R/Y 📥 TO EL-ILL . ∎ G/B ∎ 🗛 NEXT PAGE G/Y ∎₿> G/W BA G/W E81 G/R G/W Ē 3 COMBINATION FLASHER UNIT M21 В L R/B GY/L GY/R 2 SMART ENTRANCE CONTROL UNIT BAT (FUSE) FLASHER LH OUT FLASHER RH OUT G/W B 1 COMBINATION SWITCH (TURN SIGNAL SWITCH) GND1 GND2 (M144), (M145) 64 43 В В (E151) Ν G/B L2 G/Y G/Y -В в В NEXT PAGE E В G/B 🗗 Ť Ĭ. (M87) M25 <u>M</u>9 REFER TO THE FOLLOWING. 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 M15 -SUPER MULTIPLE JUNCTION (SMJ) 12 M21 3 B ¢, 4566 87213W 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 (M145) (M144) (M17) -FUSE BLOCK-HS. GΥ GY L 46 47 48 JUNCTION BOX (J/B) 2 1 3 12 8 7 6 5 9 10 11 42 W



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
43	В	GROUND	_	-
47	GY/L	LH TURN SIGNAL LAMP	WHEN DOOR LOCK OR UNLOCK IS OPERATED USING KEYFOB (ON \rightarrow OFF)	$12V \rightarrow 0V$
48	GY/R	RH TURN SIGNAL LAMP	WHEN DOOR LOCK OR UNLOCK IS OPERATED USING KEYFOB (ON \rightarrow OFF)	$12V \rightarrow 0V$
49	R/B	POWER SOURCE (FUSE)	-	12V
64	В	GROUND	-	_

IDX

EL

SC


SEL392Y

TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

Trouble Diagnoses

	Trouble Diagr	IDSES NFEL0033
Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	 Hazard switch Combination flasher unit Open in combination flasher unit circuit 	 Check hazard switch. Refer to combination flasher unit check. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	 10A fuse Hazard switch Turn signal switch Open in turn signal switch circuit 	 Check 10A fuse [No. 26, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. Check hazard switch. Check turn signal switch. Check the wire between combination flasher unit terminal 3 and turn signal switch terminal 1 for open circuit.
Hazard warning lamps do not oper- ate but turn signal lamps operate.	 1. 15A fuse 2. Hazard switch 3. Open in hazard switch circuit 	 Check 15A fuse [No. 5, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. Check hazard switch. Check the wire between combination flasher unit terminal 3 and hazard switch terminal 4 for open circuit.
Front turn signal lamp LH or RH does not operate.	 Bulb Grounds E11, E22 and E53 Front turn signal lamp circuit 	 Check bulb. Check grounds E11, E22 and E53. Check the wire between combination switch and front turn signal lamp.
Rear turn signal lamp LH or RH does not operate.	 Bulb Grounds T6 and T8 Rear turn signal lamp circuit 	 Check bulb. Check grounds T6 and T8. Check the wire between combination switch and rear turn signal lamp.
LH and RH turn indicators do not operate.	1. Ground	1. Check grounds M9, M25 and M87.
LH or RH turn indicator does not operate.	 Bulb Turn indicator circuit 	 Check bulb in combination meter. Check the wire between hazard switch and combination meter.



Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NFEL0034

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.


System Description

System Description	
The illumination lamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. The battery saver system is controlled by smart entrance control unit. Power is supplied at all times	GI
 to tail lamp relay terminals 1 and 3 	MA
 through 10A fuse (No. 60, located in the fuse and fusible link box), and 	0/00-0
 to smart entrance control unit terminal 49 	
 through 10A fuse [No. 13, located in the fuse block (J/B)]. 	EM
When ignition switch is in ON or START position, power is supplied	
 to smart entrance control unit terminal 27 	LC
 through 10A fuse [No. 10, located in the fuse block (J/B)], and 	
When the ignition switch is in ACC or ON position, power is supplied	RA
 to smart entrance control unit terminal 26 	EC
 through 10A fuse [No. 1, located in the fuse block (J/B)]. 	
Ground is supplied to smart entrance control unit terminals 43 and 64 from body grounds M9, M25 and M87.	FE
LIGHTING OPERATION BY LIGHTING SWITCH	
When lighting switch is 1ST (or 2ND) position, ground is supplied	CL
 to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57 	ØĽ
 through smart entrance control unit terminals 20 and 58, and 	
 through lighting switch and body grounds E11, E22 and E53. 	MT
Tail lamp relay is then energized and illumination lamps illuminate.	
The lighting switch must be in the 1ST or 2ND position for illumination.	AT
The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.	
The ground for all of the components except for door mirror remote control switch, clock and grove box lamp	$\wedge \nabla$
ashtray are controlled through terminals 2 and 3 of the illumination control switch and body grounds M9, M25	AX
and M87.	
EXTERIOR LAMP BATTERY SAVER CONTROL	SU
Illumination lamps will remain on for a short while after the ignition switch is turned OFF (ACC OFF) from ON	
(or START).	BR
Continuity between terminals 19 and 20, and between terminals 57 and 58 of smart entrance control unit will be disturbed after 5 minutes, then the beadlamps will be turned affer	
be disturbed after 5 minutes, then the headlamps will be turned off. Then illumination lamps are turned off.	00
Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II (EL-46).	ST
When the lighting switch is turned from OFF to 1ST (or 2ND) after illumination lamps are turned off by the	
battery saver control, ground is supplied	RS
• to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and	
• to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57.	BT
Then illumination lamps illuminate again.	DI
	HA
	SC
	~ ~


EL

IDX


Schematic




NFEL0036











MEL726P



GI

MA

SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

ERMINAL	WIRE COLOR	ITEM		CONDITI	ON	DATA (DC)
1	LG	DRIVER DOOR SWITCH	OFF (CLOSED) \rightarrow ON	I (OPEN)		$12V \rightarrow 0V$
2	R/L	PASSENGER DOOR SWITCH	OFF (CLOSED) → ON	I (OPEN)		$5V \rightarrow 0V$
3	R/W	REAR DOOR SWITCH	OFF (CLOSED) \rightarrow ON	I (OPEN)		$5V \rightarrow 0V$
7	W/R	AUTO LIGHT SENSOR	IGNITION SWITCH	LIGHT IS APPLIE	D TO AUTO LIGHT SENSOR	1 TO 5V
1	VV/N	(SIGNAL)	"ON" POSITION	LIGHT IS NOT AF	PLIED TO AUTO LIGHT SENSOR	LESS THAN 1V
8	P/B	AUTO LIGHT SENSOR (GND)		-		-
9	R	AUTO LIGHT SENSOR (POWER)	IGNITION SWITCH (OF	FF → ON)		$0V \rightarrow 5V$
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
			(WITH LIGHTING	\rightarrow OFF	WITHIN 5 MINUTES	0V
19	Y/B	TAIL LAMP RELAY (Out put)	SWITCH 1ST OR 2ND)	ON OR START		0V
			HEADLAMPS ILLUMIN		HT CONTROL	$0V \rightarrow 12V$
			(OPERATE → NOT OI	/		•••
20	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (O		,	$12V \rightarrow 0V$
23	L/Y	HEADLAMP SWITCH	IGNITION SWITCH "ON" POSITION	LIGHTING SWITC	CH (EXCEPT AUTO →)	12V → 0V
26	PU	IGNITION SWITCH (ACC)	"ACC" POSITION			12V
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS I	N "ON" POSITION		12V
43	В	GROUND		-		-
49	R/B	POWER SOURCE (FUSE)		-		12V
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
			(WITH LIGHTING	\rightarrow OFF	WITHIN 5 MINUTES	0V
57	Y/B	TAIL LAMP RELAY	SWITCH 1ST OR 2ND)	ON OR START		0V
			HEADLAMPS ILLUMINATE BY AUTO LIGHT CONTROL		LESS THAN	
			(OPERATE \rightarrow NOT OF			1V → 12V
58	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (O	FF OR AUTO $\rightarrow 1$	ST OR 2ND POSITION)	$12V \rightarrow 0V$
64	В	GROUND		_		_

SU SEL587Y

NOTE:

For CONSULT-II Inspection Procedure, refer to "HEADLAMP (FOR USA)" (EL-45). For CONSULT-II Application Items, refer to "HEADLAMP (FOR USA)" (EL-46). Trouble Diagnoses for exterior lamp battery saver control, refer to "HEADLAMP (FOR USA)" (EL-46).

RS

BR

ST

BT

HA

SC

EL

IDX

System Description

System Description

POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to key switch terminals 2 (M/T) or 3 (A/T) and
- to smart entrance control unit terminal 49.

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminals 1 (M/T) or 4 (A/T)
- to smart entrance control unit terminal 25.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied:

- to smart entrance control unit terminal 43 and 64
- through body grounds terminals M9, M25 and M87.

When the front driver side door is opened, ground is supplied:

- through body grounds B12 and B7 (without CD auto changer), or B59 (with CD auto changer)
- to front door switch LH terminal 3
- from front door switch LH terminal 2
- to smart entrance control unit terminal 1.

When the front passenger side door is opened, ground is supplied:

- through body grounds B106 and B127
- to front door switch RH terminal 3
- from front door switch RH terminal 2
- to smart entrance control unit terminal 2.

When any other door (except front door) is opened, ground is supplied to smart entrance control unit terminal 3 in the same manner as the front door switch.

When the front driver side door is unlocked by the door lock and unlock switch, the smart entrance control unit receives a ground signal:

- through body grounds terminals M9, M25 and M87
- to front power window switch terminal 5 (LH) or 7 (RH)
- from front power window switch terminal 8 (LH) or 11 (RH)
- to smart entrance control unit terminal 33.

When the front driver side door is unlocked by the front door key cylinder switch, the smart entrance control unit receives a ground signal:

- through body grounds terminals M9, M25 and M87
- to front door key cylinder switch LH terminal 2
- from front door key cylinder switch LH terminal 1
- to front power window main switch terminal 19
- from front power window main switch terminal 8
- to smart entrance control unit terminal 33.

When a signal, or combination of signals is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal 31
- to interior lamp terminal 2.

With power and ground supplied, the interior lamp illuminates.

SWITCH OPERATION

When interior lamp switch is ON, ground is supplied:

- through case grounds of interior lamp
- to interior lamp.

And power is supplied:

• to interior lamp terminal 1

NFEL0165S02

NFEL0165 NFEL0165S01

• from smart entrance control unit terminal 50.	
When spot lamp (LH and/or RH) is ON, ground is supplied:	
• through body grounds M9, M25 and M87	GI
• to spot lamp terminal 2.	
And power is supplied:	MA
to spot lamp terminal 1	0000 0
from smart entrance control unit terminal 50.	ena
When vanity mirror illumination (LH and/or RH) is ON, ground is supplied:	EM
 through body grounds M9, M25 and M87 	
 to vanity mirror illuminations (LH and RH) terminal 2. 	LC
And power is supplied:	
 to vanity mirror illuminations (LH and RH) terminal 1 	EC
 from smart entrance control unit terminal 50. 	L0
When rear door switch LH and/or RH is ON (door is opened), the smart entrance control unit receives a ground	
signal:	FE
through case ground of the rear door switch	
from the rear door switch terminal 1	CL
to smart entrance control unit terminal 3.	-
 from smart entrance control unit terminal 32 to front stop lamp LH and PH terminal 1 	0/052
to front step lamp LH and RH terminal 1.	MT
 And power is supplied: to front step lamp LH and RH terminal 2 	
 from smart entrance control unit terminal 50. 	AT
When front door switch LH and/or RH is ON (door is opened), ground is supplied:	
 through body grounds B12 and B7 (without CD auto changer), or B57 (with CD auto changer), and/or B106 	AX
and B127	
• to the front door switch terminal 3	011
from the front door switch terminal 2	SU
 to smart entrance control unit terminal 1 and/or 2 	
from smart entrance control unit terminal 32	BR
 to front step lamp LH and RH terminal 1. 	
And power is supplied:	ST
 to front step lamp LH and RH terminal 2 	91
 from smart entrance control unit terminal 50. 	
When trunk room lamp switch is ON (trunk lid is opened), ground is supplied:	RS
 through body grounds T6 and T8 	
to trunk room lamp switch terminal 2	BT
from trunk room lamp switch terminal 1	u س
to trunk room lamp terminal 1	
And power is supplied:	HA
• to trunk room lamp terminal 2	
• through 10A fuse [No. 13, located in the fuse block (J/B)].	SC
With power and ground supplied, interior lamps turn ON.	
INTERIOR LAMP TIMER OPERATION	EL
When interior lamp switch is in the "DOOR" position, the smart entrance control unit keeps the interior lamp	

When interior lamp switch is in the "DOOR" position, the smart entrance control unit keeps the interior lamp illuminated for about 30 seconds when:

- unlock signal is supplied from driver's door unlock sensor while all doors are closed and key is out of ignition key cylinder
- unlock signal is supplied from keyfob or door key cylinder while driver's door is locked and all doors are closed
- key is removed from ignition key cylinder while all doors are closed

EL-93

System Description (Cont'd)

• driver's door is opened and then closed while key is out of the iginition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key removed, the timer is operated.)

The timer is canceled when:

- driver's door is locked,
- driver's door is opened, or
- ignition switch is turned ON.

When driver's door is locked, interior room lamp timer is canceled as described before.

However, ignition key hole illumination remains on for about 30 seconds after driver's door has been locked.

ON-OFF CONTROL

When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position. When any door is opened, step lamps turn ON.

INTERIOR LAMP BATTERY SAVER CONTROL


The lamp turns off automatically when interior lamp, step lamp, spot lamp and/or vanity mirror illumination is illuminated with the ignition key is in OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in ON position for more than 30 minutes.

After lamps turn OFF by the battery saver system, the lamps illuminate again when:

- driver's door is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder.

Interior lamp battery saver control period can be changed by the function setting of CONSULT-II (EL-102).


Schematic




MEL1150


Wiring Diagram - INT/L -

Wiring Diagram — INT/L —





EL-97



MEL7510

12 M174 W

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 W

鸧

H.S.

(M144)

GY

0 21 W , 036 W

 1
 2
 3
 4
 5
 6
 7
 8
 9

 10
 11
 12
 13
 14
 15
 16
 17
 18

 19
 20
 21
 22
 23
 24

1 B10 , B107 W W (M143)


W

1 2 3 4 5 6 7 8 9 10 11 12 W

 25
 26
 27
 28
 29
 30
 31
 32
 33


 34
 35
 36
 37
 38
 39
 40
 41
 42

 43
 444
 45
 46
 47
 48



Wiring Diagram — INT/L — (Cont'd)

SMART ENTRANCE CONTROL UNIT CONNECTOR




SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	LG	DRIVER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$12V \rightarrow 0V$
2	R/L	PASSENGER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$
3	R/W	REAR DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$
25	B/R	IGNITION KEY SWITCH (INSERT)	KEY INSERTED \rightarrow KEY REMOVED FROM IGN KEY CYLINDER	12V→0V
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN "ON" POSITION	12V
30	B/Y		WHEN DOORS ARE UNLOCKED USING KEYFOB (OFF \rightarrow UNLOCK)	12V → 0V
31	R		WHEN DOORS ARE LOCKED USING KEYFOB (UNLOCK \rightarrow LOCK WITH LAMP SWITCH IN "DOOR" POSITION)	12V
32	R/W	FRONT STEP LAMP	ANY DOOR SWITCH ON (OPEN) → OFF (CLOSED)	0V →12V
33		COMMUNICATION	DOOR LOCK & UNLOCK SWITCHES (NEUTRAL → LOCK/UNLOCK)	*1
33	L	INTERFACE	FRONT DOOR KEY CYLINDER SWITCH LH (NEUTRAL \rightarrow LOCK/UNLOCK)	
43	В	GROUND	_	_
49	R/B	POWER SOURCE (FUSE)	_	12V
50	B/G	BATTERY SAVER (INTERIOR LAMP)	BATTERY SAVER DOSE OPERATE \rightarrow DOES NOT OPERATE (ON \rightarrow OFF)	$12V \rightarrow 0V$
64	В	GROUND	_	

*1: REFER TO "SMART ENTRANCE CONTROL UNIT INSPECTION TABLE" IN "SMART ENTRANCE CONTROL UNIT".

CONSULT-II Inspection Procedure



CONSULT-II Application Items

CONSULT-II Application Items

"INT LAMP" Data Monitor

Data Monitor		NFEL0259S0101
Monitored Item	Description	
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.	
DOOR SW-RR	Indicates [ON/OFF] condition of ignition switch.	
KEY ON SW	Indicates [ON/OFF] condition of key switch.	
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.	
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.	
LOCK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.	
UNLK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.	
KEY CYL LK-SW	Indicates [ON/OFF] condition of front door key cylinder switch.	
KEY CYL UN-SW	Indicates [ON/OFF] condition of front door key cylinder switch.	
LK BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.	
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.	

Active Test

	NFEL0259S0102
Test Item	Description
INT LAMP	 This test enables to check interior lamp operation. When "ON" on CONSULT-II screen is touched: Interior lamp turns on when the switch is at DOOR. (Smart entrance control unit supplies power and ground to interior lamp.)
IGN ILLUM	This test enables to check ignition key hole illumination operation. The illumination turns on when "ON" on CONSULT-II screen is touched.
STEP LAMP	This test enables to check step lamp operation. The illumination turns on when "ON" on CONSULT-II screen is touched.

Work Support

Work Item	Description
ROOM LAMP TIMER SET	Interior lamp timer mode can be changed by mode setting. Selects ON-OFF of the room lamp illumination at the time the driver door is unlocked.

"BATTERY SAVER" Data Monitor

NFEL0259S02

NFEL0259S0103

NFEL0259

NFEL0259S01

	NFEL0259S0201
Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-RR	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
KEY CYL LK-SW	Indicates [ON/OFF] condition of front door key cylinder switch.

CONSULT-II Application Items (Cont'd)

Monitored Item	Description	
KEY CYL UN-SW	Indicates [ON/OFF] condition of front door key cylinder switch.	GI
LK BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.	
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.	MA

Active Test

This test enables to check interior lamp, front step lamps, spot lamp and vanity mirror illumina- tions operations.	
 Interior lamp turns on when the switch is in ON. (Smart entrance control unit supplies power to interior lamp.) 	
 (Smart entrance control unit supplies power to front step lamps.) Spot lamp, vanity mirror illuminations turn on when the switch is in ON. (Smart entrance control unit supplies power to Spot lamp, vanity mirror illuminations.) 	
	 tions operations. When touching "ON" on CONSULT-II screen. Interior lamp turns on when the switch is in ON. (Smart entrance control unit supplies power to interior lamp.) Front step lamps turn on when any doors are open. (Smart entrance control unit supplies power to front step lamps.) Spot lamp, vanity mirror illuminations turn on when the switch is in ON.

Work Support

Work Item	Description	0,052
ROOM LAMP BAT SAV SET	Interior lamp battery saver control period can be changed by mode setting. Selects interior lamp battery saver control period between two modes.	MT
	MODE 1 (30 minutes)/MODE 2 (60 minutes)	AT

AX

SU

BR

ST

NFEL0259S0203

RS

BT

HA

SC

EL


IDX

Trouble Diagnoses for Interior Lamp Timer

Trouble Diagnoses for Interior Lamp Timer DIAGNOSTIC PROCEDURE 1

=NFEL0215






Trouble Diagnoses for Interior Lamp Timer (Cont'd)

2 CHECK FRONT LH DOOR SWITCH INPUT SIGNAL	
With CONSULT-II Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.	GI
DATA MONITOR MONITOR	MA
DOOR SW-DR OFF OPEN:	EM
DOOR SW-DR ON When driver's door is	
closed: DOOR SW-DR OFF	LC
SEL319WA	EC
Without CONSULT-II Check voltage between smart entrance control unit harness connector M143 terminal 1 (LG) and ground.	FE
Smart entrance control unit connector	GL
Voltage [V]:	
Approx. 5 Condition of driver's door: OPENED	MT
	AT
SEL004Y	AX
OK or NG	4
OK ▶ GO TO 4.	SU
NG DO TO 3.	
3 CHECK FRONT LH DOOR SWITCH	BR
Check continuity between door switch connector B29 terminals 2 and 3.	ST
	01
Front door switch LH	RS
Door switch is pushed.	BT
Door switch is released.	
Yes Yes	HA
SEL325WB OK or NG	SC
OK of NG OK Check the following.	┤
 Front LH door switch ground circuit and condition 	EL
 Harness for open or short between smart entrance control unit and front LH door switch 	
NG Replace front LH door switch.	- IDX

Trouble Diagnoses for Interior Lamp Timer (Cont'd)



5	CHECK FRONT RH DC	OR SWITCH
Check	k continuity between door s	witch connector B129 terminals 2 and 3.
	Front door switch RH	Continuity: Door switch is pushed. No Door switch is released. Yes
		SEL325WC
		OK or NG
ОК		 Check the following. Front RH door switch ground circuit and condition Harness for open or short between smart entrance control unit and front RH door switch
NG	►	Replace front RH door switch.

Trouble Diagnoses for Interior Lamp Timer (Cont'd)


6 CHECK REAR LH AND	RH DOOR SWITCHES	INPUT SIGNAL	
With CONSULT-II Check door switches ("DOOR S)	V-RR") in "DATA MONITOI	R" mode with CONSULT-II.	G]
	DATA MONITOR MONITOR DOOR SW-RR OFF	When rear door LH and/or RH is open:	MA
		DOOR SW-RR ON	EM
		When driver's door is closed: DOOR SW-RR OFF	LC
			EC
Without CONSULT-II Check voltage between smart er	trance control unit harness	s connector M143 terminals 3 (R/W) and ground.	FE
-	entrance control		
unit cor	H.S.	Voltage [V]:	CL
		Condition of rear LH and/or RH door: CLOSED Approx. 5 Condition of rear LH and/or RH door: OPENED	MT
		0	AT
	OK	SEL155Y K or NG	AX
ОК	GO TO 8.		SU
NG	GO TO 7.		
7 CHECK REAR LH AND	RH DOOR SWITCHES		BR
 Disconnect door switch harne Check continuity between door 		ound.	ST
Rear door switch connector			RS
		Continuity: Door switch is pushed.	DT
	T.S.	No	BT
		Door switch is released. Yes	HA
		SEL156Y	SC
	04	SEL156Y K or NG	
ОК	Check the following. ● Rear LH and/or RH door		SC IL

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

NG

►


Replace key switch.



Trouble Diagnoses for Interior Lamp Timer (Cont'd)

10 CHECK DOOR L	-OCK/L	JNLOCK	SWITCH INPUT SIGNAL	
With CONSULT-II Check door lock/unlock s	witch ("	LOCK SW	/ DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.	G]
	data mon	ITOR		MA
	NITOR			
	W DR/AS W DR/AS	OFF OFF	When lock/unlock switch is turned to LOCK: LOCK SW DR/AS ON	EM
			When lock/unlock switch is turned to UNLOCK: UNLK SW DR/AS ON	LC
			SEL	341W
	ition swi /een sm	art entran	ce control unit harness connector M144 terminal 33 (L) and ground with osc	illo-
	ich are	shown in	urned "LOCK" or "UNLOCK". he figure below can be detected during 10 sec. just after door lock/unlock	GL
(V) 15				MT
10 5 0			Voltage: 12V → 9V (10 sec.) measurement by analog circuit tester.	AT
				AX
2 s				_396Y
01/			OK or NG	BR
OK		GO TO 1		
NG	▶	GrounHarne	the following. d circuit for each front power window switch ss for open or short between each front power window switch and smart	ST
			ce control unit connector e systems are normal, replace the front power window switch.	RS
				BT
				HA
				SC
				EL

Trouble Diagnoses for Interior Lamp Timer (Cont'd)



Trouble Diagnoses for Interior Lamp Timer (Cont'd)

12	CHECK DOOR KEY C	YLINDER SWITCH	1				
	connect door key cylinde eck continuity between d						GI
		r key cylinder ch connector	🧕 : Ground				M/
	治 T.S.	321)	(3) : Door loo	ck switch terminal Key position	Continuity		EN
			3 - 2	Neutral/Unlock	No		
	E Ę)			Lock Neutral/Lock	Yes No		LC
			1 - 2	Unlock	Yes		
						SEL187Y	E(
		1	OK or NG				FE
OK			ler switch ground circu				
		inder switch	en or short between frons are normal, replace				CL
NG	►	Replace door key	cylinder switch.				M
							•
							AT
							AD

HA

SU

BR

ST

RS

BT


SC

EL

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

DIAGNOSTIC PROCEDURE 2


SYMPTOM: Interior lamp timer does not cancel properly.




Trouble Diagnoses for Interior Lamp Timer (Cont'd)

2 CHECK FRONT LH DOOR SWITCH INPUT SIGNAL	
With CONSULT-II Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.	GI
DATA MONITOR MONITOR	MA
DOOR SW-DR OFF OPEN:	EM
DOOR SW-DR ON When driver's door is	
closed: DOOR SW-DR OFF	LC
SEL319	WA
Without CONSULT-II Check voltage between smart entrance control unit harness connector M143 terminal 1 (LG) and ground.	FE
Smart entrance control unit connector	GL
Voltage [V]: Condition of driver's door: CLOSED Approx. 5 Condition of driver's door: OPEN	MT
	AT
SEL004	iya AX
OK or NG OK	
OK GO TO 4. NG GO TO 3.	SU
	BR
3 CHECK FRONT LH DOOR SWITCH	
Check continuity between door switch connector B29 terminals 2 and 3.	ST
Front door switch LH	RS
2 3 0	BT
I I I I I I I I I I I I I I I I I I I	HA
SEL325 OK or NG	wb SC
OK Check the following.	
 Front LH door switch ground circuit and condition Harness for open or short between smart entrance control unit and front LH door switch 	EL
NG Replace front LH door switch.	IDX

Trouble Diagnoses for Interior Lamp Timer (Cont'd)



Trouble Diagnoses for Interior Lamp Timer (Cont'd)



18

HA


BT

SC

EL

IDX


Trouble Diagnoses for Interior Lamp Timer (Cont'd)



NFEL0042

AT

Component Parts and Harness Connector Location




System Description

UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit built-in combination meter.
- Digital meter is adopted for odo/trip meter.*
 *The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER



NOTE:

Turn ignition switch to the "ON" position to operate odo/trip meter.

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to combination meter terminal 23.

With the ignition switch in the ACC or ON position, power is supplied.

- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to combination meter terminal 31.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 30, located in the fuse block (J/B)]
- to combination meter terminal 24.

Ground is supplied

- to combination meter terminal 22
- through body grounds M9, M25 and M87.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is received engine coolant temperature signal from ECM. ECM is detected by water temperature sensor. The water temperature gauge is received by a signal

• from ECM terminal 18

• to combination meter terminal 18

The needle on the gauge moves from "C" to "H"

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

- The tachometer is regulated by a signal
- from terminal 34 of the ECM
- to combination meter terminal 16 for the tachometer.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank. The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 17 for the fuel gauge
- from terminal 2 of the fuel level sensor unit
- through terminal 5 of the fuel level sensor unit and
- through body ground B13.

SPEEDOMETER

The combination meter provides a voltage signal to the vehicle speed sensor for the speedometer. The voltage is supplied

- from combination meter terminal 15 for the speedometer
- to terminal 22 of ABS/TCS control unit (with TCS).
- to terminal 18 (A/T) or 19 (M/T) of ABS actuator and electric unit (without TCS).

The speedometer converts the voltage into the vehicle speed displayed.


NFEL0042S08

NFEL0042S02

NFEL0042S03

NFEL0042S04

Combination Meter



MEL080O


NFEL0254

MEL081O



Schematic -w -0 68 (A): With A/T -w (TS): With TCS -∕₩^-(TS)-∞ 54 TS-₩ 서 ┫ -w^ -ww TS) Ŵ --0 10 ∕₩^--í-K TS ABS Ŵ -w ٠٨٨ TS) TS - 49 WASHER w w -~~~ -0 67 STOP/TAIL —° 3 w -~ 2 W BRAKE ✐ SEAT BELT -~~~ -~ 5 60 ----- 63 62 0----- 58 BOARD --- 59 COMPUTER FUEL M SPEEDOMETER -0 32 -0 16 UNIFIED METER TACHOMETER CONTROL UNIT **-**∼ 15 (WITH ODO/TRIP WATER TEMP. **-**∽ 13 GAUGE METER) -0 31 FUEL GAUGE (λ) -0 17 23 -24 0 --- 22 Ŵ AIR BAG - -w ₩ - - -∣∢ **-**○ 28 A/T CHECK (A) → 52 CRUISE -~~~ ---- 46 47 아 DOOR Đ ┣ -~~~ _____ 7 SET 50 ~ TURN RH (1.4W) 29 0 ത TURN LH (1.4W) 25 - $^{\odot}$ [∢] HIGH BEAM (1.4W) 1 **-**∼ 27 26 -METER ILLUMINATION (X4 BULBS) (3W) 1 64 -[∢] Ē 34 0-A -~~~ ┢ R 35 - \bigcirc ┢ A/T Ν 36 --> INDICATOR D 37 -۲ 3 38 --> 2 39 -► \bigcirc <u>1</u> → 56 o-✐

EL-120



EL-121

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode


Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode DIAGNOSIS FUNCTION

NFEL0151

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE

- 1. Turn ignition switch to ON and change odo/trip meter to "TRIP".
- 2. Turn ignition switch to OFF.
- 3. Turn ignition switch to ON when pushing odo/trip meter switch.
- 4. Release odo/trip meter switch 1 second after ignition switch is turned ON.
- 5. Push odo/trip meter switch more than three times within 7 seconds.



6. All odo/trip meter segments should be turned on.

NOTE:


If some segments are not turned on, unified meter control unit assembly should be replaced.

At this point, the unified control meter is turned to diagnosis mode.


7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE:

It takes about a few seconds for indication of fuel gauge and water temperature gauge to become stable.




Trouble Diagnoses





SYMPTOM CHART

	STIVIF I OIVI CHA	NFEL0046S10
Symptom	Possible causes	Repair order
One of speedometer/ tachometer/fuel gauge/ water temp. gauge is mal- functioning.	 Sensor signal Vehicle speed signal Engine revolution signal Fuel gauge Water temp. gauge Unified meter control unit 	 Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-125.) INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-126.) INSPECTION/FUEL LEVEL SENSOR UNIT (Refer to EL-127.)
Multiple meter/gauge are malfunctioning. (except odo/trip meter)	Unified meter control unit	 INSPECTION/THERMAL TRANSMITTER (Refer to EL-128.) Replace unified meter control unit assembly.

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-123.







POWER SUPPLY AND GROUND CIRCUIT CHECK **Power Supply Circuit Check**

NFEL0046S0701

				NI EL004030701
Term	ninals	lgn	ition switch posit	ion
(+)	(-)	OFF	ACC	ON
23	Ground	Battery voltage	Battery voltage	Battery voltage
24	Ground	0V	0V	Battery voltage
31	Ground	0V	Battery voltage	Battery voltage

If NG, check the following.

- 10A fuse [No. 12, located in fuse block (J/B)] •
- 10A fuse [No. 30, located in fuse block (J/B)] •
- 10A fuse [No. 1, located in fuse block (J/B)] •
- Harness for open or short between fuse and combination • meter

Ground Circuit Check

Bround Circuit Check	NFEL0046S0702
Terminals	Continuity
22 - Ground	Yes

Trouble Diagnoses (Cont'd)

INSPECTION/VEHICLE SPEED SENSOR


		=NFEL0046S03
1 CHECK ABS CONTRO	DL UNIT OUTPUT SIGNAL	
 With CONSULT-II Lift up drive wheels. 		
2. Start engine and drive vehic	le at more than 20 km/h (12 MPH).	
	ination meter terminal 15 and ground when rotating wheels with eng in "SUB MODE" with CONSULT-II.)	jine at idle. (Use
	Triggering Menu Stop Triggering	
	Set Auto Trigger	
	>> 10.0 V/Div 50 mS/Div T	
		SEL938W
Without CONSULT-II		
I. Lift up drive wheels.		
	le at more than 20 km/h (12 MPH). bination meter terminal 15 and ground when rotating wheels with er	ngine at idle.
combination	meter harness connector Voltage: Approx.	0 - 5V
		051 00014
	OK or NG	SEL939W
OK 🕨	ABS/TCS control unit or ABS actuator and electric unit is OK.	
NG	Check the following.	
	Harness for open or short between ABS/TCS control unit or AB	S actuator and electric
	 unit and combination meter. ABS/TCS control unit or ABS actuator and electric unit. Refer to 	o BR-110 (with TCS),
	BR-61 (without TCS), "Wheel Sensor or Rotor".	

HA

SC

EL


INSPECTION/ENGINE REVOLUTION SIGNAL




INSPECTION/FUEL LEVEL SENSOR UNIT =NFEL0046S08 1 CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT GI Check harness continuity between fuel level sensor unit and fuel pump connector terminal 5 and ground. MA Fuel level sensor unit and fuel pump connector (B19) Continuity should exist. LC EC SEL182W OK or NG FE OK GO TO 2. ► NG Repair harness or connector. CL CHECK FUEL LEVEL SENSOR UNIT 2 MT Refer to "FUEL LEVEL SENSOR UNIT CHECK" (EL-129). OK or NG AT OK GO TO 3. ► NG Replace fuel level sensor unit. AX 3 CHECK HARNESS FOR OPEN OR SHORT 1. Disconnect combination meter connector and fuel level sensor unit and fuel pump connector. SU 2. Check continuity between combination meter terminal 17 and fuel level sensor unit and fuel pump connector terminal 2. Continuity should exist. 3. Check continuity between combination meter terminal 17 and ground. Continuity should not exist. ST Fuel level sensor unit and Combination meter fuel pump connector (B19) connector M33 G G BT Ω HA SEL183W OK or NG SC OK Fuel level sensor unit is OK. Þ NG Repair harness or connector. ► EL

1DX

INSPECTION/THERMAL TRANSMITTER



3 CHECK W	TER TEMPERATURE OUTPUT SIGNAL	
 Connect combine Start engine. 	tion meter connector and ECM connector.	GI
3. Check output si	nal between combination meter harness connector M33 terminal 18 (PU/W) and ground. (Use OSCOPE" in "SUB MODE" with CONSULT-II.	MA
	Triggering Menu Start Triggering	
	Set Auto Trigger	EM
		LC
		EC
	>> [A] 5.0 V/Div 50 ms/Div SEL414Y	FE
	OK or NG	
OK	Replace combination meter.	CL
NG	Check ECM.	00
		MT



Electrical Components Inspection FUEL

	NFEL0047	AT	
FUEL LEVEL SENSOR UNIT CHECK			000
• For removal, refer to FE-6.			
Check the resistance between terminals 2 and 5.			AX
Ohmmeter		Resistance	

Ohm	Ohmmeter		Float position	mm (in)	Resistance	
(+)	(–)		Float position	value Ω	SU	
		*1	Full	158 (6.22)	Approx. 4.5 - 5.5	
2	5	*2	1/2	89.7 (3.531)	31.5 - 33.5	BR
		*3	Empty	22.1 (0.870)	80.0 - 80.3	~_
*1 and *3: When float rod is in contact with stopper					ST	

*1 and *3: When float rod is in contact with stopper.

RS

BT

HA

SC

EL

IDX

System Description

FUNCTION

This board computer can indicate following items.

- Outside air temperature
- Range (Cruising possible distance)
- Journey time (hour meter)
- Average fuel consumption
- Average vehicle speed

Outside air temperature indication

- This indicator shows indication of outside air temperature while ignition switch is in ON position.
- Ambient sensor is used commonly by auto air conditioner and this board computer. When auto air conditioner operates, board computer will correct ambient sensor signal based on positive voltage signal to terminal 60 of board computer from A/C auto amp.
- Indication range is between -30 and +55°C (-22 and 131°F). (When outside temperature is less than -30°C (-22°F) or more than +55°C (131°F), display shows "- - -".)
- When outside temperature is less than 3°C (37°F) continuously, display will blink as a warning. In this case, the display will change to the OUTSIDE AIR TEMPERATURE mode even though the display is showing a different item. (See NOTE.)
- The indicated temperature is not affected by engine heat. It changes only when one of the following condition exists.
- a) When vehicle speed is more than 20 km/h (12 MPH).
- b) The ignition key has been turned to OFF position for more than 3.5 hours.
- c) When outside temperature is lower than indicated temperature.

Range (Cruising possible distance) indication

- The range indication provides driver with an estimation of the distance that can be driven before refueling. The range is conducted by fuel tank gauge unit (fuel remaining), ECM pulse signal (fuel consumption) and vehicle speed signal.
- Indication will be refreshed every 30 seconds.
- When fuel remaining is less than approx. 10.8 ℓ (11-3/8 US qt, 9-1/2 Imp qt), indication will blink as a warning. If the fuel remaining less than approx. 10.5 ℓ (11-1/8 US qt, 9-1/4 Imp qt), indication will show "----". In this case, the display will change to the RANGE mode automatically even though the display is showing a different item. (See NOTE.)

Average fuel consumption

- Average fuel consumption indication is conducted by ECM pulse signal and vehicle speed signal after system is reset.
- Indication will be refreshed every 30 seconds.
- After reset operation, the display shows "...." until the vehicle is driven 500 m (1,600 ft) and 30 seconds has passed.

Average vehicle speed

- Average vehicle speed indication is conducted by running distance and running time.
- Indication will be refreshed every 30 seconds.
- After reset operation, the displays shows "...." for 30 seconds.

Journey time

• Journey time indication is conducted by integration of ignition ON time.

HOW TO CHANGE/RESET INDICATION

- Indication can be changed by in following order by pushing board computer steering switch "TRIP".
 OUTSIDE AIR TEMPERATURE → RANGE → AVERAGE FUEL CONSUMPTION → AVERAGE VEHICLE SPEED → JOURNEY TIME
- Continuous pushing the switch (more than 0.8 second) can reset the indication of journey time (hour meter), average vehicle speed and average fuel consumption.


NOTE:

• After the display changes automatically, the indication can be changed to the last mode by pushing the board computer steering switch. In this case, the cursor ("▲") will blink as a warning.


NFEL0283 NFEL0283S01

When the OUTSIDE AIR TEMPERATURE warning and the RANGE warning match warning condi-tions at the same time, the display automatically indicates the OUTSIDE AIR TEMPERATURE. • GI MA EM LC EC FE CL MT AT AX SU BR ST RS BT HA SC EL IDX

Wiring Diagram — B/COMP —



BOARD COMPUTER



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.

IDX

BOARD COMPUTER

Trouble Diagnoses

SEGMENT CHECK

Board computer display segment can be checked by the procedure shown below.

- 1. Turn ignition switch to ON position with pushing board computer steering switch "TRIP". Then segment check will start.
- 2. Segment check will end after 1 cycle of segment check is performed or any of following conditions exists.
- Ignition switch is returned to ACC or OFF position.
- Vehicle speed signal is input.


PRELIMINARY CHECK

NFEL0285S02

NFEL0285S03

=NFEL0285

NFEL0285S01



DIAGNOSES PROCEDURE


		11 22020000
Symptom	Possible cause	Repair order
Outside air temperature is not displayed properly. (It may take a short time to steady the indication after ignition switch is turned to ON.)	 Ambient sensor Ambient sensor circuit A/C on signal (For models with auto A/C) Vehicle speed sensor signal 	 Check ambient sensor. Refer to "Electrical Components Inspection", EL-135. Check harness for open or short between ambient sensor and board computer. Verify more than 4V is present at terminal 60 of board computer when A/C is operated. Make sure journey distance (trip) is displayed properly. If NG, check journey distance (trip) display.
Range (Cruising possible distance) is not displayed properly.	 Average fuel consumption display Fuel tank gauge signal circuit 	 Make sure fuel consumption is displayed properly. If NG, check fuel consumption display. Make sure fuel gauge operates properly. If NG, check fuel gauge. Refer to EL-127.

EL-134

BOARD COMPUTER

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	-
Journey time (hour meter) is not indicated properly.	1. 10A fuse	 10A fuse [No. 12, located in the fuse block (J/B)]. Verify battery voltage is present at terminal 23 of combination meter. 	GI
Average fuel consumption is not displayed properly.	Fuel consumption signal	Check harness for open or short between ECM termi- nals (20, 34) and combination meter terminals (62, 16).	MA
Average vehicle speed is not indicated properly.	Journey time (hour meter) display	Make sure journey time is displayed properly. If NG, check journey time display.	EM



Electrical Components Inspection AMBIENT SENSOR

The ambient sensor is attached to the radiator core support. It detects ambient temperature and converts it into a resistance value which is then input to A/C auto amp. and board computer. After disconnecting ambient sensor harness connector, measure resistance between terminals 1 and 2, using the table below.

resistance between terminals 1 and 2, using the table below.				
Temperature °C (°F)				
-15 (5)				
-10 (14)				
-5 (23)				
0 (32)				
5 (41)				
10 (50)				
15 (59)				
20 (68)				
25 (77)				
30 (86)				
35 (95)				
40 (104)				
45 (113)				

BT

LC

EC

FE

NFEL0286


HA

SC

EL


IDX


Schematic




NFEL0049

Wiring Diagram — WARN —







MEL744P









Continuity

Ω

Ohmmeter

Ð Ю

exist

Diode

		Electrical Components Inspection		
	EI	ectrical Components Inspection		
	FUEL WARNING LAMP OPERATION CHECK			
	1.	Turn ignition switch "OFF".		
	2.	Disconnect fuel level sensor unit and fuel pump harness con- nector B19.		
	3.	Connect a resistor (80Ω) between fuel level sensor unit and fuel pump harness connector terminals 2 and 5.		
	4.	Turn ignition switch "ON".		
	The fuel warning lamp should come on.			
5W	NOTE:			
	ECM might store the 1st trip DTC P0180 and the 1st trip DTC P0464 during this inspection.			
	If the DTC is stored in ECM memory, erase the DTC after recon necting fuel level sensor unit and fuel pump harness connector.			

٥r. Refer to EC-91, "HOW TO ERASE EMISSION-RELATED DIAG-NOSTIC INFORMATION". FE

CL

GI


MA

LC

EC

- MT

NEEL 0051502



MEL425F

SEL901F

No continuity

Ω

Э \oplus

			AT
	Oil pressure kPa (kg/cm ² , psi)	Continuity	
Engine running	More than 10 - 20 (0.1 - 0.2, 1 - 3)	No	AX
Engine not running	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	Yes	SU

Check the continuity between the terminals of oil pressure switch BR and body ground.

DIODE CHECK

Check continuity using an ohmmeter. •

NFEL0051S03

- Diode is functioning properly if test results are as shown in the • figure at left.
- Check diodes at the combination meter harness connector instead of on the combination meter assembly. Refer to BT EL-137, "WARNING LAMP" wiring diagrams.

NOTE:


Specification may vary depending on the type of tester. Before HA performing this inspection, be sure to refer to the instruction manual for the tester to be used.

SC




EL-141






A/T INDICATOR

EL-AT/IND-02



WARNING CHIME

Component Parts and Harness Connector Location



System Description

NFEL0053

The warning chime is controlled by the smart entrance control unit. The warning chime is located in the smart entrance control unit. Power is supplied at all times

- through 10A fuse [No. 13, located in fuse block (J/B)]
- to smart entrance control unit terminal 49 and
- to key switch terminal 2 (M/T) or 3 (A/T)
- through 10A fuse (No. 60, located in the fuse and fusible link box)
- to tail lamp relay terminals 1 and 3.
- With the ignition switch in the ON or START position, power is supplied
- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied to smart entrance control unit terminals 43 and 64 through body grounds M9, M25 and M87.

When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

IGNITION KEY WARNING CHIME

With the key in the ignition switch in the OFF position, and the driver's door open, the warning chime will sound. Power is supplied

- from key switch terminal 1 (M/T) or 4 (A/T)
- to smart entrance control unit terminal 25.

Ground is supplied

- from front door switch LH (driver side) terminal 2
- to smart entrance control unit terminal 1.


Front door switch LH (driver side) terminal 3 is grounded through body grounds B7 (without CD auto changer) or B59 (with CD auto changer) and B12.

LIGHT WARNING CHIME


With ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. Power is supplied.

- from tail lamp relay terminal 2
- to smart entrance control unit terminals 19 and 57.


Ground is supplied	
• from front door switch LH (driver side) terminal 2	G]
• to smart entrance control unit terminal 1.	
Front door switch LH (driver side) terminal 3 is grounded through body grounds B7 (without CD auto chao or B59 (with CD auto changer) and B12.	anger) MA
SEAT BELT WARNING CHIME	FEL0053S03
With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sour approximately 6 seconds.	ind for EM
Ground is supplied	
from seat belt switch terminal 1	LC
• to smart entrance control unit terminal 28.	
Seat belt switch terminal 2 is grounded through body grounds B7 (without CD auto changer) or B59 (w auto changer) and B12.	EC
	FE
	CL
	NASS
	MT
	AT
	<i>[</i> A] I
	AX
	SU
	00
	BR
	ST
	RS
	BT
	HA
	SC
	EL
	IDX



Wiring Diagram — CHIME — (Cont'd)



SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION			DATA (DC)
1	LG	DRIVER DOOR SWITCH	DFF (CLOSED) \rightarrow ON (OPEN)			$12V \rightarrow 0V$
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
			(WITH LIGHTING	$\rightarrow OFF$	WITHIN 5 MINUTES	0V
19	Y/B	TAIL LAMP RELAY	SWITCH 1ST OR 2ND)	ON OR START		0V
			HEADLAMPS ILLUMINA	TE BY AUTO LIGH	T CONTROL	LESS THAN
			(OPERATE → NOT OPE	RATE)		1V → 12V
20	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (OF	F OR AUTO $\rightarrow 1S^{-}$	FOR 2ND POSITION)	$12V \rightarrow 0V$
25	B/R	IGNITION KEY SWITCH		$12V \rightarrow 0V$		
23	B/IT	(INSERT)	KEY INSERTED \rightarrow KEY REMOVED FROM IGN KEY CYLINDER			120-00
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN	GNITION SWITCH IS IN "ON" POSITION		
28	OR	SEAT BELT BUCKLE SWITCH	UNFASTENED \rightarrow FAST	INFASTENED \rightarrow FASTENED (IGNITION SWITCH IS IN "ON" POSITION)		
43	В	GROUND		_		
49	R/B	POWER SOURCE (FUSE)		-	_	12V
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
			(WITH LIGHTING	→ OFF	WITHIN 5 MINUTES	0V
57	Y/B TAIL	TAIL LAMP RELAY	SWITCH 1ST OR 2ND) ON OR START			0V
			HEADLAMPS ILLUMINATE BY AUTO LIGHT CONTROL			LESS THAN
			$(OPERATE \rightarrow NOT OPERATE)$			1V → 12V
58	SB	TAIL LAMP SWITCH	LIGHTING SWITCH (OFF OR AUTO → 1ST OR 2ND POSITION)			$12V \rightarrow 0V$
64	В	GROUND				-

Data link connector Steering column Steering column Data link connector Steering column Steering column	.0216 G[
	(())
NEELO?	
 Turn ignition switch "OFF". Connect "CONSULT-II" and "CONSULT-II CONVERTER" the data link connector. 	
SEF289X	LC
3. Turn ignition switch "ON". 4. Touch "START (NISSAN BASED VHCL)".	EG
ENGINE	FE
START (NISSAN BASED VHCL) START (RENAULT BASED VHCL) SUB MODE	CL
SKIA3098E 5. Touch "SMART ENTRANCE".	MT
SELECT SYSTEM ENGINE	AT
ABS SMART ENTRANCE	AX
AIR BAG	SU
SEL398Y	BR
6. Touch "KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BE ALM".	LT _{ST}
REAR DEFOGGER KEY WARN ALM	RS
LIGHT WARN ALM SEAT BELT ALM	BT
	HA
SEL023X OATA MONITOR and ACTIVE TEST are available for the wa	rn- SC
SELECT DIAG MODE ing chime. DATA MONITOR active test	EL
	IDX
SEL322W	

CONSULT-II Application Items

"KEY WARNING ALARM" Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW DR	Indicates [ON/OFF] condition of front door switch LH.

Active Test

	NFEL0217S0102
Test Item	Description
	This test is able to check key warning chime operation. Key warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

"LIGHT WARN ALM"

Data Monitor

		NFEL0217S0201
Monitored Item	Description	
LIGHT SW 1ST	Indicates [ON/OFF] condition of lighting switch.	
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.	
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.	

Active Test

	NFEL0217S0202
Test Item	Description
CHIME	This test is able to check light warning chime operation. Light warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

"SEAT BELT WARM ALM" Data Monitor

NFEL	.021	7S	03

NFEL0217

NFEL0217S01

NFEL0217S0101

NFEL0217S02

	NFEL0217S0301
Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of seat belt switch.

Active Test

	NFEL0217S0302
Test Item	Description
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds for 2 seconds after touching "ON" on CONSULT-II screen.

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NFEL0055


STMFTOM CHART						
REFERENCE PAGE (EL-)	151	153	154	155	156	
	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH CHECK)	DIAGNOSTIC PROCEDURE 4	MA EM LC EC
SYMPTOM	<u>ط</u> 0	0 <u>5</u> D		0 50 N		
Light warning chime does not activate.	х	х			х	FE
Ignition key warning chime does not activate.	х		х		X	CL
Seat belt warning chime does not activate.	х			х	X	MT
All warning chimes do not activate.	Х				X	UVU U

AT

SU

BR

ST



POWER SUPPLY AND GROUND CIRCUIT CHECK Power Supply Circuit Check

	NFEL0055S0201	
Terminals (Wire color)	Voltage	RS
49 (R/B) - Ground	Battery voltage	BT


SC

HA

EL

IDX


Trouble Diagnoses (Cont'd)



Ground Circuit Check		
Terminals (Wire color)	Continuity	
43 (B) - Ground	Yes	
64 (B) - Ground	Yes	

EL-152

DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)




IDX


NG

Replace key switch.


DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)




DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH CHECK)



DIAGNOSTIC PROCEDURE 4



2 CHECK DOO	R SWITCH INPUT SIG	NAL		1
With CONSULT-II			TA MONITOR" mode with CONSULT-II.	C
	_			
		IONITOR	-	R
	MONITOR		When driver's door is	
	DOOR SW-DR	OFF	open:	
			DOOR SW-DR ON	
			When driver's door is	I
			closed:	
			DOOR SW-DR OFF	
			SEL319W	
🕅 Without CONSUL	.T-II			1_
		l unit harnes	ss connector M143 terminal 1 (LG) and ground.	F
	Oment entrenes contro			
	Smart entrance contro unit connector			0
		H S		
		CONNECT	Voltage [V]: Condition of driver's door: CLOSED	
	┟╏┼┼┼┝╧╧╧┥┼┼┼┤	F		
			Approx. 12 Condition of driver's door: OPENED	
	$\mathbf{\nabla}$			
			0	ŀ
÷ ·				
			SEL996XA	ļ
		-		L ^F
		0	DK or NG	
ЭК	► GO TO 4.			6
NG	► GO TO 3.			
				_ [
CHECK DRIV	ER SIDE DOOR SWIT	СН		ן ר
Sheck continuity betw	een terminals 2 and 3.			(
Door sw	itch driver side			
connecto				
			Continuity:	
2	— —		Door switch is pushed.	
3	1 .S.		No	
			Door switch is released.	
T			Yes	
			SEL325W	
		C	0K or NG	
	Cheale the f			┨╻
ЭК	Check the fe		h ground circuit and condition	
			short between smart entrance control unit and driver side door	
	switch			1
NG		or cido door	r cwitch	
NG	Replace driv	51 SIDE 0001	i Switch.	1



System Description System Description NFEL0057 WIPER OPERATION NFEL0057S01 The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions: LO speed MA HI speed INT (Intermittent) With the ignition switch in the ON or START position, power is supplied through 20A fuse [No. 25, located in the fuse block (J/B)] to wiper motor terminal 4 and LC to wiper switch terminal 15. Low (Mist) and High Speed Wiper Operation NFEL0057S0101 Ground is supplied to wiper switch terminal 17 through body grounds E11, E22 and E53. When the wiper switch is placed in the LO or MIST position, ground is supplied through terminal 14 of the wiper switch • to wiper motor terminal 3. With power and ground supplied, the wiper motor operates at low speed. GL When the wiper switch is placed in the HI position, ground is supplied through terminal 16 of the wiper switch MT to wiper motor terminal 1. With power and ground supplied, the wiper motor operates at high speed. Auto Stop Operation AT NEEL 005750102 With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base. When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided AX • from terminal 14 of the wiper switch to wiper motor terminal 3, in order to continue wiper motor operation at low speed. Ground is also supplied through terminal 13 of the wiper switch • to wiper motor terminal 2 through terminal 6 of the wiper motor, and through body grounds E11, E22 and E53. When wiper arms reach base of windshield, wiper motor terminals 2 and 4 are connected instead of terminals 2 and 6. Wiper motor will then stop wiper arms at the STOP position. Intermittent Operation NFEL0057S0103 The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 3 to 13 seconds. This feature is controlled by the wiper amplifier (INT SW) combined with wiper switch. When the wiper switch is placed in the INT position, ground is supplied to wiper amplifier. The desired interval time is input to wiper amplifier (INT VR) from wiper volume switch combined with wiper switch. Then intermittent ground is supplied HA to wiper motor terminal 3 from terminal 14 of wiper switch SC through wiper amplifier (OUTPUT). The wiper motor operates at low speed at the desired interval. EL WASHER OPERATION NFEL0057S02 With the ignition switch in the ON or START position, power is supplied through 20A fuse [No. 25, located in the fuse block (J/B)] to washer motor terminal 1. When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal 2, and
- from terminal 18 of the wiper switch

System Description (Cont'd)

- through terminal 17 of the wiper switch, and
- through body grounds E11, E22 and E53.

With power and ground supplied, the washer motor operates.

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

FRONT WIPER AND WASHER

Wiring Diagram - WIPER -

Wiring Diagram — WIPER —

NFEL0058 **EL-WIPER-01** GI IGNITION SWITCH ON OR START MA FUSE BLOCK (J/B) E89 δ 20A 25 REFER TO EL-POWER. ¢ EM 3G F LC EC F 1/Y2 FE FRONT WIPER MOTOR E78 STOP LOW FRONT WASHER MOTOR HIGH M MOVE CL (E41) 3 6 L/B Ē MT AT R LY 14 18 VARIABLE INTERMITTENT WIPER VOLUME AX COMBINATION SWITCH (FRONT WIPER INT LO OFF OFF WASH INT IGN SW SW AUTO INT STOP VR MIST INT LO OFF WASH SU 4 SWITCH) OUT-PUT GND INT VR нı (E153) BR 17 B JOINT CONNECTOR-7 В ST **1** 1 Ľ RS B BT В HA (E53) (E22) ĒIJ REFER TO THE FOLLOWING. 1 1 1 1 1 1 1 1 1 GY 14 18 E153 16 17 13 15 GY $\begin{array}{c}
\hline
2 \\
1 \\
\hline
GY
\end{array}$ $\begin{array}{c}
\hline
1 \\
2 \\
4 \\
5 \\
\hline
6 \\
\end{array}$ $\begin{array}{c}
\hline
6 \\
\hline
7 \\
\hline
7 \\
\hline
6 \\
\hline
7 \\
\hline

7 \\
\hline

7 \\
\hline

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\

7 \\


7 \\

7 \\

7 \\$ E89 -FUSE BLOCK-SC JUNCTION BOX (J/B) EL IDX

MEL1310


FRONT WIPER AND WASHER



Removal and Installation WIPER ARMS


NFEL0060

- Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
- 2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance " L_1 " & " L_2 " immediately before tightening nut.
- 3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
- 4. Ensure that wiper blades stop within clearance "L₁" & "L₂".
 Clearance "L₁": 48 64 mm (1.89 2.52 in)
 Clearance "L₂": 40 56 mm (1.57 2.20 in)
- Tighten wiper arm nuts to specified torque.
 - Front wiper: 21 26 N-m (2.1 2.7 kg-m, 16 19 ft-lb)



• Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER LINKAGE



FRONT WIPER AND WASHER

-Suitable tool

Washer nozzle

Washer tube


Washer tank

Max. 10°

 2. Detach wijer midde nom wijer midde at bair joint. 3. Remove wijer linkage. Be careful not to break ball joint rubber boot. Installation Grease ball joint portion before installation. Installation is the reverse order of removal. Washer Nozzle Adjustment Methods and the figure at left. Adjust washer nozzle with suitable tool as shown in the figure at left. Adjustable range: ±10° Unit: mm (in) 				Removal and	Installation (Cont d)	
Installation • Grease ball joint portion before installation. 1. Installation is the reverse order of removal. • Masher Nozzle Adjustment • Adjust washer nozzle with suitable tool as shown in the figure at left. • Adjustable range: ±10° • Unit: mm (in)		 Remove 4 bo Detach wiper Remove wipe 	motor from wip er linkage.	er linkage at bal		GI MA
table tool Negative for the figure of th		Installation Grease ball joint 	oint portion befo	ore installation.	NFEL006050202	EM
Adjustable range: ±10°	table tool	 Adjust washe 	-		own in the figure	LC EC
Nozzle hole bore diameter 0.8 mm (0.031 in) SEL241P Unit: mm (in)			le range: ±10°			FE
	bore diameter 0.8 mm (0.031 in)					MT
				*=		AT
				-		<i>U</i> -71
*2 286 (11.26) *6 203 (7.99) *3 285 (11.22) *7 382 (15.04)	i Nda			-		AX
*: The diameters of these circles are less than 80 mm (3.15 in).	*5 + *6 + + + + + + + + + + + + + + + + +					SU BR
		Washer Tube	e Layout		NFEL0062	ST
	De D					RS
	SCAL					BT
MEL377K	MEL377K					HA
						SC




IDX




CIGARETTE LIGHTER


Wiring Diagram — CIGAR —



Wiring Diagram — CLOCK —



MEL277K



BR

	BR
System Description	ST
The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes. Power is supplied at all times	RS
 to rear window defogger relay terminal 3 	
 through 20A fuse [No. 7, located in the fuse block (J/B)] and 	BT
 to rear window defogger relay terminal 6 	
 through 20A fuse [No. 4, located in the fuse block (J/B)]. 	
 to smart entrance control unit terminal 49 	HA
 through 10A fuse [No. 13, located in the fuse block (J/B)]. 	
With the ignition switch in the ON or START position, power is supplied	SC
 through 10A fuse [No. 10, located in the fuse block (J/B)] 	90
 to the rear window defogger relay terminal 1 and 	
 to smart entrance control unit terminal 27. 	EL
Ground is supplied	
 to terminals 2 and 5 of the rear window defogger switch 	IDX
 through body grounds M9, M25 and M87 (with navigation system), 	
 to terminal 32 of the A/C auto amp. (with auto A/C) or 	
 to terminal 17 of the A/C control unit (with manual A/C) 	
 through body grounds M9, M25 and M87 (without navigation system). 	
 to smart entrance control unit terminals 43 and 64 and rear window defogger switch terminal 5 	

EL-167

System Description (Cont'd)

• through body grounds M9, M25 and M87.

When the rear defogger switch is turned ON, ground is supplied

- through terminal 1 of the rear window defogger switch (with navigation system),
- through terminal 31 of the A/C auto amp. or 9 of the A/C control unit (with manual A/C)
- to smart entrance control unit terminal 14.

Terminal 37 of the smart entrance control unit then supplies ground to the rear window defogger relay terminal 2.


With power and ground supplied, the rear window defogger relay is energized. Power is supplied


- through terminals 5 and 7 of the rear window defogger relay
- to the rear window defogger and
- to terminal 30 of the A/C auto amp. (with auto A/C) or
- to terminal 10 of the A/C control unit (with manual A/C)
- to rear window defogger switch terminal 4 (with navigation system).

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window. When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Wiring Diagram — DEF —





MEL1360


* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.

SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
14	G/W	REAR WINDOW DEFOGGER	$OFF \rightarrow ON$ (WHEN ONLY PUSHED)	$5V \rightarrow 0V$
14	G/W	SWITCH	$OFF \rightarrow ON (WHEN ONE FOSHED)$	
27				12V
37	G/R	REAR WINDOW DEFOGGER	OFF \rightarrow ON (IGNITION SWITCH IS IN "ON" POSITION)	$12V \rightarrow 0V$
37	G/H	RELAY		120 - 00
43	В	GROUND	_	-
49	R/B	POWER SOURCE (FUSE)	_	12V
64	В	GROUND	_	-

SEL199YA

EL-170



CONSULT-II Application Items

"REAR DEFOGGER" Data Monitor

NFEL0219

NFEL0219S01

		NFEL0219S0101
Monitored Item	Description	
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.	
REAR DEF SW	Indicates [ON/OFF] condition of rear window defogger switch.	
Active Test		NFEL0219S0102
Tost Itom	Description	

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation. Rear window defogger activates when "ON" on CONSULT-II screen is touched.

Trouble Diagnoses


DIAGNOSTIC PROCEDURE

NFEL0075

CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL




1



SC

EL

IDX



EL-174


Г


Trouble Diagnoses (Cont'd)

3 CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL	
B With CONSULT-II Select "REAR DEF SW" in "DATA MONITOR" mode with CONSULT-II.	GI
DATA MONITOR MONITOR	MA
REAR DEF SW ON When rear window defogger switch is pushed:	EM
REAR DEF SW should be ON.	LC
SEL352W	EC
Without CONSULT-II Check continuity between smart entrance control unit harness connector M143 terminal 14 (G/W) and ground.	FE
Smart entrance control unit connector Continuity:	CL
Rear window defogger switch is pushed. Continuity should exist.	MT
Rear window defogger switch is released. Continuity should not exist.	AT
SEL999X OK or NG	AX
OK GO TO 4.	SU
NG Check the following. • Rear window defogger switch	BR
 (Refer to EL-177.) Harness for open or short between smart entrance control unit and rear window defogger switch Rear window defogger switch ground circuit 	ST
• Real window delogger switch ground circuit	J RS
	BT
	HA
	SC


IDX

Trouble Diagnoses (Cont'd)






Electrical Components Inspection



10X

EL

Filament Check



Filament Check

 Attach probe circuit tester (in volt range) to middle portion of each filament.


• When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.


2. If a filament is burned out, circuit tester registers 0 or 12 volts.


3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

SEL266

		ament Repair	
		PAIR EQUIPMENT	GI
	1) 2)	Conductive silver composition (Dupont No. 4817 or equivalent) Ruler 30 cm (11.8 in) long	
	3)	Drawing pen	MA
	4)	Heat gun	
	5)	Alcohol	EM
	6)	Cloth	UVU
			LC
	RE	PAIRING PROCEDURE	60
<	1.	Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.	EC
	2.	Apply a small amount of conductive silver composition to tip of drawing pen.	FL
		ake silver composition container before use.	
	3.	Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of	CL
(in) BE540		the break.	MT
	4.	After repair has been completed, check repaired wire for con- tinuity. This check should be conducted 10 minutes after silver composition is deposited.	AT
	Do	not touch repaired area while test is being conducted.	AX
			141242
			SU
			90
			BR
SEL012D			<u>D</u> N
	5.	Apply a constant stream of hot air directly to the repaired area	ST
		for approximately 20 minutes with a heat gun. A minimum dis- tance of 3 cm (1.2 in) should be kept between repaired area	01
		and hot air outlet. If a heat gun is not available, let the repaired	RS
		area dry for 24 hours.	ЦЭ
			BT
			HA
SEL013D			
			SC







EL

IDX

AUDIO

System Description

BASE SYSTEM

Refer to Owner's Manual for audio system operating instructions. Power is supplied at all times

- through 15A fuse (No. 56, located in the fuse and fusible link box)
- to audio unit terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to audio unit terminal 10.

Ground is supplied through the case of the audio unit. Audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 1 and 2 of front door speaker LH and RH
- to terminals 1 and 2 of rear door speaker LH and RH
- to terminals 1 and 2 of tweeter LH and RH (with 6 speakers).

BOSE SYSTEM

Refer to Owner's Manual for audio system operating instructions. Power is supplied at all times

- through 15A fuse (No. 56, located in the fuse and fusible link box)
- to Bose speaker amp. terminal 27, and
- to CD auto changer terminal 3 (with CD auto changer)
- to audio unit terminal 6.
- through 15A fuse (No. 67, located in the fuse and fusible link box)
- to woofer terminal 48.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to CD auto changer terminal 1 (with CD auto changer) and
- to audio unit terminal 10.

Ground is supplied through the case of the audio unit. Ground is supplied

- to Bose speaker amp. terminal 40, and
- to woofer terminal 47
- through body grounds B106 and B127.
- to CD auto changer terminal 7 (with CD auto changer)
- through body grounds B12 and B59.

When the audio unit POWER button is pressed, power is supplied to BOSE speaker amp. terminal 25 and woofer terminal 45 from audio unit terminal 12.

- CD (audio) signals are supplied (with CD auto changer)
- through CD auto changer terminals 16, 6, 15 and 5
- to terminals 41, 42, 43 and 44 of the audio unit.

Audio signals are supplied

- through audio unit terminals 2, 1, 4, 3, 14, 13, 16 and 15
- to Bose speaker amp. terminals 33, 20, 35, 22, 34, 21, 36 and 23.
- through audio unit terminal 12
- to Bose speaker amp. terminal 25 and
- to woofer terminal 45.

Audio signals are amplified by the Bose speaker amp.

The amplified audio signals are supplied

- through Bose speaker amp. terminals 30, 31, 28, 29, 18, 17, 41 and 42
- to terminals 1 and 2 of the front door speaker LH and RH
- to terminals 1 and 2 of the tweeter LH and RH,
- to terminals 1 and 2 of the rear speaker LH and RH.

NFEL0079S02

NFEL0079

NFEL0079S01

- through Bose speaker amp. terminals 24 and 37
- to terminal 44 and 43 of the woofer.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BŢ
HA
SC
EL

IDX

AUDIO

Schematic


BOSE SYSTEM



(CD) : With CD auto changer To antenna amp. To illumination system AUDIO UNIT BOSE SPEAKER AMP. COMBINATION REAR DOOR SPEAKER RH ಕ್ರ UNIFIED METER CONTROL UNIT (WITH ODO/ TRIP METER) ഹ œ REAR DOOR SPEAKER LH CD AUTO CHANGER CD z ω ω TWEETER RH -11 E \sim T I FRONT DOOR SPEAKER RH 1 1 L ಇ С S 1 1 1 1 ഹ TWEETER LH ತ თ Q IGNITION SWITCH ACC or ON FUSE FRONT DOOR SPEAKER LH Э z ω z I ς. FUSE ဖ WOOFER FUSE BATTERY


AUDIO

MEL829P





EL-183

AUDIO UNIT (M64)





MEL140O






MEL830P





MEL143O

EL-AUDIO-07



IDX

MEL831P

AUDIO UNIT

Trouble Diagnoses

NFEL0220

NFEL0220S01

Symptom	Possible causes	Repair order
Audio unit inoperative (no digital display and no sound from speakers).	 10A fuse Poor audio unit case ground Audio unit 	 Check 10A fuse [No. 1, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery posi- tive voltage is present at terminal 10 of audio unit. Check audio unit case ground. Remove audio unit for repair.
Audio unit presets are lost when ignition switch is turned OFF.	 1. 15A fuse 2. Audio unit 	 Check 15A fuse (No. 56, located in fuse and fusible link box) and verify that battery positive voltage is present at terminal 6 of audio unit. Remove audio unit for repair.
AM/FM stations are weak or noisy.	 Window antenna Audio unit ground Audio unit 	 Check window antenna. Check audio unit ground condition. Remove audio unit for repair.
Audio unit generates noise in AM and FM modes with engine running.	 Poor audio unit ground Loose or missing ground bonding straps Ignition condenser or rear window defog- ger noise suppressor condenser Ignition coil or secondary wiring Audio unit 	 Check audio unit ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check ignition coil and secondary wiring. Remove audio unit for repair.
Audio unit generates noise in AM and FM modes with accessories on (switch pops and motor noise).	 Poor audio unit ground Antenna Accessory ground Faulty accessory 	 Check audio unit ground. Check antenna. Check accessory ground. Replace accessory.

BASE SYSTEM

BASE STOTEM			
Symptom	Possible causes	Repair order	
Individual speaker is noisy or inoperative.	 Speaker Audio unit output Speaker circuit Audio unit 	 Check speaker. Check audio unit output voltages. Check wires for open or short between audio unit and speaker. Remove audio unit for repair. 	


BOSE SYSTEM


Symptom	Possible causes	Repair order
Audio unit controls are operational, but no sound is heard from any speaker.	 1. 15A fuse 2. Amp. ON/OFF signal circuit 3. Speaker amp. ground 	 Check 15A fuse (No. 56, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 27 of speaker amp. Check harness continuity between audio unit termi- nal 12 and speaker amp. terminal 25. Check harness continuity between speaker amp. terminal 40 and ground.
Individual rear speaker is noisy or inoperative.	 Each speaker Output circuit to each speaker 	 Check speaker. Check the output circuits to each speaker between audio unit and speaker amp. between speaker amp. and each speaker.
Woofer does not operate.	 Power supply to woofer Amp. ON/OFF signal circuit Speaker amp. ground Output circuit to woofer 	 Check 15A fuse [No. 67, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 48 of woofer. Check harness continuity between audio unit termi- nal 12 and woofer terminal 45. Check harness continuity between woofer terminal 47 and ground. Check the output circuits to woofer from speaker amp.

AUDIO


Insp	pection
Inspection	
AUDIO UNIT AND AMP.	NFEL0221
All voltage inspections are made with:	FEL0221S01 (
Ignition switch ON or ACC	
Audio unit ON	R
• Audio unit and amps. connected (If audio unit or amp. is removed for inspection, supply a ground	to the
case using a jumper wire.)	
ANTENNA	
Using a jumper wire, clip an auxiliary ground between antenna and body.	FEL0221S02
 If reception improves, check antenna ground (at body surface). 	
• If reception does not improve, check main feeder cable for short circuit or open circuit.	
	7
	(
	R
	ļ
	Ŀ
	l
	Ĩ
	L
	F
	Ŀ
	п
	ŀ
	0

EL IDX






MEL730P




MEL1450

AUDIO ANTENNA

Location of Antenna





Window Antenna Repair ELEMENT CHECK


NFEL0250

 Attach probe circuit tester (in ohm range) to antenna terminal on each side.

If an element is OK, continuity should exist.

If an element is broken, no continuity should exist. Go to step 2.

AUDIO ANTENNA



IDX

System Description

OUTLINE

Electric sunroof system consists of

- Sunroof switch
- Sunroof motor
- Smart entrance control unit

Smart entrance control unit controls retained power operation.

OPERATION

The sunroof can be opened or closed and tilted up or down with the sunroof switch.

RETAINED POWER OPERATION

When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 seconds.

- to sunroof motor terminal 6
- from smart entrance control unit terminal 46.

When power is supplied, the electrical sunroof can be operated.

The retained power operation is canceled when the driver or passenger side door is opened. RAP signal period can be changed by CONSULT-II (EL-199).

INTERRUPTION DETECTION FUNCTION

The CPU of sunroof motor monitors the sunroof motor operation and the sunroof position (full closed or other) for sunroof by the signals from encoder and limit switch in sunroof motor.

When sunroof motor detects interruption during the following close operation,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation


sunroof switch controls the motor for open and the sunroof will operate about 150 mm (5.91 in).

NFEL0222 NFEL0222S01

NFEL0222S03

POWER SUNROOF

Wiring Diagram — SROOF –



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	LG	DRIVER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$12V \rightarrow 0V$
2	R/L	PASSENGER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN "ON" POSITION	12V
43	В	GROUND	_	-
46	PU	SUNROOF MOTOR	RETAIND POWER OPERATION IS OPERATED (ON \rightarrow OFF)	$12V \rightarrow 0V$
49	R/B	POWER SOURCE (FUSE)	_	12V
64	В	GROUND	_	-

SEL986XB


SC

EL

IDX

POWER SUNROOF

CONSULT-II Inspection Procedure



CONSULT-II Application Items

NFEL0224 NFEL0224S01 G

LC

"RETAINED PWR" Data Monitor

	NFEL0224S0101	
Monitored Item	Description	MA
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.	
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.	EM
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.	

Active Test

Active Test	NFEL0224S0102	2
Test Item	Description	RA
	This test is able to supply RAP signal (power) from smart entrance control unit to power window system, power sunroof system. Those systems can be operated when turning on	- EC
	"RETAINED PWR" on CONSULT-II screen even if the ignition switch is tuned OFF. NOTE:	FE
RETAINED PWR	During this test, CONSULT-II can be operated with ignition switch "OFF" position. "RETAINED PWR" should be turned "ON" or "OFF" on CONSULT-II screen when ignition switch is ON. Then turn ignition switch OFF for checking retained power operation. CONSULT-II might be stuck if "RETAINED PWR" is turned "ON" or "OFF"	GL
	on CONSULT-II screen when ignition switch is OFF.	. MT

Work Support

	NFEL0224\$0103	
Work Item	Description	AT
RETAINED PWR SET	RAP signal's power supply period can be changed by mode setting. Selects RAP signal's power supply period between two steps.MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (2 min.)	AX

BR

Trouble Diagnoses


	Irouble Diagnoses		ST
Symptom	Possible cause	Repair order	
Power sunroof cannot be operated using any switch.	 10A fuse, 40A fusible link and E90 circuit breaker Grounds M9, M25 and M87 	 Check 10A fuse [No. 10, located in fuse block (J/B)], 40A fusible link (letter I, located in fuse and fusible link box) and E90 circuit breaker. Turn igni- 	RS
	 Sunroof switch Sunroof switch circuit Sunroof motor 	tion switch "ON" and verify battery positive voltage is present at terminals 1 and 6 of sunroof motor. 2. Check grounds M9, M25, M87.	BT
		 Check grounds ins, in25, in67. Check sunroof switch. Check harness between sunroof switch and sunroof motor. 	HA
		5. Replace sunroof motor.	SC
Power sunroof cannot be operated using one of the sunroof switches.	 Sunroof switch Sunroof switch circuit 	 Check sunroof switch. Check the harness between sunroof motor and sunroof switch. 	EL


POWER SUNROOF

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Power sunroof cannot be opened or closed fully.	 Full closed position not initialized Sunroof slide mechanism Sunroof switch Sunroof switch circuit Sunroof motor 	 Initialize full closed position. Check the following. Check obstacles in sunroof, etc. Check worn or deformed sunroof. Check sunroof sash tilted too far inward or outward. Check sunroof switch. Check harness between sunroof motor and sunroof switch. Replace sunroof motor.
Retained power operation does not operate properly.	 RAP signal circuit Driver or passenger side door switch circuit Smart entrance control unit 	 Check RAP signal. a. (With CONSULT-II) Check RAP signal with CONSULT-II. Use "ACTIVE TEST" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-198.) If NG, go to the step b. below. b. Verify 12 positive voltage from smart entrance con- trol unit is present at terminal 6 of sunroof motor: Within 45 seconds after ignition switch turns off. When front door LH and RH is closed. Check harness between smart entrance control unit and driver or passenger side door switch. Check driver or passenger side door switch. Check smart entrance control unit. (EL-350)

Wiring Diagram — MIRROR -





1 2 3 4 5 6 7 8 9 10 11 12 W 7654321 (R15) B


> REFER TO THE FOLLOWING. (M19) - FUSE BLOCK -JUNCTION BOX (J/B)

(M25)

(M87)

TRUNK LID AND FUEL FILLER LID OPENER

Wiring Diagram — T&FLID -




SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
16		TRUNK AND FUEL LID	$OFF \rightarrow ON$ (when only pulled)	$12V \rightarrow 0V$
16 L		OPENER SWITCH		
43	В	GROUND	_	_
49	R/B	POWER SOURCE (FUSE)	_	12V
63	1	TRUNK LID OPENER	WHEN TRUNK LID OPENER ACTUATOR IS OPERATED USING	$0V \rightarrow 12V$
03	L	ACTUATOR	KEYFOB (ON \rightarrow OFF)	00-720
64	В	GROUND	-	-


SC

EL

IDX




Wiring Diagram — PHONE —




Wiring Diagram — SEAT — NFEL0092 EL-SEAT-01 GI BATTERY S REFER TO EL-POWER. 40A | | MA W/P EM W/B CIRCUIT BREAKER LC (E90) 2 EC W/R |6A | ₩/R (E81) M15 FE W/R (M6) CL B3 W/R MT **B**35 (B521) AT AX - \rightarrow NEXT PAGE SU B POWER SEAT SWITCH LH (B550) Ν Ν Ν BACKWARD FORWARD FORWARD BR BACKWARD SLIDING SWITCH RECLINING SWITCH 4 Ľŝ 6 5 BR ST B/Y w/B RS BR ₩/B B/Y G 6 5 4 BT SLIDING MOTOR LH RECLINING MOTOR LH {(M) **[** M] (B525) (B523) HA - BACKWARD FORWARD -- BACKWARD FORWARD -REFER TO THE FOLLOWING. 1 2 3 4 5 X 6 7 8 9 10 11 12 13 14 15 16 17 18 W 1 (E90) , (B35) 2 W W SC 5 B523 M15 - SUPER MULTIPLE JUNCTION (SMJ) 403 8525 B 4 8 6 5 3 7 2 1 10 9 W EL w * : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL-SECTION. IDX

MEL1540



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.

POWER SEAT




* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.

EL

IDX


Wiring Diagram — HSEAT —



HEATED SEAT

Seatback Heating Unit

Seatback Heating Unit



- AT

AX

- SU
- BR

ST

RS

BT

HA


SC

EL

IDX

AUTOMATIC DRIVE POSITIONER

Component Parts and Harness Connector Location



Component Parts and Harness Connector

AUTOMATIC DRIVE POSITIONER

		System Description		
	System Description			
OPERATIVE CONDITION	,	=NFEL0288 NFEL0288S01	GI	
The drive position can be set in 2 wa	ays, manually and automatically.	W EL220501	GII	
Manual Operation		NFEL0288S0101	MA	
The driver's seat can be adjusted fo LH power seat switches. The manual		ght and rear cushion height with the	UVUZAL	
Automatic Operation				
The driver's seat is adjusted to the proper positions for the driver automatically, in 3 different ways: MEMORY AUTOMATIC SET, AUTOMATIC EXITING SETTING and AUTOMATIC SET RETURN. (Automatic Drive Positioner = ADP)				
CONDITIONS INHIBITING AUTO	MATIC OPERATION	NET 000000	EC	
Automatic memory setting procedures are suspended under any of the following conditions: 1) When vehicle speed is more than 7 km/h (4 MPH).				
 When driver's side power seat switch is turned on. When any two of the switches (set switch and memory switches 1 and 2) are turned ON. When appeal switch is turned on. 			FE	
 4) When cancel switch is turned on. 5) When selector lever is in any position other than "P" (A/T) or parking brake is released (M/T). 6) When ignition switch is turned to "START" position. 			CL	
(Operation resumes when ignition switch is returned to "ON".)7) When detention switch malfunction is detected:			MT	
 Detention switch failure is sensed when detention switch remains off for at least 2 seconds at a vehicle speed of greater than 7 km/h (4 MPH). 			AT	
FAIL-SAFE SYSTEM		NFEL0288S03		
Output Failure When the ignition switch is in the ON position, if any of the parts (indicated in the following chart) move more				
than the specified amount within a period "T2" when no "ON" input is sent from any of the switches (indicated in the following chart), or an output from the automatic drive positioner is not produced, an output failure is sensed. Motor operation will be suspended automatically, and all automatic operations will be ineffective. (In this case, the motor will not operate manually.)				
OPERATED PORTION	Τ2	Allowable measurement	BR	
Seat sliding	Approx. 2.5 sec.	Within 6 mm (0.24 in)		
Seat reclining	Same as above	Change angle within 1°	ST	
	Same as above			
Absolving When moving selector lever back to	"P" position after baying moved it	to any position except " D " (Λ/T) or	RS	
When moving selector lever back to "P" position after having moved it to any position except "P" (A/T) or applying parking brake after having released it (M/T), fail-safe operation will be canceled.				
INITIALIZATION (A/T MODEL ONLY) After reconnecting battery cable, perform initialization procedure A or B. If initialization has not been performed, automatic drive positioner will not operate. PROCEDURE A				
 Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.) Open → close → open driver side door. (Do not perform with the door switch operation.) End 				
PROCEDURE B 1) Drive the vehicle at more than 25 km/h (16 MPH).				
2) End	· · ·		IDX	

MEMORY AUTOMATIC SET

Two drive positions can be retained in the memory. Press memory switch to set driver's seat to preset position.

PROCEDURE FOR STORING MEMORY

Adjust the position of driver's seat with manual set operations.				
	Ignition switch "ON".			
Touch set switch.	Indicator LEDs			
	(1) Indicator LED for which driver's seat positions are already retained in memory illuminates for 5 seconds.			
	(2) Indicator LED for which driver's seat positions are not entered in memory illuminates for 0.5 seconds.			
Within 5 seconds.				
Press memory switch for which driv- er's seat positions are to be entered in memory for more than 0.5 sec- onds. (2 driver's seat positions can be memorized.)	Indicator LEDs			
	 (1) To modify driver's seat positions, press memory switch. Indicator LED will then go out for 0.5 seconds and then illuminate for 5 seconds. 			
	(2) To enter driver's seat positions in blank memory, indicator LED illuminates for 5 seconds after memory switch is pressed.			
END OF MEMORY SETTING				

SEL592W

NOTE:

- When memory switch for which driver's seat positions are already retained in memory is pressed, new seat
 positions will be retained in memory in place of the previously set positions.
- Drive position is erased from the memory when battery cable is disconnected more than 30 seconds. After connecting battery cable, perform initialization procedures.

SELECTING THE MEMORIZED POSITION

PROCEDURE-A Turn ignition switch "ON" and press desired memory switch for more than 0.3 seconds. (Indicator LED illuminates.)	 PROCEDURE-B (A/T model only) Open driver's door and withdraw key from ignition key cylinder. Then press desired memory switch for more than 0.3 seconds. (Indicator LED illuminates.) (See NOTE 2.)
	(See NOTE 1.) Within 1 minute
	 Insert key into ignition key cylinder. (Memory indicator illuminates.)
↓	
The driver's seat will move to the (During adjustments, indicator LE seconds after adjustment.)	

AUTOMATIC DRIVE POSITIONER

System Description (Cont'd)

GI

EC

NFEL0288S06

NOTE:


- 1) Do not keep cancel switch pressed as it will not operate.
- 2) Automatic exiting setting will be performed.
- 3) The driver's seat position (see the following Table) operates in the order of priority.

The order of priority	Operated portion	MA
1	Seat sliding	
2	Seat reclining	EM
3	Seat front lifting	
4	Seat rear lifting	LC

AUTOMATIC EXITING SETTING (A/T MODEL ONLY)


"Exiting" positions:

Driver's seat ... Slides about 40 mm (1.57 in) rear from normal sitting position.



AUTOMATIC SET RETURN (A/T MODEL ONLY)

With driver's seat set to the "exiting" position, operating one of the following procedures moves it to the position previously retained in memory.



HA


SU

SC

EL


Schematic

NFEL0289




AUTOMATIC DRIVE POSITIONER

Wiring Diagram - AUT/DP -




 $\boldsymbol{\star}$: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION


MEL1470




MEL148O



MEL149O



EL-218




IDX


MEL1510

EL-219

EL-AUT/DP-06



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.




*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", EL SECTION.

IDX


MEL750P

On Board Diagnosis



HOW TO PERFORM SELF-DIAGNOSIS

NFEL0291S01



SEL596W

*1: If no malfunction is indicated, self-diagnosis will end after the vehicle speed sensor diagnosis is performed. *2: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

EL-222

NFEL0291

MALFUNCTION CODE TABLE

In this mode, a malfunction code is indicated by the number of flashes from the automatic drive positioner indicator lamps (indicator lamp 1, indicator lamp 2) as shown below.

GI

		1		IMIA
Code No.	Detected items	Indication of seat memory switches 1 and 2	Explanation	
1	Seat sliding			EM
2	Seat reclining		While the seat motors are moving for 2.5 seconds, if the number of seat	LC
3	Seat lifting front		sliding/reclining/lifting encoder pulses changes 2 times or less, the seat device is determined	EC
4	Seat lifting rear		to be malfunctioning.	FE
9	Vehicle speed sensor circuit	IND1, IND2	If the vehicle speed sensor output of less than 7 km/h (4 MPH) is detected, the vehicle speed sensor is determined to be malfunctioning.	CL MT
				AT
_	No malfunction in the above items		_	XA
	items	0.5 sec. 5 sec.		SU
L	1	1		BR


SEL597W

Code No.	Detected items	Diagnostic procedure	Refer- ence page	Code No.	Detected items	Diagnostic procedure	Refer- ence page	ST
1	Seat sliding	PROCEDURE 2 (Sliding encoder check) PROCEDURE 6 (Sliding motor check)	EL-229 EL-237	4	Seat lifting rear	PROCEDURE 5 [Lifting encoder (rear) check] PROCEDURE 9 [Lifting motor (rear) check]	EL-235 EL-240	· RS BT
2	Seat reclining	PROCEDURE 3 (Reclining encoder check) PROCEDURE 7 (Reclining motor check)	EL-231 EL-238	9	Vehicle speed sensor	PROCEDURE 12 (Vehicle speed sensor check)	EL-242	HA
3	Seat lifting	PROCEDURE 4 [Lifting encoder (front) check]	EL-233					SC
	front	PROCEDURE 8 [Lifting motor (front) check]	EL-239					EL

IDX

Trouble Diagnoses WORK FLOW

NFEL0292 NFEL0292S01



*1 EL-222

*2 EL-223

SEL599W

effected?

lοκ

ОК

οк

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK NFEL0292S02 GI NG (Both operation) Are automatic operation No seat system functions oper-SYMPTOM 1 and manual operation ate Some of the seat system func-SYMPTOM 2 MA tions do not operate. SYMPTOM 3 No functions operate during automatic operation and some/all functions do not operate during LC manual operation. EC Some NG (Automatic Inoperative functions Some of the seat system func-SYMPTOM 4 operation) functions FE tions do not operate. CL All functions No automatic operation functions SYMPTOM 5 operate. MT Only storing memory function SYMPTOM 6 does not operate. Memorized position set (proce-Perform initializa-AT dure B), automatic exiting and tion*1 automatic set return functions do not operate. (A/T model only) AX NG (Manual operation) Seat system SYMPTOM 7 NG Can be cancellation performed during SYMPTOM 8 automatic operation? ST NG Does memory indicator light up? SYMPTOM 9 INSPECTION END BT SEL600WA HA

*1: After reconnecting battery cable, perform initialization procedure A or B.

SC If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- EL 1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- Open \rightarrow close \rightarrow open driver side door. (Do not perform with \mathbb{D}) 2) the door switch operation.)
- 3) End

PROCEDURE B

1) Drive the vehicle at more than 25 km/h (16 MPH).

EL-225

2) End

After performing preliminary check, go to symptom chart below.

Before starting trouble diagnoses below, perform preliminary check, EL-225. Symptom numbers in the symptom chart correspond with those of preliminary check.

SYMPTOM CHART

NFEL0292S03

PROC	EDURE				Dia	ignostic proce	edure		
REFE	RENCE PAGE (EL-	228	229	231	233	235	237	238	
SYMPTOM		DIAGNOSTIC PROCEDURE 1 (Power supply and ground circuit for Driver's seat control unit)	DIAGNOSTIC PROCEDURE 2 (Sliding encoder check)	DIAGNOSTIC PROCEDURE 3 (Reclining encoder check)	DIAGNOSTIC PROCEDURE 4 [Litting encoder (front) check]	DIAGNOSTIC PROCEDURE 5 [Lifting encoder (rear) check]	DIAGNOSTIC PROCEDURE 6 (Sliding motor check)	DIAGNOSTIC PROCEDURE 7 (Reclining motor check)	
1	No seat system functions operate.		Х						
	Some of the seat	Sliding						х	
2	system functions do not operate	Reclining							X
2	during automatic/	Lifting (Front)							
	manual operation.	Lifting (Rear)							
3	No functions operate during auto- matic operation, and some/all func- tions do not during manual opera- tion.								
	Some of the seat	Sliding		Х					
4	system functions	Reclining			х				
4	do not operate during automatic	Lifting (Front)				Х			
	operation.	Lifting (Rear)					Х		
5	No automatic oper operate.	ation functions							
6	Drive position can the memory.	not be retained in							
	Does not operate	Sliding							
7	during manual	Reclining							
7	operation. (Oper- ates during auto-	Lifting (Front)							
	matic operation.)	Lifting (Rear)							
8	Automatic operatic celed.	on cannot be can-							
9	Memory indicator	does not light up.							


X : Applicable

PROC	EDURE				Dia	agnostic proc	edure			-
REFERENCE PAGE (EL-)		239	240	241	241	242	244	245	GI	
SYMPTOM		DIAGNOSTIC PROCEDURE 8 [Lifting motor (front) check]	DIAGNOSTIC PROCEDURE 9 [Lifting motor (rear) check]	DIAGNOSTIC PROCEDURE 10 (Power seat switch check)	DIAGNOSTIC PROCEDURE 11 (Cencel switch check)	DIAGNOSTIC PROCEDURE 12 (Key, park position, parking brake, door switch and vehicle speed sensor check)	DIAGNOSTIC PROCEDURE 13 (Seat memory switch check)	DIAGNOSTIC PROCEDURE 14 (Memory indicator check)	MA EM LC FE	
1	No seat system fu	nctions operate.								CL
	Some of the seat	Sliding								- 0,052
2	system functions do not operate	Reclining								MT
L	during automatic/ manual operation.	Lifting (Front)	Х							- AT
		Lifting (Rear)		X						_
3	No functions operate during auto- matic operation, and some/all func- tions do not during manual opera- tion.				x		X (ACC, ON START signal)			AX
	Some of the seat	Sliding								- SU
4	system functions do not operate	Reclining								_ _
4	during automatic	Lifting (Front)								- BR
	operation.	Lifting (Rear)								- ST
5	No automatic oper operate.	ation functions				x	x			91
6	Drive position can the memory.	not be retained in					X (IGN ON signal)	x		- RS
		Sliding			X					- BT
	Does not operate during manual	Reclining			X					-
7	operation. (Oper- ates during auto-	Lifting (Front)			Х					- HA
	matic operation.)	Lifting (Rear)			Х					- SC
8	Automatic operatic celed.	on cannot be can-				х				
9	Memory indicator	does not light up.							Х	EL

X : Applicable

IDX

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 1

(Power supply and ground circuit for driver's seat control unit)

Power Supply Circuit Check

Check voltage between seat control unit LH terminal 1 and ground. (Refer to wiring diagram in EL-215.)


Terminals		Ignition swi	tch position			
Terminais	OFF	ACC	ON	START		
1 - Ground	Battery voltage					

If NG, check the following.

Circuit breaker •

-

Harness for open or short between circuit breaker and seat control unit LH



Ground Circuit Check

Check continuity between seat control unit LH terminal 33 and ground.

(Refer to wiring diagram in EL-215.)

Terminals	Continuity
33 - Ground	Yes

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2 =NFEL0292S05 (Sliding encoder check) GI 1 CHECK SLIDING ENCODER OUTPUT SIGNAL Measure voltage between seat control unit LH terminal 18 and ground with CONSULT-II or oscilloscope when power seat MA slide is operated. **از ا** HI -----EM Seat control unit LH (B512) 18 LC LO-----Р HI: Approx. 5V EC LO: Approx. 0V FE SEL603W OK or NG CL OK Sliding encoder is OK. NG GO TO 2. ► MT 2 CHECK SLIDING ENCODER INPUT SIGNAL Check voltage between seat control unit LH terminal 17 and ground. AT AX Seat control unit LH (B512) Battery voltage should exist. SU GY/R SEL604W ST OK or NG GO TO 3. OK ► NG Replace seat control unit LH. BT

HA

SC

EL

Trouble Diagnoses (Cont'd)


GY/R

OK

NG

Y/C

►



OK or NG

Replace sliding encoder.

Repair harness.

No

SEL606W

18 - Ground

28 - Ground

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 3 =NFEL0292S06 (Reclining encoder check) GI 1 CHECK RECLINING ENCODER OUTPUT SIGNAL Measure voltage between seat control unit LH terminal 29 and ground with CONSULT-II or oscilloscope when power seat MA reclining is operated. HI -----EM Seat control unit LH (B512) LC 29 LO-----LG HI: Approx. 5V EC LO: Approx. 0V F FE SEL607W OK or NG CL OK Reclining encoder is OK. ► GO TO 2. NG ► MT 2 CHECK RECLINING ENCODER INPUT SIGNAL Check voltage between seat control unit LH terminal 17 and ground. AT AX Seat control unit LH (B512) 17 Battery voltage should exist. SU GY/R SEL608W ST OK or NG GO TO 3. OK ► NG Replace seat control unit LH. BT


HA

SC

EL

Trouble Diagnoses (Cont'd)





Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4 =NFEL0292S07 [Lifting encoder (front) check] GI 1 CHECK LIFTING ENCODER (FRONT) OUTPUT SIGNAL Measure voltage between seat control unit LH terminal 19 and ground with CONSULT-II or oscilloscope when power seat MA lifting (front) is operated. E٦ HI -----EM Seat control unit LH (8512) LC LO-----L/R HI: Approx. 5V EC LO: Approx. 0V FE SEL611W OK or NG CL OK Lifting encoder (front) is OK. NG GO TO 2. MT 2 CHECK LIFTING ENCODER (FRONT) INPUT SIGNAL Check voltage between seat control unit LH terminal 17 and ground. AT AX Seat control unit LH (B512) 17 Battery voltage should exist. SU GY/R SEL612W ST OK or NG GO TO 3. OK ► NG Replace seat control unit LH. BT

HA

SC

EL


Trouble Diagnoses (Cont'd)

Y/G

►

OK

NG



OK or NG

Replace lifting encoder (front).

Repair harness.

SEL614W


Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 5 =NFEL0292S08 [Lifting encoder (rear) check] GI CHECK LIFTING ENCODER (REAR) OUTPUT SIGNAL 1 Measure voltage between seat control unit LH terminal 30 and ground with CONSULT-II or oscilloscope when power seat MA lifting (rear) is operated. HI -----EM Seat control unit LH (8512) LC 30 LO-----SB HI: Approx. 5V EC LO: Approx. 0V FE SEL615W OK or NG CL OK Lifting encoder (rear) is OK. NG GO TO 2. MT 2 CHECK LIFTING ENCODER (REAR) INPUT SIGNAL Check voltage between seat control unit LH terminal 17 and ground. AT AX Seat control unit LH (B512) Battery voltage should exist. SU GY/R SEL616W ST OK or NG GO TO 3. OK ► NG Replace seat control unit LH. BT

SC


EL

Trouble Diagnoses (Cont'd)





Trouble Diagnoses (Cont'd)




SC

EL


IDX

DIAGNOSTIC PROCEDURE 7


=NFEL0292S10



- 1. Disconnect reclining device LH connector B515.
- 2. Apply 12V DC direct current to motor and check operation.



Trouble Diagnoses (Cont'd)




SC


EL

IDX

DIAGNOSTIC PROCEDURE 9 [Lifting motor (rear) check]

=NFEL0292S12






Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 10 (Power seat switch check)


=NFEL0292S13




IDX


DIAGNOSTIC PROCEDURE 12

(Key, detention, stop lamp, parking brake, door switch and vehicle speed sensor check)






Trouble Diagnoses (Cont'd)



1DX

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 13 (Seat memory switch check)

NFEL0292S16

1	CHECK SEAT MEMORY	SWITCH							
	sconnect seat memory switc neck continuity between sea		(D14).						
	Seat memory swit]	Switch	Condition		Term 2	ninals	4	
			Memory-1	ON	0	2	3	4	
		Memory-2	ON		0		0		
		Set	ON			0-	<u>+o</u> _		
									SEL634V
		OK	or NG						
ОК	OK Check the following. Ground circuit for seat memory switch Harness for open or short between seat control unit LH and seat memory switch 								
NG	►	Replace seat memory switch.							

Trouble Diagnoses (Cont'd)

		DIAGNOSTIC PROCEDURE 14 (Memory indicator check)	17				
1	CHECK INDICATOR LA] GI				
Chec	Check indicator lamp illumination.						
	OK or NG						
OK		GO TO 2.	1				
NG		Replace seat memory switch (indicator lamp).	EM				
			•				
2	CHECK POWER SUPP	LY CIRCUIT FOR INDICATOR LAMP	LC				
	 Disconnect seat memory switch connector (D14). Check voltage between seat memory switch terminal 5 and ground. 						
	Seat memory switch		FE				
	Battery voltage should exist.						
	Y/R V		MT				
		SEL635WB	AT				
	OK or NG						
ОК		Check harness for open or short between seat control unit LH and seat memory switch					
NG	•	 Check the following. 10A fuse [No. 12 located in the fuse block (J/B)] Harness for open or short between fuse and indicator lamp 	SU				

BR

ST

RS

BT

HA

SC

EL

System Description

System Description

Refer to EC-53, "Automatic Speed Control Device (ASCD) System" in "ENGINE AND EMISSION BASIC DESCRIPTION CONTROL SYSTEM".

System Description	
Power is supplied at all times	
• from 40A fusible link (letter I, located in the fuse and fusible link box)	GI
to circuit breaker terminal 1	
through circuit breaker terminal 2	MA
 to power window relay terminal 3 and 	
 to front power window main switch terminal 4 	eM
 to front power window switch RH terminal 6. 	EM
With ignition switch in ON or START position, power is supplied	
 through 10A fuse [No. 10, located in the fuse block (J/B)] 	LC
 to rear power window switch LH and RH terminal 6 	
 to smart entrance control unit terminal 27. 	EC
Ground is supplied to power window relay terminal 1	LV
 through body grounds M9, M25 and M87. 	
Ground is supplied to rear power window switch LH terminal 7	FE
 through body ground B12 and B7 (without CD auto changer), or B59 (with CD auto changer). 	
Ground is supplied to rear power window switch RH terminal 7	CL
 through body grounds B106 and B127. 	05
The power window relay is energized and power is supplied	
through power window relay terminal 5	MT
• to front power window main switch terminal 11,	
 to front power window switch RH terminal 13, 	AT
 to rear power window switch LH and RH terminal 5. 	0 00
MANUAL OPERATION	0.5/7
Front Door LH	AX
Ground is supplied	
 to front power window main switch terminal 5 	SU
 through body grounds M9, M25 and M87. 	
WINDOW UP	തെ
When the front LH switch in the front power window main switch is pressed in the up position, power is sup-	BR.
plied	
 to front power window regulator LH terminal 1 	ST
 through front power window main switch terminal 2. 	
Ground is supplied	RS
 to front power window regulator LH terminal 3 	no
 through front power window main switch terminal 3. 	
Then, the motor raises the window until the switch is released.	BT
WINDOW DOWN	
When the LH switch in the power window main switch is pressed in the down position, power is supplied	HA
to front power window regulator LH terminal 3	0 00 0
through front power window main switch terminal 3.	~ ~ ~
Ground is supplied	SC
to front power window regulator LH terminal 1	
through front power window main switch terminal 2.	EL
Then, the motor lowers the window until the switch is released.	
Front Door RH	
Ground is supplied	IUX
 to front power window switch RH terminal 5 	
the second has developed a MO MOS and MOZ	

• through body grounds M9, M25 and M87.

WINDOW UP

When the front RH switch in the front power window switch is pressed in the UP position, power is supplied

System Description (Cont'd)

- to front power window regulator RH terminal 1
- through front power window switch RH terminal 5. Ground is supplied
- to front power window regulator RH terminal 3
- through front power window switch RH terminal 4.

Then, the motor raises the window until the switch is released. WINDOW DOWN

When the RH switch in the front power window switch is pressed in the DOWN position, power is supplied

- to front power window regulator RH terminal 3
- through front power window switch RH terminal 4.

Ground is supplied

- to front power window regulator RH terminal 1
- through front power window switch RH terminal 5.

Then, the motor lowers the window until the switch is released.

Rear Door

REAR DOOR MAIN SWITCH OPERATION Rear Door LH Power is supplied

- through front power window main switch terminal (13, 12)
- to rear power window switch LH terminal (3, 4)
- The subsequent operation is the same as front power window switch RH operation. REAR POWER WINDOW SWITCH LH OPERATION

Power is supplied

- through rear power window switch LH terminal (1, 2)
- to rear power window regulator LH terminal (1, 2)

Ground is supplied

- to rear power window regulator LH terminal (2, 1)
- through rear power window switch LH terminal (2, 1)
- to rear power window switch LH terminal (4, 3)
- through front power window main switch terminal (12, 13)

Then, the motor raises or lowers the window until the switch is released.

Rear Door RH

Power is supplied

- through front power window main switch terminal (9, 10)
- to rear power window switch RH terminal (3, 4)
- through rear power window switch RH terminal (1, 2)
- to rear power window regulator RH terminal (1, 2)

Ground is supplied

- to rear power window regulator RH terminal (2, 1)
- through rear power window switch RH terminal (2, 1)
- to rear power window switch RH terminal (4, 3)
- through front power window main switch terminal (10, 9)

Then, the motor raises or lowers the window until the switch is released.

Power Window Opened/Closed Operation

- When ignition key switch is OFF, front power window can be opened or closed by turning the front door key cylinder to UNLOCK/LOCK direction.
- Power window can be opened as the door key cylinder is kept fully turning to the UNLOCK direction.
- Power window can be closed as the door key cylinder is kept fully turning to the LOCK direction.

The power window opening stops when the following operations are carried out:

• While performing open/close the window, power window is stopped at the position as the door key cylinder is placed on Neutral.

EL-248


NFEL0191S0103

When the ignition switch is turned ON while the power window opening is operated.	
AUTO OPERATION	G
The power window AUTO feature enables the driver to open or close the driver's and passenger's side win- dows without holding the window switch in the down or up position.	GII
The AUTO feature only operates on the driver's and passenger's side windows.	MA
POWER WINDOW LOCK	
The power window lock is designed to lock operation of all windows except for driver's door window. When the lock switch is pressed to lock position, ground of the front and rear power window switches in the power window main switch is disconnected. This prevents the power window motors from operating.	EM
RETAINED POWER OPERATION	LC
When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 sec- onds	EC
to power window relay terminal 2	
 from smart entrance control unit terminal 46. Ground is always supplied 	FE
 to power window relay terminal 1 	
 through body grounds M9, M25 and M87. 	CL
When power and ground are supplied, the power window relay continues to be energized, and the power win-	0Ľ
dow can be operated. The retained power operation is canceled when the driver or passenger side door is opened. RAP signal's period can be changed by CONSULT-II. (Refer to EL-257.)	MT
INTERRUPTION DETECTION FUNCTION	AT
Power window main switch monitors the power window regulator motor operation and the power window position (full closed or other) for driver's and passenger's side power window by the signals from encoder and limit switch in front power window regulator (driver's and passenger's side). When power window main switch detects interruption during the following close operation in the driver's side door,	AX
 automatic close operation when ignition switch is in the "ON" position 	SU
automatic close operation during retained power operation	
manual close operation during retained power operation	BR
power window main switch controls driver's and passenger's side power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in).	
	ST
	RS
	BT
	HA
	SC
	F 1-
	EL


IDX

Schematic


NFEL0103





MEL751P




POWER WINDOW







MEL732P



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	LG	DRIVER DOOR SWITCH	OFF (CLOSED) \rightarrow ON (OPEN)	$12V \rightarrow 0V$
2	R/L	PASSENGER DOOR SWITCH	OFF (CLOSED) \rightarrow ON (OPEN)	$5V \rightarrow 0V$
27	G	IGNITION SWITCH (ON)	IGNITION KEY IS IN "ON" POSITION	12V
33			DOOR LOCK & UNLOCK SWITCHES (NEUTRAL \rightarrow LOCK/UNLOCK) FRONT DOOR KEY CYLINDER SWITCH LH (NEUTRAL \rightarrow LOCK/UNLOCK)	*1
43	В	GROUND	-	-
46	PU	POWER WINDOW RELAY	RETAIND POWER OPERATION IS OPERATED (ON \rightarrow OFF)	$12V \rightarrow 0V$
49	R/B	POWER SOURCE (FUSE)	_	12V
64	В	GROUND	_	-

*1: REFER TO "SMART ENTRANCE CONTROL UNIT INSPECTION TABLE" IN "SMART ENTRANCE CONTROL UNIT".


HA

SC

EL

IDX

CONSULT-II Inspection Procedure



CONSULT-II Application Items

NFEL0236 NFEL0236S01 []

LC

"RETAINED PWR" Data Monitor

		NFEL0236501	01
Moni	tored Item	Description	MA
IGN ON SW		Indicates [ON/OFF] condition of ignition switch.	
DOOR SW-D	R	Indicates [ON/OFF] condition of front door switch LH.	EM
DOOR SW-A	S	Indicates [ON/OFF] condition of front door switch RH.	_

Active Test

Active lest	NFEL0236S0102	2
Test Item	Description	RA
RETAINED PWR	This test is able to supply RAP signal (power) from smart entrance control unit to power window system, power sunroof system and headlamp battery saver control unit. Those systems can be operated when turning on "RETAINED PWR" on CONSULT-II screen even if the ignition switch is tuned OFF.	· EC FE
	During this test, CONSULT-II can be operated with ignition switch in "OFF" position. "RETAINED PWR" should be turned "ON" or "OFF" on CONSULT-II screen when ignition switch is ON. Then turn ignition switch OFF to check retained power operation. CON- SULT-II might be stuck if "RETAINED PWR" is turned "ON" or "OFF" on CONSULT-II screen	CL
	when ignition switch is OFF.	MT.

Work Support

Work Item	Description	- 1731
RETAINED PWR SET	Rap signal's power supply period can be changed by mode setting. Selects rap signal's power supply period between two steps. • MODE 1 (45 sec.)/MODE 2 (OFF)	AX
		SU

NFEL0236S0103

BR


Trouble Diag	gnoses NFEL0105	ST
Possible cause	Repair order	
 1. 10A fuse, 40A fusible link 2. E90 circuit breaker 3. Power window relay 	1. Check 10A fuse [No. 13 located in fuse block (J/B)], 40A fusible link (letter I, located in fuse and fusible link box).	RS
4. E90 circuit breaker circuit	2. Check E90 circuit breaker.	BT
5. Power window relay circuit	3. Check power window relay.	
 Ground circuit Front power window main switch 	a. Check harness between E90 circuit breaker and 40A fusible link (letter I, located in fuse and fusible link	HA
	b. Check harness between E90 circuit breaker and power window main switch.	SC
	a. Check harness between E90 circuit breaker and power window relay.	EL
	 b. Check harness between fuse and power window relay. 6. Check the following. a. Check ground circuit of front power window main switch terminal 5. b. Check power window relay ground circuit. 	IDX
	Possible cause 1. 10A fuse, 40A fusible link 2. E90 circuit breaker 3. Power window relay 4. E90 circuit breaker circuit 5. Power window relay circuit 6. Ground circuit 7. Front power window main	Possible causeRepair order1. 10A fuse, 40A fusible link1. Check 10A fuse [No. 13 located in fuse block (J/B)],2. E90 circuit breaker40A fusible link (letter I, located in fuse and fusible3. Power window relay2. Check E90 circuit breaker.4. E90 circuit breaker circuit3. Check power window relay.5. Power window relay circuit3. Check power window relay.6. Ground circuit3. Check the following.7. Front power window main switch3. Check harness between E90 circuit breaker and 40A fusible link (letter I, located in fuse and fusible link box).b. Check harness between E90 circuit breaker and 40A fusible link (letter I, located in fuse and fusible link box).b. Check harness between E90 circuit breaker and power window main switch.c. Check the following.a. Check harness between E90 circuit breaker and power window relay.b. Check harness between E90 circuit breaker and power window relay.check harness between E90 circuit breaker and power window relay.b. Check harness between E90 circuit breaker and

EL-257

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Driver side power window cannot be operated but other windows can be operated.	 Driver side power window regulator circuit Driver side power window regulator Front power window main switch 	 Check harness between front power window main switch and driver side power window regulator for open or short circuit. Check driver side power window regulator. Check front power window main switch.
One or more power windows except driver's side window cannot be operated.	 Power window switches Power window regulators Power window main switch Power window circuit 	 Check power window switch. Check power window regulator. Check power window main switch. Check the following. Check harness between the rear power window switch (LH and RH) terminal 5 and power window relay terminal 5. Check harnesses between power window main switch and power window switch for open/short circuit. Check harnesses between power window switch and power window switch and power window switch and power window regulator for open/short circuit.
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power win- dow switch.	1. Power window main switch	1. Check front power window main switch.
Driver side power window auto- matic operation does not function properly.	 Front power window main switch Encoder and limit switch 	 Check front power window main switch. Check encoder and limit switch. (EL-259)
Retained power operation does not operate properly.	 RAP signal circuit Driver or passenger side door switch circuit Smart entrance control unit 	 Check RAP signal. (With CONSULT-II) Check RAP signal with CONSULT-II. Use "WORK SUPPORT" mode, "RETAINED PWR" in
Interruption detection function does not operate properly.	1. Encoder and limit switch	1. Check encoder and limit switch. (EL-259)

NOTE: *1 RAP signal's period can be changed by CONSULT-II. (EL-257)



IDX

EL

GO TO 5.

GO TO 4.

►

►


OK


NG


Trouble Diagnoses (Cont'd)

4 RESET LIMIT SWITCH

Reset limit switch. Refer to BT-22, "Front Door Glass Limit Switch Reset". Then check voltage between front power window main switch harness connector D10 terminal 15 (G/W) and ground or front power window switch RH harness connector D42 terminal 16 (G/W) and ground during power window closing operation at least ten times.







BR

NFEL0107

NFEL0107S04

System Description


OPERATION

- The lock/unlock switches (LH and RH) on door trim can lock and unlock all doors.
- With the door key inserted in the key cylinder on front LH, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors. (Signals from door key cylinder switch) Select unlock mode can be changed by CONSULT-II (EL-268).
- If the ignition key is in the ignition key cylinder and one or more of the doors are open, setting the lock/ unlock switch to "LOCK" locks the doors once but then immediately unlocks them. Key reminder door mode can be changed by CONSULT-II (EL-268).


SC


EL

IDX




MEL1760






MEL1770



MEL1780

FIG. 3

SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)	
1	LG	DRIVER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$12V \rightarrow 0V$	
2	R/L	PASSENGER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$	
3	R/W	REAR DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$	
25	I B/B	IGNITION KEY SWITCH (INSERT)	KEY INSERTED \rightarrow KEY REMOVED FROM IGN KEY CYLINDER	$12V \rightarrow 0V$	
33		COMMUNICATION	DOOR LOCK & UNLOCK SWITCHES (NEUTRAL \rightarrow LOCK/UNLOCK)	- *1)	
		INTERFACE	FRONT DOOR KEY CYLINDER SWITCH LH (NEUTRAL \rightarrow LOCK/UNLOCK)		
43	В	GROUND	_	-	
49	R/B	POWER SOURCE (FUSE)	_	12V	
51	W/R	POWER SOURCE (PTC)	_	12V	
54	GY	DOOR LOCK ACTUATORS	DOOR LOCK & UNLOCK SWITCH (FREE \rightarrow LOCK)	$0V \rightarrow 12V$	
55	I W/B	DRIVER DOOR LOCK	DOOR LOCK & UNLOCK SWITCH (FREE → UNLOCK)	$0V \rightarrow 12V$	
	=	ACTUATOR		00 /120	
56 GY		PASSENGER AND REAR	DOOR LOCK & UNLOCK SWITCH (FREE → UNLOCK)	$0V \rightarrow 12V$	
		DOORS LOCK ACTUATOR			
64	В	GROUND	-	-	

*1: REFER TO "SMART ENTRANCE CONTROL UNIT INSPECTION TABLE" IN "SMART ENTRANCE CONTROL UNIT".

	CONSULT-II Inspection Procedure				
Data link connector Steering column	CONSULT-II Inspection Procedure "DOOR LOCK" 1. Turn ignition switch "OFF". 2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to	" G]			
	the data link connector.	MA			
		EM			
SEF289X	3. Turn ignition switch "ON".	LC			
CONSULT- II	4. Touch "START (NISSAN BASED VHCL)".	EC			
		FE			
ENGINE START (NISSAN BASED VHCL) START (RENAULT BASED VHCL)		CL			
SUB MODE LIGHT COPY SKIA3098E		MT			
SELECT SYSTEM ENGINE	5. Touch "SMART ENTRANCE".	AT			
ABS SMART ENTRANCE		AX			
AIR BAG		SU			
		BR			
SEL398Y	6. Touch "DOOR LOCK".	0T			
DOOR LOCK		ST			
REAR DEFOGGER		RS			
KEY WARN ALM					
LIGHT WARN ALM SEAT BELT ALM		BT			
INT LAMP					
SEL023X		HA			
	7. Select diagnosis mode.	SC			
SELECT DIAG MODE DATA MONITOR	"DATA MONITOR", "ACTIVE TEST" and "WORK SUPPORT" are available.	,			
ACTIVE TEST		EL			
WORK SUPPORT					
		IDX			
SEL274W					
SLL2/4W					

CONSULT-II Application Items

"DOOR LOCK" Data Monitor

NFEL0239S01

Monitored Item	Description
KEY ON SW	Indicates [ON/OFF] condition of key switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
DOOR SW-RR	Indicates [ON/OFF] condition of door switch (Rear).
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from key cylinder.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from key cylinder.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

Active Test

NFEL0239S0102


Test Item	Description
ALL D/LK MTR	This test is able to check all door lock actuators lock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
DR D/UN MTR	This test is able to check front door lock actuator LH unlock operation. The actuator unlocks when "ON" on CONSULT-II screen is touched.
NON DR D/UN	This test is able to check door lock actuators (except front door lock actuator LH) unlock operation. These actuators unlock when "ON" on CONSULT-II screen is touched.


Work Support

	NFEL0239S0103
Work Item	Description
DOOR LOCK-UNLOCK SET	Select unlock mode can be changed in this mode. Selects ON-OFF of select unlock mode.
ANTI-LOCK OUT SET	Key reminder door mode can be changed in this mode. Selects ON-OFF of key reminder door mode.

Trouble Diagnoses

		Diagno: M CHART				=NFEL0193 NFEL0193S01	GI
REFERENCE PAGE (EL-)	269	270	271	273	274	275	
	MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK				HECK		M/ EN
	OUND CIF			CHECK	SWITCH CHECK	×	LC
SYMPTOM	AND GR		CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	INDER	DOOR LOCK ACTUATOR CHECK	EC
	SUPPLY	DOOR SWITCH CHECK	SWITCH (INSERT) CHECK	NLOCK	FRONT DOOR KEY CYLINDER	стиато	FE
	OWER (SWITCH	итсн (I	LOCK/U	DOOR	LOCK A	CL
	MAIN F	DOOR	KEY SV	DOOR	FRONT	DOOR	M٦
Key reminder door system does not operate properly.	х	x	х			Х	AT
Specific door lock actuator does not operate.	Х					Х	\wedge
Power door lock does not operate with door lock and unlock switch (LH and RH) on door trim.	х			X			AX
Power door lock does not operate with front door key cylinder operation.	х				х		SU





MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK Main Power Supply Circuit Check NFEL0193S0201

NFEL0193S0202

			10 22010000201		
Terminals		Ignition switch			
()	OFF	ACC	ON	RS	
Cround	Battery volt-	Battery volt-	Battery volt-	BT	
Giouna	age	age	age		
1		(-) OFF Ground Battery volt-	(-) OFF ACC Ground Battery volt- Battery volt-	Ignition switch (-) OFF ACC ON Ground Battery volt- Battery volt- Battery volt-	

HA

SC

BR

ST


Ground Circuit Check

_

Terminals	Continuity	
43 - Ground	Yes	EL
64 - Ground	Yes	
		IDX

EL-269

DOOR SWITCH CHECK



EL-270

KEY SWITCH (INSERT) CHECK



1 CHECK KEY SWITC	H INPUT SIGNAL			GI
With CONSULT-II Chask key switch (#KEX ON 6				
Check key switch ("KEY ON S		dae with CONSULI-II.		M
	MONITOR KEY ON SW ON	When key is inserted to ignition key cylinder:		E
		KEY ON SW ON When key is removed from ignition key cylinder:		L(
		KEY ON SW OFF		E(
🛞 Without CONSULT-II			SEL315W	FE
Smart entrance control	t entrance control unit harnes	s connector M144 terminal 25 (B/R) and ground.		C[
		Voltage [V]:		M
	C Approx 12V 0V	Condition of key switch: Key is removed.		Aī
		0		AD
Refer to wiring diagram in EL			SEL011Y	SI
		K or NG		
OK NG	 Key switch is OK. GO TO 2. 			B
-				@=
				SI
				R


BT

HA

SC


EL

IDX



EL-272

DOOR LOCK/UNLOCK SWITCH CHECK




SC

EL

IDX

FRONT DOOR KEY CYLINDER SWITCH CHECK




Trouble Diagnoses (Cont'd)

2	2 CHECK DOOR KEY CYLINDER SWITCH					
1. Disconnect door key cylinder switch harness connector. G 2. Check continuity between door key cylinder switch terminals. G					GI	
Door key cylinder switch connector connector Connec			MA EM			
			Terminals ③ - ②	Key position Neutral/Unlock Lock Neutral/Lock	Continuity No Yes No	LC
				Unlock	Yes SEL034X	EC
			OK or NG		000.00	
ОК		Check the following.				FE
		 Door key cylinder s Harness for open of inder switch If above systems are n 	r short between front		switch and door key cyl- ain switch.	CL
NG	►	Replace door key cylir	nder switch.			MT
DOOR LOCK ACTUATOR CHECK					AT	
					1-7.11	
1. Sel 2. Sel	2. Select "ALL D/LK MTR" and touch "ON".				AX	
	en, select "DR D/UN MTR' ect "NON DR D/UN" and t	ouch "ON".				SU
	ALL D/LK M	IVE TEST ITR OFF				BR
	(DR D/UN (NON DR I		Door lock	motor should opera	ate.	ST
						RS
NOTE	ON SEL343W				BT	
If CONSULT-II is not available, skip this procedure and go to the next step.						
	~	Deers la classica de la c	OK or NG			HA
OK NG				SC		
		00102.				

EL

IDX




 OK or NG

 OK

 Check harness for open or short between smart entrance control unit connector and door lock actuator.

 NG



to smart entrance control unit terminal 2

EL-277

System Description (Cont'd)

- through front door switch RH terminal 2, and
- to front door switch RH terminal 3
- through body grounds B106 and B127.

When the rear door switches are ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 3
- through rear door switches terminal 1
- to rear door switches case grounds.

When door lock/unlock switch of front power window main switch is LOCK/UNLOCK, ground is supplied

- to smart entrance control unit terminal 33
- through front power window main switch terminals 8 and 5, and
- through body grounds M9, M25 and M87.

Keyfob signal is inputted to smart entrance control unit (The antenna of the system is combined with smart entrance control unit).

The remote keyless entry system controls operation of the

- power door lock
- auto door lock
- trunk lid opener
- interior lamp
- panic alarm
- hazard and horn reminder
- power window opener

OPERATED PROCEDURE

Power Door Lock Operation

Smart entrance control unit receives a LOCK signal from keyfob. Smart entrance control unit locks all doors with input of LOCK signal from keyfob.

When an UNLOCK signal is sent from keyfob once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from keyfob again within 5 seconds, all other door will be unlocked. Select unlock mode can be changed by CONSULT-II (EL-288).

Auto Door Lock Operation

Auto lock function signal is sent for operation when any of the following signals are not sent within 5 minutes after the unlock signal is sent from the keyfob:

- when door switch is turned ON for open.
- when the ignition switch is turned ON.
- when the lock signal is sent from the keyfob.

Auto door lock mode can be changed by CONSULT-II (EL-288).

Hazard and Horn Reminder

Power is supplied at all times

- to vehicle security horn relay-1 terminals 1 and 3, and
- to vehicle security horn relay-2 terminal 1
- through 10A fuse (No. 61, located in the fusible link and fuse box), and
- to horn relay terminal 2
- through 10A fuse (No. 57, located in the fusible link and fuse box)

When smart entrance control unit receives LOCK or UNLOCK signal from keyfob with all doors closed, ground is supplied

- to vehicle security horn relay-2 terminal 2
- through smart entrance control unit terminal 42

Vehicle security horn relay-2 is then energized

- to horn relay terminal 1, and
- to vehicle security horn relay-1 terminal 2
- through vehicle security horn relay-2 terminals 5 and 3, and
- through body ground E11, E22 and E53

EL-278

NFEL0194S0202

NFEL0194S02

System Description (Cont'd)

to smart entrance control unit terminals 47 and 48 from hazard warning lamp system.

Vehicle security horn relay-1 and horn relay are now energized, and hazard warning lamp flashes and horn sounds as a reminder.

The hazard and horn reminder has six steps.

Operating function of hazard and horn reminder

	Lock		Unlock		UVU2~3
	Hazard warning lamp flash	Horn sound	Hazard warning lamp flash	Horn sound	EM
C MODE	Twice	Once	Once	—	- LC
S MODE	Twice	—	—	—	
MODE 3	—	_	—	_	. EC
MODE 4	Twice	_	Once	_	
MODE 5	Twice	Once	_	_	FE
MODE 6	—	Once	Once	—	


How to change hazard and horn reminder mode

With CONSULT-II

Hazard and horn reminder can be changed by CONSULT-II (EL-288).

🛞 Without CONSULT-II

When LOCK and UNLOCK signals are sent from the keyfob for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp flashes and horn sounds as follows:



NOTE:

Reminder mode setting cannot be changed without CONSULT-II for MODES 3,4, 5, and 6. However, C and S MODES can be changed without CONSULT-II. \mathbb{R}

Interior Lamp Operation

When the following input signals are both supplied:

- door switch CLOSED (when all the doors are closed);
- driver's door LOCKED;

remote keyless entry system turns on interior lamp and key hole illumination (for 30 seconds) with input of UNLOCK signal from keyfob.

For detailed description, refer to "INTERIOR, STEP, SPOT, VANITY MIRROR AND TRUNK ROOM LAMPS" SC (EL-92).

Panic Alarm Operation

When key switch is OFF (when ignition key is not inserted in key cylinder), remote keyless entry system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from keyfob.

The alarm automatically turns off after 25 seconds or when smart entrance control unit receives any signal from keyfob.

For detailed description, refer to "VEHICLE SECURITY SYSTEM" (EL-312).

The panic alarm button's pressing time on keyfob can be changed by CONSULT-II (EL-288).

CL

MA

MT

NFEL0194S0203

BT

EL

System Description (Cont'd)

Trunk Lid Opener Operation

Power is supplied at all times

- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to trunk lid opener actuator terminal 2.

When a TRUNK OPEN signal is sent with key OFF (ignition key removed from key cylinder) from keyfob, ground is supplied

- to trunk lid opener actuator terminal 1
- through smart entrance control unit terminal 63.

Then power and ground are supplied, trunk lid opener actuator opens trunk lid.

The trunk lid opener button's pressing time on keyfob can be changed by CONSULT-II (EL-288).

Power Window Opener Operation

The front power windows open when the unlock button on keyfob is activated and kept pressed for more than 3 seconds with the ignition key OFF. The windows keep opening if the unlock button is continuously pressed. The power window opening stops when the following operations are carried out:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.


The unlock button's pressing time can be changed by CONSULT-II (EL-288).


Door Lock/Unlock and front power window down signal is supplied

- through smart entrance control unit terminal 33
- to front power window main switch terminal 8 and
- to front power window switch RH terminal 11.


NFEL0194S0205








MEL180O




MEL752P


Wiring Diagram — KEYLES — (Cont'd)

FIG. 3






SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	LG	DRIVER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$12V \rightarrow 0V$
2	R/L	PASSENGER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$
3	R/W	REAR DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$	$5V \rightarrow 0V$
			IGNITION SWITCH ON OR START MORE THAN 5 MINUTES	12V
21	OR	HEADLAMP LH RELAY	(WITH LIGHTING \rightarrow OFF WITHIN 5 MINUTES	0V
21			SWITCH 2ND) ON OR START	0V
			HEADLAMPS ILLUMINATE BY AUTO LIGHT CONTROL	0V
25	B/R	IGNITION KEY SWITCH (INSERT)	KEY INSERTED \rightarrow KEY REMOVED FROM IGN KEY CYLINDER	12V → 0V
26	PU	IGNITION SWITCH (ACC)	"ACC" POSITION	12V
27	G	IGNITION SWITCH (ON)	IGNITION SWITCH IS IN "ON" POSITION	12V
30	I B/Y	IGNITION KEYHOLE	WHEN DOORS ARE UNLOCKED USING KEYFOB (OFF $ ightarrow$ UNLOCK)	12V→ 0V
31	R	INTERIOR LAMP	WHEN DOORS ARE LOCKED USING KEYFOB (UNLOCK \rightarrow LOCK WITH LAMP SWITCH IN "DOOR" POSITION)	0V → 12V
33	COMMUNICATION	DOOR LOCK & UNLOCK SWITCHES (NEUTRAL \rightarrow LOCK/UNLOCK)	*1	
		INTERFACE	FRONT DOOR KEY CYLINDER SWITCH LH (NEUTRAL $ ightarrow$ LOCK/UNLOCK)	
42	BR/Y	VEHICLE SECURITY HORN RELAY	WHEN PANIC ALARM IS OPERATED USING KEYFOB (ON \rightarrow OFF)	12V → 0V
43	В	GROUND	-	_
47	GY/L	LH TURN SIGNAL LAMP	WHEN DOOR LOCK OR UNLOCK IS OPERATED USING KEYFOB (ON \rightarrow OFF)	12V → 0V
48	GY/R	RH TURN SIGNAL LAMP	WHEN DOOR LOCK OR UNLOCK IS OPERATED USING KEYFOB (ON \rightarrow OFF)	$12V \rightarrow 0V$
49	R/B	POWER SOURCE (FUSE)	-	12V
50	R/G	BATTERY SAVER (INTERIOR LAMP)	BATTERY SAVER DOSE OPERATE \rightarrow DOES NOT OPERATE (ON \rightarrow OFF)	12V → 0V
51	W/R	POWER SOURCE (PTC)	-	12V
54	GY	DOOR LOCK ACTUATORS	DOOR LOCK & UNLOCK SWITCH (FREE → LOCK)	$0V \rightarrow 12V$
55	W/B	DRIVER DOOR LOCK ACTUATORS	DOOR LOCK & UNLOCK SWITCH (FREE \rightarrow UNLOCK)	$0V \rightarrow 12V$
56	GY	PASSENGER AND REAR DOORS LOCK ACTUATOR	DOOR LOCK & UNLOCK SWITCH (FREE \rightarrow UNLOCK)	0V → 12V
			IGNITION SWITCH ON OR START MORE THAN 5 MINUTES	12V
59	Р	HEADLAMP RH RELAY	(WITH LIGHTING \rightarrow OFF WITHIN 5 MINUTES	0V
29			SWITCH 2ND) ON OR START	0V
			HEADLAMPS ILLUMINATE BY AUTO LIGHT CONTROL (OPERATE → NOT OPERATE)	LESS THAN 1V→12V
63	L	TRUNK LID OPENER ACTUATOR	WHEN TRUNK LID OPENER ACTUATOR IS OPERATED USING KEYFOB (ON \rightarrow OFF)	$0V \rightarrow 12V$

*1: REFER TO "SMART ENTRANCE CONTROL UNIT INSPECTION TABLE" IN "SMART ENTRANCE CONTROL UNIT".



CONSULT-II Application Items

"MULTI REMOTE ENT" Data Monitor

NFEL0242

NFEL0242S01

NFEL0242S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.
PANIC BTN	Indicates [ON/OFF] condition of panic signal from keyfob.
UN BUTTON ON	Indicates [ON/OFF] condition of unlock switch form keyfob.
LK/UN BTN ON	Indicates [ON/OFF] condition of lock/unlock signal at the same time from keyfob.

Active Test

Test Item	Description
INT/IGN ILLUM	This test is able to check interior lamp and ignition key hole illumination operation. The interior lamp and ignition key hole illumination are turned on when "ON" on CONSULT-II screen is touched.
HAZARD	This test is able to check hazard reminder operation. The hazard lamp turns on when "ON" on CONSULT-II screen is touched.
TRUNK OUTPUT	This test is able to check trunk lid opener actuator operation. The trunk is unlocked when "ON" on CONSULT-II screen is touched.
HORN	This test is able to check panic alarm and horn reminder operations. The alarm activate for 0.5 seconds after "ON" on CONSULT-II screen is touched.
HEAD LAMP	This test is able to check headlamps panic alarm operation. The headlamp illuminates for 0.5 seconds after "ON" on CONSULT-II screen is touched.
PW REMOTE DOWN SET	This test is able to check power window open operation. The front power windows activate for 10 seconds after "ON" on CONSULT-II screen is touched.

Work Support

	NFEL0242S0103
Test Item	Description
REMO CONT ID CONFIR	It can be checked whether keyfob ID code is registered or not in this mode.
REMO CONT ID REGIST	Keyfob ID code can be registered.
REMO CONT ID ERASUR	Keyfob ID code can be erased.
MULTI ANSWER BACK SET	Hazard and horn reminder mode can be changed with this mode. Selects hazard and horn reminder mode among six steps (EL-278).

CONSULT-II Application Items (Cont'd)

Test Item	Description	
AUTO LOCK SET	Auto door lock mode can be selected among the following periods: • MODE 1 (5 min.)/MODE 2 (OFF-Mode)/MODE 3 (1 min.)	GI
PANIC ALARM SET	The panic alarm button's pressing time on keyfob can be selected among the following periods: • MODE 1 (0.5 sec.)/MODE 2 (OFF-Mode)/MODE 3 (1.5 sec.)	MA
TRUNK OPENER	The trunk lid opener button's pressing time on keyfob can be selected among the following peri- ods: • MODE 1 (0.5 sec.)/MODE 2 (OFF-Mode)/MODE 3 (1.5 sec.)	EM
PW DOWN SET	The unlock button's pressing time on keyfob can be selected among the following periods: • MODE 1 (3 sec.)/MODE 2 (OFF-Mode)/MODE 3 (5 sec.)	LC

EC

FE

CL

MT

AT

AX

SU

NFEL0195

NFEL0195S01

Trouble Diagnoses SYMPTOM CHART NOTE: Always check keyfob battery before replacing keyfob.

The panic alarm operation and trunk lid opener operation of keyfob system do not activate with the ignition key inserted in the ignition key cylinder.

Symptom	Diagnoses/service procedure	Reference page (EL-)	BR
All function of remote keyless entry system do not	1. Keyfob battery and function check	291	
operate.	2. Power supply and ground circuit for smart entrance control unit check	292	ST
	3. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	303	RS
The new ID of keyfob cannot be entered.	1. Keyfob battery and function check	291	BT
	2. Key switch (insert) check	295	
	3. Door switch check	294	HA
	4. Door lock/unlock switch LH check	296	. SC
	5. Power supply and ground circuit for smart entrance control unit check	292	
	6. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	303	EL
Door lock or unlock does not function.	1. Keyfob battery and function check	291	. IDA
(If the power door lock system does not operate manually, check power door lock system. Refer to EL-269)	2. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	303	

•

•

Trouble Diagnoses (Cont'd)

Symptom	Diagnoses/service procedure	Reference page (EL-)
Hazard and horn reminder does not activate prop-	1. Keyfob battery and function check	291
erly when pressing lock or unlock button of key- fob.	2. Hazard reminder check	298
	 Horn reminder check* Horn chirp can be activated or deactivated. First check the horn chirp setting. Refer to "System Description", EL-277. 	299
	4. Door switch check	294
	5. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	303
Interior lamp and key hole illumination operation	1. Interior lamp operation check	301
do not activate properly.	2. Key hole illumination operation check	302
	3. Door switch check	294
Panic alarm (horn and headlamp) does not acti-	1. Keyfob battery and function check	291
vate when panic alarm button is continuously pressed.	2. Theft warning operation check. Refer to "PRELIMINARY CHECK" in "VEHICLE SECURITY SYSTEM".	324
	3. Key switch (insert) check	295
	 Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning. 	303
Trunk lid does not open when trunk opener button	1. Keyfob battery and function check	
is continuously pressed.	2. Trunk lid opener actuator check	297
	3. Key switch (insert) check	295
	4. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	303

Trouble Diagnoses (Cont'd)

KEYFOB BATTERY AND FUNCTION CHECK

NG Replace battery. 2 CHECK KEYFOB FUNCTION ③ With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" and	
Voltage [V]: 2.5 - 3.0 NOTE: Keyfob does not function if battery is not set correctly. Image: Stamped (+) SEL237 OK or NG OK GO TO 2. NG Replace battery. 2 CHECK KEYFOB FUNCTION Image: With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. Image: Monitor item should be turned as follows. Condition Monitor item should be turned as follows.	CHECK KEYFOE
SEL237 OK GO TO 2. NG ▶ Replace battery. 2 CHECK KEYFOB FUNCTION ③ With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. Data MONITOR When pushing each button of keyfob, the corresponding monitor item should be turned as follows.	age [V]: 5 - 3.0
SEL237 OK or NG OK GO TO 2. NG Replace battery. 2 CHECK KEYFOB FUNCTION Image: Select transmission of the select transmission of transmission of transmission of the select transmission of the select transmission of transmissi	
OK or NG GO TO 2. NG ▶ Replace battery. 2 CHECK KEYFOB FUNCTION ③ With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. DATA MONITOR When pushing each button of keyfob, the corresponding monitor item should be turned as follows. INSULT ONISTIC Condition	
OK ► GO TO 2. NG ► Replace battery. 2 CHECK KEYFOB FUNCTION ③ With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. DATA MONITOR When pushing each button of keyfob, the corresponding monitor item should be turned as follows. UK BUTTON/SIG ON	
NG ▶ Replace battery. 2 CHECK KEYFOB FUNCTION ③ With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. DATA MONITOR When pushing each button of keyfob, the corresponding monitor item should be turned as follows. LK BUTTON/SIG ON	
2 CHECK KEYFOB FUNCTION With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. DATA MONITOR When pushing each button of keyfob, the corresponding monitor item should be turned as follows. LK BUTTON/SIG ON	
With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" an "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. DATA MONITOR When pushing each button of keyfob, the corresponding monitor item should be turned as follows. Condition Monitor item	
MONITOR Condition Monitor item	CONSULT-II keyfob function ("L BTN ON") in "DAT
	MONITOR
	LK BUTTON/SIG
UN BUTTON/SIG ON Pushing UNLOCK UN BUTTON/SIG ON	UN BUTTON/SIG
TRUNK BTN/SIG ON Pushing TRUNK TRUNK BTN/SIG ON	TRUNK BTN/SIG
PANIC BTN ON Pushing PANIC PANIC BTN/SIG ON	PANIC BTN
at the same time	
LK/UN BTN ON ON SEL42	LK/UN BIN ON
OK or NG	

 OK or NG

 OK
 Keyfob is OK. Further inspection is necessary. Refer to "SYMPTOM CHART", EL-289.


 NG
 Replace keyfob. Refer to ID Code Entry Procedure.

HA

SC

EL

POWER SUPPLY AND GROUND CIRCUIT CHECK



ОК	►	GO TO 3.
NG		 Check the following. 10A fuse [No. 1, located in fuse block (J/B)] Harness for open or short between smart entrance control unit and fuse

Trouble Diagnoses (Cont'd)

3	CHECK GROUND CIRC	UIT FOR SMART ENTRANCE CONTROL UNIT	
Check and gr		entrance control unit harness connector M144 terminal 4	3 (B) or M145 terminal 64 (B)
	Smart entrance c	ontrol unit connector	
			ity should exist.
			LG
Refer	to wiring diagram in EL-28	· · · · · · · ·	SEL020Y
Relet	to winny diagram in EE-20	OK or NG	FE
ОК	•	Power supply and ground circuits are OK.	
NG	►	Check ground harness.	CL
			TM
			AT
			AX
			SU
			BR
			ST

EL

RS

BT

HA

SC

IDX

DOOR SWITCH CHECK

=NFEL0195S04

1 CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT-II


Check door switches ("DOOR SW-RR", "DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CON-SULT-II.

DATA MON	NITOR				
MONITOR					1
DOOR SW-RR	OFF		Monitor item	Condition	Condition
DOON SW-NN	UFF	DOOR SW-RR	Rear doors switch	Open	ON
DOOR SW-DR	OFF	DOOR SW-RR	Rear doors switch	Closed	OFF
DOOR SW-AS	OFF		Door switch LH	Open	ON
	0.1	DOOR SW-DR		Closed	OFF
			Deer switch DU	Open	ON
		DOOR SW-AS	Door switch RH	Closed	OFF

SEL024Y

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M143 terminals 1 (LG), 2 (R/L) or 3 (R/W) and ground.



2 CHECK DOOR SWITCH

- 1. Disconnect door switch harness connector.
- 2. Check continuity between door switch terminals.

Door switch connector Front LH : 200	Door switch connector Rear LH : 1810	治 T.S.				
	Rear RH : 🖲 🕅			Terminals	Condition	Continuity
	_		Front door	2 - 3	Closed	No
	[]		switches	2 0	Open	Yes
			Rear door	1 - Ground	Closed	No
			switches		Open	Yes
		L OK or NC	3			SEL192W
ок 🕨	 Check the following Door switch ground Harness for open of 	d circuit or o			nit and door	switch
NG	Replace door switch.					

EL-294

1

CHECK KEY SWITCH INPUT SIGNAL


Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERT) CHECK




DATA MONITOR MONITOR When key is inserted to KEY ON SW ON ignition key cylinder: **KEY ON SW ON** LC When key is removed from ignition key cylinder: **KEY ON SW OFF** EC SEL315W FE **Without CONSULT-II** Check voltage between control unit harness connector M144 terminal 25 (B/R) and ground. Refer to wiring diagram in EL-282. GL Smart entrance control unit connector MT Voltage [V]: Condition of key switch : Key is inserted. AT Approx. 12 Condition of key switch : Key is removed. 0 AX SEL022Y SU OK or NG OK Key switch is OK. ► NG GO TO 2. ►



EL-295

DOOR LOCK/UNLOCK SWITCH LH CHECK




Trouble Diagnoses (Cont'd)

TRUNK LID OPENER ACTUATOR CHECK =NFEL0195S12 1 CHECK TRUNK LID OPENER GI Check trunk lid opener operation with trunk lid opener switch. NOTE: First check trunk lid opener cancel lever position. MA Does trunk lid open? Yes GO TO 2. EM No Check trunk lid opener actuator and the circuit. LC CHECK TRUNK LID OPENER ACTUATOR OPERATION 2 (P) With CONSULT-II 1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. EC 2. Select "TRUNK OUTPUT" and touch "ON". ACTIVE TEST FE TRUNK OUTPUT OFF GL Trunk lid opener should operate. MT ON AT SEL345W NOTE: If CONSULT-II is not available, skip this procedure and go to the next step. AX OK or NG OK ► Trunk lid opener actuator circuit is OK. NG ► Check harness for open or short between smart entrance control unit and trunk lid opener actuator. CHECK TRUNK LID OPENER ACTUATOR CIRCUIT 3 **Without CONSULT-II** 1. Disconnect smart entrance control unit harness connector. 2. Apply ground to smart entrance control unit harness connector M145 terminal 63 (L). Smart entrance control unit connector BT HA SC SEL026Y Refer to wiring diagram in EL-285. EL Does trunk lid open? Yes Replace smart entrance control unit. ► IDX No ► Check harness for open or short between smart entrance control unit and trunk lid opener actuator.

HAZARD REMINDER CHECK

			=NFEL0195S08
1	CHECK HAZARD INDIC	CATOR	
Check	if hazard indicator flashes	with hazard switch.	
		Does hazard indicator operate?	
Yes		GO TO 2.	
No	►	Check "hazard indicator" circuit.	



3	CHECK HAZARD REMI	INDER OPERATIO	N WITHOUT CONSULT-II		
	/ithout CONSULT-II k voltage between smart en	trance control unit h	narness connector M144 terminal 47 (GY/L) or 48 (GY/	R) and ground.
	Smart entrance unit connector	e control			
		H.S.	Condition of lock or unlock button	Voltage (V)	
			Push.	Approx. 0 - 12	
			Do not push.	0	
Refe	r to wiring diagram in EL-28	5.			SEL592Y
			OK or NG		
OK		System is OK.			
NG	►	Replace smart entr	rance control unit.		

Trouble Diagnoses (Cont'd)


		HORN REMINDER CHECK	509
1	CHECK HORN		GI
Check	if horn sounds with horn s	switch.	
		Does horn operate?	MA
Yes		GO TO 2.	
No		Check horn circuit.	EM
			7
2	th CONSULT-II	DER OPERATION WITH CONSULT-II	LC
1. Sel		JLTI REMOTE ENT" with CONSULT-II. N".	EC
	HORN	ACTIVE TEST OFF	
		Urr -	FE
		Horn should sound.	GL
			MT
	ON	SEL451Y	
NOTE	: If CONSULT-II is not av	ailable, skip this procedure and go to the next step.	AT
		OK or NG	
ОК	►	Horn reminder operation is OK.	
NG	•	GO TO 4.	l _{su}
3		DER OPERATION WITHOUT CONSULT-II	
	thout CONSULT-II		BR
1. Dis	connect smart entrance co	ontrol unit harness connector.	
2. Ap	ply ground to smart entran	ce control unit harness connector M144 terminal 42 (BR/Y).	ST
		Smart entrance control unit connector	
			RS
			BT
			HA
		₩ SEL028Y	
Re	fer to wiring diagram in EL		SC
		Does horn sound?	
Yes	•	Replace smart entrance control unit.	EL
No		GO TO 4.	

IDX

Trouble Diagnoses (Cont'd)

CHECK VEHICLE SECURITY HORN RELAY-2				
Check vehicle security horn relay-2.				
OK or NG				
	GO TO 5.			
NG Replace vehicle security horn relay-2.				
	ehicle security horn relay			


5	CHECK POWER SUPP	LY FOR VEHICLE SECURITY HORN RELAY-2	
		orn relay-2 harness connector. le security horn relay-2 harness connector E63 terminal 1 (G/R) and ground.	
		Vehicle security horn relay-2	
			SEL031Y
		Does battery voltage exist?	
Yes	►	GO TO 6.	
No	►	 Check the following. 10A fuse (No. 61, located in the fuse and fusible link box) Harness for open or short between vehicle security horn relay-2 and fuse 	



INTERIOR LAMP OPERATION CHECK =NFEL0195S10 1 CHECK INTERIOR LAMP GI Check if the interior lamp switch is in the "ON" position and the lamp illuminates. Does interior lamp illuminate? MA GO TO 2. Yes No Check the following. • Harness for open or short between smart entrance control unit and interior lamp Interior lamp LC 2 CHECK INTERIOR LAMP OPERATION With CONSULT-II EC

- 1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II.
- 2. Select "INT/IGN ILLUM" and touch "ON".

2. Select "INT/IGN I	ILLUIVI" and touc	n "ON".	
	ACTIVE TES	ST	
	IN T/IGN ILLUM	OFF	
			Interior lamp should illuminate.
			·
	ON		
			SEL349W
Without CONSU			
			osed and driver's door locked, and check voltage between smart entrance
control unit harness	connector M144	terminal	31 (R) and ground.
Sn	nart entrance cont	rol	



IDX

FE

CL

MT

AT

AX


SU

KEY HOLE ILLUMINATION OPERATION CHECK

NFEL0195S13

1	CHECK KEY HOLE ILLU	
() 1. Se	/ith CONSULT-II	_TI REMOTE ENT" with CONSULT-II.
	ACTIV IN T/IGN ILLU	E TEST M OFF Key hole illuminate should illuminate.
	ON	SEL350W
Push contr	ol unit harness connector M1- Smart entrance control unit connector	all doors closed and driver's door locked, and check voltage between smart entrance 44 terminal 30 (R/Y) and ground. Voltage [V]: Unlock button is pushed. 0 (For approx. 30 seconds) Unlock button is not pushed. Battery voltage
Refe	r to wiring diagram in EL-284.	OK or NG
ОК	► S	System is OK.
NG		 Check the following. Harness for open or short between smart entrance control unit and key hole illumination. Key hole illumination

ID Code Entry Procedure



SELECT DIAG MODE

DATA MONITOR			
ACTIVE TEST			
WORK SUPPORT			
	SEL274W		
		8.	The
SELECT WORK ITEM			"REI
REMO CONT ID CONFIR		•	Use
REMO CONT ID REGIST			not.
REMO CONT ID ERASUR		•	"REI
MULTI ANSWER BACK SET		NOT	Use
AUTO LOCK SET		NO1 Reg	∣E: ∣istei
PANIC ALARM SET			is r
		•	"REI
	SEL424Y		Use

7. Touch "WORK SUPPORT".

- 8. The items are shown on the figure at left can be set up.
- "REMO CONT ID CONFIR" Use this mode to confirm if a keyfob ID code is registered or not
- "REMO CONT ID REGIST" Use this mode to register a keyfob ID code.

Register the ID code when keyfob or smart entrance control unit is replaced, or when additional keyfob is required.

"REMO CONT ID ERASUR"

Use this mode to erase a keyfob ID code.

Refer to the EL-288 "Work Support" in "CONSULT-II Application Items" for the following items.

- "MULTI ANSWER BACK SET"
- "AUTO LOCK SET"
- "PANIC ALARM SET"
- "TRUNK OPENER"
- "PW DOWN SET"

KEYFOB ID SET UP WITHOUT CONSULT-II

		G
Close all doors.		GII
		MA
(Hazard warning lamps winner NOTE		EM
	ely from ignition key cylinder each time. ned too fast, system will not enter registration mode.	LC
		PA
Insert key into ignition ke	y cylinder and turn to ACC position.	EC
	•	FE
	b once. (Hazard warning lamp will then flash twice.) ID code is erased and the new ID code is entered.	CL
		0/052
	additional keyfob ID codes? es can be entered. If more than four ID codes are entered, the	MT
oldest ID code will be e		AT
	Tes	0.57
	ADDITIONAL ID CODE ENTRY Unlock the door, then lock again with lock/unlock switch LH (in power	AX
	window main switch). NOTE Operate this procedure even if the door is in the state of the un-	SU
	lock.	BR
	Push any button on keyfob once. (Hazard warning lamp will then flash twice.)	 ST
	At this time, The oldest ID code is erased and the new ID code is entered.	RS
		_
N	▼ A maximum four ID codes can be entered. If more than four ID	BT
■ No	codes are entered, the oldest ID code will be erased. Do you want to enter any additional keyfob ID codes?	HA
	Yes	
	ADDITIONAL ID CODE ENTRY	SC
	Unlock the door, then lock again with lock/unlock switch LH (in power window main switch).	EL
		I⊡∾
Open driver side door. (E After entering ID code, e	ND) check operation of remote keyless entry system.	IDX

NOTE:


 If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost keyfob is not known, all keyfob ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfobs must be re-registered.

To erase all ID codes in memory, register one ID code (keyfob) four times. After all ID codes are erased, the ID codes of all remaining and/or new keyfobs must be re-registered.


- When registering an additional keyfob, the existing ID codes in memory may or may not be erased. If four ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than four ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new keyfobs, repeat the procedure "Additional ID code entry" for each new keyfob.
- Entry of maximum four ID codes is allowed. When more than four ID codes are entered, the oldest ID code will be erased.
- Even if same ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

Keyfob Battery Replacement

Keyfob Battery Replacement



Component Parts and Harness Connector Location



System Description

	System Description	NFEL0263	
DESCRIPTION 1. Operation Flow		NFEL0263S01	GI
-	SECURITY indicator lamp output	NFEL0263S0101	
SYSTEM phase			MA
	→ ← ¹³ OFF ·· → ← − − → ← − − → ← − − → ← → ←	T3 = 0.2 sec T4 = 2.4 sec	EM
PRE-ARMED	ON	T2 = 30 sec	LC
			EC
ARMED	$\begin{array}{c} ON \\ \hline \\ \hline \\ \hline \\ OFF \\ \hline \\$	T3 = 0.2 sec T4 = 2.4 sec	FE
	ON		
ALARM	OFF		CL
		SEL334W	MT
2. Setting The Vehicle Securit	ty System	NFEL0263S0102	AT
1) Ignition switch is in OFF positi	on.		AX
onds.	is in the disarmed phase, the security indicator lamp bl	inks every 2.6 sec-	SU
	or 2) is performed, the vehicle security system turns ir	nto the "pre-armed"	
	p illuminates.) ceives LOCK signal from key cylinder switch or keyfob a	after hood, trunk lid	BR
and all doors are closed.2) Hood trunk lid and all doors a	re closed after front doors are locked by key, lock/unloo	k switch or keyfob	ST
-	em automatically shifts into the "armed" phase (the s	-	
3. Canceling The Set Vehicle	· · ·		RS
When the following 1) or 2) operat 1) Unlock the doors with the key	ion is performed, the armed phase is canceled. or keyfob.	NFEL0263S0103	BT
2) Open the trunk lid with the key	ation of The Vehicle Security System		HA
Make sure the system is in the arr	ned phase. (The security indicator lamp blinks every 2. 2) is performed, the system sounds the horns and flas		SC
	door is opened during armed phase.		
,	the battery connector before canceling armed phase.		EL
POWER SUPPLY AND GROU Power is supplied at all times	NU	NFEL0263S02	IDX
 through 10A fuse [No. 12, loca to security indicator lamp term 			
Power is supplied at all timesthrough 10A fuse [No. 13, local			
	EL-309		

System Description (Cont'd)

to smart entrance control unit terminal 49.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.
- With the ignition switch in the ACC or ON position, power is supplied
- through 10A fuse [No. 1, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M9, M25 and M87.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the vehicle security system is controlled by the doors, hood and trunk lid.

Pattern A

To activate the vehicle security system, the smart entrance control unit must receive signals indicating the doors, hood and trunk lid are closed.

When a door is open, smart entrance control unit terminal 1, 2 or 3 receives a ground signal from each door switch.

When the hood is open, smart entrance control unit terminal 6 receives a ground signal

- from terminal 1 of the hood switch
- through body grounds E11, E22 and E53.

When the trunk lid is open, smart entrance control unit terminal 13 receives a ground signal

- from terminal 1 of the trunk room lamp switch
- through body grounds T6 and T8.

When smart entrance control unit receives LOCK signal from key cylinder switch or keyfob and none of the described conditions exist, the vehicle security system will automatically shift to armed mode.

Pattern B

To activate the vehicle security system, the smart entrance control unit must receive signal indicating any door (including hood and trunk lid) is opened.

When the front doors are locked with key, lock/unlock switch or keyfob and then all doors are closed, the vehicle security system will automatically shift to armed mode.

VEHICLE SECURITY SYSTEM ACTIVATION

Pattern A

With all doors (including hood and trunk lid) closed if the key is used to lock doors, front power window main switch terminal 6 receives a ground signal

- from terminal 3 of the key cylinder switch LH
- through body grounds M9, M25 and M87.

If this signal, or lock signal from keyfob is received by the smart entrance control unit, the vehicle security system will activate automatically.

NOTE:

Vehicle security system can be set even though all doors are not locked.

Pattern B

With any door (including hood and trunk lid) open if lock/unlock switch is used to lock doors, terminal 33 receives a ground signal

- from terminal 8 of lock/unlock switch LH, or
- from terminal 11 of lock/unlock switch RH
- through body grounds M9, M25 and M87, or

With any door (including hood and trunk lid) open if the key is used to lock doors, front power window main switch terminal 6 receives a ground signal

- from terminal 3 of the key cylinder switch LH
- through body grounds M9, M25 and M87.

NFEL0263S03

NFEL0263S04

System Description (Cont'd)

If these signals and lock signal from keyfob are received by the smart entrance control unit, ground signals of terminals 1, 2 and 3 are interrupted and all doors are closed, the vehicle security system will activate automatically.	GI
NOTE:	
Vehicle security system can be set even though the rear door is not locked.	MA
Once the vehicle security system has been activated, smart entrance control unit terminal 38 supplies ground to terminal 5 of the security indicator lamp. The security lamp will illuminate for approximately 30 seconds and then blinks every 2.6 seconds. Now the vehicle security system is in armed phase.	EM
VEHICLE SECURITY SYSTEM ALARM OPERATION	
The vehicle security system is triggered by	LC
 opening a door 	
 opening the hood or the trunk lid 	EC
detection of battery disconnect and connect.	60
Once the vehicle security system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 1, 2, 3 (door switch), 13 (trunk room lamp switch) or 6 (hood switch), the vehicle security system will be triggered. The headlamps flash and the horn sounds intermittently. Power is supplied at all times	FE
 through 10A fuse (No, 61 located in fuse and fusible link box) 	CL
 to vehicle security horn relay-1 terminals 1 and 3, and 	
 to vehicle security horn relay-2 terminal 1 	MT
 through 10A fuse (No. 57, located in fuse and fusible link box) 	000 0
• to horn relay terminal 2.	052
Power is also supplied at all times	AT
 through 15A fuse (No. 68, located in fuse and fusible link box) to headlamp relay LH terminal 3, 	AX
through 20A fuse (No. 54, located in fuse and fusible link box)	
• to headlamp relay LH terminals 1 and 6,	SU
 through 15A fuse (No. 69, located in fuse and fusible link box) 	
• to headlamp relay RH terminal 3, and • through 200 fues (No. 55, leasted in fues and fusible link bax)	DD
 through 20A fuse (No. 55, located in fuse and fusible link box) to headlamp relay RH terminals 1 and 6. 	BR
• to headlamp relay RH terminals 1 and 6. When the vehicle security system is triggered, ground is supplied intermittently	
 to headlamp LH relay terminal 2 from smart entrance control unit terminal 21 and 	ST
 to headlamp RH relay terminal 2 from smart entrance control unit terminal 21 and to headlamp RH relay terminal 2 from smart entrance control unit terminal 59 	
 through smart entrance control unit terminals 43 and 64. 	RS
When headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).	
The headlamps flash intermittently. When the vehicle security system is triggered, ground is supplied intermittently	BT
from smart entrance control unit terminal 42	
 to vehicle security horn relay-2 terminal 2. 	HA
When vehicle security horn relay-2 is energized, ground is supplied intermittently	
to vehicle security horn relay-1 terminal 2, and	SC
• to horn relay terminal 1.	00
When vehicle security horn relay-1 and horn relay are energized, then power is supplied to vehicle security horn and horn. The horn sounds intermittently.	EL
The alarm automatically turns off after 50 seconds but will reactivate if the vehicle is tampered with again.	
VEHICLE SECURITY SYSTEM DEACTIVATION	IDX
To deactivate the vehicle security system, a door or trunk lid must be unlocked with the key or keyfob. When the key is used to unlock the door, front power window main switch terminal 19 receives a ground signal	

• from terminal 1 of the LH key cylinder switch.

System Description (Cont'd)

When the key is used to open the trunk lid, smart entrance control unit terminal 12 receives a ground signal from terminal 1 of the trunk lid key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from keyfob, the vehicle security system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Remote keyless entry system may or may not operate vehicle security system (horn and headlamps) as required.

When the remote keyless entry system (panic alarm) is triggered, ground is supplied intermittently

- from smart entrance control unit terminal 42
- to vehicle security horn relay-2 terminal 2,
- from smart entrance control unit terminal 21
- to headlamp LH relay terminal 2 and
- from smart entrance control unit terminal 59
- to headlamp RH relay terminal 2

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 25 seconds or when smart entrance control unit receives any signal from keyfob.


System Description (Cont'd)

NOTE:


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Schematic

NFEL0121





Schematic (Cont'd)




EL-315

Wiring Diagram - VEHSEC -









MEL750O









MEL186O

Wiring Diagram — VEHSEC — (Cont'd)



SMART ENTRANCE CONTROL UNIT CONNECTOR



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

		TROL UNIT TERMINALS AND	REFERENCE VALUE			
ERMINAL	WIRE COLOR	ITEM		CONDITI	ON	DATA (DC)
1	LG	DRIVER DOOR SWITCH	OFF (CLOSED) \rightarrow ON	$OFF(CLOSED) \to ON(OPEN) $ 12		
2	R/L	PASSENGER DOOR SWITCH	$OFF (CLOSED) \rightarrow ON (OPEN)$ 5			$5V \rightarrow 0V$
3	R/W	REAR DOOR SWITCH	OFF (CLOSED) \rightarrow ON	I (OPEN)		$5V \rightarrow 0V$
6	Y/R	HOOD SWITCH	ON (OPEN) \rightarrow OFF (C	LOSED)		$0V \rightarrow 12V$
12	G/B	TRUNK LID KEY CYLINDER SWITCH	OFF (NEUTRAL) \rightarrow C	N (UNLOCK)		$5V \rightarrow 0V$
13	PU/Y	TRUNK ROOM LAMP SWITCH	ON (OPEN) \rightarrow OFF (C	LOSED)		0V →12V
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
21	OB	HEADLAMP LH RELAY	(WITH LIGHTING	$\rightarrow OFF$	WITHIN 5 MINUTES	0V
21			SWITCH 2ND)	ON OR START		0V
			HEADLAMPS ILLUMIN	ATE BY AUTO LI	GHT CONTROL	0V
26	PU	IGNITION SWITCH (ACC)	"ACC" POSITION			12V
27	G	IGNITION SWITCH (ON)	IGNITION KEY IS IN "C	N" POSITION		12V
33		COMMUNICATION INTERFACE	DOOR LOCK & UNLO	CK SWITCHES (N	NEUTRAL → LOCK/UNLOCK)	*1
			FRONT DOOR KEY CYLINDER SWITCH LH (NEUTRAL \rightarrow LOCK/UNLOCK			
38	G/OR	SECURITY INDICATOR	GOES OFF → ILLUMI	NATES		$12V \rightarrow 0V$
42	BR/Y	VEHICLE SECURITY HORN	WHEN PANIC ALARM	IS OPERATED U	SING KEYFOB (ON \rightarrow OFF)	$12V \rightarrow 0V$
43	В	GROUND		-		-
49	R/B	POWER SOURCE (FUSE)		-		12V
			IGNITION SWITCH	ON OR START	MORE THAN 5 MINUTES	12V
			(WITH LIGHTING	$\rightarrow OFF$	WITHIN 5 MINUTES	0V
59	P	HEADLAMP RH RELAY	SWITCH 2ND)	ON OR START		0V
			HEAD LAMP ILLUMINA	ATE BY AUTO LIC	GHT CONTROL	LESS THAN
			(OPERATE → NOT OF	PERATE)		1.5V→12V
64	В	GROUND		_		_

*1: REFER TO "SMART ENTRANCE CONTROL UNIT INSPECTION TABLE" IN "SMART ENTRANCE CONTROL UNIT".

BR

GI

MA

ST

BT

RS

HA


SC

EL

IDX

SEL593Y

CONSULT-II Inspection Procedure



CONSULT-II Application Item

NFEL0245

NFEL0245S01 G

CONSULT-II Application Item

"THEFT	WAR	ALM"
Data Mo	nitor	

	NFEL	0245S0101
Monitored Item	Description	
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.	
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.	[
KEY CYL LK SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.	
KEY CYL UN SW	Indicates [ON/OFF] condition of unlock signal from key cylinder switch.	[
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.	
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.	[
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.	
TRUNK SW	Indicates [ON/OFF] condition of trunk switch.	[
TRUNK KEY SW	Indicates [ON/OFF] condition of trunk key cylinder switch.	
HOOD SWITCH	Indicates [ON/OFF] condition of hood switch.	(
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch LH and RH.	
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from door lock/unlock LH and RH.	[
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.	
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.	
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.	

Active Test

N		02
Test Item	Description	SI
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when "ON" on CONSULT-II screen is touched.	- BF
HORN	This test is able to check vehicle security alarm operation. The alarm will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.	
HEADLAMP	This test is able to check vehicle security alarm headlamp operation. The headlamp illumi- nates for 0.5 seconds after "ON" on CONSULT-II screen is touched.	- ST
Nork Support		RS

Work Support

Test Item	Description	BT
THEFT ALM TRG	The switch which triggered theft warning alarm is recorded. This mode is able to confirm and erase the record of theft waning alarm. The trigger data can be erased by touching "CLEAR" on CONSULT-II screen.	HA
SECURITY ALARM SET	This mode is able to confirm and change security alarm ON-OFF setting.	

SC


EL

Trouble Diagnoses

Trouble Diagnoses PRELIMINARY CHECK

=NFEL0123

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



SEL254WC

For details of "Pattern A" and "Pattern B" about vehicle security (theft warning) system setting, refer to EL-309. *: Refer to EL-372.

After performing preliminary check, go to symptom chart on next page.

Trouble Diagnoses (Cont'd)

			5	SYMPT	ом сн	ART				-	NFEL0123S02	
REFE	RENCE PA	GE (EL-)	324	326	327	333	335	337	338	339	289	GI
	S	YMPTOM	PRELIMINARY CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR, HOOD AND TRUNK ROOM LAMP SWITCH CHECK	SECURITY INDICATOR LAMP CHECK	DOOR KEY CYLINDER SWITCH CHECK	TRUNK LID KEY CYLINDER SWITCH CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	VEHICLE SECURITY HORN AND HEADLAMP ALARM CHECK	Check "REMOTE KEYLESS ENTRY SYSTEM".	MA EM LC EC FE CL
		curity indicator does not	x	X	ă	x X	ă		ă	- N	Ö	AT
		for 30 seconds.										
1	Vehicle security system cannot be set by	All items	Х	X	X							AX
1	ehicle securit ystem canno be set by	Door outside key	Х				Х					
	hicle stem	Lock/unlock switch	Х						Х			SU
	sy Ce	Keyfob	Х								Х	
2	*1 Vehicle security system does not alarm when	One of the door is opened	х		x							BR ST RS
3	Vehicle security alarm does not activate.	Horn or headlamp alarm	х		x					x		BT
	curity not be y	Door outside key	х				x					SC
4	Vehicle security system cannot be canceled by	Trunk lid key	Х					Х				
	Veh syste can	Keyfob	x								x	EL

X : Applicable

*1: Make sure the system is in the armed phase.

Before starting trouble diagnoses above, perform preliminary check, EL-324.

IDX


Symptom numbers in the symptom chart correspond with those of preliminary check.

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK Power Supply Circuit Check


NFEL0123S03

- 1. Disconnect smart entrance control unit harness connector.
- 2. Check voltage between smart entrance control unit harness connector M144 terminals 26 (PU), 27 (G), M145 terminal 49 (R/B) and ground.



Ground Circuit Check

- 1. Disconnect smart entrance control unit harness connector.
- 2. Check continuity between smart entrance control unit harness connector M144 terminal 43 (B), M145 terminal 64 (B) and ground.



Trouble Diagnoses (Cont'd)

DOOR, HOOD AND TRUNK ROOM LAMP SWITCH CHECK

				CHECK	itch Check					=NFEL0123S04	G
				D001 3W						NFEL0123S0401	e
1. Turn "SE	PRELIMINARY ignition switch C CURITY" indicates all doors, hood	OFF and tor lamp	remove ke should b								M
 Lock "SE 4. Unic 	COURTY indication of the second se	ob from i t or lamp the doo	inside the v should tu r lock knot	urn on for 30 set o and open the de		seconds	after doo	or is locke	d.		EI L(
				OK	or NG						
ОК			Door swit	ch is OK, and go	to hood switc	h check.					E
NG			GO TO 2								
2	CHECK DOOR	SWITCI	H INPUT S	SIGNAL							F
	h CONSULT-II door switches ("E I.	DOOR S	W-RR", "D0	OOR SW-DR" an	d "DOOR SW-	-AS") in "	DATA M	ONITOR"	mode with C	ON-	C
	DATA MO		_								N
	MONITOR		_								
	DOOR SW-RR	OFF	_		Monito	r item		ndition	Condition		ļ
	DOOR SW-DR	OFF		DOOR SW-RR	Rear doors s	witch		open osed	ON OFF		U
	DOOR SW-AS	OFF		DOOR SW-DR	Door switch I	LH	С)pen osed	ON OFF		ļ
				DOOR SW-AS	Door switch I	RH		osed	ON OFF		00
										SEL024Y	
	hout CONSULT-I voltage between Smart entrance	smart er	ntrance cor	ntrol unit harness	connector M1	43 termi	nals 1 (L	.G), 2 (R/I	_) or 3 (R/W)	and	(
	unit connector	control					ninals	Conditior	n Voltage [V]		Г
				H.S.	Front door switch LH	(+)	(–) Ground	Open Closed	0 Approx. 12		
					Front door switch RH	2	Ground	Open Closed	0 Approx. 5		1
		⊕ ⊖	_ Į		Rear door switches	3	Ground	Open Closed	0 Approx. 5		ľ
Refer to	o wiring diagram	in EL-31	7.							SEL021YC	99
<u></u>					or NG						
OK				ch is OK, and go	to hood switc	h check.					
NG			GO TO 3								

3	CHECK DOOR SWI	тсн					
2. Cł	oor switch connect door switch co	door switch terminals.	御				
		S. Rear LH : (B10)	T.S.				
					Terminals	Condition	Continuity
				Front door	2-3	Closed	No
		[1]		switches	2-5	Open	Yes
	2	Ī		Rear door switches	1 - Ground	Closed	No
	Ω		Ē		1	Open	Yes SEL192W
			OK or N	G			
ОК	Þ	 Check the following Door switch ground Harness for open of 	d circuit or			nit and door	switch
NG		Replace door switch.					

Trouble Diagnoses (Cont'd)

Hood Switch Check

			=NFEL0123S04	02
1 PRELIMINA	RY CHECK			G
"SECURITY" ind 2. Close all doors, h 3. Lock doors with k	dicator lamp nood and trui keyfob from i	should b nk lid. inside the v	y from ignition key cylinder. ink every 2.6 seconds. rehicle. rn on for 30 seconds.	M
4. Unlock hood with	hood opene	er within 30	seconds after door is locked.	E
"SECURITY" ind	licator lamp	should tu	rn off. OK or NG	
ОК	•	Hood swit	ch is OK, and go to trunk room lamp switch check.	- L(
NG		GO TO 2.		
		Į		[(_
2 CHECK HO	OD SWITCH	H FITTING	CONDITION	F
			OK or NG	
ОК		GO TO 3.		C
NG		Adjust ins	tallation of hood switch or hood.	
3 CHECK HO			IGNAL	ר 🕅
(P) With CONSULT-		01 0		1
		ITCH") in "	DATA MONITOR" mode with CONSULT-II.	A
F		NITOR		
 א	MONITOR	OFF		A
			When hood is open: HOOD SWITCH ON	S
			•	Š
			HOOD SWITCH ON When hood is closed:	
Without CONSU Check voltage between	JLT-II een smart er		HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF	
Čheck voltage betwe	JLT-II een smart er Smart entran- unit connecto	ntrance con	HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF SEL354W trol unit harness connector M143 terminal 6 (Y/R) and ground.	
Check voltage betwe	een smart er Smart entran	ntrance cor ce control	HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF SEL354W	
-	Smart entran- unit connecto	ntrance cor ce control	HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF SEL354W trol unit harness connector M143 terminal 6 (Y/R) and ground.	
Check voltage betwe	een smart er Smart entran- unit connecto	ntrance con ce control or	HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF SEL354W trol unit harness connector M143 terminal 6 (Y/R) and ground. Voltage [V]: Engine hood is open. 0 Engine hood is closed.	
Check voltage betwe	een smart er Smart entran- unit connecto	ntrance con ce control or	HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF SEL354W trol unit harness connector M143 terminal 6 (Y/R) and ground. Voltage [V]: Engine hood is open. 0 Engine hood is closed. Approx. 12	
Čheck voltage betwe	een smart er Smart entran- unit connecto	ntrance cor ce control or 6.	HOOD SWITCH ON When hood is closed: HOOD SWITCH OFF SEL354W trol unit harness connector M143 terminal 6 (Y/R) and ground. Voltage [V]: Engine hood is open. 0 Engine hood is closed. Approx. 12	

4	CHECK HOOD SWITCH
	connect hood switch connector. eck continuity between hood switch terminals 1 and 2. Hood switch connector Hood switch connector Hood switch connector Continuity: Condition: Pushed No Condition: Released Yes
	SEL240W
	OK or NG
ОК	 Check the following. Hood switch ground circuit Harness for open or short between smart entrance control unit and hood switch
NG	Replace hood switch.

Trouble Diagnoses (Cont'd)

Trunk Room Lamp Switch Check

		Trunk Room Lamp Switch	n Check
1 PREL	IMINARY CHECK		G
 "SECURIT Close all c Lock doors "SECURIT Open trunt 	FY" indicator lamp doors, hood and trur s with keyfob from i FY" indicator lamp	side the vehicle. • hould turn on for 30 seconds. ener switch (on driver side door trim) within 30 se	IV
		OK or NG	
OK		runk room lamp switch is OK.	
NG	•	60 TO 2.	E
2 CHEC			
		AMP SWITCH INPUT SIGNAL	F
		RUNK SW"), in "DATA MONITOR" mode with CC	DNSULT-II.
	DATA MONI	R	G
	MONITOR		
	TRUNK SW	OFF When trunk lid is op	pen:
		TRUNK SW ON	
		When trunk lid is clo TRUNK SW OFF	osed:
🕅 Without C			SEL355W
		ance control unit harness connector M143 termin	
	Sn	rt entrance control	
	un	connector	
	F		j: lid is open. S
			prox. 0
		//d \\	lid is closed. prox. 12
	Ŧ		SEL036Y
Refer to wirin	g diagram in EL-31		SLUSOT
		OK or NG	Ľ
ОК		runk room lamp switch is OK.	
NG	►	60 то 3.	Ś

EL

2	CHECK TRUNK ROOM			
3	CHECK TRUNK ROOM			
	isconnect trunk room lamp s heck continuity between trur	witch connector. hk room lamp switch terminals	1 and 2.	
		k room lamp		
		ch connector (T9)	Continuity:	
			Condition: Closed No Condition: Open Yes SEL	_242W
		OK or	NG	
ОК	►	 Check the following. Trunk room lamp switch growth and the switch growth and the switch switch 	ound circuit between smart entrance control unit and trunk room larr	ιp
NG	►	Replace trunk room lamp swi	tch.	

Trouble Diagnoses (Cont'd)


SECURITY INDICATOR LAMP CHECK

	SECONT INDICATOR EAMI CHECK	=NFEL0123S05
1 CHECK INDICATOR	LAMP OPERATION	G
 With CONSULT-II Select "ACTIVE TEST" in Select "THEFT IND" and t 		M.
THEFT IND	OFF	E
	Security indicator lamp should illuminate.	L(
		E
<u></u> ON		SEL356W
	e control unit harness connector. hart entrance control unit harness connector M144 terminal 38 (G/OR) and ground.	G
Smart entr unit conne	ance control stor	M
	Battery voltage should exist.	TA
		A
Refer to wiring diagram in	드 · · · · · · · · · · · · · · · · · · ·	SEL037Y
	OK or NG	B
ОК	Security indicator lamp is OK.	
NG	GO TO 2.	SI
2 CHECK INDICATOR	LAMP	R
	OK or NG	
ОК	GO TO 3.	BI
NG	Replace indicator lamp.	

HA

SC

EL




Trouble Diagnoses (Cont'd)

DOOR KEY CYLINDER SWITCH CHECK =NFEL0123S07 1 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL) GI Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-MA Π. DATA MONITOR MONITOR KEY CYL LK-SW OFF When key inserted in front key cylinder is turned to LOCK: **KEY CYL UN-SW** OFF **KEY CYL LK-SW ON** LC When key inserted in front key cylinder is turned to UNLOCK: **KEY CYL UN-SW ON** EC FE SEL342W **Without CONSULT-II** 1. Check the signal between smart entrance control unit harness connector M144 terminal 33 (L) and ground with oscillo-CL scope when key inserted in front key cylinder is turned to "LOCK" or "UNLOCK". 2. Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned to "LOCK" or "UNLOCK". MT (V) Neutral 15 AT 10 Unlock Lock Voltage: 5 $12V \rightarrow 9V$ (10 sec.) measurement by analog circuit tester. AX 0 SU 2 s SEL397Y Refer to wiring diagram in EL-318. OK or NG ST OK Door key cylinder switch is OK. ► NG GO TO 2. ► BT

EL

HA


SC



CHECK TR	UNK LID K	EY CYLINDER SWITCH	INPUT SIGN	AL (UNI		AL)	
) With CONSUL				V ⁻		,	
		itch ("TRUNK KEY SW") in	"DATA MONI	FOR" mo	de with CON	SULT-II.	
Γ	DATA MO	NITOR					
	MONITOR						
r	RUNK KEY SW	OFF	Whon ke	w in kow	ovlindor in a	t Noutral pag	vition
					-	t Neutral pos	SHIOT:
						t Unlock pos	ition:
			TRUNK	KEY SW	/ ON		
E							SEL358W
Without CONS		entrance control unit harnes	s connector M	11/13 torn	ninal 12 (G/B) and around	
eek voltage bet	Sinar e) and ground.	
Çontinui	ty exist						
Neutral		Smart entrance control					
		unit connector		Term		Key position	Voltage [V]
				(+)	(-)	Neutral	Approx. 5
				12	Ground	Unlock	0
	÷						SEL039Y
fer to wiring diag	ram in EL-3						
			K or NG				
ζ		Trunk lid key cylinder swi	itch is OK.				
3		GO TO 2.					
		EY CYLINDER SWITCH					
		nder switch connector. unk lid key cylinder switch te	orminals				
Check continuity	Detween in		erriniais.				
۲ ۲							
	<u>T.S.</u> 도국가						
		i lid key Ier switch (18108)	Kev	position		Continuity	
				Ieutral		No	
~			ι	Jnlock		Yes	
	Ω						
Ľ							SEL248W
			K or NG				02227077
(Check the following.					
			witch around	circuit			
		 Trunk lid key cylinder s 	switch ground	Circuit			
		Harness for open or sh			trance contro	I unit and trur	k lid key cylin-
			nort between s		rance contro	I unit and trur	ık lid key cylin-


Trouble Diagnoses (Cont'd)

DOOR LOCK/UNLOCK SWITCH CHECK



Trouble Diagnoses (Cont'd)

VEHICLE SECURITY HORN AND HEADLAMP ALARM CHECK




RS

BT

HA


SC

EL



3	CHECK VEHICLE SECURITY HORN RELAYS						
Check	Check vehicle security horn relay-1 and relay-2.						
		OK or NG					
OK	OK 🕨 GO TO 4.						
NG	NG Replace.						

Trouble Diagnoses (Cont'd)



EL

Description

Description

OUTLINE

The smart entrance control unit totally controls the following body electrical system operations.

- Heated steering
- Headlamp system
- Warning chime
- Rear defogger and door mirror defogger
- Power door lock
- Remote keyless entry system
- Vehicle security system
- Interior lamp

In addition, the following timer operations are controlled by the smart entrance control unit.

- Battery saver control
- Retained power control

BATTERY SAVER CONTROL

NFEL0124S02

Headlamps/Parking Lamps/License Lamps/Tail Lamps/Fog Lamps/Illumination Lamps While the headlamp is turned ON by "1st" or "2ND" step of light switch, the 5 minute timer is activated when the ignition switch signal changes from ON (or START) to OFF (ACC OFF). The headlamps (including parking, license, tail, fog and illumination lamps) are turned off after 5 minutes.

While the headlamp is turned ON by "AUTO" of light switch, the 5 minute timer is activated when the ignition switch signal changes from ON (or START) to OFF (ACC OFF), and either one of LH or RH front door switch ON signal is input.

The auto light delay off timer is activated as the following:

- When the door switch signal changes from ON to OFF while the timer is activated, the timer in operation is discontinued and the 45 second timer is reset.
- When the door switch signal changes from OFF to ON while the timer is activated, the timer is discontinued and the 45 second timer is reset.
- When the one of four door switch signals changes from OFF to ON while the timer is activated, the timer is discontinued and the 5 minute timer is reset.
- When all the door switch ON signals are input while the timer is activated, the timer is discontinued and the 45 second timer is reset.

Exterior lamp battery saver control mode and auto light delay off timer period can be changed by the function setting of CONSULT-II.

Interior Lamp/Spot Lamp/Vanity Mirror Illumination

The lamps turn off automatically when the interior lamp, spot lamp or/and vanity mirror illumination are illuminated with the ignition key in the OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in the ON position for more than 30 minutes.

After lamps are turned off by the battery saver system, the lamps illuminate again when:

- Driver's door is locked or unlocked with keyfob, door lock/unlock switch or door key cylinder.
- Ignition switch is turned to ON.
- Door is opened or closed,
- Key is inserted into ignition key cylinder.

Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

Rear Window Defogger/Door Mirror Defogger

Rear window defogger and door mirror defogger are turned off in approximately 15 minutes after the rear window defogger switch is turned on.

Heated Steering

Heated steering is turned off in approximately 30 minutes after the heated steering switch is turned ON.

RETAINED POWER CONTROL

When the ignition switch is turned to OFF (or ACC) position from ON or START position, the following systems can be operated for 45 seconds by the RAP signal from the smart entrance control unit terminal 46.

Electric sunroof

NFEL0124 NFEL0124S01

• Power window

The retained power operation is canceled when the driver or passenger side door is opened. RAP signal period can be changed by CONSULT-II.

INPUT/OUTPUT

\bigcirc	Π
ଏ	U

System	Input	Output
Power door lock	Door lock and unlock switch LH and RH Key switch (Insert) Door switches Door key cylinder switches	Door lock actuators
Remote keyless entry	Key switch (Insert) Ignition switch (ACC) Door switches Keyfob signal Door lock/unlock switch LH	Horn relay Vehicle security horn relay-1 Vehicle security horn relay-2 Hazard warning lamp Interior lamp Ignition key hole illumination Door lock actuator Trunk lid opener actuator
Varning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch (driver's seat) Front door switch LH	Warning chime (located in smart entrance control unit)
Rear window defogger and loor mirror defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
/ehicle security	Ignition switch (ACC, ON) Door switches Hood switch Trunk room lamp switch Door lock/unlock switches Door key cylinder switches (lock/unlock) Trunk lid key cylinder switch (unlock)	Vehicle security horn relay-2 Headlamp relay Security indicator
nterior lamp	Door switches Keyfob signal (lock/unlock) Door lock/unlock switches (lock/unlock) Door key cylinder switch (lock/unlock) Ignition switch (ON) Key switch (Insert)	Interior lamp Key hole illumination Step lamp Door indicator
attery saver control for eadlamps/parking lamps/ cence lamps/tail lamps/fog amps/illumination lamps	Ignition switch (ON) Front door switches Lighting switches	Headlamps Parking lamps Licence lamps Tail lamps Fog lamps Illumination lamps
attery saver control for inte- or lamp/spot lamp/vanity mir- or illumination	Ignition switch (ON) Front door switches Lamp switches	Interior lamp Step lamp Spot lamp Vanity mirror illumination
attery saver control for rear indow defogger and door irror defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
etained power control for lectric sunroof	Ignition switch (ON) Front door switches	Sunroof motor
Retained power control for ower window	Ignition switch (ON) Front door switches	Power window relay

Description (Cont'd)

System	Input	Output
Heated steering	Ingition switch (ON) Heated steering switch (ON)	Heated steering relay

	NFEL0247 NFEL0247S01			
Item (CONSULT-II screen terms)	Diagnosed system	DATA MONITOR	ACTIVE TEST	WORK SUPPORT
DOOR LOCK	Power door lock	Х	Х	Х
REAR DEFOGGER	Rear window defogger	Х	Х	
KEY WARN ALM	Warning chime	Х	Х	
LIGHT WARN ALM	Warning chime	Х	Х	
SEAT BELT ALM	Warning chime	Х	Х	
INT LAMP	Interior lamps	Х	Х	Х
BATTERY SAVER	Battery saver control for interior lamp	Х	Х	Х
THEFT WAR ALM	Vehicle security system	Х	Х	Х
RETAINED PWR	Retained power control	Х	Х	Х
MULTI REMOTE ENT	Remote keyless entry system	Х	Х	Х
HEAD LAMP	Headlamp	Х	Х	Х

X: Applicable

For diagnostic item in each control system, refer to the relevant pages for each system.

CONSULT-II (Cont'd)

DIAGNOSTIC ITEM DESCRIPTION

MODE	Description
DATA MONITOR	Input/output data in the smart entrance control unit can be read.
ACTIVE TEST	Diagnostic Test Mode in which CONSULT-II drives some sys- tems apart from the smart entrance control unit.
WORK SUPPORT for DOOR LOCK	 Select unlock mode ON-OFF setting can be changed. Key reminder door mode ON-OFF setting can be changed.
WORK SUPPORT for INT LAMP	Interior lamp timer mode ON-OFF setting can be changed.
WORK SUPPORT for BATTERY SAVER	Interior lamp battery saver period can be changed.
WORK SUPPORT for THEFT WAR ALM	 The recorded trigger signal when vehicle security system was activated can be checked. Security alarm ON-OFF setting can be changed.
WORK SUPPORT for RETAINED PWR SET	RAP signal's power supply period can be changed.
WORK SUPPORT for MULTI REMOTE ENT	 ID code of keyfob can be registered and erased. Keyless answer back mode can be changed. Pressing time of panic alarm, trunk lid opener and door unlock (for power window down operation) buttons on keyfob
	Auto lock operation starting time can be changed.
WORK SUPPORT for HEAD LAMP	 Auto light sensitivity can be changed. Exterior lamp battery saver control ON-OFF setting can be changed. Auto light delay off time can be changed.

BR

SU

ST

RS


BT

HA

SC

EL

CONSULT-II (Cont'd)



NOTE:


GI

MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA

SC


EL

Schematic



EL-348

Schematic (Cont'd)



EL-349

Smart Entrance Control Unit Inspection Table

Smart Entrance Control Unit Inspection Table


						NFEL026		
Terminal No.	Wire color	Connections		Operated conditio	n	Voltage (Approximate val- ues)		
1	LG	Driver door switch	OFF (Closed) \rightarrow ON (Open)			$12V \rightarrow 0V$		
2	R/L	Passenger door switch	OFF (Closed) \rightarrow	ON (Open)		5V ightarrow 0V		
3	R/W	Rear door switch	OFF (Closed) \rightarrow	ON (Open)		$5V \rightarrow 0V$		
4	G	Heated steering switch	$OFF \rightarrow ON$ (Only	/ when pushed)		$5V \rightarrow 0V$		
6	Y/R	Hood switch	ON (Open) → OF	FF (Closed)		$0V \rightarrow 12V$		
7	W/R	Auto light sensor (Signal)	Ignition switch	Light is applied to sor.	o auto light sen-	1 to 5V		
1	VV/IX		ON position	Light is not applie sensor.	ed to auto light	Less than 1V		
8	P/B	Auto light sensor (GND)		—				
9	R	Auto light sensor (Power)	Ignition switch (O	$PFF \to ON)$		$0V \rightarrow 5V$		
12	G/B	Trunk lid key cylinder switch	OFF (Neutral) \rightarrow	ON (Unlock)		5V ightarrow 0V		
13	PU/Y	Trunk room lamp switch	ON (Open) \rightarrow OF	FF (Closed)		0V ightarrow 12V		
14	G/W	Rear window defogger switch	$OFF \rightarrow ON$ (Only	$OFF \to ON$ (Only when pushed)		$5V \rightarrow 0V$		
16	L	Trunk and fuel lid opener switch	$OFF \to ON$ (Only	$OFF \to ON$ (Only when pulled)		$12V \rightarrow 0V$		
					Ignition switch (with lighting		More than 5 minutes after ignition switch is turned to OFF position	12V
19	Y/B	Tail lamp relay (Output)	lamp relay (Output)switch 1ST or 2ND)Within 5 mi after ignitio switch is tu	Within 5 minutes after ignition switch is turned to OFF position	0V			
				ON or START po	sition	0V		
			Headlamps illumi → Not operate)	nate by auto light	control. (Operate	Less than $1V \rightarrow 12V$		
20	SB	Tail lamp switch	Light switch (OFF	F or AUTO \rightarrow 1ST	or 2ND position)	$12V \rightarrow 0V$		
			Ignition switch (with lighting switch 2ND)	ON or START	More than 5 minutes after ignition switch is turned to OFF position	12V		
21	OR Headlamp LH relay	Headlamp LH relay		→ OFF position	Within 5 minutes after ignition switch is turned to OFF position	0V		
				ON or START po	sition	0V		
			Headlamps illumi	nate by auto light	control.	0V		

Smart Entrance Control Unit Inspection Table (Cont'd)

Terminal No.	Wire color	Connections		Operated condition	Voltage (Approximate val- ues)
			l inhtin a switch	Except PASS or 2ND position	12V
22	L/OR	Headlamp switch	Lighting switch	hting switch PASS or 2ND position 0V	0V
			Headlamps illumi → Not operate)	nate by auto light control. (Operate	10V→ 12V
23	L/Y	Headlamp switch	Ignition switch "ON" position	Lighting switch (Except AUTO \rightarrow AUTO position)	$12V \rightarrow 0V$
25	B/R	Ignition key switch (Insert)	Key inserted \rightarrow k	Key removed from IGN key cylinder	$12V \rightarrow 0V$
26	PU	Ignition switch (ACC)	"ACC" position		12V
27	G	Ignition switch (ON)	Ignition switch is	in "ON" position	12V
28	OR	Seat belt buckle switch	Unfastened \rightarrow Fa tion)	astened (Ignition key is in "ON" posi-	$0V \rightarrow 12V$
30	R/Y	Ignition keyhole illumination	When doors are Unlock)	unlocked using keyfob (OFF $ ightarrow$	$12V \rightarrow 0V$
31	R	Interior lamp		locked using keyfob (Unlock \rightarrow lock in "DOOR" position)	0V ightarrow 12V
32	R/W	Front step lamp	Any door switch	ON (Open) \rightarrow OFF (Closed)	$0V \rightarrow 12V$
			Door lock & unlock switches (Neutral → Lock/Unlock)		
33	L	Communication interface	Front door key cylinder switch LH (Neutral \rightarrow Lock/ Unlock)		EL-352
37	G/R	Rear window defogger relay	$OFF \rightarrow ON$ (Ignition key is in "ON" position)		$12V \rightarrow 0V$
38	G/OR	Security indicator	Goes off \rightarrow Illum	inates	$12V \rightarrow 0V$
40	B/R	Heated steering relay	$OFF \rightarrow ON$ (Ignit	tion key is in "ON" position)	$12 \rightarrow 0V$
42	BR/Y	Vehicle Security horn relay	When panic alarr OFF)	m is operated using keyfob (ON $ ightarrow$	$12V \rightarrow 0V$
43	В	Ground		_	—
46	PU	Power window relay	Retained power of	operation is operated (ON \rightarrow OFF)	$12V \rightarrow 0V$
47	GY/L	LH turn signal lamp	When door lock ($(ON \rightarrow OFF)$	or unlock is operated using keyfob	$12V \rightarrow 0V$
48	GY/R	RH turn signal lamp	When door lock ($(ON \rightarrow OFF)$	or unlock is operated using keyfob	$12V \rightarrow 0V$
49	R/B	Power source (Fuse)		_	12V
50	R/G	Battery saver (Interior lamp)	Battery saver ope →OFF)	erates \rightarrow Does not operate (ON	$12V \rightarrow 0V$
51	W/R	Power source (PTC)		_	12V
54	GY	Door lock actuators	Door lock & unlo	ck switch (Free \rightarrow Lock)	$0V \rightarrow 12V$
55	W/B	Driver door lock actuator	Door lock & unlo	ck switch (Free \rightarrow Unlock)	$0V \rightarrow 12V$
56	GY	Passenger and rear doors lock actuator	Door lock & unlo	ck switch (Free \rightarrow Unlock)	$0V \rightarrow 12V$

Smart Entrance Control Unit Inspection Table (Cont'd)

Terminal No.	Wire color	Connections		Operated condition		
		(Ignition switch (with lighting	ON or START \rightarrow OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
57	57 Y/B Tail la		switch 1ST or 2ND)		Within 5 minutes after ignition switch is turned to OFF position	٥V
				ON or START po	sition	0V
			Headlamps illumi → Not operate)	nate by auto light control. (Operate		Less than $1V \rightarrow 12V$
58	SB	Tail lamp switch	Lighting switch (OFF or AUTO \rightarrow 1ST or 2ND)		$12V \rightarrow 0V$	
		P Headlamp RH relay	Ignition switch	hting \rightarrow OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
59	Ρ		(with lighting switch 2ND)		Within 5 minutes after ignition switch is turned to OFF position	OV
			ON or START position		0V	
				Headlamps illuminate by auto light control. (Operate \rightarrow Not operate)		Less than $1V \rightarrow 12V$
				Except PASS or 2ND position		12V
60	LG/R H	Headlamp switch	Lighting switch PASS or 2NI		sition	0V
				Headlamps illuminate by auto light control. (Operate \rightarrow Not operate)		
63	L	Trunk lid opener actuator	When trunk lid opener actuator is operated using keyfob. (ON \rightarrow OFF)		$0V \rightarrow 12V$	
64	В	Ground		_		_



COMMUNICATION INTERFACE SIGNAL


NFEL0262S01

12 V \rightarrow 9V (10 sec.) measurement by analog circuit tester.

Voltage:

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram - TRNSCV-



SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
27	G	IGNITION SWITCH (ON)	IGNITION KEY IS IN "ON" POSITION	12V
43	В	GROUND	-	-
49	R/B	POWER SOURCE (FUSE)	-	12V
50	R/G	BATTERY SAVER	BATTERY SAVER DOSE OPERATE \rightarrow DOES NOT OPERATE	$12V \rightarrow 0V$
50	R/G	(INTERIOR LAMP)	$(ON \rightarrow OFF)$	120 - 00
64	В	GROUND	-	_

SC

EL

Trouble Diagnoses


DIAGNOSTIC PROCEDURE

NFEL0128


NFEL0128S01

SYMPTOM: Transmitter does not activate receiver.

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is malfunctioning, not vehicle related.



2	CHECK TRANSMITTER FUNCTION					
Check transmitter with Tool. For details, refer to Technical Service Bulletin.						
	OK or NG					
OK	OK Receiver or handheld transmitter is malfunctioning, not vehicle related.					
NG	NG Replace transmitter with sun visor assembly.					



EL-354

HOMELINK UNIVERSAL TRANSCEIVER

4 CHECK GROUND CIRCUIT	
Check continuity between terminal 2 and ground.	GI
Integrated homelink transmitter connector	MA
Continuity should exist.	EM
	LC
÷ SEL368W	EC
OK or NG OK Replace transmitter with sun visor assembly.	PP
NG Repair harness.	FE
	CL
	MT
	AT
	AX
	SU
	BR
	ST
	RS
	BT
	HA
	SC
	EL
	IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Component Parts and Harness Connetor Location

Component Parts and Harness Connetor Location NFEL0172 Security indicator lamp Fuse block (J/B) 1 2 3 4 5 6 7 8 9 10 11 b c d e 51 52 13 14 15 16 17 18 19 20 12 • C 61 62 g 23 24 25 26 27 28 29 30 31 21 22 Clóck UP View with steering wheel and steering View with glove box removed column removed С ЕС́М NVIS (NATS) IMMU

SEL301W

NOTE:

If customer reports a "No Start" condition, request ALL KEYS be brought to a NISSAN dealer to check for an NVIS (NATS) malfunction.

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

System Description

=NFEL0173

System Description


NVIS (Nissan Vehicle Immobilizer System-NATS) has the following immobilizer functions:

- Since only NVIS (NATS) ignition keys, whose ID nos. have been registered into the ECM and IMMU of NVIS (NATS), allow the engine to run, operation of a stolen vehicle without an NVIS (NATS) registered key is prevented by NVIS (NATS).
 That is to say, NVIS (NATS) will immobilize the engine if someone tries to start it without the registered key of NVIS (NATS).
- All of the originally supplied ignition key IDs have been NVIS (NATS) registered.
 If requested by the vehicle owner, a maximum of five key IDs can be registered into the NVIS (NATS) components.
- The security indicator blinks when the ignition switch is in "OFF" or "ACC" position. Therefore, NVIS (NATS) LC warns outsiders that the vehicle is equipped with the anti-theft system.
- When NVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the "ON" position.
- NVIS (NATS) trouble diagnoses, system initialization and additional registration of other NVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NVIS (NATS) software. Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II operation manual, IVIS/NVIS.
- When servicing a malfunction of the NVIS (indicated by lighting up of Security Indicator Lamp) or registering another NVIS ignition key ID no., it is necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.

System Composition

The immobilizer function of the NVIS (NATS) consists of the following:

- NVIS (NATS) ignition key
- NVIS (NATS) immobilizer control unit (IMMU) located in the ignition key cylinder
- Engine control module (ECM)
- Security indicator



MT

AT

AX


NFEL0174

SC

EL

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM - NATS)

Wiring Diagram — NATS



MEL1910

SMART ENTRANCE CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN EACH TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
27	G	IGNITION SWITCH (ON)	IGNITION KEY IS IN "ON" POSITION	12V
38	G/OR	SECURITY INDICATOR	GOES OFF → ILLUMINATES	12V→ 0V
43	В	GROUND	-	-
49	R/B	POWER SOURCE (FUSE)	-	12V
64	В	GROUND	-	-

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

CONSULT-II

Data link connector						
Steering	column 1.	ONSULT-II INSPECTION PROCEDURE Turn ignition switch OFF.	GI			
	2.	-	MA			
			EM			
	SEF289X		LC			
NISSAN	3.	 Program card NATS (AEN02B) 	EC			
CONSULT-II	4. 5.	0	FE			
START			CL			
SUB MODE	PBR455D		MT			
SELECT SYSTEM	6.	Select "NATS V.5.0".				
NATS V.5.0			AT			
			AX			
			SU			
			BR			
	SEL851W	Deferm each diagnestic test made according to each convice				
SELECT DIAG MODE	7.	Perform each diagnostic test mode according to each service procedure.	ST			
C/U INITIALIZATION SELF DIAGNOSIS		or further information, see the CONSULT-II Operation anual, IVIS/NVIS.	RS			
			BT			
			HA			
	SEL728W		0 UU U			
CONSULT-II DIAGNOSTIC TEST MODE FUNCTION						
CONSULT-II DIAGNOSTIC TEST MODE		Description	EL			
C/U INITIALIZATION		ng any of the following three components, C/U initialization is necessary. ignition key/IMMU/ECM]	IDX			
		ems (screen terms) are as shown in the chart EL-360				


SELF DIAGNOSIS Detected items (screen terms) are as shown in the chart EL-360.

EL-359

CONSULT-II (Cont'd)

NOTE:

- When any initialization is performed, all ID previously registered will be erased and all NVIS (NATS) ignition keys must be registered again.
- The engine cannot be started with an unregistered key. In this case, the system will show "DIFFERENCE OF KEY" or "LOCK MODE" as a self-diagnostic result on the CONSULT-II screen.
- In rare case, "CHAIN OF ECM-IMMU" might be stored as a self-diagnostic result during key registration procedure, even if the system is not malfunctioning.



NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART

N	FFI	01	76S	04

Detected items (NATS program card screen terms)	P No. Code (Self-diag- nostic result of "ENGINE"	Malfunction is detected when	Reference page
ECM INT CIRC-IMMU	NATS MAL- FUNCTION P1613	The malfunction of ECM internal circuit of IMMU com- munication line is detected.	EL-364
CHAIN OF ECM-IMMU	NATS MAL- FUNCTION P1612	Communication impossible between ECM and IMMU (In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.)	EL-365
DIFFERENCE OF KEY	NATS MAL- FUNCTION P1615	IMMU can receive the key ID signal but the result of ID verification between key ID and IMMU is NG.	EL-369
CHAIN OF IMMU-KEY	NATS MAL- FUNCTION P1614	IMMU cannot receive the key ID signal.	EL-370
ID DISCORD, IMM-ECM	NATS MAL- FUNCTION P1611	The result of ID verification between IMMU and ECM is NG. System initialization is required.	EL-371

EL-360

CONSULT-II (Cont'd)

Detected items (NATS program card screen terms)		Malfunction is detected when	Reference page	GI
LOCK MODE	NATS MAL- FUNCTION P1610	 When the starting operation is carried out five or more times consecutively under the following conditions, NVIS (NATS) will shift the mode to one which prevents the engine from being started. Unregistered ignition key is used. IMMU or ECM's malfunctioning. 	EL-374	MA EM
DON'T ERASE BEFORE CHECKING ENG DIAG	_	All engine trouble codes except NVIS (NATS) trouble code has been detected in ECM.	EL-362	LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

EL-361

Trouble Diagnoses



Trouble Diagnoses (Cont'd)

SYMPTOM MATRIX CHART 1 NFEL0177S02 (Self-diagnosis related item) DIAGNOSTIC PROCE-Displayed "SELF-DIAG SYSTEM REFERENCE PART NO. SYMPTOM **RESULTS**" on CON-DURE (Malfunctioning part or OF ILLUSTRATION ON SULT-II screen. (Reference page) mode) NEXT PAGE MA **PROCEDURE 1** ECM INT CIRC-IMMU ECM В (EL-364) In rare cases, "CHAIN OF ECM-IMMU" might be stored during the LC key registration procedure, even if the system is not malfunc-EC tioning. Open circuit in battery voltage line of IMMU C1 circuit Open circuit in ignition C2 CL line of IMMU circuit Open circuit in ground C3 line of IMMU circuit PROCEDURE 2 MT CHAIN OF ECM-IMMU (EL-365) Open circuit in communication line between C4 AT IMMU and ECM Short circuit between • Security indicator IMMU and ECM com-AX C4 lighting up* munication line and bat-· Engine hard to start tery voltage line Short circuit between IMMU and ECM com-C4 munication line and around line ECM в IMMU А D Unregistered key PROCEDURE 3 DIFFERENCE OF KEY (EL-369) IMMU А Malfunction of key ID Е **PROCEDURE 4** chip CHAIN OF IMMU-KEY (EL-370) IMMU А HA System initialisation has F not yet been com-**PROCEDURE 5** ID DISCORD, IMMpleted. ECM (EL-371) SC ECM F **PROCEDURE 7** LOCK MODE LOCK MODE D EL (EL-374) Engine trouble data and • MIL staying ON DON'T ERASE WORK FLOW NVIS (NATS) trouble • Security indicator **BEFORE CHECKING** (EL-362) data have been lighting up* ENG DIAG detected in ECM


*: When NVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

Trouble Diagnoses (Cont'd)

SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

NFEL0177S03

(Non sen-diagnosis related item)				
SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)		
		Security ind.		
	PROCEDURE 6	Open circuit between Fuse and IMMU		
Security ind. does not light up.	(EL-372)	Continuation of initialization mode		
		ІММО		



SELF DIAGNO		
DTC RESULTS	TIME	
ECM INT CIRC-IMMU	0	
		SEL314W

DIAGNOSTIC PROCEDURE 1 Self-diagnostic results:

NFEL0177S06

"ECM INT CIRC-IMMU" displayed on CONSULT-II screen

- 1. Confirm SELF-DIAGNOSTIC RESULTS "ECM INT CIRC-IMMU" displayed on CONSULT-II screen. Ref. part No. B.
- 2. Replace ECM.
- 3. Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".


Trouble Diagnoses (Cont'd)

		DIAGNOSTIC PROCEDURE 2
		Self-diagnostic results: "CHAIN OF ECM-IMMU" displayed on CONSULT-II screen
1 CONFIRM S	ELF-DIAGNOSTIC F	
		CHAIN OF ECM-IMMU" displayed on CONSULT-II screen.
NOTE:	NUSTIC RESULTS C	CHAIN OF ECM-IMMO displayed on CONSOLT-II screen.
	N OF ECM-IMMU" mig	ght be stored during the key registration procedure, even if the system is not
nanonotioning.		SELF DIAGNOSIS
		DTC RESULTS TIME
		CHAIN OF ECM-IMMU 0
		SEL292W
	le (CONSULT-II screen displayed as above?
Yes	► GO TO 2	
No		SYMPTOM MATRIX CHART 1.
2 CHECK PO	NER SUPPLY CIRC	UIT FOR IMMU
1. Disconnect IMMU		
2. Check voltage be	tween terminal 8 of IN	MMU and ground with CONSULT-II or tester.
IMMU co	nector (M42)	
		(AA) H.S.
		Battery voltage should exist.
		÷ CU
		SEL302W
		OK or NG
OK	► GO TO 3	
NG	-	he following
-	Check tl	
	• 15A fu	use (No. 59, located in the fuse and fusible link box)
	15A fuHarne	

EL


IDX

Trouble Diagnoses (Cont'd)



4	CHECK GROUND CIRC	UIT FOR IMMU	
	IMMU conner	veen IMMU terminal 4 and ground.	
		OK or NG	SEL304W
ОК	•	GO TO 5.	
NG	•	Repair harness. Ref. part No. C3	

Trouble Diagnoses (Cont'd)




Inl/A

SC

EL

Trouble Diagnoses (Cont'd)



8	SIGNAL FROM ECM TO	D IMMU CHECK		
tu 2. Ma	rned "ON".	-		T-II or oscilloscope when ignition switch is during 750 msec. just after ignition switch is
		Trigg	ering Menu Stop Triggering	
		Set		
		>> [A] 5.0 V/DIv 10 mS/DIv T	SEL730W
			OK or NG	
ОК	►	IMMU is malfunction Replace IMMU. Ref. Perform initialization For the operation of	. part No. A with CONSULT-II.	"CONSULT-II Operation Manual IVIS/NVIS".
NG	►	ECM is malfunctionin Replace ECM. Ref. Perform initialization For the operation of	part No. B with CONSULT-II.	"CONSULT-II Operation Manual IVIS/NVIS".

Trouble Diagnoses (Cont'd)

	I	DIAGNOSTIC	PRO	CEDURE 3 =NFEL0177S00	2
		Self-diagnostic		ts:	GI
			OFK	EY" displayed on CONSULT-II screen	GII
1 CONFIRM SELF-DIAGNOSTIC RESULTS					DЛA
Confirm SELF-DIAGNOSTIC RESULTS "DIFFERENCE OF KEY" displayed on CONSULT-II screen.					MA
		SELF DIAGNOS			
		DTC RESULTS	TIME		EM
		DIFFERENCE OF KEY	o		
					LC
					EC
				SEL293W	FE
	Is CONSU	JLT-II screen dis	played a	as above?	
Yes	GO TO 2.	•			CL
No	GO TO SYMPT	TOM MATRIX CH	ART 1.		
					MT
2 PERFORM INITIALIZA	TION WITH CO	NSULT-II			
Perform initialization with CONS				n key IDs.	AT
For initialization, refer to "CONS	ULT-II operation	manual IVIS/NVIS	S".		0 4 0
		IMMU INITIALIZA	TION		AX
					171273
		INITIALIZATIO FAIL	N		A 11
					SU
		THEN IGN KEY SW 'C			
		'ON', AFTER CONFIR SELF-DIAG AND PAS			BR
		PERFORM C/U INITIA AGAIN.	LIZATION		
				SEL297W	ST
NOTE:		o			
If the initialization is not complet				-	RS
-	1			n re-registered NVIS (NATS) ignition key?	
Yes		was unregistered.	. Ref. p	art No. D	BT
No	IMMU is malfur	nctioning. . Ref. part No. A			
	Perform initializ	ation with CONSI			HA
	For initialization	n, refer to "CONSI	ULT-II o	peration manual IVIS/NVIS".	

SC

EL

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

=NFEL0177S09

Self-diagnostic results: "CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGN	IOSTIC RESUL	OSTIC RESULTS			
Confir	m SELF-DIAGNOSTIC RE	SULTS "CHAIN (OF IMMU-KEY" o	displaye	ed on CONSULT-II screen.	
			SELF DIAGNOS	IS	1	
			DTC RESULTS	TIME]	
			CHAIN OF IMMU-KEY	o		
					-	
		•		1	SEL294W	
		Is CONSU	LT-II screen dis	played	as above?	
Yes	►	GO TO 2.				
No	►	GO TO SYMPT	OM MATRIX CH	ART 1.		

2	CHECK NVIS (NATS) IGNITION KEY ID CHIP				
Start	engine with another registe	red NVIS (NATS) ignition key.			
	Does the engine start?				
Yes	►	Ignition key ID chip is malfunctioning. Replace the ignition key. Ref. part No. E Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".			
No	►	GO TO 3.			

3	CHECK IMMU INSTALLATION				
	Check IMMU installation. Refer to "How to Replace IMMU" in EL-375.				
	OK or NG				
OK	OK IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".				
NG	•	Reinstall IMMU correctly.			

Trouble Diagnoses (Cont'd)

	DIAGNOSTIC PROCEDURE 5	
	Self-diagnostic results: "ID DISCORD, IMM-ECM" displayed on CONSULT-II screen	GI
1 CONFIRM	SELF-DIAGNOSTIC RESULTS	Giu
	GNOSTIC RESULTS "ID DISCORD, IMM-ECM" displayed on CONSULT-II screen.	M
		0002
	SELF DIAGNOSIS DTC RESULTS TIME	EN
	ID DISCORD, IMM-ECM 0	LC
		E(
	SEL298W	FE
NOTE: "ID DISCORD IMN		
	IMU is in discord with that of ECM.	C[
	Is CONSULT-II screen displayed as above?	
Yes	GO TO 2.	M
No	GO TO SYMPTOM MATRIX CHART 1.	
		Aī
	n with CONSULT-II. Re-register all NVIS (NATS) ignition key IDs. fer to "CONSULT-II operation manual IVIS/NVIS".	AD
		SI
	INITIALIZATION FAIL	
		BF
	THEN IGN KEY SW 'OFF' AND	
	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD,	
	'ON', AFTER CONFIRMING	S
	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION	SI
NOTE: If the initialization	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.	S1 Ri
-	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN. SEL297W	S1 R(
If the initialization	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN. SEL297W S not completed or fails, CONSULT-II shows above message on the screen. SEL297W Can the system be initialized? Start engine. (END)	ST RC BT
If the initialization Yes	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN. SEL297W Senot completed or fails, CONSULT-II shows above message on the screen. SEL297W Can the system be initialized? Start engine. (END) (System initialization had not been completed. Ref. part No. F)	ST RC BT
If the initialization Yes	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN. SEL297W Senot completed or fails, CONSULT-II shows above message on the screen. SEL297W Can the system be initialized? Start engine. (END) (System initialization had not been completed. Ref. part No. F) ECM is malfunctioning. ECM is malfunctioning.	ST Ri B
If the initialization	'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN. SEL297W Senot completed or fails, CONSULT-II shows above message on the screen. SEL297W Can the system be initialized? Start engine. (END) (System initialization had not been completed. Ref. part No. F)	BF ST R BT H/ SC

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6 "SECURITY INDICATOR LAMP DOES NOT LIGHT UP"

1	CHECK FUSE			
Check 10A fuse [No. 12, located in the fuse block (J/B)].				
	Is 10A fuse OK?			
Yes		GO TO 2.		
No		Replace fuse.		

2 CHECK SECURITY INDICATOR LAMP

1. Install 10A fuse.

2. Perform initialization with CONSULT-II.

- For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".
- 3. Turn ignition switch OFF.
- 4. Start engine and turn ignition switch OFF.
- 5. Check the security indicator lamp lighting.

Security indicator lamp should be blinking.


OK or NG

ОК	INSPECTION END
NG	GO TO 3.

3 CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Disconnect security indicator lamp connector.

2. Check voltage between security indicator lamp connector terminal 4 and ground.



4	4 CHECK SECURITY INDICATOR LAMP		
Check security Indicator Lamp.			
Is security indicator lamp OK?			
Yes	►	GO TO 5.	
No	►	Replace security indicator lamp.	

Trouble Diagnoses (Cont'd)

5 CHECK IMMU FUNCTION	
 Connect IMMU connector. Disconnect security indicator lamp connector. Check continuity between IMMU terminal 5 and ground. 	GI
IMMU connector (M42)	MA
HS. Connect Connect Connect Cotinuity should exis	st intermittently.
G/OR Cotinuity should exis	LC
	SEL300W
OK or NG	FE
OK Check harness for open or short between security indicate	or lamp and IMMU.
NG IMMU is malfunctioning. Replace IMMU.	GL
Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IN	/IS/NVIS".
	AT
	AX
	SU
	BR

SC

HA

ST

RS

BT

EL

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7 Self-diagnostic results: "I OCK MODE" displayed on CONS

=NFEL0177S13


		LOCK MOE		blayed on CONSULT-II screen
1	CONFIRM SELF-DIAG	NOSTIC RESULTS		
Conf	irm SELF-DIAGNOSTIC RE	SULTS "LOCK MODE" is disp	ayed on (CONSULT-II screen.
		SELF DIAG	NOSIS]
		DTC RESULTS	TIME	_
		LOCK MODE	o	
				-
				_
				SEL295W
		Is CONSULT-II screen	lisplayed	as above?
Yes	►	GO TO 2.		
No	►	GO TO SYMPTOM MATRIX	CHART 1	

2	ESCAPE FROM LOCK	MODE		
2. Tur 3. Re 4. Re	 Turn ignition switch OFF. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds. Return the key to OFF position. Repeat steps 2 and 3 twice (total of three cycles). Start the engine. 			
	Does engine start?			
Yes	-	System is OK. (Now system is escaped from "LOCK MODE".)		
No	►	GO TO 3.		

3	3 CHECK IMMU ILLUSTRATION		
Check IMMU installation. Refer to "How to Replace IMMU" in EL-375.			
OK or NG			
OK	•	GO TO 4.	
NG	•	Reinstall IMMU correctly.	

Trouble Diagnoses (Cont'd)

4	PERFORM INITIALIZA	ION WITH CONSULT-II	
	rm initialization with CONS nitialization, refer to "CONS	JLT-II. JLT-II operation manual IVIS/NVIS".	GI
			M
		INITIALIZATION FAIL	E
		THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION	L¢
		AGAIN. SEL297	E
NOTE If the		ed or fails, CONSULT-II shows the above message on the screen.	F
		Can the system be initialized?	
Yes	►	System is OK.	
No	►	GO TO DIAGNOSTIC PROCEDURE 5 to check "CHAIN OF IMMU-KEY", refer to EL-370.	
	NVIS (NAT		— M ^{CL0178} AT



AT NOTE: If NVIS (NATS) IMMU is not installed correctly, NVIS • (NATS) system will not operate properly and SELF-DIAG AX RESULTS on CONSULT-II screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".

SU

BR

ST

RS


BT

HA

SC

EL

IDX



System Description


=NFEL0294

The Navigation System (Multi-AV System) relies upon three sensing devices in order to determine vehicle location at regular time intervals.

- 1. Vehicle speed sensor: Determines the distance the vehicle has traveled.
- 2. Gyro (Angular velocity sensor): Determines vehicle steering angle and directional change.
- 3. GPS antenna (GPS data): Determines vehicle forward movement and direction.

The data provided by the three sensing functions together with a comparison of the mapping information read from the CD-ROM drive permit accurate determination of the vehicle's current location and subsequent course (map matching). The information appears on a liquid crystal display.

This comparison of GPS data (vehicle position sensing) and map matching permits precise determination of vehicle location.



Position Sensor Operating Principles

The sensor determines current vehicle location by calculating the previously sensed position, the distance traveled from this position, and the directional changes occurring during this travel.


1. Distance traveled

The distance traveled is calculated using signals received from the vehicle speed sensor. The sensor automatically compensates for the slightly reduced wheel and tire diameter resulting from tire wear.


2. Forward movement (Direction)

Changes in the direction of forward movement are calculated by the gyro (angular velocity sensor) and the GPS antenna (GPS data). Each of these functions has its advantage and disadvantages. Depending upon conditions, one function takes precedence over the other to accurately determine the direction of forward movement.

Function type	Advantage	Disadvantage
Gyro (Angular velocity sen- sor)	 Able to accurately detect minute changes in steering angle and direction. 	 Calculation errors may accumulate over a long period of continuous vehicle travel.
GPS antenna (GPS data)	 Able to sense vehicle travel in four general directions (North, South, East, and West) 	 Unable to detect direction of vehicle travel at low vehicle speeds.




for example, when the vehicle is in a tunnel, in a parking lot inside building, under an elevated superhighway or near strong power lines, the location may not be detected. Turbulent/ electric weather conditions may also affect positioning performance. If something is placed on the antenna, the radio wave from GPS satellites may not be received.



COMPONENT DESCRIPTION Display & NAVI Control Unit

NFEL0294S02

- The gyro (angular speed sensor) and the CD-ROM drive are built-in units that control the navigation functions.
- Signals are received from the gyro, the vehicle speed sensor, and the GPS antenna. Vehicle location is determined by combining this data with the data contained in the CD-ROM map. Locational information is shown on liquid crystal display panel.
- Finger-operated touch switches are positioned on the liquid crystal display panel for easy operation.
- The touch switches used to control the equipment are beneath a glass sheet and two resistance membranes at the top of the liquid crystal display panel. The switches are sensitive to resistance value where touched with your finger to detect operating status.



CD-ROM Driver


Maps, traffic control regulations, and other pertinent information can be easily red from the CD-ROM disc.

NOTE:

- When removing the CD-ROM, allow it to remain open until the liquid crystal display locks.
- The liquid crystal display must be closed when the vehicle is running.
- Do not place cups, cans or other containers containing liquids on top of the liquid crystal display.

Map CD-ROM


- The map CD-ROM has maps, traffic control regulations, and other pertinent information.
- To improve CD-ROM map matching and route determination functions, the CD-ROM uses an exclusive Nissan format. Therefore, the use of a CD-ROM provided by other manufacturers cannot be used.



FUNCTION OF TOUCH SWITCH (SUMMARY) Display with Pushed "MAP" Switch

=NFEL0294S03






The function of each touch switch is as follows:

- 1) Azimuth indication
- Position marker The tip of the arrow shows the current position. The shaft of the arrow indicates the direction in which the vehicle is traveling.
- 3) GPS reception signal (indicates current reception conditions)
- 4) Distance display (shows the distance in a reduced scale)
- 5) Current location voice information (this information is available when the route guide is being activated and the designated route is being traveled.)
- Switch display from map screen to BIRDVIEW[®] screen (change to map screen on display when the BIRDVIEW[®] is being used.)
- 7) The following items can be set.
- Save Current Location
- Edit Address Book
- Guide Volume
- System Setting
- 8) The route guide operation can be canceled.

Display with Pushed "DEST" Switch



Icon	Description	-
Address Book	Favorite place can be saved to memory. The destination can be selected from the memory.	- A
Address/Street	The destination can be searched from the address.	_ A
Point of Interest (POI)	The destination of favorite facility can be searched.	-
Previous Dest.	The previous ten destinations stored in memory are displayed.	S
Intersection	The destination from the intersection name can be retrieved.	
City	The destination can be searched from city name.	- ©
N 4		- 3

The destination can be searched from the map.

RS

BT

HA


SC

EL

IDX

Мар

Display with Toutch Screen




The function of each touch sw	vitch is as follows:
-------------------------------	----------------------

Icon	Description
Quick Stop	The selected facility is set as the destination or way- point. (Route guidance has been turned OFF or the destination has been reached.)
Where am I?	Next, current and previous street names can be displayed.
Route Info.*	 The following items can be set. Complete Route Turn List Route Simulation (Displayed only when the destination area has been set.)
Detour*	Based on the selected distance, an alternative route is searched. [Displayed only when the recommended route (not its reverse) is followed.]
Edit Route*	Change the destination or add the transit points of the route set in the route guide. (Displayed only when the automatic reroute function has been turned OFF and the recommended route is not followed.)

*: When destinations have been entered, route guidance has been turned OFF or destination has been reached, "Route Info.", "Detour" and "Edit Route" are not displayed.

Schematic



Wiring Diagram — NAVI —

NFEL0296 IGNITION SWITCH ON or START IGNITION SWITCH ACC or ON EL-NAVI-01 BATTERY A : WITH A/T ę FUSE BLOCK (J/B) 15A M : WITH M/T 56 • 10A 1 REFER TO EL- POWER 10A 10A M17 Y/G 10 30 • • (M19) 6 Y/G 1A M15 12K (E83) 7H 12L ŌR GPS ANTENNA ΡŪ G 5 (M504) (M503) ΡĪ. 6 5 1 41 2 GPS SIG IGN ACC +B +B DISPLAY AND NAVI CONTROL UNIT (M168) , (M169) , (M502) RV GND GND GND 33 OR 6 G/W (E8) Ē (F17) OR (F10) (F151) OR 1 OR OR 3 G/W (M161) 9 (F68) G/W (F68) OR (F66) 3 (F211) OR PARK/ NEUTRAL POSITION SWITCH OR (F152) : (A) G/W BACK-UP LAMP SWITCH R ď (F212) : (M) OTHERS L2 G/W (F151) 5 (F10) G/W (F211) 6 (F66) в В В В Е G/W A Ť (M9) M25 (M87) REFER TO THE FOLLOWING. 40 38 36 34 28 26 24 22 39 37 35 33 32 31 30 29 27 25 23 21 41 (M502)* M15-SUPER 20 18 16 14 6 4 2 (M168) W (M169) GY 19 17 15 13 12 11 10 9 7 5 3 1 MULTIPLE JUNCTION (SMJ) M17 , M19 , E83 -FUSE BLOCK-JUNCTION BOX (J/B) F10 GY (F17) GY F66 GY <u>31278</u> 4596 (F152) 4 5 8

 1
 2
 3
 4
 5
 6
 7
 8
 9
 10


 11
 12
 13
 14
 15
 16
 17
 18

 (M161) W (12 F212


 $\boldsymbol{\star}\,$: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" , EL SECTION.

MEL733P

Wiring Diagram — NAVI — (Cont'd)



EL-NAVI-03




MEL160O

Self-diagnosis Mode

Self-diagnosis Mode APPLICATION ITEMS

NFEL0297

					GI	
Mode Description					MA	
Self Diagnosis			Self-diagnosis for display & NAVI control unit, CD-ROM and GPS antenna connection.	EL-388		
	Display Diagn	osis	Color and gray gradation of display can be checked in this mode.	EL-396	EM	
	Diagnostic Sig	gnals from the Car	Several input signals to display & NAVI control unit, can be monitored in this mode.	EL-394	LC	
	I Navigation	Check the Map CD- ROM Version	The version (parts number) of inserted CD-ROM can be checked in this mode.	EL-395	EC	
Confirmation/ adjustment			History of Errors	Diagnosis results previously stored in the memory (before turning ignition switch ON) are displayed in this mode. Time and location when/where the errors occurred are also displayed.	EL-390	FE
			Display Longitude & Latitude	Display the map. Use the joystick to adjust position. Lon- gitude and latitude will be displayed.	EL-397	CL
			Angle Adjustment Turning angle of the vehicle on the display can be adjusted in this mode.	EL-398	MT	
			Under ordinary conditions, the navigation system dis- tance measuring function will automatically compensate for minute decreases in wheel and tire diameter caused		AT	
		Speed Calibration by tire wear or low pressure. Speed calibration immedi- ately restores system accuracy in cases such as when distance calibration is needed because of the use of tire chains in inclement weather.	EL-399	AX		
	Initialize Locat	tion	This mode is for initializing the current location. Use when the vehicle is transported a long distance on a trailer, etc.	EL-426	SU BR	





HOW TO PERFORM SELF-DIAGNOSIS MODE

- 1. Start the engine.
- Push both of "MAP" and "D/N" switches at the same time for 2. more than 5 seconds. RS
 - BT

ST


NFEL0297S02

HA

- Touch "Self Diagnosis" or "Confirmation/ adjustment". 3.
- SC For further procedure, refer to the following pages which • describe each application item of the self-diagnosis mode.

Self-diagnosis Mode (Cont'd)

NAVIGATION SYSTEM



"Self Diagnosis"

- NFEL0297S0201
- Start the engine.
 Push both "MAP" and "D/N" switches at the same time for more than 5 seconds.
- 3. Touch "Self Diagnosis".
- 4. Self-diagnosis will be performed.

5. Diagnosis results will be displayed. Diagnosis results are indicated by display color. For details refer to "SELF-DIAGNOSIS RESULTS".

To obtain detailed diagnosis results on the screen, touch "Navigation" or "GPS Antenna".

	SEL58
Self Diagnosis Pr	evious
 Display the result of self-diagnosis. 	
Connection to the following unit is abnormal. See the Service Manual for further diagnosis.	
GPS Antenna	
	SEL58

SELF-DIAGNOSIS RESULTS

		SE	ELF-DIAGNOSIS RESULTS	=NFEL0297S03
Diagnosed item	Displayed color	Detailed result	Description	Diagnoses/service procedure Recheck system at each check or replacement (When malfunction is eliminated, further repair work is not required.)
"GPS Antenna" (GPS antenna con- nection)	Green	_	GPS antenna is connected to dis- play & NAVI control unit correctly.	_
	Yellow	Connection to the follow- ing unit is abnormal. See the Service Manual for further diagnosis.	GPS antenna connection error is detected.	 Check GPS antenna feeder cable connection at display & NAVI control unit. Visually check GPS antenna feeder cable. If NG, replace GPS antenna assembly. Replace GPS antenna.
	Green	_	No failure is detected.	_
"Navigation" (Display & NAVI control unit)	Red	[*** is abnormal.]	Display & NAVI control unit is mal- functioning.	Replace display & NAVI control unit.
	Gray	Self-diagnosis for CD- ROM DRIVER of NAVI was not conducted because no CD-ROM was available.	Any CD-ROM is not inserted or dis- play & NAVI control unit is malfunc- tioning.	 Confirm that map CD-ROM is not inserted into display & NAVI con- trol unit. Replace display & NAVI control unit.
		CD-ROM or CD-ROM DRIVER of DISP & NAVI is abnormal. See the Service Manual for fur- ther diagnosis.	Display & NAVI control unit judges that inserted CD-ROM is malfunc- tioning. Map CD-ROM or CD-ROM driver of the unit is malfunctioning.	 Confirm the disk is installed correctly (not up side down.) Perform "CHECK THE MAP CD-ROM VERSION" in EL-395 to confirm whether correct CD-ROM is inserted or not. Check the disk surface. Are there
	Yellow	CD-ROM is abnormal. Please check the disc.	Inserted map CD-ROM can not be read. Map CD-ROM or CD-ROM driver of the unit is malfunctioning.	 any scratches, abrasions or pits on the surface? Replace the CD-ROM. Replace display & NAVI control unit.
		Connection to the follow- ing unit is abnormal. See the Service Manual for further diagnosis.	GPS antenna connection error is detected.	 Check GPS antenna feeder cable connection at display & NAVI control unit. Visually check GPS antenna feeder cable. If NG, replace GPS antenna assembly. Replace GPS antenna.

HA

SC

EL

Confirmation/Adjustment Mode "HISTORY OF ERRORS" MODE

Description

=NFEL0298 NFEL0298S01

NEEI 029850102

NFEL0298S0101 In this mode, historical errors of the system are displayed with the following data.

- How many times the error was detected •
- The last time data when the error was detected
- The last place where the error was detected

NOTE:

- The number of errors can be counted up to 50 times. More than 51 times will be indicated as 50 times.
- Malfunction of the GPS board (inside the display & NAVI control unit) will result in the display of incorrect time data.
- When an error occurs, an incorrect position marker appears on the display. The accuracy of the display data (position marker) will be affected.

Select one of the following. Self Diagnosis Confirmation/ adjustment Self Diagnosis Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation Initialize Location	Jeli Diag	nosis	P	revious
Confirmation/ adjustment Silect one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation	Select o	ne of the following.		
Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation		Self Diagno	osis	
Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation		Confirmation/ ac	ljustment	
Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation				
Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation				
Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation				01
Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation				01
Select one of the following. Display Diagnosis Diagnostic Signals from the Car Navigation				
Display Diagnosis Diagnostic Signals from the Car Navigation	Confirmat	ion/Adjustment	Pi	revious
Diagnostic Signals from the Car Navigation	Select o	ne of the following.		
Navigation		Display D	iagnosis	
		Disconstin Cinnal		_
Initialize Location		Diagnostic Signal	s from the Ca	r
		Naviga	ation	
		Naviga	ation	

Navigatio	n				Previous
Select	one of t	he follow	ring.		
	Chec	k the Ma	p CD-RO	M Vers	ion
		Histor	ry of Erro	rs	
	Di	splay Lor	ngitude &	Latitud	e
		Angle	Adjustme	ent	
		Speed	Calibrati	оп	

How to Perform

1.

- Start the engine. Push both "MAP" and "D/N" switch at the same time for more 2. than 5 seconds.
- 3. Touch "Confirmation/ adjustment".
- 4. Touch "Navigation".

Touch "History of Errors". 5.

NA



VI	GATION SYSTEM	
	Confirmation/Adjustment Mode (Cont'd)	
6.	If trouble items are displayed with time count, repair/replace the system according to "HISTORY OF ERRORS" TABLE, EL-392.	GI
7. o	If necessary, touch error item to display the time when the error was detected and the place where the error was detected.	MA
8.	After repairing the system, erase the diagnosis memory.	0/00/-4
	en the display & NAVI control unit must be replaced, do not se the diagnosis memory for further inspection of malfunc-	EM
a.	Start the engine.	LC
b.	Push both "Map" and "D/N" switches at the same time for more than 5 seconds.	ĽV
c.	Touch "Confirmation/ adjustment".	EC
d.	Touch "Navigation".	
e.	Touch "History of Errors".	FE
f.	Touch "Delete".	
g.	Touch "Yes".	CL
		MT
		AT
		AX

BR

SU

ST

RS

BT

HA

SC

EL

IDX

"HISTORY OF ERRORS" TABLE

"HISTORY OF ERRORS" TABLE					
Detected items	Description	Diagnosis/service procedure	Refer- ence page		
Gyro sensor disconnected	Communications malfunction between display & NAVI control unit and internal gyro	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or tempo- rary malfunction may have been caused by strong electromagnetic wave interfer- ence.	EL-387		
Connection problem of speed sensor	Input malfunction of display & NAVI con- trol unit and speed sensor	Check vehicle speed sensor signal in "DIAGNOSTIC SIGNALS FROM THE CAR" mode. If the input signal is not detected correctly, check harness for open or short between combination meter and display & NAVI control unit.	EL-394		
GPS disconnected		Perform self-diagnosis to confirm whether the display & NAVI control unit	EL-387		
GPS transmission cable malfunc- tion	Communications malfunction between display & NAVI control unit and GPS board	is malfunctioning or not. If no failure is detected, a momentary and/or tempo- rary malfunction may have been caused			
GPS input line connection error		by strong electromagnetic wave interference.			
GPS TCXO over	The transmission circuit of the GPS board frequency synchronization oscilla- tor (inside the display & NAVI control	A location error occurs. Strong electro- magnetic wave interference may have occurred. The GPS antenna may be in a	_		
GPS TCXO under	unit) is sending an oscillation frequency that is greater or less than the set value.	very hot or very cold environment. This is usually a temporary malfunction.			
GPS ROM malfunction	Internal malfunction of GPS board RAM or ROM inside the display & NAVI con-	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or tempo-			
GPS RAM malfunction	trol unit.		EL-387		
GPS RTC malfunction	Malfunction of GPS board clock IC inside the display & NAVI control unit.	rary malfunction may have been caused by strong electromagnetic wave interfer- ence.			
GPS antenna disconnected	_	Perform self-diagnosis to confirm GPS antenna connection. If no failure is detected, a momentary and/or tempo- rary malfunction may have been caused by a strong impact.	EL-388		
		1. Check power supply circuits for dis- play & NAVI control unit.	EL-411		
Low voltage of GPS	Power supply voltage for GPS board inside the display & NAVI control unit is	2. Perform self-diagnosis to confirm GPS antenna connection.	EL-388		
Low voltage of GFS	low.	3. If above diagnosis results are OK, a momentary and/or temporary malfunc- tion may have been caused by a strong impact.	_		
CD-ROM communication error	CD-ROM driver malfunction (inside the display & NAVI control unit)	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or tempo- rary malfunction may have been caused by strong electromagnetic wave interfer- ence.	EL-387		

Confirmation/Adjustment Mode (Cont'd)

Detected items	Description	Diagnosis/service procedure	Refer- ence page	G]
Loading mechanism malfunction	_	Check that whether the disc can be inserted and ejected correctly. If the loading function does not operate correctly, replace display & NAVI control unit.	_	MA EM
CD-ROM reading error	It is confirmed that the appropriate CD- ROM disc is positioned in the CD-ROM loader. However, no data can be read.	Perform self-diagnosis to confirm whether the inserted disc is malfunction-	EL-387	LC
Malfunctioning of error correction for CD-ROM	Erroneous data is read from the CD- ROM. The errors cannot be corrected.	ing or not.		EC
CD-ROM focus error	CD-ROM data reading beam is out of focus.	Rough road driving might create CD skipping like music CD audio unit.	_	
CD-ROM malfunction	_	Perform self-diagnosis to confirm whether the inserted disc is malfunction- ing or not.	EL-387	FE

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

EL-393


"DIAGNOSTIC SIGNALS FROM THE CAR" MODE

Description

In "Diagnostic Signals From the Car" mode, following input signals to the display & NAVI control unit can be checked on the display.

Item	Indication	Vehicle condition
Vehicle Speed*	ON	Vehicle speed is greater than 0 km/h (0 MPH).
	OFF	Vehicle speed is 0 km/h (0 MPH).
Light	ON	Lighting switch is in 1st or 2nd position.
	OFF	Lighting switch is in "OFF" position.
IGN	ON	Ignition switch is in "ON" position.
	OFF	Ignition switch is in "ACC" position.
Reverse	ON	Selector/shift lever is in "reverse" position.
	OFF	Selector/shift lever is in other than "reverse" position.

*: When ignition switch is in "ACC" position, indication will be changed to "---".



vehicle speed	OFF
light	OFF
IGN	ON
reverse	OFF

How to Perform

1. Start the engine.

NFEL0298S0302

=NFEL0298S03

- 2. Push both "MAP" and "D/N" switches at the same time for more than 5 seconds.
- 3. Touch "Confirmation/ adjustment".
- 4. Touch "Diagnostic Signals from the Car".

5. Then "Diagnostic Signals from the Car" mode is performed.

	"C	HECK THE MAP CD-ROM VERSION" MODE		
Self Diagnosis Previous	Но	w to Perform	=NFEL0298S04	0.1
Select one of the following.	1.	Start the engine.	NFEL0298S0401	GI
Self Diagnosis	2.	Push both "MAP" and "D/N" switches at the same time for	or more	
Confirmation/ adjustment		than 5 seconds.		MA
	3.	Touch "Confirmation/ adjustment".		
				EM
				LUVU
SEL584X		- I «SI I I I I		LC
	4.	Touch "Navigation".		
Confirmation/Adjustment Previous Select one of the following.				EC
Display Diagnosis				
Diagnostic Signals from the Car				FE
Navigation				
Initialize Location				CL
				01
				MT
SEL588X				UVU U
	5.	Touch "Check the Map CD-ROM Version".		
Navigation Previous				AT
Select one of the following.				
Check the Map CD-ROM Version				AX
History of Errors				
Display Longitude & Latitude				SU
Angle Adjustment Speed Calibration				
opeca campration				BR
SEL453Y				
	6.	The version (parts number) of CD-ROM loaded to the	display	ST
Check the map CD-ROM version Previous		and NAVI control unit will be displayed.		01
Installed CD-ROM				RS
25920 4L700-00				ЫÐ
Installed PROGRAM				
ILK22002				BT
				HA
SEL592X				
				SC
				EL


IDX

"DISPLAY DIAGNOSIS" MODE

Description

=NFEL0298S05

Use the "Display Diagnosis" mode to check the display color brightness and shading. The display & NAVI control unit must be replaced if the color brightness and shading are abnormal.




How to Perform

1. Start the engine.

- NFEL0298S0502
- 2. Push both "MAP" and "D/N" switches at the same time for more than 5 seconds.
- 3. Touch "Confirmation/ adjustment".
- 4. Touch "Display Diagnosis".

- 5. Touch "Display Color Spectrum Bar" or "Display Gradation Bar".
- 6. Then color bar/gray scale will be displayed.



Confirmation/Adjustment Mode (Cont'd)

"DISPLAY LONGITUDE & LATITUDE" MODE Description

The "Display Longitude & Latitude" is used to confirm the longitude and latitude of some optional area point. GI

NFEL0298S06

EM	

LC

MT

IDX

0602	
	EC

Self Diagnosis Previous • Select one of the following. Self Diagnosis Confirmation/ adjustment Self Diagnosis	Ho 1. 2. 3.	NFEL029850602 Start the engine. Push both "MAP" and "D/N" switches at the same time for more than 5 seconds. Touch "Confirmation/ adjustment".	EC FE CL
SEL584X Confirmation/Adjustment Previous Select one of the following. Display Diagnosis Diagnostic Signals from the Car	4.	Touch "Navigation".	MT AT AX
Navigation Initialize Location SEL588X	5.	Touch "Display Longitude & Latitude".	SU BR ST
Check the Map CD-ROM Version History of Errors Display Longitude & Latitude Angle Adjustment Speed Calibration SEL453Y	6.	Adjust the pointer with using the joystick and touch "Set".	RS BT HA
Display Longitude & Latitude Previous CENTUPY BLOD CENTUP	0. 7.		SC EL IDX

SEL595X


"ANGLE ADJUSTMENT" MODE

Description

=NFEL0298S07

If the display indicates a larger or smaller turning angle than the actual turning angle, the gyro (angular speed sensor) sensing values must be checked.

In case that the vehicle on the display makes larger angle turn than reality, touch "–". In case that the vehicle on the display makes smaller angle turn than reality, touch "+".



Left Turn

Right Turn

Set

SEL456Y

How to Perform

1. Start the engine.

- NFEL0298S0702
- 2. Push both "MAP" and "D/N" switches at the same time for more than 5 seconds.
- 3. Touch "Confirmation/ adjustment".
- 4. Touch "Navigation".

5. Touch "Angle Adjustment".

- 6. Touch "Left Turn" to adjust the angle to the left. Touch "Right Turn" to adjust the angle to the right.
- 7. Touch "+" to increase the angle change coefficient or "-" to reduce the angle change coefficient.
- 8. Touch "Set" to save the changed values in memory.
- 9. Then the vehicle turning angle on the display has adjusted.

		EED CALIBRATION	
Self Diagnosis Previous Select one of the following. Self Diagnosis	1. 2.	Start the engine. Push both "MAP" and "D/N" switches at the same time for more than 5 seconds.	G]
Confirmation/ adjustment	3. 4.	Touch "Confirmation/ adjustment". Touch "Navigation".	MA
			EM
SEL584X			LC
	5.	Touch "Speed Calibration".	
Navigation Previous Previous Select one of the following.			EC
Check the Map CD-ROM Version History of Errors			FE
Display Longitude & Latitude			
Angle Adjustment Speed Calibration			CL
SEL453Y			MT
Speed Calibration Previous	6. •	Touch "+" or "-" to adjust the distance change coefficient. To make the distance change coefficient smaller, touch "-". To make the distance change coefficient larger, touch "+".	AT
Choose "+" then press "Set" if the vehicle icon is behind the actual location. Choose "-" then press "Set" if it is ahead, then choose "Set".	7.	Touch "Set".	AX
			SU
SEL457Y			BR
			ST

HA

RS

BT

SC


EL

IDX

Setting Mode APPLICATION ITEMS

=NFEL0299

		NFEL0299S01
Mode	Description	Reference page
Display Setting	The following display settings can be customized.Display color (Day mode or Night mode)Brightness of display	EL-402
Heading	Heading of the map display can be customized for either north heading or the actual driving direction of the vehicle.	EL-405
Nearby Display Icons	Icons of facilities can be displayed. Facilities to be displayed can be selected from the variety of selections.	EL-406
Adjust Current Loca- tion	Current location of position marker can be adjusted. Direction of position marker also can be calibrated when heading direction of the vehicle on the display is not matched with the actual direction.	EL-401
Avoid Area Setting	Particular area can be avoided when routing.	_
Beep on/off	Beep sounds which correspond to the system operation can be activated/deactivated.	EL-402
Clear Memory	Address book, Previous destination or Avoid area can be deleted.	EL-406
GPS Information	The GPS includes longtitude, latitude and altitude (distance above sea level) of the present vehicle position, and current date and time for the area in which the vehicle is being driven. Also indicated are the GPS reception conditions and the GPS satellite position.	EL-400
Map & A/C	The map and A/C settings can be displayed at the same time.	EL-407
Quick Stop Customer Setting	One facility of your selection can be added to your Quick Stop.	EL-403
Route Priorities	Priorities of search request and automatic re-searching can be set for route search.	EL-404
Tracking	Tracking to the present vehicle position can be displayed.	EL-405



HOW TO PERFORM CONTROL PANEL MODE

1. Start the engine.

NFEL0299S02

- 2. Push "MAP" switch.
- For further procedures, refer to the following pages which describe each application item of the control panel mode.

"GPS INFORMATION" SETTING

NFEL0299S03

- 1. Start the engine.
- 2. Push "MAP" switch.
- 3. Touch "Setting".

4. Touch "System Setting". SETTINGS GI Select one of the following. Save Current Location MA System Setting Edit Address Book EM Softer Louder Guide Volume LC SEL461Y 5. Touch "GPS Information". EC, SYSTEM SETTINGS Clear Memory FE **GPS** Information Map & A/C CL Quick Stop Customer Settings **Route Priorities** MT SEL462Y Then GPS information will be displayed. 6. AT Previous GPS Information Calculation Longitude Latitude 8 dimension 118.24.14 38.57.26 AX Altitude 00 ß 6000 SU Qa. 3000 0 BR SEL146W "ADJUST CURRENT LOCATION" SETTING ST NFEL0299S04 Start the engine. 1. 2. Push "MAP" switch. BAFFEY ST 3. Touch "Setting". Touch "System Setting". 4. View Setting BT Cancel 1/8 m HA SEL460Y 5. Touch "Adjust Current Location". SC SYSTEM SETTINGS Select one of the following. EL Nearby Display Icons Adjust Current Location IDX Avoid Area Setting Beep on/off Clear Memory


SEL463Y

0%

BAFFEY ST

View

BEEP ON/OFF



NAVIGATION SYSTEM

- 6. Touch " \bigcirc " or " \bigcirc " to calibrate the heading direction. (Arrow marks will rotate corresponding to the calibration key.)
- Touch "Set". Then the vehicle mark will be matched to the 7. arrow mark.
- Display will show "Heading direction has been calibrated" and 8. then go back to the current location map.

BEEP ON/OFF SETTING

Start the engine. 1.

- 2. Push "MAP" switch.
- 3. Touch "Setting".
- 4. Touch "System Setting".

Touch "Beep on/off".

NFEL0299S05

TEM SETTINGS	
ect one of the following.	
Nearby Display Icons	
Adjust Current Location	
Avoid Area Setting	
Beep on/off	
Clear Memory	

Setting

Cancel

SEL460Y

SEL463Y		
	6.	Touch "On" c
	•	lf you want tl
	•	If vou do not

5.

- or "Off" icon.
- he beep sound, select "ON".
- want the beep sound, select "OFF".
- 7. Push "MAP" switch, then the display will go back to the current location map.


DISPLAY SETTING Description

NFEL0299S06

NFEL0299S0601 The following display setting can be changed in this mode.

- Dimmer operation (when lighting switch is turned on.) •
- Display color (Day mode or Night mode)
- Brightness of display

Select one of the following. On Off SEL464Y



D

	PLAY COLOR SETTING	
1.	Start the engine.	on
2.	Push "MAP" switch.	GI
3.	Touch "Setting".	
4.	Touch "System Setting".	MA
5.	Touch "Display Setting".	0000 Q
6.	Touch "Background". Display color will change to Day mode/ Night mode.	EM
7.	Touch "Previous".	
NO.	TE:	LC
•	Display color can be changed independently when light- ing switch is turned on and off.	ĽV
•	The D/N button is used to change the display color the same way as the "Background" icon.	EC
•	Initial setting of the color is as follows: When lighting switch is turned off: Day mode When lighting switch is turned on: Night mode	FE
	Day mode: White background Night mode: Black background	CL
		MT
BR	IGHTNESS SETTING	
1.	Start the engine.	AT

- DISPLAY SETTINGS # 82MD ST ¥ 83RD W 84TH ST Background V 84TH PL Brighter Contrast SEL465Y
- 1. 2. Push "MAP" switch. 3. Touch "Setting". AX Touch "System Setting". 4. 5. Touch "Display Setting". SU Touch "Brighter" or "Dark" to adjust the brightness of display. 6. Touch "Previous". 7. NOTE: BR Display brightness can be adjusted independently when light-
- ing switch is turned on and off. ST

BAFEEY ST
View too the setting Setting Cancel
SEL460Y

"QUICK STOP CUSTOMER SETTING" MODE NFEL0299S09 1. Start the engine. 2. Push the "MAP" switch.

- 3. Touch "Setting".
- Touch "System Setting". 4.

IDX

EL

BT

HA

SC

Setting Mode (Cont'd)

	TEM SETTINGS	Previous
sele	ect one of the following.	
	Clear Memory	
	GPS Information	
	Map & A/C	
	Quick Stop Customer Settings	
	Route Priorities	
		SEL462Y
	K STOP	
	ect one of the following.	
	ATM (CASH)	
	GAS STATION	
	RESTAURANT	
	HOSPITAL	
	AMUSEMENT PARK(USER DEF	INED)
_		
		SEL466Y
BAFEE	iew DOD WE EVALUATE AVE	Setting Cancel Band SEL460Y

5. Touch "Quick Stop Customer Setting".

6. Select from the itemized list.

"ROUTE PRIORITIES" MODE

NFEL0299S10

- 1. Start the engine.
- 2. Push the "MAP" switch.
- 3. Touch "Setting".
- 4. Touch "System Setting".
- 5. Touch "Route Priorities".

6. Select from the itemized list.

DEST. SETTING		
Shortest Time	Shortest Distance	Auto Reroute
Minimize T		
Minimize	Waypoint	
Use Time Restricted Roads		
Use Ferry Route		ок

SEL467Y

SYSTEM SETTINGS

Select one of the following.

Route Priorities

Tracking

Display Setting
Heading

Nearby Display Icons

EL-404

Setting Mode (Cont'd)

 Start the engine. Nature of the APP switch. Touch "System Setting". Touch "System Setting". Touch "Tracking". Touch "System Setting". Touch "System Setting". Touch "Tracking". 		"TRACKING" MODE	
SELARY 2. Push the "MAP" switch. 3. SELARY 3. Touch "System Setting". 3. SELARY 5. Touch "Tracking". 3. SELARY 5. Touch the "On" or "Off" icon. 4. SELARY 6. Touch "Tracking". 3. SELARY 7. S. 3. 3. SELARY 8. S. 3.		1. Start the engine.	
S. Touch "System Setting". NA Stilled Stilled Stiled			GI
Image: Section of Control System Setting". MA Section of Control Setting in the System Setting i	CAFEY SI	3. Touch "Setting".	
SELAGY Sin	View by ma Setting		MA
State State State State State S		, ,	0/02~2
SELAROY LC SELAROY S. Touch "Tracking". LC Selaroy S. Touch "Tracking". LC Selaroy Selaroy LC LC Selaroy Selaroy LC LC Selaroy Selaroy LC LC Selaroy Selaroy LC LC Selaroy C. Touch "Tracking". LC Selaroy C. Touch the "On" or "Off" icon. AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map. select "Off". AT I you need a trail on the map. select "Off". AT I you need a trail on the map. select "Off". AT I you need a trail on the map. select "Off". AT			
Strictor III Strictor Strictor Strictor </th <th></th> <th></th> <th>EM</th>			EM
S. Touch "Tracking". S. Image: Sector Sec	TILET ROTTE & LUN		
S. Touch "Tracking". S. Image: Sector Sec			10
SYSTEM SETTINOS EC Visited car of the following FR Display Setting GL SELGET F SELGET 6. Touch the "On" or "Off" icon. SELGET F I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail on the map, select "Off". AT I you need a trail display is turned OFF, trail data is erased from the memory. AT I Start the engine. III I Start the engine. IIII I Start the engine. IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	3624001		LU
Image: Setting inclusion		5. Touch Tracking.	
Reade Priorities PR Tracking Cl. Network Setting Not SELLEGY Cl. Not Cl. SELLEGY Cl. SELLEGY Cl. Not Cl. SELLEGY Sellegy Sellegy Cl. Sellegy Cl. Sellegy Cl. Sellegy Cl.			EC
Image: Setting File Dipploy: Setting C Note the "On" or "Off" icon. NT Image: SetLeter C Image: SetLeter C <tr< th=""><th></th><th></th><th></th></tr<>			
Image: setting in the setting marks (set), setter for the formation marks (set), setter formation marks (set), setter formation marks (set), set (set),	Route Priorities		FF
Image:	Tracking		
SELAFYY 6. Couch the "On" or "Off" icon. If I You don't need a trail on the map, select "On". If If I You don't need a trail on the map, select "On". If If I You have "MAP" switch to return the display to the current location map. If I You have "MAP" switch to return the display to the current location map. If I You have "MAP" switch to return the display to the current location map. If I You have "MAP" switch to return the display to the current location map. If I You have "MAP" switch to return the display to the current location map. If I You have "MAP" switch to return the display to the current location map. If I You have "MAP" switch. If I Start the engine. If I You have "MAP" switch. If I You have "MAP" switch. If I You have "MAP" switch. If I You have "System Setting". If I You have "Map" switch. If	Display Setting		
SELGEY If you don't need a trail on the map, select "Of". If you con't need a trail on the map, select "Of". If you need a traid trait on the map, select "Of".	Heading		GL
SEL4017 6. Touch the "On" or "Off" icon. AT I f you don't need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f off If If If If I f off If If If If If I f off If If If If If If I f of f off If If If If I	Nearby Display Icons		
SEL4017 6. Touch the "On" or "Off" icon. AT I f you don't need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f you need a trail on the map, select "Off". If If I f off If If If If I f off If If If If If I f off If If If If If If I f of f off If If If If I			MT
 If you don't need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail on the map, select "Off". If you need a trail display is turned OFF, trail data is erased from the memory. If the engine. If you che "Statt the engine. If you che "Stat	SEL467Y		000 0
 If you need a trail on the map, select "On". Push the "MAP" switch to return the display to the current origination map. If you need a trail on the map, select "On". Push the "MAP" switch to return the display to the current origination map. NOTE: When a trail display is turned OFF, trail data is erased from the memory. If the action map. NOTE: When a trail display is turned OFF, trail data is erased from the memory. If the action map. NOTE: When a trail display is turned OFF, trail data is erased from the memory. If the action map. If the action			<u> </u>
on AX or Or or Or SELGEOV RE When a trail display is turned OFF, trail data is erased from the memory. SU Image: Seldeov RE Image: Seldeov ST	TRACKING		AT
Image: Constraint of the second of the se	To delete the tracking marks (ooo), select "Off".		
On Or orr When a trail display is turned OFF, trail data is erased from the memory. SEL4697 When a trail display is turned OFF, trail data is erased from the memory. SEL4697 WHENDER VIEL00000 MEL00000 SEL4697 WHENDER VIEL00000 ST Sel4697 Statt the engine. Sel4697 Statt the "MAP" switch. Sel4697 Statt the "System Setting". Sel4697 Statt the engine. Sel4697 Statt the engine. Sel4697 Statt the engine. Sel4697 Statt the engine. Statt the engine. Statt the engine.<			AX
or When a trail display is turned OFF, trail data is erased from the memory. SU SELGOP When a trail display is turned OFF, trail data is erased from the memory. BR SELGOP "HEADING" MODE WELDERSTON TO ST SU Statt the engine. ST ST SELGOP SELGOP ST ST SELGOP ST ST ST SELGOP ST ST ST SELGOP		location map.	
SEL469Y Imemory. Immory.	On	NOTE	
SEL469Y **EL0000G** MODE **EL0000G** C ST Image: Selection of the following: Selection of the following: Heading **EL000G** C St St State Priorities St St St St Image: Selection of the following: Heading St St St St Image: St St St St St St Image: St St <t< th=""><th></th><th></th><th>@11</th></t<>			@11
SELGOY **HEADING" MODE . Start the engine. . Push the "MAP" switch. . Touch "Setting". . Touch "System Setting". ** ** ** ** ** ** ** ** ** *		When a trail display is turned OFF, trail data is erased from the	SU
Image: Strep Setting ing ing ing ing ing ing ing ing ing		When a trail display is turned OFF, trail data is erased from the	SU
 Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". Touch "System Setting". 	mo	When a trail display is turned OFF, trail data is erased from the	
 Start the engine. Push the "MAP" switch. Touch "System Setting". Touch "System Setting". 	mo	When a trail display is turned OFF, trail data is erased from the memory.	
2. Push the "MAP" switch. 3. Touch "Setting". 4. Touch "System Setting". BT HAA SEL460Y 5. Touch "Heading". 5. Touch "Heading". EL EL Display Setting Heading	Off SEL469Y	When a trail display is turned OFF, trail data is erased from the memory.	BR
 Setting . Fouch "System Setting". Touch "System Setting". BT HA Setted Setting . <l< th=""><th>Off SEL469Y</th><th>When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE</th><th>BR</th></l<>	Off SEL469Y	When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE	BR
SYSTEM SETTINGS SC System Setting EL Heading Display Setting Heading Display Setting	SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. 	BR ST
Image: Select one of the following. Fourte Priorities Tracking Display Setting Heading	Orr SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST
Image: Select one of the following. Fourte Priorities Tracking Display Setting Heading	Orr SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST
SEL460Y SC SYSTEM SETTINGS SC Select one of the following. EL Tracking Display Setting Heading IDX	Off SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST RS
SEL460Y SC SYSTEM SETTINGS SC Select one of the following. EL Tracking Display Setting Heading IDX	Off SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST RS
5. Touch "Heading". SC SC SC SC SC SC SC SC SC SC	Off SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST RS BT
SYSTEM SETTINGS Select one of the following. Route Priorities Tracking Display Setting Heading	Off SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST RS BT
Select one of the following. Route Priorities Tracking Display Setting Heading	Off SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". 	BR ST RS BT
Select one of the following. Route Priorities Tracking Display Setting Heading	Off SEL469Y	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA
Route Priorities Tracking Display Setting Heading	DIF SEL409 VIEW UND	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA
Display Setting Heading		 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA SC
Heading	Off SEL469Y Image: Selfing of the following.	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA SC
	Off	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA SC EL
	Off SEL469Y Image: Concellent of the following. Selfert one of the following. Route Priorities Tracking	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA SC EL
	Off SEL469Y Off Off Off Selfers Off Off Off Selfers Off Selfers Selfers Selfers Select one of the following. Route Priorities Tracking Display Setting	 When a trail display is turned OFF, trail data is erased from the memory. "HEADING" MODE Start the engine. Push the "MAP" switch. Touch "Setting". Touch "System Setting". 	BR ST RS BT HA SC EL

SEL467Y

Setting Mode (Cont'd)

SYSTEM SETTINGS

Select one of the following.

Nearby Display Icons

Adjust Current Location

Avoid Area Setting

Beep on/off


Clear Memory

NEARBY DISPLAY ICONS

Select the items to display on the map.

ATM (CASH) GAS STATION HOTEL RESTAURANT REST AREA

NAVIGATION SYSTEM



- 6. Touch the "Heading up" or "North up" icon.
- To display North up, select "North up".
- To display the car heading up, select "Heading up".
- 7. Push the "MAP" switch, then the display will go back to the current location map.

"NEARBY DISPLAY ICONS" MODE

- 1. Start the engine.
- 2. Push the "MAP" switch.
- 3. Touch "Setting".
- 4. Touch "System Setting".
- 5. Touch "Nearby Display Icons".

SEL460Y

SEL463Y

SEL471Y


- 6. Select and touch the itemized list.
 - 7. Push the "MAP" switch to return the display to the current location map.

"CLEAR MEMORY" MODE

- 1. Start the engine.
- 2. Push the "MAP" switch.
- 3. Touch "Setting".
- 4. Touch "System Setting".

NFEL0299S14

NFEL0299S13



EL-406

	5.	Touch "Clear Memory".	
SYSTEM SETTINGS Previous Select one of the following. Clear Memory			G]
GPS Information			MA
Map & A/C Quick Stop Customer Settings			EM
Route Priorities			LSUVU
SEL462Y	0		LC
CLEAR MEMORY Select "Yes" to delete all the stored places in "Address Book", "Avoid Area" and "Previous Dest.".	6.	To delete all the stored places in the "Address Book", "Avoid Area" and "Previous Dest.", select "Yes".	EC
Dest.". Yes			FE
No			CL
SEL472Y			MT
	7.	When the "Yes" icon is selected, the stored data will be cleared, and the [SYSTEM SETTINGS] screen will appear.	AT
■ Are you sure?			AX
Yes			SU
SEL473Y			BR
		IAP & A/C" MODE	ST
BAFEEY ST	2.	Start the engine. Push "MAP" switch.	-
View boo kyr 5 A	3. 4.	Touch "Setting". Touch "System Setting".	RS
II THER AVE			BT
V8 million SEL460Y			HA
JLL4001	5.	Touch "MAP & A/C".	SC
SYSTEM SETTINGS Previous = Select one of the following.			EL
Clear Memory GPS Information			
Map & A/C			IDX
Quick Stop Customer Settings Route Priorities			
SEL462Y			

Setting Mode (Cont'd)

fap & A/C	Previous
Select one of the following.	
Map & A/C	
map a Aro	
Мар	

NAVIGATION SYSTEM

- 6. Touch "Map & A/C" or "Map" icon.
- To set the split display with both the map and the air conditioner information as the initial setting of the NAVI system, select "MAP & A/C".
- To set the map only display as the initial setting of the NAVI system, select "MAP".
- 7. Push "MAP" switch, then the display will go back to the current location map.

NOTE:


When the enlarged view is displayed, the air conditioner control screen will not be displayed.

Trouble diagnoses SYMPTOM CHART

NFEL0300

	SYMPTOM CHART	NFEL0300S01
Symptom	Diagnoses/service procedure	Reference page
Any function of the system does not operate.	Check power supply and ground circuit for display & NAVI control unit.	EL-411
Strange screen color or	1. Check "DISPLAY SETTING".	EL-402
unusual screen brightness.	2. Check display in "Diagnosis of Display" MODE.	_
The display is not dimmed	1. Check "DISPLAY SETTING".	EL-402
when turning lighting switch to ON.	2. Check lighting switch signal input to display & NAVI control unit correctly in "DIAGNOSTIC SIGNAL FROM THE CAR" MODE.	EL-394
No navigation guide voice are heard from both front	1. Check "Voice Guidance Setting".	_
speakers.	2. Check voice guide operation.	EL-412
Beep does not sound when the system guides route.	Check "BEEP ON/OFF SETTING".	EL-402
Position marker does not trace along the route being traveled.	Go to "WORK FLOW FOR NAVIGATION INSPECTION".	EL-409
Position marker does not indicate forward or backward movement.	Check reverse signal input to display & NAVI control unit correctly by "DIAGNOS- TIC SIGNAL FROM THE CAR" MODE.	EL-394
Radio wave of GPS cannot be received. (GPS marker	1. Is there anything obstructing the GPS antenna on the rear parcel finisher? (GPS antenna located under the rear parcel finisher.)	_
on the display does not	2. Check GPS radio wave receive condition in "GPS INFORMATION SETTING".	EL-400
become green color.)	3. Check GPS antenna in "Self Diagnosis".	EL-387
Heading direction of position	1. Perform "ADJUST CURRENT LOCATION" SETTING.	EL-401
marker does not match vehicle direction.	2. Go to "WORK FLOW FOR NAVIGATION INSPECTION".	EL-409
Stored location in the address book and other memory functions are lost when battery is disconnected or becomes discharged.	Stored location in the address book and other memory functions may be lost if the battery is disconnected or becomes discharged. If this should occur, charge or replace the battery as necessary and re-enter the information.	_
Map appears grey and can- not be scrolled.	The current location in the memory is out of the map data area. Perform "Initialize Location".	EL-426

WORK FLOW FOR NAVIGATION INSPECTION



IDX

DRIVING TEST

During the driving test, diagnose the system by checking the difference of symptoms with each sensor ON or OFF.

Test pattern 1

Test method in which current position adjustment is not made according to GPS data.

Remove the GPS antenna connector from the display & NAVI control unit. Drive the vehicle.
 Before driving the vehicle, perform "ADJUST CURRENT LOCATION" (EL-401).

Test pattern 2

Test procedure in which map matching is not used.

 Before driving the vehicle, perform "ADJUST CURRENT LOCATION" (EL-401). With the ignition switch OFF and the map CD-ROM removed from the display & NAVI control unit, drive the vehicle. After driving the vehicle, reinstall the map CD-ROM. Compare the saved driving tracks for the vehicle's current location with roads on the map.

Example


<The position marker consistently indicates the wrong position when driving in the same area. Determine if this is the result of the map matching function or the GPS function.>

 \rightarrow Perform test pattern 1.

<To verify the accuracy of the road configuration shown on the display>

- \rightarrow Perform test patterns 1 and 2.
- Compare the map and the saved driving tracks. The precision of the saved driving tracks is within several hundred meters.
- <To make distance calibration and adjustments>
- \rightarrow Perform test patterns 1 and 2.
- Make adjustments by driving the vehicle over a known course (highway or other road where distances are clearly marked). Calibrate the distance against the known distance. Use the formula below.

Calibration value = Screen display distance/Actual distance



POWER SUPPLY AND GROUND CIRCUIT CHECK FOR **DISPLAY & NAVI CONTROL UNIT** =NFEL0300S04 Power Supply Circuit Check

GI

rowei	Suppiy		CHECK		NFEL0300S0401	0.0
	Terminals	S		Ignition switch		DЛ A
	(+)					MA
Con- nector	Terminal (Wire color)	(–)	OFF	ACC	ON	EM
	1 (Y)	Ground	Battery voltage	Battery voltage	Battery voltage	LC
MACO	2 (Y)	Ground	Battery voltage	Battery voltage	Battery voltage	
M168	5 (G)	Ground	0V	0V	Battery voltage	EC
	6 (PU)	Ground	0V	Battery voltage	Battery voltage	
	chock the	followin				FE

If NG, check the following.

- 10A fuse [No. 1, located in the fuse block (J/B)] •
- 10A fuse [No. 10, located in the fuse block (J/B)] •
- 15A fuse [No. 56, located in the fuse block (J/B)] •
- Harness for open or short between fuse and display & NAVI • MT control unit

Ground Circuit Check

	117 EE000000402	M57
Terminals	Continuity	/A\
3 (B) - Ground	Yes	AX
4 (B) - Ground	Yes	
33 (B) - Ground	Yes	SU
	3 (B) - Ground 4 (B) - Ground	3 (B) - Ground Yes 4 (B) - Ground Yes

CL

NEEL 030050402

ST


BT


HA

SC

EL

IDX





SEL616Y

VOICE GUIDE OPERATION CHECK


		VOICE GOIDE OPERATION CHECK	=NFEL0300S05
1 PRELIM	INARY CHECK		
 Insert the mu Try to play the 		adio and CD player.	
		Yes or No	
Yes		GO TO 2.	
No		Repair or replace audio system. Refer to "AUDIO", EL-180.	

2 CHECK NAVI OPERATION ON SIGNAL

1. Disconnect audio unit connector.

2. Push "VOICE" button.


3. Check voltage between AUDIO unit harness connector M68 terminal 28 (L/R) and ground.




3 CHECK VOICE SIGNAL CIRCUIT

1. Push "VOICE" button.

2. Check voltage between display and NAVI control unit harness connector M169 terminal 30 (L/W) or 31 (L) and ground.







AX

SU

ST

BT

HA

SC

EL

IDX

EL-413

This Condition is Not Abnormal

NFEL0301S08

BASIC OPERATIONS

Symptom	Possible cause	Remedy
No image comes on.	The brightness adjustment is at the lowest setting.	Adjust it brighter.
No map comes on the screen.	No map CD-ROM is inserted, or it is inserted upside down.	Insert the CD-ROM correctly.
	The map display mode is switched off.	Press the MAP button.
No voice guide is available. or The volume is not high enough.	The volume is not set correctly or turned off.	Adjust the volume correctly.
The screen is too dim. The movement is slow.	The temperature in the vehicle is low.	Wait for the temperature to rise.
There are darker or brighter dots in the display.	It is inherent to displays.	This is not abnormal.

- Stored location in the address book and other memory functions may be lost if the car's battery is disconnected or becomes discharged for a long time.
 - If this should occur, service the car's battery as necessary and re-enter the address book information.

Area place names are not displayed.

If area place names do not appear on the map display, these names may not be available. Use the BIRD-VIEW[®] flat surface map display function. Display output may differ. Note the items related to BIRDVIEW[®] below.

- Priority is given to the display of place names in the direction of vehicle travel.
- Extended display of vehicle travel distance for both surfaces and steering angle (flat directional changes). This phenomenon disappears after the display image has been replaced by another one.
- The names of route and area might vary between the immediate front area and distance front area.
- Alphanumeric display characters are limited to maintain display simplicity and clarity. Display details may differ with time and place.
- Identical place and road names may appear on the display at more than one location.

VEHICLE ICONS

Symptom	Possible cause	Remedy
The location names differ, between Plan- view and Birdview [™] .	This is because the displayed information is reduced so that the screen does not become too crowded. There is also a chance that names of the roads or loca- tions will be repeatedly displayed. The name appearing on the screen may be different because of the processing proce- dure.	It should not be regarded as abnormal.
The vehicle icon is not shown correctly.	The vehicle might have moved with the ignition off, for example on a ferry boat or car transporter.	Drive the vehicle with GPS on for some distance.
The screen does not switch to night screen even after turning the headlights on.	The last setting is the daytime screen, when you turned on the lights the last time.	Turn the headlights on again, go to [DIS- PLAY SETTING] screen and set it to the night screen.
The map does not scroll even when the vehicle is traveling.	The display is not switched to the map screen.	Press the MAP button.
The vehicle icon does not show up.	The display is not switched to the map screen.	Press the MAP button.

This Condition is Not Abnormal (Cont'd)

Symptom	Possible cause	Remedy
GPS indicator on the screen remains gray.	GPS signals are not received because the vehicle is indoors or in the shade of build-ings.	Move the vehicle to outdoors with a clear view of the sky.
	GPS signals are not received because some objects are placed on the instru- mental panel.	Remove the objects from the instrumental panel.
	GPS satellites are in poor locations.	Please wait for the satellites to move to better locations.
The location of vehicle icon does not match the actual position.	Driving on slippery road surface	If the position marker does not move to the correct position even after the vehicle has been driven approximately 6 miles
	Driving on slanted area	(10 km), adjust the current location. If necessary, adjust the moving speed of the vehicle.
	Rough or violent driving	If the position marker does not move to the correct position even after the vehicle has been driven approximately 6 miles (10 km), adjust the current location.
	GPS indicator remains gray.	Please check the GPS indicator on the screen to see if it remains gray.
	Because the vehicle has tire chains on, or the system was transferred to a different vehicle, errors (gain or loss) result in cal- culating the speed from the speed pulse.	It will move by driving the vehicle for 30 minutes [in case it is running at 18-3/4 miles/hour (30 km/h)]. If you still notice errors, adjust moving speed.
	The map data has an error or is incom- plete (if the location error happens always in the same area).	Please wait for the update of the Map CD-ROM.

MAP CD-ROM

		NFEL0301S09		
Symptom	Possible cause	Remedy	BR	
The message "Error" appears after opera- tion.		Check the CD-ROM and wipe it clean with a soft cloth.	05	
		In case you see any damage, replace the CD-ROM.	ST	

DESTINATION, WAY POINTS OR MENU CONTENTS

DESTINATION, WAT POINTS	S OR MENU CONTENTS	NFEL0301S10	0
Symptom	Possible cause	Remedy	BT
Turn list is not displayed.	Route search does not occur.	Set designation areas and perform route search.	
	Car marker does not appear on recom- mended route.	Drive on the recommended route.	- HA
	Route guide is OFF.	Turn the route guide ON.	SC
In rerouting, the waypoints are not included in the calculation.	The system has judged that the vehicle has already passed the point.	If you want to go to that point again, edit the route again.	EL

IDX

RS

CANNOT BE CHOSEN OR SET

Symptom	Possible cause	Remedy
Route information is not displayed.	Route calculation has not yet been requested.	Set the destination and request route cal- culation.
	The vehicle icon is not on the suggested route.	Please drive the vehicle along the sug- gested route.
	Route guidance is off.	Turn the route guidance on.
Route is not calculated automatically.	The vehicle is not running on a route that can be calculated from.	Enter the route that can be calculated from. Alternatively, you can calculate the route manually. In this case, the entire route will be calculated again.
It is impossible to request a detour.	Your vehicle is not running on the sug- gested route.	Restart route calculation or join the sug- gested route.
The detour found is the same as the pre- vious suggestion.	The system took many conditions into consideration, but the same result was obtained.	This is not abnormal.
It is impossible to set the waypoints.	The number of waypoints exceeds 5.	It is impossible to set more than 5 way- points. Please divide them in groups to find them all.
Some items in the menu cannot be selected.	The vehicle is moving.	Park the vehicle in a safe place and select the marks relevant to the sug- gested route.

VOICE GUIDANCE

VOICE GUIDANCE		NFEL0301S12
Symptom	Possible cause	Remedy
The voice guidance is not available.	Voice guidance is only available at certain intersections marked with \P . In some cases, the guidance is not available even when the vehicle should make a turn.	This is not abnormal.
	The vehicle is off the suggested route.	Go back to the suggested route or request route calculation again.
	Voice guidance is set OFF.	Turn the voice guidance ON.
	Route guidance is set OFF.	Turn the route guidance ON.
The guidance content does not corre- spond to the actual condition.	The content of the voice guidance may vary, depending on the types of junctions to make turns on.	Follow the actual rules and regulations.

ROUTE CALCULATION

		NFEL0301S13
Symptom	Possible cause	Remedy
Although the system is set with the mov- ing direction as the preference, it does not find the route by matching the preference.	There is no route found in that direction.	This is not abnormal.
Route is not indicated.	There is no road that can be found by this system close to the destination.	Reset the destination close to the road displayed with orange, or wider ones. Especially with roads which have sepa- rate lanes for opposite directions, be care- ful in setting the destination or way points on it, because results may differ depend- ing on the lane you choose.
	The starting point to the destination is too close.	Set more distant destinations.

This Condition is Not Abnormal (Cont'd)

Symptom	Possible cause	Remedy	
The route is not displayed continuously at way points, for example, that are not cal- culated route from the vehicle's current position.	Suggested routes may be displayed dis- continuously near way points as route cal- culation is done at each way point.	This is not abnormal.	GI MA
The suggested route the vehicle has trav- eled is erased.	Suggested routes are stored in memory by the blocks; if the vehicle travels past way point 1, the former data will be erased.	This is not abnormal.	EM
A very detoured route is suggested.	If there are restrictions (such as one-way traffic) on roads close to the starting point or destination, the system may suggest a detoured route.	Try slightly moving the starting point or destination.	LC EC
The landmark description does not corre- spond to the actual one.	It may be caused by insufficient or incor- rect data on the CD-ROM.	Exchange the Map CD-ROM. It will be updated.	
The suggested route does not exactly connect to the starting point, way points, or destination.	There is no data for route calculation closer to these points.	Set these points on the main road dis- played in thick orange. Please note that in some cases even main roads lack the data for route calculation.	FE CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

EXAMPLE OF CURRENT VEHICLE POSITION MARKER ERROR

The navigation system reads the vehicle distance and steering angle data. Because the vehicle is moving, there will be an error in the current position indication. After the error appears, drive the vehicle for a short distance. Stop the vehicle. If the position marker does not return to its original position, perform "ADJUST CURRENT LOCATION" (EL-401).



This Condition is Not Abnormal (Cont'd)

	Possible cause	Drive condition	Service procedure	
	Slippery road surface	On wet, icy, or gravel road where frequent wheel slippage occurs, dis- tance calculations may be errone- ous. The position marker may show the vehicle to be in inaccurate posi- tion.		GI M
Area	Slanted area	Hilly areas where the road has banked curves. When the vehicle enters these banked curves, there may be an error in steering angle measurement. The position marker may show the vehicle to be in inac- curate position.		en Lo Eo
Map data	Map display for a given road does not appear. New road SEL699V The vehicle is driven on a road whose course has been altered (usually to improve the road or to eliminate some hazard).	move to the existing map. Map marking and calibration are not possible. The position marker may indicate inaccurate position in close	If the position marker does not move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "ADJUST CUR- RENT LOCATION" (EL-401). If necessary, perform "SPEED CALIBRATION" (EL-399).	Fe
		Subsequently, when the vehicle is driven on a road which is available as map data, the position marker may still indicate an inaccurate posi- tion.		M' AT
		When the map data shown on the display and the actual conditions are different. Map matching will not be		AX
		possible. The position marker may indicate inaccurate position in close proximity to the actual position. If the vehicle is driven on the indicated road, further errors may occur.		SL BF
	SEL700V		If the position marker does not	ST
Vehicle	Use of tire chains (Stormy weather)	Tire chains will affect distance sens- ing. The position marker may indi- cate inaccurate position.	move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "SPEED CALI- BRATION" (EL-399). After removing the tire chains, sens- ing accuracy may recover by	RS
			itself.	HA

SC

EL

IDX

This Condition is Not Abnormal (Cont'd)

	Possible cause	Drive condition	Service procedure
	Driving immediately after starting engine.	The gyro (angular velocity sensor) needs about 15 seconds after the engine is started to precisely sense the angular velocity. Directional sensing errors will occur if the vehicle is moved immediately after starting the engine. The position marker may indicate inaccurate position.	Wait a few moments between starting the engine and actually driving the vehicle.
Opera- tion	Continuous driving for long distances (non-stop)	When the vehicle is driven continu- ously without stopping over a long distance, errors in directional sens- ing may occur. The position marker may indicate inaccurate position.	Stop the vehicle. Perform "SPEED CALIBRATION" (EL- 399).
	Rough or violent driving	Wheel spinning (peeling out) or simi- lar rough driving techniques can adversely affect sensing accuracy. The position marker may indicate inaccurate position.	If the position marker does not move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "ADJUST CUR- RENT LOCATION" (EL-401).
Posi- tional calibra- tion pro- cedures	Positional calibration precision Within 1 mm (0.04 in)	If current vehicle location is roughly set, the system may be unable to locate the road that the vehicle is traveling on. (This is especially true in an area where there are many roads.)	Perform "ADJUST CURRENT LOCATION" (EL-401) within a precision standard of 1 mm (0.04 in) on the display. Note: During calibration, use the most detailed map pos- sible.
	Position calibration direction Direction calibration adjustment SEL702V	When calibrating the position, check the vehicle direction. If the vehicle direction is not correct, subsequent precision of current location will be affected.	Perform "ADJUST CURRENT LOCATION", refer to EL-401.

	Possible cause: —: Vehicle running: Indication		Drive condition	Service procedure	6
	Y-intersection		In Y-intersections with a very gradual change in course, a direc- tional sensing may be inaccurate. This may result in the position marker giving the wrong road indica- tion.		. C
		SEL703V			
	Spiral road		On loop bridges and similar struc- tures which result in a large and		
			continuous turn, turning angle may be sensed inaccurately. As a result, the position marker may separate from the route on the map.		
		SEL704V			0
	Straight road		In long distance driving on a straight road or road with very gradual curves, map marking inaccuracies		R
	SEL705V	may occur. In such cases, the posi- tion marker may stray from the route being traveled during subsequent turns due to inaccurate distance cal- culation.	If the position marker does not move to the correct position even after the vehicle has been	L	
oad napes	Winding road	SEL706V	Directional sensing precision errors may occur when traveling on wind- ing roads. During map matching, the position marker may stray to an adjacent road having a similar shape. Subsequent position marker error may occur.	driven approximately 10 km (6 miles), perform "Store place". If required, also perform "ADJUST CURRENT LOCA- TION" (EL-401).	(
	Grid-like road shape		Directional sensing and distance sensing, precision errors may occur because of many roads having a similar shape in the immediate area.		[
		SEL707V	During map matching, the position marker may stray to an adjacent road having a similar shape. Subse- quent position marker error may occur.		[
	Parallel roads				(
			When driving on a parallel road, map matching errors may occur. Subsequent position marker error may also occur.		
		SEL708V			

	Possible cause: —: Vehicle running: Indication	Drive condition	Service procedure
Loca- tion	Parking lot or similar area	When the vehicle is driven in a park- ing lot or similar area, such as in an area not normally marked as a road on map, during map matching, the system may select nearby roads. This error may continue after the vehicle exits the parking area and begins to run on ordinary roads. Vehicle operation in a parking area may involve frequent turns and up and/or down operation. Directional sensing errors may occur leading to subsequent route and position mis- takes.	
	Turntable	When the ignition switch is OFF (the usual situation when the vehicle is on a turntable), the navigation system receives no data from the gyro (angular velocity sensor). When the turntable rotates, no directional change is sensed. During subsequent vehicle operation, directional and route errors may occur.	

Position marker displays a completely different location

In circumstances such as those described below, GPS signal reception conditions may result in an erroneous position of the position marker. Perform "ADJUST CURRENT LOCATION" (EL-401).

NOTE:

- When GPS satellite signal reception conditions are poor, the position of position marker may be erroneous. If correction is not made immediately, the position marker error will be compounded and a completely different location will be indicated. In an area where GPS satellite signal reception conditions are good, the system can be returned to normal operation.
- The vehicle is driven aboard a car ferry or is towed for some distance with the ignition switch OFF. Vehicle movement is not sensed. Current location calculations do not occur and current location data does not appear on the display screen. Use GPS to accurately determine actual vehicle position. The system can be returned to normal operation when the GPS satellite signal reception conditions are good.

Position marker jumps

In circumstances such as those described below, the position marker may jump as a result of automatic current location corrections made by the system.

During map matching

• During map matching, the position marker may jump from one spot to another. In this case, it may be corrected to a wrong road or to an area where no road exist.

GPS location correcting

Vehicle current location is sensed using the GPS data. Positional calibration is performed. The position
marker continues to be in the wrong position. It may jump about from one area of the screen to another.
In this case, it may be corrected to a wrong road or to an area where no road exist.

Position marker indicates that the vehicle is in the middle of an ocean or large river

The navigation system does not distinguish between land and water surfaces. In some cases, a position marker error may cause the display to show the vehicle above a water surface.

Position of position marker varies when the vehicle is repeatedly operated on the same road

Driving lane and steering wheel movement results in a variety of different positions of the position mark when traveling on the same road based on sensing results by the GPS antenna and gyro (angular velocity sensor). Slow locational correction using map matching

- The map matching function requires verification of local data. To make the map matching function, some distance needs to be driven.
- The map matching function may not provide accurate performance in an area where there are numerous parallel roads. Until the system judges the road characteristics, an incorrect position may be shown.

	PS signal reception conditions are good. However, the position mark does not return to its proper osition.	
•	he system senses the vehicle location with an error of approximately 100 m (328 ft). Due to the limitation of precision, the position marker may be inaccurate even if the GPS signal reception condition is good.	GI
•	The navigation system uses GPS data to determine vehicle location. GPS data is compared with other locational sensing data during the map matching process. The system decides which data is more precise and uses that data.	MA
•	When the vehicle is stationary, GPS data cannot be used to make system corrections.	EM
	ea designations on the map display and the BIRDVIEW® display differ.	
	prevent the display from becoming congested, alphanumeric information is abridged. o problem]	10
	prive problem	LC
Ve	chicle position changed after ignition key was turned to the OFF position (Vehicle is transported on car ferry,	
	r train, or by some other means).	EC
	perate vehicle for short time under GPS receiving conditions.] The display does not change to night-time mode even though the light switch has been turned ON.	
	ghts have been turned on. In "DISPLAY CHANGE" mode, night-time mode on display has been switched to	FE
	y-time mode and still is.	
	urn lights on again. Set the display to night-time mode. Refer to EL-402.] ap does not scroll even though the position of your vehicle is changed.	CL
	esent area does not appear on the display.	ØĽ
[P	ress the "MAP" switch.]	
	chicle position marker does not appear.	MT
	esent area does not appear on the display. ress the "MAP" switch.]	
	ne map surface precision display (GPS satellite marker) still remains gray.	AT
	chicle is parked inside a building or in the shadow of a large building. This intercepts the GPS signal.	
	love the vehicle to a more open position.] PS signal is not received because objects are placed on the rear parcel shelf.	AX
	emove objects from the rear parcel shelf.]	5 60 6
G	PS satellite position is bad.	ଢା ।
	/ait until GPS satellite position improves.]	SU
	ehicle position precision is bad. Ne map surface precision display (GPS satellite marker) still remains gray.	
	efer to "The map surface precision display (GPS satellite marker) still remains gray" item (Symptoms)]	BR
	chicle speed and elapsed distance is calculated from the vehicle speed pulse. This pulse is dependent upon	
	e size. If tire chains are used on the vehicle, accuracy will be affected (pulse rate will be too fast or too slow). The same is true if the system installed to your vehicle is removed and installed on another vehicle.	ST
	rive the vehicle at a speed higher than 30 km/h (19 MPH) for approximately 30 minutes. Automatic read-	
jūs	stment should occur. If it does not (remains too fast or too slow), distance calibration is required. Or, drive	RS
	e vehicle for a short distance. Perform "SPEED CALIBRATION" (EL-399). After removing the tire chains, ensing accuracy may recover by itself.]	0.00
	ad map data or system defect (same error consistently occurs in the same area)	65
	OUTE SEARCH/ROUTE GUIDE	BT
	If the present location or the destination location is displayed in the avoid area, it is not possible to search	
•	routes.	HA
•	If the avoid area is set to wide range area, it may not be possible to find appropriate routes or search for	
	alternate routes.	SC
٠	The automatic re-route calculates a return to the original route. Because of this, it may not be possible to search appropriate new routes. If you deviate from the original route and wish to select an appropriate new	
	route, touch "Route Calculation".	EL
•	The automatic re-route function may sometimes require considerable time.	
•	Displayed route number and directional information at a highway junction may differ from the information posted on the actual road signs.	IDX
•	Displayed street name information at a highway exit may differ from the information posted on the actual	
	road signs.	

• Street name information displayed on the enlarged intersection map may differ from the information posted on the actual road signs.

EL-423

This Condition is Not Abnormal (Cont'd)

- The enlarged intersection map may display an "Unknown Street" message at some street intersections.
- Because of road configuration, etc. the guide may finish early. If this occurs, follow the marker to reach your destination.
- Destination area side information (left side and right side) may differ from actual conditions because of data error.

LOCATION OF CAR MARKER

- If the vehicle has been parked in a multi-level parking facility or underground parking facility, the car marker position may be inaccurate immediately after exiting the parking facility.
- The GPS accuracy is within ±100 m (300 ft). Even when receiving conditions are excellent, further positional correction may not occur.

STREET INDICATION

• Street names displayed on the map may differ from the actual street names.

NFEL0301S05

• An "Unknown Street" message may appear on the map in place of street name information.


RESEARCH

- Position may be searched by house number. However, the displayed position and street may differ from the actual position and street.
- When position is searched using POI, the displayed position may differ from the actual position.
- Some data may not be available for new buildings and other structures in a map.

GPS ANTENNA

- Do not place metal objects above the GPS antenna mounted on the rear parcel shelf. This will cause interference with signal reception.
- Do not place mobile telephones or vehicle radio transceivers in close proximity to the GPS antenna mounted on the rear parcel shelf. This may cause interference with signal reception.





Note: Load the program only after the engine has been started.

SEL612X


Initialization

This procedure is for initializing the current location. Perform "Initialize Location" when the vehicle is transported a long distance by trailer, etc.

Map with grey background appears and the vehicle location cannot be adjusted by scrolling the display when the vehicle location in the memory is out of the area of the inserted map data. Perform "Initialize Location" when this occurs.

NOTE:


- Only initialize the system when the display & NAVI control unit is replaced. If the system is initialized in other cases, it may cause inaccurate positioning of the position marker for a while.
- Initialize the system outside for receiving the radio wave from the GPS satellite.



Being to the second	4.	Push "Previous" switch.	
Self Diagnosis Previous Select one of the following. Self Diagnosis			GI
Confirmation/ adjustment			MA
			EM
SEL584X	5.	Push the "MAP" switch.	LC
BAFEY ST	5. 6.	Touch "Setting".	EC
View 100 AVE Cancel			FE
18 mi			CL
SEL460Y			MT
SETTINGS	7.	Touch "System Setting".	AT
Select one of the following. Save Current Location System Setting			AX
Edit Address Book			SU
Softer Louder Guide Volume			BR
SEL461Y	8.	Touch "GPS Information".	ST
SYSTEM SETTINGS Previous			
Clear Memory GPS Information			RS
Map & A/C Quick Stop Customer Settings			BT
Route Priorities			HA
SEL462Y	9.	More than one GPS satellite icon turns green. (It may take 1	SC
GPS Information Previous Calculation Longitude Latitude		to 15 minutes.) TE: ve the vehicle for a while* in order to change the receiving	EL
8 dimension 1/18, 24, 14 38, 57, 26	coı ico	ndition of the radio wave from the GPS satellite if the GPS on does not turn green.	
		The driving distance which is necessary depends on the ceiving condition of the radio wave from the GPS satellite.	IDX
SEL146W			

Initialization (Cont'd)

NAVIGATION SYSTEM




- 10. Push "MAP" switch and check the following.
- Confirm that the GPS icon on the map turns green.
- Then the position marker should show the current location.
- Position marker rotates corresponding to the movement of the vehicle.
- 11. Initialization is completed.

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


FOR A/T MODELS System Diagram



T: Transmit R: Receive

Signals	ECM	ТСМ	AT
Accelerator pedal position signal	Т	R	
Output shaft revolution signal	R	Т	AX

FOR TCS MODELS System Diagram



Input/Output Signal Chart T: Transmit R: Receive

Signals	ECM	ABS/TCS control unit	ТСМ	SC
Accelerator pedal position signal	т	R	R	
Output shaft revolution signal	R		Т	EL
TCS self-diagnostic signal	R	Т		
ABS self-diagnostic signal	R	т		IDX

System Description

NFEL0304S01

X

SU

NFEL0304S02

NFEL0304S0202

CAN SYSTEM (FOR A/T MODELS)

Component Parts and Harness Connector Location


Passenger side view with lower instrument panel removed View with lower instrument center panel removed Heater unit TCM (Transmission control module) FST SEL428Y

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

EL-430

CAN SYSTEM (FOR A/T MODELS)



MEL734P

19 20 21

Trouble Diagnoses

Trouble Diagnoses


WORK FLOW

NFEL0274

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE" and "A/T" displayed on CONSULT-II.

(Example)	SELECT DIAG MODE		SELF-DIAG RESULTS		
	WORK SUPPORT		DTC RESULTS	TIME	
	SELF-DIAG RESULTS		CAN COMM CIRCUIT (U1000)	0	
	DATA MONITOR				
	DATA MONITOR (SPEC)				
	CAN DIAG SUPPORT MNTR				
	ACTIVE TEST				
			F	.F.DATA	
	Scroll Down		ERASE PF	RINT	
	BACK LIGHT COPY		MODE BACK LIGHT	COPY	PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE" and "A/T" displayed on CONSULT-II.



- 3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to "CHECK SHEET" (EL-433).
- 4. Based on the "CAN DIAG SUPPORT MNTR" results, put "v" marks onto the items with "UNKWN" or "NG" in the check sheet table. Refer to "CHECK SHEET" (EL-433).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

5. According to the check sheet results (example), start inspection. Refer to "CHECK SHEET RESULTS (EXAMPLE)" (EL-434).

CHECK SHEET

=NFEL0274S02

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the Giagnosed control unit, replace the control unit.

			CAN DIAG SU		SELECT SYSTEM
		Receive c	Transmit	Initial	screen
	ТСМ	ECM	diagnosis	diagnosis	
	UNKWN	_	UNKWN	NG	NGINE
	-	UNKWN	UNKWN	NG	/Т
					Symptoms:
	Attach copy of A/T SELF-DIAG RESULTS			copy of	Attach o
					ENG SELF-DIAG
		Attach copy A/T			Attach c ENG
	ORT MNTR	CAN DIAG SUPPO		PORT MNTR	CAN DIAG SUF

EL

IDX

CHECK SHEET RESULTS (EXAMPLE)

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check CAN communication circuit. Refer to "CAN COMMUNICATION CIRCUIT CHECK" (EL-434).

	CAN DIAG SUPPORT MNTR				
SELECT SYSTEM screen	Initial	Transmit	Receive diagnosis		
Scieeli	diagnosis diagno	diagnosis	ECM	ТСМ	
NGINE	NG	UNKWN	-	UNKWN	
Т	NG	UNKWN	UNKWN	_	


PKIB0382E

NFEL0274S04

CAN COMMUNICATION CIRCUIT CHECK


- CHECK CONNECTOR
 Turn ignition switch OFF.
 Check following terminals and connector for damage, bend and loose connection. (control module-side and harness-side)
 TCM
- ECM
- Between ECM and TCM

	OK or NG
OK 🕨	GO TO 2.
NG 🕨	Repair terminal or connector.




=NFEL0274S03

Trouble Diagnoses (Cont'd)




Component Parts and Harness Connector Location



System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.



MEL735P


Trouble Diagnoses

Trouble Diagnoses

NFEL0279

WORK FLOW

Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "ABS" and "A/T" displayed on CONSULT-II.



Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "ABS" and "A/T" displayed on CONSULT-II.

(Example)	SELECT DIAG MODE		CAN DIAG SUP		
	WORK SUPPORT		ENGI	PRSNT	
	SELF-DIAG RESULTS		INITIAL DIAG TRANSMIT DIAG	ок ок	
	DATA MONITOR		тсм	OK	
	DATA MONITOR (SPE		VDC/TCS/ABS METER/M&A	OK OK	
	CAN DIAG SUPPORT MI	ITR	ICC	UNKWN	
	ACTIVE TEST		BCM/SEC IPDM E/R	OK OK	
			AWD/4WD/e4WD	UNKWN Scroll	
	Scroll D		PRINT	Down	
	BACK		MODE BACK L	IGHT COPY	PKIA8343E

- 3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to "CHECK SHEET" (EL-439).
- 4. Based on the "CAN DIAG SUPPORT MNTR" results, put "v" marks onto the items with "UNKWN" or "NG" in the check sheet table. Refer to "CHECK SHEET" (EL-439).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

5. According to the check sheet results (example), start inspection. Refer to "CHECK SHEET RESULTS (EXAMPLE)" (EL-440).

CHECK SHEET

=NFEL0279S02

NOTE: If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the Gil diagnosed control unit, replace the control unit.

Check sheet table		CAN D	IAG SUPPOR	T MNTR]
SELECT SYSTEM screen	Initial	Transmit		Receive diagnosis	S	1
	diagnosis	diagnosis	ECM	VDC/TCS/ABS UNKWN	тсм]
ENGINE	NG	UNKWN	_		UNKWN	-
ABS A/T	NG NG	UNKWN UNKWN	UNKWN UNKWN		UNKWN -	-
	NG.	ONIXWIN	UNIXWIN]
Symptoms :						
]
Attach copy of ENGINE SELF-DIAG RESULTS	S	Attach copy of ABS ELF-DIAG RESU		Attach co A/T SELF-DIAG		
			_			
						1
Attach copy of		Attach copy of	F	Attach co		
ENGINE CAN DIAG SUPPORT MNT		ABS DIAG SUPPORT		A/T CAN DIAG SUP		
CAN DIAG SUPPORT MINT		DIAG SUPPORT		CAN DIAG SUP	PORTMINTR	
						PKIA8323

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

Check ECM circuit. Refer to "ECM CIRCUIT CHECK" (EL-441).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial Transmit		Receive diagnosis			
	diagnosis diag	diagnosis	ECM	VDC/TCS/ABS	тсм	
ENGINE	NG	UNKWN	-	UNKWN	UNKWN	
ABS	NG	UNKWN	UNKWN	-	UNKWN	
A/T	NG	UNKWN	UNKWN	UNKWN	-	

PKIA8325E




Case 2

Check ABS/TCS control unit circuit. Refer to "ABS/TCS CONTROL UNIT CIRCUIT CHECK" (EL-442).

	CAN DIAG SUPPORT MNTR					
SELECT SYSTEM screen	Initial	Transmit	Receive diagnosis			
	diagnosis diagno	diagnosis	ECM	VDC/TCS/ABS	ТСМ	
ENGINE	NG	UNKWN	-	UNKWN	UNKWN	
ABS	NG	UNKWN	UNKWN	-	UNKWN	
A/T	NG	UNKWN	UNKWN	UNKWN	-	

PKIA8326E



=NFEL0279S03

NFEL0279S0301

Trouble Diagnoses (Cont'd)

NFEL0279S0303

GI


AX

65

Case 3

Check TCM circuit. Refer to "TCM CIRCUIT CHECK" (EL-443).

	CAN DIAG SUPPORT MNTR						
SELECT SYSTEM screen	Initial	Transmit	Receive diagnosis				
	diagnosis	diagnosis	ECM	VDC/TCS/ABS	ТСМ		
ENGINE	NG	UNKWN	-	UNKWN	UNKWN		
ABS	NG	UNKWN	UNKWN	-	UNKWN		
A/T	NG	UNKWN	UNKWN	UNKWN	-		



Case 4


NFEL0279S0304 Check CAN communication circuit. Refer to "CAN COMMUNICATION CIRCUIT CHECK" (EL-443).

		CAN DIAG SUPPORT MNTR					
SELECT SYSTEM screen	Initial						
	diagnosis	diagnosis	ECM	VDC/TCS/ABS	ТСМ		DD
ENGINE	NG	UNKWN	_	UNKWN	UNKWN		
ABS	NG	UNKWN	UNKWN	-	UNKWN		9
А/Т	NG	UNKWN	UNKWN	UNKWN	-		9

ECM CIRCUIT CHECK

	NFEL027950	BT
1 CHECK CONNECTOR		
 Turn ignition switch OFF. Check following terminals and side) 	l connector for damage, bend and loose connection. (control module-side and harness-	HA
 ECM Harness connector F55 Harness connector M162 		SC
Harness connector M15Harness connector E81		EL
	OK or NG	
ОК	GO TO 2.	IDX
NG	Repair terminal or connector.	


Trouble Diagnoses (Cont'd)



ABS/TCS CONTROL UNIT CIRCUIT CHECK

1	CHECK CONNECTOR							
2. Che	 Turn ignition switch OFF. Check the terminals and connector of ABS/TCS control unit for damage, bend and loose connection. (control unit-side and harness-side) 							
	OK or NG							
OK	►	GO TO 2.						
NG	•	Repair terminal or connector.						

NFEL0279S07



Trouble Diagnoses (Cont'd)

тсм	CIRCUIT CHECK	NFEL027950)8
1	CHECK CONNECTOR		GI
2. Cł sic • TC	de) M	l connector for damage, bend and loose connection. (control module-side and harness-	MA
● Ha ● Ha	rness connector F55 rness connector M162 rness connector M15 rness connector E81		EM
		OK or NG	LC
OK		GO TO 2.]
NG		Repair terminal or connector.	EC
			-
2	CHECK HARNESS FOR	R OPEN CIRCUIT	FE
	sconnect TCM connector. neck resistance between TC	$\mathbb{C}M$ harness connector F51 terminals 5 (L) and 6 (R).	CL
			MT
		TCM OCONNECTOR 5 6 5 6	AT AX

	OK or NG
ОК	Replace TCM.
NG 🕨	Repair harness ABS/TCS control unit and TCM.
	·

Ω

CAN COMMUNICATION CIRCUIT CHECK

		CIRCUIT CHECK NFEL027950	4 ST
1 CHEC	K CONNECTOR		
2. Check follo	on switch OFF. owing terminals and arness-side)	d connector for damage, bend and loose connection. (control module-side, control unit-	RS
 TCM ECM ABS/TCS d 	·		BT
 Between E 	CM and TCM		HA
		OK or NG	
ОК	►	GO TO 2.	SC
NG	►	Repair terminal or connector.	

EL

SEL439Y

SU

BR

IDX

Trouble Diagnoses (Cont'd)


ECM

OK

NG

109, 113

GO TO 4.



OK or NG

Repair harness between ECM and harness connector F55.


Continuity should not exist.

SEL432Y


Trouble Diagnoses (Cont'd)


EL


IDX




Trouble Diagnoses (Cont'd)







Trouble Diagnoses (Cont'd)




Trouble Diagnoses (Cont'd)

12	ECM/TCM INTERNAL C	IRCUIT INSPECTION							
Check	Check components inspection. Refer to "ECM/TCM INTERNAL CIRCUIT INSPECTION" (EL-448).								
		OK or NG							
OK		Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-438).							
NG		Replace ECM and/or TCM.							

•

•



Component Inspection ECM/TCM INTERNAL CIRCUIT INSPECTION

NFEL0280

NFEL0280S01

- Remove ECM and TCM from vehicle.
 - Check resistance between ECM terminals 109 and 113.
 - Check resistance between TCM terminals 5 and 6.


Unit	Terminal	Resistance value (Ω)
ECM	109 - 113	Approx 109 122
ТСМ	5 - 6	Approx. 108 - 132

Engine Compartment







NFEL0129



Passenger Compartment






MEL072O

NFEL0130

Passenger Compartment (Cont'd)




HA

SC


EL

IDX

MEL073O



Trunk lid opener actuator



MEL074O

How to Read Harness Layout

now to read namess Layout	NFEL0131	
Example:		GI
G2 E1 B/6 : ASCD ACTUATOR		MA
Connector color/Cavity Connector number		EM
Grid reference		LC
SEL252V		
The following Harness Layouts use a map style grid to help locate connectors on the drawings:		EC

- Main Harness
- Engine Room Harness (Engine Compartment)

TO USE THE GRID REFERENCE

- 1. Find the desired connector number on the connector list.
- 2. Find the grid reference.
- 3. On the drawing, find the crossing of the grid reference letter column and number row.
- 4. Find the connector number in the crossing zone.
- 5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector turo	Water p	roof type	Standa	ard type	AX
Connector type	Male	Female	Male	Female	
Cavity: Less than 4Relay connector	Ø	5	Ø		— su
• Cavity: From 5 to 8	\bigcirc		\bigcirc		BR
Cavity: More than 9	_	_	\bigcirc	\bigcirc	ST
• Ground terminal etc.	-	_	C	P	RS

FE

CL

MT

AT

NFEL0131S01

NFEL0131S02


HA

SC

EL

Outline

HARNESS LAYOUT



NOTE:


For detailed ground distribution information, refer to "Ground Distribution", "GROUND", EL-19.


NOTE:

GI
MA
EM
LC
EC
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

Main Harness

HARNESS LAYOUT





MEL044O

	Audio unit (With BOSE system)	Audio unit (With BOSE system)	Audio unit (With BASE system)	Audio unit (With BASE system)	Audio unit	Antenna amp. (Via sub-harness)	Ashtray illumination	Heated seat switch LH	Heated seat switch RH	Parking brake switch	Power socket	Intake sensor (With auto A/C)	To (F49)	Glove box lamp	Intake door motor (With manual A/C)	Intake door motor (With auto A/C)	Sunload sensor (With auto A/C)	Tweeter RH (Via sub-harness)	Body ground	To B103	To (B104)	To (E105)	Indirect lamp (Without navigation system)	Smart entrance control unit	Smart entrance control unit	Smart entrance control unit	Air bag diagnosis sensor unit	To (M201)	Passenger air bag module	To (E147)	Memory seat cancel switch (With memory seat)		Combination switch (With heated steering)	Combination switch (Air bag module) (Via spiral cable)	Combination switch (Steering switch and horn switch)		Accelerator pedal position sensor Door window defender ewitch (With periodication evotom)		~~	
~	• •	••	• •	••	••	••	••	••	••	• •	• •	••	••	••	••	••	••	••	••	••	••	••	••	• •	••	••	••	•••	• •	••	• •	•••	• •	••	• •					
harness	W/6	W/10	W/6	W/10	W/16	W/2	W/2	L/4	W/4	B/1	B/2	W/3	W/20	W/2	W/8	W/3	B/2	BR/2	I	W/12	W/10	G/2	BR/2	W/24	GY/24	GY/16	Y/28	W/3	Y/4	Y/4	GY/6	W/8	W/2	Y/6	GY/8		0//b	W/18	W/18	
Main	H61	M62	M63	M64	M68	M71	M72	M74	M75	LZM	M78	M80	F BM	M82	M83	M84	M85	(M86	MB7	Fel	M92	7 00	M108	M143	M144	M145	M146	M147	M149	M150	M154	M155	M156	M157	M158		M159		M162	
	F4,D3	E2,F3	F4,	E3	F3,F4	F3	F4	F5	F4	F4	G4	F4	F3★	F2	F2	F2	Ē	Ē	€ 1 *	F2	F3	G2	E2	ő	C3	D3	G5	C2	F2	G2	C4	04	ü	C3	C4	C (5 8	5 T	D4	

 Shift lock control unit (With A/T) To (B52) (With memory seat) A/T device (with A/T) To (F69) Heated stearing relay (With heated stearing) 	Display and NAVI control unit Display and NAVI control unit A/C auto amp. (With auto A/C) (With navigation system) A/C auto amp. (With auto A/C) (With navigation system) To 6145) Audio unit (With CD auto changer) Ignition keyhole illumination	rness-1 : To (M30) : Clock	ess-2 To (M147) Auto light sensor
0	W//20 :: 3Y//20 :: 3Y/20 :: 3R//26 :: 8R//24 :: W//2 :: W//2 ::	а	
		gy/6 GY/6 BR/8	Sub- W/3 W/3 W/3
M165 M165 M165 M165 M165 M165 M165 M165	M173 M173 M172 M172 M172	Main M151 M152	Main M203 M202
Е4 Е5 С2 С2	С С С С С С С С С С С С С С С С С С С	C2 D1	B2 C2


★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

MEL754P


NOTE:

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL

IDX




MEL046O



Engine Room Harness (Cont'd)

MEL047O





EL-462

MEL048O

NOTE:

GI
MA
EM
LC
EC
FE
GL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL

IDX

Engine Control Harness


Engine Control Harness NFEL0135 က 4 ഹ N Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections. 10 വ വ Failure to do so may cause the ECM to have diagnostic trouble codes. Be sure to connect and lock the connectors securely after repair work. F213) F212) F211 F66 F92 F112 F115) F91 Ш LL E14 ¹64 ★ F67 F114 E9 Ð F222 F221 F152 F10) ഹായ ш Ш F197 \odot F194) 8Ë F58 F13 (F132 F151 (Di + F22 8 192 F59 F23) F56 43 F65 F173 Ø F28 F57 10 \Box Δ .. ★ F231 Ð F198 F34 Q, 3 (F25) F70 F42 ø D F171 * ന F36 F30 F37 8 (F232) C F41 F31 F62 F63 C F199 F35 F29 F60 F46 F50 F51 F61 F49 F54 F40 F42 മ മ F48 F68 Engine ground F69 ∢ ∢ F55 N က 4 ഹ MEL049O

 46 (a) (41 + 1) (41 + 1) (41) 57 (41) + 1) (41) 58 (41) + 1) (41) 59 (41) + 1) (41) 50 (41) + 1) (41) 51 (41) + 1) (41) 52 (42) + 1) (41) 52 (42) + 1) (41) 53 (42) + 1) (41) 54 (41) + 1) (41) 55 (42) + 1) (41) 56 (42) + 1) (41) 	GI MA EM LC EC FE CL MT AT AX
Theres 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 10 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) 11 (11) <td>SU BR ST RS BT HA SC</td>	SU BR ST RS BT HA SC
Engline Control harness Engline Eontrol BR/3 F rear E3 * Fig B/2 T o F E3 * Fig B/2 T o F E3 * Fig B/10 T o F E3 * Fig B/10 T o F E4 * Fig G/10 T o F G4 * Fig G/12 B/8 T o F G4 * Fig G/12 B/8 T o F F D3 Fig G/12 L 1/2 Juint F F D4 * Fig G/12 S </td <td>SC EL IDX</td>	SC EL IDX

MEL755P


HARNESS LAYOUT





水 sà b F	GI
em) epair work. EC and AT	MA
bag syst ger) ger) SES in l	EM
a side air tuto chan tuto chan nave diag fi DIAGNO	LC
er Chith CD is with CD is with CD is with CD is connected to I ECM to I ECM to I ECM to I TROUBLE exters extended to the connected to the conn	EC
 CD auto changer Satellite sensor LH (With side air bag system) Body ground (With CD auto changer) Body ground (With CD auto changer) Body ground with CD auto changer) Body ground in the connectors securely after reparates Body ground CD auto changer Body ground in the connectors securely after reparates CD auto changer Body ground CD auto changer) Intess Int	FE
 CD at Statelli Body Body Body Rear Body Rear Body MORK F 	CL
 E4 (BF) W16 : CD auto changer C3 (BS) Y2 : satellite sensor LH (With side air bag system) C3 (B3) - : Body ground (With CD auto changer) C4 (B1) : Rear window defogger C5 (B1) B/1 : Rear window defogger C6 (B1) B/1 : Rear window defogger C7 (B2) - : Body ground C8 (B1) B/1 : Rear window defogger C9 (B1) B/1 : Rear window defograves C9 (B1) B/1 : Rear window de	MT
	AT
s)	AX
am) (Via system) ub-harnes	SU
) auto changer) lay defogger) defogger) With M/T) Mith M/T) d fuel pump valve ol valve ssure sensor valve ol valve ssure sensor valve ssure sensor valve ol valve ssure sensor valve ol valve ssure sensor valve ssure sensor vith M/T) Mith side air bag system) (Via unit (With side air bag system) air bag system) in memory seat) (Via sub-harnee With A/T) Mith A/T)	BR
auto changer) ay defogger) defogger) defogger) di M/T) l fuel pump valve sure sensor i valve sure sensor arness) d marness) d d d marness) d d d d d d d d d d d d d d d d d d	ST
ut CD auto er relay I dow defogg amp (Withou Pass valve control valvv pass valve control valvv pass valve control valvv pass valve tit and fuel pass valve control valvv pass valve control valvv dot LH control valvv control valvv control valvv control valvv control valvv control valvv dot H control valvv control	RS
(J/B) d (Withou relay w defogg switch LH (Rear win d d ed stop li lamp l sensor I sensor run sensor un sensor un sensor un sensor l l sensor l (With s ener actu with mem With mem With mem Vith mem l unit LH Sensor I l sensor I	BT
Do (m) Co Co To (m) Co Co To (m) Co Co Fue block (J/B) Body ground (Without CD auto changer) Co Evel pump relay Evel pump relay Co Rear window defogger relay Evel pump relay Evel pump relay Rear window defogger relay Evel pump relay Evel pump relay Body ground Body ground Body ground Evel pump relay Body ground Body ground Evel pump value Evel pump relay Fuel level sensor nut and fuel pump vacuum cut valve bypass valve EVAP canister vent control valve EVAP canister vent control valve EVAP canister vent control valve EVAP canister vent control valve Evel pump vacuum cut valve bypass valve EVAP canister vent control valve EVAP canister vent control valve Evel pump vacuum cut valve bypass valve EVAP canister vent control valve Evel pump vacuum cut valve bypass valve Evel pump vacuum cut valve bypass valve EVAP canister vent control valve EVAP canister vent control valve Evel pump vacuum cut valve bypass valve EVAP canister vent control valve Evel pump vacuum cut valve bypass valve Evel pump vacuum cut valve bypass valve	HA
Marness W/16 X W/16 X W/18 X W/1 X W/1 X W/1 X W/1 X W/1 X W/10 X W/16 X W/16 <t< td=""><td>SC</td></t<>	SC
<u>andanananananananananananananananananan</u>	EL
8 8	IDX

MEL834P




	GI
	MA
	EM
	LC
	EC
	FE
	CL
	MT
(see	AT
no (mai) to (mai) to (mai) Body ground Bead door switch RH Truck lid key cylinder switch Truck lid key cylinder switch Truck lid key cylinder switch Truch lid key cylinder switch Truch lid key cylinder switch Truch lide sen pa H License lamp LH Truch BOSE system) BoSE spater amp. (With BOSE system) BoSE spater amp. (With BOSE system) BoSE spater amp. (With BOSE system) BoS ground BoS ground BoS spater amp. (With side air bag system) Bost belt pre-tensioner RH Air bag diagnosis sensor unit Heated seat RH (Via sub-harness) Bower seat RH (Via sub-harnes) Bower seat RH (Via sub-harnes) Bower seat RH (Via sub-harnes) Bower seat RH (AX
stem) (Vis	SU
em) m) j system) r spoiler)	BR
vitch th BOSE system) air bag system) air bag system) h side air bag s H b-harness) (With side air l stem) RH (With rear air si	ST
th ler switch System) . (With B side air l RH in Sub-har a sub-har a sub-har if sub-har	RS
ind switch F key cylinc imp LH wmp LH with BOSE aker amp ind (With BOSE saker amp ind (With BOSE wat RH (Vi ag modul (With BO buckle switch symp ited stop	BT
arness To (MG) To (MG) Bedy ground Read door switch RH Trunk lid key cylinder switch Trunk lid key cylinder switch Trunk lid key cylinder switch Trunk lid key cylinder switch Trunk lid key cylinder switch License lamp LH License lamp LH To (E24) Woofer (With BOSE system) BOSE speaker amp. (With BOSE system) BOSE speaker amp. (With BOSE system) BOSE speaker amp. (With side air bag system) Front door switch RH To (E24) BOSE speaker amp. (With side air bag system) Front door switch RH To (E10) Seat belt pre-tensioner RH Air bag diagnosis sensor unit Heated seat RH (Via sub-harness) Side air bag module RH (With side air bag system) Seat belt pre-tensioner RH To (E10) Seat belt buckle switch RH To (E10) To (E10)	HA
No. 2 harness W/12 : To (M92) W/10 : To (M92) W/11 : Rear doo W/1 : Rear doo W/2 : Trunk lid BR/2 : To (B16) W/2 : License li W/2 : License li W/3 : Front doc W/3 : Front doc W/3 : Front doc W/3 : Seat belt Y/2 : Stellite si W/3 : Seat belt W/3 : Seat belt W/2 : Side air li BR/2 : To (B10) BR/2 : To (B10) W/3 : Seat belt W/3 : Seat belt	SC
	EL
83 43 43 43 43 43 43 43 43 43 43 43 43 43	IDX

MEL054O

Tail Harness


HARNESS LAYOUT

Tail Harness



MEL055O

NFEL0138



MEL056O

BR

ST

RS

BT

HA


SC


EL

IDX

EL-471

Front Door Harness





SU

BR

ST

RS

BT


HA

SC

EL

IDX

Rear Door Harness



BR

ST

RS


BT

HA

SC

EL

IDX



BULB SPECIFICATIONS

Headlamp		
	Headlamp	NFEL0144S03
	Item	Wattage (W)
High/Low		60/35 (HB3)
	Exterior Lamp	NFEL0144S01
	Item	Wattage (W)
Front fog lamp		55 (H3)
Front turn signal lamp		21
Parking lamp		5
Front side marker lamp		3.8
	Turn signal	21
Rear combination lamp	Stop/Tail	21/5
	Back-up	13
Rear side marker lamp		3.8
License lamp		5
High-mounted stop lamp (without re	ar spoiler)	21
	Interior Lamp	NFEL0144S02
	Item	Wattage (W)
Interior room lamp		10
Map lamp		8
Vanity mirror lamp		1.4
Trunk room lamp		3.4
Step lamp		2.7

EL-476

Use the chart below to find out what each wiring

diagram code stands for. Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Codo		Wiring Diagram Name
Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
ABS	BR	Anti-lock Brake System
A/C, A	HA	Auto Air Conditioner
A/C, M	HA	Manual Air Conditioner
APPS1	EC	Accelerator Pedal Position Sen- sor (Sensor 1)
APPS2	EC	Accelerator Pedal Position Sen- sor (Sensor 2)
APPS3	EC	Accelerator Pedal Position Sen- sor
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch
ASC/VS	EC	Automatic Speed Control Device (ASCD) Vehicle Speed Sensor
ASCBOF	EC	Automatic Speed Control Device (ASCD) Brake Switch (Off)
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator
AT/IND	EL	A/T Indicator Lamp
AUDIO	EL	Audio
AUT/DP	EL	Automatic Drive Positioner
BACK/L	EL	Back-up Lamp
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
B/COMP	EL	Board Computer
BRK/SW	EC	Brake Switch
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CAN	AT	CAN System
CAN	EC	CAN System
CAN	EL	CAN System
CHARGE	SC	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter

Section EL EC EL	Wiring Diagram Name Clock Cooling Fan Control	G]
EC		GI
	Cooling Fan Control	
EL		
	Rear Window Defogger	MA
EL	Power Door Lock	
EC	Data Link Connector	EM
EL	Headlamp - With Daytime Light System	LC
EC	ECM Power Supply	
EC	Engine Coolant Temperature Sensor	EC
EC	Electronic Controlled Engine Mount	FE
AT	Engine Speed Signal	A
EC	Electrical Throttle Function	CL
EC	Electrical Throttle Control Motor Relay	MT
EC	Electrical Throttle Control Motor	
EL	Front Fog Lamp	AT
EC	Fuel Level Sensor	
EC	Fuel Level Sensor	AX
EC	Fuel Level Sensor	0.0.0
EC	Fuel Pump Control	su
AT	A/T Fluid Temperature Sensor	66
EC	Fuel Tank Temperature Sensor	BR
EC	Fuel Injection System Function (Bank 1)	ST
EC	Fuel Injection System Function (Bank 2)	RS
EL	Headlamp	
EL	Horn	BT
EL	Heated Seat	
EL	Heated Steering	HA
EL	Inside Mirror (Auto Anti-dazzling Mirror)	SC
EC	Intake Air Temperature Sensor	
EC	Ignition System	EL
EL	Illumination	
EC	Injector	IDX
EL	Interior, Step, Spot, Vanity Mirror and Trunk Room Lamps	
EC	Intake Valve Timing Control Sole- noid Valve RH	
	EC EC AT EC AT EC EL EL EL EL EL EC EL EL EL EC EL EC EL EC EL EC EL EC EL EC EL EL EL	ELSystemECECM Power SupplyECEngine Coolant Temperature SensorECElectronic Controlled Engine MountATEngine Speed SignalECElectrical Throttle FunctionECElectrical Throttle Control Motor RelayECElectrical Throttle Control MotorELFront Fog LampECFuel Level SensorECFuel Level SensorECFuel Level SensorECFuel Nevel SensorECFuel Injection System Function (Bank 1)ECFuel Injection System Function (Bank 2)ELHeaddampELHeated SteeringELHeated SteeringELInside Mirror (Auto Anti-dazzling Mirror)ECIntake Air Temperature SensorECELInterior, Step, Spot, Vanity Mirror and Trunk Room LampsELIntake Valve Timing Control Sole-

WIRING DIAGRAM CODES (CELL CODES)

CodeSectionWiring Diagram NameIVCB2ECIntake Valve Timing Control Solenoid Valve LHKEYLESELRemote Keyless Entry SystemKSECKnock SensorLOADECElectrical Load SignalLPSVATLine Pressure Solenoid ValveMAFSECMass Air Flow SensorMAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 1 (Bank 2)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S1B2ECHeated Oxygen Sensor 2 (Bank 2)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid ValvePNP/SWATPark/Neutral Position Switch<			
IVCB2ECnoid Valve LHKEYLESELRemote Keyless Entry SystemKSECKnock SensorLOADECElectrical Load SignalLPSVATLine Pressure Solenoid ValveMAFSECMass Air Flow SensorMAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B1ECHeated Oxygen Sensor 1 (Bank 1)02H2B2ECHeated Oxygen Sensor 1 (Bank 1)02H2B2ECHeated Oxygen Sensor 1 (Bank 2)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PHONEELTelephone (Pre-wire)PHONEELTelephon	Code	Section	Wiring Diagram Name
KSECKnock SensorLOADECElectrical Load SignalLPSVATLine Pressure Solenoid ValveMAFSECMass Air Flow SensorMAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 1 (Bank 2)02S1B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 2 (Bank 1)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	IVCB2	EC	•
LOADECElectrical Load SignalLOADECElectrical Load SignalLPSVATLine Pressure Solenoid ValveMAFSECMass Air Flow SensorMAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 1 (Bank 1)02H2B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S1B1ECHeated Oxygen Sensor 2 (Bank 1)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCarmshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	KEYLES	EL	Remote Keyless Entry System
LPSVATLine Pressure Solenoid ValveMAFSECMass Air Flow SensorMAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S2B1ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCarshaft Position Sensor (PHASE) (Bank 1)PHASEECCarshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	KS	EC	Knock Sensor
MAFSECMass Air Flow SensorMAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 2)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	LOAD	EC	Electrical Load Signal
MAINATMain Power Supply and Ground CircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B2ECHeated Oxygen Sensor 1 (Bank 1)02H2B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	LPSV	AT	Line Pressure Solenoid Valve
MAINAICircuitMAINECMain Power Supply and Ground CircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire) PHONEPGC/VECEVAP Canister Purge Volume Control Solenoid Valve	MAFS	EC	Mass Air Flow Sensor
MAINECCircuitMETERELSpeedometer, Tachometer, Temp. and Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 1)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	MAIN	AT	
METERELand Fuel GaugesMILECMalfunction Indicator LampMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	MAIN	EC	
MIRELoMateriotics metador bangMIRRORELPower Door MirrorNATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 2)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	METER	EL	
NATSELNVIS (Nissan Vehicle Immobilizer System — NATS)NAVIELNavigation SystemNONDTCATNon-detectable ItemsO2H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)O2H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)O2H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)O2H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)O2H2B1ECHeated Oxygen Sensor 2 Heater (Bank 2)O2H2B2ECHeated Oxygen Sensor 1 (Bank 1)O2S1B1ECHeated Oxygen Sensor 1 (Bank 1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	MIL	EC	Malfunction Indicator Lamp
NATSELSystem — NATS)NAVIELNavigation SystemNONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 2)02H2B2ECHeated Oxygen Sensor 1 (Bank 1)02S1B1ECHeated Oxygen Sensor 1 (Bank 2)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	MIRROR	EL	Power Door Mirror
NONDTCATNon-detectable Items02H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)02H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)02H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 1)02H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)02S1B1ECHeated Oxygen Sensor 1 (Bank 1)02S1B2ECHeated Oxygen Sensor 1 (Bank 2)02S2B1ECHeated Oxygen Sensor 1 (Bank 2)02S2B2ECHeated Oxygen Sensor 2 (Bank 1)02S2B2ECHeated Oxygen Sensor 2 (Bank 2)0VRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	NATS	EL	
O2H1B1ECHeated Oxygen Sensor 1 Heater (Bank 1)O2H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)O2H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)O2H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)O2H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)O2S1B1ECHeated Oxygen Sensor 1 (Bank 1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 2)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	NAVI	EL	Navigation System
O2H1B1EC(Bank 1)O2H1B2ECHeated Oxygen Sensor 1 Heater (Bank 2)O2H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)O2H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)O2S1B1ECHeated Oxygen Sensor 1 (Bank 1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 2)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	NONDTC	AT	Non-detectable Items
O2H1B2EC(Bank 2)O2H2B1ECHeated Oxygen Sensor 2 Heater (Bank 1)O2H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)O2S1B1ECHeated Oxygen Sensor 1 (Bank 1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 1)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	O2H1B1	EC	
O2H2B1EC(Bank 1)O2H2B2ECHeated Oxygen Sensor 2 Heater (Bank 2)O2S1B1ECHeated Oxygen Sensor 1 (Bank 1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 1)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	O2H1B2	EC	
O2H2B2EC(Bank 2)O2S1B1ECHeated Oxygen Sensor 1 (Bank 1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 1)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	O2H2B1	EC	
O2S1B1EC1)O2S1B2ECHeated Oxygen Sensor 1 (Bank 2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 1)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	O2H2B2	EC	
O2S1B2EC2)O2S2B1ECHeated Oxygen Sensor 2 (Bank 1)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	O2S1B1	EC	
O2S2B1EC1)O2S2B2ECHeated Oxygen Sensor 2 (Bank 2)OVRCSVATOverrun Clutch Solenoid ValvePHASEECCamshaft Position Sensor (PHASE) (Bank 1)PHASEECCamshaft Position Sensor (PHASE) (Bank 2)PHONEELTelephone (Pre-wire)PGC/VECEVAP Canister Purge Volume Control Solenoid Valve	O2S1B2	EC	
OZSZB2 EC 2) OVRCSV AT Overrun Clutch Solenoid Valve PHASE EC Camshaft Position Sensor (PHASE) (Bank 1) PHASE EC Camshaft Position Sensor (PHASE) (Bank 2) PHONE EL Telephone (Pre-wire) PGC/V EC EVAP Canister Purge Volume Control Solenoid Valve	O2S2B1	EC	
PHASE EC Camshaft Position Sensor (PHASE) (Bank 1) PHASE EC Camshaft Position Sensor (PHASE) (Bank 2) PHONE EL Telephone (Pre-wire) PGC/V EC EVAP Canister Purge Volume Control Solenoid Valve	O2S2B2	EC	
PHASE EC (PHASE) (Bank 1) PHASE EC Camshaft Position Sensor (PHASE) (Bank 2) PHONE EL Telephone (Pre-wire) PGC/V EC EVAP Canister Purge Volume Control Solenoid Valve	OVRCSV	AT	Overrun Clutch Solenoid Valve
PHASE EC (PHASE) (Bank 2) PHONE EL Telephone (Pre-wire) PGC/V EC EVAP Canister Purge Volume Control Solenoid Valve	PHASE	EC	
PGC/V EC EVAP Canister Purge Volume Control Solenoid Valve	PHASE	EC	
Control Solenoid Valve	PHONE	EL	Telephone (Pre-wire)
PNP/SW AT Park/Neutral Position Switch	PGC/V	EC	
	PNP/SW	AT	Park/Neutral Position Switch

Code	Section	Wiring Diagram Name
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Oil Pressure Sen- sor
REF	EC	Crankshaft Position Sensor (CKPS) (REF)
REMOTE	EL	Audio (Remote Control Switch)
RP/SEN	EC	Refrigerant Pressure Sensor
SEN/PW	EC	Sensor Power Supply
SEAT	EL	Power Seat
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
S/SIG	EC	Start Signal
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop Lamp
TAIL/L	EL	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock Up)
TCS	EC	ABS/TCS Communication Line
TCS	BR	Traction Control System
ТСV	AT	Torque Converter Clutch Solenoid Valve
T&FLID	EL	Trunk Lid and Fuel Filler Lid Opener
TPS	AT	Throttle Position Sensor
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TRNSCV	EL	Homelink Universal Transceiver
TURN	EL	Turn Signal and Hazard Warning Lamps
VEHSEC	EL	Vehicle Security (Theft Warning) System

WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
VENT/V	EC	EVAP Canister Vent Control Valve
VIAS	EC	Variable Induction Air Control System
VIAS/V	EC	Variable Induction Air Control System
VSS	EC	Vehicle Speed Sensor
VSSA/T	AT	Vehicle Speed Sensor A/T (Revo- lution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
W/ANT	EL	Audio Antenna
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer

AT

AX

SU

MT

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES