

LT  
**SECTION**  
**LIGHTING SYSTEM**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

**CONTENTS**

<p><b>PRECAUTIONS</b> ..... 5</p> <p>    Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... 5</p> <p>    General Precautions for Service Operations ..... 5</p> <p><b>HEADLAMP - XENON TYPE -</b> ..... 6</p> <p>    Component Parts and Harness Connector Location... 6</p> <p>    System Description ..... 6</p> <p>        OUTLINE ..... 6</p> <p>        LOW BEAM OPERATION ..... 7</p> <p>        HIGH BEAM OPERATION ..... 7</p> <p>        FLASH-TO-PASS OPERATION ..... 8</p> <p>        COMBINATION SWITCH READING FUNCTION... 8</p> <p>        EXTERIOR LAMP BATTERY SAVER CONTROL... 8</p> <p>        AUTO LIGHT OPERATION ..... 8</p> <p>        VEHICLE SECURITY SYSTEM ..... 8</p> <p>        XENON HEADLAMP ..... 9</p> <p>    CAN Communication System Description ..... 9</p> <p>    CAN Communication Unit ..... 9</p> <p>    Schematic ..... 10</p> <p>    Wiring Diagram — H/LAMP — ..... 11</p> <p>    Terminals and Reference Values for BCM ..... 15</p> <p>    Terminals and Reference Values for IPDM E/R .... 17</p> <p>    How to Proceed With Trouble Diagnosis ..... 17</p> <p>    Preliminary Check ..... 17</p> <p>        CHECK POWER SUPPLY AND GROUND CIRCUIT ..... 17</p> <p>    CONSULT-II Functions (BCM) ..... 19</p> <p>        CONSULT-II BASIC OPERATION ..... 19</p> <p>        WORK SUPPORT ..... 19</p> <p>        DATA MONITOR ..... 19</p> <p>        ACTIVE TEST ..... 20</p> <p>    CONSULT-II Functions (IPDM E/R) ..... 21</p> <p>        CONSULT-II BASIC OPERATION ..... 21</p> <p>        DATA MONITOR ..... 21</p> <p>        ACTIVE TEST ..... 22</p> <p>    Headlamps Do Not Change To High Beam (Both Sides) ..... 22</p> <p>    Headlamp Does Not Change To High Beam (One Side) ..... 24</p>	<p>    Headlamps Do Not Illuminate (Both Sides) ..... 25</p> <p>    Headlamp Does Not Illuminate (One Side) ..... 28</p> <p>    Headlamps Do Not Turn OFF ..... 30</p> <p>    General Information for Xenon Headlamp Trouble</p> <p>        Diagnosis ..... 31</p> <p>        Caution: ..... 31</p> <p>        Xenon Headlamp Trouble Diagnosis ..... 31</p> <p>        Aiming Adjustment ..... 32</p> <p>            PREPARATION BEFORE ADJUSTING ..... 32</p> <p>            LOW BEAM AND HIGH BEAM ..... 32</p> <p>            ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE) ..... 33</p> <p>    Bulb Replacement ..... 34</p> <p>        HEADLAMP HIGH/LOW BEAM ..... 34</p> <p>        PARKING LAMP ..... 34</p> <p>        FRONT TURN SIGNAL LAMP ..... 34</p> <p>        FRONT SIDE MARKER LAMP ..... 34</p> <p>    Removal and Installation ..... 35</p> <p>        REMOVAL ..... 35</p> <p>        INSTALLATION ..... 35</p> <p>    Disassembly and Assembly ..... 36</p> <p>        DISASSEMBLY ..... 36</p> <p>        ASSEMBLY ..... 36</p> <p><b>HEADLAMP - CONVENTIONAL TYPE-</b> ..... 37</p> <p>    Component Parts and Harness Connector Location.. 37</p> <p>    System Description ..... 37</p> <p>        OUTLINE ..... 37</p> <p>        LOW BEAM OPERATION ..... 38</p> <p>        HIGH BEAM OPERATION ..... 38</p> <p>        FLASH-TO-PASS OPERATION ..... 39</p> <p>        COMBINATION SWITCH READING FUNCTION.. 39</p> <p>        EXTERIOR LAMP BATTERY SAVER CONTROL.. 39</p> <p>        AUTO LIGHT OPERATION ..... 39</p> <p>        VEHICLE SECURITY SYSTEM ..... 39</p> <p>    CAN Communication System Description ..... 39</p> <p>    CAN Communication Unit ..... 39</p> <p>    Schematic ..... 40</p> <p>    Wiring Diagram — H/LAMP — ..... 41</p> <p>    Terminals and Reference Values for BCM ..... 45</p> <p>    Terminals and Reference Values for IPDM E/R .... 47</p>
--	--

How to Proceed With Trouble Diagnosis .....	47	CUIT .....	76
Preliminary Check .....	47	CHECK PARKING BRAKE SWITCH CIRCUIT ...	77
CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	47	CONSULT-II Functions (BCM) .....	78
CONSULT-II Functions (BCM) .....	49	CONSULT-II BASIC OPERATION .....	78
CONSULT-II BASIC OPERATION .....	49	WORK SUPPORT .....	78
WORK SUPPORT .....	49	DATA MONITOR .....	78
DATA MONITOR .....	49	ACTIVE TEST .....	79
ACTIVE TEST .....	50	CONSULT-II Functions (IPDM E/R) .....	80
CONSULT-II Functions (IPDM E/R) .....	51	CONSULT-II BASIC OPERATION .....	80
CONSULT-II BASIC OPERATION .....	51	DATA MONITOR .....	80
DATA MONITOR .....	51	ACTIVE TEST .....	81
ACTIVE TEST .....	52	Daytime Light Control Does Not Operate Properly...	81
Headlamp High Beams Do Not Illuminate (Both Side) .....	52	<b>AUTO LIGHT SYSTEM .....</b>	<b>84</b>
Headlamp High Beam Does Not Illuminate (One Side) .....	54	Component Parts and Harness Connector Location..	84
Headlamp Low Beams Do Not Illuminate (Both Sides) .....	56	System Description .....	84
Headlamp Low Beam Does Not Illuminate (One Side) .....	58	OUTLINE .....	85
Headlamp RH Low Beam and High Beam Do Not Illuminate .....	59	COMBINATION SWITCH READING FUNCTION..	85
Headlamp LH Low Beam and High Beam Do Not Illuminate .....	60	DELAY TIMER FUNCTION .....	85
Headlamps Do Not Turn OFF .....	61	CAN Communication System Description .....	85
Aiming Adjustment .....	62	CAN Communication Unit .....	85
PREPARATION BEFORE ADJUSTING .....	62	Schematic .....	86
LOW BEAM AND HIGH BEAM .....	62	Wiring Diagram — AUTO/L — .....	87
ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE) .....	63	Terminals and Reference Values for BCM .....	90
Bulb Replacement .....	63	Terminals and Reference Values for IPDM E/R .....	91
HEADLAMP HIGH/LOW BEAM .....	63	How to Proceed with Trouble Diagnosis .....	91
PARKING LAMP .....	64	Preliminary Check .....	92
FRONT TURN SIGNAL LAMP .....	64	SETTING CHANGE FUNCTIONS .....	92
FRONT SIDE MARKER LAMP .....	64	CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	92
Removal and Installation .....	64	CONSULT-II Functions (BCM) .....	93
REMOVAL .....	64	CONSULT-II BASIC OPERATION .....	93
INSTALLATION .....	64	WORK SUPPORT .....	93
Disassembly and Assembly .....	65	DATA MONITOR .....	94
DISASSEMBLY .....	65	ACTIVE TEST .....	95
ASSEMBLY .....	65	CONSULT-II Functions (IPDM E/R) .....	95
<b>DAYTIME LIGHT SYSTEM .....</b>	<b>66</b>	CONSULT-II BASIC OPERATION .....	95
Component Parts and Harness Connector Location..	66	DATA MONITOR .....	95
System Description .....	66	ACTIVE TEST .....	96
OUTLINE .....	66	Symptom Chart .....	96
DAYTIME LIGHT OPERATION .....	67	Lighting Switch Inspection .....	97
COMBINATION SWITCH READING FUNCTION..	67	Optical Sensor System Inspection .....	97
EXTERIOR LAMP BATTERY SAVER CONTROL..	67	Removal and Installation of Optical Sensor .....	100
AUTO LIGHT OPERATION .....	68	REMOVAL .....	100
CAN Communication System Description .....	68	INSTALLATION .....	100
CAN Communication Unit .....	68	<b>HEADLAMP AIMING CONTROL .....</b>	<b>101</b>
Schematic .....	69	Wiring Diagram — H/AIM — .....	101
Wiring Diagram — DTRL — .....	70	Removal and Installation .....	103
Terminals and Reference Values for BCM .....	73	REMOVAL .....	103
Terminals and Reference Values for IPDM E/R .....	75	INSTALLATION .....	103
How to Proceed with Trouble Diagnosis .....	75	Switch Circuit Inspection (Xenon type) .....	103
Preliminary Check .....	76	<b>FRONT FOG LAMP .....</b>	<b>104</b>
CHECK POWER SUPPLY AND GROUND CIR-		Component Parts and Harness Connector Location	104
		System Description .....	104
		OUTLINE .....	104
		FRONT FOG LAMP OPERATION .....	105
		COMBINATION SWITCH READING FUNCTION	105
		EXTERIOR LAMP BATTERY SAVER CONTROL	105
		CAN Communication System Description .....	105
		CAN Communication Unit .....	105

Wiring Diagram — F/FOG — .....	106	<b>LIGHTING AND TURN SIGNAL SWITCH .....</b>	<b>144</b>	
Terminals and Reference Values for BCM .....	108	Removal and Installation .....	144	A
Terminals and Reference Values for IPDM E/R ..	109	REMOVAL .....	144	
How to Proceed with Trouble Diagnosis .....	109	INSTALLATION .....	144	
Preliminary Check .....	109	<b>HAZARD SWITCH .....</b>	<b>145</b>	B
CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	109	Removal and Installation .....	145	
CONSULT-II Functions (BCM) .....	110	REMOVAL .....	145	
CONSULT-II Functions (IPDM E/R) .....	110	INSTALLATION .....	145	C
Front Fog Lamps Do Not Illuminate (Both Sides)..	111	<b>COMBINATION SWITCH .....</b>	<b>146</b>	
Front Fog Lamp Does Not Illuminate (One Side)..	113	Wiring Diagram — COMBSW — .....	146	D
Aiming Adjustment .....	115	Combination Switch Reading Function .....	147	
Bulb Replacement .....	116	Terminals and Reference Values for BCM .....	147	
Removal and Installation .....	116	CONSULT-II Functions (BCM) .....	152	E
REMOVAL .....	116	CONSULT-II BASIC OPERATION .....	152	
INSTALLATION .....	116	DATA MONITOR .....	152	
<b>TURN SIGNAL AND HAZARD WARNING LAMPS.117</b>		Combination Switch Inspection .....	153	
Component Parts and Harness Connector Location	117	Removal and Installation .....	155	F
System Description .....	117	<b>STOP LAMP .....</b>	<b>156</b>	
OUTLINE .....	117	Component Parts and Harness Connector Location	156	
TURN SIGNAL OPERATION .....	118	System Description .....	156	G
HAZARD LAMP OPERATION .....	119	OUTLINE .....	156	
INTERLOCKED HAZARD LAMP OPERATION		STOP LAMP OPERATION .....	156	
WITH REMOTE KEYLESS ENTRY SYSTEM .	120	Schematic .....	158	H
INTERLOCKED HAZARD LAMP OPERATION		Wiring Diagram — STOP/L — .....	159	
WITH INTELLIGENT KEY SYSTEM .....	120	Terminals and Reference Value for Rear Combina- tion Lamp Control Unit .....	162	
COMBINATION SWITCH READING FUNCTION	120	How to Proceed with Trouble Diagnosis .....	162	I
CAN Communication System Description .....	120	Stop Lamp of Rear Combination Lamp Does Not Operate But High-Mounted Stop Lamp Operate .	162	
CAN Communication Unit .....	120	High-Mounted Stop Lamp .....	163	J
Schematic .....	121	BULB REPLACEMENT, REMOVAL AND INSTALLATION .....	163	
Wiring Diagram — TURN — .....	122	Stop Lamp .....	163	
Terminals and Reference Value for BCM .....	125	BULB REPLACEMENT .....	163	LT
Terminals and Reference Value for Rear Combina- tion Lamp Control Unit .....	126	REMOVAL AND INSTALLATION .....	163	
How to Proceed with Trouble Diagnosis .....	129	<b>BACK-UP LAMP .....</b>	<b>164</b>	
Preliminary Check .....	130	Wiring Diagram — BACK/L — .....	164	L
CHECK POWER SUPPLY AND GROUND CIR- CUIT .....	130	Bulb Replacement .....	165	
CONSULT-II Functions (BCM) .....	131	Removal and Installation .....	165	
CONSULT-II BASIC OPERATION .....	131	REMOVAL .....	165	M
DATA MONITOR .....	131	INSTALLATION .....	165	
ACTIVE TEST .....	131	<b>PARKING, LICENSE PLATE AND TAIL LAMPS ..</b>	<b>166</b>	
Turn Signal Lamps Do Not Operate .....	132	Component Parts and Harness Connector Location	166	
Turn Signal Lamps Go ON, But Flash at High Speed (Both Sides) .....	135	System Description .....	166	
Turn Signal Lamps Go ON, But Flash at High Speed (One Side) .....	137	OUTLINE .....	166	
Hazard Warning Lamps Do Not Operate But Turn Signal Lamps Operate .....	140	PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION .....	167	
Any Function of Rear Combination Lamps Does Not Work (Both sides) .....	142	COMBINATION SWITCH READING FUNCTION	168	
Any Function of Rear Combination Lamps Does Not Work (One side) .....	143	EXTERIOR LAMP BATTERY SAVER CONTROL	168	
Bulb Replacement .....	143	CAN Communication System Description .....	168	
FRONT TURN SIGNAL LAMP .....	143	CAN Communication Unit .....	168	
REAR TURN SIGNAL LAMP .....	143	Schematic .....	169	
Removal and Installation .....	143	Wiring Diagram — TAIL/L — .....	170	
FRONT TURN SIGNAL LAMP .....	143	Terminals and Reference Values for BCM .....	175	
REAR TURN SIGNAL LAMP .....	143	Terminals and Reference Values for IPDM E/R ...	176	
		Terminals and Reference Value for Rear Combina- tion Lamp Control Unit .....	176	
		How to Proceed with Trouble Diagnosis .....	176	
		Preliminary Check .....	176	

CHECK POWER SUPPLY AND GROUND CIRCUIT .....	176	CONSULT-II Functions (BCM) .....	210
CONSULT-II Functions (BCM) .....	177	CONSULT-II BASIC OPERATION .....	210
CONSULT-II Functions (IPDM E/R) .....	177	WORK SUPPORT (INT LAMP) .....	210
Parking, License Plate, Side Marker and Tail Lamps Do Not Illuminate .....	178	DATA MONITOR (INT LAMP) .....	210
Tail Lamp Does Not Operate But Parking, License Plate and Side Marker Lamps Operate .....	182	ACTIVE TEST (INT LAMP) .....	211
Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes) .....	182	WORK SUPPORT (BATTERY SAVER) .....	212
Bulb Replacement .....	183	DATA MONITOR (BATTERY SAVER) .....	212
LICENSE PLATE LAMP .....	183	ACTIVE TEST (BATTERY SAVER) .....	213
PARKING LAMP .....	183	Room Lamp Does Not Illuminate .....	214
TAIL LAMP .....	183	Personal Lamp Does Not Illuminate .....	215
FRONT SIDE MARKER LAMP .....	183	Ignition Key Hole Illumination Does Not Illuminate .....	217
REAR SIDE MARKER LAMP .....	183	Step Lamp Does Not Illuminate .....	219
Removal and Installation .....	183	All Interior Room Lamp Does Not Operate .....	220
LICENSE PLATE LAMP .....	183	Bulb Replacement .....	220
PARKING LAMP .....	183	MAP LAMP .....	220
TAIL LAMP .....	183	PERSONAL LAMP .....	220
FRONT SIDE MARKER LAMP .....	183	ROOM LAMP .....	221
REAR SIDE MARKER LAMP .....	183	STEP LAMP .....	221
<b>REAR COMBINATION LAMP .....</b>	<b>184</b>	LUGGAGE ROOM LAMP .....	222
Bulb Replacement .....	184	VANITY MIRROR LAMP .....	222
STOP, TAIL & REAR TURN SIGNAL LAMP BULB, REAR SIDE MARKER LAMP BULB .....	184	IGNITION KEY HOLE ILLUMINATION .....	222
Removal and Installation .....	184	Removal and Installation .....	223
REAR COMBINATION LAMP .....	184	MAP LAMP .....	223
REAR COMBINATION LAMP CONTROL UNIT .....	184	PERSONAL LAMP .....	223
<b>INTERIOR ROOM LAMP .....</b>	<b>185</b>	ROOM LAMP .....	223
Component Parts and Harness Connector Location .....	185	STEP LAMP .....	224
System Description .....	185	LUGGAGE ROOM LAMP .....	224
POWER SUPPLY AND GROUND .....	186	<b>ILLUMINATION .....</b>	<b>225</b>
SWITCH OPERATION .....	187	System Description .....	225
ROOM LAMP TIMER OPERATION .....	188	OUTLINE .....	225
INTERIOR LAMP BATTERY SAVER CONTROL .....	189	ILLUMINATION LAMP OPERATION .....	225
Schematic .....	191	EXTERIOR LAMP BATTERY SAVER CONTROL .....	226
Wiring Diagram — ROOM/L — .....	193	CAN Communication System Description .....	226
WITH INTELLIGENT KEY .....	193	CAN Communication Unit .....	226
WITHOUT INTELLIGENT KEY .....	200	Schematic .....	227
Terminals and Reference Values for BCM .....	207	Wiring Diagram — ILL — .....	228
How to Proceed with Trouble Diagnosis .....	208	Removal and Installation .....	234
Preliminary Check .....	209	ILLUMINATION CONTROL SWITCH .....	234
CHECK FOR POWER SUPPLY AND GROUND CIRCUIT .....	209	CONSOLE POCKET LAMP .....	234
		GLOVE BOX LAMP .....	234
		COIN BOX ILLUMINATION .....	234
		<b>BULB SPECIFICATIONS .....</b>	<b>235</b>
		Headlamp .....	235
		Exterior Lamp .....	235
		Interior Lamp/Illumination .....	235

# PRECAUTIONS

## PRECAUTIONS

PPF:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS001MS

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.



#### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### General Precautions for Service Operations

NKS001MT

- Never work with wet hands.
- Xenon headlamp includes high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, never touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector, and housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. (If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.)
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.




# HEADLAMP - XENON TYPE -

## HEADLAMP - XENON TYPE -

PFP:26010

### Component Parts and Harness Connector Location

NKS001MV



## System Description

NKS001MW

- BCM (Body Control Module) controls headlamps low and high operation.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates headlamp bulbs and high beam solenoids according to CAN communication signals from BCM.
- Combination meter operates high beam indicator lamp according to CAN communication signals from BCM.

## OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R,
- to headlamp high relay located in IPDM E/R and
- to headlamp low relay located in IPDM E/R, from battery direct,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse [No. 21, located in the fuse block (J/B)]

# HEADLAMP - XENON TYPE -

- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14 located in fuse block (J/B)]
- to combination meter terminal 20.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M14 and M78,
- to IPDM E/R terminals 38 and 60
- through grounds E13, E26 and E28,
- to combination meter terminals 22, 23 and 24
- through grounds M14 and M78.

## LOW BEAM OPERATION

When the lighting switch is in 2ND position, BCM detects the HEAD LAMP1 and 2 (ON) by BCM combination switch reading function. BCM sends low beam request signal (ON) through CAN communication.

When IPDM E/R receives low beam request signal (ON), it turns ON headlamp low relay in IPDM E/R. IPDM E/R supplies power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 4,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 4.

Ground is supplied

- to front combination lamp RH terminal 5
- through grounds E13, E26 and E28,
- to front combination lamp LH terminal 5
- through grounds E13, E26 and E28.

With power and ground supplied, headlamp low beams illuminate.

## HIGH BEAM OPERATION

When the lighting switch is in HIGH BEAM position and then also in 2ND position, BCM detects the HEAD LAMP1, 2 (ON) and the HI BEAM (ON) by BCM combination switch reading function. BCM sends low beam request signal (ON) and high beam request signal (ON) through CAN communication.

When receiving those signals, IPDM E/R turns ON headlamp low and high relays in IPDM E/R. IPDM E/R supplies power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 4,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 4,
- through 10A fuse (No. 72, located in the IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 1,
- through 10A fuse (No. 74, located in the IPDM E/R)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## HEADLAMP - XENON TYPE -

---

- through IPDM E/R terminal 28
- to front combination lamp LH terminal 1.

Ground is supplied

- to front combination lamp RH and LH terminals 5
- through grounds E13, E26 and E28.

With power and ground supplied, headlamp high beams illuminate.

High beam solenoids move the bulb shades in the front combination lamps, and the bulb shades change to high beam position.

Combination meter receives high beam request signal (ON) through CAN communication, and make high beam indicator lamp turn ON in combination meter.

### FLASH-TO-PASS OPERATION

When the lighting switch is in PASSING position, BCM detects the PASSING (ON) by BCM combination switch reading function. BCM sends low beam request signal (ON) and high beam request signal (ON) through CAN communication.

When receiving those signals, IPDM E/R turns ON headlamp low and high relays in IPDM E/R. IPDM E/R supplies power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 4,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 4,
- through 10A fuse (No. 72, located in the IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 1,
- through 10A fuse (No. 74, located in the IPDM E/R)
- through IPDM E/R terminal 28
- to front combination lamp LH terminal 1.

Ground is supplied

- to front combination lamp RH and LH terminals 5
- through grounds E13, E26 and E28.

With power and ground supplied, headlamp high beams illuminate.

High beam solenoids move the bulb shades in the front combination lamps to change beams from/to high and low.

Combination meter receives high beam request signal (ON) through CAN communication, and make high beam indicator lamp turn ON in combination meter.

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

### EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, and then the headlamps are turned off. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

### AUTO LIGHT OPERATION

Refer to [LT-84, "System Description"](#) .

### VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-204, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .



# HEADLAMP - XENON TYPE -

## XENON HEADLAMP

Xenon type lamps are used for to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to strong lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Followings are some advantages of the xenon type headlamp.

- The light produced by the headlamps is white color similar to sunlight that is easy to the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- Counter-reflected luminance increases and the contrast enhances on the wet road in the rain. That makes visibility go up more than the increase of the light volume.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.

## CAN Communication System Description

NKS001MX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS001MY

Refer to [LAN-49, "CAN System Specification Chart"](#) .


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



# HEADLAMP - XENON TYPE -

## Schematic

NKS001MZ



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

TKWB2550E





# HEADLAMP - XENON TYPE -

## Wiring Diagram — H/LAMP —

NKS001N0

### LT-H/LAMP-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)




(M34), (M35) - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# HEADLAMP - XENON TYPE -


LT-H/LAMP-02



TKWB2552E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-03






TKWA0740E

# HEADLAMP - XENON TYPE -

LT-H/LAMP-04

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWB2553E

# HEADLAMP - XENON TYPE -

## Terminals and Reference Values for BCM

NKS002T3

**CAUTION:**





- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152. "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	R	Combination switch input 5	ON	OFF	Approx. 0 V
				Lighting switch HIGH beam (Operates only HIGH beam switch)	<p style="text-align: right; font-size: small;">PKIB4959J</p>
3	P/L	Combination switch input 4	ON	Lighting switch 2ND	<p style="text-align: right; font-size: small;">PKIB4953J</p>
				Any of the conditions below	<ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul> <p style="text-align: right; font-size: small;">PKIB4959J</p>
11	P/B	Ignition switch (ACC)	ACC	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

## HEADLAMP - XENON TYPE -

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
34	LG/R	Combination switch output 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	 <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Any of the conditions below	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
35	G/B	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	 <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Any of the conditions below	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
38	R	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN - H	—	—	—	
40	Y	CAN - L	—	—	—	
42	GR	Battery power supply	OFF	—	Battery voltage	
52	B	Ground	ON	—	Approx. 0 V	
55	W/B	Battery power supply	OFF	—	Battery voltage	



# HEADLAMP - XENON TYPE -

## Terminals and Reference Values for IPDM E/R

NKS002T4

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
20	R/Y	Headlamp HIGH & LOW (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
27	L/W	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0 V
					ON	Battery voltage
28	G	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0 V
					ON	Battery voltage
30	L	Headlamp HIGH & LOW (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	
49	Y	CAN – L	—	—	—	
60	B	Ground	ON	—	Approx. 0 V	

## How to Proceed With Trouble Diagnosis

NKS002T5

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-6, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-17, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS002T6

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	72
		74
		76
		86

Refer to [LT-11, "Wiring Diagram — H/LAMP —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# HEADLAMP - XENON TYPE -

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# HEADLAMP - XENON TYPE -

## CONSULT-II Functions (BCM)

NKS00277

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### WORK SUPPORT

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

#### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF.	ON	×
		OFF	—

## DATA MONITOR

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

#### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.

## HEADLAMP - XENON TYPE -

Monitor item	Contents
LIGHT SW 1 ST	"ON/OFF" Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW	"ON/OFF" Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW	"ON/OFF" Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF" Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
RR FOG SW <sup>NOTE</sup>	—
DOOR SW - DR	"ON/OFF" Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF" Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF" Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF" Displays status of the rear door as judged from the passenger door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW	"ON/OFF" Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R	"ON/OFF" Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF" Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE</sup>	—
OPTICAL SENSOR	"0 - 5 V" Displays "outside brightness (close to 5 V when light/close to 0 V when dark)" judged from optical sensor signal.

**NOTE:**

This item is displayed, but cannot be monitored.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE</sup>	—

**NOTE:**

This item is displayed, but cannot be tested.

# HEADLAMP - XENON TYPE -

## CONSULT-II Functions (IPDM E/R)

NKS00278

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE " screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS", or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Font fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

# HEADLAMP - XENON TYPE -

## ACTIVE TEST

### Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "OFF" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option. (Headlamp high beam repeats ON-OFF every 1 second.)
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

## Headlamps Do Not Change To High Beam (Both Sides)

NKS00279

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is : HI BEAM SW ON  
HIGH BEAM position**

☒ Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HI BEAM SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7585E

### 2. HEADLAMP ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operates.

**Headlamp high beam should operate.  
(Headlamp high beam repeats ON-OFF every 1 second.)**

☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS	OFF		
		HI	
LO	FOG		
MODE	BACK	LIGHT	COPY

SKIA5774E

# HEADLAMP - XENON TYPE -

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HI position.

**When lighting switch is HIGH BEAM position : HL LO REQ ON  
: HL HI REQ ON**

DATA MONITOR			
MONITOR			
HL LO REQ		ON	
HL HI REQ		ON	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5775E


### OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .
- NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

## 4. CHECK HEADLAMP INPUT SIGNAL

### With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II. and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "HI" screen.
6. When headlamp high beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground (Headlamp high beam repeats ON-OFF every 1 second).



		(+)	(-)	Voltage
Front combination lamp connector		Terminal		
RH	E30	1	Ground	Battery voltage
LH	E17	1		

### Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
4. When headlamp high beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground.

		(+)	(-)	Voltage
Front combination lamp connector		Terminal		
RH	E30	1	Ground	Battery voltage
LH	E17	1		

### OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

# HEADLAMP - XENON TYPE -


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E30 terminal 1.

**27 - 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E17 terminal 1.

**28 - 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .  
 NG >> Repair harness or connector.


## 6. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.

**5 - Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 - Ground : Continuity should exist.**



OK or NG


- OK >> Replace front combination lamp. Refer to [LT-35, "Removal and Installation"](#) .  
 NG >> Repair harness or connector.

## Headlamp Does Not Change To High Beam (One Side)

NKS002TA

### 1. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connectors.
3. Turn ignition switch ON.
4. Lighting switch is turned HIGH BEAM position.
5. Check voltage between front combination lamp RH or LH harness connectors and ground.



		(+)	(-)	Voltage
Front combination lamp connector		Terminal		
RH	E30	1	Ground	Battery voltage
LH	E17	1		

OK or NG

- OK >> GO TO 3.  
 NG >> GO TO 2.



# HEADLAMP - XENON TYPE -


## 2. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E30 terminal 1.

**27 – 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E17 terminal 1.

**28 – 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.

## 3. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.


**5 – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground : Continuity should exist.**

OK or NG

- OK >> Replace front combination lamp. Refer to [LT-35, "Removal and Installation"](#).
- NG >> Repair harness or connector.



## Headlamps Do Not Illuminate (Both Sides)

NKS0027C

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL


Ⓜ With CONSULT-II  
Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 2ND position : HEAD LAMP SW 1 ON  
: HEAD LAMP SW 2 ON**

ⓧ Without CONSULT-II  
Refer to [LT-153, "Combination Switch Inspection"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).



# HEADLAMP - XENON TYPE -

## 2. HEADLAMP ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST" ITEM screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

ACTIVE TEST			
LAMPS		OFF	
		HI	
LO		FOG	
MODE	BACK	LIGHT	COPY

SKIA5774E

OK or NG

- OK >> GO TO 3.  
NG >> GO TO 4.

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is 2ND : HL LO REQ ON position**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
HL LO REQ		ON	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY


SKIA5780E

# HEADLAMP - XENON TYPE -

## 4. CHECK HEADLAMP INPUT SIGNAL

④ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground.



Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E30	4	Ground	Battery voltage
LH	E17	4		

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When headlamp low beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground.

Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E30	4	Ground	Battery voltage
LH	E17	4		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E30 terminal 4.

**20 – 4 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E17 terminal 4.

**30 – 4 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.

# HEADLAMP - XENON TYPE -

## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.


**5 – Ground : Continuity should exist.**

3. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp harness and connectors, ballasts (HID control unit), and xenon bulbs. Refer to [LT-31, "Xenon Headlamp Trouble Diagnosis"](#) .
- NG >> Repair harness or connector.



## Headlamp Does Not Illuminate (One Side)

NKS002TD

### 1. CHECK BULB

Check ballast (HID control unit) and xenon bulb of lamp which does not illuminate. Refer to [LT-31, "Xenon Headlamp Trouble Diagnosis"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Replace malfunctioning part.


### 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connectors.
3. Turn ignition switch ON.
4. Lighting switch is turned 2ND position.
5. Check voltage between front combination lamp RH or LH harness connectors and ground.

(+)		Terminal	(-)	Voltage
Front combination lamp connector				
RH	E30	4	Ground	Battery voltage
LH	E17	4		

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



# HEADLAMP - XENON TYPE -


## 3. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E30 terminal 4.

**20 – 4** : Continuity should exist.

4. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E17 terminal 4.

**30 – 4** : Continuity should exist.



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .
- NG >> Repair harness or connector.

## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.


**5 – Ground** : Continuity should exist.

2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground** : Continuity should exist.

OK or NG

- OK >> Check connector for connection, bend and loose fit and repair.
- NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

NKS002TG

## Headlamps Do Not Turn OFF

### 1. CHECK HEADLAMP TURN OFF

Make sure that lighting switch is OFF. And make sure headlamp turns off when ignition switch is turned OFF.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is OFF : HEAD LAMP SW 1 OFF position : HEAD LAMP SW 2 OFF**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	OFF		
HEAD LAMP SW2	OFF		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7588E

### 3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" on CONSULT-II, and perform self-diagnosis for "BCM".

Display of self-diagnosis results

- NO DTC>> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- CAN COMM CIRCUIT>> Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

# HEADLAMP - XENON TYPE -

## General Information for Xenon Headlamp Trouble Diagnosis

NKS002TH

In most cases, malfunction of xenon headlamp - "does not illuminate", "flickers" or "dark" - is caused by a malfunctioning xenon bulb. A malfunctioning HID control unit or lamp housing, however, may be a cause. Be sure to perform trouble diagnosis following the steps described below.

### Caution:

NKS002TI

- Installation or removal of connector must be done with lighting switch OFF.
- Disconnect the battery cable from the negative terminal or remove power fuse.
- When the lamp is illuminated (when lighting switch is ON), never touch harness, HID control unit, inside of lamp, or lamp metal parts.
- To check illumination, temporarily install lamp in vehicle. Be sure to connect power at vehicle side connector.
- If error can be traced directly to electrical system, first check for items such as blown fuses and fusible links, broken wires or loose connectors, dislocated terminals, and improper connections.
- Never work with wet hands.
- Using a tester for HID control unit circuit trouble diagnosis is prohibited.
- Disassembling HID control unit or harnesses (bulb socket harness, ECM harness) is prohibited.
- Immediately after illumination, light intensity and color will fluctuate, but there is nothing wrong.
- When bulb has come to end of its life, brightness will drop significantly, it will flash repeatedly, or light color will turn reddish.

## Xenon Headlamp Trouble Diagnosis

NKS002TJ

### 1. CHECK 1: XENON HEADLAMP LIGHTING

Install normal xenon bulb to corresponding xenon bulb headlamp, and check if lamp lights up.

OK or NG

- OK >> Replace xenon bulb.
- NG >> GO TO 2.

### 2. CHECK 2: XENON HEADLAMP LIGHTING

Install normal HID control unit to corresponding xenon headlamp, and check if lamp lights up.

OK or NG

- OK >> Replace HID control unit.
- NG >> GO TO 3.

### 3. CHECK 3: XENON HEADLAMP LIGHTING

Install normal xenon lamp housing assembly to corresponding xenon headlamp, and check if lamp lights up.

OK or NG


- OK >> Replace xenon headlamp housing assembly. [Malfunction in starter (boosting circuit) in xenon headlamp housing]
- NG >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP - XENON TYPE -

## Aiming Adjustment

NKS002TK



### PREPARATION BEFORE ADJUSTING

**For Details, Refer To the Regulations In Your Own Country.**

Before performing aiming adjustment, check the following.

1. Keep all tires inflated to correct pressures.
2. Place vehicle on level ground.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.


### LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam ON.
2. Use adjusting screws to perform aiming adjustment.



# HEADLAMP - XENON TYPE -

## ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)




If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Basic illumination area for adjustment should be within the range shown on the aiming chart. Adjust headlamp accordingly.

**CAUTION:**

Be sure aiming switch is set to "0" when performing aiming adjustment.




# HEADLAMP - XENON TYPE -

NKS002TL

## Bulb Replacement HEADLAMP HIGH/LOW BEAM

1. Turn lighting switch OFF.
2. Disconnect the battery cable from the negative terminal or remove power fuse.
3. Remove fender protector (front). Refer to [EI-21, "FENDER PROTECTOR"](#) .
4. Turn plastic cap counterclockwise and unlock it.
5. Turn bulb socket counterclockwise and unlock it.
6. Unlock retaining spring and remove bulb from headlamp.
7. Installation is the reverse order of removal.



### NOTE:

After installation, perform aiming adjustment. Refer to [LT-32, "Aiming Adjustment"](#) .

**Headlamp high/low beam (Xenon) : 12 V - 35 W (D2S)**

## PARKING LAMP

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-21, "FENDER PROTECTOR"](#) .
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.
5. Installation is the reverse order of removal.

**Parking lamp : 12 V - 3.8 W**

## FRONT TURN SIGNAL LAMP

1. Turn lighting switch OFF.
2. Remove air cleaner case (when replacing LH bulb). Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#) .
3. Remove IPDM E/R (when replacing RH bulb). Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .
4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulb from its socket.
6. Installation is the reverse order of removal.

**Front turn signal lamp : 12 V - 21 W (amber)**

## FRONT SIDE MARKER LAMP

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-21, "FENDER PROTECTOR"](#) .
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.
5. Installation is the reverse order of removal.

**Front side marker lamp : 12 V - 3.8 W**

### CAUTION:

After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.


# HEADLAMP - XENON TYPE -

NKS002TM

## Removal and Installation

### REMOVAL

1. Disconnect the battery cable from the negative terminal or remove power fuse.
2. Remove front bumper. Refer to [EI-14, "FRONT BUMPER"](#).
3. Remove headlamp mounting bolts.
4. Remove plastics bumper bracket, then pull headlamp toward vehicle front, disconnect connector, and remove headlamp.



### INSTALLATION

Installation is the reverse order of removal.

**Headlamp mounting bolt**  : 5.1 N·m (0.52 kg·m, 45 in·lb)

### NOTE:

After installation, perform aiming adjustment. Refer to [LT-32, "Aiming Adjustment"](#).

A

B

C

D

E

F

G

H

I

J

LT


L

M

# HEADLAMP - XENON TYPE -

## Disassembly and Assembly

NKS0027TN




- |                                 |                               |  |
|---------------------------------|-------------------------------|--|
| 1. Retaining spring             | 2. Side marker lamp bulb      | 3. Side marker lamp bulb socket        |
| 4. Seal rubber                  | 5. Plastic cap                | 6. Xenon bulb                          |
| 7. Parking lamp bulb            | 8. Parking lamp bulb socket   | 9. Xenon bulb socket                   |
| 10. Seal packing                | 11. HID control unit          | 12. Front turn signal lamp bulb socket |
| 13. Front turn signal lamp bulb | 14. Headlamp housing assembly |  |

### DISASSEMBLY

1. Turn plastic cap counterclockwise and unlock it.
2. Turn xenon bulb socket counterclockwise, and unlock it.
3. Unlock retaining spring, and remove xenon bulb.
4. Disconnect HID control unit connector, and remove HID control unit screws.
5. Turn parking lamp bulb socket counterclockwise and unlock it.
6. Remove parking lamp bulb from its socket.
7. Turn front turn signal lamp bulb socket counterclockwise and unlock it.
8. Remove front turn signal lamp bulb from its socket.
9. Turn front side marker lamp bulb socket counterclockwise and unlock it.
10. Remove front side marker lamp bulb from its socket.

### ASSEMBLY

Assembly is the reverse order of disassembly.

**HID control unit mounting screw**  : 3.2 N-m (0.33 kg-m, 28 in-lb)

### CAUTION:

- When HID control unit is removed, reinstall it securely and avoid any looseness.
- After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.


# HEADLAMP - CONVENTIONAL TYPE-

## HEADLAMP - CONVENTIONAL TYPE-

PPF:26010

### Component Parts and Harness Connector Location

NKS001NM



PKIB2148E

## System Description

NKS001NN

- BCM (Body Control Module) controls headlamps low and high operation.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates headlamp bulbs according to CAN communication signals from BCM.
- Unified meter and A/C amp. operates high beam indicator lamp according to CAN communication signals from BCM.

## OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R
- to headlamp high relay located in IPDM E/R and
- to headlamp low relay located in IPDM E/R, from battery direct,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 10A fuse [No. 21, located in fuse block (J/B)]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## HEADLAMP -CONVENTIONAL TYPE-

---

- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery direct
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14 located in fuse block (J/B)]
- to combination meter terminal 20.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M14 and M78,
- to IPDM E/R terminals 38 and 60
- through grounds E13, E26 and E28,
- to combination meter terminals 22, 23 and 24
- through grounds M14 and M78.

### LOW BEAM OPERATION

When the lighting switch is in 2ND position, BCM detects the HEAD LAMP1 and 2 (ON) by BCM combination switch reading function. BCM sends low beam request signal (ON) through CAN communication.

When receiving low beam request signal (ON), IPDM E/R turns ON headlamp low relay in IPDM E/R. IPDM E/R supplies power

- through 15A fuse (No. 76, located in IPDM E/R)
- through IPDM E/R terminal 20
- to front combination lamp RH terminal 4,
- through 15A fuse (No. 86, located in IPDM E/R)
- through IPDM E/R terminal 30
- to front combination lamp LH terminal 4.

Ground is supplied at all times

- to front combination lamp RH and LH terminals 5
- through grounds E13, E26 and E28.

With power and ground supplied, headlamp low beams illuminate.

### HIGH BEAM OPERATION

When the lighting switch is in HIGH BEAM position and then also in 2ND position, BCM detects the HEAD LAMP1, 2 (ON) and the HI BEAM (ON) by BCM combination switch reading function. BCM sends low beam request signal (OFF) and high beam request signal (ON) through CAN communication.

When receiving those signals, IPDM E/R turns OFF head lamp low relay and turns ON headlamp high relay in IPDM E/R. IPDM E/R supplies power

- through 10A fuse (No. 72, located in IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 1,
- through 10A fuse (No. 74, located in IPDM E/R)
- through IPDM E/R terminal 28
- to front combination lamp LH terminal 1.

Ground is supplied

- to front combination lamp RH and LH terminals 5
- through grounds E13, E26 and E28.

With power and ground supplied, headlamp high beams illuminate.

Unified meter and A/C amp. receives high beam request signal (ON) through CAN communication, and makes high beam indicator lamp turn ON in combination meter.

# HEADLAMP -CONVENTIONAL TYPE-

## FLASH-TO-PASS OPERATION

When the lighting switch is in PASSING position, BCM detects the PASSING (ON) by BCM combination switch reading function. BCM sends high beam request signal (ON) through CAN communication.

When receiving high beam request signal (ON), IPDM E/R turns ON headlamp high relay in IPDM E/R. IPDM E/R supplies power

- through 10A fuse (No. 72, located in IPDM E/R)
- through IPDM E/R terminal 27
- to front combination lamp RH terminal 1,
- through 10A fuse (No. 74, located in IPDM E/R)
- through IPDM E/R terminal 28
- to front combination lamp LH terminal 1.

Ground is supplied

- to front combination lamp RH and LH terminals 5
- through grounds E13, E26 and E28.

With power and ground supplied, headlamp high beams illuminate.

Unified meter and A/C amp. receives high beam request signal (ON) through CAN communication, and makes high beam indicator lamp turn ON in combination meter.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, and then the headlamps are turned off. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## AUTO LIGHT OPERATION

Refer to [LT-84, "System Description"](#) .

## VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to [BL-204, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .

## CAN Communication System Description

NKS001NO

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS001NP

Refer to [LAN-49, "CAN System Specification Chart"](#) .


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# HEADLAMP -CONVENTIONAL TYPE-

## Schematic

NKS001N0



\* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

TKWB2554E







# HEADLAMP - CONVENTIONAL TYPE-

## Wiring Diagram — H/LAMP —

NKS001NR

### LT-H/LAMP-05

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)




(M34), (M35) - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# HEADLAMP -CONVENTIONAL TYPE-


LT-H/LAMP-06



TKWB2556E

# HEADLAMP - CONVENTIONAL TYPE-

LT-H/LAMP-07






TKWA0745E

# HEADLAMP -CONVENTIONAL TYPE-

LT-H/LAMP-08

▬ : DATA LINE



REFER TO THE FOLLOWING.  
(M1), (M2) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWB2557E

# HEADLAMP -CONVENTIONAL TYPE-

## Terminals and Reference Values for BCM

NKS00270

### CAUTION:





- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152. "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value		
			Ignition switch	Operation or condition			
2	R	Combination switch input 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V	
				Lighting, turn, wiper switch (Wiper intermittent dial position 4)	Lighting switch HIGH beam (Operates only HIGH beam switch)	<p>PKIB4959J</p>	Approx. 1.0 V
					Lighting switch 2ND	<p>PKIB4953J</p>	Approx. 2.0 V
3	P/L	Combination switch input 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V	
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul>	<p>PKIB4959J</p>	Approx. 1.0 V
11	P/B	Ignition switch (ACC)	ACC	—		Battery voltage	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# HEADLAMP -CONVENTIONAL TYPE-

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
34	LG/R	Combination switch output 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch HI beam (Operates only HI beam switch)</li> </ul>  <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
35	G/B	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul>  <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
38	R	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	Y	CAN - L	—	—	—
42	GR	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/B	Battery power supply	OFF	—	Battery voltage

# HEADLAMP -CONVENTIONAL TYPE-

## Terminals and Reference Values for IPDM E/R

NKS001NT

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
20	R/Y	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF Approx. 0 V
					ON Battery voltage
27	L/W	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF Approx. 0 V
					ON Battery voltage
28	G	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF Approx. 0 V
					ON Battery voltage
30	L	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF Approx. 0 V
					ON Battery voltage
38	B	Ground	ON	—	Approx. 0 V
48	L	CAN – H	—	—	—
49	Y	CAN – L	—	—	—
60	B	Ground	ON	—	Approx. 0 V

## How to Proceed With Trouble Diagnosis

NKS001NU

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-37, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-47, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS001NV

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	72
		74
		76
		86

Refer to [LT-41, "Wiring Diagram — H/LAMP —"](#) .

#### OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# HEADLAMP -CONVENTIONAL TYPE-

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.





# HEADLAMP -CONVENTIONAL TYPE-

## CONSULT-II Functions (BCM)

NKS001NW

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### WORK SUPPORT

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

#### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF.	ON	×
		OFF	—

## DATA MONITOR

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

#### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.

## HEADLAMP -CONVENTIONAL TYPE-

Monitor item	Contents
LIGHT SW 1 ST	"ON/OFF" Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW	"ON/OFF" Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW	"ON/OFF" Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF" Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
RR FOG SW <sup>NOTE</sup>	—
DOOR SW - DR	"ON/OFF" Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF" Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF" Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF" Displays status of the rear door as judged from the passenger door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW	"ON/OFF" Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R	"ON/OFF" Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF" Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE</sup>	—
OPTICAL SENSOR	"0 - 5V" Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

This item is displayed, but cannot be monitored.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE</sup>	—

**NOTE:**

This item is displayed, but cannot be tested.

# HEADLAMP -CONVENTIONAL TYPE-

## CONSULT-II Functions (IPDM E/R)

NKS001NX

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE " screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS", or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Font fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

# HEADLAMP -CONVENTIONAL TYPE-

## ACTIVE TEST

### Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "OFF" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option. (Headlamp high beam repeats ON-OFF every 1 second.)
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

## Headlamp High Beams Do Not Illuminate (Both Side)

NKS001NY

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

☑ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is : HI BEAM SW ON  
HIGH BEAM position**

☒ Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HI BEAM SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7585E

### 2. HEADLAMP ACTIVE TEST

☑ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

☒ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS	OFF		
		HI	
LO	FOG		
MODE	BACK	LIGHT	COPY

SKIA5774E

# HEADLAMP -CONVENTIONAL TYPE-

## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HI position.

**When lighting switch is HIGH BEAM position** : HL LO REQ ON  
 : HL HI REQ ON

DATA MONITOR			
MONITOR			
HL LO REQ		ON	
HL HI REQ		ON	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5775E


### OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .
- NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

## 4. CHECK HEADLAMP INPUT SIGNAL

### With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "HI" screen.
6. When headlamp high beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground (Headlamp high beam repeats ON-OFF every 1 second).



		(+)	(-)	Voltage
Front combination lamp connector		Terminal		
RH	E30	1	Ground	Battery voltage
LH	E17	1		

### Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
4. When headlamp high beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground.

		(+)	(-)	Voltage
Front combination lamp connector		Terminal		
RH	E30	1	Ground	Battery voltage
LH	E17	1		

### OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

# HEADLAMP -CONVENTIONAL TYPE-


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E30 terminal 1.

**27 – 1** : Continuity should exist.

4. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E17 terminal 1.

**28 – 1** : Continuity should exist.



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .  
NG >> Repair harness or connector.


## 6. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.

**5 – Ground** : Continuity should exist.

2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground** : Continuity should exist.



OK or NG

- OK >> Check headlamp bulb.  
NG >> Repair harness or connector.

## Headlamp High Beam Does Not Illuminate (One Side)

NKS001NZ

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.  
NG >> Replace headlamp bulb.

# HEADLAMP -CONVENTIONAL TYPE-


## 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connectors.
3. Turn ignition switch ON.
4. Lighting switch is turned HIGH BEAM position.
5. Check voltage between front combination lamp RH or LH harness connectors and ground.

Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E30	1	Ground	Battery voltage
LH	E17	1		

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



## 3. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E30 terminal 1.


**27 – 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E17 terminal 1.

**28 – 1 : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .  
 NG >> Repair harness or connector.



## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.


**5 – Ground : Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp harness and connector.  
 NG >> Repair harness or connector.



# HEADLAMP -CONVENTIONAL TYPE-

NKS00101

## Headlamp Low Beams Do Not Illuminate (Both Sides)

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 2ND position : HEAD LAMP SW 1 ON  
: HEAD LAMP SW 2 ON**

⊗ Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
HEAD LAMP SW1	ON		
HEAD LAMP SW2	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7586E

### 2. HEADLAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST" ITEM screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
2. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS		OFF	
		HI	
LO		FOG	
MODE	BACK	LIGHT	COPY

SKIA5774E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is 2ND position : HL LO REQ ON**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .

NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

DATA MONITOR			
MONITOR			
HL LO REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5780E




# HEADLAMP -CONVENTIONAL TYPE-

## 4. CHECK HEADLAMP INPUT SIGNAL

④ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground.



Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E30	4	Ground	Battery voltage
LH	E17	4		

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When headlamp low beam is operating, check voltage between front combination lamp (RH and LH) harness connector and ground.

Front combination lamp connector		(+)	(-)	Voltage
		Terminal		
RH	E30	4	Ground	Battery voltage
LH	E17	4		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E30 terminal 4.

**20 – 4 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E17 terminal 4.

**30 – 4 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.

# HEADLAMP -CONVENTIONAL TYPE-

## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.


**5 – Ground : Continuity should exist.**

3. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp bulb.  
 NG >> Repair harness or connector.



## Headlamp Low Beam Does Not Illuminate (One Side)

NKS00102

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair malfunctioning part.


### 2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH or LH connectors.
3. Turn ignition switch ON.
4. Lighting switch is turned 2ND position.
5. Check voltage between front combination lamp RH or LH harness connectors and ground.

(+)		Terminal	(-)	Voltage
Front combinatin lamp connector				
RH	E30	4	Ground	Battery voltage
LH	E17	4		

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.



# HEADLAMP -CONVENTIONAL TYPE-


## 3. CHECK HEADLAMP CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E30 terminal 4.

**20 – 4** : **Continuity should exist.**

3. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E17 terminal 4.

**30 – 4** : **Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .  
NG >> Repair harness or connector.

## 4. CHECK HEADLAMP GROUND

1. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.


**5 – Ground** : **Continuity should exist.**

2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground** : **Continuity should exist.**

OK or NG

- OK >> Check headlamp harness and connector.  
NG >> Repair harness or connector.



## Headlamp RH Low Beam and High Beam Do Not Illuminate

NKS00103

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.  
NG >> Replace headlamp bulb.


### 2. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH connector.
3. Check continuity between front combination lamp RH harness connector E30 terminal 5 and ground.

**5 – Ground** : **Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.




# HEADLAMP -CONVENTIONAL TYPE-

## 3. CHECK HEADLAMP CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E7 terminal 27 and front combination lamp RH harness connector E30 terminal 1.

**27 – 1** : Continuity should exist.




3. Check continuity between IPDM E/R harness connector E7 terminal 20 and front combination lamp RH harness connector E30 terminal 4.

**20 – 4** : Continuity should exist.

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.



## Headlamp LH Low Beam and High Beam Do Not Illuminate

NKS00104

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

- OK >> GO TO 2.
- NG >> Replace headlamp bulb.


### 2. CHECK HEADLAMP GROUND

1. Disconnect front combination lamp LH connector.
2. Check continuity between front combination lamp LH harness connector E17 terminal 5 and ground.

**5 – Ground** : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.




# HEADLAMP -CONVENTIONAL TYPE-

## 3. CHECK HEADLAMP CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E7 terminal 28 and front combination lamp LH harness connector E17 terminal 1.

**28 – 1 : Continuity should exist.**



3. Check continuity between IPDM E/R harness connector E7 terminal 30 and front combination lamp LH harness connector E17 terminal 4.

**30 – 4 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.

## Headlamps Do Not Turn OFF

### 1. CHECK HEADLAMP TURN OFF

Make sure that lighting switch is OFF. And make sure headlamps turns off when ignition switch is turned OFF.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.


### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turn ON-OFF linked with operation of lighting switch.

**When lighting switch is OFF : HEAD LAMP SW 1 OFF position : HEAD LAMP SW 2 OFF**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
- NG >> Check combination lamp (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).



## HEADLAMP -CONVENTIONAL TYPE-

### 3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" on CONSULT-II, and perform self-diagnosis for "BCM".

#### Display of self-diagnosis results

NO DTC>> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).


CAN COMM CIRCUIT>> Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

### Aiming Adjustment

NKS00106



PKIA2515E

#### PREPARATION BEFORE ADJUSTING

**For Details, Refer To the Regulations In Your Own Country.**

Before performing aiming adjustment, check the following.


1. Keep all tires inflated to correct pressures.
2. Place vehicle on level ground.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.

#### LOW BEAM AND HIGH BEAM

1. Turn headlamp low beam ON.
2. Use adjusting screws to perform aiming adjustment.

# HEADLAMP -CONVENTIONAL TYPE-

## ADJUSTMENT USING AN ADJUSTMENT SCREEN (LIGHT/DARK BORDERLINE)



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Basic illumination area for adjustment should be within the range shown on the aiming chart. Adjust headlamp accordingly.

### Bulb Replacement HEADLAMP HIGH/LOW BEAM

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-21, "FENDER PROTECTOR"](#) .
3. Turn plastic cap counterclockwise and unlock it.
4. Disconnect bulb terminal.
5. Unlock retaining spring and remove bulb from headlamp.
6. Installation is the reverse order of removal.

**Headlamp high/low beam (Halogen) : 12V - 65/55W (HB5)**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP -CONVENTIONAL TYPE-

## PARKING LAMP

1. Turn lighting switch OFF.
2. Remove air cleaner case (when replacing LH bulb). Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#) .
3. Remove IPDM E/R (when replacing RH bulb). Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .
4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulb from its socket.
6. Installation is the reverse order of removal.

**Parking lamp** : 12V - 3.8W

## FRONT TURN SIGNAL LAMP

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-21, "FENDER PROTECTOR"](#) .
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.
5. Installation is the reverse order of removal.

**Front turn signal lamp** : 12V - 21W (amber)

### CAUTION:

After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.

## FRONT SIDE MARKER LAMP

1. Turn lighting switch OFF.
2. Remove fender protector (front). Refer to [EI-21, "FENDER PROTECTOR"](#) .
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.
5. Installation is the reverse order of removal.

**Front side marker lamp** : 12V - 3.8W


### CAUTION:

After installing bulb, be sure to install plastic cap and socket securely to insure watertightness.

## Removal and Installation

### REMOVAL

1. Remove front bumper. Refer to [EI-14, "FRONT BUMPER"](#) .
2. Remove headlamp mounting bolts.
3. Remove plastics bumper bracket, then pull headlamp toward vehicle front, disconnect connector, and remove headlamp.



### INSTALLATION

Installation is the reverse order of removal.

**Headlamp mounting bolt**  : 5.1N·m (0.52 kg·m, 45 in·lb)

### NOTE:


After installation, perform aiming adjustment. Refer to [LT-62, "Aiming Adjustment"](#) .



# HEADLAMP -CONVENTIONAL TYPE-

## Disassembly and Assembly

NKS00109



- |                                |                                       |                           |
|--------------------------------|---------------------------------------|---------------------------|
| 1. Side marker lamp bulb       | 2. Side marker lamp bulb socket       | 3. Halogen bulb connector |
| 4. Front turn signal lamp bulb | 5. Front turn signal lamp bulb socket | 6. Plastic holder         |
| 7. Halogen bulb                | 8. Parking lamp bulb socket           | 9. Parking lamp bulb      |
| 10. Headlamp housing assembly  |                                       |                           |

### DISASSEMBLY

1. Disconnect the connector to the halogen bulb (high/low).
2. Turn plastic holder counterclockwise and unlock it.
3. Disconnect bulb socket.
4. Unlock retaining spring, and remove halogen bulb (high/low).
5. Turn parking lamp bulb socket counterclockwise and unlock it.
6. Remove parking lamp bulb from its socket.
7. Turn front turn signal lamp bulb socket counterclockwise and unlock it.
8. Remove front turn signal lamp bulb from its socket.
9. Turn front side marker lamp bulb socket counterclockwise and unlock it.
10. Remove front side lamp marker lamp bulb from its socket.

### ASSEMBLY

Assembly is the reverse order of disassembly.

#### **CAUTION:**

**After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# DAYTIME LIGHT SYSTEM

PFP:284B2

## DAYTIME LIGHT SYSTEM

### Component Parts and Harness Connector Location

NKS0010A



PKIB2158E

## System Description

NKS0010B

Daytime light system turns ON daytime light lamps (front fog lamps) while driving. Daytime light lamps are not turned ON if engine is activated with parking brake ON. Release parking brake to turn on daytime light lamps. The lamps turn OFF when lighting switch is in the 2ND position or AUTO position (headlamp is ON) and when lighting switch is in the PASSING position. (Daytime light lamps are not turned off only by parking brake itself.) A parking brake signal and engine run or stop signal are sent to BCM (body control module) by CAN communication line, and control daytime light system.

## OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R (intelligent power distribution module engine room), from battery direct,

# DAYTIME LIGHT SYSTEM

- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU (central processing unit) located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 21, located in fuse block (J/B)]
- to combination meter terminal 21.

A  
B  
C  
D  
E

When the ignition switch is in ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 20.

F  
G

When the ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

H

Ground is supplied

- to BCM terminal 52
- through grounds M14 and M78,
- to IPDM E/R terminals 38 and 60
- through grounds E13, E26 and E28,
- to combination meter terminals 22, 23 and 24
- through grounds M14 and M78.

I  
J

## DAYTIME LIGHT OPERATION

Once the parking brake is turned OFF after ignition switch ON, if the lighting switch is turned OFF while engine running, the BCM sends front fog lamp request signal (ON) through CAN communication.

When receiving front fog lamp request signal (ON), IPDM E/R turns ON front fog lamp relay in IPDM E/R. IPDM E/R supplies power

- through IPDM E/R terminal 37
- to front fog lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front fog lamp RH terminal 1.

LT  
L  
M

Ground is supplied

- to front fog lamp RH and LH terminals 2
- through grounds E13, E26 and E28.

With power and ground supplied, front fog lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated.

Under this condition, the front fog lamps remain illuminated for 5 minutes, and then the front fog lamps are turned off.

Exterior lamp battery saver control made can be changed by the function setting of CONSULT-II.

# DAYTIME LIGHT SYSTEM

---

## AUTO LIGHT OPERATION

For auto light operation, refer to [LT-84, "System Description"](#) in "AUTO LIGHT SYSTEM".

## CAN Communication System Description

NKS0010C

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


NKS0010D

Refer to [LAN-49, "CAN System Specification Chart"](#) .

# DAYTIME LIGHT SYSTEM

## Schematic

NKS0010E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

TKWB0446E







# DAYTIME LIGHT SYSTEM

## Wiring Diagram — DTRL —

NKS0010F

LT-DTRL-01

▬ : DATA LINE







REFER TO THE FOLLOWING.

(M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWM4961E

# DAYTIME LIGHT SYSTEM

LT-DTRL-02




REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M34), (M35) - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# DAYTIME LIGHT SYSTEM

LT-DTRL-03




REFER TO PG-POWER.

IPDM E/R  
(INTELLIGENT  
POWER  
DISTRIBUTION  
MODULE  
ENGINE ROOM)  
E8, E9

— : DATA LINE

PRE-  
CEDING  
PAGE



TKWB2559E



# DAYTIME LIGHT SYSTEM

## Terminals and Reference Values for BCM

NKS0010G







**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152. "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	R	Combination switch input 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	Approx. 0 V
				Lighting switch 2ND	<p style="text-align: right;">PKIB4953J</p>
3	P/L	Combination switch input 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	Approx. 2.0 V
				Front fog lamp switch (Operate only front fog lamp switch)	<p style="text-align: right;">PKIB4955J</p>
				Any of the conditions below	<ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> </ul> <p style="text-align: right;">PKIB4959J</p>
4	R/G	Combination switch input 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	Approx. 0 V
				Any of the conditions below	<ul style="list-style-type: none"> <li>● Lighting switch AUTO</li> </ul> <p style="text-align: right;">PKIB4959J</p>
11	P/B	Ignition switch (ACC)	ACC	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# DAYTIME LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
32	LG/B	Combination switch output 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Front fog lamp switch (Operates only front fog lamp switch)  <p style="text-align: right;">PKIB4956J</p> <p style="text-align: center;">Approx. 1.0 V</p>
33	G/Y	Combination switch output 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Lighting switch AUTO  <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
34	LG/R	Combination switch output 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Lighting switch 2ND  <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>

# DAYTIME LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
35	G/B	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF  PKIB4960J Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASS-ING (Operates only PASS-ING switch)</li> </ul> PKIB4958J Approx. 1.2 V
38	R	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN – H	—	—	—
40	Y	CAN – L	—	—	—
42	GR	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/B	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Values for IPDM E/R

NKS0010H

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
36	G/W	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON.	OFF	Approx. 0 V
					ON	Battery voltage
37	W/R	Front fog lamp (LH)	ON	Lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON.	OFF	Approx. 0 V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	
49	Y	CAN – L	—	—	—	
60	B	Ground	ON	—	Approx. 0 V	

## How to Proceed with Trouble Diagnosis

NKS0010I

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-66, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-76, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# DAYTIME LIGHT SYSTEM

NKS0010J

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	88

Refer to [LT-70. "Wiring Diagram — DTRL —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3. "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# DAYTIME LIGHT SYSTEM

## CHECK PARKING BRAKE SWITCH CIRCUIT

### 1. CHECK BRAKE INDICATOR

1. Turn ignition switch ON.
2. When parking brake is made ON/OFF, it checks whether the brake indicator lamp of combination meter lights up/puts out the light.

OK or NG

- OK >> INSPECTION END  
 NG >> GO TO 2.


### 2. CHECK PARKING BRAKE SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between parking brake switch harness connector and ground, when parking brake is released.

(+)		(-)	Condition	Voltage
Parking brake switch Connector	Terminal			
E112	1	Ground	Not released	Approx. 0 V
			Released	Battery voltage

OK or NG

- OK >> GO TO 3  
 NG >> Replace parking brake switch.




### 3. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector and combination meter connector.
3. Check continuity between combination meter harness connector M25 terminal 1 and parking brake switch harness connector E112 terminal 1.

**1 - 1 : Continuity should exist.**

OK or NG

- OK >> INSPECTION END  
 NG >> Repair harness or connector.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# DAYTIME LIGHT SYSTEM

## CONSULT-II Functions (BCM)

NKS0010K

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### WORK SUPPORT

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

#### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two ON/OFF.	ON	×
		OFF	—

## DATA MONITOR

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

#### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.

# DAYTIME LIGHT SYSTEM

Monitor item	Contents
LIGHT SW 1 ST	"ON/OFF" Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW	"ON/OFF" Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW	"ON/OFF" Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW	"ON/OFF" Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
RR FOG SW <sup>NOTE</sup>	"OFF" —
DOOR SW - DR	"ON/OFF" Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF" Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR	"ON/OFF" Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF" Displays status of the rear door as judged from the passenger door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW	"ON/OFF" Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R	"ON/OFF" Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L	"ON/OFF" Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE</sup>	"OFF" —
OPTICAL SENSOR	"0 - 5V" Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

This item is displayed, but cannot be monitored.

## ACTIVE TEST

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE</sup>	—

**NOTE:**

This item is displayed, but cannot be tested.

# DAYTIME LIGHT SYSTEM

## CONSULT-II Functions (IPDM E/R)

NKS0010L

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19. "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II BASIC OPERATION

Refer to [GI-37. "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE " screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS", or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Font fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.



# DAYTIME LIGHT SYSTEM

## ACTIVE TEST

### Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "OFF" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option. (Headlamp high beam repeats ON-OFF every 1 second.)
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

## Daytime Light Control Does Not Operate Properly

NKS0010M

### 1. FRONT FOG LAMP ACTIVE TEST

#### ☐ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure front fog lamps operates.

**Front fog lamps should operate.**


#### ⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
2. Make sure front fog lamps operates.

**Front fog lamps should operate.**

#### OK or NG

- OK >> GO TO 5.  
 NG >> GO TO 2.




# DAYTIME LIGHT SYSTEM

## 2. CHECK FRONT FOG LAMP INPUT SIGNAL

☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "FOG" screen.
6. When front fog lamps are operating, check voltage between front fog lamp (RH and LH) harness connector and ground.



(+)		Terminal	(-)	Voltage
Front fog lamp connector				
RH	E94	1	Ground	Battery voltage
LH	E92	1		

☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When front fog lamps are operating, check voltage between front fog lamp (RH and LH) harness connector and ground.


(+)		Terminal	(-)	Voltage
Front fog lamp connector				
RH	E94	1	Ground	Battery voltage
LH	E92	1		

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 3.

## 3. CHECK FRONT FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 and front fog lamp RH harness connector E94 terminal 1.  
**36 – 1 : Continuity should exist.**
4. Check continuity between IPDM E/R harness connector E8 terminal 37 and front fog lamp LH harness connector E92 terminal 1.  
**37 – 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.

# DAYTIME LIGHT SYSTEM

## 4. CHECK FRONT FOG LAMP GROUND

1. Check continuity between front fog lamp RH harness connector E94 terminal 2 and ground.


**2 – Ground** : **Continuity should exist.**

2. Check continuity between front fog lamp LH harness connector E92 terminal 2 and ground.

**2 – Ground** : **Continuity should exist.**

OK or NG

- OK >> Check front fog lamp bulbs.
- NG >> Repair harness or connector.



## 5. CHECK SELF-DIAGNOSIS

Select "BCM" on CONSULT-II, and self-diagnosis for "BCM".

Displayed results of self-diagnosis

- No malfunction detected>> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- CAN communications or CAN system>> Check BCM CAN communication system. Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# AUTO LIGHT SYSTEM

## AUTO LIGHT SYSTEM

PFP:28491

### Component Parts and Harness Connector Location

NKS0010R



PKIB2159E

## System Description

NKS0010S

- BCM (Body Control Module) controls auto light operation according to signals from optical sensor, lighting switch, driver door switch, passenger door switch and ignition switch.
- Optical sensor detects ambient brightness of 800 to 2,500 lux. And optical sensor converts light (lux) to voltage, then sends the optical sensor signal to BCM.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates parking, license plate, tail lamps and headlamps low according to CAN communication signals from BCM.
- For a description of headlamp low operation, refer to [LT-6, "System Description"](#) .
- For a description of parking, license plate, side marker and tail lamp operation, refer to [LT-166, "System Description"](#) .

# AUTO LIGHT SYSTEM

## OUTLINE

The auto light control system has an optical sensor inside it that detects outside brightness. When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking lamps and the headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, Refer to [LT-92, "SETTING CHANGE FUNCTIONS"](#) .

Optical sensor, power is supplied

- from BCM (body control module) terminal 17
- to optical sensor terminal 1.

Optical sensor, ground is supplied

- to optical sensor terminal 3
- through BCM terminal 18.

When ignition switch is turn to "ON" position, and

When outside brightness is darker than prescribed level, input is supplied

- from optical sensor terminal 2
- to BCM terminal 14.

The headlamps will then illuminate. For a description of headlamp operation, Refer to [LT-84, "System Description"](#) .

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## DELAY TIMER FUNCTION

Delay timer function carries out a function that BCM activates the timer and controls lights out of headlamps by door switch signal and lightning switch signal when turning the Ignition switch OFF while it is ON and headlamps are ON by the auto light function.

Timer types are a 5-minute timer and a 45-second timer

- When opening any door (door switch is ON), the 5-minute timer starts and then headlamps go out five minutes later
- When all the doors are closed (from door switch ON to OFF), the 45-second timer starts and then headlamps go out forty-five seconds later. If any door is opened (door switch ON) while the 45-second timer is in operation, the 5-minute timer starts again
- The timer stops when turning on the ignition switch or turning off the auto light switch under the above conditions.

Delay timer control mode can be changed by the function setting of CONSULT-II or display.

## CAN Communication System Description

NKS0010T

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


NKS0010U

Refer to [LAN-49, "CAN System Specification Chart"](#) .

# AUTO LIGHT SYSTEM

## Schematic

NKS0010W



TKWB0450E




# AUTO LIGHT SYSTEM

## Wiring Diagram — AUTO/L —

NKS0010X

LT-AUTO/L-01

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M34), (M35) - ELECTRICAL UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM



LT-AUTO/L-02

◊IK◊ : WITH INTELLIGENT KEY

◊OK◊ : WITHOUT INTELLIGENT KEY

\*1 R/G : ◊IK◊    \*2 R/W : ◊IK◊

R : ◊OK◊            R/Y : ◊OK◊



REFER TO THE FOLLOWING.

◊D1◊, ◊D31◊ -SUPER MULTIPLE JUNCTION (SMJ)

◊M34◊, ◊M36◊ -ELECTRICAL UNITS




TKWB2561E



# AUTO LIGHT SYSTEM

LT-AUTO/L-03

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



TKWB2562E




# AUTO LIGHT SYSTEM

NKS0010Y

## Terminals and Reference Values for BCM

**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152, "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value		
			Ignition switch	Operation or condition			
4	R/G	Combination switch input 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V	
					Lighting switch AUTO	 <p style="text-align: right; font-size: small;">PKIB4959J</p>	Approx. 1.0 V
11	P/B	Ignition switch (ACC)	ACC	—		Battery voltage	
12	R/G <sup>*1</sup> R <sup>*2</sup>	Front door switch AS signal	OFF	Front door switch AS	ON (open)	Approx. 0 V	
					OFF (closed)	Battery voltage	
13	R/W <sup>*1</sup> R/Y <sup>*2</sup>	Rear door switch RH signal	OFF	Rear door switch RH	ON (open)	Approx. 0 V	
					OFF (closed)	Battery voltage	
14	W	Optical sensor signal	ON	When optical sensor is illuminated		3.1 V or more <sup>NOTE</sup>	
				When optical sensor is not illuminated		0.6 V or less	
17	BR/Y	Optical sensor power supply	ON	—		Approx. 5 V	
18	P	Keyless and auto light sensor ground	ON	—		Approx. 0 V	
33	G/Y	Combination switch output 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p>	Approx. 7.2 V
					Lighting switch AUTO	 <p style="text-align: right; font-size: small;">PKIB4958J</p>	Approx. 1.2 V
38	R	Ignition switch (ON)	ON	—		Battery voltage	
39	L	CAN - H	—	—		—	

# AUTO LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
40	Y	CAN – L	—	—	—	
42	GR	Battery power supply	OFF	—	Battery voltage	
52	B	Ground	ON	—	Approx. 0 V	
55	W/B	Battery power supply	OFF	—	Battery voltage	
62	SB	Front door switch DR signal	OFF	Front door switch DR	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage
63	R/W	Rear door switch LH signal	OFF	Rear door switch LH	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage

\*1: With intelligent key, \*2: Without intelligent key

**NOTE:**

Optical sensor must be securely subjected to work lamp light. If the optical sensor is insufficiently illuminated, the measured value may not satisfy standard.

## Terminals and Reference Values for IPDM E/R

NKS0010Z

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
20	R/Y	Headlamp HIGH & LOW (RH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
22	R/L	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF	Approx. 0 V
					ON	Battery voltage
27	L/W	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0 V
					ON	Battery voltage
28	G	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF	Approx. 0 V
					ON	Battery voltage
30	L	Headlamp HIGH & LOW (LH)	ON	Lighting switch 2ND position	OFF	Approx. 0 V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	
49	Y	CAN – L	—	—	—	
60	B	Ground	ON	—	Approx. 0 V	

## How to Proceed with Trouble Diagnosis

NKS001P0

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-84, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-92, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction. Refer to [LT-96, "Symptom Chart"](#) .
5. Does the auto light system operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# AUTO LIGHT SYSTEM

NKS001P1

## Preliminary Check SETTING CHANGE FUNCTIONS

Sensitivity of auto light system can be adjusted using CONSULT-II. Refer to [LT-93, "WORK SUPPORT"](#) .

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71
		72
		74
		76
		86
		86

Refer to [LT-87, "Wiring Diagram — AUTO/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM con- nector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



# AUTO LIGHT SYSTEM


## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

- OK >> INSPECTION END
- NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

NKS001P2

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### WORK SUPPORT

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "CUSTOM A/LIGHT SETTING" or "ILL DELAY SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "NORMAL" or "MODE 2 - 4" of setting to be changed (CUSTOM A/LIGHT SETTING) or touch "MODE1-8" of setting to be changed (ILL DELAY SET).
6. Touch "SETTING CHANGE".
7. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
8. Touch "END".

#### Work Support Setting Item

Sensitivity of auto light can be selected and set from four modes.

Work item	Description
CUSTOM A/LIGHT SETTING	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. <ul style="list-style-type: none"> <li>● MODE 1 (Normal)/ MODE 2 (sensitive)/MODE 3 (Desensitized)/MODE4 (Insensitive)</li> </ul>
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. <ul style="list-style-type: none"> <li>● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/MODE 5 (90 sec.)/MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)</li> </ul>

# AUTO LIGHT SYSTEM

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1 ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
RR FOG SW <sup>NOTE</sup> "OFF"	—
DOOR SW - DR "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RR "ON/OFF"	Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL "ON/OFF"	Displays status of the rear door as judged from the passenger door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW "ON/OFF"	Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW <sup>NOTE</sup> "OFF"	—
OPTICAL SENSOR "0 - 5V"	Displays "outside brightness (close to 5V when light/close to 0V when dark)" judged from optical sensor signal.

**NOTE:**

This item is displayed, but cannot be monitored.

# AUTO LIGHT SYSTEM

## ACTIVE TEST

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CORNERING LAMP <sup>NOTE</sup>	—

#### NOTE:

This item is displayed, but cannot be tested.

## CONSULT-II Functions (IPDM E/R)

NKS001P3

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to <a href="#">PG-19, "SELF-DIAG RESULTS"</a> .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE " screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS", or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all items.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Selects items and monitors them.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

# AUTO LIGHT SYSTEM

## All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Font fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

### ACTIVE TEST

#### Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "OFF" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI ON, LO ON) at your option. (Headlamp high beam repeats ON-OFF every 1 second.)
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

## Symptom Chart

NKS001P4

Phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> <li>● Parking, license plate, side marker and tail lamps and headlamps will not illuminate when outside of the vehicle becomes dark. (Lighting switch 1ST position and 2ND position operate normally.)</li> <li>● Parking, license plate, side marker and tail lamps and headlamp will not go out when outside of the vehicle becomes light. (Lighting switch 1ST position and 2nd position operate normally.)</li> <li>● Headlamps go out when outside of the vehicle becomes light, but parking lamps stay on.</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-93, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-97, "Lighting Switch Inspection"</a> .</li> <li>● Refer to <a href="#">LT-97, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM.</p>
Auto light adjustment system will not operate. (Lighting switch AUTO, 1ST position and 2ND position operate normally.)	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-97, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above system is normal, replace BCM.</p>
Shut off delay feature will not operate.	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-13, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> <li>● Refer to <a href="#">BL-43, "Check Door Switch"</a> .</li> </ul> <p>If above system is normal, replace BCM.</p>



# AUTO LIGHT SYSTEM

## Lighting Switch Inspection

NKS001P5

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

① With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "AUTO LIGHT SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is AUTO : AUTO LIGHT SW ON position**

② Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#).

OK or NG

OK >> INSPECTION END

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
AUTO LIGHT SW		ON	
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7595E

## Optical Sensor System Inspection

NKS001P6

### 1. CHECK OPTICAL SENSOR INPUT SIGNAL

① With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "OPTICAL SENSOR", check difference in voltage when the optical sensor is illuminated and not illuminated.

**Illuminated**

**OPTICAL SENSOR : 3.1 V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6 V or less**

#### CAUTION:

**Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.**

② Without CONSULT-II

1. Turn ignition switch ON.

2. Check voltage between BCM harness connector M34 terminal 14 and ground.

**Illuminated**

**OPTICAL SENSOR : 3.1 V or more**

**Not illuminated**

**OPTICAL SENSOR : 0.6 V or less**

#### CAUTION:

**Optical sensor must be securely subjected to work lamp light. If optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.**


OK or NG

OK >> INSPECTION END

NG >> GO TO 2.

DATA MONITOR			
MONITOR			
OPTICAL SENSOR		0.75V	
RECORD			
MODE	BACK	LIGHT	COPY

PKIA7596E



# AUTO LIGHT SYSTEM


## 2. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and optical sensor connector.
3. Check continuity (open circuit) between BCM harness connector M34 terminal 17 and optical sensor harness connector M16 terminal 1.

**17 – 1 : Continuity should exist.**

4. Check continuity (short circuit) between BCM harness connector M34 terminal 17 and ground.

**17 – Ground : Continuity should not exist.**



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.


## 3. CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M34 terminal 14 and optical sensor harness connector M16 terminal 2.

**14 – 2 : Continuity should exist.**

2. Check continuity (short circuit) between BCM harness connector M34 terminal 14 and ground.

**14 – Ground : Continuity should not exist.**



OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.


## 4. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M34 terminal 18 and optical sensor harness connector M16 terminal 3.

**18 – 3 : Continuity should exist.**

2. Check continuity (short circuit) between BCM harness connector M34 terminal 18 and ground.

**18 – Ground : Continuity should not exist.**



OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.

# AUTO LIGHT SYSTEM


## 5. CHECK OPTICAL SENSOR VOLTAGE

1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M34 terminal 17 and ground.

**17 – Ground : Approx. 5 V**

### OK or NG

- OK >> Replace optical sensor. Refer to [LT-100, "Removal and Installation of Optical Sensor"](#).
- NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# AUTO LIGHT SYSTEM

## Removal and Installation of Optical Sensor

NKS001P7

### REMOVAL

1. Remove instrument mask (LH) assembly. Refer to [IP-11, "Removal and Installation"](#).
2. While pressing pawl in direction as shown in the figure, remove the sensor unit from instrument mask.



### INSTALLATION

Installation is the reverse order of removal.

# HEADLAMP AIMING CONTROL

PFP:26010

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M





## HEADLAMP AIMING CONTROL

### Wiring Diagram — H/AIM —

NKS001P8

#### LT-H/AIM-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(M34), (M35) - ELECTRICAL UNITS










TKWB2563E

# HEADLAMP AIMING CONTROL

**LT-H/AIM-02**

▬ : DATA LINE

REFER TO PG-POWER.




TKWB2564E

# HEADLAMP AIMING CONTROL

## Removal and Installation

### REMOVAL

1. Remove the side ventilator assembly (LH). Refer to [IP-11, "Removal and Installation"](#) .
2. Press the headlamp aiming switch fixing pawls and remove the unit from the side ventilator assembly (LH).




### INSTALLATION

Installation is the reverse order of removal.

### Switch Circuit Inspection (Xenon type)

Using a circuit tester, check resistance between the headlamp aiming switch connector terminals in each operation status of the aiming switch.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# FRONT FOG LAMP

## FRONT FOG LAMP

PFP:26150

### Component Parts and Harness Connector Location

NKS001PB



## System Description

NKS001PC

- BCM (Body Control Module) controls front fog lamp operation.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates front fog lamps according to CAN communication signals from BCM.

## OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R, from battery direct,
- through 15A fuse (No. 88, located in IPDM E/R)
- to front fog lamp relay, located in IPDM E/R,
- through 10A fuse (No. 71, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42.

When the ignition switch is in ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery direct,



# FRONT FOG LAMP

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

When the ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds E13, E26 and E28,
- to IPDM E/R terminals 38 and 60
- through grounds E13, E26 and E28.

## FRONT FOG LAMP OPERATION

When the lighting switch is in front fog lamp ON position and also in 2ND position or AUTO position (LOW beam is ON\*), BCM detects FR FOG (ON) and the HEAD LAMP1, 2 (ON) or the AUTO LIGHT (ON) by BCM combination switch reading function. BCM sends front fog lamp request signal (ON) through CAN communication.

When receiving front fog lamp request signal (ON), IPDM E/R turns ON front fog lamp relay in IPDM E/R. IPDM E/R supplies power

- through IPDM E/R terminal 37
- to front fog lamp LH terminal 1,
- through IPDM E/R terminal 36
- to front fog lamp RH terminal 1.

Ground is supplied

- to front fog lamp RH and LH terminals 2
- through grounds E13, E26 and E28.

With power and ground supplied, front fog lamp illuminate.

\*: For a description of auto light operation, refer to [LT-84, "System Description"](#) .

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), the fog lamp switch is ON, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the fog lamps (and headlamps) remain illuminated for 5 minutes, and then the fog lamps (and headlamps) are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

NKS001PD

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS001PE

Refer to [LAN-49, "CAN System Specification Chart"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT





# FRONT FOG LAMP

NKS001PF

## Wiring Diagram — F/FOG —

LT-F/FOG-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)



(M34), (M35) - ELECTRICAL UNITS

TKWB2565E

# FRONT FOG LAMP

LT-F/FOG-02

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



TKWB2566E




# FRONT FOG LAMP

NKS001PG

## Terminals and Reference Values for BCM

### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152. "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
3	P/L	Combination switch input 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					Front fog lamp switch (Operates only front fog lamp switch)	 <p>Approx. 0.8 V</p>
11	P/B	Ignition switch (ACC)	ACC	—	Battery voltage	
32	LG/B	Combination switch output 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	 <p>Approx. 7.2 V</p>
					Front fog lamp switch (Operates only front fog lamp switch)	 <p>Approx. 1.0 V</p>
38	R	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN – H	—	—	—	
40	Y	CAN – L	—	—	—	
42	GR	Battery power supply	OFF	—	Battery voltage	
52	B	Ground	ON	—	Approx. 0 V	
55	W/B	Battery power supply	OFF	—	Battery voltage	

# FRONT FOG LAMP

## Terminals and Reference Values for IPDM E/R

NKS001PH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
36	G/W	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON) and the front fog lamp switch must be ON.	OFF	Approx. 0 V
					ON	Battery voltage
37	W/R	Front fog lamp (LH)	ON		OFF	Approx. 0 V
					ON	Battery voltage
38	B	Ground	ON	—	Approx. 0 V	
48	L	CAN – H	—	—	—	
49	Y	CAN – L	—	—	—	
60	B	Ground	ON	—	Approx. 0 V	

## How to Proceed with Trouble Diagnosis

NKS001PI

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-104, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-109, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS001PJ

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	88

Refer to [LT-106, "Wiring Diagram — F/FOG —"](#) .

#### OK or NG

- OK >> GO TO 2.
- NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#) .

# FRONT FOG LAMP

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

Refer to [LT-19, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP -XENON TYPE-.

Refer to [LT-49, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP -CONVENTIONAL TYPE-.

## CONSULT-II Functions (IPDM E/R)

Refer to [LT-21, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP -XENON TYPE-.

Refer to [LT-51, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP -CONVENTIONAL TYPE-.

NKS001PK

NKS001PL

# FRONT FOG LAMP

## Front Fog Lamps Do Not Illuminate (Both Sides)

NKS001PM

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is FOG : FR FOG SW ON position**

⊗ Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
FR FOG SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7598E

### 2. FRONT FOG LAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" screen.
4. Make sure front fog lamps operate.

**Front fog lamps should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
2. Make sure front fog lamps operate.

**Front fog lamps should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
LAMPS	OFF		
		HI	
LO	FOG		
MODE	BACK	LIGHT	COPY

SKIA5774E

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when lighting switch is in FOG position.

**When lighting switch is FOG : FR FOG REQ ON position**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .

NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

DATA MONITOR			
MONITOR			
FR FOG REQ	ON		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY


SKIA5898E

# FRONT FOG LAMP

## 4. CHECK FRONT FOG LAMP INPUT SIGNAL

☑ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "LAMPS" on "SELECT TEST ITEM" screen.
5. Touch "FOG" screen.
6. When front fog lamps are operating, check voltage between front fog lamp (RH and LH) harness connector and ground.



(+)		Terminal	(-)	Voltage
Front fog lamp connector				
RH	E94	1	Ground	Battery voltage
LH	E92	1		

☒ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. When front fog lamps are operating, check voltage between front fog lamp (RH and LH) harness connector and ground.

(+)		Terminal	(-)	Voltage
Front fog lamp connector				
RH	E94	1	Ground	Battery voltage
LH	E92	1		

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.


## 5. CHECK FRONT FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 and front fog lamp RH harness connector E94 terminal 1.

**36 – 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 and front fog lamp LH harness connector E92 terminal 1.

**37 – 1 : Continuity should exist.**



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.



# FRONT FOG LAMP

## 6. CHECK FRONT FOG LAMP GROUND

1. Check continuity between front fog lamp RH harness connector E94 terminal 2 and ground.


**2 – Ground : Continuity should exist.**

2. Check continuity between front fog lamp LH harness connector E92 terminal 2 and ground.

**2 – Ground : Continuity should exist.**

OK or NG

- OK >> Check front fog lamp bulbs.
- NG >> Repair harness or connector.



NKS001PN

## Front Fog Lamp Does Not Illuminate (One Side)

### 1. CHECK BULB

Check bulb of lamp which does not illuminate.


OK or NG

- OK >> GO TO 2.
- NG >> Replace front fog lamp bulb.

### 2. CHECK FRONT FOG LAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH or LH connector.
3. Check voltage between front fog lamp RH or LH harness connector and ground.

		(+)		(-)	Voltage
Front fog lamp Connector		Terminal			
RH	E94	1		Ground	Battery voltage
LH	E92	1			



OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

### 3. CHECK FRONT FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E8 terminal 36 and front fog lamp RH harness connector E94 terminal 1.


**36 - 1 : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E8 terminal 37 and front fog lamp LH harness connector E92 terminal 1.

**37 - 1 : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair harness or connector.



# FRONT FOG LAMP

## 4. CHECK FRONT FOG LAMP GROUND

1. Check continuity between front fog lamp RH harness connector E94 terminal 2 and ground.


**2 – Ground : Continuity should exist.**

2. Check continuity between front fog lamp LH harness connector E92 terminal 2 and ground.

**2 – Ground : Continuity should exist.**

OK or NG

- OK >> Check connector for connection, bend and loose fit and repair.
- NG >> Repair harness or connector.



# FRONT FOG LAMP


## Aiming Adjustment

NKS001PO


The front fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.


Adjust aiming in the vertical direction by turning the adjusting screw.



1. Set the distance between the screen and the center of the front fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is in the hatched area as shown in the figure.
  - When performing this adjustment, cover the headlamps and the opposite front fog lamp, if necessary.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP

## Bulb Replacement

NKS001PP


1. Remove fender protector front. Refer to [EI-21, "FENDER PRO-TECTOR"](#) .
2. Remove the one side of front bumper where a front fog lamp bulb to be changed.
3. Disconnect connector.
4. Turn bulb socket counterclockwise and unlock it.

**Front fog lamp** :12 V - 51 W (HB4 halogen)

5. Installation is the reverse order of removal.

### CAUTION:

- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Never leave bulb out of front fog lamp reflector for a long time because dust, moisture smoke, etc. May affect the performance of front fog lamp. When replacing bulb, be sure to replace it with new one.




## Removal and Installation

### REMOVAL

NKS001PQ

1. Remove fender protector front. Refer to [EI-21, "FENDER PRO-TECTOR"](#) .
2. Remove the one side of front bumper where a front fog lamp needs to be changed. Refer to [EI-14, "FRONT BUMPER"](#) .
3. Remove bumper finisher. Refer to [EI-14, "FRONT BUMPER"](#) .
4. Remove front fog lamp mounting bolt.
5. Pull out front fog lamp from vehicle and disconnect connector.



### INSTALLATION

Installation is the reverse order of removal.

**Front fog lamp mounting bolt**  : 5.5 N·m (0.56 kg·m, 49 in·lb)


# TURN SIGNAL AND HAZARD WARNING LAMPS

## TURN SIGNAL AND HAZARD WARNING LAMPS

PF26120

### Component Parts and Harness Connector Location

NKS001PR



PKIC6811E

### System Description OUTLINE

NKS001PS

Power is supplied at all times

- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM (body control module) terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 9,
- through 10A fuse [No. 21, located in fuse block (J/B)]
- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 12, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 16,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 20.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M14 and M78,
- to rear combination lamp control unit terminals 12
- through grounds B7 and B20,
- to combination meter terminals 22, 23 and 24
- through grounds M14 and M78.

## TURN SIGNAL OPERATION

### LH Turn Signal Lamp

When the turn signal switch (combination switch) is in left position with the ignition switch in ON position, BCM detects the TURN LH (ON) by combination switch reading function. BCM outputs the turn signal (LH) intermittently, and BCM also sends the turn indicator signal (LH) intermittently through CAN communication. BCM supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 2, and
- to rear combination lamp control unit terminal 3.

When receiving the turn signal (LH), rear combination lamp control unit detects the turn signal (LH) ON, then rear combination lamp control unit outputs the rear combination lamp drive signal LH intermittently (turn signal output). Rear combination lamp control unit supplies power

- through rear combination lamp control unit terminal 5
- to rear combination lamp LH terminal 1.

Ground is supplied

- to front combination lamp LH terminal 8
- through grounds E13, E26 and E28,
- to rear combination lamp LH terminal 4
- through rear combination lamp control unit terminal 13.

Unified meter and A/C amp. receives the turn indicator signal (LH) through CAN communication, then makes turn signal indicator (LH) start flashing operation interlocked with the buzzer sounds in combination meter.

With power and ground supplied, BCM controls the flashing of the LH turn signal lamps.

### RH Turn Signal Lamp

When the turn signal switch (combination switch) is in right position with the ignition switch in ON position, BCM detects the TURN RH (ON) by combination switch reading function. BCM outputs the turn signal (RH) intermittently, and BCM also sends the turn indicator signal (RH) intermittently through CAN communication. BCM supplies power

- through BCM terminal 46
- to front combination lamp RH terminal 2, and
- to rear combination lamp control unit terminal 4.

When receiving the turn signal (RH), rear combination lamp control unit detects the turn signal (RH) ON, then rear combination lamp control unit outputs the rear combination lamp drive signal RH intermittently (turn signal output). Rear combination lamp control unit supplies power

- through rear combination lamp control unit terminal 7
- to rear combination lamp RH terminal 1.

Ground is supplied

- to front combination lamp RH terminal 8
- through grounds E13, E26 and E28,
- to rear combination lamp RH terminal 4
- through rear combination lamp control unit terminal 14.

Unified meter and A/C amp. receives the turn indicator signal (RH) through CAN communication, then makes turn signal indicator (RH) start flashing operation interlocked with the buzzer sounds in combination meter.

With power and ground supplied, BCM controls the flashing of the RH turn signal lamps.

# TURN SIGNAL AND HAZARD WARNING LAMPS

## LED Cut Detect Function

LED circuit has 9 rows of parallel circuits with 3 LEDs\* to 1 row and diagnosis circuit built in rear combination lamp. Diagnosis circuit detects the state of rear combination lamp circuits and transmits the LED cut detect signal to rear combination lamp control unit. Rear combination lamp control unit monitors the rear combination lamp circuits via the LED cut detect signal during turn signal LH/RH operation. Then rear combination lamp control unit judges the normality of rear combination lamp circuits and transmits the warning output signal (OK/NG) to unified meter and A/C amp. Unified meter and A/C amp. transmits the LED burnout status signal (OK/NG) to BCM through CAN communication depending on the warning output signal.

If BCM receives the LED burnout status signal (NG), BCM controls the high speed flashing during turn signal LH/RH operation.

\*: One of 9 circuits looks to have only 2 LEDs.

Operation	LED circuit malfunction	Warning output signal/ LED burnout signal	Flashing
Left/right turn signal lamp	1 row or less	OK	Normal speed
	2 rows or more	NG	High speed
Hazard lamp	1 row or less (both sides)	OK	Normal speed
	2 rows or more (one side or both sides)	NG	Normal speed
No operation	—	NG	—

## HAZARD LAMP OPERATION

When the hazard switch is in ON position, combination meter detects hazard switch ON. Then combination meter supplies ground

- to BCM terminal 29
- through combination meter terminal 9

When receiving the hazard switch signal, BCM detects the hazard switch signal ON. BCM outputs the turn signal (LH and RH) intermittently, and BCM also sends the turn indicator signal (LH and RH) intermittently through CAN communication. BCM supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 2
- to rear combination lamp control unit terminal 3,
- through BCM terminal 46
- to front combination lamp RH terminal 2
- to rear combination lamp control unit terminal 4.

When receiving the turn signal (LH and RH), rear combination lamp control unit detects the turn signal (LH and RH) ON, then rear combination lamp control unit outputs the rear combination power lamp drive signal LH and RH intermittently (hazard output). Rear combination lamp control unit supplies power

- through rear combination lamp control unit terminal 5
- to rear combination lamp LH terminal 1,
- through rear combination lamp control unit terminal 7
- to rear combination lamp RH terminal 1.

Ground is supplied

- to front combination lamp RH and LH terminals 8
- through grounds E13, E26 and E28,
- to rear combination lamp LH terminal 4
- through rear combination lamp control unit terminal 13,
- to rear combination lamp RH terminal 4
- through rear combination lamp control unit terminal 14.

Unified meter and A/C amp. receives the turn indicator signal (LH and RH) through CAN communication, then makes turn signal indicator (LH and RH) start flashing operation interlocked with the buzzer sounds in combination meter.

With power and ground supplied, BCM controls the flashing of the hazard lamps.

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

## **INTERLOCKED HAZARD LAMP OPERATION WITH REMOTE KEYLESS ENTRY SYSTEM**

BCM receives the keyfob signal (door lock/unlock signal) from remote keyless entry receiver, then BCM controls hazard lamps.

Refer to [BL-57, "REMOTE KEYLESS ENTRY SYSTEM"](#) .

## **INTERLOCKED HAZARD LAMP OPERATION WITH INTELLIGENT KEY SYSTEM**

BCM receives the door lock/unlock signal from Intelligent Key unit through CAN communication, then BCM controls hazard lamps.

Refer to [BL-87, "INTELLIGENT KEY SYSTEM"](#) .

## **COMBINATION SWITCH READING FUNCTION**

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## **CAN Communication System Description**

*NKS001PT*

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## **CAN Communication Unit**

*NKS001PU*


Refer to [LAN-49, "CAN System Specification Chart"](#) .



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Schematic

NKS001PV



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

TKWB2567E





# TURN SIGNAL AND HAZARD WARNING LAMPS

NKS001PW

## Wiring Diagram — TURN —

**LT-TURN-01**

▬ : DATA LINE



REFER TO THE FOLLOWING.


(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(M34), (M35) - ELECTRICAL UNITS

TKWB2568E


# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT





REFER TO THE FOLLOWING.  
 (M1), (E101) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M35) - ELECTRICAL UNITS

TKWB2569E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03

▬ : DATA LINE



REFER TO THE FOLLOWING.  
 (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWB2570E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Terminals and Reference Value for BCM



NKS001PX

**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152. "DATA MONITOR"](#).


Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
2	R	Combination switch input 5	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					Turn signal switch to right	<p style="text-align: right; font-size: small;">PKIB4959J</p>
3	P/L	Combination switch input 4	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					Turn signal switch to left	<p style="text-align: right; font-size: small;">PKIB4959J</p>
11	P/B	Ignition switch (ACC)	ACC	—	Battery voltage	
29	G/R	Hazard switch signal	OFF	Hazard switch	ON	Approx. 0 V
					OFF	Battery voltage
36	L/W	Combination switch output 1	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	<p style="text-align: right; font-size: small;">PKIB4960J</p>
					Any of the conditions below	<ul style="list-style-type: none"> <li>● Turn signal switch to right</li> <li>● Turn signal switch to left</li> </ul> <p style="text-align: right; font-size: small;">PKIB4958J</p>
38	R	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN - H	—	—	—	
40	Y	CAN - L	—	—	—	

# TURN SIGNAL AND HAZARD WARNING LAMPS




Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
42	GR	Battery power supply	OFF	—	Battery voltage
45	G/B	Turn signal (left)	ON	Combination switch Turn left ON	 <p style="text-align: right; font-size: small;">PKIC6370E</p> <p style="text-align: center;">Approx. 6.0 V</p>
46	G/Y	Turn signal (right)	ON	Combination switch Turn right ON	 <p style="text-align: right; font-size: small;">PKIC6370E</p> <p style="text-align: center;">Approx. 6.0 V</p>
52	B	Ground	ON	—	Approx. 0 V
55	W/B	Battery power supply	OFF	—	Battery voltage

## Terminals and Reference Value for Rear Combination Lamp Control Unit

NKS002SV

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
1	R/L	Tail lamp signal	—	Lighting switch OFF	Approx. 0 V
				Lighting switch 1ST	Battery voltage
2	R/G	Stop lamp signal	—	Brake pedal released (stop lamp switch OFF)	Approx. 0 V
				Brake pedal depressed (stop lamp switch ON)	Battery voltage
3	G/B	Turn signal lamp LH signal	ON	Turn signal switch OFF, hazard switch OFF	Approx. 0 V
			ON	Turn signal switch LH	 <p style="text-align: right; font-size: small;">PKIC6370E</p> <p style="text-align: center;">Approx. 6.0 V</p>
			—	Hazard switch ON	





# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
4	G/Y	Turn signal lamp RH signal	ON	Turn signal switch OFF, hazard switch OFF	Approx. 0 V	
			ON	Turn signal switch RH	 <p style="text-align: right;">PKIC6370E</p>	
			—	Hazard switch ON		Approx. 6.0 V
5	Y	Rear combination lamp drive signal (LH)	—	Lighting switch OFF, brake pedal released (stop lamp switch OFF), turn signal switch OFF, hazard switch OFF	Approx. 0 V	
			—	Lighting switch 1ST	 <p style="text-align: right;">PKIC6371E</p>	Approx. 3.0 V
			—	Brake pedal depressed (stop lamp switch ON)	Battery voltage	
			ON	Turn signal switch LH	 <p style="text-align: right;">PKIC6370E</p>	
			—	Hazard switch ON		Approx. 6.0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M




LT

# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
6	B/Y	LED cut detect signal (LH)	—	Lighting switch OFF, brake pedal released (stop lamp switch OFF), turn signal switch OFF, hazard switch OFF	Approx. 5 V
				Lighting switch 1ST	 <p style="text-align: right; font-size: small;">PKIC6372E</p>
			ON	Turn signal switch RH	Approx. 3.6 V
			—	Hazard switch ON	 <p style="text-align: right; font-size: small;">PKIC6373E</p>
7	W	Rear combination lamp drive signal (RH)	—	Lighting switch OFF, brake pedal released (stop lamp switch OFF), turn signal switch OFF, hazard switch OFF	Approx. 0 V
				Lighting switch 1ST	 <p style="text-align: right; font-size: small;">PKIC6371E</p>
			ON	Turn signal switch RH	Battery voltage
			—	Hazard switch ON	 <p style="text-align: right; font-size: small;">PKIC6370E</p>



# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
8	B/R	LED cut detect signal (RH)	—	Lighting switch OFF, brake pedal released (stop lamp switch OFF), turn signal switch OFF, hazard switch OFF	Approx. 5 V
				Lighting switch 1ST	 PKIC6372E Approx. 3.2 V
			ON	Turn signal switch RH	Approx. 3.6 V
			—	Hazard switch ON	 PKIC6373E Approx. 4.2 V
9	G/W	Battery power supply	OFF	—	Battery voltage
11	G/W	Warning output signal	ON	When turn signal lamp operates normally	 PKIC6374E Approx. 6.3 V
				Except when turn signal lamp operates normally	Approx. 12 V
12	B	Ground	ON	—	Approx. 0 V
13	BR	Rear combination lamp LH ground	ON	—	Approx. 0 V
14	B	Rear combination lamp LH ground	ON	—	Approx. 0 V
16	G	Ignition switch (ON)	ON	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
M

LT

## How to Proceed with Trouble Diagnosis

NKS001PY

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-117, "System Description"](#) .
3. Perform preliminary check. Refer to [LT-130, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Do turn signal and hazard warning lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

# TURN SIGNAL AND HAZARD WARNING LAMPS

NKS001PZ

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6

Refer to [LT-122, "Wiring Diagram — TURN —"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT


- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## CONSULT-II Functions (BCM)

NKS001Q0

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
FLASHER	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

#### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
HAZARD SW "ON/OFF"	Displays "Hazard ON (ON)/Hazard OFF (OFF)" status, determined from hazard switch signal.
TURN SIGNAL R "ON/OFF"	Displays "Turn right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn left (ON)/Other (OFF)" status, determined from lighting switch signal.
BRAKE SW <sup>NOTE</sup> "OFF"	—

#### NOTE:

This item is displayed, but cannot be monitored

### ACTIVE TEST

#### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

#### Display Item List

Test item	Description
FLASHER	With a certain operation (OFF, RH, LH), turn signal lamp can be operated.

# TURN SIGNAL AND HAZARD WARNING LAMPS

NKS001Q1

## Turn Signal Lamps Do Not Operate

### 1. ACTIVE TEST

④ With CONSULT-II

1. Select "FLASHER" during active test. Refer to [LT-131, "ACTIVE TEST"](#).
2. Make sure "FLASHER RIGHT" and "FLASHER LEFT" operates.

**Turn signal lamps should operate.**

⊗ Without CONSULT-II

GO TO 2.

OK or NG

OK >> GO TO 2.

NG >> GO TO 3.

ACTIVE TEST			
FLASHER	OFF		
RH	LH	OFF	
MODE	BACK	LIGHT	COPY

PKIA5276E

### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "TURN SIGNAL R" and "TURN SIGNAL L" turns ON-OFF linked with operation of turn signal switch.

**When turn signal switch is : TURN SIGNAL R ON  
RH position**

**When turn signal switch is : TURN SIGNAL L ON  
LH position**

⊗ Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#).

OK or NG

OK >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
TURN SIGNAL R	ON		
TURN SIGNAL L	ON		
RECORD			
MODE	BACK	LIGHT	COPY


PKIA7600E

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 3. CHECK TURN SIGNAL CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector, front combination lamp RH and LH connectors, and rear combination lamp control unit connector.
3. Check continuity between BCM harness connector (A) and front combination lamp harness connector (B).

A		B			Continuity
Connector	Terminal	Connector	Terminal		
RH	M35	46	RH	E30	Yes
LH		45	LH	E17	




4. Check continuity between BCM harness connector (A) and rear combination lamp control unit harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
RH	M35	B42	4	Yes
LH			3	



5. Check continuity (short circuit) between BCM harness connector and ground.

BCM connector		Terminal	Ground	Continuity
RH	M35	46		No
LH		45		



### OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# TURN SIGNAL AND HAZARD WARNING LAMPS

## 4. CHECK TURN SIGNAL OUTPUT VOLTAGE

④ With CONSULT-II

1. Connect BCM connector, front combination lamp RH and LH connectors, and rear combination lamp control unit connector.
2. Select "FLASHER" during active test. Refer to [LT-131, "ACTIVE TEST"](#) .
3. When turn signal lamp is operating, check voltage between BCM harness connector and ground.

(+)		Terminal	(-)	Voltage
BCM connector				
RH	M35	46	Ground	Battery voltage
LH		45		




⊗ Without CONSULT-II

1. Connect BCM connector, front combination lamp RH and LH connector, and rear combination lamp control unit connector.
2. Turn signal switch is turned RH or LH position.
3. When turn signal lamp is operating, check voltage between BCM harness connector and ground.

(+)		Terminal	(-)	Voltage
BCM connector				
RH	M35	46	Ground	
LH		45		

PKIC6370E



### OK or NG

- OK >> Check connector connection bend and loose fit.  
 NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Turn Signal Lamps Go ON, But Flash at High Speed (Both Sides)

NKS002SX


### NOTE:

Check if LED circuit is normally. Refer to [LT-119, "LED Cut Detect Function"](#) .

### 1. CHECK WARNING OUTPUT SIGNAL

Select "METER A/C AMP" on CONSULT-II. With data monitor to make sure "RR COMB STATE" turns OK-NG linked with operation of turn signal switch.

**When turn signal switch is : RR COMB STATE OK  
RH or LH position**



### OK or NG

OK >> Check CAN communication. Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .

NG >> GO TO 2.


### 2. CHECK WARNING OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear combination lamp control unit connector and unified meter and A/C amp. connector.
3. Check continuity rear combination lampcontrol unit harness connector (A) B42 terminal 11 and unified meter and A/C amp. harness connector (B) M49 terminal 16.

**11 – 16 : Continuity should exist.**

4. Check continuity (short circuit) between rear combination lamp control unit harness connector (A) B42 terminal 11 and ground.

**11 – Ground : Continuity should not exist.**



### OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## 3. CHECK WARNING OUTPUT SIGNAL

1. Connect rear combination lamp control unit connector and unified meter and A/C amp. connector.
2. Hazard switch is ON.
3. Check voltage between rear combination lamp control unit harness connector B42 terminal 11 and ground.

**11 – Ground**

:



OK or NG


- OK >> Replace unified meter and A/C amp.. Refer to [DI-36, "Removal and Installation of Unified Meter and A/C Amp."](#)
- NG >> ● If voltage is approx. 0 V, GO TO 4.  
● If voltage is approx. 12 V, replace rear combination lamp control unit.

## 4. CHECK UNIFIED METER AND A/C AMP. WARNIG OUTPUT SIGNAL POWER SUPPLY

1. Discnnect rear combination lamp control unit connector.
2. Check voltage between rear combination lamp control unit harness connector B42 terminal 11 and ground.

**11 – Ground**

: **Battery voltage.**



OK or NG

- OK >> Replace rear combination lamp control unit. Refer to [LT-184, "REAR COMBINATION LAMP CONTROL UNIT"](#).
- NG >> Replace unified meter and A/C amp.. Refer to [DI-36, "Removal and Installation of Unified Meter and A/C Amp."](#)



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Turn Signal Lamps Go ON, But Flash at High Speed (One Side)

NKS002SZ

### NOTE:

Check if LED circuit is normally. Refer to [LT-119, "LED Cut Detect Function"](#) .

### 1. CHECK WARNING OUTPUT SIGNAL

Select "METER A/C AMP" on CONSULT-II. With data monitor to make sure "RR COMB STATE" turns OK-NG linked with operation of turn signal switch.

**When turn signal switch is : RR COMB STATE OK  
RH or LH position**

DATA MONITOR			
MONITOR			
RR COMB STATE	OK		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIC6968E

### OK or NG

- OK >> GO TO 2.
- NG >> GO TO 4.

### 2. CHECK FRONT TURN SIGNAL LAMP BULB

Check front turn signal lamp bulb standard of front turn signal lamp RH or LH is correct.

### OK or NG

- OK >> GO TO 3.
- NG >> Replace turn signal lamp bulb.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LT

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 3. CHECK TURN SIGNAL CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector, front combination lamp RH or LH connectors, and rear combination lamp control unit connector.
3. Check continuity between BCM harness connector (A) and front combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
RH	M35	46	RH E30	Yes
LH		45	LH E17	



4. Check continuity between BCM harness connector (A) and rear combination lamp control unit harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
RH	M35	B42	4	Yes
LH			3	



### OK or NG

- OK >> Check connector connection bend and loose fit.  
 NG >> Repair harness or connector.


## 4. CHECK LED CUT DETECT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear combination lamp control unit connector and rear combination lamp RH or LH connectors.
3. Check continuity rear combination lamp control unit harness connector (A) and rear combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B42	8	RH	B29	Yes
	6	LH	B24	

4. Check continuity (short circuit) between rear combination lamp control unit (A) harness connector and ground.

A		Ground	Continuity
Connector	Terminal		
RH	B42	8	No
LH		6	




### OK or NG


- OK >> GO TO 5.  
 NG >> Repair harness or connector.

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 5. CHECK LED CUT DETECT SIGNAL

1. Turn ignition switch OFF.
2. Connect rear combination lamp control unit connector and rear combination lamp RH or LH connectors.
3. Hazard switch is ON.
4. Check voltage between rear combination lamp control unit harness connector and ground.

(+)		Terminal	(-)	Voltage
Rear combination lamp control unit connector				
B42	RH	8	Ground	 (V) 6 4 2 0 1s PKIC6373E
	LH	6		




OK or NG

- OK >> Replace rear combination lamp control unit. Refer to [LT-184, "REAR COMBINATION LAMP CONTROL UNIT"](#).
- NG >> GO TO 6.

## 6. CHECK REAR COMBINATION LAMP CONTROL UNIT LED CUT DETECT SIGNAL POWER SUPPLY

1. Disconnect rear combination lamp connector.
2. Turn ignition switch ON.
3. Check voltage between rear combination lamp control unit harness connector and ground.

(+)		Terminal	(-)	Voltage
Rear combination lamp control unit connector				
RH	B42	8	Ground	Approx. 5 V
LH		6		



OK or NG

- OK >> Replace rear combination lamp. Refer to [LT-184, "REAR COMBINATION LAMP"](#).
- NG >> Replace rear combination lamp control unit. Refer to [LT-184, "REAR COMBINATION LAMP CONTROL UNIT"](#).

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Hazard Warning Lamps Do Not Operate But Turn Signal Lamps Operate

NKS001Q2


### 1. CHECK HAZARD SWITCH INPUT SIGNAL

① With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor to make sure "HAZARD SW" turns ON-OFF linked with operation of hazard switch.

**When hazard switch is ON : HAZARD SW ON position**

② Without CONSULT-II  
GO TO 2.



OK or NG

OK >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .  
NG >> GO TO 2.


### 2. CHECK HAZARD SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and combination meter connector.
3. Check continuity BCM harness connector M34 terminal 29 and combination meter harness connector M25 terminal 9.

**29 – 9 : Continuity should exist.**

4. Check continuity (short circuit) BCM harness connector M34 terminal 29 and ground.

**29 – Ground : Continuity should not exist.**



OK or NG


OK >> GO TO 3.  
NG >> Repair harness or connector.

# TURN SIGNAL AND HAZARD WARNING LAMPS

## 3. CHECK HAZARD SWITCH INPUT SIGNAL

1. Connect BCM connector and combination meter connector.
2. Check voltage between BCM harness connector M34 terminal 29 and ground.

(+)		(-)	Condition	Voltage
BCM connector	Terminal			
M34	29	Ground	Hazard switch is ON	Approx. 0 V
			Hazard switch is OFF	Approx. 12 V




### OK or NG

- OK >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .
- NG >> ● If voltage is approx. 0 V , replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .
- If voltage is approx. 12 V , GO TO 4.

## 4. CHECK HAZARD SWITCH

1. Turn ignition switch OFF.
2. Remove hazard switch. Refer to [LT-145, "Removal and Installation"](#) .
3. Check continuity hazard switch terminals.

Terminal		Condition	Continuity
Hazard switch			
1	2	Hazard switch is ON	Yes
		Hazard switch is OFF	No




### OK or NG

- OK >> GO TO 5.
- NG >> Replace hazard switch. Refer to [LT-145, "Removal and Installation"](#) .

## 5. CHECK HAZARD SWITCH CIRCUIT

1. Disconnect combination meter connector and hazard switch connector.
2. Check continuity between hazard switch harness connector and combination meter harness connector.

Hazard switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
M304	1	M302	36	Yes
	2		33	



### OK or NG

- OK >> Replace combination meter. Refer to [DI-24, "Removal and Installation of Combination Meter"](#) .
- NG >> Repair harness or connector.

# TURN SIGNAL AND HAZARD WARNING LAMPS


## Any Function of Rear Combination Lamps Does Not Work (Both sides)

NKS002SW

### 1. CHECK REAR COMBINATION LAMP CONTROL UNIT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between rear combination lamp control unit harness connector B42 terminal 9 and ground.

**9 – Ground** : **Battery voltage.**




OK or NG

- OK >> GO TO 2.  
NG >> Repair harness or connector.

### 2. CHECK REAR COMBINATION LAMP CONTROL UNIT GROUND CIRCUIT

1. Disconnect rear combination lamp control unit connector.
2. Check continuity rear combination lamp control unit harness connector B42 terminal 12 and ground.

**12 – Ground** : **Continuity should exist.**



OK or NG

- OK >> Replace rear combination lamp control unit. Refer to [LT-184, "REAR COMBINATION LAMP CONTROL UNIT"](#) .  
NG >> Repair harness or connector.

# TURN SIGNAL AND HAZARD WARNING LAMPS


## Any Function of Rear Combination Lamps Does Not Work (One side)

NKS002SY

### 1. CHECK REAR COMBINATION LAMP DRIVE SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear combination lamp control unit connector and rear combination lamp RH or LH connectors.
3. Check continuity rear combination lamp control unit harness connector (A) and rear combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B42	7	RH	B29	Yes
	5	LH	B24	



4. Check continuity (short circuit) between rear combination lamp control unit harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
RH	B42	7	No
LH		5	


OK or NG

- OK >> GO TO 2.
- NG >> Repair harness or connector.

### 2. CHECK REAR COMBINATION LAMP CONTROL UNIT GROUND CIRCUIT

Check continuity between rear combination lamp control unit harness connector and ground.

Rear combination lamp control unit connector		Terminal	Ground	Continuity
RH	B42	14		
LH		13		



OK or NG

- OK >> Replace rear combination lamp control unit. Refer to [LT-184, "REAR COMBINATION LAMP CONTROL UNIT"](#).
- NG >> Repair harness or connector.

### Bulb Replacement FRONT TURN SIGNAL LAMP

NKS001Q4

- Refer to [LT-34, "Bulb Replacement"](#) (xenon type headlamp).
- Refer to [LT-63, "Bulb Replacement"](#) (conventional type headlamp).

### REAR TURN SIGNAL LAMP

- Refer to [LT-184, "Bulb Replacement"](#).

### Removal and Installation FRONT TURN SIGNAL LAMP

NKS001Q6

- Refer to [LT-35, "Removal and Installation"](#) (xenon type headlamp).
- Refer to [LT-64, "Removal and Installation"](#) (conventional type headlamp).

### REAR TURN SIGNAL LAMP

- Refer to [LT-184, "Removal and Installation"](#).

# LIGHTING AND TURN SIGNAL SWITCH

## LIGHTING AND TURN SIGNAL SWITCH


PFP:25540

### Removal and Installation

NKS00108

#### REMOVAL

1. Remove instrument driver lower panel and steering column cover. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. While pressing pawls in direction as shown in the figure, pull lighting and turn signal switch toward driver door and disconnect from the base.



#### INSTALLATION

Installation is the reverse order of removal.



# HAZARD SWITCH

## HAZARD SWITCH


PFP:25290

### Removal and Installation

NKS001Q9

#### REMOVAL

1. Remove meter lid. Refer to [DI-24, "Disassembly and Assembly of Combination Meter"](#) .
2. Disconnect hazard switch connector.
3. Press pawl on reverse side and remove the hazard switch.



#### INSTALLATION

Installation is the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# COMBINATION SWITCH

PFP:25567





## COMBINATION SWITCH

### Wiring Diagram — COMBSW —

NKS001QA

## LT-COMBSW-01

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(M34), (M35) - ELECTRICAL UNITS

TKWB2571E

# COMBINATION SWITCH

## Combination Switch Reading Function

NKS001QB

For details, refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## Terminals and Reference Values for BCM

NKS002TT

### CAUTION:






- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-152, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	R	Combination switch input 5	ON	OFF	Approx. 0 V
				Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 1ST</li> <li>● Lighting switch HIGH beam (Operates only HIGH beam switch)</li> <li>● Turn signal switch to right</li> </ul>	<p>PKIB4959J</p>
3	P/L	Combination switch input 4	ON	Lighting switch 2ND	<p>PKIB4953J</p>
				Front fog lamp switch (Operates only front fog lamp switch)	<p>PKIB4955J</p>
3	P/L	Combination switch input 4	ON	Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> <li>● Turn signal switch to left</li> </ul>	<p>PKIB4959J</p>

# COMBINATION SWITCH





Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
4	R/G	Combination switch input 3	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	Approx. 0 V
					<ul style="list-style-type: none"> <li>● Lighting switch AUTO</li> <li>● Front wiper switch MIST</li> <li>● Front wiper switch INT</li> <li>● Front wiper switch LO</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4959J</p>
5	R/B	Combination switch input 2	ON	Lighting, turn, wiper switch	OFF	Approx. 0 V
					<ul style="list-style-type: none"> <li>● Front washer switch (Wiper intermittent dial position 4)</li> <li>● Rear washer switch (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 5</li> <li>● Wiper intermittent dial position 6</li> </ul>	<p style="text-align: right; font-size: small;">PKIB4959J</p>
					Rear wiper switch ON (Wiper intermittent dial position 4)	<p style="text-align: right; font-size: small;">PKIB4955J</p>

# COMBINATION SWITCH





Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
6	R/W	Combination switch input 1	ON	Lighting, turn, wiper switch	OFF  Any of the conditions below <ul style="list-style-type: none"> <li>● Front wiper switch HI (Wiper intermittent dial position 4)</li> <li>● Rear wiper switch INT (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 3</li> </ul>	Approx. 0 V   PKIB4959J Approx. 1.0 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> </ul>	 PKIB4952J Approx. 1.7 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Wiper intermittent dial position 6</li> <li>● Wiper intermittent dial position 7</li> </ul>	 PKIB4955J Approx. 0.8 V
11	P/B	Ignition switch (ACC)	ACC	—	Battery voltage	
32	LG/B	Combination switch output 5	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)	 PKIB4960J Approx. 7.2 V
					Any of the conditions below <ul style="list-style-type: none"> <li>● Front fog lamp switch (Operates only front fog lamp switch) (Wiper intermittent dial position 4)</li> <li>● Rear wiper switch ON (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> <li>● Wiper intermittent dial position 6</li> <li>● Wiper intermittent dial position 7</li> </ul>	 PKIB4956J Approx. 1.0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
33	G/Y	Combination switch output 4	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch AUTO (Wiper intermittent dial position 4)</li> <li>● Lighting switch 1ST (The same result with lighting switch 2ND) (Wiper intermittent dial position 4)</li> <li>● Rear wiper switch INT (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 5</li> <li>● Wiper intermittent dial position 6</li> </ul>  <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
34	LG/R	Combination switch output 3	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
					Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND (Wiper intermittent dial position 4)</li> <li>● Lighting switch HI beam (Operates only HI beam switch) (Wiper intermittent dial position 4)</li> <li>● Rear washer switch (Wiper intermittent dial position 4)</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> <li>● Wiper intermittent dial position 3</li> </ul>  <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>

# COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
35	G/B	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<p>OFF</p>  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
				Any of the conditions below	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
36	L/W	Combination switch output 1	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<p>OFF</p>  <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">Approx. 7.2 V</p>
				Any of the conditions below	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">Approx. 1.2 V</p>
38	R	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	Y	CAN - L	—	—	—
42	GR	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/B	Battery power supply	OFF	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# COMBINATION SWITCH

## CONSULT-II Functions (BCM)

NKS001QC

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
COMB SW	DATA MONITOR	Displays BCM input data in real time.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#) .

### DATA MONITOR

#### Operation Procedure

1. Touch "COMB SW" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitors them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the signals will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

#### Display Item List

Monitor item	Contents
TURN SIGNAL R "ON/OFF"	Displays "Turn Right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn Left (ON)/Other (OFF)" status, determined from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 1 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1ST or 2ND position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays "Auto light switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR FOG SW "ON/OFF"	Displays "Front fog lamp switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR WIPER HI "ON/OFF"	Displays "Front Wiper HI (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER LOW "ON/OFF"	Displays "Front Wiper LOW (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER INT "ON/OFF"	Displays "Front Wiper INT (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WASHER SW "ON/OFF"	Displays "Front Washer Switch (ON)/Other (OFF)" status, determined from wiper switch signal.
INT VOLUME "1 - 7"	Displays intermittent operation knob setting (1 - 7), determined from wiper switch signal.
RR WIPER ON "ON/OFF"	Displays "rear Wiper (ON)/Other (OFF)" status as judged from wiper switch signal.
RR WIPER INT "ON/OFF"	Displays "rear Wiper INT (ON)/Other (OFF)" status as judged from wiper switch signal.
RR WASHER SW "ON/OFF"	Displays "rear Washer Switch (ON)/Other (OFF)" status as judged from wiper switch signal.



# COMBINATION SWITCH

## Combination Switch Inspection

NKS002TU

### 1. SYSTEM CHECK

Referring to table below, check which system malfunctioning switch belongs to.

System 1	System 2	System 3	System 4	System 5
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
INT VOLUME 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	LIGHT SW 1ST
INT VOLUME 2	RR WIPER ON	—	FR FOG	—

>> Check the system to which malfunctioning switch belongs, and GO TO 2.

### 2. SYSTEM CHECK

 With CONSULT-II

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Connect CONSULT-II, and select "COMB SW" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR".
3. Select "START", and confirm that other switches in malfunctioning system operate normally.

Example: When the auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in system 3, to which the auto light switch belongs, turn ON-OFF normally.

DATA MONITOR			
MONITOR			
TURN SIGNAL R		OFF	
TURN SIGNAL L		OFF	
HIBEAM SW		OFF	
HEAD LAMP SW1		OFF	
HEAD LAMP SW2		OFF	
LIGHT SW 1ST		OFF	
PASSING SW		OFF	
AUTO LIGHT SW		OFF	
FR FOG SW		OFF	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7602E

 Without CONSULT-II

Operating combination switch, and confirm that other switches in malfunctioning system operate normally.  
Example: When the auto light switch is malfunctioning, confirm that FRONT WIPER LOW and FRONT WIPER INT in system 3, to which the auto light switch belongs, operate normally.

#### Check results

Other switches in malfunctioning system operate normally.>>Replace lighting switch or wiper switch.


Other switches in malfunctioning system do not operate normally.>>GO TO 3.

# COMBINATION SWITCH

## 3. CHECK HARNESS


1. Turn ignition switch OFF.
2. Disconnect BCM connector and combination switch connector.
3. Check for continuity between BCM harness connector of the suspect system and the corresponding combination switch harness connector.

Suspect system	BCM		Combination switch		Continuity	
	Connector	Terminal	Connector	Terminal		
1	M1	Input 1	6	M29	6	Yes
		Output 1	36		1	
2		Input 2	5		7	
		Output 2	35		2	
3		Input 3	4		10	
		Output 3	34		3	
4		Input 4	3		9	
		Output 4	33		4	
5		Input 5	2		8	
		Output 5	32		5	



4. Check for continuity between BCM harness connector in suspect malfunctioning system and ground.

Suspect system	BCM connector	Terminal	Continuity		
1	M1	Input 1	6	Ground	No
		Output 1	36		
2		Input 2	5		
		Output 2	35		
3		Input 3	4		
		Output 3	34		
4		Input 4	3		
		Output 4	33		
5		Input 5	2		
		Output 5	32		



OK or NG


OK >> GO TO 4.

NG >> Check harness between BCM and combination switch for open or short circuit.

# COMBINATION SWITCH

## 4. CHECK BCM OUTPUT TERMINAL

1. Turn lighting switch and wiper switch OFF position.
2. Set wiper dial position 4.
3. Connect BCM connector and combination switch connector.
4. Turn ignition switch ON.
5. Check BCM output terminal voltage waveform of suspect malfunctioning system.



Suspect system	(+)		(-)	Reference value
	Combination switch connector	Terminal		
1	M29	1	Ground	
2		2		
3		3		
4		4		
5		5		

OK or NG

OK >> Open circuit in combination switch, GO TO 5.

NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

## 5. CHECK COMBINATION SWITCH

Referring to table below, perform combination switch inspection.

Procedure												
1	2		3		4		5		6		7	
Replace lighting switch	Confirm check results	OK	INSPECTION END		Confirm check results	OK	INSPECTION END		Confirm check results	OK	INSPECTION END	
		NG	Replace wiper switch			NG	Replace switch base			NG	Confirm symptom again	

>> INSPECTION END

## Removal and Installation

For details, refer to [LT-144, "LIGHTING AND TURN SIGNAL SWITCH"](#) .


# STOP LAMP

PFP:26550

## STOP LAMP

### Component Parts and Harness Connector Location

NKS002T0



## System Description

### OUTLINE

NKS002T2

Power is supplied at all times

- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 9 and
- to stop lamp switch terminal 3,
- through 10A fuse [No. 21, located in fuse block (J/B)]
- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 12, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 16,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 20.

Ground is supplied

- to rear combination lamp control unit terminals 12
- through grounds B7 and B20,
- to combination meter terminals 22, 23 and 24
- through grounds M14 and M78.

## STOP LAMP OPERATION

When the stop lamp switch is depressed supplies power

# STOP LAMP

- through stop lamp switch terminal 3
- to rear combination lamp control unit terminal 2
- to high-mounted stop lamp terminal 1 and
- to unified meter and A/C amp..

When receiving the stop lamp signal, rear combination lamp control unit detects the stop lamp ON, then rear combination lamp control unit outputs the rear combination lamp drive signal RH and LH (stop lamp output). Rear combination lamp control unit supplies power

- through rear combination lamp control unit terminal 7
- to rear combination lamp RH terminal 1,
- through rear combination lamp control unit terminal 5
- to rear combination lamp LH terminal 1.

Ground is supplied

- to high-mounted stop lamp terminal 2
- through grounds B7 and B20,
- to rear combination lamp RH terminal 4
- through rear combination lamp control unit terminal 14,
- to rear combination lamp LH terminal 4
- through rear combination lamp control unit terminal 13.

With power and ground supplied, stop lamp and high-mounted stop lamp illuminate.

A

B

C

D

E

F

G

H

I

J

LT


L

M

# STOP LAMP

## Schematic

NKS002.Q7








TKWB2572E

# STOP LAMP

## Wiring Diagram — STOP/L —

NKS001QF

LT-STOP/L-01





REFER TO THE FOLLOWING.

(E101) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWB2573E

# STOP LAMP

LT-STOP/L-02







REFER TO THE FOLLOWING.  
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWB2574E



# STOP LAMP

LT-STOP/L-03



REFER TO THE FOLLOWING.

(M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)

(M34) - ELECTRICAL UNITS

TKWB2575E

# STOP LAMP

## Terminals and Reference Value for Rear Combination Lamp Control Unit

NKS002TP

Refer to [LT-126, "Terminals and Reference Value for Rear Combination Lamp Control Unit"](#) .

## How to Proceed with Trouble Diagnosis

NKS002TQ

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-156, "System Description"](#) .
3. Check symptom and repair or replace the cause of malfunction.
4. Do turn signal and hazard warning lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
5. INSPECTION END

## Stop Lamp of Rear Combination Lamp Does Not Operate But High-Mounted Stop Lamp Operate

NKS002TR

### 1. CHECK REAR COMBINATION LAMP OPERATION

Check if turn signal lamp and tail lamp operation is normally.

OK or NG

OK >> GO TO 2.


- NG >> ● Both sides do not operate: Refer to [LT-142, "Any Function of Rear Combination Lamps Does Not Work \(Both sides\)"](#) .
- One side does not operate: Refer to [LT-143, "Any Function of Rear Combination Lamps Does Not Work \(One side\)"](#) .

### 2. CHECK STOP LAMP SIGNAL

1. Turn ignition switch OFF.
2. Stop lamp switch is depressed.
3. Check voltage between rear combination lamp control unit harness connector B42 terminal 2 and ground.

**2 - Ground**

**: Battery voltage**



OK or NG

- OK >> Replace rear combination lamp control unit. Refer to [LT-184, "REAR COMBINATION LAMP CONTROL UNIT"](#) .
- NG >> Repair harness or connector between stop lamp switch and rear combination lamp control unit.

# STOP LAMP

## High-Mounted Stop Lamp

### BULB REPLACEMENT, REMOVAL AND INSTALLATION

NKS001QG


1. Remove cover high-mounted stop lamp on back door inner panel. Refer to [EI-39, "BACK DOOR TRIM"](#) .
2. Disconnect high-mounted stop lamp connector.
3. Remove washer tube from high-mounted stop lamp.
4. Remove nuts and remove high-mounted stop lamp from back door.

**High-mounted stop lamp : LED**

5. Installation is the reverse order of removal.
  - Install a new seal packing to the high-mounted stop lamp.

#### **CAUTION:**

**Seal packing cannot be reused.**



## Stop Lamp

### BULB REPLACEMENT

NKS001QH

Refer to [LT-184, "Bulb Replacement"](#) .

### REMOVAL AND INSTALLATION

Refer to [LT-184, "Removal and Installation"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# BACK-UP LAMP

PFP:26550






NKS001QK

## LT-BACK/L-01

▬ : DATA LINE

### BACK-UP LAMP

### Wiring Diagram — BACK/L —



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(F103) - ELECTRICAL UNITS

TKWM4962E


# BACK-UP LAMP

## Bulb Replacement

1. Remove back door finisher. Refer to [EI-39, "BACK DOOR TRIM"](#).
2. Disconnect the back-up lamp connector.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.

**Back-up lamp : 12V - 16W**


5. Installation is the reverse order of removal.



## Removal and Installation

### REMOVAL

1. Remove back door finisher. Refer to [EI-39, "BACK DOOR TRIM"](#).
2. Remove the back-up lamp mounting nuts and remove it.
3. Disconnect the back-up lamp connector.



### INSTALLATION

Installation is the reverse order of removal.

**Back-up lamp mounting nuts  : 5.5 N·m (0.56 kg-m, 49 in-lb)**


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## PARKING, LICENSE PLATE AND TAIL LAMPS

PF26550

### Component Parts and Harness Connector Location

NKS001QN



PKIC7602E

### System Description

NKS001QO

- BCM (Body Control Module) controls parking, license plate, side marker and tail lamps operation.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates parking, license plate and side marker lamps and sends tail lamp signal to rear combination lamp control unit, according to CAN communication signals from BCM.
- Rear combination lamp control unit operate tail lamp according to tail lamp signal from IPDM E/R.

### OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)

## PARKING, LICENSE PLATE AND TAIL LAMPS

- to tail lamp relay located in IPDM E/R and
- to CPU located in IPDM E/R,
- through 15A fuse (No. 78 located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 21, located in fuse block (J/B)]
- to combination meter terminal 21,
- through 10A fuse [No. 19, located in fuse block (J/B)]
- to unified meter and A/C amp. terminal 21,
- through 10A fuse [No. 20, located in fuse block (J/B)]
- to rear combination lamp control unit terminal 9.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 20,
- through 10A fuse [No. 12, located in fuse block (J/B)]
- to unified meter and A/C amp. terminal 22 and
- to rear combination lamp control unit terminal 16.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 52
- through grounds M14 and M78,
- to IPDM E/R terminals 38 and 60
- through grounds E13, E26 and E28.
- to combination meter terminals 22, 23 and 24, and
- to unified meter and A/C amp. terminals 29 and 30
- through grounds M14 and M78,
- to rear combination lamp control unit terminal 12
- through grounds B7 and B20.

### PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

When the lighting switch is in 1ST position, BCM detects the LIGHTING SWITCH 1ST POSITION (ON) by BCM combination switch reading function. BCM sends position light request signal (ON) through CAN communication.

When receiving position light request signal (ON), IPDM E/R turns ON tail lamp relay in IPDM E/R. IPDM E/R supplies power

- through IPDM E/R terminal 22
- to front combination lamp RH and LH terminals 7
- to license plate lamp RH and LH terminals 1
- to rear combination lamp RH and LH terminals 2 and
- to rear combination lamp control unit terminal 1.

When receiving the tail lamp signal, rear combination lamp control unit detects the tail lamp ON, then rear combination lamp control unit outputs the rear combination lamp drive signal RH and LH (tail lamp output). Rear combination lamp control unit supplies power

## PARKING, LICENSE PLATE AND TAIL LAMPS

---

- through rear combination lamp control unit terminal 7
- to rear combination lamp RH terminal 1,
- through rear combination lamp control unit terminal 5
- to rear combination lamp LH terminal 1.

Ground is supplied at all times

- to front combination lamp RH and LH terminals 5
- through grounds E13, E26 and E28,
- to rear combination lamp RH and LH terminals 2 and
- to license plate lamp RH and LH terminals 2
- through grounds B7 and B20,
- to rear combination lamp RH terminal 4
- through rear combination lamp control unit terminal 14,
- to rear combination lamp LH terminal 4
- through rear combination lamp control unit terminal 13.

With power and ground supplied, parking, license plate, side marker and tail lamps illuminate.

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

### EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST (or 2ND) position, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the parking, license plate, side marker and tail lamps remain illuminated for 5 minutes, and then the parking, license plate, side marker and tail lamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

### CAN Communication System Description

NKS001QP

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### CAN Communication Unit

NKS001QQ


Refer to [LAN-49, "CAN System Specification Chart"](#) .



# PARKING, LICENSE PLATE AND TAIL LAMPS

## Schematic

NKS001QR



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

TKWB2577E





# PARKING, LICENSE PLATE AND TAIL LAMPS

NKS001QS

## Wiring Diagram — TAIL/L —

### LT-TAIL/L-01

▬ : DATA LINE



REFER TO THE FOLLOWING.



(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(M34), (M35) - ELECTRICAL UNITS

TKWB2578E

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02






TKWB2579E



# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-04




REFER TO THE FOLLOWING.  
 (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWB2581E

# PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-05



TKWB2582E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for BCM

NKS001QT

### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-II. Refer to [LT-152. "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Measuring condition		Reference value
			Ignition switch	Operation or condition	
2	R	Combination switch input 5	ON	OFF	Approx. 0 V
				Lighting switch 1ST	<p>PKIB4959J</p>
11	P/B	Ignition switch (ACC)	ACC	—	Battery voltage
33	G/Y	Combination switch output 4	ON	OFF	<p>PKIB4960J</p>
				Lighting switch 1ST (The same result with lighting switch 2ND)	<p>PKIB4958J</p>
38	R	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN - H	—	—	—
40	Y	CAN - L	—	—	—
42	GR	Battery power supply	OFF	—	Battery voltage
52	B	Ground	ON	—	Approx. 0 V
55	W/B	Battery power supply	OFF	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for IPDM E/R

NKS001QU

Terminal No.	Wire color	Signal name	Measuring condition			Reference value
			Ignition switch	Operation or condition		
22	R/L	Parking, license plate, side marker and tail lamp	ON	Lighting switch 1ST position	OFF	Approx. 0 V
					ON	Battery voltage
38	B	Ground	ON	—	—	Approx. 0 V
48	L	CAN – H	—	—	—	—
49	Y	CAN – L	—	—	—	—
60	B	Ground	ON	—	—	Approx. 0 V

## Terminals and Reference Value for Rear Combination Lamp Control Unit

NKS002TV

Refer to [LT-126, "Terminals and Reference Value for Rear Combination Lamp Control Unit"](#).

## How to Proceed with Trouble Diagnosis

NKS001QV

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-166, "System Description"](#).
3. Perform the preliminary check. Refer to [LT-176, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Do the parking, license plate, side marker and tail lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

## Preliminary Check

NKS001QW

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START position	1
	Ignition switch ACC or ON position	6
IPDM E/R	Battery	71

Refer to [LT-170, "Wiring Diagram — TAIL/L —"](#).

#### OK or NG

OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).



# PARKING, LICENSE PLATE AND TAIL LAMPS

## 2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position		
BCM connector	Terminal		OFF	ACC	ON
M34	11	Ground	Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



## CONSULT-II Functions (BCM)

Refer to [LT-19, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP -XENON TYPE-.

Refer to [LT-49, "CONSULT-II Functions \(BCM\)"](#) in HEADLAMP -CONVENTIONAL TYPE-.

## CONSULT-II Functions (IPDM E/R)

Refer to [LT-21, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP -XENON TYPE-.

Refer to [LT-51, "CONSULT-II Functions \(IPDM E/R\)"](#) in HEADLAMP -CONVENTIONAL TYPE-.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Parking, License Plate, Side Marker and Tail Lamps Do Not Illuminate

NKS001QZ

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "LIGHT SW 1ST" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is 1ST : LIGHT SW 1 ST ON position**

⊗ Without CONSULT-II

Refer to [LT-153, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-153, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
LIGHT SW 1ST	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7607E

### 2. ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
3. Touch "ON" screen.
4. Make sure parking, license plate, side marker and tail lamps operate.

**Parking, license plate, side marker and tail lamps should operate.**

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-21, "Auto Active Test"](#) .
2. Make sure parking, license plate, side marker and tail lamps operate.

**Parking, license plate, side marker and tail lamps should operate.**

ACTIVE TEST			
TAIL LAMP	OFF		
ON			
MODE	BACK	LIGHT	COPY

SKIA5957E

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

### 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "TAIL & CLR REQ" turns ON when lighting switch is in 1ST position.

**When lighting switch is 1ST : TAIL & CLR REQ ON position**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#) .

NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#) .

DATA MONITOR			
MONITOR			
TAIL&CLR REQ	ON		
		RECORD	
MODE	BACK	LIGHT	COPY


SKIA5958E

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 4. CHECK PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS CIRCUIT


- Turn ignition switch OFF.
- Disconnect IPDM E/R connector, front combination lamp RH and LH connectors, license plate lamp RH and LH connectors, rear combination lamp RH and LH connectors, and rear combination lamp control unit connector.
- Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp (Parking and side marker)			Continuity
Connector	Terminal	Connector	Terminal		
E7	22	RH	E30	7	Yes
		LH	E17	7	




- Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

IPDM E/R		License plate lamp			Continuity
Connector	Terminal	Connector	Terminal		
E7	22	RH	D104	1	Yes
		LH	D102		




- Check continuity between IPDM E/R harness connector (A) and rear combination lamp harness connector (B).

A		B			Continuity
Connector	Terminal	Connector	Terminal		
E7	22	RH	B29	2	Yes
		LH	B24		



- Check continuity between IPDM E/R harness connector (A) E7 terminal 22 and rear combination lamp control unit harness connector (B) B42 terminal 1.

**22 - 1 : Continuity should exist.**



OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.


# PARKING, LICENSE PLATE AND TAIL LAMPS

## 5. CHECK PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OUTPUT VOLTAGE

④ With CONSULT-II


1. Turn ignition switch OFF.
2. Connect IPDM E/R connector, front combination lamp RH and LH connectors, license plate lamp RH and LH connectors, rear combination lamp RH and LH connectors, and rear combination lamp control unit connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
5. Touch "ON" screen.
6. Check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Front combination lamp (Parking and side marker) connector				
RH	E30	7	Ground	Battery voltage
LH	E17	7		




7. Check voltage between license plate lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
License plate lamp connector				
RH	D104	1	Ground	Battery voltage
LH	D102			



8. Check voltage between rear combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Rear combination lamp (Side marker) connector				
RH	B29	2	Ground	Battery voltage
LH	B24			




# PARKING, LICENSE PLATE AND TAIL LAMPS

9. Check voltage between rear combination lamp harness connector B42 terminal 1 and ground.

**1 - Ground**


**: Battery voltage**



⊗ Without CONSULT-II


1. Turn ignition switch OFF.
2. Disconnect front combination lamp RH and LH, license plate lamp RH and LH, rear combination lamp RH and LH, and rear combination lamp control unit connectors.
3. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
4. Check voltage between front combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Front combination lamp (Parking and side marker) connector				
RH	E30	7	Ground	Battery voltage
LH	E17	7		




5. Check voltage between license plate lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
License plate lamp connector				
RH	D104	1	Ground	Battery voltage
LH	D102			



6. Check voltage between rear combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Rear combination lamp (Side marker) connector				
RH	B29	2	Ground	Battery voltage
LH	B24			



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LT


# PARKING, LICENSE PLATE AND TAIL LAMPS

7. Check voltage between rear combination lamp harness connector B42 terminal 1 and ground.

**1 - Ground** : **Battery voltage**

OK or NG

- OK >> Check connector connection bend and loose fit.  
NG >> Replace IPDM E/R.



## Tail Lamp Does Not Operate But Parking, License Plate and Side Marker Lamps Operate

NKS002TS

### 1. CHECK REAR COMBINATION LAMP OPERATION

Check if turn signal lamp and stop lamp operation is normally.


OK or NG

- OK >> GO TO 2.  
NG >> ● Both sides do not operate: Refer to [LT-142, "Any Function of Rear Combination Lamps Does Not Work \(Both sides\)"](#) .  
● One side does not operate: Refer to [LT-143, "Any Function of Rear Combination Lamps Does Not Work \(One side\)"](#) .

### 2. CHECK TAIL LAMP SIGNAL

1. Turn ignition switch OFF.
2. Lighting switch is 1ST position.
3. Check voltage between rear combination lamp control unit harness connector B42 terminal 1 and ground.

**1 - Ground** : **Battery voltage**



OK or NG

- OK >> Replace rear combination lamp control unit.  
NG >> Repair harness or connector between IPDM E/R and rear combination lamp control unit.

## Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

NKS001R0

### 1. CHECK IPDM E/R

1. Turn the ignition switch ON. Place the combination switch (lighting switch) in the ON position. Turn the ignition switch OFF.
2. Make sure the parking, license plate, and tail lamps turn OFF after approximately 10 minutes.

OK or NG

- OK >> INSPECTION END  
NG >> Ignition relay malfunction. Refer to [PG-18, "Function of Detecting Ignition Relay Malfunction"](#) .

# PARKING, LICENSE PLATE AND TAIL LAMPS


## Bulb Replacement LICENSE PLATE LAMP

NKS001R1

1. Remove back door inner finisher. Refer to [EI-39, "BACK DOOR TRIM"](#) .
2. Disconnect license plate lamp connector.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb from its socket.

**License plate lamp : 12V - 5W**

5. Installation is the reverse order of removal.



## PARKING LAMP

Refer to [LT-34, "Bulb Replacement"](#) in HEADLAMP -XENON TYPE-.  
Refer to [LT-63, "Bulb Replacement"](#) in HEADLAMP -CONVENTIONAL TYPE-.

## TAIL LAMP

Refer to [LT-184, "Bulb Replacement"](#) .

## FRONT SIDE MARKER LAMP

Refer to [LT-34, "Bulb Replacement"](#) in HEADLAMP -XENON TYPE-.  
Refer to [LT-63, "Bulb Replacement"](#) in HEADLAMP -CONVENTIONAL TYPE-.


## REAR SIDE MARKER LAMP

Refer to [LT-184, "Bulb Replacement"](#) .

## Removal and Installation LICENSE PLATE LAMP

NKS001R2

1. Remove back door inner finisher. Refer to [EI-39, "BACK DOOR TRIM"](#) .
2. Remove rear wiper motor. Refer to [WW-52, "Removal and Installation of Rear Wiper Motor"](#) .
3. Remove license plate lamp mounting screws and remove it.
4. Installation is the reverse order of removal.



## PARKING LAMP

Refer to [LT-35, "Removal and Installation"](#) in HEADLAMP -XENON TYPE-.  
Refer to [LT-64, "Removal and Installation"](#) in HEADLAMP -CONVENTIONAL TYPE-.

## TAIL LAMP

Refer to [LT-184, "Removal and Installation"](#) .

## FRONT SIDE MARKER LAMP

Refer to [LT-35, "Removal and Installation"](#) in HEADLAMP -XENON TYPE-.  
Refer to [LT-64, "Removal and Installation"](#) in HEADLAMP -CONVENTIONAL TYPE-.

## REAR SIDE MARKER LAMP

Refer to [LT-184, "Removal and Installation"](#) .

# REAR COMBINATION LAMP

## REAR COMBINATION LAMP

PFP:26554

### Bulb Replacement

NKS001R3

#### STOP, TAIL & REAR TURN SIGNAL LAMP BULB, REAR SIDE MARKER LAMP BULB

1. Remove rear combination lamp. Refer to [LT-184, "Removal and Installation"](#) .
2. Replacement integral with rear combination lamp.

**Stop/tail/rear turn signal lamp** : LED

**Rear side marker lamp** : LED


### Removal and Installation

#### REAR COMBINATION LAMP

NKS001R4

##### Removal

1. Remove rear combination lamp finisher.
2. Remove rear combination lamp mounting bolts.
3. Pull the rear combination lamp toward side of the vehicle and remove from the vehicle.
4. Disconnect rear combination lamp connector.



##### Installation


Installation is the reverse order of removal.

**Rear combination lamp mounting bolt**  : 5.5 N·m (0.56 kg-m, 49 in-lb)

### REAR COMBINATION LAMP CONTROL UNIT

##### Removal

1. Remove luggage floor finisher (front) and luggage floor finisher (center). Refer to [EI-37, "LUGGAGE FLOOR TRIM"](#) .
2. Disconnect rear combination lamp control unit connector (1).
3. Remove rear combination lamp control unit mounting bolt (A).
4. Remove rear combination lamp control unit (2).



##### Installation

Installation is the reverse order of removal.

**Rear combination lamp control unit mounting bolt**  : 5.5 N·m (0.56 kg-m, 49 in-lb)




# INTERIOR ROOM LAMP

## INTERIOR ROOM LAMP

PF26410

### Component Parts and Harness Connector Location

NKS001RA



## System Description

NKS001RB

When the room lamp and personal lamp switch is in DOOR position, room lamp and personal lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch driver side, unlock signal from key fob, door lock and unlock switch, key cylinder lock and unlock switch, ignition switch. When the room lamp and personal lamp turns ON, there is a gradual brightening over 1 second. When room lamp and personal lamp turns OFF, there is a gradual dimming over 1 second.

The room lamp and personal lamp timer is controlled by the BCM (body control module).

Room lamp and personal lamp timer control settings can be changed with CONSULT-II.

Ignition key hole illumination turns ON at time when driver door is opened (door switch ON) or removed key fob from key cylinder. Illumination turns OFF when driver door is closed (door switch OFF).

Step lamp turns ON at time when driver door or passenger door is opened (door switch ON). Lamp turns OFF when driver, passenger doors are closed (all door switches OFF).

# INTERIOR ROOM LAMP

---

## POWER SUPPLY AND GROUND

Power is supplied at all times (without Intelligent Key system)

- through 10A fuse [No. 21, located in fuse block (J/B)]
- to key switch terminal 3,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55.

Power is supplied at all times (with Intelligent Key system)

- through 10A fuse [No.22, located in fuse block (J/B)]
- to key switch and ignition knob switch terminals 1 and 3,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55.

When the key is inserted to ignition key cylinder, power is interrupted (without Intelligent Key system)

- through key switch terminal 4
- to BCM terminal 37.

When inserted key plate to key switch and ignition knob switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 4
- to BCM terminal 37.

When pushed key switch and ignition knob switch, power is supplied (with Intelligent Key system)

- through key switch and ignition knob switch terminal 2
- to intelligent key unit terminal 27.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 52
- through grounds M14 and M78.

When the driver side door is opened, ground is supplied

- to BCM terminal 62
- through front door lock assembly (driver side) (door switch) terminal 4
- through front door lock assembly (driver side) (door switch) terminal 5
- through grounds M14 and M78.

When the passenger side door is opened, ground is supplied

- to BCM terminal 12
- through front door lock assembly (passenger side) (door switch) terminal 4
- through front door lock assembly (passenger side) (door switch) terminal 5
- through grounds M14 and M78.

When the rear door LH is opened, ground is supplied

- to BCM terminal 63
- through rear door lock assembly LH (door switch) terminal 4
- through rear door lock assembly LH (door switch) terminal 5
- through grounds B7 and B20.

When the rear door RH is opened, ground is supplied

- to BCM terminal 13
- through rear door lock assembly RH (door switch) terminal 4
- through rear door lock assembly RH (door switch) terminal 5
- through grounds B105 and B116.

When the driver side door is unlocked by the door lock and unlock switch, BCM receives a ground signal

# INTERIOR ROOM LAMP

- through grounds M14 and M78
- to power window main switch (door lock and unlock switch) terminal 17 or front power window switch (passenger side) (door lock and unlock switch) terminal 11
- from power window main switch (door lock and unlock switch) terminal 14 or front power window switch (passenger side) (door lock and unlock switch) terminal 16
- to BCM terminal 22.

When the front driver side door is unlocked by the driver side door lock assembly (door key cylinder switch), BCM receives a ground signal

- through grounds M14 and M78
- to front door lock assembly (driver side) (door key cylinder switch) terminal 5 (without Intelligent Key system)
- to door key cylinder switch terminal 2 (with Intelligent Key system)
- from front door lock assembly (driver side) (door key cylinder switch) terminal 6 (without Intelligent Key system)
- from door key cylinder switch terminal 3 (with Intelligent Key system)
- to power window main switch (door lock and unlock switch) terminal 6
- from power window main switch (door lock and unlock switch) terminal 14
- to BCM terminal 22.

When a signal, or combination of signals is received by BCM, ground is supplied

- to room lamp terminal 1 and
- to personal lamp LH and RH terminals 3
- through BCM terminal 48.

With power and supplied, the interior lamp illuminates.

## SWITCH OPERATION

When driver door switch is ON (door is opened), ground is supplied

- to ignition key hole illumination terminal 2
- through BCM terminal 1.

And power is supplied

- from BCM terminal 41
- to ignition key hole illumination terminal 1.

When any door switch is ON (door is opened), ground is supplied

- through BCM terminal 47
- to step lamp (driver side and passenger side) terminal 2.

And power is supplied

- from BCM terminal 41
- to step lamp (driver side and passenger side) terminal 1.

When map lamp switch is ON, ground is supplied

- to map lamp terminal 2
- through grounds M14 and M78.

And power is supplied

- from BCM terminal 41
- to map lamp terminal 1.

When vanity mirror lamp (driver side and passenger side) is ON, ground is supplied

- to vanity mirror lamp (driver side and passenger side) terminal 2
- through grounds M14 and M78.

And power is supplied

- from BCM terminal 41
- to vanity mirror lamp (driver side and passenger side) terminal 1.

When personal lamp LH and RH switches are ON, ground is supplied

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT

# INTERIOR ROOM LAMP

---

- to personal lamp LH and RH terminals 2
- through grounds M14 and M78.

And power is supplied

- from BCM terminal 41
- to personal lamp LH and RH terminals 1.

When room lamp switch is ON, ground is supplied

- to room lamp terminal 3
- through grounds M14 and M78.

And power is supplied

- from BCM terminal 41
- to room lamp terminal 2.

When luggage room lamp RH and LH are ON, and then back door switch is ON, ground is supplied

- to luggage room lamp RH and LH terminals 2
- through back door switch terminal 3
- through back door switch terminal 4
- through grounds B7 and B20.

And power is supplied

- from BCM terminal 41
- to luggage room lamp RH and LH terminals 1.

## ROOM LAMP TIMER OPERATION

### Without Intelligent Key System

When room lamp and personal lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for room lamp and personal lamp ON/OFF.

In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to key switch terminal 3.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37.

Ground is supplied

- from BCM terminal 22
- to power window main switch (door lock and unlock switch) terminal 14.

At this time, BCM detects that driver door is unlocked. It determines that room lamp and personal lamp timer operation conditions are met, and turns the room lamp and personal lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON),

Power is supplied

- through key switch terminal 4
- to BCM terminal 37.

When key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. BCM detects that key has been removed, determines that room lamp and personal lamp timer conditions are met, and turns the room lamp and personal lamp ON for 30 seconds.

When driver door opens → closes, and the key is not inserted in the key switch and key lock solenoid (key switch OFF), BCM terminal 62 changes between 0V (door open) → 12V (door closed). The BCM determines that conditions for room lamp and personal lamp operation are met and turns the interior lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked key fob or power window main switch (door lock and unlock switch), door key cylinder switch]
- Driver door is opened (driver door switch turns ON)
- Ignition switch ON.

# INTERIOR ROOM LAMP

## With Intelligent Key System

When the room lamp and personal lamp switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 second) for room lamp and personal lamp ON/OFF.

In addition, when spot turns ON or OFF there is gradual brightening or dimming over 1 second.

Power is supplied

- to 10A fuse [No. 22, located in fuse and fuse block (J/B)]
- through key switch and ignition knob switch terminals 1 and 3.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37. And not turned ignition knob switch, power will not be supplied to Intelligent Key unit.

Ground is supplied

- from BCM terminal 22
- to power window main switch (door lock and unlock switch) terminal 14.

At the time that driver door are opened, BCM detects that driver door is unlocked. It determines that room lamp and personal lamp timer operation conditions are met, and turns room lamp and personal lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON), or turned ignition knob switch,

Power is supplied

- through key switch terminal 4
- to BCM terminal 37,
- through key switch terminal 2
- to intelligent key unit terminal 27.

When the key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. And turned ignition knob switch, power supply to Intelligent Key unit is terminated. BCM detects that key has been removed, determines that room lamp and personal lamp timer conditions are met, and turns room lamp and personal lamp ON for 30 seconds.

When driver door opens → closes, and key is not inserted in key switch (or not turned ignition knob switch), BCM terminal 62 changes between 0V (door open) → 12V (door closed). BCM determines that conditions for room lamp and personal lamp operation are met and turns the room lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked [when locked key fob, power window main switch (door lock and unlock switch) or door key cylinder switch].
- Driver door is opened (driver door switch turns ON).
- Ignition switch ON.

## INTERIOR LAMP BATTERY SAVER CONTROL

If interior lamp is left "ON", it will not be turned out even when door is closed.

BCM turns off interior lamp automatically to save battery 30 minutes after ignition switch is turned off.

BCM controls interior lamps listed below:

- Ignition keyhole illumination
- Step lamp (driver side)
- Step lamp (passenger side)
- Vanity mirror lamp (driver side)
- Vanity mirror lamp (passenger side)
- Map lamp
- Luggage room lamp
- Room lamp
- Personal lamp RH
- Personal lamp LH

After lamps turn OFF by battery saver system, lamps illuminate again when

- signal from key fob, or power window main switch (door lock and unlock switch) or key cylinder is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder, or turned ignition knob switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

## INTERIOR ROOM LAMP


---

Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

# INTERIOR ROOM LAMP

## Schematic

NKS001RC




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

Next page

TKWB0467E

# INTERIOR ROOM LAMP



Preceding page

TKWB0468E




# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L — WITH INTELLIGENT KEY


NKS001RD

LT-ROOM/L-01

▬ : DATA LINE





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



REFER TO THE FOLLOWING.  
 (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M34), (M35), (M99) - ELECTRICAL UNITS

# INTERIOR ROOM LAMP

LT-ROOM/L-02





REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M34), (M35), (M36) -ELECTRICAL UNITS

TKWB2584E

# INTERIOR ROOM LAMP

LT-ROOM/L-03





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

TKWB2585E

# INTERIOR ROOM LAMP







LT-ROOM/L-04



TKWB2586E

# INTERIOR ROOM LAMP




LT-ROOM/L-05



TKWB0473E

# INTERIOR ROOM LAMP

LT-ROOM/L-06





REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M34) -ELECTRICAL UNITS

TKWB0474E

# INTERIOR ROOM LAMP

LT-ROOM/L-07

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M



REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M34), (M36) -ELECTRICAL UNITS





TKWB0475E

# INTERIOR ROOM LAMP

WITHOUT INTELLIGENT KEY

LT-ROOM/L-08

▬ : DATA LINE





REFER TO THE FOLLOWING.  
 (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M34), (M35) - ELECTRICAL UNITS

TKWB2587E



# INTERIOR ROOM LAMP

LT-ROOM/L-09





REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M34), (M35), (M36) -ELECTRICAL UNITS

TKWB2588E

# INTERIOR ROOM LAMP

LT-ROOM/L-10





TKWB2589E

# INTERIOR ROOM LAMP

LT-ROOM/L-11







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



TKWB2590E

# INTERIOR ROOM LAMP




LT-ROOM/L-12




TKWB2591E

# INTERIOR ROOM LAMP

LT-ROOM/L-13





REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M34) -ELECTRICAL UNITS



# INTERIOR ROOM LAMP

LT-ROOM/L-14






REFER TO THE FOLLOWING.  
 (D1), (D31) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M34), (M36) -ELECTRICAL UNITS

TKWB2593E

# INTERIOR ROOM LAMP




## Terminals and Reference Values for BCM

NKS001RE

Terminal No.	Wire color	Signal name	Measuring condition			Reference value	
			Ignition switch	Operation or condition			
1	R/Y	Ignition key hole illumination signal	OFF	Ignition keyhole illumination	Illuminated	Battery voltage	
					Not illuminated	Approx. 0 V	
12	R/G <sup>*1</sup> , R <sup>*2</sup>	Front door switch AS signal	OFF	Front door switch AS	ON (open)	Approx. 0 V	
					OFF (closed)	 <p style="text-align: center;">Approx. 7.5 - 8.0 V</p>	
13	R/W <sup>*1</sup> , R/Y <sup>*2</sup>	Rear door switch RH signal	OFF	Rear door switch RH	ON (open)	Approx. 0 V	
					OFF (closed)	 <p style="text-align: center;">Approx. 8.5 - 9.0 V</p>	
22	BR/W	Power window switch serial link	—	Power window main switch (door lock and unlock switch) and power window sub-switch (front passenger side) (door lock and unlock switch)	Lock or unlock switch ON	 <p style="text-align: center;">Approx. 9.0 - 9.5 V</p>	
					NOTE: Approx. 10 seconds after door lock and unlock switch (driver side and passenger side) is turned "LOCK" or "UNLOCK".		
37	B/R	Key-in detection switch signal	OFF	Vehicle key is removed.	Approx. 0 V		
				Vehicle key is inserted.	Battery voltage		
38	R	Ignition power supply	ON	—	Battery voltage		
39	L	CAN - H	—	—	—		
40	Y	CAN - L	—	—	—		
41	P	Battery saver output signal	OFF	30 minutes after ignition switch is turned to OFF.	Approx. 0 V		
			ON	—	Battery voltage		
42	GR	Battery power supply	OFF	—	Battery voltage		
47	R/W	Step lamp signal	OFF	Any door is open. (ON)	Approx. 0 V		
				All doors are closed. (OFF)	Battery voltage		
48	R	Personal lamp LH and RH, and room lamp illumination output signal	OFF	Interior lamps switch: DOOR position	Any door switch	ON (open)	Approx. 0 V
					OFF (closed)	Battery voltage	
52	B	Ground	ON	—	Approx. 0 V		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value	
			Ignition switch	Operation or condition		
55	W/B	Battery power supply	OFF	—	Battery voltage	
58	V/W	Back door switch signal	OFF	Back door switch	ON (open)	Approx. 0 V
					OFF (closed)	 <p style="text-align: center;">Approx. 9.0 - 9.5 V</p>
62	SB	Front door switch DR signal	OFF	Front door switch DR	ON (open)	Approx. 0 V
					OFF (closed)	 <p style="text-align: center;">Approx. 7.0 - 7.5 V</p>
63	R/W	Rear door switch LH signal	OFF	Rear door switch LH	ON (open)	Approx. 0 V
					OFF (closed)	 <p style="text-align: center;">Approx. 8.5 - 9.0 V</p>

\*1: With intelligent key, \*2: Without intelligent key

## How to Proceed with Trouble Diagnosis

NKS001RF

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-185, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-209, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the interior room lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END



# INTERIOR ROOM LAMP

NKS001RG

## Preliminary Check CHECK FOR POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES AND FUSIBLE LINK

Check for blown fuses and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
		21
		22
	Ignition switch ON or START position	1

Refer to [LT-193. "Wiring Diagram — ROOM/L —"](#) .

#### OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-3. "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Ignition switch position	
BCM connector	Terminal		OFF	ON
M34	38	Ground	Approx. 0 V	Battery voltage
M35	42		Battery voltage	Battery voltage
	55		Battery voltage	Battery voltage



#### OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

### 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M35	52		Yes

#### OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

## CONSULT-II Functions (BCM)

NKS002TW

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
INT LAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.
BATTERY SAVER	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

## CONSULT-II BASIC OPERATION

Refer to [GI-37, "CONSULT-II Start Procedure"](#).

### WORK SUPPORT (INT LAMP)

#### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "SET I/L D- UNLCK INTCON" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

#### Display Item List

Item	Description	CONSULT-II
SET I/L D-UNLCK INTCON	The 30 seconds glowing function interior room lamps and ignition keyhole illumination can be selected when driver door is released (unlocked).	ON/OFF
ROOM LAMP ON TIME SET	The time in order to escalate illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned on.	MODE 1 – 7
ROOM LAMP OFF TIME SET	The time in order to diminish illumination can be adjusted when interior room lamps and ignition keyhole illumination is turned off.	MODE 1 – 7

Reference between "MODE" and "TIME" for "TURN ON/OFF"

MODE	1	2	3	4	5	6	7
Time (sec.)	0.5	1	2	3	4	5	0

### DATA MONITOR (INT LAMP)

#### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

# INTERIOR ROOM LAMP

## Display Item List

Monitor item		Contents
IGN ON SW	"ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
KEY ON SW	"ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from the key switch signal.
DOOR SW - DR	"ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS	"ON/OFF"	Displays status of the passenger door as judged from passenger door switch signal. (Door open (ON)/Door closed (OFF))
DOOR SW - RR	"ON/OFF"	Displays status of rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL	"ON/OFF"	Displays status of rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW	"ON/OFF"	Displays status of the back door as judged from back door switch signal. (Door open (ON)/Door closed (OFF))
KEY CYL LK - SW	"ON/OFF"	Displays "Door locked (ON) status, determined from key cylinder lock switch in driver door.
KEY CYL UN - SW	"ON/OFF"	Displays "Door unlocked (OFF) status, determined from key cylinder lock switch in driver door.
CDL LOCK SW	"ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF) status, determined from locking detection switch in driver door.
CDL UNLOCK SW	"ON/OFF"	Displays "Door unlocked (OFF)" status, determined from locking detection switch in passenger door.
I - KEY LOCK <sup>NOTE 1</sup>	"ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
I - KEY UNLOCK <sup>NOTE 1</sup>	"ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.
KEYLESS LOCK <sup>NOTE 2</sup>	"ON/OFF"	Displays status (door is locked: ON/other: OFF) of remote keyless entry system lock signal from the remote key less entry receiver signal.
KEYLESS UNLOCK <sup>NOTE 2</sup>	"ON/OFF"	Displays status (door is unlocked: ON/other: OFF) of remote keyless entry system unlock signal from the remote key less entry receiver signal.

### NOTE:

- 1: Vehicle with Intelligent Key system display this item.
- 2: Vehicle with remote keyless entry system display this item.

## ACTIVE TEST (INT LAMP)

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "OFF" deactivates the operation.

## Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.
IGN ILLUM	Ignition key hole illumination can be operated by ON-OFF operation.
STEP LAMP TEST	All step lamp can be operated by ON-OFF operation.
LUGGAGE LAMP TEST <sup>NOTE</sup>	—

### NOTE:

This item is displayed, but cannot be tested.

# INTERIOR ROOM LAMP

## WORK SUPPORT (BATTERY SAVER)

### Operation Procedure

1. Touch "BATTERY SAVER" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "ROOM LAMP BAT SAV SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

### Display Item List

Item	Description	CONSULT-II
ROOM LAMP TIME SET	Interior room lamp battery saver timer setting can be changed.	MODE 1: 30min MODE 2: 60min

## DATA MONITOR (BATTERY SAVER)

### Operation Procedure

1. Touch "BATTERY SAVER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects items and monitor them.

4. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all items will be monitored.
5. Touch "START".
6. Touch "RECORD" while monitoring, then the status of monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
KEY ON SW "ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from the key switch signal.
DOOR SW - DR "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - AS "ON/OFF"	Displays status of the passenger door as judged from passenger door switch signal. (Door open (ON)/Door closed (OFF))
DOOR SW - RR "ON/OFF"	Displays status of rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW - RL "ON/OFF"	Displays status of rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW "ON/OFF"	Displays status of the back door as judged from back door switch signal. (Door open (ON)/Door closed (OFF))
KEY CYL LK - SW "ON/OFF"	Displays "Door locked (ON) status, determined from key cylinder lock switch in driver door.
KEY CYL UN - SW "ON/OFF"	Displays "Door unlocked (OFF) status, determined from key cylinder lock switch in driver door.
CDL LOCK SW "ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF) status, determined from locking detection switch in driver door.
CDL UNLOCK SW "ON/OFF"	Displays "Door unlocked (OFF)" status, determined from locking detection switch in passenger door.
I - KEY LOCK <sup>NOTE 1</sup> "ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.

# INTERIOR ROOM LAMP

Monitor item	Contents
I – KEY UNLOCK <sup>NOTE 1</sup> “ON/OFF”	Displays “Unlocked (ON)/Other (OFF)” status, determined from unlock signal.
KEYLESS LOCK <sup>NOTE 2</sup> “ON/OFF”	Displays status (door is locked: ON/other: OFF) of remote keyless entry system lock signal from the remote key less entry receiver signal.
KEYLESS UNLOCK <sup>NOTE 2</sup> “ON/OFF”	Displays status (door is unlocked: ON/other: OFF) of remote keyless entry system unlock signal from the remote key less entry receiver signal.

**NOTE:**

- 1: Vehicle with Intelligent Key system display this item.
- 2: Vehicle with remote keyless entry system display this item.

## ACTIVE TEST (BATTERY SAVER)

### Operation Procedure

1. Touch “BATTERY SAVER” on “SELECT TEST ITEM” screen.
2. Touch “ACTIVE TEST” on “SELECT DIAG MODE” screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching “OFF” deactivates the operation.

### Display Item List

Test item	Description
BATTERY SAVER	Interior room lamp can be operated by ON–OFF operations.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

LT

# INTERIOR ROOM LAMP

NKS001R1

## Room Lamp Does Not Illuminate

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-211, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E

### 2. CHECK WITH ACTIVE TEST

- Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
- When room lamp switch is in "DOOR" position, use active test to make sure room lamp operates.

OK or NG

- OK >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6366E


### 3. CHECK POWER SUPPLY TO ROOM LAMP

- Turn ignition switch OFF.
- Disconnect room lamp connector.
- Turn ignition switch ON.
- Check voltage between room lamp harness connector R9 terminal 2 and ground.

**2 - Ground : Battery voltage.**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 6.




### 4. CHECK ROOM LAMP

Check continuity between room lamp terminals.

Terminal		Condition	Continuity
Room lamp			
1	2	Room lamp switch is DOOR	Yes
		Room lamp switch is OFF	No

OK or NG

- OK >> GO TO 5.
- NG >> Check bulb or replace room lamp.



# INTERIOR ROOM LAMP


## 5. CHECK POWER SUPPLY CIRCUIT FOR ROOM LAMP

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M35 terminal 48 and room lamp harness connector R9 terminal 1.

**48 - 1** : Continuity should exist.

### OK or NG

- OK >> Replace BCM if room lamp does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK GROUND CIRCUIT FOR ROOM LAMP

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M35 terminal 41 and room lamp harness connector R9 terminal 2.

**41 - 2** : Continuity should exist.

### OK or NG

- OK >> Replace BCM if room lamp does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



## Personal Lamp Does Not Illuminate

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-211, "Display Item List"](#) for switches and their functions.

### OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR			
MONITOR			
IGN ON SW	ON		
KEY ON SW	ON		
DOOR SW-DR	ON		
DOOR SW-AS	ON		
DOOR SW-RR	OFF		
DOOR SW-RL	OFF		
BACK DOOR SW	OFF		
KEY CYL LK-SW	OFF		
KEY CYL UN-SW	OFF		
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

NKS001RJ

PKIB3532E

### 2. CHECK WITH ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
2. When personal lamp switch is in "DOOR" position, use active test to make sure personal lamp operates.

### OK or NG

- OK >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6366E

# INTERIOR ROOM LAMP


## 3. CHECK PERSONAL LAMP INPUT

1. Turn ignition switch OFF.
2. Disconnect personal lamp connectors.
3. Turn ignition switch ON.
4. Check voltage between personal lamp RH harness connector R10 terminal 1 and ground.

**1 - Ground : Battery voltage.**

5. Check voltage between personal lamp LH harness connector R8 terminal 1 and ground.

**1 - Ground : Battery voltage.**



OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 6.


## 4. CHECK PERSONAL LAMP

1. Disconnect personal lamp connector.
2. Check continuity between personal lamp terminals.

Terminal		Condition	Continuity
Personal lamp			
1	3	Personal lamp switch is DOOR	Yes
		Personal lamp switch is OFF	No

OK or NG

- OK >> GO TO 5.  
 NG >> Check bulb or replace personal lamp.



## 5. CHECK PERSONAL LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector M35 terminal 48 and personal lamp RH harness connector R10 terminal 3.


**48 - 3 : Continuity should exist.**

4. Check continuity between BCM harness connector M35 terminal 48 and personal lamp LH harness connector R8 terminal 3.

**48 - 3 : Continuity should exist.**

OK or NG

- OK >> Replace BCM if personal amp does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness or connector.





# INTERIOR ROOM LAMP


## 6. CHECK PERSONAL LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector M35 terminal 41 and personal lamp RH harness connector R10 terminal 1.

41 - 1 : Continuity should exist.

4. Check continuity between BCM harness connector M35 terminal 41 and personal lamp LH harness connector R8 terminal 1.

41 - 1 : Continuity should exist.



OK or NG

OK >> Replace BCM if personal lamp does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).

NG >> Repair harness or connector.

## Ignition Key Hole Illumination Does Not Illuminate

NKS001RK

### 1. CHECK BULB

Check bulb of lamp which does not operate.

OK or NG

OK >> GO TO 2.

NG >> Replace bulb.

### 2. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-211, "Display Item List"](#) for switches and their functions.

OK or NG

OK >> GO TO 3.

NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB3532E

### 3. CHECK WITH ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
2. Select "IGN ILLUM" active test to make sure lamp operates.

OK or NG

OK >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).

NG >> GO TO 4.

ACTIVE TEST	
IGN ILLUM	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6375E

# INTERIOR ROOM LAMP


## 4. CHECK POWER SUPPLY TO IGNITION KEY HOLE ILLUMINATION

1. Turn ignition switch OFF.
2. Disconnect ignition key hole illumination connector.
3. Turn ignition switch ON.
4. Check voltage between ignition key hole illumination harness connector M40 terminal 1 and ground.

**1 - Ground** : **Battery voltage.**

OK or NG

- OK >> GO TO 6.  
NG >> GO TO 5.




## 5. CHECK POWER SUPPLY CIRCUIT FOR IGNITION KEY HOLE ILLUMINATION

1. Turn ignition switch OFF.
2. Disconnect BCM connector and key hole illumination connector.
3. Check continuity between BCM harness connector M35 terminal 41 and key hole illumination harness connector M40 terminal 1.

**41 - 1** : **Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK GROUND CIRCUIT FOR IGNITION KEY HOLE ILLUMINATION

1. Turn ignition switch OFF.
2. Disconnect BCM connector and key hole illumination connector.
3. Check continuity between BCM harness connector M34 terminal 1 and key hole illumination harness connector M40 terminal 2.

**1 (R/Y) - 2 (R/Y)** : **Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition key hole illumination does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP

NKS001RL

## Step Lamp Does Not Illuminate

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor to make sure switches listed below turn ON-OFF linked with switch operation.

Switch name	CONSULT screen
Driver side door switch	DOOR SW - DR
Passenger side door switch	DOOR SW - AS

#### OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR			
MONITOR			
IGN ON SW	ON		
KEY ON SW	ON		
DOOR SW-DR	ON		
DOOR SW-AS	ON		
DOOR SW-RR	OFF		
DOOR SW-RL	OFF		
BACK DOOR SW	OFF		
KEY CYL LK-SW	OFF		
KEY CYL UN-SW	OFF		
Page Down			
RECORD			
MODE	BACK	LIGHT	COPY

PKIB3532E

### 2. CHECK BULB

Check bulb of lamp which does not illuminate.

#### OK or NG

- OK >> GO TO 3.
- NG >> Replace bulb.

### 3. CHECK STEP LAMP INPUT

1. Turn ignition switch OFF.
2. Disconnect step lamp (driver side and passenger side) connectors.
3. Turn ignition switch ON.
4. Check voltage between step lamp (driver side) harness connector D9 terminal 1 and ground.

**1 - Ground : Battery voltage.**

5. Check voltage between step lamp (passenger side) harness connector D37 terminal 1 and ground.

**1 - Ground : Battery voltage.**

#### OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

### 4. CHECK GROUND CIRCUIT FOR STEP LAMP

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector M35 terminal 47 and step lamp (driver side) harness connector D9 terminal 2.



**47 - 2 : Continuity should exist.**

4. Check continuity between BCM harness connector M35 terminal 47 and step lamp (passenger side) harness connector D37 terminal 2.

**47 - 2 : Continuity should exist.**

#### OK or NG

- OK >> Replace BCM if step lamp does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



# INTERIOR ROOM LAMP


## 5. CHECK STEP LAMP CIRCUIT

1. Disconnect BCM connector and step lamp connector.
2. Check continuity between BCM harness connector M35 terminal 41 and step lamp (driver side) harness connector D9 terminal 1.

**41 - 1 : Continuity should exist.**

3. Check continuity between BCM harness connector M35 terminal 41 and step lamp (passenger side) harness connector D37 terminal 1.

**41 - 1 : Continuity should exist.**



OK or NG

- OK >> Replace BCM if step lamp does not work after setting the connector again. Refer to [BCS-14, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.

## All Interior Room Lamp Does Not Operate

NKS001RM


### 1. CHECK POWER SUPPLY CIRCUIT

1. All interior room lamps switch are OFF.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M35 terminal 41 and ground.

**41 - Ground : Battery voltage**

OK or NG

- OK >> Repair harness or connector. In a case of making a short circuit, be sure to disconnect battery negative cable after repairing harness, and then reconnect
- NG >> Replace BCM. Refer to [BCS-14, "Removal and Installation of BCM"](#).




## Bulb Replacement MAP LAMP

NKS001RN

1. Disconnect the battery negative cable.
2. Remove the lens using clip driver or suitable tool.
3. Remove the bulb.

**Map lamp : 12V - 8 W**

4. Installation is the reverse order of removal.



## PERSONAL LAMP


1. Remove the personal lamp. Refer to [LT-223, "PERSONAL LAMP"](#).

# INTERIOR ROOM LAMP

2. Remove the housing mounting screws, and separate it.
3. Remove bulb from the base.

**Personal lamp : 12V - 8W**

4. Installation is the reverse order of removal.




A  
B  
C  
D

## ROOM LAMP

1. Disconnect the battery negative cable.
2. Remove the lens using clip driver or suitable tool.
3. Remove the bulb.

**Room lamp : 12V - 8W**

4. Installation is the reverse order of removal.



E  
F  
G


## STEP LAMP

1. Disconnect the battery cable from the negative terminal or remove power fuse.
2. Insert a screwdriver in the chink between lens and door trim, and remove the lens.

3. Remove the bulb.

**Step lamp : 12V - 2.7W**

4. Installation is the reverse order of removal.



H  
I  
J  
LT

L  
M


# INTERIOR ROOM LAMP

## LUGGAGE ROOM LAMP

1. Remove luggage room lamp. Refer to [LT-224, "LUGGAGE ROOM LAMP"](#).
2. Remove the bulb.

**Luggage room lamp : 12V - 8W**

3. Installation is the reverse order of removal.




## VANITY MIRROR LAMP

1. Insert a thin screwdriver in the notch and remove lens.
2. Remove bulb.

**Vanity mirror lamp : 12V - 2W**

3. Installation is the reverse order of removal.




## IGNITION KEY HOLE ILLUMINATION

### Without intelligent key system

1. Remove the ignition key finisher. Refer to [IP-11, "Removal and Installation"](#).
2. Turn the bulb socket counterclockwise and unlock it.


**Ignition key hole illumination : 12V - 0.8W**



### With intelligent key system

1. Remove the ignition key finisher. Refer to [IP-11, "Removal and Installation"](#).
2. Remove the steering lock escutcheon.
3. Turn the bulb socket counterclockwise and unlock it.

**Ignition key hole illumination : 12V - 0.8W**



# INTERIOR ROOM LAMP


## Removal and Installation

### MAP LAMP

NKS001RO

#### Removal

1. Pull wider part of thin plate of the map lamp to disengage the metal clip.
2. Pull map lamp in direction shown by the arrow in the figure.
3. Disconnect map lamp connector and remove the map lamp.




#### Installation

Installation is the reverse order of removal.

### PERSONAL LAMP

#### Removal

1. Insert a clip driver or suitable tool and disengage the metal clip fittings of the personal lamp.
2. Disconnect personal lamp connector and remove the personal lamp.




#### Installation

Installation is the reverse order of removal.

### ROOM LAMP

#### Removal

1. Remove the lens using clip driver or suitable tool.
2. Using a clip driver or suitable tool and disengage the metal clip fittings of the room lamp.
3. Disconnect room lamp connector and remove the room lamp.



#### Installation

Installation is the reverse order of removal.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP


## STEP LAMP

### Removal

1. Insert a screwdriver in the chink between lens and door trim, and remove the lens.



2. Using a clip driver or a suitable tool, press and disengage the metal clip fittings of the step lamp.
3. Disconnect the step lamp connector and remove the step lamp.




### Installation

Installation is the reverse order of removal.

## LUGGAGE ROOM LAMP

### Removal

1. Insert a screwdriver as shown in the figure and pull out the luggage room lamp.
2. Disconnect the luggage room lamp connector and remove luggage room lamp.



### Installation

Installation is the reverse order of removal.



## ILLUMINATION

PFP:27545

### System Description

NKS001RP

- BCM (Body Control Module) controls illumination lamp operation.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates illumination lamps according to CAN communication signals from BCM.

### OUTLINE

Power is supplied at all times

- to ignition relay located in IPDM E/R, from battery direct,
- through 10A fuse (No. 71, located in IPDM E/R)
- to tail lamp relay located in IPDM E/R and
- to CPU located in IPDM E/R,
- through 15A fuse (No. 78, located in IPDM E/R)
- to CPU located in IPDM E/R,
- through 50A fusible link (letter F, located in fuse and fusible link block)
- to BCM terminal 55,
- through 10A fuse [No. 18, located in fuse block (J/B)]
- to BCM terminal 42,
- through 10A fuse [No. 21, located in fuse block (J/B)]
- to combination meter terminal 21.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery direct,
- through 10A fuse [No. 1, located in fuse block (J/B)]
- to BCM terminal 38,
- through 10A fuse [No. 14, located in fuse block (J/B)]
- to combination meter terminal 20.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal and 52
- through grounds M14 and M78,
- to IPDM E/R terminals 38 and 60
- through grounds E13, E26 and E28,
- to combination meter 22, 23 and 24
- through grounds M14 and M78.

### ILLUMINATION LAMP OPERATION

When the lighting switch is in 1ST position, BCM detects the LIGHTING SWITCH 1ST POSITION (ON) by BCM combination switch reading function. And then, BCM sends position light request signal (ON) through CAN communication.

When receiving position light request signal (ON), IPDM E/R turns ON tail lamp relay in IPDM E/R. And then supplies power

- through IPDM E/R terminal 22
- to CVT illumination terminal 1
- to VDC off switch (illumination) terminal 3 (with VDC)
- to headlamp aiming switch (illumination) terminal 3 (with headlamp aiming)
- to AWD lock switch (illumination) terminal 4 (AWD models)
- to heated seat switch (driver side) (illumination) terminal 5 (with heater seat)
- to heated seat switch (passenger side) (illumination) terminal 5 (with heater seat)
- to door mirror remote control switch (illumination) terminal 16

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# ILLUMINATION

---

- to combination switch (spiral cable) terminal 26
- to A/C and AV switch terminal 3
- NAVI control unit (illumination) terminal 61 (with NAVI)
- to coin box illumination terminal 1 and
- to glove box lamp terminal 1,
- through combination switch (spiral cable) terminal 28
- to audio steering switch (illumination) and
- to ASCD steering switch (illumination).

Ground is supplied

- to audio steering switch (illumination) and
- to ASCD steering switch (illumination)
- through combination switch (spiral cable) terminal 27,
- to CVT illumination terminal 2
- to VDC off switch (illumination) terminal 4 (with VDC)
- to headlamp aiming switch (illumination) terminal 4 (with headlamp aiming)
- to AWD lock switch (illumination) terminal 2 (AWD models)
- to heated seat switch (driver side) (illumination) terminal 6 (with heater seat)
- to heated seat switch (passenger side) (illumination) terminal 6 (with heater seat)
- to door mirror remote control switch (illumination) terminal 15
- to combination switch (spiral cable) terminal 30 and
- to A/C and AV switch terminal 4
- through combination meter terminal 15,
- to NAVI control unit (illumination) terminal 1
- to coin box illumination terminal 2 and
- to glove box lamp terminal 2
- through grounds M14 and M78.

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST or 2ND position (or if auto light system is activated), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated. Under this condition, the illumination lamps remain illuminated for 5 minutes, and then the illumination lamps are turned off.

When the lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps are turned off by the battery saver control, and illumination lamps illuminate again.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

NKS001RQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit

NKS001RR


Refer to [LAN-49, "CAN System Specification Chart"](#) .

# ILLUMINATION

## Schematic

NKS001RS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M





(AW) : AWD models  
 (HA) : With headlamp aiming  
 (VD) : With VDC  
 (NV) : With NAVI  
 (HS) : With heater seat  
 \* : This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

# ILLUMINATION

NKS001RT

## Wiring Diagram — ILL —

LT-ILL-01



REFER TO THE FOLLOWING.



- (M1) - FUSE BLOCK-JUNCTION BOX (J/B)
- (M34), (M35) - ELECTRICAL UNITS

# ILLUMINATION

LT-ILL-02

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M



▬ : DATA LINE



TKWB2596E

# ILLUMINATION

LT-ILL-03



REFER TO THE FOLLOWING.  
 M1, M2 - FUSE BLOCK-JUNCTION BOX (J/B)



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWB2597E

# ILLUMINATION

LT-ILL-04

- : AWD MODELS
- : WITH HEADLAMP AIMING
- : WITH VDC
- : WITH HEATER SEAT







TKWB2808E

# ILLUMINATION

LT-ILL-05

MM : WITH MEMORY MIRROR

OM : WITHOUT MEMORY MIRROR



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.




TKWB2598E



# ILLUMINATION

LT-ILL-06

: WITH NAVI




TKWB2599E

# ILLUMINATION

## Removal and Installation ILLUMINATION CONTROL SWITCH

NKS001RU


1. Remove meter lid. Refer to [DI-24, "Disassembly and Assembly of Combination Meter"](#) .
2. Remove illumination control switch fixing screws and remove the unit from the meter lid.



## CONSOLE POCKET LAMP

1. Remove instrument stay cover. Refer to [IP-11, "Removal and Installation"](#) .
2. Turn bulb socket counterclockwise and unlock it.


**Console pocket lamp : 12V - 1.4W**



## GLOVE BOX LAMP

1. Remove instrument passenger lower panel. Refer to [IP-11, "Removal and Installation"](#) .
2. Turn bulb socket counterclockwise and unlock it.


**Glove box lamp : 12V - 1.4W**



## COIN BOX ILLUMINATION

1. Remove A/T console finisher. Refer to [IP-17, "CENTER CONSOLE ASSEMBLY"](#) .
2. Turn bulb socket counterclockwise and unlock it.

**Coin box illumination : 12V - 1.4W**



# BULB SPECIFICATIONS

## BULB SPECIFICATIONS

PPF:26297

### Headlamp

NKS001RV

Item	Wattage (W)
High/Low (Halogen type)	65/55 (HB5)
High/Low (Xenon type)	35 (D2S)

### Exterior Lamp

NKS001RX

Item	Wattage (W)	
Front combination lamp	Front turn signal lamp	21 (amber)
	Parking lamp	3.8
	Front side marker lamp	3.8
Rear combination lamp	Stop/Tail/Rear turn signal lamp	LED
	Rear side marker lamp	LED
Front fog lamp	51 (HB4)	
Back-up lamp	16	
License plate lamp	5	
High-mounted stop lamp (back door mount)	LED	

### Interior Lamp/Illumination

NKS001RX

Item	Wattage (W)
Map lamp	8
Room lamp	8
Personal lamp	8
Luggage room lamp	8
Step lamp	2.7
Glove box lamp	1.4
Vanity mirror lamp	2
Ignition key hole illumination	0.8
Console pocket lamp	1.4
Coin box illumination	1.4

# BULB SPECIFICATIONS

---