



|  |           |   |           |
|--|-----------|---|-----------|
| DTC Logic .....  | 31        | Diagnosis Procedure .....   | 67        |
| Diagnosis Procedure .....  | 31        | <b>TURN SIGNAL LAMP BLINKS .....</b>                                  | <b>69</b> |
| Special Repair Requirement .....                                 | 31        | Description .....   | 69        |
| <b>POWER SUPPLY AND GROUND CIRCUIT ....</b>                      | <b>32</b> | Diagnosis Procedure .....   | 69        |
| <b>BCM (BODY CONTROL MODULE) .....</b>                           | <b>32</b> | <b>ID REGISTRATION CANNOT BE COMPLET-<br/>ED .....</b>                | <b>70</b> |
| BCM (BODY CONTROL MODULE) : Diagnosis<br>Procedure .....         | 32        | Description .....   | 70        |
| <b>REMOTE KEYLESS ENTRY RECEIVER .....</b>                       | <b>33</b> | Diagnosis Procedure .....   | 70        |
| Description .....  | 33        | <b>NORMAL OPERATING CONDITION .....</b>                               | <b>71</b> |
| Diagnosis Procedure .....  | 33        | Description .....   | 71        |
| <b>TIRE PRESSURE WARNING CHECK<br/>SWITCH .....</b>              | <b>35</b> | <b>NOISE, VIBRATION AND HARSHNESS<br/>(NVH) TROUBLESHOOTING .....</b> | <b>72</b> |
| Description .....  | 35        | NVH Troubleshooting Chart .....                                       | 72        |
| Diagnosis Procedure .....  | 35        | <b>PRECAUTION .....</b>   | <b>73</b> |
| <b>TPMS .....</b>  | <b>37</b> | <b>PRECAUTIONS .....</b>  | <b>73</b> |
| Description .....  | 37        | Service Notice or Precautions .....                                   | 73        |
| Wiring Diagram - TIRE PRESSURE MONITOR-<br>ING SYSTEM - .....    | 38        | <b>PREPARATION .....</b>  | <b>74</b> |
| <b>ECU DIAGNOSIS .....</b>                                       | <b>40</b> | <b>PREPARATION .....</b>  | <b>74</b> |
| <b>BCM (BODY CONTROL MODULE) .....</b>                           | <b>40</b> | Special Service Tools .....   | 74        |
| Reference Value .....  | 40        | Commercial Service Tools .....  | 74        |
| Wiring Diagram - BCM - .....                                     | 55        | <b>ON-VEHICLE MAINTENANCE .....</b>                                   | <b>75</b> |
| Fail-safe .....  | 59        | <b>ROAD WHEEL .....</b>   | <b>75</b> |
| DTC Inspection Priority Chart .....                              | 60        | Inspection .....  | 75        |
| DTC Index .....  | 60        | <b>ON-VEHICLE REPAIR .....</b>  | <b>76</b> |
| <b>SYMPTOM DIAGNOSIS .....</b>                                   | <b>62</b> | <b>ROAD WHEEL TIRE ASSEMBLY .....</b>                                 | <b>76</b> |
| <b>TPMS .....</b>  | <b>62</b> | Adjustment .....  | 76        |
| Symptom Table .....  | 62        | <b>TRANSMITTER .....</b>  | <b>79</b> |
| <b>LOW TIRE PRESSURE WARNING LAMP<br/>DOES NOT TURN ON .....</b> | <b>64</b> | Exploded View .....   | 79        |
| Description .....  | 64        | Removal and Installation .....  | 79        |
| Diagnosis Procedure .....  | 64        | <b>SERVICE DATA AND SPECIFICATIONS<br/>(SDS) .....</b>                | <b>81</b> |
| <b>LOW TIRE PRESSURE WARNING LAMP<br/>STAYS ON .....</b>         | <b>65</b> | <b>SERVICE DATA AND SPECIFICATIONS<br/>(SDS) .....</b>                | <b>81</b> |
| Description .....  | 65        | Road Wheel .....  | 81        |
| Diagnosis Procedure .....  | 65        | Tire .....  | 81        |
| <b>LOW TIRE PRESSURE WARNING LAMP<br/>BLINKS .....</b>           | <b>67</b> |   |           |
| Description .....  | 67        |   |           |

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Repair Work Flow

INFOID:000000004236595

#### DETAILED FLOW

#### 1. VERIFY CUSTOMER COMPLAINTS

Interview the customer to obtain detailed information about the symptom.

>> GO TO 2.

#### 2. DETERMINE REFERENCE ITEM RELATED TO SYMPTOM

Check the symptom on the vehicle from the information obtained.  
(cruise test, warning lamp illumination or blinking, etc.)

Is the symptom confirmed?

YES >> GO TO 3.

NO >> GO TO 4.

#### 3. PRELIMINARY INSPECTION

1. Perform basic inspection.
2. Check all tire pressures. Refer to [WT-81, "Tire"](#).
3. Check the low tire pressure warning lamp for illumination or blinking. Refer to [WT-62, "Symptom Table"](#).

Is the malfunction corrected?

YES >> INSPECTION END

NO >> GO TO 4.

#### 4. PERFORM SELF-DIAGNOSIS

1. Perform self-diagnosis. Record any DTCs and data displayed on CONSULT-III.
2. Perform inspection according to the displayed DTC. Refer to [WT-60, "DTC Index"](#).

Is the causal factor identified from DTC?

YES >> GO TO 6.

NO >> GO TO 5.

#### 5. CHECK SYMPTOM

Perform troubleshooting by symptom. Refer to [WT-62, "Symptom Table"](#).

Is the causal factor identified?

YES >> GO TO 6.

NO >> GO TO 4.

#### 6. REPAIR OR REPLACE MULFUNCTIONING PARTS

Repair or replace the applicable part.

>> GO TO 7.

#### 7. CHECK SELF-DIAGNOSIS RESULT

1. Erase DTCs. Refer to [WT-12, "AIR PRESSURE MONITOR : Diagnosis Description"](#).
2. Perform self-diagnosis again.

Is any DTC displayed?

YES >> GO TO 4.

NO >> GO TO 8.

#### 8. FINAL CHECK

1. Perform a cruise test.
2. Check the warning lamp for illumination or blinking.

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

Is the malfunction corrected?

YES >> INSPECTION END

NO >> GO TO 4.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT TRANSMITTER WAKE UP OPERATION

### TRANSMITTER WAKE UP OPERATION : Description

INFOID:000000004236596

This procedure must be done after replacement of a transmitter, BCM, or rotation of wheels.

### TRANSMITTER WAKE UP OPERATION : Special Repair Requirement


INFOID:000000004236597

#### 1. TRANSMITTER WAKE-UP PROCEDURE

1. Turn the ignition switch ON.
2. Contact the transmitter activation tool (J-45295) (1) to the side of the tire at the location to the transmitter.
3. Press and hold the activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

**CAUTION:**

Perform the wake-up procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.



4. Check that the low tire pressure warning lamp blinks in the pattern shown as per the following. The pattern indicates that the transmitter wake-up procedure for the wheel is completed.

| Low tire pressure warning lamp blinking timing |  | Activation tire position                 |
|--|--|--|
| ON<br>OFF                                      |  | a : 0.3 sec.<br>b : 1.3 sec.<br>Front LH |
| ON<br>OFF                                      |  | a : 0.3 sec.<br>b : 1.3 sec.<br>Front RH |
| ON<br>OFF                                      |  | a : 0.3 sec.<br>b : 1.3 sec.<br>Rear RH  |
| ON<br>OFF                                      |  | a : 0.3 sec.<br>b : 1.3 sec.<br>Rear LH  |
| ON<br>OFF                                      |  | a : 2 sec.<br>b : 0.2 sec.<br>All tires  |

5. Check that the turn signal lamps blink twice when the transmitter wake-up procedure for all wheels is completed.
6. Check that the low tire pressure warning lamp turns OFF, after the transmitter wake-up procedure is completed for all wheels and turns OFF.

Is the transmitter wake-up procedure completed?

YES >> Perform the transmitter ID registration procedure. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

NO >> Perform trouble diagnosis for the transmitter. Refer to [WT-17, "Diagnosis Procedure"](#).

## ID REGISTRATION PROCEDURE

### ID REGISTRATION PROCEDURE : Description

INFOID:000000004236598

This procedure must be done after replacing or rotating wheels, replacing transmitter or BCM.

### ID REGISTRATION PROCEDURE : Special Repair Requirement

INFOID:000000004236599

#### 1. TRANSMITTER ID REGISTRATION PROCEDURE

With CONSULT-III.

# INSPECTION AND ADJUSTMENT

## < BASIC INSPECTION >

1. Display the "WORK SUPPORT" screen and select "ID REGIST".

Is the transmitter activation tool (J-45295) used for the transmitter ID registration procedure?


- YES >> GO TO 2.
- NO >> GO TO 3.

## 2. TRANSMITTER ID REGISTRATION PROCEDURE (WITH THE TRANSMITTER ACTIVATION TOOL)

1. Turn the ignition switch ON.
2. Select the start button on the "ID REGIST" screen.
3. Contact the transmitter activation tool (J-45295) (1) to the side of the tire at the location to the transmitter.
4. Press and hold the activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

**CAUTION:**

**Perform the ID registration procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.**



5. When ID registration is completed, check the following pattern at each wheel.

| Se-quence | ID registration position | Turn signal lamp | CONSULT-III           |
|-----------|--------------------------|------------------|-----------------------|
| 1         | Front left wheel         | 2 blinks         | "Red"<br>↓<br>"Green" |
| 2         | Front right wheel        |                  |                       |
| 3         | Rear right wheel         |                  |                       |
| 4         | Rear left wheel          |                  |                       |

6. After the ID registration procedure for all wheels is completed, press "END" to end ID registration, and check that ID registration for all wheels is completed.

Is the check result normal?

- YES >> ID registration END.
- NO >> Performs trouble-diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to [WT-12. "AIR PRESSURE MONITOR : Diagnosis Description"](#).

## 3. TRANSMITTER ID REGISTRATION PROCEDURE (WITHOUT THE TRANSMITTER ACTIVATION TOOL)

1. Adjust the tire pressure for all wheels to match the list below.

| Tire position | Tire pressure kPa (kg/cm <sup>2</sup> , psi) |
|---------------|--|
| Front LH      | 240 (2.4, 35)                                |
| Front RH      | 220 (2.2, 31)                                |
| Rear RH       | 200 (2.0, 29)                                |
| Rear LH       | 180 (1.8, 26)                                |

2. Drive the vehicle at a speed at more than 40 km/h (25 MPH) for 3 minutes or more, then perform the transmitter ID registration procedure.
3. After ID registration for all wheels is completed, press "END" to end ID registration.

| ID registration position | CONSULT-III           |
|--------------------------|-----------------------|
| Front LH                 | "Red"<br>↓<br>"Green" |
| Front RH                 |                       |
| Rear RH                  |                       |
| Rear LH                  |                       |

4. Adjust the tire pressures for all wheels to the specified value. Refer to [WT-81. "Tire"](#).

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

Is ID registrations for all wheels completed?

YES >> ID registration END.

NO >> Performs trouble-diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to [WT-12, "AIR PRESSURE MONITOR : Diagnosis Description"](#).

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

# TPMS


< FUNCTION DIAGNOSIS >

## FUNCTION DIAGNOSIS

### TPMS

#### System Diagram

INFOID:000000004236600



#### System Description

INFOID:000000004236601


#### DISCRIPTION

During driving, the TPMS (Tire Pressure Monitoring System) receives the signal transmitted from transmitter installed in each wheel, when the tire pressure becomes low. The BCM (Body Control Module) of this system has pressure judgment and trouble diagnosis functions. When the tire pressure monitoring system detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

#### TRANSMITTER


A sensor-transmitter (1) integrated with a valve is installed on a wheel (2), and transmits a detected air pressure signal by radio wave.

⇐ : Outside



#### REMOTE KEYLESS ENTRY RECEIVER

The remote keyless entry receiver (tire pressure receiver) (1) receives the air pressure signal transmitted by the transmitter in each wheel.




#### BCM (BODY CONTROL MODULE)



# TPMS


## < FUNCTION DIAGNOSIS >

The BCM (1) reads the air pressure signal received by the remote keyless entry receiver (tire pressure receiver), and controls the low tire pressure warning lamp and the buzzer operations. It also has a judgment function to detect a system malfunction.



### LOW TIRE PRESSURE WARNING LAMP

The combination meter receives tire pressure status from the BCM using CAN communication. When BCM judges from a transmitter signal that tire pressure is insufficient, BCM transmits a signal to combination meter through CAN communication. combination meter turns on the low tire pressure warning lamp mounted on the combination meter.



#### Low tire pressure warning lamp indication


| Condition  | Low tire pressure warning lamp            |
|--|---|
| Less than 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) [NOTE]         | ON  |
| Low tire pressure warning system malfunction [Other diagnostic item] | Warning lamp blinks 1 min, then turns ON. |

NOTE: Standard air pressure is for 230 kPa (2.3 kg/cm<sup>2</sup>, 33 psi) vehicles.

### TIRE PRESSURE WARNING CHECK SWITCH

The following item can be checked by grounding the tire pressure warning check switch (1) harness connector terminal.

- The low tire pressure warning lamp in the combination meter will blink according to the self-diagnostic results.




A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TPMS

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:000000004236602



- |   |                                    |   |
|---|------------------------------------|---|
| 1. Transmitter                          | 2. BCM                             | 3. Remote keyless entry receiver (Tire pressure receiver) |
| 4. Tire pressure warning check switch   | 5. Low tire pressure warning lamp  |   |
| A. Wheel                                | B. Behind glove box cover assembly | C. Behind glove box cover assembly                        |
| D. Behind instrument driver lower cover | E. Inside combination meter        |   |

## Component Description

INFOID:000000004236603

| Component parts  | Function   |
|--|--|
| BCM (Body Control Module)                              | <a href="#">BCS-7, "System Description"</a> .  |
| Transmitter  | <a href="#">WT-17, "Description"</a> .   |
| Remote keyless entry receiver (Tire pressure receiver) | <a href="#">WT-33, "Description"</a> .   |
| Tire pressure warning check switch                     | <a href="#">WT-35, "Description"</a> .   |
| Turn signal lamp                                       | ID registration of each wheel has been completed, turn signal lamp flashes.                      |
| Combination meter                                      | Controls a low tire pressure warning lamp, turn signal lamp, and buzzer by signals from the BCM. |
| Low tire pressure warning lamp                         | Illuminates if malfunction is detected in electrical system of TPMS.                             |

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000004236604

### APPLICATION ITEM

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

| Diagnosis mode           | Function description  |
|--------------------------|---|
| ECU Identification       | BCM part number is displayed.   |
| Self-Diagnostic Result   | Displays the diagnosis results judged by BCM. Refer to <a href="#">BCS-63, "DTC Index"</a> .  |
| Data Monitor             | BCM input/output signals are displayed.   |
| Active Test              | The signals used to activate each device are forcibly supplied from BCM.  |
| Work Support             | Changes the setting for each system function.   |
| Configuration            | <ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul> |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from BCM.   |

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

| System                               | CONSULT-III sub system selection item | Diagnosis mode |              |             |
|--------------------------------------|---------------------------------------|----------------|--------------|-------------|
|                                      |                                       | Work Support   | Data Monitor | Active Test |
| Door lock                            | DOOR LOCK                             | x              | x            | x           |
| Rear window defogger                 | REAR DEFOGGER                         |                | x            | x           |
| Warning chime                        | BUZZER                                |                | x            | x           |
| Interior room lamp control           | INT LAMP                              | x              | x            | x           |
| Remote keyless entry system          | MULTI REMOTE ENT                      | x              | x            | x           |
| Exterior lamp                        | HEAD LAMP                             | x              | x            | x           |
| Wiper and washer                     | WIPER                                 | x              | x            | x           |
| Turn signal and hazard warning lamps | FLASHER                               |                | x            | x           |
| Air conditioner                      | AIR CONDITONER                        |                | x            |             |
| Intelligent Key system               | INTELLIGENT KEY                       |                | x            |             |
| Combination switch                   | COMB SW                               |                | x            |             |
| —                                    | BCM                                   | x              |              |             |
| Immobilizer                          | IMMU                                  |                | x            | x           |
| Interior room lamp battery saver     | BATTERY SAVER                         | x              | x            | x           |
| Back door open                       | TRUNK                                 |                | x            | x           |
| Vehicle security system              | THEFT ALM                             | x              | x            | x           |
| RAP system                           | RETAINED PWR                          | x              | x            | x           |
| Signal buffer system                 | SIGNAL BUFFER                         |                | x            | x           |
| —                                    | FUEL LID*                             |                |              |             |
| TPMS                                 | TPMS (AIR PRESSURE MONITOR)           | x              | x            | x           |
| Panic alarm system                   | PANIC ALARM                           |                |              | x           |

\*: This item is displayed, but is not function.

## AIR PRESSURE MONITOR

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

## AIR PRESSURE MONITOR : Diagnosis Description

INFOID:00000004236605

### DESCRIPTION

During driving, the TPMS receives the signal transmitted from the transmitter installed in each wheel, when the tire pressure becomes low. The control unit (BCM) of this system has pressure judgment and trouble diagnosis functions.

When the TPMS detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

### SELF DIAGNOSTIC PROCEDURE (WITH CONSULT-III)


④ With CONSULT-III

Touch "SELF-DIAG RESULT" display shows malfunction experienced since the last erasing operation. Refer to [WT-60, "DTC Index"](#).

### SELF DIAGNOSTIC PROCEDURE (WITHOUT CONSULT-III)

⊗ Without CONSULT-III

To start the self-diagnostic results mode, ground terminal of the tire pressure warning check connector. The malfunction location is indicated by the low tire pressure warning lamp blinking.



### NOTE:

When the low tire pressure warning lamp blinks 5 Hz and continues repeating it, the system is normal.

| Blinking pattern | Items                                 | Diagnostic items detected when...   | Check item            |
|------------------|---------------------------------------|---|-----------------------|
| 15               | Tire pressure value (Front LH)        | Front LH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE] | -                     |
| 16               | Tire pressure value (Front RH)        | Front RH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE] |                       |
| 17               | Tire pressure value (Rear RH)         | Rear RH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE]  |                       |
| 18               | Tire pressure value (Rear LH)         | Rear LH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE]  |                       |
| 21               | Transmitter no data (Front LH)        | Data from front LH transmitter can not be receive.  | <a href="#">WT-17</a> |
| 22               | Transmitter no data (Front RH)        | Data from front RH transmitter can not be receive.  |                       |
| 23               | Transmitter no data (Rear RH)         | Data from Rear RH transmitter can not be receive.   |                       |
| 24               | Transmitter no data (Rear LH)         | Data from Rear LH transmitter can not be receive.   |                       |
| 31               | Transmitter checksum error (Front LH) | Checksum data from front LH transmitter is malfunctioning.                                  | <a href="#">WT-20</a> |
| 32               | Transmitter checksum error (Front RH) | Checksum data from front RH transmitter is malfunctioning.                                  |                       |
| 33               | Transmitter checksum error (Rear RH)  | Checksum data from rear RH transmitter is malfunctioning.                                   |                       |
| 34               | Transmitter checksum error (Rear LH)  | Checksum data from rear LH transmitter is malfunctioning.                                   |                       |

# DIAGNOSIS SYSTEM (BCM)

## < FUNCTION DIAGNOSIS >

| Blinking pattern | Items                                      | Diagnostic items detected when...                            | Check item             |
|------------------|--|--|------------------------|
| 35               | Transmitter pressure data error (Front LH) | Air pressure data from front LH transmitter is malfunction.  |                        |
| 36               | Transmitter pressure data error (Front RH) | Air pressure data from front RH transmitter is malfunction.  | <a href="#">WT-23</a>  |
| 37               | Transmitter pressure data error (Rear RH)  | Air pressure data from rear RH transmitter is malfunction.   |                        |
| 38               | Transmitter pressure data error (Rear LH)  | Air pressure data from rear LH transmitter is malfunction.   |                        |
| 41               | Transmitter function code error (Front LH) | Function code data from front LH transmitter is malfunction. |                        |
| 42               | Transmitter function code error (Front RH) | Function code data from front RH transmitter is malfunction. | <a href="#">WT-25</a>  |
| 43               | Transmitter function code error (Rear RH)  | Function code data from rear RH transmitter is malfunction.  |                        |
| 44               | Transmitter function code error (Rear LH)  | Function code data from rear LH transmitter is malfunction.  |                        |
| 45               | Transmitter battery voltage low (Front LH) | Battery voltage of front LH transmitter drops.               | <a href="#">WT-28</a>  |
| 46               | Transmitter battery voltage low (Front RH) | Battery voltage of front RH transmitter drops.               |                        |
| 47               | Transmitter battery voltage low (Rear RH)  | Battery voltage of rear RH transmitter drops.                |                        |
| 48               | Transmitter battery voltage low (Rear LH)  | Battery voltage of rear LH transmitter drops.                |                        |
| 52               | Vehicle speed signal error                 | Speed signal is not detected.                                | <a href="#">WT-31</a>  |
| 54               | Ignition line                              | BCM ignition line is malfunction.                            | <a href="#">BCS-36</a> |
| No blinking      | Tire pressure warning check switch         | Tire pressure warning switch circuit is open.                | -                      |

NOTE: Standard air pressure is for 230 kPa (2.3 kg/cm<sup>2</sup>,33 psi) vehicles

## ERASE SELF-DIAGNOSIS

### With CONSULT-III

1. Perform applicable inspection of malfunctioning item and then repair or replace.
2. Turn ignition switch "ON" and select "SELF-DIAG RESULTS" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Touch "ERASE" on CONSULT-III screen to erase memory.

### Without CONSULT-III

- In order to make it easier to find the cause of hard-to-duplicate malfunctions, malfunction information is stored into the control unit as necessary during use by the user. This memory is not erased no matter how many times the ignition switch is turned "ON" and "OFF".
- However, this information is erased by turning ignition switch "OFF" after performing self-diagnostic or by erasing the memory using the CONSULT-III.

## AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONITOR)

INFOID:000000004236606

## WORK SUPPORT MODE

### ID Read

The registered ID number is displayed.

### ID Regist

Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

## DIAGNOSIS SYSTEM (BCM)

### < FUNCTION DIAGNOSIS >

#### SELF-DIAG RESULTS MODE

Operation Procedure

Refer to [WT-60. "DTC Index"](#).

#### DATA MONITOR MODE

Screen of data monitor mode is displayed.

**NOTE:**

When malfunction is detected, CONSULT-III perform REAL-TIME DIAGNOSIS.

Also, any malfunction detected while in this mode will be displayed at real time.

Display item list

| Monitor  | Condition  | Specification  |
|--|--|--|
| VEHICLE SPEED  | Drive vehicle  | Vehicle speed (km/h or MPH)  |
| AIR PRESS FL<br>AIR PRESS FR<br>AIR PRESS RR<br>AIR PRESS RL | <ul style="list-style-type: none"> <li>• Drive vehicle for a few minutes.</li> <li style="text-align: center;">or</li> <li>• Ignition switch ON and transmitter activation tool is transmitting activation signals.</li> </ul> | Tire pressure (kPa or Psi)   |
| ID REGST FL<br>ID REGST FR<br>ID REGST RR<br>ID REGST RL     | Ignition switch ON   | Registration ID: Done<br>No registration: Yet                                    |
| WARNING LAMP   |  | Low tire pressure warning lamp ON: On<br>Low tire pressure warning lamp OFF: Off |
| BUZZER   |  | Buzzer in combination meter ON: On<br>Buzzer in combination meter OFF: Off       |

**NOTE:**

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction location may be different from that displayed on CONSULT-III.

#### ACTIVE TEST MODE

**NOTE:**

Before performing the self-diagnosis, be sure to register the ID, or erase the actual malfunction may be different from that displayed on CONSULT-III.

#### TEST ITEM LIST

| Test item         | Content  |
|-------------------|--|
| WARNING LAMP      | This test is able to check to check that the low tire pressure warning lamp turns on.                      |
| ID REGIST WARNING | This test is able to check to check that the buzzer sounds or the low tire pressure warning lamp turns on. |
| FLAT TIRE WARNING | This test is able to check to check that the buzzer sounds.  |
| HORN              | This test is able to check to check that the horn sounds.  |
| FLASHER           | This test is able to check to check that each turn signal lamp turns on.                                   |
| RUNFLAT TIRE W/L  | <b>NOTE:</b><br>This item is displayed, but cannot be use this item.                                       |

# C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< COMPONENT DIAGNOSIS >

## COMPONENT DIAGNOSIS

### C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

#### Description

INFOID:000000004236607

When the tire pressure monitoring system detects low inflation pressure, the low tire pressure warning lamps in the combination meter comes on.

#### DTC Logic

INFOID:000000004236608

#### DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition   | Possible cause       |
|------------|------------------------|---|----------------------|
| C1704      | LOW PRESSURE FL        | Front LH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE] | Tire pressure is low |
| C1705      | LOW PRESSURE FR        | Front RH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE] |                      |
| C1706      | LOW PRESSURE RR        | Rear RH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE]  |                      |
| C1707      | LOW PRESSURE RL        | Rear LH tire pressure drops to 182.7 kPa (1.9 kg/cm <sup>2</sup> , 26 psi) or less. [NOTE]  |                      |

NOTE: Standard air pressure is for 230 kPa (2.3 kg/cm<sup>2</sup>, 33 psi) vehicles.

#### DTC CONFIRMATION PROCEDURE

##### 1. CHECK ID REGISTRATION AND VEHICLE DRIVING

 With CONSULT-III

Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [WT-15, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000004236609

##### 1. ADJUST TIRE AIR PRESSURE

1. Adjust all tire air pressures. Refer to [WT-81, "Tire"](#).

2. Check all tire air pressures.

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or replace the tire or wheels and adjust the tire pressure to the specification.

##### 2. CHECK AIR PRESSURE SIGNAL

Drive at a speed of 40 km/h (25 MPH) or more 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

## C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

### < COMPONENT DIAGNOSIS >

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Inspect or replace the tire or wheels. Refer to [WT-73, "Service Notice or Precautions"](#).



# C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< COMPONENT DIAGNOSIS >

## C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

### Description

INFOID:000000004236610

A sensor-transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

### DTC Logic

INFOID:000000004236611

### DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition                         | Possible cause  |
|------------|------------------------|---|---|
| C1708      | [NO DATA] FL           | Data from front-LH transmitter can not receive. | <ul style="list-style-type: none"> <li>• Harness or connector (Remote keyless entry receiver, BCM)</li> <li>• ID registration is not finished</li> <li>• Transmitter malfunction</li> </ul> |
| C1709      | [NO DATA] FR           | Data from front-RH transmitter can not receive. |   |
| C1710      | [NO DATA] RR           | Data from rear-RH transmitter can not receive.  |   |
| C1711      | [NO DATA] RL           | Data from rear-LH transmitter can not receive.  |   |

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK ID REGISTRATION AND VEHICLE DRIVING

Ⓜ With CONSULT-III

1. Perform ID registration of all transmitters. Refer to [WT-5. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [WT-17. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004236612

#### 1. CHECK AIR PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Start the engine
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", "AIR PRESS RL".

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Are all tire pressures displayed 0 kPa?

YES >> GO TO 2.

NO >> GO TO 4.

#### 2. CHECK HARNESS BETWEEN BCM AND REMOTE KEYLESS ENTRY RECEIVER

1. Turn the ignition switch "OFF".

## C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

### < COMPONENT DIAGNOSIS >

2. Disconnect BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.
3. Check continuity between BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.

| BCM       |          | Remote keyless entry receiver<br>(Tire pressure receiver) |          | Continuity |
|-----------|----------|---|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| M65       | 18       | M91   | 1        | Existed    |
|           | 19       |   | 4        |            |
|           | 20       |   | 2        |            |

Also check harness for short to ground and short to power.

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace damaged parts.

### 3.CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver (tire pressure receiver). Refer to [WT-33, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damage parts.  
NO >> Replace the remote keyless entry receiver (tire pressure receiver).

### 4.CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

#### Can ID registration of all transmitters be completed?

- YES >> GO TO 5.  
NO >> Replace malfunctioning transmitter, then GO TO 6.

### 5.CHECK TIRE PRESSURE MONITORING SYSTEM

Ⓟ With CONSULT-III

1. Drive at a speed 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed becomes 17 km/h (11 MPH).

#### Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END  
NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

### 6.CHECK ID REGISTRATION

Ⓟ With CONSULT-III

1. Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

#### Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END  
NO >> Perform the self-diagnosis, inspect detected malfunction.

### Special Repair Requirement

INFOID:000000004236613

### 1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-81, "Tire"](#).

#### Does all tire pressure data meet the specification?

- YES >> GO TO 2.

## C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

### < COMPONENT DIAGNOSIS >

---

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

### 2. PERFORM ID REGISTRATION

---

Perform ID registration. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

# C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

< COMPONENT DIAGNOSIS >

## C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

### Description

INFOID:000000004236614

A sensor-transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

### DTC Logic

INFOID:000000004236615

### DTC DETECTION LOGIC

| DTC   | Trouble diagnosis name | DTC detecting condition                                 | Possible case  |
|-------|------------------------|---|--|
| C1712 | [CHECKSUM ERR] FL      | Checksum data from front-LH transmitter is malfunction. | • Remote keyless entry receiver (Tire pressure receiver) malfunction<br>• Transmitter malfunction<br>• BCM malfunction |
| C1713 | [CHECKSUM ERR] FR      | Checksum data from front-RH transmitter is malfunction. |  |
| C1714 | [CHECKSUM ERR] RR      | Checksum data from rear-RH transmitter is malfunction.  |  |
| C1715 | [CHECKSUM ERR] RL      | Checksum data from rear-LH transmitter is malfunction.  |  |

### DTC CONFIRMATION PROCEDURE

#### 1. VEHICLE DRIVING

ⓐ With CONSULT-III

1. Driving at a speed 40 km/h (25 MPH) or more for 3 minutes, and then driving the vehicle at any speed for 10 minutes.
2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [WT-20, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004236616

#### 1. CHECK ID REGISTRATION

ⓐ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 2.

#### 2. CHECK AIR PRESSURE SIGNAL

ⓐ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

# C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

## < COMPONENT DIAGNOSIS >

| Monitored item | Condition   | Display value  |
|----------------|---|--|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display |
| AIR PRESS FR   |   |  |
| AIR PRESS RR   |   |  |
| AIR PRESS RL   |   |  |

Are all tire pressures displayed 0 kPa?

YES >> GO TO 3.

NO >> GO TO 5.

### 3.CHECK HARNESS BETWEEN BCM AND REMOTE KEYLESS ENTRY RECEIVER

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.
3. Check continuity between BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.

| BCM       |          | Remote keyless entry receiver<br>(Tire pressure receiver) |          | Continuity |
|-----------|----------|---|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| M65       | 18       | M91   | 1        | Existed    |
|           | 19       |   | 4        |            |
|           | 20       |   | 2        |            |

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

### 4.CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver (tire pressure receiver). Refer to [WT-33. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

NO >> Replace the remote keyless entry receiver (tire pressure receiver).

### 5.CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-5. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 7 after malfunctioning transmitter replacement.

### 6.CHECK TIRE PRESSURE MONITORING SYSTEM

ⓂWith CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed becomes 17 km/h (11 MPH).

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Replace BCM. Refer to [BCS-67. "Removal and Installation"](#).

### 7.CHECK ID REGISTRATION

ⓂWith CONSULT-III

## C1712, C1713, C1714, C1715 TRANSMITTER (CHECKSUM)

### < COMPONENT DIAGNOSIS >

1. Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END  
NO >> GO TO 2.

### Special Repair Requirement

INFOID:000000004236617

#### 1. CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-81, "Tire"](#).

Does all tire pressure data meet the specification?

- YES >> GO TO 2.  
NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

#### 2. PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

- YES >> END  
NO >> GO TO 1.

# C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

< COMPONENT DIAGNOSIS >

## C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

### Description

INFOID:000000004236618

A sensor-transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

### DTC Logic

INFOID:000000004236619

### DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition                                 | Possible case  |
|------------|------------------------|---|--|
| C1716      | [PRESSDATA ERR] FL     | Air pressure data from front-LH transmitter malfunction | <ul style="list-style-type: none"> <li>ID registration is not finished</li> <li>Transmitter malfunction</li> </ul> |
| C1717      | [PRESSDATA ERR] FR     | Air pressure data from front-RH transmitter malfunction |  |
| C1718      | [PRESSDATA ERR] RR     | Air pressure data from rear-RH transmitter malfunction  |  |
| C1719      | [PRESSDATA ERR] RL     | Air pressure data from rear-LH transmitter malfunction  |  |

### DTC CONFIRMATION PROCEDURE

#### 1. VEHICLE DRIVING

Ⓜ With CONSULT-III

1. Drive at a speed 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition  | Display value   |
|----------------|--|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |  |   |
| AIR PRESS RR   |  |   |
| AIR PRESS RL   |  |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to Diagnosis procedure. Refer to [WT-23, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004236620

#### 1. CHECK TIRE PRESSURE

Ⓜ With CONSULT-III

1. Adjust tire pressure to specified value. Refer to [WT-81, "Tire"](#).
2. Perform the ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
3. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
4. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FL   |   |   |
| AIR PRESS FL   |   |   |
| AIR PRESS FL   |   |   |

Is tire pressure indicated as 438.60 kPa (4.47kg/cm<sup>2</sup>, 63.60 psi) on the "DATA MONITOR" screen?

YES >> Replace malfunctioning transmitter.

NO >> GO TO 2.

# C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

< COMPONENT DIAGNOSIS >

---

## 2. CHECK TIRE PRESSURE MONITORING SYSTEM

---

④ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Perform the self-diagnosis, inspect detected malfunction. Refer to [WT-12, "AIR PRESSURE MONITOR : Diagnosis Description"](#).

## Component Inspection

INFOID:000000004236621

### 1. CHECK TRANSMITTER

---

④ With CONSULT-III

1. Adjust tire pressure to specified value. Refer to [WT-81, "Tire"](#).
2. Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
3. Drive at a 40 km/h (25 MPH) or more for several minutes without stopping.
4. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

Is tire pressure indicated as 438.60 kPa (4.47 kg/cm<sup>2</sup>, 63.60 psi) on the "DATA MONITOR" screen?

YES >> Replace malfunctioning transmitter.

NO >> Check BCM and remote keyless entry receiver (tire pressure receiver).

## Special Repair Requirement

INFOID:000000004236622

### 1. CHECK TIRE AIR PRESSURE

---

Check all tire air pressures. Refer to [WT-81, "Tire"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

### 2. PERFORM ID REGISTRATION

---

Perform ID registration. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.



# C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

< COMPONENT DIAGNOSIS >

## C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

### Description

INFOID:000000004236623

A sensor-transmitter integrated with a valve is installed on a wheel, and detected air pressure signal by radio wave.

### DTC Logic

INFOID:000000004236624

### DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition                                      | Possible case  |
|------------|------------------------|--|--|
| C1720      | [CODE ERR] FL          | function code data from front-LH transmitter is malfunction. | <ul style="list-style-type: none"><li>• Remote keyless entry receiver (Tire pressure receiver) malfunction</li><li>• Transmitter malfunction</li><li>• BCM malfunction</li></ul> |
| C1721      | [CODE ERR] FR          | function code data from front-RH transmitter is malfunction. |  |
| C1722      | [CODE ERR] RR          | function code data from rear-RH transmitter is malfunction.  |  |
| C1723      | [CODE ERR] RL          | function code data from rear-LH transmitter is malfunction.  |  |

### DTC CONFIRMATION PROCEDURE

#### 1. VEHICLE DRIVING

Ⓜ With CONSULT-III

1. Driving at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [WT-25. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004236625

#### 1. CHECK ID REGISTRATION

Ⓜ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-5. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 2.

#### 2. CHECK ALL TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSUR MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

# C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

## < COMPONENT DIAGNOSIS >

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Are all tire pressure displayed 0 kPa?

YES >> GO TO 3.

NO >> GO TO 5.

### 3. CHECK HARNESS BETWEEN BCM AND REMOTE KEYLESS ENTRY RECEIVER

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.
3. Check continuity between BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.

| BCM       |          | Remote keyless entry receiver<br>(Tire pressure receiver) |          | Continuity |
|-----------|----------|---|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| M65       | 18       | M91   | 1        | Existed    |
|           | 19       |   | 4        |            |
|           | 20       |   | 2        |            |

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damage parts.

### 4. CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver (tire pressure receiver). Refer to [WT-33, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

NO >> Replace the remote keyless entry receiver (tire pressure receiver).

### 5. CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 7 after malfunctioning transmitter replacement.

### 6. CHECK TIRE PRESSURE MONITORING SYSTEM

Ⓟ With CONSULT-III

1. Drive at a speed of 40 km/h (25 MPH) or more for several minutes without stopping.
2. Check all tire pressures with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed become 17 km/h (11 MPH).

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END.

NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

### 7. CHECK ID REGISTRATION

Ⓟ With CONSULT-III

1. Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

# C1720, C1721, C1722, C1723 TRANSMITTER (CODE)

## < COMPONENT DIAGNOSIS >

2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END.

NO >> GO TO 2.

## Special Repair Requirement

INFOID:000000004236626

### 1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-81, "Tire"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

### 2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WT

# C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

< COMPONENT DIAGNOSIS >

## C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

### Description

INFOID:000000004236627

A sensor -transmitter integrated with a valve is installed on a wheel, and transmits a detected air pressure signal by radio wave.

### DTC Logic

INFOID:000000004236628

### DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition                        | Possible case  |
|------------|------------------------|--|--|
| C1724      | [BATT VOLT LOW] FL     | Battery voltage of front-LH transmitter drops. | <ul style="list-style-type: none"><li>• Transmitter malfunction</li><li>• Remote keyless entry receiver (Tire pressure receiver) malfunction</li><li>• BCM malfunction</li></ul> |
| C1725      | [BATT VOLT LOW] FR     | Battery voltage of front-RH transmitter drops. |  |
| C1726      | [BATT VOLT LOW] RR     | Battery voltage of rear-RH transmitter drops.  |  |
| C1727      | [BATT VOLT LOW] RL     | Battery voltage of rear-LH transmitter drops.  |  |

### DTC CONFIRMATION PROCEDURE

#### 1.VEHICLE DRIVING

Ⓜ With CONSULT-III

Driving at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed 10minutes. Then check all tire pressure with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FL   |   |   |
| AIR PRESS FL   |   |   |
| AIR PRESS FL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [WT-28, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004236629

#### 1.CHECK ID REGISTRATION

Ⓜ With CONSULT-III

1. Perform the ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 2.

#### 2.CHECK AIR PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Start the engine.
2. Select "DATA MONITOR" mode for "AIR PRESSURE MONITOR" with CONSULT-III.
3. Read out the value of "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".

# C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

## < COMPONENT DIAGNOSIS >

| Monitored item | Condition   | Display value  |
|----------------|---|--|
| AIR PRESS FL   | Start the engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display |
| AIR PRESS FR   |   |  |
| AIR PRESS RR   |   |  |
| AIR PRESS RL   |   |  |

Are all tire pressures displayed 0 kPa?

YES >> GO TO 3.

NO >> GO TO 5.

### 3. CHECK HARNESS BETWEEN BCM AND TIRE PRESSURE RECEIVER

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.
3. Check continuity between BCM harness connector and remote keyless entry receiver (tire pressure receiver) harness connector.

| BCM       |          | Remote keyless entry receiver<br>(Tire pressure receiver) |          | Continuity |
|-----------|----------|---|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| M65       | 18       | M91   | 1        | Existed    |
|           | 19       |   | 4        |            |
|           | 20       |   | 2        |            |

Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

### 4. CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver (tire pressure receiver). Refer to [WT-33, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damage parts.

NO >> Replace the remote keyless entry receiver (tire pressure receiver).

### 5. CHECK ID REGISTRATION

Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> GO TO 6.

NO >> GO TO 7 after malfunctioning transmitter replacement.

### 6. CHECK TIRE PRESSURE MONITORING SYSTEM

Ⓜ With CONSULT-III

1. Drive at a speed for 40 km/h (25 MPH) or more several minutes without stopping.
2. Check all tire pressure with CONSULT-III "DATA MONITOR" within 15 minutes after vehicle speed becomes 17 km/h (11 MPH).

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

### 7. CHECK ID REGISTRATION

Ⓜ With CONSULT-III

1. Perform ID registration of all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

## C1724, C1725, C1726, C1727 TRANSMITTER (BATT VOLT)

### < COMPONENT DIAGNOSIS >

---

2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

YES >> INSPECTION END

NO >> GO TO 2.

### Special Repair Requirement

INFOID:000000004236630

#### 1.CHECK TIRE AIR PRESSURE

---

Check all tire air pressures. Refer to [WT-81, "Tire"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

#### 2.PERFORM ID REGISTRATION

---

Perform ID registration. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.

# C1729 VEHICLE SPEED SIG ERR

< COMPONENT DIAGNOSIS >

## C1729 VEHICLE SPEED SIG ERR

### Description

INFOID:000000004236631

BCM detects no vehicle speed signal.

### DTC Logic

INFOID:000000004236632

### DTC DETECTION LOGIC

| DTC number | Trouble diagnosis name | DTC detecting condition              | Possible case  |
|------------|------------------------|--------------------------------------|--|
| C1729      | VHCL SPEED SIG ERR     | Vehicle speed signal is not detected | <ul style="list-style-type: none"><li>CAN communication error</li><li>Combination meter malfunction</li></ul> Refer to <a href="#">MWI-38, "Diagnosis Procedure"</a> |

### DTC CONFIRMATION PROCEDURE

#### 1.VEHICLE DRIVING

 With CONSULT-III

Drive at speed 40 km/h (25 MPH) or more for several minutes without stopping.

Does "DATA MONITOR" displayed the standardized value without turning low pressure warning lamp ON?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [WT-31, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000004236633

#### 1.CHECK SELF-DIAGNOSTIC RESULTS

 With CONSULT-III

1. On "SELECT DIAG MODE", select the "SELF-DIAG RESULT" screen.

2. Check display contents in self-diagnostic results.

Is the "CAN COMM CIRCUIT" displayed in the self-diagnosis display?

YES >> Perform trouble diagnosis for CAN communication system. Refer to [LAN-24, "CAN System Specification Chart"](#).

NO >> Check combination meter. Refer to [MWI-38, "Diagnosis Procedure"](#).

### Special Repair Requirement

INFOID:000000004236634

#### 1.CHECK TIRE AIR PRESSURE

Check all tire air pressures. Refer to [WT-81, "Tire"](#).

Does all tire pressure data meet the specification?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels and adjust the tire pressure to the specification.

#### 2.PERFORM ID REGISTRATION

Perform ID registration. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

YES >> END

NO >> GO TO 1.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000004236635

### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

| Signal name           | Fuses and fusible link No. |
|-----------------------|----------------------------|
| Battery power supply  | 10                         |
|                       | J                          |
| ACC power supply      | 20                         |
| Ignition power supply | 1                          |

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and the ground.

| BCM       |          | —      | Ignition switch position |                 |                 |
|-----------|----------|--------|--------------------------|-----------------|-----------------|
| Connector | Terminal |        | OFF                      | ACC             | ON              |
| M67       | 70       | Ground | Battery voltage          | Battery voltage | Battery voltage |
|           | 57       |        | Approx. 0 V              | Battery voltage | Battery voltage |
| M65       | 11       |        | Approx. 0 V              | Approx. 0 V     | Battery voltage |
|           | 38       |        |                          |                 |                 |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and the ground.

| BCM       |          | —      | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M67       | 67       | Ground | Existed    |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair the harness or connector.



# REMOTE KEYLESS ENTRY RECEIVER

< COMPONENT DIAGNOSIS >

## REMOTE KEYLESS ENTRY RECEIVER

### Description

INFOID:000000004236638

The remote keyless entry receiver (tire pressure receiver) receives the air pressure signal transmitted by the transmitter in each wheel.

### Diagnosis Procedure

INFOID:000000004236639

#### 1. CHECK REMOTE KEYLESS ENTRY RECEIVER (TIRE PRESSURE RECEIVER)

1. Turn the ignition OFF.
2. Check remote keyless entry receiver (tire pressure receiver) connector M91 terminal 2 and ground signal with oscilloscope.

| remote keyless entry receiver<br>(Tire pressure receiver) |          | —      | Condition                              | Voltage (Approx.) |
|---|----------|--------|--|-------------------|
| Connector   | Terminal |        |  |                   |
| M91   | 2        | Ground | Standby state                          |                   |
|   |          |        | When receiving signal from transmitter |                   |

Is the reference signal inputted?

- YES >> INSPECTION END  
 NO >> GO TO 2.

#### 2. CHECK REMOTE KEYLESS ENTRY RECEIVER (TIRE PRESSURE RECEIVER) INPUT VOLTAGE

1. Disconnect remote keyless entry receiver (tire pressure receiver) connector.
2. Check voltage between remote keyless entry receiver (tire pressure receiver) connector M91 terminal 4 and ground.

| remote keyless entry receiver (Tire pressure receiver) |          | —      | Voltage (Approx.) |
|--|----------|--------|-------------------|
| Connector  | Terminal |        |                   |
| M91  | 4        | Ground | 5.0 V             |

Is the reference voltage inputted?

- YES >> GO TO 3.  
 NO >> Check BCM harness and connector.

#### 3. CHECK REMOTE KEYLESS ENTRY RECEIVER (TIRE PRESSURE RECEIVER) GROUND CIRCUIT

1. Disconnect BCM harness connector and remote keyless entry receiver (tire pressure receiver) connector.
2. Check continuity between BCM harness connector M65 terminal 18 and remote keyless entry receiver (tire pressure receiver) connector M91 terminal 1.

# REMOTE KEYLESS ENTRY RECEIVER

## < COMPONENT DIAGNOSIS >

| BCM       |          | Remote keyless entry receiver<br>(Tire pressure receiver) |          | Continuity |
|-----------|----------|---|----------|------------|
| Connector | Terminal | Connector   | Terminal |            |
| M65       | 18       | M91   | 1        | Existed    |

Also check harness for short to ground.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

### **4.**CHECK BCM CIRCUIT

Inspect the BCM circuit. Refer to [BCS-37. "Diagnosis Procedure"](#).

Is the BCM circuit normal?

YES >> Replace remote keyless entry receiver (tire pressure receiver).

NO >> Repair or replace BCM circuit. Replace BCM. Refer to [BCS-67. "Removal and Installation"](#).

# TIRE PRESSURE WARNING CHECK SWITCH

< COMPONENT DIAGNOSIS >

## TIRE PRESSURE WARNING CHECK SWITCH

### Description

INFOID:000000004236640


The following item can be checked by grounding the tire pressure warning check switch harness connector terminal.

- The low tire pressure warning lamp in the combination meter blink according to the self-diagnostic results.

#### NOTE:

If low tire pressure warning lamp blinks below, the system is normal.

- This mode shows transmitter status is in OFF-mode.  
Perform transmitter wake up operation. Refer to [WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"](#).



### Diagnosis Procedure

INFOID:000000004236641

#### 1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

1. Turn the ignition switch "OFF".
2. Check signal between tire pressure warning check switch connector M92 terminal 1 and ground with oscilloscope.

| Tire pressure warning check switch |          | —      | Condition           | Voltage (Approx.) |
|------------------------------------|----------|--------|---------------------|-------------------|
| Connector                          | Terminal |        |                     |                   |
| M92                                | 1        | Ground | Ignition switch OFF | <p>1.5 V</p>      |

Is the reference voltage outputted?

- YES >> Repair or replace BCM circuit. Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

1. Disconnect BCM harness connector
2. Check continuity between BCM harness connector M65 terminal 15 and tire pressure warning check switch connector M92 terminal 1.
3. Check harness for short to ground.

| BCM       |          | Tire pressure warning check switch |          | Continuity |
|-----------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector                          | Terminal |            |
| M65       | 15       | M92                                | 1        | Existed    |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace damaged parts.

#### 3. CHECK BCM

## TIRE PRESSURE WARNING CHECK SWITCH

### < COMPONENT DIAGNOSIS >

---

Check BCM input/output signal. Refer to [WT-40, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check BCM pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts. Replace BCM Refer to [BCS-67, "Removal and Installation"](#).

# TPMS

< COMPONENT DIAGNOSIS >

## TPMS

### Description

INFOID:000000004236636

During driving, the TPMS receives the signal transmitted from the transmitter installed in each wheel, when the tire pressure becomes low. The control unit (BCM) of this system has pressure judgment and trouble diagnosis functions.

When the TPMS detects low inflation pressure or another unusual symptom, the low tire pressure warning lamps in the combination meter comes on.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**WT**


# TPMS

< COMPONENT DIAGNOSIS >

## Wiring Diagram - TIRE PRESSURE MONITORING SYSTEM -

INFOID:000000004236637

### TIRE PRESSURE MONITORING SYSTEM



2008/07/15

JCEWM0069Gf



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000004513738

#### VALUES ON THE DIAGNOSIS TOOL

| Monitor Item   | Condition   | Value/Status |
|----------------|---|--------------|
| IGN ON SW      | Ignition switch OFF or ACC  | Off          |
|                | Ignition switch ON  | On           |
| KEY ON SW      | Mechanical key is removed from key cylinder                               | Off          |
|                | Mechanical key is inserted to key cylinder                                | On           |
| CDL LOCK SW    | Door lock/unlock switch does not operate                                  | Off          |
|                | Press door lock/unlock switch to the lock side                            | On           |
| CDL UNLOCK SW  | Door lock/unlock switch does not operate                                  | Off          |
|                | Press door lock/unlock switch to the unlock side                          | On           |
| DOOR SW-DR     | Driver's door closed  | Off          |
|                | Driver's door opened  | On           |
| DOOR SW-AS     | Passenger door closed   | Off          |
|                | Passenger door opened   | On           |
| DOOR SW-RR     | Rear RH door closed   | Off          |
|                | Rear RH door opened   | On           |
| DOOR SW-RL     | Rear LH door closed   | Off          |
|                | Rear LH door opened   | On           |
| BACK DOOR SW   | Back door closed  | Off          |
|                | Back door opened  | On           |
| KEY CYL LK-SW  | Other than driver door key cylinder LOCK position                         | Off          |
|                | Driver door key cylinder LOCK position                                    | On           |
| KEY CYL UN-SW  | Other than driver door key cylinder UNLOCK position                       | Off          |
|                | Driver door key cylinder UNLOCK position                                  | On           |
| KEYLESS LOCK   | "LOCK" button of key fob is not pressed                                   | Off          |
|                | "LOCK" button of key fob is pressed                                       | On           |
| KEYLESS UNLOCK | "UNLOCK" button of key fob is not pressed                                 | Off          |
|                | "UNLOCK" button of key fob is pressed                                     | On           |
| I-KEY LOCK     | "LOCK" button of Intelligent Key or door request switch are not pressed   | Off          |
|                | "LOCK" button of Intelligent Key or door request switch are pressed       | On           |
| I-KEY UNLOCK   | "UNLOCK" button of Intelligent Key or door request switch are not pressed | Off          |
|                | "UNLOCK" button of Intelligent Key or door request switch are pressed     | On           |
| ACC ON SW      | Ignition switch OFF   | Off          |
|                | Ignition switch ACC or ON   | On           |
| REAR DEF SW    | Rear window defogger switch OFF   | Off          |
|                | Rear window defogger switch ON  | On           |
| LIGHT SW 1ST   | Lighting switch OFF   | Off          |
|                | Lighting switch 1ST   | On           |



## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

| Monitor Item   | Condition   | Value/Status |    |
|----------------|---|--------------|----|
| BUCKLE SW      | The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF] | Off          | A  |
|                | The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]    | On           | B  |
| KEYLESS PANIC  | PANIC button of key fob is not pressed  | Off          | C  |
|                | PANIC button of key fob is pressed  | On           |    |
| KEYLESS TRUNK  | <b>NOTE:</b><br>The item is indicated, but not monitored.                       | Off          |    |
| TRNK OPN MNTR  | <b>NOTE:</b><br>The item is indicated, but not monitored.                       | Off          | D  |
| RKE LCK-UNLCK  | LOCK/UNLOCK button of key fob is not pressed and held simultaneously            | Off          | WT |
|                | LOCK/UNLOCK button of key fob is pressed and held simultaneously                | On           |    |
| RKE KEEP UNLK  | UNLOCK button of key fob is not pressed   | Off          | F  |
|                | UNLOCK button of key fob is pressed and held                                    | On           |    |
| HI BEAM SW     | Lighting switch OFF   | Off          | G  |
|                | Lighting switch HI  | On           |    |
| HEAD LAMP SW 1 | Lighting switch OFF   | Off          | H  |
|                | Lighting switch 2ND   | On           |    |
| HEAD LAMP SW 2 | Lighting switch OFF   | Off          | I  |
|                | Lighting switch 2ND   | On           |    |
| AUTO LIGHT SW  | <b>NOTE:</b><br>The item is indicated, but not monitored.                       | Off          |    |
| PASSING SW     | Other than lighting switch PASS   | Off          | J  |
|                | Lighting switch PASS  | On           |    |
| FR FOG SW      | Front fog lamp switch OFF   | Off          | K  |
|                | Front fog lamp switch ON  | On           |    |
| RR FOG SW      | <b>NOTE:</b><br>The item is indicated, but not monitored.                       | Off          |    |
| TURN SIGNAL R  | Turn signal switch OFF  | Off          | L  |
|                | Turn signal switch RH   | On           |    |
| TURN SIGNAL L  | Turn signal switch OFF  | Off          | M  |
|                | Turn signal switch LH   | On           |    |
| ENGINE RUN     | Engine stopped  | Off          | N  |
|                | Engine running  | On           |    |
| PKB SW         | Parking brake switch is OFF   | Off          | O  |
|                | Parking brake switch is ON  | On           |    |
| CARGO LAMP SW  | <b>NOTE:</b><br>The item is indicated, but not monitored.                       | Off          |    |
| OPTICAL SENSOR | <b>NOTE:</b><br>The item is indicated, but not monitored.                       | 0 V          | P  |
| IGN SW CAN     | Ignition switch OFF or ACC  | Off          |    |
|                | Ignition switch ON  | On           |    |
| FR WIPER HI    | Front wiper switch OFF  | Off          |    |
|                | Front wiper switch HI   | On           |    |
| FR WIPER LOW   | Front wiper switch OFF  | Off          |    |
|                | Front wiper switch LO   | On           |    |

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

| Monitor Item  | Condition   | Value/Status                      |
|---------------|---|-----------------------------------|
| FR WIPER INT  | Front wiper switch OFF  | Off                               |
|               | Front wiper switch INT  | On                                |
| FR WASHER SW  | Front washer switch OFF   | Off                               |
|               | Front washer switch ON  | On                                |
| INT VOLUME    | Wiper intermittent dial is in a dial position 1 - 7   | 1 - 7                             |
| FR WIPER STOP | Any position other than front wiper stop position   | Off                               |
|               | Front wiper stop position   | On                                |
| VEHICLE SPEED | While driving   | Equivalent to speedometer reading |
| RR WIPER ON   | Rear wiper switch OFF   | Off                               |
|               | Rear wiper switch ON  | On                                |
| RR WIPER INT  | Rear wiper switch OFF   | Off                               |
|               | Rear wiper switch INT   | On                                |
| RR WASHER SW  | Rear washer switch OFF  | Off                               |
|               | Rear washer switch ON   | On                                |
| RR WIPER STOP | Rear wiper stop position  | Off                               |
|               | Other than rear wiper stop position   | On                                |
| RR WIPER STP2 | <b>NOTE:</b><br>The item is indicated, but not monitored.   | Off                               |
| H/L WASH SW   | <b>NOTE:</b><br>The item is indicated, but not monitored.   | Off                               |
| HAZARD SW     | Hazard switch OFF   | Off                               |
|               | Hazard switch ON  | On                                |
| BRAKE SW      | Brake pedal is not depressed  | Off                               |
|               | Brake pedal is depressed  | On                                |
| FAN ON SIG    | Blower fan motor switch OFF   | Off                               |
|               | Blower fan motor switch ON (other than OFF)   | On                                |
| AIR COND SW   | Compressor ON is not requested from auto amp.<br>(A/C indicator OFF, blower fan motor switch OFF or etc.) | Off                               |
|               | Compressor ON is requested from auto amp.<br>(A/C indicator ON and blower fan motor switch ON).           | On                                |
| I-KEY TRUNK   | <b>NOTE:</b><br>The item is indicated, but not monitored.   | Off                               |
| I-KEY PW DWN  | UNLOCK button of Intelligent Key is not pressed   | Off                               |
|               | UNLOCK button of Intelligent Key is pressed and held  | On                                |
| I-KEY PANIC   | PANIC button of Intelligent Key is not pressed  | Off                               |
|               | PANIC button of Intelligent Key is pressed  | On                                |
| PUSH SW       | Return to ignition switch to "LOCK" position  | Off                               |
|               | Press ignition switch   | On                                |
| TRNK OPNR SW  | When back door opener switch is not pressed   | Off                               |
|               | When back door opener switch is pressed   | On                                |
| TRUNK CYL SW  | <b>NOTE:</b><br>The item is indicated, but not monitored.   | Off                               |
| HOOD SW       | Close the hood<br><b>NOTE:</b><br>Vehicles of except for Mexico are OFF-fixed                             | Off                               |
|               | Open the hood   | On                                |

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS >

| Monitor Item | Condition  | Value/Status                  |           |
|--------------|--|-------------------------------|-----------|
| OIL PRESS SW | <ul style="list-style-type: none"> <li>• Ignition switch OFF or ACC</li> <li>• Engine running</li> </ul> | Off                           | A         |
|              | Ignition switch ON   | On                            | B         |
| AIR PRESS FL | Ignition switch ON (Only when the signal from the transmitter is received)                               | Air pressure of front LH tire | C         |
| AIR PRESS FR | Ignition switch ON (Only when the signal from the transmitter is received)                               | Air pressure of front RH tire | D         |
| AIR PRESS RR | Ignition switch ON (Only when the signal from the transmitter is received)                               | Air pressure of rear RH tire  | D         |
| AIR PRESS RL | Ignition switch ON (Only when the signal from the transmitter is received)                               | Air pressure of rear LH tire  | D         |
| ID REGST FL1 | ID of front LH tire transmitter is registered  | Done                          | <b>WT</b> |
|              | ID of front LH tire transmitter is not registered  | Yet                           |           |
| ID REGST FR1 | ID of front RH tire transmitter is registered  | Done                          | F         |
|              | ID of front RH tire transmitter is not registered  | Yet                           |           |
| ID REGST RR1 | ID of rear RH tire transmitter is registered   | Done                          | G         |
|              | ID of rear RH tire transmitter is not registered   | Yet                           |           |
| ID REGST RL1 | ID of rear LH tire transmitter is registered   | Done                          | H         |
|              | ID of rear LH tire transmitter is not registered   | Yet                           |           |
| WARNING LAMP | Tire pressure indicator OFF  | Off                           | I         |
|              | Tire pressure indicator ON   | On                            |           |
| BUZZER       | Tire pressure warning alarm is not sounding  | Off                           | I         |
|              | Tire pressure warning alarm is sounding  | On                            |           |

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## TERMINAL LAYOUT



### PHYSICAL VALUES




**CAUTION:**

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-III. Refer to [BCS-27. "COMB SW : CONSULT-III Function \(BCM - COMB SW\)"](#).
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9. "System Diagram"](#).

| Terminal No.<br>(Wire color) |        | Description                            |                  | Condition                         |           | Value<br>(Approx.)     |
|------------------------------|--------|--|------------------|-----------------------------------|-----------|------------------------|
| +                            | -      | Signal name                            | Input/<br>Output | Ignition key hole<br>illumination | OFF<br>ON | Battery voltage<br>0 V |
| 1<br>(V)                     | Ground | Ignition key hole illumination control | Output           | Ignition key hole illumination    | OFF<br>ON | Battery voltage<br>0 V |

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                   |                  | Condition   | Value<br>(Approx.)       |   |
|------------------------------|--------|-------------------------------|------------------|---|--------------------------|---|
|                              |        | Signal name                   | Input/<br>Output |   |                          |   |
| +                            | -      |                               |                  |   |                          |   |
| 2<br>(G)                     | Ground | Combination switch<br>INPUT 5 | Input            | Combination<br>switch<br>(Wiper intermit-<br>tent dial 4) | All switch OFF           | 0 V   |
|                              |        |                               |                  |   | Turn signal switch RH    |    |
|                              |        |                               |                  |   | Lighting switch HI       |   |
|                              |        |                               |                  |   | Lighting switch 1ST      |   |
|                              |        |                               |                  |   | Lighting switch 2ND      |   |
| 3<br>(Y)                     | Ground | Combination switch<br>INPUT 4 | Input            | Combination<br>switch<br>(Wiper intermit-<br>tent dial 4) | All switch OFF           | 0 V   |
|                              |        |                               |                  |   | Turn signal switch LH    |   |
|                              |        |                               |                  |   | Lighting switch PASS     |   |
|                              |        |                               |                  |   | Lighting switch 2ND      |   |
|                              |        |                               |                  |   | Front fog lamp switch ON |   |
| 4<br>(W)                     | Ground | Combination switch<br>INPUT 3 | Input            | Combination<br>switch<br>(Wiper intermit-<br>tent dial 4) | All switch OFF           | 0 V   |
|                              |        |                               |                  |   | Front wiper switch LO    |  |
|                              |        |                               |                  |   | Front wiper switch MIST  |   |
|                              |        |                               |                  |   | Front wiper switch INT   |   |

A  
B  
C  
D  
**WT**  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                   |                  | Condition             | Value<br>(Approx.)   |   |
|------------------------------|--------|-------------------------------|------------------|-----------------------|--|---|
| +                            | -      | Signal name                   | Input/<br>Output |                       |  |   |
| 5<br>(R)                     | Ground | Combination switch<br>INPUT 2 | Input            | Combination<br>switch | All switch OFF<br>(Wiper intermittent dial 4)  | 0 V   |
|                              |        |                               |                  |                       | Front washer switch<br>(Wiper intermittent dial 4)<br>Rear washer ON<br>(Wiper intermittent dial 4)<br>Any of the condition below<br>with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul> | <br>PKIB4955J<br>1.0 V   |
|                              |        |                               |                  |                       | Rear wiper switch ON<br>(Wiper intermittent dial 4)  | <br>PKIB4955J<br>0.8 V   |
| 6<br>(P)                     | Ground | Combination switch<br>INPUT 1 | Input            | Combination<br>switch | All switch OFF<br>(Wiper intermittent dial 4)  | 0 V   |
|                              |        |                               |                  |                       | Front wiper switch HI<br>(Wiper intermittent dial 4)<br>Rear wiper switch INT<br>(Wiper intermittent dial 4)<br>Wiper intermittent dial 3<br>(All switch OFF)  | <br>PKIB4959J<br>1.0 V  |
|                              |        |                               |                  |                       | Any of the condition below<br>with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> </ul>   | <br>PKIB4952J<br>1.7 V |
|                              |        |                               |                  |                       | Any of the condition below<br>with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>   | <br>PKIB4955J<br>0.8 V |

# BCM (BODY CONTROL MODULE)




## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                               |                  | Condition                             | Value<br>(Approx.)   |
|------------------------------|--------|---|------------------|---------------------------------------|--|
| +                            | -      | Signal name                               | Input/<br>Output |                                       |  |
| 7<br>(L)                     | Ground | Door key cylinder<br>switch UNLOCK signal | Input            | Door key cylinder<br>switch           | NEUTRAL position<br><br><br>8.0 - 8.5 V                         |
|                              |        |   |                  | UNLOCK position                       | 0 V  |
| 8<br>(R)                     | Ground | Door key cylinder<br>switch LOCK signal   | Input            | Door key cylinder<br>switch           | NEUTRAL position<br><br><br>8.0 - 8.5 V                         |
|                              |        |   |                  | LOCK position                         | 0 V  |
| 9<br>(R)                     | Ground | Stop lamp switch                          | Input            | Stop lamp<br>switch                   | OFF (Brake pedal is not<br>depressed) 0 V<br>ON (Brake pedal is de-<br>pressed) Battery voltage  |
|                              |        |   |                  |                                       |  |
| 10<br>(SB)                   | Ground | Rear window defog-<br>ger switch          | Input            | Rear window<br>defogger switch        | Not pressed Battery voltage<br>Pressed 0 V   |
|                              |        |   |                  |                                       |  |
| 11<br>(SB)                   | Ground | Ignition switch ACC                       | Input            | Ignition switch OFF                   | 0 V  |
|                              |        |   |                  | Ignition switch ACC or ON             | Battery voltage  |
| 12<br>(P)                    | Ground | Passenger door<br>switch                  | Input            | Passenger door<br>switch              | OFF<br>(When passenger door<br>closed)<br><br><br>7.5 - 8.0 V |
|                              |        |   |                  | ON<br>(When passenger door<br>opened) | 0 V  |
| 13<br>(LG)                   | Ground | Rear door switch RH                       | Input            | Rear door<br>switch RH                | OFF<br>(When rear door RH<br>closed)<br><br><br>8.0 - 8.5 V   |
|                              |        |   |                  | ON<br>(When rear door RH<br>opened)   | 0 V  |

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)




## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                                |                  | Condition                      |  | Value<br>(Approx.)   |
|------------------------------|--------|--|------------------|--------------------------------|--|--|
|                              |        | Signal name                                | Input/<br>Output |                                |  |  |
| +                            | -      |  |                  |                                |  |  |
| 15*<br>(O)                   | Ground | Tire pressure warning check switch         | Input            | Ignition switch OFF            |  |  <p style="text-align: right; font-size: small;">JPMIA0588GB</p> <p style="text-align: center;">1.5 V</p>   |
| 18*<br>(O)                   | Ground | Remote keyless entry receiver ground       | Input            | Ignition switch ON             |  | 0 V  |
| 19*<br>(V)                   | Ground | Remote keyless entry receiver power supply | Input            | Without Intelligent Key system | At any condition   | 5 V  |
|                              |        |  |                  | With Intelligent Key system    | <ul style="list-style-type: none"> <li>• Ignition switch OFF</li> <li>• For 3 seconds after ignition switch OFF to ON</li> </ul> | 0 V  |
|                              |        |  |                  |                                | 3 seconds or later after ignition switch OFF to ON   | 5 V  |
| 20*<br>(GR)                  | Ground | Remote keyless entry receiver signal       | Input            | Without Intelligent Key system | At any condition   |  <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p><b>NOTE:</b><br/>The wave form changes according to signal-receiving condition.</p>  |
|                              |        |  |                  |                                | <ul style="list-style-type: none"> <li>• Ignition switch OFF</li> <li>• For 3 seconds after ignition switch OFF to ON</li> </ul> | 0 V  |
|                              |        |  |                  | With Intelligent Key system    | 3 seconds or later after ignition switch OFF to ON   |  <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p><b>NOTE:</b><br/>The wave form changes according to signal-receiving condition.</p> |
|                              |        |  |                  |                                |  |  |
| 21<br>(G)                    | Ground | Immobilizer antenna signal (Clock)         | Input/<br>Output | Ignition switch OFF            |  | Battery voltage  |



# BCM (BODY CONTROL MODULE)





## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                              |                  | Condition                         | Value<br>(Approx.)  |   |
|------------------------------|--------|--|------------------|-----------------------------------|---|---|
| +                            | -      | Signal name                              | Input/<br>Output |                                   |   |   |
| 23<br>(B)                    | Ground | Security indicator<br>signal             | Input            | Security indica-<br>tor           | ON  | 0 V   |
|                              |        |  |                  | Blinking (Ignition switch<br>OFF) |  <p style="text-align: right; font-size: small;">JPMIA0590GB</p> | 12.0 V  |
|                              |        |  |                  | OFF                               | Battery voltage   |   |
| 25<br>(BR)                   | Ground | Immobilizer anten-<br>na signal (Rx, Tx) | Input/<br>Output | Ignition switch OFF               | Battery voltage   |   |
| 27<br>(Y)                    | Ground | A/C switch                               | Input            | Ignition switch OFF               |   |   |
|                              |        |  |                  | Ignition switch<br>ON             | A/C switch OFF  |  <p style="text-align: right; font-size: small;">JPMIA0591GB</p>   |
|                              |        |  |                  | A/C switch ON                     | 0 V   |   |
| 28<br>(LG)                   | Ground | Blower fan switch                        | Input            | Ignition switch OFF               |   |   |
|                              |        |  |                  | Ignition switch<br>ON             | Blower fan switch OFF   |  <p style="text-align: right; font-size: small;">JPMIA0592GB</p> |
|                              |        |  |                  | Blower fan switch ON              | 0 V   |   |
| 29<br>(W)                    | Ground | Hazard switch                            | Input            | Hazard switch                     | OFF   | Battery voltage   |
|                              |        |  |                  | ON                                | 0 V   |   |
| 30<br>(G)                    | Ground | Back door opener<br>switch               | Input            | Back door<br>opener switch        | Not pressed   | Battery voltage   |
|                              |        |  |                  | Pressed                           | 0 V   |   |

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color)   |        | Description                    |                  | Condition             | Value<br>(Approx.)                                      |  |
|--|--------|--------------------------------|------------------|-----------------------|---|--|
| +  | -      | Signal name                    | Input/<br>Output |                       |   |  |
| 32<br>(BR)   | Ground | Combination switch<br>OUTPUT 5 | Output           | Combination<br>switch | All switch OFF<br>(Wiper intermittent dial 4)           |  <p style="text-align: right; font-size: small;">PKIB4966J</p> <p style="text-align: center;">7.2 V</p>   |
|  |        |                                |                  |                       | Front fog lamp switch ON<br>(Wiper intermittent dial 4) |  <p style="text-align: right; font-size: small;">PKIB4966J</p> <p style="text-align: center;">1.0 V</p>   |
|  |        |                                |                  |                       | Rear wiper switch ON<br>(Wiper intermittent dial 4)     |  |
| Any of the condition below<br>with all switch OFF  |        |                                |                  |                       |   |  |
| <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul> |        |                                |                  |                       |   |  |
| 33<br>(GR)   | Ground | Combination switch<br>OUTPUT 4 | Output           | Combination<br>switch | All switch OFF<br>(Wiper intermittent dial 4)           |  <p style="text-align: right; font-size: small;">PKIB4966J</p> <p style="text-align: center;">7.2 V</p>  |
|  |        |                                |                  |                       | Lighting switch 1ST<br>(Wiper intermittent dial 4)      |  <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p> |
|  |        |                                |                  |                       | Rear wiper switch INT<br>(Wiper intermittent dial 4)    |  |
| Any of the condition below<br>with all switch OFF  |        |                                |                  |                       |   |  |
| <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>                                      |        |                                |                  |                       |   |  |

# BCM (BODY CONTROL MODULE)




## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color)  |        | Description                    |                  | Condition   | Value<br>(Approx.)                                   |  |
|---|--------|--------------------------------|------------------|---|--|--|
| +   | -      | Signal name                    | Input/<br>Output |   |  |  |
| 34<br>(L)   | Ground | Combination switch<br>OUTPUT 3 | Output           | Combination<br>switch                                     | All switch OFF<br>(Wiper intermittent dial 4)        |  <p style="text-align: center;">7.2 V</p>   |
|   |        |                                |                  |   | Lighting switch 2ND<br>(Wiper intermittent dial 4)   |  <p style="text-align: center;">1.2 V</p>   |
|   |        |                                |                  |   | Lighting switch HI<br>(Wiper intermittent dial 4)    |  |
|   |        |                                |                  |   | Rear washer switch ON<br>(Wiper intermittent dial 4) |  |
| Any of the condition below<br>with all switch OFF   |        |                                |                  |   |  |  |
| <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul> |        |                                |                  |   |  |  |
| 35<br>(B)   | Ground | Combination switch<br>OUTPUT 2 | Output           | Combination<br>switch<br>(Wiper intermit-<br>tent dial 4) | All switch OFF                                       |  <p style="text-align: center;">7.2 V</p>  |
|   |        |                                |                  |   | Lighting switch 2ND                                  |  <p style="text-align: center;">1.2 V</p> |
|   |        |                                |                  |   | Lighting switch PASS                                 |  |
|   |        |                                |                  |   | Front wiper switch INT                               |  |
| Front wiper switch HI   |        |                                |                  |   |  |  |
| 36<br>(V)   | Ground | Combination switch<br>OUTPUT 1 | Output           | Combination<br>switch<br>(Wiper intermit-<br>tent dial 4) | All switch OFF                                       |  <p style="text-align: center;">7.2 V</p> |
|   |        |                                |                  |   | Turn signal switch RH                                |  <p style="text-align: center;">1.2 V</p> |
|   |        |                                |                  |   | Turn signal switch LH                                |  |
|   |        |                                |                  |   | Front wiper switch LO<br>(Front wiper switch MIST)   |  |
| Front washer switch ON  |        |                                |                  |   |  |  |

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                               |                  | Condition  | Value<br>(Approx.)  |
|------------------------------|--------|---|------------------|--|---|
| +                            | -      | Signal name                               | Input/<br>Output |  |   |
| 37<br>(LG)                   | Ground | Key switch                                | Input            | Insert mechanical key into ignition key cylinder   | Battery voltage   |
|                              |        |   |                  | Remove mechanical key from ignition key cylinder   | 0 V   |
| 38<br>(G)                    | Ground | Ignition switch ON                        | Input            | Ignition switch OFF or ACC                         | 0 V   |
|                              |        |   |                  | Ignition switch ON or START                        | Battery voltage   |
| 39<br>(L)                    | Ground | CAN-H                                     | Input/<br>Output | —  | —   |
| 40<br>(P)                    | Ground | CAN-L                                     | Input/<br>Output | —  | —   |
| 43<br>(V)                    | Ground | Back door switch                          | Input            | Back door switch<br>OFF<br>(When back door closed) |  <p style="text-align: right; font-size: small;">JPMIA0593GB</p> <p style="text-align: center;">9.5 - 10.0 V</p> |
|                              |        |   |                  | ON<br>(When back door opened)                      | 0 V   |
| 44<br>(B)                    | Ground | Rear wiper auto stop                      | Input            | Ignition switch ON                                 | Rear wiper stop position  |
|                              |        |   |                  | Any position other than rear wiper stop position   | Battery voltage   |
| 45<br>(P)                    | Ground | Door lock and unlock switch LOCK signal   | Input            | Door lock and unlock switch<br>NEUTRAL position    |  <p style="text-align: right; font-size: small;">JPMIA0591GB</p> <p style="text-align: center;">1.6 V</p>      |
|                              |        |   |                  | LOCK position                                      | 0 V   |
| 46<br>(BR)                   | Ground | Door lock and unlock switch UNLOCK signal | Input            | Door lock and unlock switch<br>NEUTRAL position    |  <p style="text-align: right; font-size: small;">JPMIA0591GB</p> <p style="text-align: center;">1.6 V</p>      |
|                              |        |   |                  | UNLOCK position                                    | 0 V   |

# BCM (BODY CONTROL MODULE)



## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                     |                  | Condition   | Value<br>(Approx.)  |
|------------------------------|--------|---------------------------------|------------------|---|---|
| +                            | -      | Signal name                     | Input/<br>Output |   |   |
| 47<br>(W)                    | Ground | Driver door switch              | Input            | Driver door switch  |  <p>OFF<br/>(When driver door closed)</p> <p style="text-align: right;">8.0 - 8.5 V</p>  |
|                              |        |                                 |                  | Driver door switch  | ON<br>(When driver door opened) <p style="text-align: center;">0 V</p>  |
| 48<br>(GR)                   | Ground | Rear door switch LH             | Input            | Rear door switch LH   |  <p>OFF<br/>(When rear door LH closed)</p> <p style="text-align: right;">8.5 - 9.0 V</p> |
|                              |        |                                 |                  | Rear door switch LH   | ON<br>(When rear door LH opened) <p style="text-align: center;">0 V</p>   |
| 49<br>(L)                    | Ground | Back door lamp control          | Output           | Back door lamp switch DOOR position                               | Back door is closed<br>(Back door lamp turns OFF) <p style="text-align: center;">Battery voltage</p>  |
|                              |        |                                 |                  | Back door lamp switch DOOR position                               | Back door is opened<br>(Back door lamp turns ON) <p style="text-align: center;">0 V</p>   |
| 53<br>(V)                    | Ground | Back door open                  | Output           | Back door opener switch   | Not pressed<br>(Back door actuator is activated) <p style="text-align: center;">0 V</p>   |
|                              |        |                                 |                  | Back door opener switch   | Pressed<br>(Back door actuator is activated) <p style="text-align: center;">Battery voltage</p>   |
| 55<br>(SB)                   | Ground | Rear wiper motor                | Output           | Ignition switch ON  | Rear wiper switch OFF <p style="text-align: center;">0 V</p>  |
|                              |        |                                 |                  | Ignition switch ON  | Rear wiper switch ON <p style="text-align: center;">Battery voltage</p>   |
| 56<br>(Y)                    | Ground | Interior room lamp power supply | Output           | After passing the interior room lamp battery saver operation time |   |
|                              |        |                                 |                  | After passing the interior room lamp battery saver operation time | Any other time after passing the interior room lamp battery saver operation time <p style="text-align: center;">Battery voltage</p>   |
| 57<br>(G)                    | Ground | Battery power supply            | Input            | Ignition switch OFF   |   |
| 59<br>(L)                    | Ground | Driver door UN-LOCK             | Output           | Driver door   | UNLOCK (Actuator is activated) <p style="text-align: center;">Battery voltage</p>   |
|                              |        |                                 |                  | Driver door   | Other than UNLOCK (Actuator is not activated) <p style="text-align: center;">0 V</p>  |

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

| Terminal No.<br>(Wire color) |        | Description                         |                  | Condition                                   | Value<br>(Approx.)                            |  |
|------------------------------|--------|-------------------------------------|------------------|---|---|--|
| +                            | -      | Signal name                         | Input/<br>Output |   |   |  |
| 60<br>(BR)                   | Ground | Turn signal LH                      | Output           | Ignition switch OFF                         | 0 V   |  |
|                              |        |                                     |                  | Ignition switch ON                          | Turn signal switch LH                         | <br>6.0 V |
| 61<br>(GR)                   | Ground | Turn signal RH                      | Output           | Ignition switch OFF                         | 0 V   |  |
|                              |        |                                     |                  | Ignition switch ON                          | Turn signal switch RH                         | <br>6.0 V |
| 63<br>(R)                    | Ground | Interior room lamp timer control    | Output           | Interior room lamp                          | OFF   | Battery voltage  |
|                              |        |                                     |                  | ON  | 0 V   |  |
| 65<br>(V)                    | Ground | All doors LOCK                      | Output           | All doors                                   | LOCK (Actuator is activated)                  | Battery voltage  |
|                              |        |                                     |                  | Other then LOCK (Actuator is not activated) | 0 V   |  |
| 66<br>(G)                    | Ground | Passenger door and rear door UNLOCK | Output           | Passenger door and rear door                | UNLOCK (Actuator is activated)                | Battery voltage  |
|                              |        |                                     |                  |   | Other then UNLOCK (Actuator is not activated) | 0 V  |
| 67<br>(B)                    | Ground | Ground                              | Output           | Ignition switch ON                          | 0 V   |  |
| 68<br>(L)                    | Ground | P/W power supply (RAP)              | Output           | Ignition switch ON                          | Battery voltage                               |  |
| 69<br>(P)                    | Ground | P/W power supply (BAT)              | Output           | Ignition switch OFF                         | Battery voltage                               |  |
| 70<br>(Y)                    | Ground | Battery power supply                | Input            | Ignition switch OFF                         | Battery voltage                               |  |


\*: Except for Mexico

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## Wiring Diagram - BCM -

INFOID:000000004513739



2008/07/15


JCMW2850G

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

IK : With Intelligent Key  
OI : Without Intelligent Key




JCMWM2851G



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

- <XM> : Except for Mexico
- <SR> : With sunroof
- <PS> : With power seat
- <AN> : With anti-pinch system
- <VM> : With vanity mirror lamp




\*: This connector is not shown in "Harness Layout".

JCMWM2852GI

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



JCMWM2853G

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## BCM (BODY CONTROL MODULE)

|                |                    |
|----------------|--------------------|
| Connector No.  | M27                |
| Connector Name | COMBINATION SWITCH |
| Connector Type | TK16FW             |



|    |    |    |   |   |   |   |   |
|----|----|----|---|---|---|---|---|
| 12 | 13 | 10 | 9 | 8 | 7 |   |   |
| 14 | 11 | 1  | 2 | 3 | 4 | 5 | 6 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | V             | INPUT 1                     |
| 2            | B             | INPUT 2                     |
| 3            | L             | INPUT 3                     |
| 4            | GR            | INPUT 4                     |
| 5            | BR            | INPUT 5                     |
| 6            | P             | OUTPUT 1                    |
| 7            | R             | OUTPUT 2                    |
| 8            | G             | OUTPUT 5                    |
| 9            | Y             | OUTPUT 4                    |
| 10           | W             | OUTPUT 3                    |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M67                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA09FB-FHA6-SA           |



|    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 |    |    |    |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 56           | Y             | BATTERYSAVEROUTPUT          |
| 57           | G             | BAT FUSE                    |
| 58           | L             | D/L UNLOCK DR               |
| 59           | BR            | FLASHER OUT PUT (LEFT)      |
| 60           | GR            | FLASHER OUT PUT (RIGHT)     |
| 61           | GR            | ROOMLAMPOUTPUT              |
| 62           | R             | D/L LOCK ALL                |
| 63           | V             | D/L UNLOCK OTHER            |
| 64           | G             | GND                         |
| 65           | B             | POWER WDM OUTPUT(GAP)       |
| 66           | L             | POWER WDM OUTPUT(BAT)       |
| 67           | B             |                             |
| 68           | P             |                             |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M65                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH4QFV-NH                 |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | V             | KEY RING OUTPUT             |
| 2            | G             | INPUT 5                     |
| 3            | Y             | INPUT 4                     |
| 4            | W             | INPUT 3                     |
| 5            | R             | INPUT 2                     |
| 6            | P             | INPUT 1                     |
| 7            | L             | KEY CYL UNLOCK              |
| 8            | R             | KEY CYL LOCK SW             |
| 9            | R             | BRAKE SW                    |
| 10           | SB            | RR DEF SW                   |
| 11           | SB            | ACC                         |

|    |   |        |
|----|---|--------|
| 70 | Y | BAT FL |
|----|---|--------|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 12           | P             | DR SW AS                    |
| 13           | LG            | DR SW RR                    |
| 15           | O             | TPMS MODE TRIGGER SW        |
| 18           | O             | KEYLESS TUNER SERVS GND     |
| 19           | V             | KEYLESS TUNER POWER         |
| 20           | GR            | KEYLESS TUNER SIGNAL        |
| 21           | G             | IMMOBILIZANT(GLOCK)         |
| 23           | B             | SECURITY IN/OUT PUT         |
| 25           | BR            | IMMOBILIZANT(RX.TX)         |
| 27           | Y             | AIRCON SW                   |
| 28           | LG            | BLOWER FAN SW               |
| 29           | W             | HAZARD SW                   |
| 30           | G             | BACK DOOR OPEN SW           |
| 32           | BR            | OUTPUT 5                    |
| 33           | GR            | OUTPUT 4                    |
| 34           | L             | OUTPUT 3                    |
| 35           | B             | OUTPUT 2                    |
| 36           | V             | OUTPUT 1                    |
| 37           | LG            | KEY SW                      |
| 38           | G             | IGN                         |
| 39           | L             | CAN-H                       |
| 40           | P             | CAN-L                       |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M66                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA09FW-FHA6-SA           |



|    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 |
| 50 | 51 | 52 | 53 | 54 | 55 |    |    |    |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 43           | V             | BACK DOOR SW                |
| 44           | B             | RR WIP AUTO STOP            |
| 45           | P             | GDL LOCKSW                  |
| 46           | BR            | GDL UNLOCKSW                |
| 47           | W             | DR SW DR                    |
| 48           | GR            | DR SW RL                    |
| 49           | L             | LUGGAGE LAMP OUTPUT         |
| 53           | V             | BACKDOORPENEROUTPUT         |
| 55           | SB            | RR WIP MTR OUT              |

## Fail-safe

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal. When the rear wiper stop position signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

1. Pass more than 1 minute after the rear wiper stop.
2. Turn the rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

### DTC Inspection Priority Chart

INFOID:000000004513741

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC   |
|----------|---|
| 1        | U1000: CAN COMM CIRCUIT   |
| 2        | C1735: IGN CIRCUIT OPEN   |
| 3        | <ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1712: [CHECKSUM ERR] FL</li> <li>• C1713: [CHECKSUM ERR] FR</li> <li>• C1714: [CHECKSUM ERR] RR</li> <li>• C1715: [CHECKSUM ERR] RL</li> <li>• C1716: [PRESS DATA ERR] FL</li> <li>• C1717: [PRESS DATA ERR] FR</li> <li>• C1718: [PRESS DATA ERR] RR</li> <li>• C1719: [PRESS DATA ERR] RL</li> <li>• C1720: [CODE ERR] FL</li> <li>• C1721: [CODE ERR] FR</li> <li>• C1722: [CODE ERR] RR</li> <li>• C1723: [CODE ERR] RL</li> <li>• C1724: [BATT VOLT LOW] FL</li> <li>• C1725: [BATT VOLT LOW] FR</li> <li>• C1726: [BATT VOLT LOW] RR</li> <li>• C1727: [BATT VOLT LOW] RL</li> <li>• C1729: VHCL SPEED SIG ERR</li> </ul> |

### DTC Index

INFOID:000000004513742

#### NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

| CONSULT display         | Tire pressure monitor warning lamp ON | Reference              |
|-------------------------|---------------------------------------|------------------------|
| U1000: CAN COMM CIRCUIT | —                                     | <a href="#">BCS-35</a> |

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

| CONSULT display            | Tire pressure monitor warning lamp ON | Reference              |    |
|----------------------------|---------------------------------------|------------------------|----|
| C1704: LOW PRESSURE FL     | ×                                     | <a href="#">WT-15</a>  | A  |
| C1705: LOW PRESSURE FR     | ×                                     |                        | B  |
| C1706: LOW PRESSURE RR     | ×                                     |                        |    |
| C1707: LOW PRESSURE RL     | ×                                     |                        |    |
| C1708: [NO DATA] FL        | ×                                     | <a href="#">WT-17</a>  | C  |
| C1709: [NO DATA] FR        | ×                                     |                        |    |
| C1710: [NO DATA] RR        | ×                                     |                        | D  |
| C1711: [NO DATA] RL        | ×                                     |                        |    |
| C1712: [CHECKSUM ERR] FL   | ×                                     | <a href="#">WT-20</a>  | WT |
| C1713: [CHECKSUM ERR] FR   | ×                                     |                        |    |
| C1714: [CHECKSUM ERR] RR   | ×                                     |                        |    |
| C1715: [CHECKSUM ERR] RL   | ×                                     |                        |    |
| C1716: [PRESS DATA ERR] FL | ×                                     | <a href="#">WT-23</a>  | F  |
| C1717: [PRESS DATA ERR] FR | ×                                     |                        |    |
| C1718: [PRESS DATA ERR] RR | ×                                     |                        | G  |
| C1719: [PRESS DATA ERR] RL | ×                                     |                        |    |
| C1720: [CODE ERR] FL       | ×                                     | <a href="#">WT-25</a>  | H  |
| C1721: [CODE ERR] FR       | ×                                     |                        |    |
| C1722: [CODE ERR] RR       | ×                                     |                        |    |
| C1723: [CODE ERR] RL       | ×                                     |                        | I  |
| C1724: [BATT VOLT LOW] FL  | —                                     | <a href="#">WT-28</a>  |    |
| C1725: [BATT VOLT LOW] FR  | —                                     |                        | J  |
| C1726: [BATT VOLT LOW] RR  | —                                     |                        |    |
| C1727: [BATT VOLT LOW] RL  | —                                     |                        |    |
| C1729: VHCL SPEED SIG ERR  | ×                                     | <a href="#">WT-31</a>  | K  |
| C1735: IGN CIRCUIT OPEN    | —                                     | <a href="#">BCS-36</a> |    |

# TPMS

< SYMPTOM DIAGNOSIS >










## SYMPTOM DIAGNOSIS

### TPMS

#### Symptom Table




INFOID:000000004236647

#### LOW TIRE PRESSURE WARNING LAMP SYMPTOM CHART

| Diagnosis Item                 | Symptom (Ignition switch ON)  | Low tire pressure warning lamp   | Cause  | Action   |
|--------------------------------|---|--|--|--|
| Low tire pressure warning lamp | Low tire pressure warning lamp comes on immediately and turns off after 1 second.               | <br>ON 1 sec > stays OFF<br>SEIA0592E   | All wheel transmitters are "activated" (working).    | None (system OK)   |
|                                | Low tire pressure warning lamp blinks on for 2 seconds, then turns off for 0.2 seconds-repeats. |  Blinks: <br>ON 2 sec > OFF 0.2 sec<br>SEIA0593E   | All wheel transmitters are not activated.            | Activate all wheel tire pressure transmitters. Refer to <a href="#">WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"</a> . |
|                                | Low tire pressure warning lamp blinks 1 time.   | <br>Blinks 1 time<br>ON 0.3 sec > OFF 1.3 sec<br>SEIA0594E  | Tire pressure transmitter front LH is not activated. | Activate tire pressure transmitter front LH. Refer to <a href="#">WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"</a> .   |
|                                | Low tire pressure warning lamp blinks 2 times.  |  <br>Blinks 2 times<br>ON 0.3 sec > OFF 0.3 sec<br>SEIA0595E   | Tire pressure transmitter front RH is not activated. | Activate tire pressure transmitter front RH. Refer to <a href="#">WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"</a> .   |
|                                | Low tire pressure warning lamp blinks 3 times.  |   <br>Blinks 3 times<br>ON 0.3 sec > OFF 0.3 sec<br>SEIA0596E | Tire pressure transmitter rear RH is not activated.  | Activate tire pressure transmitter rear RH. Refer to <a href="#">WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"</a> .    |

# TPMS

## < SYMPTOM DIAGNOSIS >

| Diagnosis Item                 | Symptom (Ignition switch ON)   | Low tire pressure warning lamp   | Cause  | Action  |
|--------------------------------|--|--|--|---|
| Low tire pressure warning lamp | Low tire pressure warning lamp blinks 4 times.   |  <p>Blinks 4 times<br/>ON 0.3 sec &gt; OFF 0.3 sec<br/>SEIA0597E</p>            | Tire pressure transmitter rear LH is not activated.  | Activate tire pressure transmitter rear LH. Refer to <a href="#">WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"</a> .   |
|                                | Low tire pressure warning lamp comes on and does not turn off.   |  <p>Comes ON and stays ON<br/>SEIA0598E</p>                                     | Tire pressure is low.  | Check tire pressure with CONSULT-III. Refer to <a href="#">WT-13, "AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONITOR)"</a> .  |
|                                | Low tire pressure warning lamp blinks on for 0.5 seconds then turns off for 0.5 seconds-repeats for 1 minute, and then stays on. |  <p>Blinks 1 min<br/>ON 0.5 sec &gt; OFF 0.5 sec and stays ON<br/>SEIA0788E</p> | <p>The fuse for combination meter from battery is pulled out.</p> <p>BCM connector pulled out.</p> <p>Low tire pressure or tire pressure monitoring system malfunction.</p>                                  | <p>Check the fuse for combination meter from battery. Install or replace (if needed).</p> <p>Check BCM connector. Reconnect if needed.</p> <ul style="list-style-type: none"> <li>Perform CONSULT-III Self-Diagnosis. Refer to <a href="#">WT-13, "AIR PRESSURE MONITOR : CONSULT-III Function (BCM - AIR PRESSURE MONITOR)"</a>.</li> <li>Perform ID Registration if needed. Refer to <a href="#">WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"</a>.</li> </ul> |
| Turn signal lamp               | Turn signal lamp does not blink 2 times or buzzer does not sound after transmitter activation.                                   | —  | <ol style="list-style-type: none"> <li>Tool J-45295 [SST]</li> <li>Ignition OFF during activation.</li> <li>Tool J-45295 [SST] not positioned correctly.</li> <li>Transmitters already activated.</li> </ol> | <ol style="list-style-type: none"> <li>Install new battery.</li> <li>Check ignition is ON during activation.</li> <li>Position tool correctly during activation.</li> <li>Nothing.</li> </ol>   |

**NOTE:**

If more than one wheel transmitter is NOT activated, the low tire pressure warning lamp blinking patterns for those wheels will combine. (Example: one blink/OFF/three blinks = Tire pressure transmitter rear LH and rear RH are not activated.)

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

---

## LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

### Description

INFOID:000000004236648

#### DESCRIPTION

The low tire pressure warning lamp illuminates for approximately 1 second and then turns OFF when the ignition switch is turned ON. This is to check that no abnormal condition is present in the tire pressure monitoring system.

The lamp bulb may be burnt out or the tire pressure monitoring system may be malfunctioning if the low tire pressure warning lamp does not illuminate when the ignition switch is turned ON.

### Diagnosis Procedure

INFOID:000000004236649

---

#### 1. CHECK SELF-DIAGNOSIS RESULTS

Ⓜ With CONSULT-III

1. On the "SELECT DIAG" mode, select the "SELF-DIAG RESULTS" screen.
2. Check display contents in self-diagnostic results.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

YES >> Perform trouble diagnosis for CAN communication system. Refer to [LAN-24, "CAN System Specification Chart"](#).

NO >> GO TO 2.

---

#### 2. CHECK COMBINATION METER

Check combination meter function. Refer to [MWI-33, "CONSULT-III Function \(METER/M&A\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

---

#### 3. CHECK LOW TIRE PRESSURE WARNING LAMP

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connectors.
3. Turn ignition switch "ON". (Never start engine.)

Does low tire pressure warning lamp turn on?

YES >> GO TO 4.

NO >> Check combination meter and repair or replace. Refer to [MWI-32, "Diagnosis Description"](#).

---

#### 4. CHECK SYMPTOM

Check again.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

---

#### 5. CHECK BCM

Check BCM input/output signal. Refer to [WT-40, "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 6.

---

#### 6. CHECK BCM HARNESS CONNECTOR

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

NO >> Repair or replace damaged parts.



# LOW TIRE PRESSURE WARNING LAMP STAYS ON

< SYMPTOM DIAGNOSIS >

## LOW TIRE PRESSURE WARNING LAMP STAYS ON

### Description

INFOID:000000004236650

### DESCRIPTION

The tire pressure monitoring system is checked and the warning lamp is illuminated for approximately 1 second when the ignition switch is turned ON. The low tire pressure warning lamp turns OFF after the system check finishes.

The system may be malfunctioning if the low tire pressure warning lamp does not turn off approximately 1 second after the ignition switch is turned ON.

### Diagnosis Procedure

INFOID:000000004236651

#### 1. CHECK SYSTEM FOR BCM

④ With CONSULT-III

1. On "SELF-DIAG" mode, select the "SELF-DIAG RESULTS" screen.
2. Check display contents in self-diagnostic results.

Does self-diagnostic results indicate any malfunction?

YES >> Perform trouble diagnosis. Refer to [WT-13, "AIR PRESSURE MONITOR : CONSULT-III Function \(BCM - AIR PRESSURE MONITOR\)"](#).

NO >> GO TO 2.

#### 2. CHECK ID REGISTRATION

Perform ID registration all transmitters. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Does low tire pressure warning lamp turn OFF?

YES >> INSPECTION END

NO >> GO TO 3.

#### 3. CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connector.
3. Check voltage between BCM and harness connector terminals and ground.

| BCM       |          | —      | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal |        |                   |
| M67       | 57       | Ground | Battery voltage   |
|           | 70       |        |                   |

Is the power supply normal?

YES >> GO TO 4.

NO >> Check the following. If any items are damaged, repair or replace damage parts.

- 50 A fusible link [No. J located in the fuse block]. Refer to [PG-88, "Fuse and Fusible Link Arrangement"](#).
- 10 A fuse [No. 10 located in the fuse block (J/B)]. Refer to [PG-87, "Fuse, Connector and Terminal Arrangement"](#).
- Harness for short or open between battery and BCM harness connector M67 terminal 57.
- Harness for short or open between battery and BCM harness connector M67 terminal 70.
- Check battery voltage.

#### 4. CHECK GROUND CIRCUIT

1. Turn the ignition switch "OFF".
2. Disconnect BCM harness connector.
3. Check continuity between BCM harness connector M67 terminal 67 and ground.

# LOW TIRE PRESSURE WARNING LAMP STAYS ON

## < SYMPTOM DIAGNOSIS >

---

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M67       | 67       |        | Existed    |

Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to power in harness or connectors.

### 5.CHECK SYMPTOM

---

Check again.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

### 6.CHECK BCM

---

Check BCM input/output signal. Refer to [WT-40, "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 7.

### 7.CHECK BCM HARNESS CONNECTOR

---

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

NO >> Repair or replace damaged parts.

# LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

## LOW TIRE PRESSURE WARNING LAMP BLINKS

### Description

INFOID:000000004236652

### DESCRIPTION

The low tire pressure warning lamp illuminates or blinks.


However, a check is necessary because the symptom may not be caused by a system malfunction. For example, the transmitter may not be initialized.

#### NOTE:

If low tire pressure warning lamp blinks below, the system is normal.

Blink Mode A

- This mode shows transmitter status is in OFF- mode. Perform transmitter wake up operation. Refer to [WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"](#).



### Diagnosis Procedure

INFOID:000000004236653

#### 1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

- Turn the ignition switch "OFF".
- Check signal between tire pressure warning check switch connector M92 terminal 1 and ground with oscilloscope.

| Tire pressure warning check switch |          | —      | Condition           | Voltage (Approx.) |
|------------------------------------|----------|--------|---------------------|-------------------|
| Connector                          | Terminal |        |                     |                   |
| M92                                | 1        | Ground | Ignition switch OFF | <p>1.5 V</p>      |

Is the reference voltage outputted?

- YES >> Repair or replace BCM circuit. Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

- Disconnect BCM harness connector
- Check continuity between BCM harness connector M65 terminal 15 and tire pressure warning check switch connector M92 terminal 1.
- Check harness for short to ground.

| BCM       |          | Tire pressure warning check switch |          | Continuity |
|-----------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector                          | Terminal |            |
| M65       | 15       | M92                                | 1        | Existed    |

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace damaged parts.

## LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

---

### 3.CHECK BCM

---

Check BCM input/output signal. Refer to [WT-40. "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 1.

NO >> GO TO 4.

### 4.CHECK BCM HARNESS CONNECTOR

---

Check BCM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-67. "Removal and Installation"](#).

NO >> repair or replace damaged parts.

# TURN SIGNAL LAMP BLINKS

< SYMPTOM DIAGNOSIS >

## TURN SIGNAL LAMP BLINKS

### Description

INFOID:000000004236654

### DESCRIPTION


The turn signal lamp blinks when the ignition switch is turned ON.  
The BCM connector or circuit may have a malfunction.

### Diagnosis Procedure

INFOID:000000004236655

#### 1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY

- Turn the ignition switch "OFF".
- Check signal between tire pressure warning check switch connector M92 terminal 1 and ground with oscilloscope.

| Tire pressure warning check switch |          | —      | Condition           | Voltage (Approx.)   |
|------------------------------------|----------|--------|---------------------|---|
| Connector                          | Terminal |        |                     |   |
| M92                                | 1        | Ground | Ignition switch OFF |  <p style="text-align: right;">JPMIA0588GB<br/>1.5 V</p> |

Is the reference voltage outputted?

- YES >> Repair or replace BCM circuit. Replace BCM. Refer to [BCS-67. "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

- Disconnect BCM harness connector
- Check continuity between BCM harness connector M65 terminal 15 and tire pressure warning check switch connector M92 terminal 1.
- Check harness for short to ground.

| BCM       |          | Tire pressure warning check switch |          | Continuity |
|-----------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector                          | Terminal |            |
| M65       | 15       | M92                                | 1        | Existed    |

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace damaged parts.

#### 3. CHECK SYMPTOM

Check again.

Does the turn signal lamp remain blinking?

- YES >> Check turn signal lamp operation. Refer to [BCS-26. "FLASHER : CONSULT-III Function \(BCM - FLASHER\)"](#).  
NO >> INSPECTION END

# ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

## ID REGISTRATION CANNOT BE COMPLETED

### Description

INFOID:000000004236656

### DESCRIPTION

The ID of the transmitter installed in each wheel cannot be registered in the tire pressure monitoring system. Inspect the transmitter or the tire pressure monitoring system circuit.

### Diagnosis Procedure

INFOID:000000004236657

#### 1. CHECK ID REGISTRATION

1. Perform ID registration of all transmitter. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes. Then check all tire pressures with CONSULT-III "DATA MONITOR" within 5 minutes.

| Monitored item | Condition   | Display value   |
|----------------|---|---|
| AIR PRESS FL   | Start engine and drive at 40 km/h (25 MPH) or more for several minutes. | Approximately equal to the indication on vehicle information display. |
| AIR PRESS FR   |   |   |
| AIR PRESS RR   |   |   |
| AIR PRESS RL   |   |   |

Does "DATA MONITOR" displayed the standardized value without turning low tire pressure warning lamp ON?

- YES >> INSPECTION END  
NO >> GO TO 2.

#### 2. CHECK TRANSMITTER

1. Perform trouble diagnosis for transmitter. Refer to [WT-17, "Diagnosis Procedure"](#).
2. Perform ID registration of all transmitter. Refer to [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

Can ID registration of all transmitters be completed?

- YES >> INSPECTION END  
NO >> Repair or replace the malfunctioning connector. Repair or replace the malfunctioning part. GO TO 1.

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

## NORMAL OPERATING CONDITION

### Description


INFOID:000000004236658

#### LOW TIRE PRESSURE WARNING LAMP BLINKS

The tire pressure monitoring system is not malfunctioning if the low tire pressure warning lamp blinks in the pattern as shown in the figure.

The incident occurs because the transmitter of each wheel is not wake up.

Perform transmitter wake up operation. Refer to [WT-5, "TRANSMITTER WAKE UP OPERATION : Special Repair Requirement"](#).



A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

### NVH Troubleshooting Chart

INFOID:000000004236659

Use chart below to find the cause of the symptom. If necessary, repair or replace these parts.

| Symptom |            | Possible cause and SUSPECTED PARTS | Reference page                   |              |           |                         |                  |                       |                |                     |                 |              |                                 |                               |       |             |             |       |          |   |
|---------|------------|------------------------------------|----------------------------------|--------------|-----------|-------------------------|------------------|-----------------------|----------------|---------------------|-----------------|--------------|---------------------------------|-------------------------------|-------|-------------|-------------|-------|----------|---|
|         |            |                                    | Improper installation, looseness | Out-of-round | unbalance | Incorrect tire pressure | Uneven tire wear | Deformation or damage | Non-uniformity | Incorrect tire size | PROPELLER SHAFT | DIFFERENTIAL | FRONT AXLE AND FRONT SUSPENSION | REAR AXLE AND REAR SUSPENSION | TIRES | ROAD WHEELS | DRIVE SHAFT | BRAKE | STEERING |   |
| Symptom | TIRES      | Noise                              | x                                | x            | x         | x                       | x                | x                     | x              |                     | x               | x            | x                               | x                             |       | x           | x           | x     | x        |   |
|         |            | Shake                              | x                                | x            | x         | x                       | x                | x                     |                | x                   | x               |              | x                               | x                             |       | x           | x           | x     | x        |   |
|         |            | Vibration                          |                                  |              |           | x                       |                  |                       |                |                     | x               | x            |                                 | x                             | x     |             |             | x     |          | x |
|         |            | Shimmy                             | x                                | x            | x         | x                       | x                | x                     | x              | x                   |                 |              | x                               | x                             |       | x           |             | x     | x        | x |
|         |            | Judder                             | x                                | x            | x         | x                       | x                | x                     |                | x                   |                 |              | x                               | x                             |       | x           |             | x     | x        | x |
|         |            | Poor quality ride or handling      | x                                | x            | x         | x                       | x                | x                     |                | x                   |                 |              | x                               |                               | x     | x           |             |       |          |   |
|         | ROAD WHEEL | Noise                              | x                                | x            | x         |                         |                  |                       | x              |                     |                 | x            | x                               | x                             | x     |             | x           | x     | x        | x |
|         |            | Shake                              | x                                | x            | x         |                         |                  |                       | x              |                     |                 | x            |                                 | x                             | x     |             | x           | x     | x        | x |
|         |            | Shimmy, Judder                     | x                                | x            | x         |                         |                  |                       | x              |                     |                 |              | x                               | x                             | x     |             |             | x     |          | x |
|         |            | Poor quality ride or handling      | x                                | x            | x         |                         |                  |                       | x              |                     |                 |              | x                               | x                             | x     |             |             |       |          |   |

x: Applicable



# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Service Notice or Precautions

INFOID:000000004236660

- Low tire pressure warning lamp blinks 1min, then turns ON when occurring any malfunction except low tire pressure. Delete the memory with CONSULT-III, or register the ID to turn low tire pressure warning lamp OFF. Refer to [WT-12, "AIR PRESSURE MONITOR : Diagnosis Description"](#), [WT-5, "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).
- ID registration is required when replacing or rotating wheels, replacing transmitter or BCM. Refer to
- Replace grommet seal, valve core and cap of transmitter in TPMS every tire replacement by reaching wear limit of tire. Refer to [WT-79, "Exploded View"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WT

# PREPARATION

< PREPARATION >


## PREPARATION

### PREPARATION

#### Special Service Tools


INFOID:000000004236661

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description     |
|---|-----------------|
| –<br>(J-45295)<br>Transmitter activation tool<br><br>SEIA0462E | ID registration |

#### Commercial Service Tools

INFOID:000000004236662

| Tool name   | Description              |
|---|--------------------------|
| Power tool<br><br>PBIC0190E | Loosening bolts and nuts |

# ROAD WHEEL

< ON-VEHICLE MAINTENANCE >

## ON-VEHICLE MAINTENANCE

### ROAD WHEEL

#### Inspection


INFOID:000000004236663

#### ALUMINUM WHEEL

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
  - a. Remove tire from aluminum wheel and mount on a tire balance machine.
  - b. Set dial indicator as shown in the figure.
  - c. If the total runout value exceeds the limit, replace aluminum wheel.

**Lateral runout limit (A)** Refer to [WT-81, "Road Wheel"](#).

**Vertical runout limit (B)** Refer to [WT-81, "Road Wheel"](#).



#### STEEL WHEEL

1. Check tires for were and improper inflation.
2. Check wheels for deformation, clacks and other damage. If deformed, remove wheel and check wheel runout.
  - a. Remove tire from steel wheel and mount wheel on a tire balance machine.
  - b. Set two dial indicators as shown in the illustration.
  - c. Set each dial indicator to "0".
  - d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
  - e. Calculate runout at each point as shown below.

**Lateral runout limit (A):**  $(1+2)/2$

**Radial runout limit (B):**  $(3+4)/2$

- f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout.

**CAUTION:**


**In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout.**

**Limit**

**A:** Refer to [WT-81, "Road Wheel"](#).

**B:** Refer to [WT-81, "Road Wheel"](#).

- g. If the total runout value exceeds limit, replace steel wheel.



# ROAD WHEEL TIRE ASSEMBLY

< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### ROAD WHEEL TIRE ASSEMBLY

#### Adjustment

INFOID:000000004236664

#### BARANCING WHEELS (BONDING WEIGHT TYPE)

##### Preparation Before Adjustment

Using releasing agent, remove double-faced adhesive tape from the road wheel.

##### **CAUTION:**

- **Be careful not scratch the road wheel during removal.**
- **After removing double-faced adhesive tape, wipe clean traces of releasing agent from the road wheel.**

##### Wheel Balance Adjustment

- If a tire balance machine has adhesion balance weight mode settings and drive-in weight mode setting, select and adjust a drive-in weight mode suitable for road wheels.

1. Set road wheel on tire balance machine using the center hole as a guide. Start the tire balance machine.
2. When inner and outer unbalance values are shown on the tire balance machine indicator, multiply outer unbalance value by  $5/3$  to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install in to the designated outer position of, or at the designated angle in relation to the road wheel.

##### **CAUTION:**

- **Do not install the inner balance weight before installing the outer balance weight.**
- **Before installing the balance weight, be sure to clean the mating surface of the road wheel.**

- a. Indicated unbalance value  $\times 5/3$  = balance weight to be installed

##### **Calculation example:**

$23 \text{ g (0.81 oz)} \times 5/3 = 38.33 \text{ g (1.35 oz)} \Rightarrow 40 \text{ g (1.41 oz)}$  balance weight (closer to calculated balance weight value)


##### **NOTE:**

Note that balance weight value must be closer to the calculated balance weight value.

##### **Example:**

$37.4 \Rightarrow 35 \text{ g (1.23 oz)}$

$37.5 \Rightarrow 40 \text{ g (1.41 oz)}$



- b. Installed balance weight in the position.


# ROAD WHEEL TIRE ASSEMBLY

## < ON-VEHICLE REPAIR >

- When installing balance weight (1) to road wheels, set it into the grooved area (A) on the inner wall of the road wheel as shown in the figure so that the balance weight center (B) is aligned with the tire balance machine indication position (angle) (C).

**CAUTION:**

- Always use genuine NISSAN adhesion balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Do not install more than three sheets of balance weight.



- If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown in the figure.

**CAUTION:**


**Do not install one balance weight sheet on top another.**

- Start tire balance machine again.
- Install drive-in balance weight on inner side of road wheel in the tire balance machine indication position (angle).

**CAUTION:**

**Do not install more than two balance weight.**

- Start tire balance machine. Make sure that inner and outer residual unbalance values are 5 g (0.17 oz) each or below.
- If either residual unbalance value exceeds 5 g (0.17 oz), repeat installation procedures.




| Wheel balance               | Dynamic (At flange)                            | Static (At flange) |
|-----------------------------|--|--------------------|
| Maximum allowable unbalance | Refer to <a href="#">WT-81, "Road Wheel"</a> . |                    |

## TIRE ROTATION

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-10, "FOR NORTH AMERICA : Schedule 1"](#).
- When installing the wheel, tighten wheel nuts to the specified torque.

**CAUTION:**

- Do not include the T-type spare tire when rotating the tires.
- When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
- Be careful not to tighten wheel nut at torque exceeding the criteria for preventing strain of disc rotor.
- Use NISSAN genuine wheel nuts for aluminum wheels.



**Wheel nuts tightening torque** : Refer to [WT-81, "Road Wheel"](#).

## ROAD WHEEL TIRE ASSEMBLY

< ON-VEHICLE REPAIR >


- 
- Perform the ID registration, after tire rotation. Refer to [WT-5. "ID REGISTRATION PROCEDURE : Special Repair Requirement"](#).

# TRANSMITTER

< ON-VEHICLE REPAIR >

## TRANSMITTER

### Exploded View



- |                |                 |              |
|----------------|-----------------|--------------|
| 1. Transmitter | 2. Grommet seal | 3. Valve nut |
| 4. Valve core  | 5. Cap          |              |


Refer to [GI-4, "Components"](#) for symbols in figure.

### Removal and Installation


INFOID:000000004236666

#### REMOVAL

1. Deflate tire. Unscrew transmitter retaining nut and allow transmitter to fall into tire.
2. Gently bounce tire so that transmitter falls to bottom of tire. Place on tire changing machine and break both tire beads ensuring that the transmitter remains at the bottom of the tire.



3. Turn tire so that valve hole is at bottom and bounce so that transmitter (1) is near valve hole. Carefully lift tire onto turntable and position valve hole (and transmitter) 270 degree from mounting/dismounting head (2).
4. Lubricate tire well and remove first side of the tire. Reach inside the tire and remove the transmitter.




#### INSTALLATION

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TRANSMITTER

## < ON-VEHICLE REPAIR >

1. Put first side of tire onto rim.



2. Mount transmitter on rim and tighten nut.

**CAUTION:**


**Speed for tightening nut should be less than 10 rpm.**

3. Place wheel on turntable of tire machine. Ensure that transmitter (1) is 270 degree from mounting head (2) when second side of tire is fitted.

**NOTE:**

Do not touch transmitter at mounting head.

4. Lubricate tire well and fit second side of tire as normal. Ensure that tire does not rotate relative to rim.
5. Inflate tire and fit to appropriate wheel position.





# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Road Wheel

INFOID:000000004236667

| Kind of wheel                     |                     | Aluminum                           | Steel                    |
|-----------------------------------|---------------------|------------------------------------|--------------------------|
| Maximum radial runout limit       | Lateral deflection  | Less than 0.3 mm (0.012 in)        | Less than 0.8 mm (0.031) |
|                                   | Vertical deflection | Less than 0.3 mm (0.012 in)        | Less than 0.5 mm (0.020) |
| Maximum allowable unbalance limit | Dynamic (At flange) | Less than 5 g (0.17 oz) (one side) |                          |
|                                   | Static (At flange)  | Less than 10 g (0.35 oz)           |                          |
| Wheel nuts tightening torque      |                     | 108 N·m (11 kg-m, 80 ft-lb)        |                          |

#### Tire

INFOID:000000004236668

Unit: kPa (kg/cm<sup>2</sup>, psi)

| Tire size       | Air pressure  |               |
|-----------------|---------------|---------------|
|                 | Front         | Rear          |
| P215/70R16 99H  | 230 (2.3, 33) | 230 (2.3, 33) |
| P225/60R17 98H  | 230 (2.3, 33) | 230 (2.3, 33) |
| T155/90R16 110M | 420 (4.2, 60) | 420 (4.2, 60) |