

ELECTRICAL SYSTEM

SECTION **EL**

CONTENTS

| | | | |
|---|----|---|----|
| PRECAUTIONS | 4 | BACK-UP LAMP | 50 |
| Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 4 | Wiring Diagram - BACK/L - | 50 |
| Wiring Diagrams and Trouble Diagnosis | 4 | FRONT FOG LAMP | 51 |
| PREPARATION | 5 | System Description..... | 51 |
| Special Service Tools | 5 | Wiring Diagram - F/FOG - | 52 |
| HARNESS CONNECTOR | 6 | Aiming Adjustment | 53 |
| Description | 6 | Removal and Installation | 54 |
| STANDARDIZED RELAY | 8 | Bulb and Lens Replacement | 54 |
| Description | 8 | TURN SIGNAL AND HAZARD WARNING LAMPS | 55 |
| POWER SUPPLY ROUTING | 10 | System Description..... | 55 |
| Circuit Diagram | 10 | Wiring Diagram - TURN - | 57 |
| Wiring Diagram - POWER - | 12 | Trouble Diagnoses..... | 59 |
| Inspection..... | 17 | Electrical Components Inspection | 59 |
| GROUND | 18 | TRAILER TOW | 60 |
| Ground Distribution..... | 18 | System Description..... | 60 |
| COMBINATION SWITCH | 32 | Wiring Diagram - T/TOW - | 61 |
| Check..... | 32 | Trouble Diagnoses..... | 62 |
| Replacement..... | 33 | ILLUMINATION | 63 |
| STEERING SWITCH | 34 | System Description..... | 63 |
| Check..... | 34 | Wiring Diagram - ILL - | 64 |
| HEADLAMP (FOR USA) | 35 | INTERIOR ROOM LAMP | 66 |
| System Description..... | 35 | Component Parts and Harness Connector | |
| Wiring Diagram - H/LAMP - | 36 | Location | 66 |
| Trouble Diagnoses..... | 37 | System Description..... | 67 |
| Bulb Replacement | 38 | Wiring Diagram - ROOM/L - | 69 |
| Aiming Adjustment..... | 38 | Trouble Diagnosis..... | 72 |
| HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM - | 40 | METERS AND GAUGES | 75 |
| System Description (For Canada)..... | 40 | Component Parts and Harness Connector | |
| Circuit Diagram | 42 | Location | 75 |
| Wiring Diagram - DTRL - | 43 | System Description..... | 76 |
| Trouble Diagnoses..... | 46 | Combination Meter | 78 |
| Bulb Replacement | 47 | Wiring Diagram - METER - | 80 |
| Aiming Adjustment..... | 47 | Meter/Gauge Operation and Odo/Trip Meter | |
| PARKING, LICENSE AND TAIL LAMPS | 48 | Segment Check in Diagnosis Mode | 81 |
| Wiring Diagram - TAIL/L - | 48 | Trouble Diagnoses..... | 82 |
| STOP LAMP | 49 | Electrical Components Inspection | 89 |
| Wiring Diagram - STOP/L - | 49 | COMPASS AND THERMOMETER | 90 |
| | | System Description..... | 90 |
| | | Wiring Diagram - COMPAS - | 91 |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CONTENTS (Cont'd)

| | | | |
|---|-----|---|-----|
| Trouble Diagnoses..... | 92 | System Description..... | 157 |
| Calibration Procedure for Compass..... | 93 | Circuit Diagram..... | 159 |
| WARNING LAMPS | 94 | Wiring Diagram - ASCD -..... | 160 |
| Circuit Diagram..... | 94 | Fail-safe System..... | 163 |
| Wiring Diagram - WARN -..... | 95 | Trouble Diagnoses..... | 164 |
| Electrical Components Inspection..... | 102 | Electrical Component Inspection..... | 172 |
| WARNING CHIME | 103 | ASC Wire Adjustment..... | 174 |
| Component Parts and Harness Connector | | POWER WINDOW | 176 |
| Location..... | 103 | System Description..... | 176 |
| System Description..... | 103 | Circuit Diagram..... | 179 |
| Wiring Diagram - CHIME -..... | 106 | Wiring Diagram - WINDOW -..... | 180 |
| Trouble Diagnoses..... | 108 | Trouble Diagnoses..... | 184 |
| FRONT WIPER AND WASHER | 118 | POWER DOOR LOCK | 186 |
| System Description..... | 118 | Component Parts and Harness Connector | |
| Wiring Diagram - WIPER -..... | 120 | Location..... | 186 |
| Removal and Installation..... | 122 | System Description..... | 187 |
| Washer Nozzle Adjustment..... | 123 | Circuit Diagram..... | 190 |
| Washer Tube Layout..... | 123 | Wiring Diagram - D/LOCK -..... | 191 |
| REAR WIPER AND WASHER | 124 | Trouble Diagnoses..... | 195 |
| System Description..... | 124 | REMOTE KEYLESS ENTRY SYSTEM | 202 |
| Wiring Diagram - WIP/R -..... | 125 | Component Parts and Harness Connector | |
| Removal and Installation..... | 126 | Location..... | 202 |
| Washer Nozzle Adjustment..... | 127 | System Description..... | 203 |
| Washer Tube Layout..... | 128 | Circuit Diagram..... | 205 |
| Check Valve..... | 128 | Wiring Diagram - MULTI -..... | 206 |
| HORN | 129 | Trouble Diagnoses..... | 209 |
| Wiring Diagram - HORN -..... | 129 | ID Code Entry Procedure..... | 218 |
| CIGARETTE LIGHTER | 130 | Keyfob Battery Replacement..... | 219 |
| Wiring Diagram - CIGAR -..... | 130 | VEHICLE SECURITY (THEFT WARNING) | |
| REAR WINDOW DEFOGGER | 131 | SYSTEM | 220 |
| Component Parts and Harness Connector | | Component Parts and Harness Connector | |
| Location..... | 131 | Location..... | 220 |
| System Description..... | 132 | System Description..... | 222 |
| Wiring Diagram - DEF -..... | 134 | Circuit Diagram..... | 225 |
| Trouble Diagnoses..... | 136 | Wiring Diagram - VEHSEC -..... | 226 |
| Electrical Components Inspection..... | 141 | Trouble Diagnoses..... | 229 |
| Filament Check..... | 142 | Electrical Components Inspection..... | 241 |
| Filament Repair..... | 143 | SMART ENTRANCE CONTROL UNIT | 242 |
| AUDIO | 144 | Description..... | 242 |
| System Description..... | 144 | Circuit Diagram..... | 243 |
| Schematic - With Audio Amplifier..... | 145 | Smart Entrance Control Unit Inspection Table..... | 245 |
| Wiring Diagram - AUDIO -..... | 146 | ELECTRICAL UNITS LOCATION | 247 |
| Trouble Diagnoses..... | 150 | Engine Compartment..... | 247 |
| Inspection..... | 151 | Passenger Compartment..... | 248 |
| AUDIO ANTENNA | 153 | HARNES LAYOUT | 250 |
| Location of Antenna..... | 153 | How to Read Harness Layout..... | 250 |
| Fixed Antenna Rod Replacement..... | 153 | Outline..... | 251 |
| DOOR MIRROR | 154 | Main Harness..... | 252 |
| Wiring Diagram - MIRROR -..... | 154 | Engine Room Harness..... | 255 |
| AUTOMATIC SPEED CONTROL DEVICE (ASC D) | 155 | Engine Control Harness..... | 261 |
| Component Parts and Harness Connector | | Engine No. 2 Harness..... | 267 |
| Location..... | 155 | Body Harness..... | 270 |

CONTENTS (Cont'd)

| | | |
|--|---|----|
| Body No. 2 and Chassis Harness.....271 | BULB SPECIFICATIONS276 | GI |
| Room Lamp Harness.....272 | Headlamp.....276 | |
| Front Door Harness.....273 | Exterior Lamp276 | MA |
| Rear Door Harness.....274 | Interior Lamp.....276 | |
| Back Door Harness275 | WIRING DIAGRAM CODES (CELL CODES)277 | EM |

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NGEL0001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Wiring Diagrams and Trouble Diagnosis

NGEL0002

When you read wiring diagrams, refer to the following:

- **GI-10**, "HOW TO READ WIRING DIAGRAMS"
- **EL-10**, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnosis, refer to the following:

- **GI-33**, "How to Follow Test Groups in Trouble Diagnoses".
- **GI-22**, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

Check for any Service bulletins before servicing the vehicle.


PREPARATION

Special Service Tools

Special Service Tools

NGEL0217

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|---|
| (J-43241) Remote keyless entry tester | <div style="text-align: center;">  </div> <p style="text-align: center;">Used to test keyfobs</p> <p>LEL946A</p> |

*: Special tool or commercial equivalent

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HARNESS CONNECTOR

Description

Description

NGEL0003

NGEL0003S01

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to EL-7 for description of the slide-locking type connector.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



SEL769D

HARNESS CONNECTOR

Description (Cont'd)

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)


-NGEL0003S02

- A new style slide-locking connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

Be careful not to damage the connector support bracket when disconnecting the connector.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

STANDARDIZED RELAY

Description


Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NGEL0004

NGEL0004S01




SEL881H

TYPE OF STANDARDIZED RELAYS

NGEL0004S02

| | | | |
|----|------------|-------|----------------|
| 1M | 1 Make | 2M | 2 Make |
| 1T | 1 Transfer | 1M·1B | 1 Make 1 Break |



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

| Type | Outer view | Circuit | Connector symbol and connector | Case color |
|-------|------------|---------|--------------------------------|------------|
| 1T | | | | BLACK |
| | | | | |
| 2M | | | | BROWN |
| 1M•1B | | | | GRAY |
| 1M | | | | BLUE |
| | | | | |

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GEL264

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

POWER SUPPLY ROUTING


Circuit Diagram

Circuit Diagram

NGEL0005

NOTE:


For detailed ground distribution information, refer to "Ground Distribution", EL-18.



WEL812A

POWER SUPPLY ROUTING

Circuit Diagram (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

WEL108B

EL



IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02

⬡PS : With power socket
 ⬡FL : With fog lamps



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC

WEL808A

EL

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START

-NGEL0006S03

NOTE:

For detailed ground distribution information, refer to "Ground Distribution", EL-18.

EL-POWER-04



Refer to the following.

(M26), (M27), (E49), (E50), (E52)

| | | | | | |
|---|----|----|----|----|----|
| 1 | 6 | 11 | 16 | 21 | 25 |
| 2 | 7 | 12 | 17 | 22 | 26 |
| 3 | 8 | 13 | 18 | 23 | 27 |
| 4 | 9 | 14 | 19 | 24 | |
| 5 | 10 | 15 | 20 | | 28 |



- FUSE BLOCK - JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IXD

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05




Refer to the following.

(M26), (M27), (M31), (E49)
(E50), (E52)

| | | | | | |
|---|----|----|----|----|----|
| 1 | 6 | 11 | 16 | 21 | 25 |
| 2 | 7 | 12 | 17 | 22 | 26 |
| 3 | 8 | 13 | 18 | 23 | 27 |
| 4 | 9 | 14 | 19 | 24 | |
| 5 | 10 | 15 | 20 | | 28 |

- FUSE BLOCK - JUNCTION BOX (J/B)

WEL811A




Inspection

FUSE

NGEL0007

NGEL0007S01

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for “ELECTRICAL PARTS (BAT)” if vehicle is not used for a long period of time.




FUSIBLE LINK

NGEL0007S02

A melted fusible link can be detected either by visual inspection or by feeling with fingertip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



CIRCUIT BREAKER

NGEL0007S03

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- power window
- power door lock
- remote keyless entry

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

GROUND



Ground Distribution

Ground Distribution MAIN HARNESS

NGEL0171

NGEL0171S01

Body ground





| CONNECTOR NUMBER | CONNECT TO |
|------------------|--|
| M5 | Clutch interlock switch (Terminal No. 2) (with M/T) |
| M6 | Vehicle security relay (Terminal No. 3) (with power door locks)(with A/T, except KA24DE) |
| M11 | Warning chime unit (Terminal No. 8) (without power door locks) |
| M13 | Power window relay (Terminal No. 1) (with power windows) |
| M19 | Seat belt buckle switch LH (Terminal No. 2) |
| M27 | Fuse block (J/B) (Terminal No. 3N) <ul style="list-style-type: none"> • Accessory relay • Blower relay • Ignition relay |
| M28 | Illumination control switch (Terminal No. 5) |
| M32 | Data link connector (Terminal No. 4) |
| M35 | A/T device (shift lock) (Terminal No. 1) (with A/T) |
| M35 | A/T device (overdrive control switch) (Terminal No. 5) (with A/T) |
| M38 | Combination meter (Terminal No. 13) <ul style="list-style-type: none"> • Four wheel drive indicator • Turn signal indicators |
| M39 | Combination meter (Terminal No. 13) <ul style="list-style-type: none"> • ABS warning lamp |
| M76 | ATP relay (Terminal Nos. 2 and 4) (with 4-wheel drive and A/T) |
| M85 | Rear window defogger timer (Terminal No. 4) (without power door locks) |
| M89 | Rear wiper switch (Terminal No. 3) (with rear wiper) |
| M11 | Smart entrance control unit (Terminal No. 43) (with power door locks) |
| M112 | Smart entrance control unit (Terminal No. 64) (with power door locks) |
| M14 | Air bag diagnosis sensor unit (Terminal No. 2) |
| M19 | ASCD control unit (Terminal No. 17) (with ASCD) |
| M131 | Seat belt buckle switch RH (Terminal No. 2) |
| D7 | Main power window and door lock/unlock switch (with power door locks) (Terminal No. 10) |
| D9 | Front door key cylinder switch LH (with power door locks) (Terminal No. 2) |
| D10 | Door mirror remote control switch (Terminal No. 3) |

WEL818A

GROUND

Ground Distribution (Cont'd)

Body ground



WEL819A

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

GROUND


Ground Distribution (Cont'd)

ENGINE ROOM HARNESS KA24DE



NGEL0171S02

NGEL0171S0201

Body ground



Body ground





WEL820A

GROUND

Ground Distribution (Cont'd)

Body ground



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

WEL898A

HA

SC

EL

IDX



GROUND

Ground Distribution (Cont'd)

VG33E and VG33ER

NGEL0171S0202

Body ground




WEL821A


GROUND

Ground Distribution (Cont'd)


Body ground




Body ground



(B) To (E12)



| CONNECTOR NUMBER | CONNECT TO |
|------------------|--|
| (M6) | Vehicle security relay (Terminal No. 4) (with power door locks) |
| (E1) | Headlamp RH |
| (E17) | Daytime light control unit (Terminal No. 9) (for Canada) |
| (E19) | Front combination lamp RH (Terminal No. 2) • Parking lamp • Turn signal lamp |
| (E21) | ASCD relay (Terminal No. 2) (with A/T and ASCD) |
| (E22) | Vehicle security lamp relay (Terminal No. 2) |
| (E27) | Park/neutral position (PNP) relay (Terminal No. 1) (with A/T) |
| (E27) | Park/neutral position (PNP) relay (Terminal No. 6) (with A/T) |
| (E42) | Front wiper motor (Terminal No. E) |
| (E57) | Front fog lamp RH (Terminal No. 2) (with fog lamps) |
| (E86) | Side marker lamp RH (Terminal No. 2) |



| CONNECTOR NUMBER | CONNECT TO |
|------------------|---|
| (E39) | ABS actuator and electric unit (control unit) (Terminal No. 24) |

WEL822A

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

GROUND


Ground Distribution (Cont'd)

ENGINE NO. 2 HARNESS KA24DE

NGEL0171S08

NGEL0171S0801

Body ground



| CONNECTOR NUMBER | CONNECT TO |
|------------------|------------|
| E206 | Generator |



AEL710C

GROUND

Ground Distribution (Cont'd)

GENERATOR HARNESS VG33E and VG33ER

NGEL0171S03

NGEL0171S0301

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


AEL697C

SC


EL

IDX

Body ground



| CONNECTOR NUMBER | CONNECT TO |
|------------------|------------|
| A7 | Generator |




GROUND

Ground Distribution (Cont'd)



VG33E and VG33ER

NGEL0171S0402

Engine ground (VG33E)



Engine ground (VG33ER)



*Early production

WEL111B

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX



GROUND

Ground Distribution (Cont'd)

Engine ground (VG33E)



Engine ground (VG33ER)



WEL825A


GROUND

Ground Distribution (Cont'd)



BODY HARNESS

NGEL0171S05

Body ground



Body ground



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

LEL734

SC

EL

IDX


GROUND

Ground Distribution (Cont'd)



BODY NO. 2 HARNESS

NGEL0171S06

Body ground



Body ground



WEL826A


GROUND

Ground Distribution (Cont'd)



BACK DOOR NO. 2 HARNESS

NGEL0171S07

Body ground



Body ground



LEL736

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

COMBINATION SWITCH


Check

Check


NGEL0009



FRONT WIPER AND WASHER SWITCH (WITH INTERMITTENT OPERATION)



VARIABLE INTERMITTENT WIPER VOLUME



LIGHTING SWITCH

| | OFF | | | 1ST | | | 2ND | | |
|----|-----|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| | A | B | C | A | B | C | A | B | C |
| 5 | | | <input type="checkbox"/> | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 6 | | <input type="checkbox"/> | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 7 | | | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 8 | | | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 9 | | <input type="checkbox"/> | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 10 | | | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 11 | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 12 | | | | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

TURN SIGNAL LAMP SWITCH

| | R | N | L |
|---|--------------------------|--------------------------|--------------------------|
| 1 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 2 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 3 | | | <input type="checkbox"/> |




FRONT FOG LAMP SWITCH

| | OFF | ON |
|----|-----|--------------------------|
| 31 | | <input type="checkbox"/> |
| 32 | | <input type="checkbox"/> |

WEL112B

COMBINATION SWITCH

Replacement



Replacement

For removal and installation of spiral cable, refer to ^{NGEL0010} **RS-16**, "Driver Air Bag Module and Spiral Cable".

- Each switch can be replaced without removing combination switch base.

- To remove combination switch base, remove base attaching screws.

- Before installing the steering wheel, align the turn signal cancel tab with the notch of the combination switch. Refer to **RS-16**, "Driver Air Bag Module and Spiral Cable".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

STEERING SWITCH

Check

Check

NGEL0011



WEL113B

System Description

NGEL0012

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- through 15A fuse (No. 37, located in the fuse and fusible link box)
- to lighting switch terminal 5 and
- through 15A fuse (No. 38, located in the fuse and fusible link box)
- to lighting switch terminal 8.

GI

MA

EM

LOW BEAM OPERATION

NGEL0012S01

With the lighting switch in the headlamp ON (2ND) position and LOW BEAM (B) position, power is supplied

- from lighting switch terminal 10
- to headlamp LH terminal D and
- from lighting switch terminal 7
- to headlamp RH terminal D.

LC

EC

Ground is supplied to headlamp LH/RH terminal E through body grounds E12 and E54. With power and ground supplied, the low beams illuminate.

FE

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

NGEL0012S02

With the lighting switch in the FLASH-TO-PASS (C) position or the headlamp ON (2ND) position and HIGH BEAM (A) position, power is supplied

- from lighting switch terminal 6
- to headlamp RH terminal M and
- from lighting switch terminal 9
- to headlamp LH terminal M and
- to combination meter terminal 11 for the high beam indicator.

CL

MT

AT

Ground is supplied to terminal 10 of the combination meter through body grounds M14 and M68. Ground is supplied to headlamp LH/RH terminal E through body grounds E12 and E54. With power and ground supplied, the high beams and the high beam indicator illuminate.

TF

VEHICLE SECURITY SYSTEM

NGEL0012S03

The vehicle security system will flash the high beams if the system is triggered. Refer to "System Description", EL-222.

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX




HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP —

Wiring Diagram — H/LAMP —

NGEL0013

EL-H/LAMP-01



Refer to the following.
 E43 - SUPER
 MULTIPLE JUNCTION (SMJ)

HEADLAMP (FOR USA)

Trouble Diagnoses

Trouble Diagnoses

NGEL0014

| Symptom | Possible cause | Repair order | |
|--|--|--|----------------|
| Neither headlamp LH nor headlamp RH operate. | 1. Lighting switch | 1. Check lighting switch. | GI |
| Headlamp LH does not operate, but headlamp RH operates properly. | 1. Bulb 2. Headlamp LH ground circuit 3. 15A fuse 4. Lighting switch | 1. Check bulb. 2. Check continuity between headlamp LH terminal E and grounds E12 and E54. 3. Check 15A fuse (No. 38, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 of lighting switch. 4. Check lighting switch. | MA EM LC |
| Headlamp RH does not operate, but headlamp LH operates properly. | 1. Bulb 2. Headlamp RH ground circuit 3. 15A fuse 4. Lighting switch | 1. Check bulb. 2. Check continuity between headlamp RH terminal E and grounds E12 and E54. 3. Check 15A fuse (No. 37, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 of lighting switch. 4. Check lighting switch. | EC FE |
| High beam LH does not operate, but low beam LH operates. | 1. Bulb 2. Open in high beam LH circuit 3. Lighting switch | 1. Check bulb. 2. Check R/G wire between lighting switch terminal 9 and headlamp LH terminal M for an open circuit. 3. Check lighting switch. | CL MT |
| Low beam LH does not operate, but high beam LH operates. | 1. Bulb 2. Open in low beam LH circuit 3. Lighting switch | 1. Check bulb. 2. Check R wire between lighting switch terminal 10 and headlamp LH terminal D for an open circuit. 3. Check lighting switch. | AT |
| High beam RH does not operate, but low beam RH operates. | 1. Bulb 2. Open in high beam RH circuit 3. Lighting switch | 1. Check bulb. 2. Check R/W wire between lighting switch terminal 6 and headlamp RH terminal M for an open circuit. 3. Check lighting switch. | TF PD |
| Low beam RH does not operate, but high beam RH operates. | 1. Bulb 2. Open in low beam RH circuit 3. Lighting switch | 1. Check bulb. 2. Check R/B wire between lighting switch terminal 7 and headlamp RH terminal D for an open circuit. 3. Check lighting switch. | AX |
| High beam indicator does not work. | 1. Bulb 2. High beam indicator ground circuit 3. Open in high beam circuit | 1. Check bulb in combination meter. 2. Check continuity between combination meter terminal 10 and grounds M14 and M68. 3. Check R/G wire between lighting switch terminal 9 and combination meter terminal 11 for an open circuit. | SU BR |

ST

RS

BT

HA


SC

EL

IDX

HEADLAMP (FOR USA)

Bulb Replacement



Bulb Replacement

=NGEL0015

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**
1. Disconnect the battery cable.
 2. Disconnect the harness connector from the back side of the bulb.
 3. Remove bulb retaining ring.
 4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
 5. Install in the reverse order of removal.

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

Aiming Adjustment

NGEL0208

When performing headlamp aiming adjustment, use an aiming wall screen.

For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.

- 1) **Keep all tires inflated to correct pressures.**
- 2) **Place vehicle on flat surface.**
- 3) **See that the vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in the driver's seat.**


LOW BEAM

NGEL0208S01

NOTE:

The horizontal headlamp aim cannot be adjusted. Only vertical aim is adjustable.


1. Turn headlamp low beam on.



2. Use adjusting screw to adjust the vertical aim of the lamp.
- **Cover the opposite lamp and ensure fog lamps, if equipped, are turned off.**
 - **Adjust beam pattern until cut-off line (top edge of illumination area) is positioned at same height off ground as bulb center (on H-line). Measure cut-off line within distance A on H-line. See aiming chart following.**

HEADLAMP (FOR USA)

Aiming Adjustment (Cont'd)



WEL536A

If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- **Basic illuminating area (shaded) for adjustment should be within the range shown on the aiming chart. Adjust headlamps accordingly.**

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (For Canada)

System Description (For Canada)

NGEL0017

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied. If the daytime light control unit receives a ground signal from the generator, the daytime lights will not be illuminated. The daytime lights will illuminate once a battery positive voltage signal is sent to the daytime light control unit from the generator.

Power is supplied at all times

- through 15A fuse (No. 38, located in the fuse and fusible link box)
- to daytime light control unit terminal 3 and
- to lighting switch terminal 8.

Power is also supplied at all times

- through 15A fuse (No. 37, located in the fuse and fusible link box)
- to daytime light control unit terminal 2 and
- to lighting switch terminal 5.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 5, located in the fuse block (J/B)]
- to daytime light control unit terminal 12.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse [No. 7, located in the fuse block (J/B)]
- to daytime light control unit terminal 1.

Ground is supplied to daytime light control unit terminal 9 through body grounds E12 and E54.

HEADLAMP OPERATION

NGEL0017S01

Low Beam Operation

NGEL0017S0101

When the lighting switch is turned to the headlamp ON (2ND) position, LOW BEAM (B), power is supplied

- from lighting switch terminal 7
- to headlamp RH terminal D and
- to daytime light control unit terminal 4.

Ground is supplied to headlamp RH terminal E through body grounds E12 and E54.

Also, when the lighting switch is turned to the headlamp ON (2ND) position, LOW BEAM (B), power is supplied

- from lighting switch terminal 10
- to headlamp LH terminal D.

Ground is supplied

- to headlamp LH terminal E
- from daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through body grounds E12 and E54.

With power and ground supplied, the low beam headlamps illuminate.

High Beam Operation/Flash-to-pass Operation

NGEL0017S0102

When the lighting switch is turned to the headlamp ON (2ND) position, HIGH BEAM (A) or FLASH-TO-PASS (C) position, power is supplied

- from lighting switch terminal 6
- to headlamp RH terminal M and
- to daytime light control unit terminal 8.

Also, when the lighting switch is turned to the headlamp ON (2ND) position, HIGH BEAM (A) or FLASH-TO-PASS (C) position, power is supplied

- from lighting switch terminal 9
- to combination meter terminal 11 for the high beam indicator and
- to daytime light control unit terminal 5
- through daytime light control unit terminal 6

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (For Canada) (Cont'd)

- to headlamp LH terminal M.

Ground is supplied in the same manner as low beam operation.

Ground is supplied to combination meter terminal 10 through body grounds M14 and M68.

With power and ground supplied, the high beam headlamps and HI BEAM indicator illuminate.

DAYTIME LIGHT OPERATION

NGEL0017S02

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal 6
- to headlamp LH terminal M
- through headlamp LH terminal E
- to daytime light control unit terminal 7
- through daytime light control unit terminal 8
- to headlamp RH terminal M.

Ground is supplied to headlamp RH terminal E through body grounds E12 and E54.

Because the high beam headlamps are now wired in series, they operate at half illumination.

OPERATION (FOR CANADA)

NGEL0017S03

After starting the engine with the lighting switch in the OFF or parking lamp (1ST) position, the headlamp high beams automatically turn on. Lighting switch operations other than the above are the same as conventional light systems.

| Engine | | With engine stopped | | | | | | | | | With engine running | | | | | | | | |
|--|---|---------------------|-----------|---|-----|---|---|-----|---|---|---------------------|---|----|-----|---|----|-----|---|---|
| | | OFF | | | 1ST | | | 2ND | | | OFF | | | 1ST | | | 2ND | | |
| Lighting switch | | A | B | C | A | B | C | A | B | C | A | B | C | A | B | C | A | B | C |
| | | Headlamp | High beam | X | X | O | X | X | O | O | X | O | △* | △* | O | △* | △* | O | O |
| Low beam | X | | X | X | X | X | X | X | O | X | X | X | X | X | X | X | X | O | X |
| Clearance and tail lamp | | X | X | X | O | O | O | O | O | O | X | X | X | O | O | O | O | O | O |
| License and instrument illumination lamp | | X | X | X | O | O | O | O | O | O | X | X | X | O | O | O | O | O | O |

A: HIGH BEAM position

B: LOW BEAM position

C: FLASH-TO-PASS position

O : Lamp ON

X : Lamp OFF

△ : Lamp dims. (Added functions)

*: When starting the engine with the parking brake released, the daytime lights will come ON.

When starting the engine with the parking brake pulled, the daytime lights won't come ON.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Circuit Diagram

Circuit Diagram

NGEL0019



LEL714A


HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL —

Wiring Diagram — DTRL —

NGEL0020

EL-DTRL-01






GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST

RS
BT
HA
SC

EL

IDX






Refer to the following.
 (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

WEL657A

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02




LEL658A

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



Refer to the following.
(E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

WEL659A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses

Trouble Diagnoses

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

NGEL0021

NGEL0021S01

| Terminal No. | Wire color | Item | Condition | Voltage (Approx.) |
|--------------|------------|--|---|-------------------|
| 1 | L/OR | Ignition switch start signal | Ignition switch in START position | 12 |
| | | | All other conditions | 0 |
| 2 | Y/G | Power source for headlamp RH | — | 12 |
| 3 | Y/B | Power source for headlamp LH | — | 12 |
| 4 | R/B | Lighting switch headlamp RH low beam output | Lighting switch in the headlamp ON (2ND) position and LOW BEAM (B) position | 12 |
| | | | All other conditions | 0 |
| 5 | R/G | Lighting switch headlamp LH high beam output | Lighting switch in the FLASH-TO-PASS (C) position or headlamp ON (2ND) position and HIGH BEAM (A) position | 12 |
| | | | All other conditions | 0 |
| 6 | R/Y | Headlamp LH high beam | Lighting switch in the FLASH-TO-PASS (C) position or headlamp ON (2ND) position and HIGH BEAM (A) position | 12 |
| | | | With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions CAUTION: Block wheels and ensure selector lever is in P or N position. | 12 |
| | | | All other conditions | 0 |
| 7 | B/W | Headlamp LH control (ground) | Lighting switch in the FLASH-TO-PASS (C) position or headlamp ON (2ND) position | 0 |
| | | | All other conditions | 6 |
| 8 | R/W | Lighting switch headlamp RH high beam output | Lighting switch in the FLASH-TO-PASS (C) position or headlamp ON (2ND) position and HIGH BEAM (A) position | 12 |
| | | | With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions CAUTION: Block wheels and ensure selector lever is in P or N position. | 6 |
| | | | All other conditions | 0 |
| 9 | B | Ground | — | — |
| 10 | Y | Parking brake switch | Parking brake released | 12 |
| | | | Parking brake set | 0 |
| 11 | Y/B | Generator (L terminal) | When engine is running | 12 |
| | | | All other conditions | 0 |

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

| | | | | | |
|----|-----|---------------------------|-------------------------------------|----|----|
| 12 | G/W | Ignition switch on signal | Ignition switch OFF, ACC positions | 0 | GI |
| | | | Ignition switch ON, START positions | 12 | |

GI

MA

EM

LC

Bulb Replacement

Refer to "Bulb Replacement", EL-38.

NGEL0022

EC

FE

CL

MT

Aiming Adjustment

Refer to "Aiming Adjustment", EL-38.

NGEL0023

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

Wiring Diagram — TAIL/L —

NGEL0024

EL-TAIL/L-01




⬡KA : With KA24DE
 ⬡XK : Except KA24DE

Refer to "EL-POWER".

Refer to the following.

⬡E43 - SUPER
 MULTIPLE JUNCTION (SMJ)



WEL144B








STOP LAMP

Wiring Diagram — STOP/L —

Wiring Diagram — STOP/L —

NGEL0025

EL-STOP/L-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST

RS
BT
HA
SC

WEL661A

EL

IDX


BACK-UP LAMP

Wiring Diagram — BACK/L —

Wiring Diagram — BACK/L —




NGEL0026

EL-BACK/L-01



Refer to "EL-POWER".

- ⬡ A : With A/T
- ⬡ KA : With KA24DE
- ⬡ XK : Except KA24DE
- ⬡ MK : With M/T and KA24DE
- ⬡ MV : With M/T and except KA24DE



Refer to the following.
 (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

System Description

NGEL0027

Power is supplied at all times

- through 15A fuse (No. 40, located in the fuse and fusible link box)
- to front fog lamp relay terminal 5 and
- through 15A fuse (No. 37, located in the fuse and fusible link box)
- to lighting switch terminal 5.

With the lighting switch in the headlamp ON (2ND) position and LOW BEAM (B) position, power is supplied

- through lighting switch terminal 7
- to front fog lamp switch terminal 1.

FRONT FOG LAMP OPERATION

NGEL0027S01

The front fog lamp switch is built into the combination switch. The lighting switch must be in the headlamp ON (2ND) position and LOW BEAM (B) position for front fog lamp operation.

With the front fog lamp switch in the ON position:

- power is supplied to front fog lamp relay terminal 2
- through front fog lamp switch terminal 2
- through front fog lamp switch terminal 1.

The front fog lamp relay is energized and power is supplied

- through front fog lamp relay terminal 3
- to front fog lamp LH/RH terminal 1.

Ground is supplied to front fog lamp LH/RH terminal 2 and front fog lamp relay terminal 1 through body grounds E12 and E54.

With power and ground supplied, the front fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX






FRONT FOG LAMP

Wiring Diagram — F/FOG —

Wiring Diagram — F/FOG —


NGEL0028

EL-F/FOG-01



FRONT FOG LAMP

Aiming Adjustment




Aiming Adjustment

NGEL0029


Before performing aiming adjustment, make sure of the following.

- 1) Keep all tires inflated to correct pressure.
- 2) Place vehicle on level ground.
- 3) See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Loosen front fog lamp adjusting nuts and adjust aiming by moving front fog lamps.



1. Set the distance between the screen and the center of the front fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.
- **When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.**
4. Tighten the front fog lamp adjusting nuts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

FRONT FOG LAMP


Removal and Installation

Removal and Installation

=NGEL0184

1. Disconnect front fog lamp harness connector.
2. Remove mounting bolt and remove lens and housing assembly from front bumper cover.
3. Install in reverse order of removal. Ensure top of lens faces up.
4. Tighten mounting bolt.

 : 5 – 6 N·m (0.51 – 0.61 kg·m, 44.3 – 53.1 in·lb)



Bulb and Lens Replacement

NGEL0185

1. Remove front fog lamp. Refer to "Removal and Installation", EL-54.
2. Remove bulb cover.
3. Release the spring retainer.
4. Disconnect fog lamp bulb connector.
5. Remove fog lamp bulb.
6. Install in reverse order of removal. Ensure top of lens faces up. **DO NOT TOUCH BULB.**

System Description

NGEL0030

TURN SIGNAL OPERATION

NGEL0030S01

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 2, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through the hazard switch terminal 1
- to combination flasher unit terminal B
- through combination flasher unit terminal L
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal E through body grounds M14 and M68.

LH Turn

NGEL0030S0101

With the turn signal switch in the LH position, power is supplied from turn signal switch terminal 3 to

- front combination lamp LH terminal 1
- combination meter terminal 11 and
- rear combination lamp LH terminal 3.

Ground is supplied to front combination lamp LH terminal 2 through body grounds E12 and E54.

Ground is supplied to rear combination lamp LH terminal 2 through body grounds B6 and B10.

Ground is supplied to combination meter terminal 36 through body grounds M14 and M68.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH Turn

NGEL0030S0102

With the turn signal switch in the RH position, power is supplied from turn signal switch terminal 2 to

- front combination lamp RH terminal 1
- combination meter terminal 28 and
- rear combination lamp RH terminal 3.

Ground is supplied to the front combination lamp RH terminal 2 through body grounds E12 and E54.

Ground is supplied to the rear combination lamp RH terminal 2 through body grounds B106 and B116.

Ground is supplied to combination meter terminal 36 through body grounds M14 and M68.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

NGEL0030S02

Power is supplied at all times to hazard switch terminal 3 through:

- 10A fuse [No. 17, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through hazard switch terminal 1
- to combination flasher unit terminal B
- through combination flasher unit terminal L
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal E through body grounds M14 and M68.

Power is supplied through hazard switch terminal 5 to

- front combination lamp LH terminal 1
- combination meter terminal 11 and
- rear combination lamp LH terminal 3.

Power is supplied through hazard switch terminal 6 to

- front combination lamp RH terminal 1
- combination meter terminal 28 and
- rear combination lamp RH terminal 3.

Ground is supplied to front combination lamp LH/RH terminal 2 through body grounds E12 and E54.

Ground is supplied to rear combination lamp LH terminal 2 through body grounds B6 and B10.

Ground is supplied to rear combination lamp RH terminal 2 through body grounds B106 and B116.

Ground is supplied to combination meter terminal 36 through body grounds M14 and M68.

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

REMOTE KEYLESS ENTRY SYSTEM OPERATION

NGEL0030S04

Power is supplied at all times to smart entrance control unit terminal 49

- through 9.5A fuse [No. 28, located in the fuse block (J/B)].

Ground is supplied to smart entrance control unit terminals 43 and 64.

Refer to "REMOTE KEYLESS ENTRY SYSTEM", EL-203.

When smart entrance control unit receives LOCK or UNLOCK signal from key fob with all doors closed, power is supplied through smart entrance control unit terminal 47

- to front combination lamp LH terminal 1
- to combination meter terminal 11
- to rear combination lamp LH terminal 3.

Power is supplied through smart entrance control unit terminal 48

- to front combination lamp RH terminal 1
- to combination meter terminal 28
- to rear combination lamp RH terminal 3.

Ground is supplied to terminal 2 of each front combination lamp through body grounds E12 and E54.

Ground is supplied to terminal 2 of rear combination lamp LH through body grounds B6 and B10.

Ground is supplied to terminal 2 of rear combination lamp RH through body grounds B106 and B116.

Ground is supplied to combination meter terminal 36 through body grounds M14 and M68.

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.





TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

Wiring Diagram — TURN —

NGEL0032

EL-TURN-01




Refer to the following.
 (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

WEL664A




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)



KA : With KA24DE
 XK : Except KA24DE



WEL665A


TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

Trouble Diagnoses

NGEL0033

| Symptom | Possible cause | Repair order |
|--|---|---|
| Turn signal and hazard warning lamps do not operate. | <ol style="list-style-type: none"> 1. 7.5A fuse 2. 10A fuse 3. Hazard switch 4. Combination flasher unit 5. Open in combination flasher unit circuit | <ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 2, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check 10A fuse [No. 17, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. 3. Check hazard switch. 4. Refer to combination flasher unit check. 5. Check wiring to combination flasher unit for open circuit. |
| Turn signal lamps do not operate but hazard warning lamps operate. | <ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit | <ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 2, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check G wire between combination flasher unit and turn signal switch for open circuit. Check the harness between turn signal switch and front combination lamp for an open circuit. |
| Hazard warning lamps do not operate but turn signal lamps operate. | <ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit | <ol style="list-style-type: none"> 1. Check 10A fuse [No. 17, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check G wire between combination flasher unit and hazard switch for open circuit. |
| Front turn signal lamp LH or RH does not operate. | <ol style="list-style-type: none"> 1. Bulb 2. Front turn signal lamp ground circuit | <ol style="list-style-type: none"> 1. Check bulb. 2. Check front turn signal lamp ground circuit. |
| Rear turn signal lamp LH does not operate. | <ol style="list-style-type: none"> 1. Bulb 2. Rear turn signal lamp LH ground circuit | <ol style="list-style-type: none"> 1. Check bulb. 2. Check rear turn signal lamp LH ground circuit. |
| Rear turn signal lamp RH does not operate. | <ol style="list-style-type: none"> 1. Bulb 2. Rear turn signal lamp RH ground circuit | <ol style="list-style-type: none"> 1. Check bulb. 2. Check rear turn signal lamp RH ground circuit. |
| LH and RH turn indicators do not operate. | <ol style="list-style-type: none"> 1. Ground circuit | <ol style="list-style-type: none"> 1. Check ground circuit. |
| LH or RH turn indicator does not operate. | <ol style="list-style-type: none"> 1. Bulb 2. Turn indicator circuit | <ol style="list-style-type: none"> 1. Check bulb in cluster lid A. 2. Check continuity between combination meter terminals 12, 14 and 13. |



Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NGEL0034

NGEL0034S01

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TRAILER TOW

System Description

System Description

NGEL0161

Power is supplied at all times

- through 15A fuse [No. 22, located in the fuse block (J/B)]
- to trailer tow control unit terminal 6.

Ground is supplied

- to trailer tow control unit terminal 7 and
- to trailer harness connector terminal 1
- through body grounds B106 and B116.

TRAILER TAIL LAMP OPERATION

NGEL0161S01

With the lighting switch in the parking and tail lamp ON (1ST) or headlamp ON (2ND) position, power is supplied

- from lighting switch terminal 12
- to trailer harness connector terminal 2.

TRAILER STOP, TURN SIGNAL AND HAZARD LAMP OPERATION

NGEL0161S02

The trailer stop, turn signal and hazard lamps are all controlled by the trailer tow control unit. The trailer tow control unit regulates the amount of voltage supplied to the trailer lamps. If either turn signal or the hazard lamps are turned on and the trailer tow control unit gets a brake lamp input, the trailer tow control unit supplies more voltage to the trailer lamps to make them illuminate brighter.

Power is supplied to trailer tow control unit terminal 6 through 15A fuse (No. 22, located in the fuse block) at all times.

Stop lamp input is supplied to trailer tow control unit terminal 3.

Left turn signal and hazard lamp input is supplied to trailer tow control unit terminal 4.

Right turn signal and hazard lamp input is supplied to trailer tow control unit terminal 1.

Based on the stop lamp, turn signal lamp and hazard lamp inputs to the trailer tow control unit, power is supplied to trailer stop/turn lamp LH

- from trailer tow control unit terminal 8
- to trailer harness connector terminal 3.

Power is also supplied to trailer stop/turn lamp RH

- from trailer tow control unit terminal 5
- to trailer harness connector terminal 4.



TRAILER TOW

Wiring Diagram — T/TOW —

Wiring Diagram — T/TOW —

NGEL0162

EL-T/TOW-01



Refer to the following.
E43 - SUPER
 MULTIPLE JUNCTION (SMJ)

WEL666A

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TRAILER TOW

Trouble Diagnoses

Trouble Diagnoses

TRAILER TOW CONTROL UNIT INSPECTION TABLE

NGEL0163
NGEL0163S01

| Terminal No. | Wire color | Item | Condition | Voltage (Approx.) |
|--------------|------------|----------------------------|--|---------------------|
| 1 | G/R | RH turn lamps input | When RH turn lamps or hazard lamps operate | 12 (intermittently) |
| | | | All other conditions | 0 |
| 3 | BR/R | Stop lamps signal input | When brake pedal is depressed | 12 |
| | | | When brake pedal is released | 0 |
| 4 | G/Y | LH turn lamps input | When LH turn lamps or hazard lamps operate | 12 (intermittently) |
| | | | All other conditions | 0 |
| 5 | G | Stop/RH turn lamp (output) | When brake pedal is depressed | 12 |
| | | | When RH turn lamps or hazard lamps operate | 12 (intermittently) |
| | | | All other conditions | 0 |
| 6 | R/B | Power supply | — | 12 |
| 7 | B | Ground | — | — |
| 8 | Y | Stop/LH turn lamp (output) | When brake pedal is depressed | 12 |
| | | | When LH turn lamps or hazard lamps operate | 12 (intermittently) |
| | | | All other conditions | 0 |

ILLUMINATION

System Description

System Description

NGEL0035

Power is supplied at all times

- through 15A fuse (No. 39, located in the fuse and fusible link box)
- to lighting switch terminal 11.

The lighting switch must be in the parking and tail lamps ON (1ST) or headlamps ON (2ND) position for illumination.

The illumination control switch controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

| Component | Connector No. | Power terminal | Ground terminal |
|---|---------------|----------------|-----------------|
| Illumination control switch | M28 | 1 | 5 |
| Air control | M95 | 10 | 9 |
| Audio unit | M51 | 8 | 7 |
| Hazard switch | M53 | 7 | 8 |
| Rear wiper switch | M89 | 4 | 5 |
| Compass and thermometer | R5 | 3 | 4 |
| Combination meter | M39 | 30, 32 | 42 |
| Main power window and door lock/unlock switch | D7 | 3 | 8 |
| A/T device | M35 | 4 | 3 |

The ground for all of the components are controlled through terminals 4 and 5 of the illumination control switch and body grounds M14 and M68.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


ILLUMINATION

Wiring Diagram — ILL —


Wiring Diagram — ILL —

NGEL0037

EL-ILL-01



⬡ : With compass and thermometer



Refer to the following.
 (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

WEL667A

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-02

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST


RS

BT

HA

SC

⬡A⬡ : With A/T
 ⬡DL⬡ : With power door locks



WEL115B

EL









IDX

INTERIOR ROOM LAMP

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0194



System Description

MODELS WITHOUT POWER DOOR LOCKS

NGEL0038

Room Lamp

NGEL0038S01

NGEL0038S0106

Power is supplied at all times

- through 7.5A fuse [No. 26, located in the fuse block (J/B)]
- to front room lamp terminal + and
- to rear room lamp terminal +.

With the front/rear room lamp switch in the ON position, ground is supplied through the case of the front/rear room lamp.

With one or more doors open, with the front/rear room lamp switch in the DOOR position, ground is supplied

- to front/rear room lamp terminal DR
- through front door switch LH terminal 1 and/or
- through front door switch RH, rear door switch LH/RH and/or back door switch terminal +.

Ground is supplied to back door switch terminal – through body grounds D402 and D404.

MODELS WITH POWER DOOR LOCKS

Room Lamp

NGEL0038S06

NGEL0038S0601

Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to smart entrance control unit terminal 49.

With the front/rear room lamp or map lamp switches in the ON position, ground is supplied

- through the case of the front/rear room lamp or
- through body grounds M14 and M68
- to map lamp terminal –.

Power is also supplied

- to front/rear room lamp or map lamp terminal +
- from smart entrance control unit terminal 50.

With the front door LH open and the front/rear room lamp switch in the DOOR position, ground is supplied

- to front/rear room lamp terminal DR
- through front door switch LH terminal 1 and
- to smart entrance control unit terminal 1
- through front door switch LH terminal 2
- through body grounds B6 and B10.

With the front door RH open and the front/rear room lamp switch in the DOOR position, ground is supplied

- to smart entrance control unit terminal 2
- through front door switch RH terminal + and
- to front/rear room lamp terminal DR
- through smart entrance control unit terminal 31
- through smart entrance control unit terminal 43 and 64
- through body grounds M14 and M68.

With rear door LH/RH and/or back door open and the front/rear room lamp switch in the DOOR position, ground is supplied

- to smart entrance control unit terminal 3 (with vehicle security system) or terminal 2 (without vehicle security system)
- through rear door switch LH/RH and/or back door switch terminal + and
- to front/rear room lamp terminal DR
- through smart entrance control unit terminal 31
- through smart entrance control unit terminal 43 and 64
- through body grounds M14 and M68.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

INTERIOR ROOM LAMP

System Description (Cont'd)

Room Lamp Timer Operation

-NGEL0038S0603

When the room lamp switch is in the DOOR position, the smart entrance control unit keeps the room lamp illuminated for about 30 seconds when:

- unlock signal is supplied from driver door lock and unlock switch while all doors are closed and key is removed from ignition key cylinder
- unlock signal is supplied from key fob while all doors are closed and driver door is locked
- key is removed from ignition key cylinder while driver door is closed
- driver door is opened and then closed while key is removed from ignition key cylinder. (However, if the driver door is closed with the key inserted in the ignition key cylinder after the driver door is opened with key removed, the timer is operated.)

The timer is canceled when:

- driver door is locked, or
- driver door is opened or
- ignition switch is turned ON.

ON-OFF CONTROL

NGEL0038S0602

When the driver door, front passenger door, rear LH, RH door or back door is opened, the interior room lamp turns on while the room lamp switch is in the "DOOR" position.

BATTERY SAVER

NGEL0038S0604

The lamp turns off automatically when front/rear room lamp, map lamp is illuminated with the ignition key in the OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in ON position for more than 30 minutes.

After lamps turn OFF by the battery saver system, the lamps illuminate again when:






- driver door is locked or unlocked,
- door is opened or closed,
- key is inserted in or removed from ignition key cylinder.

INTERIOR ROOM LAMP

Wiring Diagram — ROOM/L — (Cont'd)

MODELS WITH POWER DOOR LOCKS

NGEL0040S02





WEL670A

INTERIOR ROOM LAMP

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-03

: With vehicle security system



WEL117B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR ROOM LAMP

Trouble Diagnosis


Trouble Diagnosis

SYMPTOM: Front and rear room lamp does not turn on or off properly. NGEL0207

MODELS WITHOUT POWER DOOR LOCKS NGEL0207S01

| | | | |
|---|--|--|--|
| 1 | CHECK FRONT AND REAR ROOM LAMP FUSE | | |
| Check 7.5 A fuses [No. 26 located in fuse block (J/B)]. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Replace fuse and check harness for short between fuse and front and rear room lamps. | |

| | | | |
|---|--|--|--|
| 2 | CHECK FRONT AND REAR ROOM LAMP SWITCH SIGNALS | | |
| 1. Close all doors, turn ON front and rear room lamp switches. Do front and rear room lamps turn on? 2. Turn off front and rear room lamp switches. Do front and rear room lamps turn off? | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Check the following. <ul style="list-style-type: none"> ● Front or rear room lamp switch ● Front or rear room lamp switch ground circuit ● Harness for open or short between front or rear room lamp switch and front door switch LH, front door switch RH, rear door switch LH, rear door switch RH or back door switch | |

| 3 | CHECK FRONT AND REAR ROOM LAMP POWER SUPPLY | | | | | | | | | | | | | | | | |
|---|--|---|-------------|--|-----------|--|-------------|-----|-----|-----------------|---|--------|------------|----------------|---|--------|------------|
| Check voltage between front room lamp connector R2, or rear room lamp connector R3 terminal + (R/G) and ground. | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Front room lamp</td> <td style="text-align: center;">+</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td>Rear room lamp</td> <td style="text-align: center;">+</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">Approx. 12</td> </tr> </tbody> </table> | | | | | Terminals | | Voltage [V] | (+) | (-) | Front room lamp | + | Ground | Approx. 12 | Rear room lamp | + | Ground | Approx. 12 |
| | Terminals | | Voltage [V] | | | | | | | | | | | | | | |
| | (+) | (-) | | | | | | | | | | | | | | | |
| Front room lamp | + | Ground | Approx. 12 | | | | | | | | | | | | | | |
| Rear room lamp | + | Ground | Approx. 12 | | | | | | | | | | | | | | |
| LEL341A | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | |
| NG | ▶ | Check harness for open between fuse and front or rear room lamps. | | | | | | | | | | | | | | | |

| | | | |
|--------------------------------|--------------------------------------|---------------|--|
| 4 | CHECK INTERIOR ROOM LAMP BULB | | |
| Check interior room lamp bulb. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 5. | |
| NG | ▶ | Replace bulb. | |

INTERIOR ROOM LAMP

Trouble Diagnosis (Cont'd)


| | | | |
|---|---|--|--|
| 5 | CHECK KEY SWITCH (INSERTED) AND IGNITION ON SIGNAL | | |
| 1. Insert key into ignition key cylinder. 2. Open front door LH. Does warning chime sound? 3. Turn ignition key to ON position. Does warning chime stop sounding? | | | |
| YES or NO | | | |
| YES | ▶ | Check harness for open or short between front or rear room lamp switch and front door switch LH, front door switch RH, rear door switch LH, rear door switch RH or back door switch. | |
| NO | ▶ | Check "WARNING CHIME" system, refer to EL-103. | |

MODELS WITH POWER DOOR LOCKS

NGEL0207S02

| | | | |
|---|--|--|--|
| 1 | CHECK FRONT AND REAR ROOM LAMP FUSE | | |
| Check 7.5 A fuses [No. 28 located in fuse block (J/B)]. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | Replace fuse and check harness for short between fuse and front and rear room lamps. | |

| | | | |
|---|--|---|--|
| 2 | CHECK FRONT AND REAR ROOM LAMP SWITCH SIGNALS | | |
| 1. Close all doors, turn ON front and rear room lamp switches. Do front and rear room lamps turn on? 2. Turn off front and rear room lamp switches. Do front and rear room lamps turn off? | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Check the following. <ul style="list-style-type: none"> ● Front or rear room lamp switch ● Front or rear room lamp switch ground circuit ● Harness for open or short between front or rear room lamp switch and smart entrance control unit | |

| 3 | CHECK FRONT AND REAR ROOM LAMP POWER SUPPLY | | | | | | | | | | | | | | | | |
|--|--|---|-------------|--|-----------|--|-------------|-----|-----|-----------------|---|--------|------------|----------------|---|--------|------------|
| Check voltage between front room lamp connector R2, or rear room lamp connector R3 terminal + (R/G) and ground. | | | | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  <p>Room lamp connector</p> </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Front room lamp</td> <td>+</td> <td>Ground</td> <td>Approx. 12</td> </tr> <tr> <td>Rear room lamp</td> <td>+</td> <td>Ground</td> <td>Approx. 12</td> </tr> </tbody> </table> </div> | | | | | Terminals | | Voltage [V] | (+) | (-) | Front room lamp | + | Ground | Approx. 12 | Rear room lamp | + | Ground | Approx. 12 |
| | Terminals | | Voltage [V] | | | | | | | | | | | | | | |
| | (+) | (-) | | | | | | | | | | | | | | | |
| Front room lamp | + | Ground | Approx. 12 | | | | | | | | | | | | | | |
| Rear room lamp | + | Ground | Approx. 12 | | | | | | | | | | | | | | |
| LEL341A | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | |
| OK | ▶ | GO TO 4. | | | | | | | | | | | | | | | |
| NG | ▶ | Check harness for open between fuse and front or rear room lamps. | | | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR ROOM LAMP

Trouble Diagnosis (Cont'd)

| 4 | | CHECK INTERIOR ROOM LAMP BULB |
|--------------------------------|---|-------------------------------|
| Check interior room lamp bulb. | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Replace bulb. |

| 5 | | CHECK KEY SWITCH (INSERTED) AND IGNITION ON SIGNAL |
|---|---|--|
| 1. Insert key into ignition key cylinder. 2. Open front door LH. Does warning chime sound? 3. Turn ignition key to ON position. Does warning chime stop sounding? | | |
| YES or NO | | |
| YES | ▶ | GO TO 6. |
| NO | ▶ | Check "WARNING CHIME" system, refer to EL-103. |








| 6 | | CHECK DOOR SWITCH INPUT SIGNAL |
|--|---|--|
| Unlock doors using LH door key cylinder Do the doors unlock? | | |
| YES or NO | | |
| YES | ▶ | Replace smart entrance control unit. |
| NO | ▶ | Refer to "DOOR KEY CYLINDER SWITCH CHECK", EL-200. |

METERS AND GAUGES

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0041



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

WEL916A

METERS AND GAUGES

System Description

System Description

NGEL0042


UNIFIED CONTROL METER

NGEL0042S06

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by unified meter control unit combined with speedometer and odo/trip meter.
- Digital meter is adopted for odo/trip meter.*
*The record of the odometer is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

NGEL0042S07



NOTE:

Turn ignition switch ON to operate odo/trip meter.

POWER SUPPLY AND GROUND CIRCUIT

NGEL0042S08

Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to combination meter terminal 31.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminal 32.

Ground is supplied

- to combination meter terminal 33
- through body grounds M14 and M68.

FUEL GAUGE

NGEL0042S03

The fuel gauge indicates the approximate fuel level in the fuel tank. The reading on the gauge is based on the resistance of the fuel level sensor unit.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 47 for the fuel gauge
- through fuel level sensor unit terminal 2
- through fuel level sensor unit terminal 4
- through body grounds B106 and B116.

METERS AND GAUGES

System Description (Cont'd)

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

The water temperature gauge is regulated by a variable ground signal supplied

- to combination meter terminal 46
- through thermal transmitter terminal 1.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases and the needle on the gauge moves from C to H.

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- to combination meter terminal 48 for the tachometer
- from ECM terminal 3.

SPEEDOMETER

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals 34 and 35 for the speedometer
- from vehicle speed sensor terminals 1 and 2.

The unified meter control unit converts the voltage to the vehicle speed and displays it on the speedometer.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

METERS AND GAUGES

Combination Meter

Combination Meter

NGEL0043



| | | | | | | | | | | | | | |
|-----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| M39 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 |
| | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | | |

| Bulb socket color | Bulb wattage |
|-------------------|--------------|
| Brown | 1.4 W |
| Black | 3.0 W |

() : Bulb socket color



| | | | | | | | | | | | | | |
|-----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| M38 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | | |

- A4 : With A/T and 4-wheel drive
- A : With A/T
- N : For Canada
- U : For USA
- AS : With ASCD
- 4W : With 4-wheel drive
- XK : Except with KA24DE engine

LEL894A

METERS AND GAUGES

Combination Meter (Cont'd)



- (4A) : With A/T and 4-wheel drive
- (A) : With A/T
- (AS) : With ASCD
- (4W) : With 4-wheel drive
- (XK) : Except KA24DE
- (2W) : With 2-wheel drive

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

WEL118B

EL


IDX

METERS AND GAUGES



Wiring Diagram — METER —

Wiring Diagram — METER —

NGEL0045






- ⬡ : With A/T
 - ⬢ : With M/T
 - ⬤ : With KA24DE
 - ⬢ : With VG33E
 - ⬢ : With VG33ER
 - ⬢ : Except VG33ER
 - ⬢ : Except KA24DE
- * 1 ⬢ : 4
 - ⬢ : 5
 - * 2 ⬢ : 3
 - ⬢ : 4



Refer to the following.

- ⬢ - SUPER MULTIPLE JUNCTION (SMJ)
- ⬢ - ELECTRICAL UNITS
- ⬢, ⬢ - FUSE BLOCK (J/B)



WEL119B

METERS AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

NGEL0151

GI

DIAGNOSIS FUNCTION

NGEL0151S01

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

MA

HOW TO ALTERNATE DIAGNOSIS MODE

NGEL0151S02

EM

1. Turn ignition switch ON while pressing and holding trip reset switch for 0.8 second.
2. Push trip reset switch 3 times within 7 seconds.
3. All odo/trip meter segments should be turned on.

LC

NOTE:

EC



If some segments are not turned on, speedometer (unified meter control unit) with odo/trip meter should be replaced.

FE

At this point, the unified meter control unit is in diagnosis mode.

CL

MT



4. Push odo/trip meter switch. Indication of each meter/gauge should be as shown in figure at left while pushing odo/trip meter switch if it is not malfunctioning.

AT

NOTE:

TF

It takes about 1 minute for indication of fuel gauge to become stable.

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


METERS AND GAUGES

Trouble Diagnoses

Trouble Diagnoses PRELIMINARY CHECK

NGEL0046

NGEL0046S04



WEL835A

*1: EL-81

*2: EL-84

*3: EL-83

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

-NGEL0046S05

| Symptom | Possible causes | Repair order |
|---|--|--|
| Speedometer and odo/trip meter are malfunctioning. | <ul style="list-style-type: none"> ● Signal - Speedometer, Odo/Trip meter ● Unified meter control unit | <ol style="list-style-type: none"> 1. Check vehicle speed sensor. Refer to INSPECTION/VEHICLE SPEED SENSOR, EL-85. 2. Replace combination meter. |
| Multiple meters/gauges are malfunctioning (except speedometer, odo/trip meter). | <ul style="list-style-type: none"> ● Unified meter control unit | <ul style="list-style-type: none"> ● Replace combination meter. |
| One gauge (tachometer, fuel gauge or water temp. gauge) is malfunctioning. | <ul style="list-style-type: none"> ● Unified meter control unit | <ol style="list-style-type: none"> 1. Replace combination meter. |

Before starting trouble diagnoses above, refer to "PRELIMINARY CHECK", EL-82.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT CHECK

=NGEL0046S07


Power Supply Circuit Check

NGEL0046S0701

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | | | |
| Connector | Terminal (wire color) | | | | |
| M39 | 31 (R/Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| M39 | 32 (W/B) | Ground | 0V | 0V | Battery voltage |

If NG, check the following.

- 7.5A fuse [No. 28, located in fuse block (J/B)]
- 10A fuse [No. 11, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter



Ground Circuit Check

NGEL0046S0702




| Terminals | | Continuity | |
|-----------|-----------------------|------------|-----|
| (+) | | (-) | |
| Connector | Terminal (wire color) | | |
| M39 | 33 (B/R) | Ground | Yes |



METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/VEHICLE SPEED SENSOR

=NGEL0046S03

| | | | |
|----------|--|---|---|
| 1 | CHECK VEHICLE SPEED SENSOR OUTPUT | <p>1. Remove vehicle speed sensor from transmission.</p> <p>2. Check voltage between combination meter connector M39 terminal 34 (BR/W) and terminal 35 (SB) while quickly turning speed sensor pinion.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Combination meter harness connector</p> </div> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <p style="color: blue; font-weight: bold;">Voltage: Approx. 0.5V</p> <p style="text-align: center; font-weight: bold;">OK or NG</p> | <p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> |
| OK | ▶ | Vehicle speed sensor is OK. | |
| NG | ▶ | GO TO 2. | |

| | | | |
|----------|-----------------------------------|--|---|
| 2 | CHECK VEHICLE SPEED SENSOR | <p>Check resistance between vehicle speed sensor terminals 1 and 2.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Vehicle speed sensor</p> </div> <div style="text-align: center;">  </div> </div> <p style="color: blue; font-weight: bold;">Resistance: Approx. 285Ω</p> <p style="text-align: center; font-weight: bold;">OK or NG</p> | <p>AT</p> <p>TF</p> <p>PD</p> <p>AX</p> <p>SU</p> <p>BR</p> |
| OK | ▶ | Check harness and connector between speedometer and vehicle speed sensor. | |
| NG | ▶ | Replace vehicle speed sensor. | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/ENGINE REVOLUTION SIGNAL

NGEL0046S02


| | | | |
|---|-------------------------|--|--|
| 1 | CHECK ECM OUTPUT | | |
| <p>1. Start engine. 2. Check voltage between combination meter connector M39 terminal 48 (P/L) and terminal 33 (B/R) at idle and 2,000 rpm.</p> | | | |
|  | | | |
| <p>Higher rpm = Higher voltage Lower rpm = Lower voltage Voltage should change with rpm.</p> | | | |
| WEL795A | | | |
| OK or NG | | | |
| OK | ▶ | Engine revolution signal is OK. | |
| NG | ▶ | Check harness for open or short between ECM and combination meter. | |

METERS AND GAUGES


Trouble Diagnoses (Cont'd)

INSPECTION/FUEL LEVEL SENSOR UNIT

=NGEL0046S08

| | | |
|--|--|------------------------------|
| 1 | CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT | |
| Check harness continuity between fuel level sensor unit harness connector B108 terminal 4 (B) and ground. | | |
| <p>Fuel level sensor unit harness connector</p>  <p style="text-align: right;">Does continuity exist?</p> <p style="text-align: right;">LEL004A</p> | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | Repair harness or connector. |

| | | |
|---|-------------------------------------|---------------------------------|
| 2 | CHECK FUEL LEVEL SENSOR UNIT | |
| Refer to "FUEL LEVEL SENSOR UNIT CHECK", EL-89. | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Replace fuel level sensor unit. |

| | | |
|--|--|-------------------------------|
| 3 | CHECK HARNESS FOR OPEN OR SHORT | |
| <ol style="list-style-type: none"> 1. Disconnect combination meter harness connector M39, fuel level sensor unit harness connector B108 and ECM connector F29. 2. Check continuity between combination meter harness connector M39 terminal 47 (OR/B) and fuel level sensor unit harness connector B108 terminal 2 (OR/B). Continuity should exist. 3. Check continuity between combination meter harness connector M39 terminal 47 (OR/B) and ground. Continuity should not exist. | | |
| <p>Combination meter harness connector</p> <p>Fuel level sensor unit harness connector</p>  <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">WEL796A</p> | | |
| OK | ▶ | Fuel level sensor unit is OK. |
| NG | ▶ | Repair harness or connector. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX




METERS AND GAUGES

Trouble Diagnoses (Cont'd)


INSPECTION/THERMAL TRANSMITTER

NGEL0046S09

| | | |
|--|----------------------------------|------------------------------|
| 1 | CHECK THERMAL TRANSMITTER | |
| Refer to "THERMAL TRANSMITTER CHECK", EL-89. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Replace thermal transmitter. |

| | | |
|---|--|------------------------------|
| 2 | CHECK HARNESS FOR OPEN OR SHORT | |
| <p>1. Disconnect combination meter harness connector M39 and thermal transmitter harness connector.</p> <p>2. Check continuity between combination meter harness connector M39 terminal 46 (GY) and thermal transmitter harness connector terminal 1.</p> <p>Continuity should exist.</p> <p>3. Check continuity between combination meter harness connector M39 terminal 46 (GY) and ground.</p> <p>Continuity should not exist.</p> | | |
| <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Combination meter harness connector</p>  </div> <div style="text-align: center;"> <p>Thermal transmitter harness connector</p>  </div> </div> <div style="text-align: center; margin-top: 20px;">  </div> | | |
| OK or NG | | |
| OK | ▶ | Thermal transmitter is OK. |
| NG | ▶ | Repair harness or connector. |

WEL797A



Electrical Components Inspection FUEL LEVEL SENSOR UNIT CHECK

NGEL0047


=NGEL0047S01

- For removal, refer to **FE-4**, "Removal and Installation".

Check the resistance between fuel level sensor unit terminals 2 and 4.

| Ohmmeter | | Float position mm (in) | | | Resistance value (Ω) |
|----------|-----|------------------------|-------|-------------|----------------------|
| (+) | (-) | | | | |
| 2 | 4 | *1 | Full | 96 (3.78) | Approx. 4 - 6 |
| | | *2 | 1/2 | 188 (7.40) | 30 - 34 |
| | | *3 | Empty | 257 (10.12) | 80 - 83 |

*1 and *3: When float rod is in contact with stopper.




THERMAL TRANSMITTER CHECK

NGEL0047S02

Check the resistance between thermal transmitter terminal 1 and body ground.

| Water temperature | Resistance |
|-------------------|--------------------|
| 60°C (140°F) | Approx. 170 - 210Ω |
| 100°C (212°F) | Approx. 47 - 53Ω |



VEHICLE SPEED SENSOR SIGNAL CHECK

NGEL0047S03

- Remove vehicle speed sensor from transmission.
- Turn vehicle speed sensor pinion quickly and measure voltage across 1 and 2.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

COMPASS AND THERMOMETER

System Description

System Description

NGEL0209



This unit displays following items:

- Earth magnetism and heading direction of vehicle.
- Outside air temperature.
- Caution for frozen road surfaces.

OUTSIDE TEMPERATURE DISPLAY

NGEL0209S01

Push the switch when the ignition key is in the "ACC" or "ON" position. The outside temperature will be displayed in "°F".

- Selecting the indication range
Push the switch to change from "°F" to "°C".
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
 - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
 - b) The vehicle speed is greater than 20 km/h (13 MPH).
(This is to prevent the indicated temperature from being affected by engine heat during low-speed driving.)
 - c) The ignition key has been turned to the "OFF" position for more than 2 hours. (The engine is cold.)

DIRECTION DISPLAY

NGEL0209S02

Push the switch when the ignition key is in the "ACC" or "ON" position. The direction will be displayed.


COMPASS AND THERMOMETER

Wiring Diagram — COMPAS —

Wiring Diagram — COMPAS —

NGEL0210


EL-COMPAS-01



- ⬡ : With A/T
- ⬡ : With M/T
- ⬡ : With VG33E
- ⬡ : With VG33RE
- *1 ⬡ : 3
- ⬡ : 4
- *2 ⬡ : 4
- ⬡ : 5

Refer to "EL-POWER".

Refer to the following.
 (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)



COMPASS AND THERMOMETER

Trouble Diagnoses

Trouble Diagnoses

NGEL0211

PRELIMINARY CHECK FOR THERMOMETER

NGEL0211S01

| | | |
|---|------------------------|--|
| 1 | COOL DOWN CHECK | |
| 1. Turn the ignition key switch to the "ACC" position. 2. Cool down the ambient air temperature sensor with water or ice, so that the indicated temperature falls. | | |
| Does the indicated temperature fall? | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER". |

| | | |
|---|----------------------|--|
| 2 | WARM UP CHECK | |
| 1. Leave the vehicle for 10 minutes, so that the indicated temperature rises. 2. With the ignition key in the "ACC" position, disconnect and reconnect the ambient air temperature sensor connector. | | |
| Does the indicated temperature rise? | | |
| Yes | ▶ | The system is OK. |
| No | ▶ | The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER". |

NOTE:

- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
 - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
 - b) The vehicle speed is greater than 20 km/h (13 MPH).
(This is to prevent the indicated temperature from being affected by engine heat during low-speed driving.)
 - c) The ignition key has been turned to the "OFF" position for more than 2 hours. (The engine is cold.)

INSPECTION/COMPASS AND THERMOMETER

NGEL0211S02

| Symptom | Possible causes | Repair order |
|--|---|---|
| No display at all | 1. 10A fuse 2. Ground circuit 3. Compass and thermometer | 1. Check 10A fuse [No. 11, located in fuse block (J/B)]. Turn the ignition switch ON and verify that battery positive voltage is at terminal 7 of compass and thermometer. 2. Check ground circuit for compass and thermometer. 3. Replace compass and thermometer. |
| Forward direction indication slips off the mark or incorrect. | 1. In manual correction mode (Bar and display vanish.) 2. Zone variation change is not done. | 1. Drive the vehicle and turn at an angle of 90°. 2. Perform the zone variation change. |
| Compass reading remains unchanged. | 1. Vehicle speed signal is not entered. 2. Compass and thermometer | 1. Check harness for open or short between combination meter terminal 2 and compass and thermometer terminal 1. 2. Replace compass and thermometer. |
| Displays wrong temperature when ambient temperature is between -40°C (-40°F) and 55°C (130°F). (See NOTE above.) | 1. Check operation 2. Ambient air temperature sensor circuit 3. Vehicle speed signal is not entered. 4. Ambient air temperature sensor 5. Compass and thermometer | 1. Perform preliminary check shown above. 2. Check harness for open or short between ambient air temperature sensor and compass and thermometer. 3. Check harness for open or short between combination meter terminal 2 and compass and thermometer terminal 1. 4. Replace ambient air temperature sensor. 5. Replace compass and thermometer. |
| Displays SC or OC. | 1. Ambient air temperature sensor circuit. 2. Ambient air temperature sensor. 3. Compass and thermometer. | 1. Check harness for open or short between ambient air temperature sensor and compass and thermometer. 2. Replace ambient air temperature sensor. 3. Replace compass and thermometer. |

COMPASS AND THERMOMETER


Calibration Procedure for Compass

Calibration Procedure for Compass

=NGEL0212

The difference between magnetic North and geographical North can sometimes be great enough to cause false compass readings. In order for the compass to operate accurately in a particular zone, it must be calibrated using the following procedure.

Zone Variation Chart



1. Determine your location on the zone map. Record your zone number.

2. Turn the ignition switch to the ON position.


3. Push the "Mode" switch continuously for five seconds until the current zone entry number and the "VAR" icon is displayed.

4. Press the "Mode" switch repeatedly until the desired zone number is displayed.

Once the desired zone number is displayed, stop pressing the "Mode" switch and the display will show compass direction after a few seconds.

NOTE: Use zone number 5 for Hawaii.

WEL859A



CORRECTION FUNCTIONS OF COMPASS

NGEL0212S01

The direction display is equipped with automatic correction function. If the direction is not shown correctly, carry out initial correction.

INITIAL CORRECTION PROCEDURE FOR COMPASS

NGEL0212S02

1. Pushing the "Mode" switch for about 10 seconds will enter the initial correction mode. The "CAL" icon will illuminate.
2. Turn the vehicle slowly in an open, safe place. The initial correction is completed in one or two turns.

NOTE:


In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.

WARNING LAMPS

Circuit Diagram

Circuit Diagram

NGEL0049




WARNING LAMPS

Wiring Diagram — WARN —


Wiring Diagram — WARN —

NGEL0050

EL-WARN-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC



WEL123B

EL



WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

MODELS WITHOUT POWER DOOR LOCKS

NGEL0050S01

EL-WARN-02



WEL677A

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

MODELS WITH POWER DOOR LOCKS

NGEL0050S02

EL-WARN-03

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS





BT

HA

SC

EL

IDX












WEL678A

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-04

- A : With A/T
- KA : With KA24DE
- XK : Except KA24DE





Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)

WARNING LAMPS


Wiring Diagram — WARN — (Cont'd)

EL-WARN-05

- : With 4-wheel drive and A/T
- : With A/T
- : With ASCD
- : Except KA24DE



Refer to the following.
 - SUPER
 MULTIPLE JUNCTION (SMJ)









WEL160B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-06








Refer to the following.
 (M43) - SUPER MULTIPLE JUNCTION (SMJ)

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-07



WEL682A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC


WARNING LAMPS

Electrical Components Inspection FUEL WARNING LAMP SENSOR CHECK

NGEL0051

NGEL0051S01

- 1) Turn ignition switch OFF.




- 2) Disconnect fuel level sensor unit harness connector B108.
- 3) Connect a resistor (80 Ω) between fuel level sensor unit harness connector B108 terminals 2 (OR/B) and 4 (B).
- 4) Turn ignition switch ON.

The fuel warning lamp should come on.

NOTE:

ECM might store the 1st tip DTC P0180 during this inspection. If the DTC is stored in ECM memory, erase the DTC after reconnecting the fuel level sensor unit harness connector.

Refer to **EC-86**(KA24DE), **EC-673**(VG33E), or **EC-1197**(VG33ER), "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".




OIL PRESSURE SWITCH CHECK

NGEL0051S02

| | Oil pressure kPa (kg/cm ² , psi) | Continuity |
|--------------|--|------------|
| Engine start | More than 10 - 20 (0.1 - 0.2, 1 - 3) | No |
| Engine stop | Less than 10 - 20 (0.1 - 0.2, 1 - 3) | Yes |

Check the continuity between oil pressure switch terminal 1 and body ground.



DIODE CHECK

NGEL0051S03

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.
- Check diodes at the combination meter harness connector instead of the combination meter assembly. Refer to "Wiring Diagrams —WARN—", EL-95.

NOTE:


Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual of the tester to be used.

WARNING CHIME

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0052



WEL125B

System Description

MODELS WITHOUT POWER DOOR LOCKS

NGEL0053

NGEL0053S04

The warning chime is integral with the warning chime unit, which controls its operation. Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to key switch terminal 1.

Power is supplied at all times

- through 15A fuse (No. 39, located in the fuse and fusible link box)
- to lighting switch terminal 11.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to warning chime unit terminal 1.

Ground is supplied to warning chime unit terminal 8 through body grounds M14 and M68.

When a signal, or combination of signals, is received by the warning chime unit, the warning chime will sound.

Ignition Key Warning Chime

NGEL0053S0401

With the key switch in the INSERTED (key is in the ignition key cylinder) position, the ignition switch in the OFF or ACC position and the front door LH open, the warning chime will sound. A battery positive voltage is supplied

- from key switch terminal 2
- to warning chime unit terminal 5.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WARNING CHIME

System Description (Cont'd)

Ground is supplied

- to warning chime unit terminal 7
- through front door switch LH terminal 2.

Front door switch LH terminal 3 is grounded through body grounds B6 and B10.

Light Warning Chime

NGEL0053S0402

With the ignition switch in the OFF or ACC position, front door LH open and lighting switch in the parking and tail lamps ON (1ST) or headlamps ON (2ND) position, the warning chime will sound. A battery positive voltage is supplied

- from lighting switch terminal 12
- to warning chime unit terminal 4.

Ground is supplied

- to warning chime unit terminal 7
- through front door switch LH terminal 2.

Front door switch LH terminal 3 is grounded through body grounds B6 and B10.

Seat Belt Warning Chime

NGEL0053S0403

The warning chime will sound for approximately 6 seconds when the ignition switch is turned from OFF to ON with the driver's seat belt unfastened (seat belt buckle switch ON).

Ground is supplied

- to warning chime unit terminal 2
- through seat belt buckle switch terminal 1.

Seat belt buckle switch terminal 2 is grounded through body grounds M14 and M68.

MODELS WITH POWER DOOR LOCKS

NGEL0053S05

The warning chime is controlled by the smart entrance control unit.

Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to key switch terminal 1, and
- to smart entrance control unit terminal 49.

Power is supplied at all times

- through 15A fuse (No. 39, located in the fuse and fusible link box)
- to lighting switch terminal 11.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied to smart entrance control unit terminals 43 and 64 through body grounds M14 and M68. When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

Ignition Key Warning Chime

NGEL0053S0501

With the key switch in the INSERTED (key is in the ignition key cylinder) position, the ignition switch in the OFF or ACC position and the front door LH open, the warning chime will sound. Power is supplied

- from key switch terminal 2
- to smart entrance control unit terminal 25.

Ground is supplied

- to smart entrance control unit terminal 1
- through front door switch LH terminal 2.

Front door switch LH terminal 3 is grounded through body grounds B6 and B10.

Light Warning Chime

NGEL0053S0502

With the ignition switch the OFF or ACC position, front door LH open and lighting switch in parking and tail lamps ON (1ST) or headlamps ON (2ND) position, the warning chime will sound. Power is supplied

- from lighting switch terminal 12
- to smart entrance control unit terminal 58.

Ground is supplied

WARNING CHIME

System Description (Cont'd)

- to smart entrance control unit terminal 1
- through front door switch LH terminal 2.

Front door switch LH terminal 3 is grounded through body grounds B6 and B10.

GI

Seat Belt Warning Chime

The warning chime will sound for approximately 6 seconds when the ignition switch is turned from OFF to ON with the driver's seat belt unfastened (seat belt buckle switch ON).

NGEL0053S0503

MA

Ground is supplied

- to smart entrance control unit terminal 28
- through seat belt buckle switch terminal 1.

EM

Seat belt buckle switch terminal 2 is grounded through body grounds M14 and M68.

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL







WARNING CHIME

Wiring Diagram — CHIME —

Wiring Diagram — CHIME — MODELS WITHOUT POWER DOOR LOCKS

NGEL0054

NGEL0054S01



Refer to the following.
E43 - SUPER
 MULTIPLE JUNCTION (SMJ)

LEL683A

WARNING CHIME

Wiring Diagram — CHIME — (Cont'd)



MODELS WITH POWER DOOR LOCKS

NGEL0054S02

EL-CHIME-02

Refer to "EL-POWER".

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Refer to the following.
E43 - SUPER
MULTIPLE JUNCTION (SMJ)

WEL684A

WARNING CHIME

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NGEL0055


NGEL0055S01

| REFERENCE PAGE (EL-) | Without power door locks | 109 | 111 | 112 | 114 | 116 |
|---|--------------------------|---------------------------------------|------------------------------------|-----------------------------|-------------------------------|----------------------------|
| | With power door locks | 109 | 111 | 113 | 115 | 117 |
| SYMPTOM | | POWER SUPPLY AND GROUND CIRCUIT CHECK | LIGHTING SWITCH INPUT SIGNAL CHECK | KEY SWITCH (INSERTED) CHECK | SEAT BELT BUCKLE SWITCH CHECK | FRONT DOOR SWITCH LH CHECK |
| Light warning chime does not activate. | | X | X | | | X |
| Ignition key warning chime does not activate. | | X | | X | | X |
| Seat belt warning chime does not activate. | | X | | | X | |
| All warning chimes do not activate. | | X | | | | |

X: Applicable

WARNING CHIME

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT CHECK

=NGEL0055S02

Main Power Supply Circuit Check


NGEL0055S0201

● Models without power door locks

| Terminals | | Ignition switch position | | |
|-----------|--------|--------------------------|-----|-----------------|
| (+) | (-) | OFF | ACC | ON |
| 1 | Ground | 0V | 0V | Battery voltage |

If NG, check the following

- 15A fuse (No. 39, located in fuse and fusible link box)
- Harness for open or short between warning chime unit and fuse.




● Models with power door locks

| Terminals | | Ignition switch position | | | |
|---------------|----------|--------------------------|-----------------|-----------------|-----------------|
| (+) Connector | | (-) | OFF | ACC | ON |
| M111 | 27 (G/W) | Ground | 0V | 0V | Battery voltage |
| M112 | 49 (G) | Ground | Battery voltage | Battery voltage | Battery voltage |

If NG, check the following

- 7.5A fuse [No. 28, located in fuse block (J/B)]
- 10A fuse [No. 5, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse.



Ground Circuit Check

NGEL0055S0202

● Models without power door locks

| Terminals | Continuity |
|------------|------------|
| 8 - Ground | Yes |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

WARNING CHIME

Trouble Diagnoses (Cont'd)



● Models with power door locks

| Terminals | | Continuity |
|-----------|-----------------------|------------|
| (+) | | |
| Connector | Terminal (wire color) | (-) |
| M111 | 43 (B) | Ground |
| M112 | 64 (B) | Ground |
| | | Yes |





WARNING CHIME

Trouble Diagnoses (Cont'd)

LIGHTING SWITCH INPUT SIGNAL CHECK Models without Power Door Locks


-NGEL0055S03

NGEL0055S0301

| | | |
|--|---|--|
| 1 | CHECK LIGHTING SWITCH INPUT SIGNAL | |
| <p>Check voltage between warning chime unit terminal 4 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Warning chime unit connector (M11)</p>  </div> <div style="text-align: center;">    </div> </div> <p style="text-align: right;">AEL372B</p> | | |
| <p>Voltage [V]: Condition of lighting switch: 1ST or 2ND Approx. 12 Condition of lighting switch: OFF 0</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | Lighting switch is OK. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse (No. 39, located in the fuse and fusible link box) ● Harness for open or short between warning chime unit and lighting switch |

Models with Power Door Locks

NGEL0055S0302

| | | |
|---|---|---|
| 1 | CHECK LIGHTING SWITCH INPUT SIGNAL | |
| <p>Check voltage between smart entrance control unit connector M112 terminal 58 (L/R) and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;"> <p>Voltage [V]: Condition of lighting switch: 1ST or 2ND Approx. 12 Condition of lighting switch: OFF Approx. 0</p> </div> </div> <p style="text-align: right;">LEL009A</p> | | |
| <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | Lighting switch is OK. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse (No. 39, located in the fuse and fusible link box) ● Harness for open or short between smart entrance control unit and lighting switch |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL


WARNING CHIME

Trouble Diagnoses (Cont'd)


KEY SWITCH (INSERTED) CHECK Models without Power Door Locks

NGEL0055S04

NGEL0055S0401

| 1 | CHECK KEY SWITCH INPUT SIGNAL |
|--|-------------------------------|
| <p>Check voltage between warning chime unit terminal 5 and ground.</p> <div style="text-align: center;">  </div> <p>Voltage [V]: Condition of key switch: Key is INSERTED. Approx. 12 Condition of key switch: Key is REMOVED. 0</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ Key switch is OK. |
| NG | ▶ GO TO 2. |

AEL374B

| 2 | CHECK KEY SWITCH (INSERTED) |
|--|--|
| <p>Check continuity between terminals 1 and 2.</p> <div style="text-align: center;">  </div> <p>Continuity: Condition of key switch: Key is INSERTED. Yes Condition of key switch: Key is REMOVED. No</p> <p style="text-align: center;">OK or NG</p> | |
| OK | <p>▶ Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 28, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between warning chime unit and key switch |
| NG | ▶ Replace key switch. |






AEL416B




WARNING CHIME

Trouble Diagnoses (Cont'd)

Models with Power Door Locks

NGEL005SS0402

| | | |
|--|--------------------------------------|-------------------|
| 1 | CHECK KEY SWITCH INPUT SIGNAL | |
| Check voltage between smart entrance control unit connector M111 terminal 25 (W/G) and ground. | | |
| <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;">  <p>CONNECT</p>  <p>  : Approx. 12V  : Approx. 0V </p> </div> <div style="width: 35%; text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="width: 30%;"> <p>Voltage [V]: Condition of key switch: Key is INSERTED. Approx. 12 Condition of key switch: Key is REMOVED. Approx. 0</p> </div> </div> <p style="text-align: right;">LEL010A</p> | | |
| OK or NG | | |
| OK | ▶ | Key switch is OK. |
| NG | ▶ | GO TO 2. |

| | | |
|---|------------------------------------|---|
| 2 | CHECK KEY SWITCH (INSERTED) | |
| Check continuity between terminals 1 and 2. | | |
| <div style="display: flex; justify-content: center; align-items: center;"> <div style="text-align: center; margin-right: 20px;">  <p>DISCONNECT</p>  </div> <div style="text-align: center;"> <p>Key switch (M37)</p>  </div> </div> <p style="text-align: right;">AEL416B</p> | | |
| <p>Continuity: Condition of key switch: Key is INSERTED. Yes Condition of key switch: Key is REMOVED. No</p> | | |
| OK or NG | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 28, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between smart entrance control unit and key switch |
| NG | ▶ | Replace key switch. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL

WARNING CHIME

Trouble Diagnoses (Cont'd)

SEAT BELT BUCKLE SWITCH CHECK Models without Power Door Locks

=NGEL0055S05

NGEL0055S0501

| | | |
|---|---|--------------------------------|
| 1 | CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL | |
| <p>1. Turn ignition switch ON. 2. Check voltage between warning chime unit terminal 2 and ground.</p> <div style="text-align: center;"> </div> <p>Voltage [V]: Condition of seat belt buckle switch: FASTENED Approx. 12 Condition of seat belt buckle switch: UNFASTENED 0</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | Seat belt buckle switch is OK. |
| NG | ▶ | GO TO 2. |





| | | |
|---|--------------------------------------|---|
| 2 | CHECK SEAT BELT BUCKLE SWITCH | |
| <p>Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.</p> <div style="text-align: center;"> </div> <p>Continuity: Seat belt is fastened. No Seat belt is unfastened. Yes</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Seat belt buckle switch ground circuit ● Harness for open or short between warning chime unit and seat belt buckle switch |
| NG | ▶ | Replace seat belt buckle switch. |




WARNING CHIME

Trouble Diagnoses (Cont'd)

Models with Power Door Locks

NGEL0055S0502

| 1 CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL | |
|---|----------------------------------|
| <p>1. Turn ignition switch ON. 2. Check voltage between smart entrance control unit connector M111 terminal 28 (B/P) and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 15%;">    </div> <div style="width: 30%; text-align: center;">  </div> <div style="width: 45%;"> <p>Voltage [V]: Condition of seat belt buckle switch: FASTENED Approx. 12 Condition of seat belt buckle switch: UNFASTENED Approx. 0</p> </div> </div> <p style="text-align: right;">LEL011A</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ Seat belt buckle switch is OK. |
| NG | ▶ GO TO 2. |

| 2 CHECK SEAT BELT BUCKLE SWITCH | |
|--|---|
| <p>Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.</p> <div style="display: flex; justify-content: center; align-items: center;">   </div> <p style="text-align: center;">Seat belt buckle switch connector (M19)</p> <div style="text-align: center;">  </div> <p style="text-align: right;">AEL381B</p> <p>Continuity: Seat belt is fastened. No Seat belt is unfastened. Yes</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ Check the following. <ul style="list-style-type: none"> ● Seat belt buckle switch ground circuit ● Harness for open or short between smart entrance control unit and seat belt buckle switch |
| NG | ▶ Replace seat belt buckle switch. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL





WARNING CHIME




Trouble Diagnoses (Cont'd)

FRONT DOOR SWITCH LH CHECK Models without Power Door Locks

NGEL0055S06

NGEL0055S0601

| | | |
|--|--|-----------------------------|
| 1 | CHECK FRONT DOOR SWITCH LH INPUT SIGNAL | |
| <p>Check voltage between warning chime unit terminal 7 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Warning chime unit connector (M11)</p>  <p>G/R</p> </div> <div style="text-align: center;">  <p>CONNECT</p>  <p>OFF</p> </div> </div> <div style="text-align: center; margin-top: 10px;">  </div> <p>Voltage [V]: Condition of front door LH: CLOSED Approx. 12 Condition of front door LH: OPEN 0</p> <p style="text-align: right;">AEL378B</p> | | |
| OK or NG | | |
| OK | ▶ | Front door switch LH is OK. |
| NG | ▶ | GO TO 2. |





| | | |
|---|-----------------------------------|---|
| 2 | CHECK FRONT DOOR SWITCH LH | |
| <p>Check continuity between front door switch LH connector B4 terminals 2 and 3.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Front door switch LH connector</p>  </div> <div style="text-align: center;">  <p>DISCONNECT</p>  </div> </div> <div style="margin-top: 10px;"> <p>Continuity: Front door switch LH is pressed NO Front door switch LH is released Yes</p> <p style="text-align: right;">LEL319A</p> </div> | | |
| OK or NG | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Front door switch LH ground circuit ● Harness for open or short between warning chime unit and front door switch LH |
| NG | ▶ | Replace front door switch LH. |




WARNING CHIME

Trouble Diagnoses (Cont'd)

Models with Power Door Locks

NGEL0055S0602

| | | |
|---|--|-----------------------------|
| 1 | CHECK FRONT DOOR SWITCH LH INPUT SIGNAL | |
| Check voltage between smart entrance control unit connector M110 terminal 1 (G/R) and ground. | | |
| <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">    </div> <div style="text-align: center;">  </div> <div style="text-align: left;"> <p>Voltage [V]: Condition of front door LH: CLOSED Approx. 12 Condition of front door LH: OPEN Approx. 0</p> </div> </div> | | |
| LEL012A | | |
| OK or NG | | |
| OK | ▶ | Front door switch LH is OK. |
| NG | ▶ | GO TO 2. |

| | | |
|---|-----------------------------------|--|
| 2 | CHECK FRONT DOOR SWITCH LH | |
| Check continuity between front door switch LH connector B4 terminals 2 and 3. | | |
| <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> <p>Front door switch LH connector</p>  </div> <div style="text-align: center;">   </div> <div style="text-align: left;"> <p>Continuity: Front door switch LH is pressed NO Front door switch LH is released Yes</p> </div> </div> | | |
| LEL319A | | |
| OK or NG | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Front door switch LH ground circuit ● Harness for open or short between smart entrance control unit and front door switch LH |
| NG | ▶ | Replace front door switch LH. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT WIPER AND WASHER

System Description

System Description

NGEL0057

NGEL0057S01

NGEL0057S0104

WIPER OPERATION

Models without Intermittent Wipers

The front wiper switch is controlled by a lever built into the combination switch. There are two front wiper switch positions:

- LO speed
- HI speed

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No. 6, located in the fuse block (J/B)]
- to front wiper motor terminal B.

Low and High Speed Wiper Operation

Ground is supplied to front wiper switch terminal 17 through body grounds E12 and E54.

With the front wiper switch in the LO position, ground is supplied

- to front wiper motor terminal L
- through front wiper switch terminal 14.

With power and ground supplied, the front wiper motor operates at low speed.

With the front wiper switch in the HI position, ground is supplied

- to front wiper motor terminal H
- through front wiper switch terminal 16.

With power and ground supplied, the front wiper motor operates at high speed.

Auto Stop Operation

When the front wiper switch is turned OFF, the front wiper motor will continue to operate at low speed until wiper blades reach windshield base.

When wiper blades are not located at base of windshield with front wiper switch OFF, ground is supplied

- to front wiper motor terminal L
- through front wiper switch terminal 14
- through front wiper switch terminal 13
- through front wiper motor terminal P.

Ground is supplied to front wiper motor terminal E through body grounds E12 and E54.

Models with Intermittent Wipers

The front wiper switch is controlled by a lever built into the combination switch.

There are three front wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No. 6, located in the fuse block (J/B)]
- to front wiper motor terminal B and
- to front wiper switch terminal 15.

Low and High Speed Wiper Operation

Ground is supplied to front wiper switch terminal 17 through body grounds E12 and E54

With the front wiper switch in the LO position, ground is supplied

- to front wiper motor terminal L
- through front wiper switch terminal 14.

With power and ground supplied, the front wiper motor operates at low speed.

With the front wiper switch in the HI position, ground is supplied

- to front wiper motor terminal H
- through front wiper switch terminal 16.

With power and ground supplied, the front wiper motor operates at high speed.

Auto Stop Operation

When the front wiper switch is turned OFF, the front wiper motor will continue to operate at low speed until wiper blades reach windshield base.

When wiper blades are not located at base of windshield with front wiper switch OFF, ground is supplied

NGEL0057S0105

FRONT WIPER AND WASHER

System Description (Cont'd)

- to front wiper motor terminal L
- through front wiper switch terminal 14
- through front wiper switch terminal 13
- through front wiper motor terminal P
- through front wiper motor terminal E
- through body grounds E12 and E54.

When wiper blades reach base of windshield, front wiper motor terminals B and P are connected instead of terminals P and E.

Battery power is then supplied

- through front wiper motor terminal P
- to front wiper switch terminal 13.

With battery voltage supplied to front wiper switch terminal 13, the front wiper switch will stop the front wiper motor with the wiper blades at the PARK position.

Intermittent Operation

The wiper blades perform a single wiping operation, followed by a delay interval which is adjustable from approximately 3 to 13 seconds, after which the cycle repeats. This feature is controlled by the front wiper switch.

When the front wiper switch is placed in the INT position, ground is supplied intermittently

- to front wiper motor terminal L
- through front wiper switch terminal 14
- through front wiper switch terminal 17
- through body grounds E12 and E54.

The delay interval time is controlled by the wiper switch.

Ground is supplied to front wiper switch terminal 17 through body grounds E12 and E54.

The wiper motor operates at low speed at the desired delay interval.

WASHER OPERATION

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No. 6, located in the fuse block (J/B)]
- to front washer motor terminal +.

When the lever is pulled to the WASH position, ground is supplied

- to front washer motor terminal –
- from front wiper switch terminal 18
- through front wiper switch terminal 17, and
- through body grounds E12 and E54.

With power and ground supplied, the front washer motor operates.

Models with Intermittent Wipers

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper switch in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

NGEL0057S02

PD

AX

SU

BR

NGEL0057S0201

ST

RS

BT

HA

SC

EL

IDX

FRONT WIPER AND WASHER


Wiring Diagram — WIPER —

Wiring Diagram — WIPER — MODELS WITHOUT INTERMITTENT WIPERS

NGEL0058

NGEL0058S01

EL-WIPER-01







FRONT WIPER AND WASHER

Wiring Diagram — WIPER — (Cont'd)

MODELS WITH INTERMITTENT WIPERS

NGEL0058S02

EL-WIPER-02




WEL686A

EL

FRONT WIPER AND WASHER

Removal and Installation



Removal and Installation

WIPER ARMS

NGEL0060


NGEL0060S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" and "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" and "L₂".

Clearance "L₁": 25 mm (.98 in)

Clearance "L₂": 25 mm (.98 in)


- Tighten wiper arm nuts to specified torque.
Front wiper: 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER LINKAGE

NGEL0060S02



FRONT WIPER AND WASHER

Removal and Installation (Cont'd)

Removal

NGEL0060S0201


1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.

Installation

NGEL0060S0202

- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.




Washer Nozzle Adjustment

NGEL0061

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$




Unit: mm (in)

| | | | |
|----|-------------|----|-------------|
| *1 | 390 (15.35) | *5 | 145 (5.71) |
| *2 | 160 (6.30) | *6 | 143 (5.63) |
| *3 | 379 (14.92) | *7 | 225 (8.86) |
| *4 | 140 (5.51) | *8 | 535 (21.06) |

*: The diameters of these circles are less than 80 mm (3.15 in).

Washer Tube Layout

NGEL0062



REAR WIPER AND WASHER

System Description

System Description

NGEL0063

POWER SUPPLY AND GROUND

NGEL0063S03

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to rear wiper motor terminal +A and
- to rear washer motor terminal +.

Ground is supplied

- to rear wiper switch terminal 3
- through body grounds M14 and M68.

Ground is also supplied

- to rear wiper motor terminal E
- through body grounds D402 and D404.

WIPER OPERATION

NGEL0063S01

With the rear wiper switch WIPER in the ON position, ground is supplied

- to rear wiper motor terminal I
- through rear wiper switch terminal 1.

WASHER OPERATION

NGEL0063S02

With the rear wiper switch WASHER in the ON position, ground is supplied

- to rear washer motor terminal – and
- to rear wiper motor terminal W
- through rear wiper switch terminal 2.

With power and ground supplied, the rear wiper motor and rear washer motor operate until the rear wiper switch WASHER is released from the ON position. If the switch is pressed momentarily, the rear wiper motor will cycle 2 times.

AUTO STOP OPERATION

NGEL0063S04

When the rear wiper switch is placed in the OFF position, the rear wiper motor will continue to operate until the rear wiper blade reaches the park position.

The ground is supplied through rear wiper motor terminal E. This allows the rear wiper motor to operate until the rear wiper blade reaches the park position. When the rear wiper blade reaches the park position, the rear wiper motor ground is interrupted and the rear wiper motor stops.



REAR WIPER AND WASHER

Wiring Diagram — WIP/R —

Wiring Diagram — WIP/R —

NGEL0065

EL-WIP/R-01



Refer to the following.
 (E43) - SUPER MULTIPLE
 JUNCTION (SMJ)

WEL687A



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

REAR WIPER AND WASHER

Removal and Installation

Removal and Installation

NGEL0067



- 1. Rear wiper arm
- 2. Pivot shaft cover
- 3. Pivot shaft nut

- 4. Outer collar
- 5. Seal
- 6. Rear wiper motor

- 7. Mounting bolts
- 8. Back door
- 9. Rear wiper blade


REAR WIPER AND WASHER


Removal and Installation (Cont'd)

WIPER ARMS


NGEL0067S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Install wiper arm so that wiper blade is parallel to the ground and tighten wiper arm nut to specification.

 : 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.




Washer Nozzle Adjustment

NGEL0068

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: ±10° (In any direction)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

REAR WIPER AND WASHER


Washer Tube Layout

Washer Tube Layout

NGEL0069



AEL509C



SEL411H

Check Valve

NGEL0070

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.


HORN

Wiring Diagram — HORN —




Wiring Diagram — HORN —

EL-HORN-01

NGEL0071



To EL-VEHSEC ← LG/R



Refer to the following.
 E43 - SUPER
 MULTIPLE JUNCTION (SMJ)

* : This connector is not shown in "HARNES LAYOUT" of EL section.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CIGARETTE LIGHTER

Wiring Diagram — CIGAR —






Wiring Diagram — CIGAR —

NGEL0156

EL-CIGAR-01

⬡(PS) : With power socket

Refer to "EL-POWER".



WEL127B

REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0072

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS







BT

HA

SC

EL

IDX



REAR WINDOW DEFOGGER

System Description

System Description

NGEL0073

MODELS WITHOUT POWER DOOR LOCKS

NGEL0073S01

The rear window defogger system is controlled by the rear window defogger timer. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 5 and
- through 20A fuse [No. 25, located in the fuse block (J/B)] and

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to rear window defogger relay terminal 1 and
- to rear window defogger timer terminal 1.

Ground is supplied to air control (rear window defogger switch) terminal 8 and rear window defogger timer terminal 4 through body grounds M14 and M68.

With the air control (rear window defogger switch) ON, ground is supplied

- to rear window defogger timer terminal 3
- through air control (rear window defogger switch) terminal 5.

Rear window defogger timer terminal 2 then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminal 3 of the rear window defogger relay
- to rear window defogger terminal +.

Rear window defogger terminal – is grounded through body grounds D402 and D404.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the air control (rear window defogger switch).

Power is supplied

- from rear window defogger relay terminal 3
- to air control (rear window defogger switch) terminal 4.

Air control (rear window defogger switch) terminal 8 is grounded through body grounds M14 and M68.

MODELS WITH POWER DOOR LOCKS

NGEL0073S02

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 5 and
- through 20A fuse [No. 25, located in the fuse block (J/B)] and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 28, located in the fuse block (J/B)].

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to rear window defogger relay terminal 1 and
- to smart entrance control unit terminal 27.

Ground is supplied to air control (rear window defogger switch) terminal 8 and smart entrance control unit terminals 43 and 64 through body grounds M68 and M14.

With the air control (rear window defogger switch) ON, ground is supplied

- to smart entrance control unit terminal 14
- through air control (rear window defogger switch) terminal 5.

Smart entrance control unit terminal 37 then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminal 3 of the rear window defogger relay
- to rear window defogger terminal +.

REAR WINDOW DEFOGGER

System Description (Cont'd)

Rear window defogger terminal – is grounded through body grounds D402 and D404.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the air control (rear window defogger switch).

Power is supplied

- from rear window defogger relay terminal 3
- to air control (rear window defogger switch) terminal 4.

Air control (rear window defogger switch) terminal 8 is grounded through body grounds M14 and M68.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REAR WINDOW DEFOGGER




Wiring Diagram — DEF —

Wiring Diagram — DEF — MODELS WITHOUT POWER DOOR LOCKS

NGEL0074

NGEL0074S01

EL-DEF-01







REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

MODELS WITH POWER DOOR LOCKS

NGEL0074S02

EL-DEF-02



WEL690A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER

Trouble Diagnoses

Trouble Diagnoses

NGEL0075

NGEL0075S01

DIAGNOSTIC PROCEDURE

SYMPTOM: Rear window defogger does not activate, or does not turn off after activating.

Models without Power Door Locks

NGEL0075S0101

| | |
|--|--|
| 1 | CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL |
| <p>1. Turn ignition switch ON. 2. Check voltage between rear window defogger timer harness connector terminal 2 and ground.</p> <div style="text-align: center;"> </div> <p>Voltage [V]: Rear window defogger switch is OFF. Approx. 12 Rear window defogger switch is ON. 0</p> <p style="text-align: right;">AEL629C</p> <p style="text-align: center;">OK or NG</p> | |
| OK | <p>▶ Check the following.</p> <ul style="list-style-type: none"> ● Rear window defogger relay Refer to "REAR WINDOW DEFOGGER RELAY", EL-141. ● Rear window defogger circuit ● Rear window defogger filament Refer to "Filament Check", EL-142. |
| NG | <p>▶ GO TO 2.</p> |

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

| | | | |
|----------|---|--|--|
| 2 | CHECK DEFOGGER RELAY COIL SIDE CIRCUIT | <p>1. Disconnect rear window defogger timer harness connector.</p> <p>2. Turn ignition switch ON.</p> <p>3. Check voltage between rear window defogger timer harness connector terminal 2 and ground.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">AEL630C</p> <p style="text-align: center;">Does battery voltage exist?</p> | GI MA EM LC EC FE CL MT AT |
| Yes | ▶ | GO TO 3. | |
| No | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 5, located in the fuse block (J/B)] ● Rear window defogger relay. Refer to "REAR WINDOW DEFOGGER RELAY", EL-141. ● Harness for open or short between rear window defogger relay and rear window defogger timer ● Harness for open or short between rear window defogger relay and fuse | TF PD AX SU BR ST RS |

| | | | |
|----------|---|---|----------------|
| 3 | CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL | <p>Check continuity between rear window defogger timer harness connector terminal 3 and ground.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">AEL631C</p> <p>Continuity: Rear window defogger switch is pressed. Yes Rear window defogger switch is released. No</p> <p style="text-align: center;">OK or NG</p> | BT HA SC |
| OK | ▶ | GO TO 4. | |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Air control (rear window defogger switch) Refer to "REAR WINDOW DEFOGGER SWITCH", EL-141 ● Harness for open or short between rear window defogger timer and air control (rear window defogger switch) ● Air control (rear window defogger switch) ground circuit | EL IDX |

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

| | | |
|--|------------------------------------|--|
| 4 | CHECK IGNITION INPUT SIGNAL | |
| Check voltage between rear window defogger timer harness connector terminal 1 and ground. | | |
| | | |
| <p>Voltage [V]: Ignition switch is ON. Approx. 12 Ignition switch is OFF. 0</p> | | |
| AEL632C | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | Check the following. <ul style="list-style-type: none"> ● 10A fuse [No. 5, located in the fuse block (J/B)] ● Harness for open or short between rear window defogger timer and fuse |





| | | |
|--|--|-------------------------------------|
| 5 | CHECK CONTROL UNIT GROUND CIRCUIT | |
| Check continuity between rear window defogger timer harness connector terminal 4 and ground. | | |
| | | |
| AEL633C | | |
| Does continuity exist? | | |
| Yes | ▶ | Replace rear window defogger timer. |
| No | ▶ | Repair harness or connectors. |





REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

NGEL0075S0102

Models with Power Door Locks




| | | |
|---|---|--|
| 1 | CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL | |
| <p>1. Turn ignition switch ON. 2. Check voltage between smart entrance control unit harness connector M111 terminal 37 (G/R) and ground.</p> | | |
| <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;">    </div> <div style="text-align: left;"> <p>Voltage [V]: Rear window defogger switch is OFF. Approx. 12 Rear window defogger switch is ON. 0</p> </div> </div> <p style="text-align: right;">LEL013A</p> | | |
| OK or NG | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Rear window defogger relay Refer to "REAR WINDOW DEFOGGER RELAY", EL-141. ● Rear window defogger circuit ● Rear window defogger filament Refer to "Filament Check", EL-142. |
| NG | ▶ | GO TO 2. |




| | | |
|---|---|--|
| 2 | CHECK DEFOGGER RELAY COIL SIDE CIRCUIT | |
| <p>1. Disconnect smart entrance control unit harness connector. 2. Turn ignition switch ON. 3. Check voltage between smart entrance control unit harness connector M111 terminal 37 (G/R) and ground.</p> | | |
| <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;">    </div> </div> <p style="text-align: right;">LEL014A</p> | | |
| Does battery voltage exist? | | |
| Yes | ▶ | GO TO 3. |
| No | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 5, located in the fuse block (J/B)] ● Rear window defogger relay Refer to "REAR WINDOW DEFOGGER RELAY", EL-141. ● Harness for open or short between rear window defogger relay and smart entrance control unit ● Harness for open or short between rear window defogger relay and fuse |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)


| 3 | | CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL |
|--|---|---|
| Check continuity between smart entrance control unit harness connector M110 terminal 14 (G/B) and ground. | | |
|  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Continuity: Rear window defogger switch is pressed Yes Rear window defogger switch is released No</p> </div> </div> | | |
| LEL015A | | |
| OK or NG | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Air control (rear window defogger switch) Refer to "REAR WINDOW DEFOGGER SWITCH", EL-141. ● Harness for open or short between smart entrance control unit and air control (rear window defogger switch) ● Air control (rear window defogger switch) ground circuit |

| 4 | | CHECK IGNITION INPUT SIGNAL |
|---|---|--|
| Check voltage between smart entrance control unit harness connector M111 terminal 27 (G/W) and ground. | | |
|  <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Voltage [V]: Ignition switch is ON. Approx. 12 Ignition switch is OFF. 0</p> </div> </div> | | |
| LEL016A | | |
| OK or NG | | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 5, located in the fuse block (J/B)] ● Harness for open or short between smart entrance control unit and fuse |

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

| | | | |
|--|--|--------------------------------------|--|
| 5 | CHECK CONTROL UNIT GROUND CIRCUIT | | |
| <p>Check continuity between smart entrance control unit harness connector M111 terminal 43 (B), connector M112 terminal 64 (B) and ground.</p> | | | |
| | | | |
| LEL017A | | | |
| Does continuity exist? | | | |
| Yes | ▶ | Replace smart entrance control unit. | |
| No | ▶ | Repair harness or connectors. | |



Electrical Components Inspection


REAR WINDOW DEFOGGER RELAY

NGEL0076

NGEL0076S01

Check continuity between terminals 3 and 5.

| Condition | Continuity |
|---|------------|
| 12V direct current supply between terminals 1 and 2 | Yes |
| No current supply | No |



REAR WINDOW DEFOGGER SWITCH

NGEL0076S02





Check continuity between terminals when rear window defogger switch is pushed and released.

| Terminals | | | | Condition | Continuity |
|-----------|----------|-----------|----------|---|------------|
| (+) | | (-) | | | |
| Connector | Terminal | Connector | Terminal | | |
| M95 | 5 | M95 | 8 | Rear window defogger switch is pushed | Yes |
| | | | | Rear window defogger switch is released | No |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER

Filament Check



Filament Check

NGEL0077

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

Filament Repair

NGEL0078

REPAIR EQUIPMENT

NGEL0078S01


- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth

GI

MA

EM

LC



REPAIRING PROCEDURE

NGEL0078S02

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

EC

FE

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

CL


MT

4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

AT


Do not touch repaired area while test is being conducted.

TF



PD

AX



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUDIO

System Description

NGEL0079

Refer to Owner's Manual for audio system operating instructions.

MODELS WITHOUT AUDIO AMPLIFIER

NGEL0079S03

Power is supplied at all times

- through 15A fuse (No. 41, located in the fuse and fusible link box)
- to audio unit terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 18, located in the fuse block (J/B)]
- to audio unit terminal 10.

Ground is supplied through the case of the audio unit.

When the audio unit power knob is pushed to the ON position, audio signals are supplied

- through audio unit terminals 2, 4, 14 and 16
- to door speakers, pillar tweeters and rear speakers.

MODELS WITH AUDIO AMPLIFIER

NGEL0079S04

Power is supplied at all times

- through 20A fuse (No. 33, located in the fuse and fusible link box)
- to audio amplifier terminals 5 and 12
- through 15A fuse (No. 41, located in the fuse and fusible link box)
- to audio unit terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 18, located in the fuse block (J/B)]
- to audio unit terminal 10.

Ground for the audio unit is supplied through the case of the audio unit. Ground for the audio amplifier is supplied to terminals 4 and 11 through body grounds M68 and M14.

When the audio unit power knob is pushed to the ON position, audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to audio amplifier terminals 15, 16, 17, 20, 21, 22, 23, and 24
- through audio amplifier terminals 1, 2, 3, and 9
- to front door speakers, pillar tweeters and rear speakers

When the steering switch is pushed, audio signals are supplied


- through audio unit terminal 23
- to steering wheel audio control switch terminal 15, and
- through steering wheel audio control switch terminal 16
- to audio unit terminal 24.

AUDIO

Schematic — With Audio Amplifier

Schematic — With Audio Amplifier

NGEL0213



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

WEL130B

EL

AUDIO


Wiring Diagram — AUDIO —

Wiring Diagram — AUDIO — WITHOUT AUDIO AMPLIFIER

NGEL0157

NGEL0157S01

EL-AUDIO-01



⬡ (PR) : With premium audio system








Refer to "EL-POWER".

To EL-ILL

AUDIO UNIT (M50) (M51)

Refer to the following.

⬡ (E43) - SUPER MULTIPLE JUNCTION (SMJ)



WEL161B


AUDIO

Wiring Diagram — AUDIO — (Cont'd)


WITH AUDIO AMPLIFIER

NGEL0157S02

EL-AUDIO-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL









Refer to the following.
 E43 - SUPER
 MULTIPLE JUNCTION (SMJ)

LEL693A

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-03







LEL694A

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-04



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF EL SECTION.

WEL131B

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUDIO

Trouble Diagnoses

Trouble Diagnoses

NGEL0082

AUDIO UNIT (WITHOUT AUDIO AMPLIFIER)

NGEL0082S01

| Symptom | Possible causes | Repair order |
|--|--|---|
| Audio unit inoperative (no digital display and no sound from speakers). | <ol style="list-style-type: none"> 10A fuse Poor audio unit case ground Audio unit | <ol style="list-style-type: none"> Check 10A fuse [No. 18, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of audio unit. Check audio unit case ground. Remove audio unit for repair. |
| Audio unit controls are operational, but no sound is heard from any speaker. | <ol style="list-style-type: none"> Audio unit output Audio unit | <ol style="list-style-type: none"> Check audio unit output voltages. Remove audio unit for repair. |
| Audio unit presets are lost when ignition switch is turned OFF. | <ol style="list-style-type: none"> 15A fuse Audio unit | <ol style="list-style-type: none"> Check 15A fuse (No. 41, located in fuse and fusible link box) and verify that battery positive voltage is present at terminal 6 of audio unit. Remove audio unit for repair. |
| Individual speaker is noisy or inoperative. | <ol style="list-style-type: none"> Speaker Audio unit output Speaker circuit Audio unit | <ol style="list-style-type: none"> Check speaker. Check audio unit output voltages. Check wires for open or short between audio unit and speaker. Remove audio unit for repair. |
| Audio unit stations are weak or noisy. | <ol style="list-style-type: none"> Antenna Poor audio unit ground Audio unit | <ol style="list-style-type: none"> Check antenna. Check audio unit ground. Remove audio unit for repair. |
| Audio unit generates noise in AM and FM modes with engine running. | <ol style="list-style-type: none"> Poor audio unit ground Loose or missing ground bonding straps Ignition condenser or rear window defogger noise suppressor condenser Alternator Ignition coil or secondary wiring Audio unit | <ol style="list-style-type: none"> Check audio unit ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check alternator. Check ignition coil and secondary wiring. Remove audio unit for repair. |
| Audio unit generates noise in AM and FM modes with accessories on (switch pops and motor noise). | <ol style="list-style-type: none"> Poor audio unit ground Antenna Accessory ground Faulty accessory | <ol style="list-style-type: none"> Check audio unit ground. Check antenna. Check accessory ground. Replace accessory. |

AUDIO UNIT (WITH AUDIO AMPLIFIER)

NGEL0082S04

| Symptom | Possible causes | Repair order |
|--|---|--|
| Audio unit inoperative (no digital display and no sound from speakers). | <ol style="list-style-type: none"> 10A fuse Poor audio unit case ground Audio unit | <ol style="list-style-type: none"> Check 10A fuse [No. 18, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of audio unit. Check audio unit case ground. Remove audio unit for repair. |
| Audio unit controls are operational, but no sound is heard from any speaker. | <ol style="list-style-type: none"> 20A fuse Audio amplifier ground Audio amplifier | <ol style="list-style-type: none"> Check 20A fuse (No. 33, located in fuse and fusible link box). Verify battery positive voltage is present at terminals 5 and 12. Check harness continuity between audio amplifier terminals 4 and 11, and ground. Remove audio amplifier for repair. |
| Audio unit presets are lost when ignition switch is turned OFF. | <ol style="list-style-type: none"> 15A fuse Audio unit | <ol style="list-style-type: none"> Check 15A fuse (No. 41, located in fuse and fusible link box) and verify that battery positive voltage is present at terminal 6 of audio unit. Remove audio unit for repair. |

AUDIO

Trouble Diagnoses (Cont'd)

| Symptom | Possible causes | Repair order | |
|--|---|--|----------|
| Individual speaker is noisy or inoperative. | 1. Each speaker 2. Output circuit to each speaker | 1. Check speaker. 2. Check the output circuit to each speaker ● between audio unit and audio amplifier ● between audio amplifier and each speaker | GI MA |
| Audio unit stations are weak or noisy. | 1. Antenna 2. Poor audio unit ground 3. Audio unit | 1. Check antenna. 2. Check audio unit ground. 3. Remove audio unit for repair. | EM |
| Audio unit generates noise in AM and FM modes with engine running. | 1. Poor audio unit ground 2. Loose or missing ground bonding straps 3. Ignition condenser or rear window defogger noise suppressor condenser 4. Generator 5. Ignition coil or secondary wiring 6. Audio unit | 1. Check audio unit ground. 2. Check ground bonding straps. 3. Replace ignition condenser or rear window defogger noise suppressor condenser. 4. Check generator. 5. Check ignition coil and secondary wiring. 6. Remove audio unit for repair. | LC EC |
| Audio unit generates noise in AM and FM modes with accessories on (switch pops and motor noise). | 1. Poor audio unit ground 2. Antenna 3. Accessory ground 4. Faulty accessory | 1. Check audio unit ground. 2. Check antenna. 3. Check accessory ground. 4. Replace accessory. | FE CL |
| Steering wheel audio control switch does not operate. | 1. Steering wheel audio control switch 2. Audio unit output 3. Steering wheel audio control switch circuit 4. Audio unit | 1. Check steering wheel audio control switch, refer to "STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE CHECK", EL-152. 2. Check audio unit output voltage. 3. Check harness between audio unit and steering switch. 4. Remove audio unit for repair. | MT AT |

Inspection

SPEAKER

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals + and -.
 - The resistance should be 2 - 4Ω.
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals + and -.
 - A momentary hum or pop should be heard.

ANTENNA

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
 - If reception improves, check antenna ground (at body surface).
 - If reception does not improve, check main feeder cable for short circuit or open circuit.

AUDIO UNIT

All voltage inspections are made with:

- Ignition switch ON or ACC
- Audio unit ON
- Audio unit connected (If removed for inspection, supply a ground to the case using a jumper wire.)

AUDIO UNIT VOLTAGES

| Terminal | Wire color | Voltage (V) | | Terminal | Wire color | Voltage (V) | |
|----------|------------|-------------------|----------------------|----------|------------|-------------------|----------------------|
| | | Base Audio System | Premium Audio System | | | Base Audio System | Premium Audio System |
| 1 | B/W | 5 - 7.5 | 5 - 7.5 | 9 | — | — | — |
| 2 | L | 5 - 7.5 | 5 - 7.5 | 10 | G/R | 10.8 - 15.6 | 10.8 - 15.6 |
| 3 | B/R | 5 - 7.5 | 5 - 7.5 | 11 | — | — | — |
| 4 | BR | 5 - 7.5 | 5 - 7.5 | 12 | — | — | — |


AUDIO

Inspection (Cont'd)

| Terminal | Wire color | Voltage (V) | | Terminal | Wire color | Voltage (V) | |
|----------|------------|-----------------------|-----------------------|----------|------------|-------------------|----------------------|
| | | Base Audio System | Premium Audio System | | | Base Audio System | Premium Audio System |
| 5 | — | — | — | 13 | B/Y | 5 - 7.5 | 5 - 7.5 |
| 6 | R/Y | 10.8 - 15.6 | 10.8 - 15.6 | 14 | LG | 5 - 7.5 | 5 - 7.5 |
| 7 | P/B | 0 - 12 (Illumination) | 0 - 12 (Illumination) | 15 | B/P | 5 - 7.5 | 5 - 7.5 |
| 8 | L/R | 0 (Illumination) | 0 (Illumination) | 16 | OR | 5 - 7.5 | 5 - 7.5 |

STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE


NGEL0083S05



| Connector | Terminal | Switch | Resistance Ω (Approx.) |
|-----------|----------|------------------|-------------------------------|
| M204 | 15 - 16 | VOLUME (down) sw | 21.7 - 22.2 |
| | | VOLUME (up) sw | 69.3 - 70.7 |
| | | PREVIOUS sw | 108.9 - 111.1 |
| | | NEXT sw | 158.4 - 161.6 |
| | | MODE sw | 326.7 - 333.3 |


Location of Antenna

NGEL0196



AEL508C

GI
MA
EM
LC
EC
FE
CL
MT



WEL191A

Fixed Antenna Rod Replacement REMOVAL

NGEL0192

NGEL0192S01

1. Remove antenna rod.
2. Remove rubber seal.
3. Remove cowl screen top seal.
4. Remove right wiper arm.
5. Remove right cowl to grille.
6. Remove antenna base bolts.
7. Remove right fender splash shield.
8. Remove audio unit.
9. Disconnect antenna cable from audio unit.
10. Remove attachment clip from fender apron.
11. Remove antenna base and cable.

AT
TF
PD
AX
SU
BR

INSTALLATION

Install in reverse order of removal.

NGEL0192S02

CAUTION:

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.

ST
RS
BT
HA
SC

EL

IDX



DOOR MIRROR

Wiring Diagram — MIRROR —

Wiring Diagram — MIRROR —

NGEL0090

EL-MIRROR-01




LEL696A

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0094



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA









SC

EL

WEL917A

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location (Cont'd)



System Description

Refer to Owner's Manual for ASCD operating instructions.

NGEL0095

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

NGEL0095S07

- through 15A fuse [No. 22, located in the fuse block (J/B)]
- to the stop lamp switch terminal 1

GI

MA

When ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to ASCD control unit terminal 5.
- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to park/neutral position switch terminal 1,
- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminals 32 and 38.

EM

LC

EC

When park/neutral position switch (A/T) is in the P or N position, ground is supplied

- to park/neutral position switch terminal 2
- through ASCD relay terminal 1 to ASCD relay terminal 2
- through body grounds M68 and M14.

FE

CL

When ASCD ON●OFF switch is depressed (ON), ground is supplied

- to ASCD control unit terminal 11
- from ASCD steering switch terminal 14
- from ASCD steering switch terminal 13
- from ASCD control unit terminal 24.

MT

AT

Then ASCD control unit illuminates CRUISE indicator.

Ground is supplied

- to combination meter terminal 36
- from ASCD control unit terminal 15.

TF

Ground is supplied

- to ASCD control unit terminal 17
- through body grounds M14 and M68.

PD

AX

OPERATION

Set Operation

To activate the ASCD, all of following conditions must exist

- ASCD control unit receives ASCD ON●OFF switch ON signal
- Power supply to ASCD control unit terminal 8 [Brake and clutch pedal is released (M/T), and brake pedal is released and A/T selector lever is in other than P and N position. (A/T)]
- Vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH). (Signal from combination meter)

NGEL0095S04

NGEL0095S0401

SU

BR

ST

When the COAST/SET switch is depressed, ground is supplied

- to ASCD control unit terminal 11
- from ASCD steering switch terminal 14
- from ASCD steering switch terminal 13
- from ASCD control unit terminal 24.

RS

BT

Then ASCD motor actuator is activated to control throttle wire and ASCD control unit supplies ground

- to combination meter terminal 37 to illuminate SET indicator.

HA

A/T Overdrive Control During Cruise Control Driving (A/T Models)

NGEL0095S0402

When the vehicle speed is approximately 5 km/h (3 MPH) below set speed, a signal is sent

- from ASCD control unit terminal 10
- to TCM terminal 24.

SC

When this occurs, the TCM cancels overdrive.

When vehicle speed returns to approximately 0.6 km/h (0.4 MPH) below set speed, overdrive is reactivated.

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

Coast Operation

NGEL0095S0403

When the COAST/SET switch is depressed during cruise control driving, ASCD motor actuator returns the throttle cable to decrease vehicle set speed until the switch is released. Then ASCD will keep the new set speed.

If COAST/SET switch is pressed and released quickly during cruise control driving, vehicle set speed will be reduced by 1.6 km/h (1.0 MPH).

Accel Operation

NGEL0095S0404

When the RES/ACCEL switch is depressed, ground is supplied

- to ASCD control unit terminal 11
- from ASCD steering switch terminal 14
- from ASCD steering switch terminal 13
- from ASCD control unit terminal 24

If the RES/ACCEL switch is depressed during cruise control driving, ASCD motor actuator pulls the throttle cable to increase the vehicle speed until the switch is released or vehicle speed is reached to maximum controlled speed by the system. Then ASCD will keep the new set speed.

If RES/ACCEL switch is pressed and released quickly during cruise control driving, vehicle set speed will be increased by 1.6 km/h (1.0 MPH).

Cancel Operation

NGEL0095S0405

When any of following conditions exist, cruise operation will be canceled

- CANCEL switch is depressed. (Ground is supplied to ASCD control unit terminal 11.)
- Brake pedal is depressed. (Power is supplied to ASCD control unit terminal 23 from stop lamp switch.)
- Brake or clutch pedal is depressed (M/T), brake pedal is depressed or A/T selector lever is shifted to P or N position (A/T). (Power supply to ASCD control unit terminal 8 is interrupted.)

If ON●OFF switch is turned to OFF when ASCD is activated, all of ASCD operation will be canceled and vehicle speed memory will be erased.

Resume Operation

NGEL0095S0406

When the RES/ACCEL switch is depressed, after cancel operation other than depressing ON●OFF switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions:

- Brake pedal is released.
- Clutch pedal is released (M/T).
- A/T selector lever is in other than P and N position (A/T).
- Vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH).

ASCD MOTOR ACTUATOR OPERATION

NGEL0095S05

When the ASCD activates, power is supplied

- from terminal 7 of ASCD control unit
- to ASCD motor actuator terminal 1, and
- from terminal 12 of ASCD control unit
- to ASCD motor actuator terminal 6.

Ground is supplied

- from ASCD control unit terminals 1, 13, and 14
- to terminals 3, 5, and 2 of ASCD motor actuator.


Power to the actuator motor is supplied constantly from the ASCD control unit. The ASCD control unit then switches the actuator motor ground signals ON and OFF to control actuator motor operation and vehicle speed.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Circuit Diagram

Circuit Diagram

NGEL0096



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WEL715A

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —


Wiring Diagram — ASCD —

NGEL0097

NGEL0097S01


FIG. 1

EL-ASCD-01



- ⬡ (A) : With A/T
- ⬡ (M) : With M/T
- ⬡ (KA) : With KA24DE
- ⬡ (XK) : Except KA24DE
- *1 ⬡ (VG) : 4
- ⬡ (VR) : 5
- *2 ⬡ (VG) : 3
- ⬡ (VR) : 4

Refer to "EL-POWER".



Refer to the following.
 ⬡ (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)
 ⬡ (M26), ⬡ (M27) - FUSE BLOCK (J/B)






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 2

NGEL0097S02

EL-ASCD-02



* : This connector is not shown in "HARNESS LAYOUT" of EL section.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 3

NGEL0097S03

EL-ASCD-03




Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)

WEL699A

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Fail-safe System



Fail-safe System

DESCRIPTION

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

NGEL0098

NGEL0098S01

GI

MA

EM

LC

MALFUNCTION DETECTION CONDITIONS

NGEL0098S02

| Detection conditions | ASCD operation during malfunction detection |
|---|---|
| <ul style="list-style-type: none"> ASCD steering (RES/ACCEL, CANCEL, COAST/SET) switch is stuck. ASCD motor actuator has internal malfunction. ASCD motor actuator ground circuit or power circuit is open or shorted. Vehicle speed sensor is faulty. ASCD control unit internal circuit is malfunctioning. | <ul style="list-style-type: none"> ASCD is deactivated. Vehicle speed memory is canceled. |
| <ul style="list-style-type: none"> ASCD brake switch or stop lamp switch is faulty. | <ul style="list-style-type: none"> ASCD is deactivated. Vehicle speed memory is not canceled. |

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

=NGEL0203

NGEL0203S01

| PROCEDURE | Diagnostic procedure | | | | | | |
|---|------------------------|---------------------------------------|-----------------------------------|----------------------------|----------------------------|-----------------------------------|---------------------------|
| REFERENCE PAGE (EL-) | 165 | 166 | 167 | 168 | 169 | 169 | 171 |
| SYMPTOM | FAIL-SAFE SYSTEM CHECK | POWER SUPPLY AND GROUND CIRCUIT CHECK | ASCD BRAKE/STOP LAMP SWITCH CHECK | ASCD STEERING SWITCH CHECK | VEHICLE SPEED SENSOR CHECK | ASCD MOTOR ACTUATOR CIRCUIT CHECK | ASCD MOTOR ACTUATOR CHECK |
| ASCD cannot be set. ("CRUISE" indicator lamp does not turn ON.) | | X | | X★3 | | | |
| ASCD cannot be set. ("SET" indicator lamp does not turn ON.) | | | X | X | X | | |
| ASCD cannot be set. ("SET" indicator lamp blinks.★1) | X | | X | X | X | X | |
| Vehicle speed does not decrease after COAST/SET switch has been pressed. | | | | X | | | X |
| Vehicle speed does not return to the set speed after RES/ACCEL switch has been pressed.★2 | | | | X | | | X |
| Vehicle speed does not increase after RES/ACCEL switch has been pressed. | | | | X | | | X |
| System is not released after CANCEL switch (steering) has been pressed. | | | | X | | | X |
| Large difference between set speed and actual vehicle speed. | | | | | X | X | X |
| Deceleration is greatest immediately after ASCD has been set. | | | | | X | X | X |




★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "FAIL-SAFE SYSTEM CHECK", (EL-165) to verify repairs.

★2: If vehicle speed is greater than 40 km/h (25 MPH) after system has been released, pressing RES/ACCL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ON●OFF switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

★3: Check only ON●OFF switch built into steering switch.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



FAIL-SAFE SYSTEM CHECK

=NGEL0203S02

1. Turn ignition switch to ON position.
2. Turn ON●OFF switch to ON and check if the "SET" indicator blinks.

If the indicator lamp blinks, check the following.

- ASCD steering switch. Refer to "ASCD STEERING SWITCH CHECK", EL-168.

3. Drive the vehicle at more than 40 km/h (25 MPH) and push COAST/SET switch.

If the indicator lamp blinks, check the following.

- Vehicle speed sensor. Refer to "VEHICLE SPEED SENSOR CHECK", EL-169.
- ASCD motor actuator circuit. Refer to "ASCD MOTOR ACTUATOR CIRCUIT CHECK", EL-169.
- Replace control unit.

4. Drive the vehicle at more than 20 km/h (12 MPH).

If the indicator lamp blinks, check the following.

- Replace ASCD motor actuator.
- 5. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

If the indicator lamp blinks, check the following.

- ASCD brake/stop lamp switch. Refer to "ASCD BRAKE/STOP LAMP SWITCH CHECK", EL-167.

6. END. (System is OK.)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

=NGEL0203S03

| | | |
|--|---|--|
| 1 | CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT | |
| <p>1. Disconnect ASCD control unit harness connector. 2. Turn ignition switch ON. 3. Check voltage between ASCD control unit harness connector M119 terminal 5 (G/W) and ground.</p> | | |
| <p>ASCD control unit connector</p>  | | |
| <p>Does battery voltage exist?</p> | | |
| <p>WEL018A</p> | | |
| <p>Refer to "Wiring Diagram —ASCD—", EL-160.</p> | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse (No. 5 located in the fuse block) ● Harness for open or short |





| | | |
|--|---|--|
| 2 | CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT | |
| <p>Check continuity between ASCD control unit harness connector M119 terminal 17 (B) and body ground.</p> | | |
| <p>ASCD control unit connector</p>  | | |
| <p>Does continuity exist?</p> | | |
| <p>WEL019A</p> | | |
| <p>Refer to "Wiring Diagram —ASCD—", EL-160.</p> | | |
| Yes | ▶ | Power supply and ground circuit is OK. |
| No | ▶ | Repair harness. |




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD BRAKE/STOP LAMP SWITCH CHECK

=NGEL0203S04

| | | | |
|----------|--|--|---|
| 1 | CHECK ASCD BRAKE SWITCH CIRCUIT | <p>1. Turn ignition switch OFF. 2. Disconnect ASCD control unit harness connector. 3. Check continuity between ASCD control unit harness connector M119 terminal 8 (L/Y) and terminal 5 (G/W).</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;"> <p>ASCD control unit connector</p>  </div> <div style="width: 30%;">  <p>When brake or clutch pedal is depressed (M/T), or when brake pedal is depressed or A/T selector lever is in "N" or "P" range (A/T): Continuity should not exist.</p>  <p>When brake and clutch pedal are released (M/T), or when both brake pedal is released and A/T selector lever is not in "N" or "P" range (A/T): Continuity should exist.</p>  </div> <div style="width: 30%; font-size: small;"> <p style="text-align: right;">WEL020A</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | <p>GI MA EM LC EC FE CL MT AT TF PD</p> |
| OK | ▶ | GO TO 2. | |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● ASCD brake switch Refer to "ASCD BRAKE SWITCH AND STOP LAMP SWITCH", EL-172. ● Park/neutral position switch (A/T) Refer to "PARK/NEUTRAL POSITION SWITCH (A/T)", EL-172. ● Park/neutral position relay (A/T) Refer to "ASCD RELAY (A/T MODELS)", EL-173. ● ASCD clutch switch (M/T) Refer to "ASCD CLUTCH SWITCH (M/T)", EL-172. ● Harness for open or short ● ASCD control unit | |

| | | | |
|----------|---------------------------------------|---|---|
| 2 | CHECK STOP LAMP SWITCH CIRCUIT | <p>1. Disconnect ASCD control unit harness connector. 2. Check voltage between ASCD control unit harness connector M119 terminal 23 (BR/R) and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;"> <p>ASCD control unit connector</p>  </div> <div style="width: 30%;">  <p>Voltage [V]; Stop lamp switch: Depressed Approx. 12 Stop lamp switch: Released 0</p>  </div> <div style="width: 30%; font-size: small;"> <p style="text-align: right;">WEL035A</p> </div> </div> <p style="margin-top: 10px;">Refer to "Wiring Diagram —ASCD—", EL-160.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p> | <p>AX SU BR ST RS BT HA SC EL IDX</p> |
| OK | ▶ | ASCD brake/stop lamp switch is OK. | |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse [No. 22, located in the fuse block (J/B)] ● Harness for open or short between ASCD control unit and stop lamp switch ● Harness for open or short between fuse and stop lamp switch ● Stop lamp switch Refer to "ASCD BRAKE SWITCH AND STOP LAMP SWITCH", EL-172. | |

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


ASCD STEERING SWITCH CHECK

=NGEL0203S05

1 CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT

Check resistance between ASCD control unit harness connector M119 terminals 11 (G/OR) and 24 (LG/B).

ASCD control unit connector



| | Terminal No. | Resistance (k Ω) |
|------------------|--------------|--------------------------|
| CRUISE/ON-OFF SW | 11 - 24 | Approx. 0 |
| SET/COAST SW | | 1.47 - 1.53 |
| ACCEL/RES SW | | 3.24 - 3.36 |
| CANCEL SW | | 5.00 - 5.20 |

Refer to "Wiring Diagram —ASCD—", EL-160.

WEL022A


OK or NG

| | | |
|----|---|-----------------------------|
| OK | ▶ | ASCD steering switch is OK. |
| NG | ▶ | GO TO 2. |


2 CHECK CIRCUIT CONTINUITY

1. Disconnect ASCD steering switch and ASCD control unit connector.
2. Check continuity between ASCD steering switch connector M205 terminal 14 (G) and ASCD control unit connector M119 terminal 11 (G/OR).
3. Check continuity between ASCD steering switch connector M205 terminal 13 (L) and ASCD control unit connector M119 terminal 24 (LG/B).

ASCD control unit connector



ASCD steering switch connector



Continuity should exist.

Refer to "Wiring Diagram —ASCD—", EL-160.

LEL326A

OK or NG

| | | |
|----|---|--|
| OK | ▶ | Replace ASCD steering switch. |
| NG | ▶ | Repair or replace harness or connectors. |

AUTOMATIC SPEED CONTROL DEVICE (ASCD)





Trouble Diagnoses (Cont'd)

VEHICLE SPEED SENSOR CHECK

-NGEL0203S06

| | | |
|---|------------------------------------|--|
| 1 | CHECK SPEEDOMETER OPERATION | |
| Refer to "Wiring Diagram —ASCD—", EL-160. | | |
| Does speedometer operate normally? | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | Check speedometer and vehicle speed sensor circuit. Refer to "Trouble Diagnoses", EL-82. |


GI
MA
EM

| | | |
|--|----------------------------------|---|
| 2 | CHECK VEHICLE SPEED INPUT | |
| <ol style="list-style-type: none"> Apply wheel chocks and jack up drive wheel. Disconnect ASCD control unit harness connector. Check voltage between control unit connector M119 terminal 22 (G/B) and ground while turning drive wheel slowly by hand. | | |
| <div style="display: flex; align-items: center; justify-content: space-between;"> <div style="text-align: center;"> <p>ASCD control unit connector</p>  </div> <div style="text-align: center;">  <p>DISCONNECT</p>   </div> <div style="text-align: center;"> <p>Does voltage pointer deflect?</p> </div> </div> | | |
| WEL023A | | |
| Yes | ▶ | Vehicle speed sensor is OK. |
| No | ▶ | Check harness for open or short between ASCD control unit connector M119 terminal 22 (G/B) and combination meter connector M39 terminal 37 (G/B). |

LC
EC
FE
CL
MT
AT
TF
PD

ASCD MOTOR ACTUATOR CIRCUIT CHECK

NGEL0203S07

| 1 | CHECK ASCD MOTOR ACTUATOR (CLUTCH) | | | | | | | |
|--|---|------------------------------|-----------|--|----------------|---|---|--------------|
| <ol style="list-style-type: none"> Disconnect ASCD motor actuator connector. Measure resistance between ASCD motor actuator connector E80 terminals 1 and 4. | | | | | | | | |
| <div style="display: flex; align-items: center; justify-content: space-between;"> <div style="text-align: center;"> <p>ASCD motor actuator connector</p>  </div> <div style="text-align: center;"> <table border="1"> <thead> <tr> <th colspan="2">Terminals</th> <th>Resistance (Ω)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">4</td> <td style="text-align: center;">Approx. 38.5</td> </tr> </tbody> </table> </div> </div> | | | Terminals | | Resistance (Ω) | 1 | 4 | Approx. 38.5 |
| Terminals | | Resistance (Ω) | | | | | | |
| 1 | 4 | Approx. 38.5 | | | | | | |
| WEL024A | | | | | | | | |
| Refer to "Wiring Diagram —ASCD—", EL-160. | | | | | | | | |
| OK or NG | | | | | | | | |
| OK | ▶ | GO TO 2. | | | | | | |
| NG | ▶ | Replace ASCD motor actuator. | | | | | | |



AX
SU
BR
ST
RS
BT
HA
SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

| 2 | CHECK ASCD MOTOR ACTUATOR (MOTOR) | | | | | | | | | | | |
|--|---|--|-----------|--|----------------|---|---|-------------|--|---|--|---|
| <p>1. Disconnect ASCD motor actuator connector. 2. Measure resistance between ASCD motor actuator connector E80 terminal 6 and terminals 2, 3, and 5.</p> | | | | | | | | | | | | |
| <p>ASCD motor actuator</p> | | | | | | | | | | | | |
|  |  | <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2" style="text-align: center;">Terminals</th> <th style="text-align: center;">Resistance (Ω)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;">2</td> <td rowspan="3" style="text-align: center;">Approx. 5.2</td> </tr> <tr> <td></td> <td style="text-align: center;">3</td> </tr> <tr> <td></td> <td style="text-align: center;">5</td> </tr> </tbody> </table> | Terminals | | Resistance (Ω) | 6 | 2 | Approx. 5.2 | | 3 | | 5 |
| Terminals | | Resistance (Ω) | | | | | | | | | | |
| 6 | 2 | Approx. 5.2 | | | | | | | | | | |
| | 3 | | | | | | | | | | | |
| | 5 | | | | | | | | | | | |
| WEL135B | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ASCD motor actuator and ASCD control unit ● ASCD motor actuator (clutch) ground circuit | | | | | | | | | | |
| NG | ▶ | Replace ASCD motor actuator. | | | | | | | | | | |

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD MOTOR ACTUATOR CHECK

-NGEL0203S08

| | |
|---|--|
| 1 | CHECK ASCD WIRE |
| Check wire for improper installation, rust formation or breaks. | |
| | |
| LEL620 | |
| OK or NG | |
| OK | ▶ Replace ASCD motor actuator. |
| NG | ▶ Repair or replace wire. Refer to "ASCD Wire Adjustment", EL-174. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Electrical Component Inspection



Electrical Component Inspection


=NGEL0204

ASCD STEERING SWITCH

NGEL0204S01

Check continuity between ASCD steering switch connector M205 terminals 14 and 13 by pushing each button.

| Button | Terminals | Resistance (kΩ) |
|---------------|-----------|-----------------|
| CRUISE/ON•OFF | 13 - 14 | Approx. 0 |
| COAST/SET | | 1.47 - 1.53 |
| RES/ACCEL | | 3.24 - 3.36 |
| CANCEL | | 5.00 - 5.20 |




ASCD BRAKE SWITCH AND STOP LAMP SWITCH

NGEL0204S02

| Condition | Continuity | |
|-------------------------------|---------------------------------|--------------------------------|
| | ASCD brake switch connector M48 | Stop lamp switch connector M26 |
| When brake pedal is depressed | No | Yes |
| When brake pedal is released | Yes | No |

Check brake pedal adjustment after checking each switch. Refer to **BR-12**, "Adjustment".




ASCD CLUTCH SWITCH (M/T)

NGEL0204S03

Check continuity between clutch switch connector M4 terminals 1 and 2.

| Condition | Continuity |
|--------------------------------|------------|
| When clutch pedal is depressed | No |
| When clutch pedal is released | Yes |




PARK/NEUTRAL POSITION SWITCH (A/T)

NGEL0204S04

| A/T selector lever position | Continuity |
|-----------------------------|---------------------------|
| | Between terminals 1 and 2 |
| "P" | Yes |
| "N" | Yes |
| Except "P" and "N" | No |

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Electrical Component Inspection (Cont'd)



ASCD RELAY (A/T MODELS)

NGEL0204S05

Check continuity between ASCD relay terminals 3 and 4, 3 and 5.

| Condition | Continuity |
|---|---------------------------|
| 12V direct current supply between terminals 1 and 2 | Between terminals 3 and 5 |
| No current supply | Between terminals 3 and 4 |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

ASCD Wire Adjustment

ASCD Wire Adjustment WITH KA24DE


=NGEL0205

NGEL0205S01



WITH VG33E

NGEL0205S02




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

ASCD Wire Adjustment (Cont'd)

WITH VG33ER

NGEL0205S03



CAUTION:

- Be careful not to twist ASCD wire when removing it.
 - Do not tense ASCD wire excessively during adjustment.
- Adjust the tension of ASCD wire in the following manner.
1. Loosen lock nut and adjusting nut.
 2. Make sure that accelerator wire is properly adjusted. Refer to **FE-3**, "Adjusting Accelerator Wire".
 3. Tighten adjusting nut just until throttle drum starts to move.
 4. Loosen adjusting nut again 1/2 to 1 turn.
 5. Tighten lock nut.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER WINDOW

System Description

System Description

NGEL0102

Power is supplied at all times

- from 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal +
- through circuit breaker terminal –
- to power window relay terminal 3
- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to smart entrance control unit terminal 49

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27
- through smart entrance control unit terminal 46
- to power window relay terminal 2.

Ground is supplied

- to power window relay terminal 1
- through body grounds M14 and M68.

The power window relay is energized and power is supplied

- through power window relay terminal 5
- to main power window and door lock/unlock switch terminal 2
- to front power window switch RH terminal 4
- to rear power window switch LH terminal 2
- to rear power window switch RH terminal 2

Ground is supplied

- to main power window and door lock/unlock switch terminal 10
- through body grounds M14 and M68.

When the ignition switch is turned to the OFF position from the ON or START position, the power windows will still operate for approximately 45 seconds, unless either front door is opened.

MANUAL OPERATION

NGEL0102S01

NOTE:

Numbers in parentheses are terminal numbers which apply with switch pressed in the UP and DOWN positions respectively.

Front Door LH

NGEL0102S0101

Power is supplied

- through main power window and door lock/unlock switch terminal (12, 16)
- to front power window motor LH terminal (UP, DN).

Ground is supplied

- to front power window motor LH terminal (DN, UP)
- through main power window and door lock/unlock switch terminal (16, 12).

Then, the motor raises or lowers the window until the switch is released or the window is fully closed or open.

Front Door RH

NGEL0102S0102

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OPERATION

With front RH switch pressed, power is supplied

- through main power window and door lock/unlock switch (14, 13)
- to front power window switch RH (5, 2).

The following description is the same as the front power window switch RH description.

FRONT POWER WINDOW SWITCH RH OPERATION

Power is supplied

- through front power window switch RH (6, 3)
- to front power window motor RH (UP, DN).

Ground is supplied

- to front power window motor RH (DN, UP)

POWER WINDOW

System Description (Cont'd)

- through front power window switch RH (3, 6)
- to front power window switch RH (2, 5)
- through main power window and door lock/unlock switch (13, 14).

GI

Then, the motor raises or lowers the window until the switch is released or the window is fully closed or open.

Rear Door LH

MA

NGEL0102S0103

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OPERATION

With rear LH switch pressed, power is supplied

- through main power window and door lock/unlock switch (1, 6)
- to rear power window switch LH (1, 3).

EM

The following description is the same as the rear power window switch LH description.

LC

REAR POWER WINDOW SWITCH LH OPERATION

Power is supplied

- through rear power window switch LH (4, 6)
- to rear power window motor LH (UP, DN).

EC

Ground is supplied

- to rear power window motor LH (DN, UP)
- through rear power window switch LH (6, 4)
- to rear power window switch LH (3, 1)
- through main power window and door lock/unlock switch (6, 1).

FE

CL

Then, the motor raises or lowers the window until the switch is released or the window is fully closed or open.

MT

Rear Door RH

NGEL0102S0104

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OPERATION

With rear RH switch pressed, power is supplied

- through main power window and door lock/unlock switch (7, 9)
- to rear power window switch RH (1, 3).

AT

TF

The following description is the same as the rear power window switch RH description.

REAR POWER WINDOW SWITCH RH OPERATION

Power is supplied

- through rear power window switch RH (4, 6)
- to rear power window motor RH (UP, DN).

PD

AX

Ground is supplied

- to rear power window motor RH (DN, UP)
- through rear power window switch RH (6, 4)
- to rear power window switch RH (3, 1)
- through main power window and door lock/unlock switch (9, 7).

SU

BR

Then, the motor raises or lowers the window until the switch is released or the window is fully closed or open.

ST

AUTO OPERATION

NGEL0102S02

The power window AUTO feature enables the driver to lower the driver's window without holding the switch in the DOWN position.

The AUTO feature is activated by pressing the switch beyond the DOWN position to the AUTO position.

RS

The AUTO feature only operates on the downward movement of the driver's window.

The window can be stopped before it is fully open by pressing the window switch to the UP position.

BT

POWER WINDOW LOCK

NGEL0102S03

The power window lock prevents operation of all windows except the driver's window.

When the lock switch is pressed to lock position, ground of the front power window switch RH and the rear power window switch LH and RH is disconnected in the main power window and door lock/unlock switch. This prevents the front power window motor RH and the rear power window motor LH and RH from operating.

HA

SC

RETAINED POWER OPERATION (WITH POWER DOOR LOCKS)

NGEL0102S04

When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 seconds

- to power window relay terminal 2
- from smart entrance control unit terminal 46.

EL

IDX

POWER WINDOW

System Description (Cont'd)

Ground is supplied

- to power window relay terminal 1
- through body grounds M14 and M68.

When power and ground are supplied, the power window relay continues to be energized, and the power windows can be operated.


The retained power operation is cancelled when the driver or passenger side door is opened.

POWER WINDOW

Circuit Diagram

Circuit Diagram

NGEL0206



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WEL802A





POWER WINDOW

Wiring Diagram — WINDOW —

Wiring Diagram — WINDOW —

NGEL0104

EL-WINDOW-01






WEL700A

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX




LEL703

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03



| | | | | |
|----|----|---|---|----|
| 1 | 2 | 3 | 4 | 5 |
| 6 | 7 | 8 | 9 | 10 |
| 11 | 12 | | | |

(D1) W
(D101) W

| | | | | | | |
|----|----|----|----|----|----|----|
| 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 1 | 2 | 3 | 6 | 7 | 8 | 9 |

(D7) W

(D106) B

| | |
|---|---|
| 6 | 5 |
| 2 | 3 |
| 4 | |







(D110) W

LEL704

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04



WEL701A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER WINDOW

Trouble Diagnoses

Trouble Diagnoses

NGEL0105

| Symptom | Possible cause | Repair order |
|---|---|--|
| None of the power windows can be operated using any switch. | <ol style="list-style-type: none"> 1. 7.5A fuse, 40A fusible link and M12 circuit breaker 2. Power window relay ground circuit 3. Power window relay 4. Open/short in main power window and door lock/unlock switch circuit | <ol style="list-style-type: none"> 1. Check 7.5A fuse (No. 20, located in fuse block [J/B]), 40A fusible link (letter f, located in fuse and fusible link box) and M12 circuit breaker. Turn ignition switch ON and verify battery positive voltage is present at main power window and door lock/unlock switch terminal 2, front power window switch RH terminal 4 and rear power window switch LH and RH terminal 2. 2. Check power window relay ground circuit. 3. Check power window relay. 4. Check W wire between power window relay and main power window and door lock/unlock switch for open/short circuit. |
| Driver side power window cannot be operated but other windows can be operated. | <ol style="list-style-type: none"> 1. Front power window motor LH circuit 2. Front power window motor LH circuit 3. Main power window and door lock/unlock switch | <ol style="list-style-type: none"> 1. Check harness between main power window and door lock/unlock switch and front power window motor LH for open or short circuit. 2. Check front power window motor LH. 3. Check main power window and door lock/unlock switch. |
| Passenger side power window cannot be operated. | <ol style="list-style-type: none"> 1. Front power window switch RH 2. Front power window motor RH 3. Main power window and door lock/unlock switch 4. Power window circuit | <ol style="list-style-type: none"> 1. Check front power window switch RH. 2. Check front power window motor RH. 3. Check main power window and door lock/unlock switch. 4. Check the following. <ol style="list-style-type: none"> a. Check harnesses between main power window and door lock/unlock switch RH and front power window switch RH for open/short circuit. b. Check harnesses between front power window switch RH and front power window motor RH for open/short circuit. |
| Passenger side power window cannot be operated using main power window and door lock/unlock switch but can be operated by front power window switch RH. | <ol style="list-style-type: none"> 1. Main power window and door lock/unlock switch | <ol style="list-style-type: none"> 1. Check main power window and door lock/unlock switch. |
| One or more rear power windows cannot be operated. | <ol style="list-style-type: none"> 1. Rear power window switch 2. Rear power window motor 3. Main power window switch 4. Rear power window switch circuit | <ol style="list-style-type: none"> 1. Check rear power window switch. 2. Check rear power window motor. 3. Check main power window switch. 4. Check the following. <ol style="list-style-type: none"> a. Harnesses between the main power window switch and rear power window switches b. Harnesses between the rear power window switches and rear power window motors for open or short |
| Power windows except driver side power window cannot be operated using main power window switch but can be operated by power window switches. | <ol style="list-style-type: none"> 1. Main power window and door lock/unlock switch | <ol style="list-style-type: none"> 1. Check main power window and door lock/unlock switch. |
| Driver's window AUTO function cannot be operated using main power window and door lock/unlock switch. | <ol style="list-style-type: none"> 1. Main power window and door lock/unlock switch | <ol style="list-style-type: none"> 1. Check main power window and door lock/unlock switch. |

POWER WINDOW

Trouble Diagnoses (Cont'd)

| Symptom | Possible cause | Repair order |
|--|--|--|
| Retained accessory power feature does not operate properly | <ol style="list-style-type: none"> 1. RAP signal circuit 2. Driver or passenger side door switch circuit 3. Smart entrance control unit | <ol style="list-style-type: none"> 1. Check harness between power window relay terminal 3 and smart entrance control unit terminal 46 for open/short circuit. 2. Check the following <ol style="list-style-type: none"> a. Check harness between smart entrance control unit and driver or passenger side door switch for short circuit. b. Check driver or passenger side door switch ground circuit. c. Check driver or passenger side door switch. 3. Replace smart entrance control unit. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

POWER DOOR LOCK

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0106



WEL137B

System Description

NGEL0107

Power is supplied at all times

- through 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal +
- through circuit breaker terminal –
- to smart entrance control unit terminal 51.

GI

Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to smart entrance control unit terminal 49, and
- to key switch terminal 1.

MA

EM

LC

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M14 and M68.

EC

INPUT

NGEL0107S01

With the key in the ignition key cylinder, power is supplied

- through key switch terminal 2
- to smart entrance control unit terminal 25.

FE

CL

With front door LH open, ground is supplied

- to smart entrance control unit terminal 1
- through front door switch LH terminal 2
- through front door switch LH terminal 3
- through body grounds B6 and B10.

MT

AT

With front door RH open, ground is supplied

- to smart entrance control unit terminal 2
- through front door switch RH terminal +.

TF

With the key inserted in the front door key cylinder switch LH and turned to LOCK, ground is supplied

- to smart entrance control unit terminal 11
- through front door key cylinder switch LH terminal 1
- through front door key cylinder switch LH terminal 2
- through body grounds M14 and M68.

PD

AX

With the key inserted in the back door key cylinder switch and turned to LOCK, ground is supplied

- to smart entrance control unit terminal 11
- through back door key cylinder switch terminal 1
- through back door key cylinder switch terminal 2
- through body grounds D402 and D404.

SU

BR

With the key inserted in the front door key cylinder switch LH and turned to UNLOCK, ground is supplied

- to smart entrance control unit terminal 10
- through front door key cylinder switch LH terminal 3
- through front door key cylinder switch LH terminal 2
- through body grounds M14 and M68.

ST

RS

With the key inserted in the back door key cylinder switch and turned to UNLOCK, ground is supplied

- to smart entrance control unit terminal 10
- through back door key cylinder switch terminal 3
- through back door key cylinder switch terminal 2
- through body grounds D402 and D404.

BT

HA

With the main power window and door lock/unlock switch pressed to LOCK, ground is supplied

- to smart entrance control unit terminal 5
- through main power window and door lock/unlock switch terminal 15
- through main power window and door lock/unlock switch terminal 10
- through body grounds M14 and M68.

SC

EL

With the door lock/unlock switch RH pressed to LOCK, ground is supplied

IDX

POWER DOOR LOCK

System Description (Cont'd)

- to smart entrance control unit terminal 5
- through door lock/unlock switch RH terminal 6
- through door lock/unlock switch RH terminal 4
- through body grounds M14 and M68.

With the main power window and door lock/unlock switch pressed to UNLOCK, ground is supplied

- to smart entrance control unit terminal 4
- through main power window and door lock/unlock switch terminal 11
- through main power window and door lock/unlock switch terminal 10
- through body grounds M14 and M68.

With the door lock/unlock switch RH pressed to UNLOCK, ground is supplied

- to smart entrance control unit terminal 4
- through door lock/unlock switch RH terminal 3
- through door lock/unlock switch RH terminal 4
- through body grounds M14 and M68.

OUTPUT

Unlock

Ground is supplied

- to front door lock actuator LH terminal 4
- to front door lock actuator RH terminal 4
- to rear door lock actuator LH terminal 4
- to rear door lock actuator RH terminal 4 and
- to back door lock actuator terminal 1
- through smart entrance control unit terminal 54.

FRONT DOOR LH

Power is supplied

- to front door lock actuator LH terminal 2
- through smart entrance control unit terminal 55.

FRONT DOOR RH

Power is supplied

- to front door lock actuator RH terminal 2
- through smart entrance control unit terminal 56.

REAR DOOR LH

Power is supplied

- to rear door lock actuator LH terminal 2
- through smart entrance control unit terminal 56.

REAR DOOR RH

Power is supplied

- to rear door lock actuator RH terminal 2
- through smart entrance control unit terminal 56.

BACK DOOR

Power is supplied

- to back door lock actuator terminal 3
- through smart entrance control unit terminal 56.

Then, the doors are unlocked.

Lock

Ground is supplied

- to front door lock actuator LH terminal 2
- through smart entrance control unit terminal 55 and
- to front door lock actuator RH terminal 2
- to rear door lock actuator LH terminal 2
- to rear door lock actuator RH terminal 2 and

NGEL0107S02

NGEL0107S0201

NGEL0107S0202

- to back door lock actuator 3
- through smart entrance control unit terminal 56.

Power is supplied

- to front door lock actuator LH terminal 4
- to front door lock actuator RH terminal 4
- to rear door lock actuator LH terminal 4
- to rear door lock actuator RH terminal 4 and
- to back door lock terminal 1
- through smart entrance control unit terminal 54.

Then, the doors are locked.

OPERATION

- The main power window and door lock/unlock switch and the door lock/unlock switch RH can lock and unlock all doors. NGEL0107S03
- With the key inserted in the front door key cylinder LH or the back door key cylinder, turning it to LOCK locks all doors; turning it to UNLOCK once unlocks the corresponding door; turning it to UNLOCK again within 5 seconds of the first unlock operation unlocks all other doors (signal from door key cylinder switch).

Key Reminder

When performing a door locking operation using the main power window and door lock/unlock switch, the door lock/unlock switch RH, the front door LH lock knob or a keyfob, all the doors will lock and then the front door LH will immediately unlock if the

- key switch is in INSERTED position (key is inserted into ignition key cylinder) and
- either front door switch LH or RH is in OPEN position (door is open).

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

POWER DOOR LOCK

Circuit Diagram

Circuit Diagram

NGEL0108



WEL354A



POWER DOOR LOCK

Wiring Diagram — D/LOCK —

FIG. 1

NGEL0109

NGEL0109S01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL

WEL702A



POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 2

NGEL0109S02

EL-D/LOCK-02



WEL703A


POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)


FIG. 3

NGEL0109S03

EL-D/LOCK-03



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



WEL704A







POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 4

NGEL0109S04

EL-D/LOCK-04



WEL705A

POWER DOOR LOCK


Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NGEL0110

NGEL0110S01

| REFERENCE PAGE (EL-) | 195 | 196 | 197 | 199 | 200 | 201 |
|---|--|-------------------|-----------------------------|-------------------------------|--------------------------------|--------------------------|
| SYMPTOM | MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK | DOOR SWITCH CHECK | KEY SWITCH (INSERTED) CHECK | DOOR LOCK/UNLOCK SWITCH CHECK | DOOR KEY CYLINDER SWITCH CHECK | DOOR LOCK ACTUATOR CHECK |
| Key reminder door system does not operate properly. | X | X | X | | | X |
| Specific door lock actuator does not operate. | X | | | | | X |
| Power door lock does not operate with door lock and unlock switch (LH and RH) on door trim. | X | | | X | | |
| Power door lock does not operate with front door key cylinder operation. | X | | | | X | |



MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK Main Power Supply Circuit Check

NGEL0110S02

NGEL0110S0201

| Terminal | | Ignition switch | | |
|-----------------|--------|-----------------|-----------------|-----------------|
| (+) | (-) | OFF | ACC | ON |
| M112 - 49 (G) | Ground | Battery voltage | Battery voltage | Battery voltage |
| M112 - 51 (W/R) | | | | |


If NG, check the following.

- 40A fusible link (letter f, located in fuse and fusible link box)
- 7.5A fuse [No. 28, located in fuse block (J/B)]
- Circuit breaker
- Harness for open or short between smart entrance control unit and fuse
- Harness for open or short between circuit breaker and fuse

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)



Ground Circuit Check

NGEL0110S0202

| Terminals | | (-) | Continuity |
|-----------|-----------------------|--------|------------|
| (+) | | | |
| Connector | Terminal (wire color) | | |
| M111 | 43 (B) | Ground | Yes |
| M112 | 64 (B) | Ground | Yes |

DOOR SWITCH CHECK

NGEL0110S05

1 CHECK DOOR SWITCHES INPUT SIGNAL

Check voltage between smart entrance control unit harness connector M110 terminals 1 (G/R), 2 (G/B) or 3 (R/B) and ground.

Voltage [V]:
Door is closed - Approx. 12
Door is open - Approx. 0

Refer to "Wiring Diagram —D/LOCK—", EL-191.

OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | Door switch is OK. |
| NG | ▶ | GO TO 2. |

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

| 2 CHECK DOOR SWITCHES | |
|--|--|
| <p>1. Disconnect door switch harness connector. 2. Check continuity between door switch terminals.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Door switch connector Front LH : (B4)</p> </div> <div style="text-align: center;"> <p>Front RH : (B104) Rear LH : (B7) Rear RH : (B109)</p> </div> <div style="text-align: center;"> <p>Back : (D504)</p> </div> </div> <p style="text-align: right;">AEL651C</p> <p>Continuity: Front door switch LH terminals 2 - 3 Door switch is pressed - No Door switch is released - Yes Front door switch RH, rear door switch LH, or RH, or back door switch terminal + - ground Door switch is pressed - No Door switch is released - Yes</p> <p style="text-align: center;">OK or NG</p> | |
| OK | <p>▶ Check the following.</p> <ul style="list-style-type: none"> • Front door switch LH ground circuit, front door switch RH or back door switch ground condition • Harness for open or short between smart entrance control unit and door switch |
| NG | <p>▶ Replace door switch.</p> |

KEY SWITCH (INSERTED) CHECK

NGEL0110S06

| 1 CHECK KEY SWITCH INPUT SIGNAL | |
|---|----------------------------|
| <p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M111 terminal 25 (W/G) and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p> </div> <div style="text-align: center;"> <p>Voltage [V]: Condition of key switch: Key is INSERTED. Approx. 12 Condition of key switch: Key is REMOVED. Approx. 0</p> </div> </div> <div style="margin-top: 10px;"> </div> <p>Refer to "Wiring Diagram —D/LOCK—", EL-191.</p> <p style="text-align: right;">LEL010A</p> <p style="text-align: center;">OK or NG</p> | |
| OK | <p>▶ Key switch is OK.</p> |
| NG | <p>▶ GO TO 2.</p> |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

| | | |
|--|--------------------------------------|---|
| 2 | CHECK KEY SWITCH POWER SUPPLY | |
| <p>1. Disconnect key switch harness connector. 2. Check voltage between key switch harness connector terminal 1 and ground.</p> <div style="text-align: center;"> <p>Key switch connector (M37)</p> </div> <p>Battery voltage should exist. Refer to "Wiring Diagram —D/LOCK—", EL-191.</p> <p style="text-align: right;">AEL415B</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 28, located in the fuse block (J/B)] ● Harness for open or short between key switch and fuse |

| | | |
|---|-------------------------|---|
| 3 | CHECK KEY SWITCH | |
| <p>Check continuity between key switch terminals 1 and 2.</p> <div style="text-align: center;"> <p>Key switch (M37)</p> </div> <p>Continuity Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No</p> <p style="text-align: right;">AEL416B</p> | | |
| OK or NG | | |
| OK | ▶ | Check harness for open or short between smart entrance control unit and key switch. |
| NG | ▶ | Replace key switch. |

POWER DOOR LOCK


Trouble Diagnoses (Cont'd)

DOOR LOCK/UNLOCK SWITCH CHECK

=NGEL0110S03

1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

1. Disconnect smart entrance control unit harness connector.
2. Check continuity between smart entrance control unit harness connector M110 terminal 4 (BR) or 5 (LG/R) and ground.



| Terminals | Door lock/unlock switch (LH or RH) condition | Continuity |
|------------|--|------------|
| 4 - ground | Lock | Yes |
| | N and Unlock | No |
| 5 - ground | Unlock | Yes |
| | N and Lock | No |

Refer to "Wiring Diagram —D/LOCK—", EL-191.



WEL348A

OK or NG

- | | | |
|----|---|--------------------------------|
| OK | ▶ | Door lock/unlock switch is OK. |
| NG | ▶ | GO TO 2. |

2 CHECK DOOR LOCK/UNLOCK SWITCH

1. Disconnect door lock/unlock switch harness connector.
2. Check continuity between door lock/unlock switch terminals.



AEL642C

Main power window and door lock/unlock switch

| Condition | Terminals | | |
|-----------|---------------|----|----|
| | 10 | 11 | 15 |
| Lock | ○ | ○ | ○ |
| N | No continuity | | |
| Unlock | ○ | ○ | ○ |

Door lock/unlock switch RH

| Condition | Terminals | | |
|-----------|---------------|---|---|
| | 3 | 4 | 6 |
| Lock | ○ | ○ | ○ |
| N | No continuity | | |
| Unlock | ○ | ○ | ○ |

AEL556C

OK or NG

- | | | |
|----|---|--|
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Ground circuit for door lock/unlock switch ● Harness for open or short between door lock/unlock switch and smart entrance control unit |
| NG | ▶ | Replace door lock/unlock switch. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL

IDX

POWER DOOR LOCK


Trouble Diagnoses (Cont'd)

DOOR KEY CYLINDER SWITCH CHECK

NGEL0110S07

1 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check voltage between smart entrance control unit harness connector M110, terminal 10 (Y/R) or 11 (Y) and ground.



| Terminals | | Key position | Voltage [V] |
|-----------|--------|--------------|-------------|
| (+) | (-) | | |
| 11 | Ground | Neutral | Approx. 12 |
| | | Lock | 0 |
| 10 | Ground | Neutral | Approx. 12 |
| | | Unlock | 0 |

Refer to "Wiring Diagram —D/LOCK—", EL-192.


WEL328A

OK or NG

| | | |
|----|---|---------------------------------|
| OK | ▶ | Door key cylinder switch is OK. |
| NG | ▶ | GO TO 2. |

2 CHECK DOOR KEY CYLINDER SWITCH

1. Disconnect door key cylinder switch harness connector.
2. Check continuity between door key cylinder switch terminals.



| Terminals | Key position | Continuity |
|-----------|--------------|------------|
| 1 - 2 | Neutral | No |
| | Lock | Yes |
| 3 - 2 | Neutral | No |
| | Unlock | Yes |

WEL347A

OK or NG

| | | |
|----|---|---|
| OK | ▶ | Check the following. <ul style="list-style-type: none"> • Door key cylinder switch ground circuit • Harness for open or short between smart entrance control unit and door key cylinder switch |
| NG | ▶ | Replace door key cylinder switch. |

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)


DOOR LOCK ACTUATOR CHECK

NGEL0110S04

1 CHECK DOOR LOCK ACTUATOR CIRCUIT

Check voltage for door lock actuator.

Smart entrance control unit connector



| Door lock/unlock switch condition | Terminals | | Voltage [V] |
|--|-----------|--------|-------------|
| | + | - | |
| Lock | 54 | Ground | Approx. 12 |
| Unlock (front door LH) | 55 | Ground | |
| Unlock (front door RH, rear door LH and RH, back door) | 56 | Ground | |

LEL048A

Refer to "Wiring Diagram —D/LOCK—", EL-193.

OK or NG

| | | |
|----|---|---|
| OK | ▶ | GO TO 2. |
| NG | ▶ | Replace smart entrance control unit. (Before replacing smart entrance control unit, perform other procedures indicated in "SYMPTOM CHART". Refer to "SYMPTOM CHART", EL-195). |

2 CHECK DOOR LOCK ACTUATOR

1. Disconnect door lock actuator harness connector.
2. Apply 12V direct current to door lock actuator and check operation.

Door lock actuator connector


Front LH : (D8)

Front RH : (D108)

Rear LH : (D204)

Rear RH : (D304)

Back : (D508)



WEL833A

| Door lock actuator | Operation | Terminals | |
|--------------------|---------------|-----------|---|
| | | + | - |
| Front LH | Unlock → Lock | 4 | 2 |
| Front RH | Lock → Unlock | 2 | 4 |
| Rear LH | Unlock → Lock | 4 | 2 |
| Rear RH | Lock → Unlock | 2 | 4 |
| Back | Unlock → Lock | 1 | 3 |
| | Lock → Unlock | 3 | 1 |

WEL834A

OK or NG

| | | |
|----|---|---|
| OK | ▶ | Check harness for open or short between smart entrance control unit and door lock actuator. |
| NG | ▶ | Replace door lock actuator. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL












IDX

REMOTE KEYLESS ENTRY SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NGEL0111



WEL138B

System Description

POWER SUPPLY AND GROUND

NGEL0112

NGEL0112S03

Power is supplied at all times

- through 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal +
- through circuit breaker terminal –
- to smart entrance control unit terminal 51.

GI

MA

EM

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 20, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

LC

Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to key switch terminal 1, and
- to smart entrance control unit terminal 49.

EC

FE

Power is supplied at all times

- through 15A fuse (No. 37, located in the fuse and fusible link box)
- to vehicle security lamp relay terminal 7.

CL

Power is supplied at all times

- through 15A fuse (No. 38, located in the fuse and fusible link box)
- to vehicle security lamp relay terminal 5.

MT

Power is supplied at all times

- through 15A fuse (No. 32, located in the fuse and fusible link box)
- to horn relay terminals 1 and 5.

AT

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M14 and M68.

TF

PD

INPUTS

NGEL0112S01

With the key switch in the INSERTED (key is in ignition key cylinder) position, power is supplied

- through key switch terminal 2
- to smart entrance control unit terminal 25.

AX

With front door LH open, ground is supplied

- to smart entrance control unit terminal 1
- through front door switch LH terminal 2
- through front door switch LH terminal 3
- through body grounds B6 and B10.

SU

BR

With front door RH open, ground is supplied

- to smart entrance control unit terminal 2
- through front door switch RH terminal +.

ST

With rear door LH or RH open, ground is supplied

- to smart entrance control unit terminal 3 (with vehicle security system) or terminal 2 (without vehicle security system)
- through rear door switch LH or RH terminal +.

RS

BT

With the back door open, ground is supplied

- to smart entrance control unit terminal 3 (with vehicle security system) or terminal 2 (without vehicle security system)
- through back door switch terminal +
- through back door switch terminal –
- through body grounds D402 and D404.

HA

SC

The remote keyless entry system controls operation of the:

- power door locks
- panic alarm

EL

IDX

REMOTE KEYLESS ENTRY SYSTEM

System Description (Cont'd)

- hazard reminder.

OPERATION PROCEDURE

Power Door Lock Operation

NGEL0112S02

When the keyfob sends a LOCK signal with the key switch in the REMOVED position (key is not in ignition key cylinder), the smart entrance control unit locks all doors.

NGEL0112S0201

When the keyfob sends an UNLOCK signal once, the smart entrance control unit unlocks the front door LH. Then, if the keyfob sends another UNLOCK signal within 5 seconds, the smart entrance control unit unlocks all other doors.

Key Reminder

When performing a door locking operation using the main power window and door lock/unlock switch, the door lock/unlock switch RH, the front door LH lock knob or a keyfob, all the doors will lock and then the front door LH will immediately unlock if the

NGEL0112S0206

- key switch is in INSERTED position (key is in ignition key cylinder) and
- either front door switch LH or RH is in OPEN position (door is open).

Hazard and Horn Reminder

When smart entrance control unit receives LOCK or UNLOCK signal from the keyfob with all doors closed, power is supplied

NGEL0112S0204

- through smart entrance control unit terminals 47 and 48
- to the hazard warning lamps.

Ground is supplied

- to horn relay terminal 2
- through smart entrance control unit terminal 42.

Horn relay is now energized, and hazard warning lamps flash and horn sounds as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating function of hazard and horn reminder

| | Horn chirp mode (C mode) | | Non-horn chirp mode (S mode) | |
|--------|----------------------------|------------|------------------------------|------------|
| | Hazard warning lamps flash | Horn sound | Hazard warning lamp flash | Horn sound |
| Lock | Twice | Once | Twice | — |
| Unlock | | | | |

REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — MULTI —



Wiring Diagram — MULTI —

NGEL0114

NGEL0114S01

FIG. 1

EL-KEYLES-01



WEL706A




REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — MULTI — (Cont'd)

FIG. 2

=NGEL0114S05

EL-KEYLES-02



WEL707A

EL

REMOTE KEYLESS ENTRY SYSTEM




Wiring Diagram — MULTI — (Cont'd)

FIG. 3


NGEL0114S02

U : For USA
N : For Canada

EL-KEYLES-03



Refer to the following.
E43 - SUPER MULTIPLE JUNCTION (SMJ)



WEL708A

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses

Trouble Diagnoses

=NGEL0115

NGEL0115S01

SYMPTOM CHART

NOTE:

- Always check keyfob battery before replacing keyfob
- Use Remote Keyless Entry Tester J-43241 (follow instructions on tester) to check operation of keyfob before replacing keyfob.

| Symptom | Diagnoses/service procedure | Reference page (EL-) |
|--|--|-----------------------|
| All functions of remote keyless entry system do not operate. | 1. Keyfob battery check | 210 |
| | 2. Keyfob check (use Remote Keyless Entry Tester J-43241). | — |
| | 3. Power supply and ground circuit check | 211 |
| | 4. Replace keyfob. Refer to ID Code Entry Procedure. | 218 |
| The new ID of keyfob cannot be entered. | 1. Keyfob battery check | 210 |
| | 2. Keyfob check (use Remote Keyless Entry Tester J-43241). | — |
| | 3. Power supply and ground circuit check | 211 |
| | 4. Key switch (inserted) check | 214 |
| | 5. Door switch check | 213 |
| | 6. Replace keyfob. Refer to ID Code Entry Procedure. | 218 |
| Door lock or unlock does not function (If the power door lock system does not operate manually, check power door lock system. Refer to "Trouble Diagnoses", EL-195.). | 1. Key switch (inserted) check | 214 |
| | 2. Keyfob check (use Remote Keyless Entry Tester J-43241). | — |
| | 3. Door switch check | 213 |
| | 4. Replace keyfob. Refer to ID Code Entry Procedure. | 218 |
| Hazard indicator does not flash twice when pressing lock button of keyfob. | 1. Hazard reminder check | 216 |
| | 2. Keyfob check (use Remote Keyless Entry Tester J-43241). | — |
| | 3. Replace keyfob. Refer to ID Code Entry Procedure. | 218 |
| Room lamp does not activate properly. | 1. Room lamp operation check | 216 |
| | 2. Door switch check | 213 |
| Panic alarm (horn and headlamps) does not activate when panic alarm button is pressed continuously for more than 1.5 seconds. | 1. Vehicle security operation check. Refer to "PRELIMINARY CHECK". | 229 |
| | 2. Keyfob check (use Remote Keyless Entry Tester J-43241). | — |
| | 3. Replace keyfob. Refer to ID Code Entry Procedure. | 218 |

NOTE:

The panic alarm functions of the remote keyless entry system do not activate when the key switch is in INSERTED position (key is in ignition key cylinder).

When performing a door locking operation using the main power window and door lock/unlock switch, the door lock/unlock switch RH, the front door LH lock knob, or a keyfob, all the doors will lock and then the front door LH will immediately unlock if:

- the key switch is in INSERTED position (key is in ignition key cylinder), and
- either front door switch LH or RH is in OPEN position (door is open).

REMOTE KEYLESS ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

KEYFOB BATTERY CHECK

=NGEL0115S02

1 CHECK KEYFOB BATTERY

Remove battery. Refer to "Keyfob Battery Replacement", EL-219. Measure voltage across battery positive and negative terminals, (+) and (-).



Voltage [V]:
2.5 - 3.0

SEL277V

NOTE:

Keyfob does not function if battery is not installed correctly.

OK or NG

OK



Check keyfob battery terminals for corrosion and damage.

NG



Replace battery.

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

=NGEL0115S04

POWER SUPPLY AND GROUND CIRCUIT CHECK

| | | |
|---|---|---|
| 1 | CHECK MAIN POWER SUPPLY CIRCUIT FOR CONTROL UNIT | |
| <p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M112 terminals 49 (G) and 51 (W/R), and ground.</p> | | |
| | | |
| <p>Refer to "Wiring Diagram —KEYLES—", EL-206.</p> | | |
| LEL051A | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 40A fusible link (letter f, located in fuse and fusible link box) ● 7.5A fuse [No. 28, located in fuse block (J/B)] ● M12 circuit breaker ● Harness for open or short between smart entrance control unit and fuse ● Harness for open or short between smart entrance control unit and circuit breaker |

| | | |
|---|--|--|
| 2 | CHECK IGNITION SWITCH ACC CIRCUIT | |
| <p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M111 terminal 26 (G) and ground while ignition switch is in ACC or ON position.</p> | | |
| | | |
| <p>Refer to "Wiring Diagram —KEYLES—", EL-206.</p> | | |
| LEL052A | | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 20, located in fuse block (J/B)] ● Harness for open or short between smart entrance control unit and fuse |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

| | |
|--|--|
| 3 | CHECK GROUND CIRCUIT FOR CONTROL UNIT |
| <p>Check continuity between smart entrance control unit connector M111 terminal 43 (B) and M112 terminal 64 (B) and ground.</p> | |
| <div style="display: flex; justify-content: space-between; align-items: center;"> <div data-bbox="332 325 714 598"> </div> <div data-bbox="828 304 901 525"> </div> <div data-bbox="1031 430 1307 472"> <p>Continuity should exist</p> </div> </div> <p data-bbox="154 598 682 640">Refer to "Wiring Diagram —KEYLES—", EL-206.</p> <p data-bbox="1380 577 1469 609" style="text-align: right;">WEL332A</p> <p data-bbox="755 640 868 682" style="text-align: center;">OK or NG</p> | |
| OK | ▶ Power supply and ground circuits are OK. |
| NG | ▶ Check ground harness. |

REMOTE KEYLESS ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

=NGEL0115S05

DOOR SWITCH CHECK

1 CHECK DOOR SWITCH INPUT SIGNAL

Check voltage between smart entrance control unit connector M110 terminals 1 (G/R), 2 (G/B) or 3 (R/B) and ground.



Refer to "Wiring Diagram —KEYLES—", EL-206.


LEL028A

OK or NG

| | | |
|----|---|--------------------|
| OK | ▶ | Door switch is OK. |
| NG | ▶ | GO TO 2. |

2 CHECK DOOR SWITCH

1. Disconnect door switch harness connector.
2. Check continuity between door switch terminals.



AEL651C

Continuity:

Front door switch LH - terminals 2 and 3

- Door switch is pressed - No
- Door switch is released - Yes

Front door switch RH, back door switch or rear door switch LH or RH - terminal + and ground

- Door switch is pressed - No
- Door switch is released - Yes

OK or NG

| | | |
|----|---|---|
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> • Door switch ground circuit (front door LH, back door) or door switch ground condition • Harness for open or short between smart entrance control unit and door switch |
| NG | ▶ | Replace door switch. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERTED) CHECK


=NGEL0115S07

| | | | |
|--|--------------------------------------|-------------------|--|
| 1 | CHECK KEY SWITCH INPUT SIGNAL | | |
| <p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M111 terminal 25 (W/G) and ground.</p> | | | |
| | | | |
| Refer to "Wiring Diagram —KEYLES—", EL-206. | | | |
| OK or NG | | | |
| OK | ▶ | Key switch is OK. | |
| NG | ▶ | GO TO 2. | |

| | | | |
|--|--------------------------------------|--|--|
| 2 | CHECK KEY SWITCH POWER SUPPLY | | |
| <p>1. Disconnect key switch harness connector. 2. Check voltage between key switch harness connector terminal 1 and ground.</p> | | | |
| | | | |
| Battery voltage should exist. Refer to "Wiring Diagram —KEYLES—", EL-206. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | <p>Check the following</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 28, located in the fuse block (J/B)] ● Harness for open or short between key switch and fuse | |

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

| | |
|--|---|
| 3 | CHECK KEY SWITCH (INSERTED) |
| <p>Check continuity between terminals 1 and 2.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">AEL416B</p> <p>Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ Check harness for open or short between smart entrance control unit and key switch. |
| NG | ▶ Replace key switch. |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REMOTE KEYLESS ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

HAZARD REMINDER CHECK

=NGEL0115S09

| | | |
|---|-------------------------------|--|
| 1 | CHECK HAZARD INDICATOR | |
| Check if hazard indicator flashes with hazard switch. | | |
| Does hazard indicator operate? | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | Check "hazard indicator" circuit. Refer to "Trouble Diagnoses", EL-59. |

| | | |
|---|-------------------------------|--|
| 2 | CHECK KEYFOB OPERATION | |
| Check door lock/unlock operation with keyfob. | | |
| Does door lock/unlock operate? | | |
| Yes | ▶ | GO TO 3. |
| No | ▶ | Check keyfob battery. Refer to "KEYFOB BATTERY CHECK", EL-210. |

| | | |
|---|--|--|
| 3 | CHECK HAZARD REMINDER OUTPUT SIGNAL | |
| Measure voltage between smart entrance control unit connector M111 terminals 47 (GY) and 48 (P/B) and ground with CONSULT-II or voltmeter when hazard reminder is operated. | | |
| <p>Smart entrance control unit connector</p>  <p style="text-align: right;">Voltage should be greater than 5 volts.</p> <p style="text-align: right;">WEL816A</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | Check harness for open or short between smart entrance control unit and turn signal lamps. |
| NG | ▶ | Replace smart entrance control unit. |

INTERIOR ROOM LAMP OPERATION CHECK

NGEL0115S10

| | | |
|--|---------------------------------|--|
| 1 | CHECK INTERIOR ROOM LAMP | |
| Check if the interior room lamp switch is in the "ON" position and the lamp illuminates. | | |
| Does interior room lamp illuminate? | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | Check the following. <ul style="list-style-type: none"> ● Harness for open or short between smart entrance control unit and interior room lamp ● Interior room lamp |

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)


| | | | |
|--|---|--|--|
| 2 | CHECK INTERIOR ROOM LAMP CIRCUIT | <p>When interior room lamp switch is in "DOOR" position, check voltage across smart entrance control unit connector M111 terminal 31 (R/B) and ground.</p> | |
| | | <p>Battery voltage should exist.</p> | |
| <p>Refer to "Wiring Diagram —KEYLES—", EL-208.</p> | | LEL055A | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Repair harness between smart entrance control unit and interior room lamp. | |

| | | | |
|--|----------------------------------|--|--|
| 3 | CHECK CONTROL UNIT OUTPUT | <p>Push unlock button of keyfob with key removed and all doors closed, and check voltage across smart entrance control unit connector M111 terminal 31 (R/B) and ground.</p> | |
| | | <p>Voltage [v]: Unlock button is pushed. Approx. 0 (for approx. 30 seconds.) Unlock button is not pushed. Battery voltage</p> | |
| <p>Refer to "Wiring Diagram —KEYLES—", EL-208.</p> | | LEL056A | |
| OK or NG | | | |
| OK | ▶ | Check system again. | |
| NG | ▶ | Replace smart entrance control unit. | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure



REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)

NOTE:

- If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. To erase all ID codes in memory, register one ID code (keyfob) four times. After all ID codes are erased, the ID codes of all remaining and/or new keyfobs must be re-registered.
- When registering an additional remote controller, the existing ID codes in memory may or may not be erased. If four ID codes are stored in memory when an additional code is registered, only the oldest code is erased. If less than four ID codes are stored in memory when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new keyfobs, repeat the procedure "ADDITIONAL ID CODE ENTRY" for each new keyfob.
- Entry of a maximum of four ID codes is allowed. When more than four ID codes are entered, the oldest ID code will be erased.
- If an ID code has already been registered in the memory, the same ID code can be entered in the memory again. Each registration of an ID code counts as an additional code.

GI
MA
EM
LC
EC
FE
CL
MT


Keyfob Battery Replacement

NGEL0118

NOTE:

- Be careful not to touch the circuit board or battery terminal.
- The keyfob is water-resistant. However, if it does get wet, wipe it dry immediately.
- After battery replacement, press the keyfob buttons two or three times to check their operation.

AT
TF
PD



AX
SU
BR
ST
RS
BT
HA

SC

EL


IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location















NGEL0119



WEL949A

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Component Parts and Harness Connector Location (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

WEL139B

EL

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description

System Description


NGEL0120

NGEL0120S01

NGEL0120S0101

DESCRIPTION

1. Operation Flow



2. Setting the Vehicle Security System

Initial condition

- 1) Close all doors.
- 2) Close hood.

Disarmed phase

The vehicle security system is in the disarmed phase when any door(s) or hood is opened. The security indicator lamp blinks every second.

Pre-armed phase and armed phase

The vehicle security system turns into the “pre-armed” phase when hood and all doors are closed and the doors are locked by key or keyfob. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the “armed” phase (the system is set). (The security indicator lamp blinks every 2.6 seconds.)

3. Canceling the Set Vehicle Security System

When the doors are unlocked with the key or keyfob, the armed phase is canceled.

4. Activating the Alarm Operation of the Vehicle Security System

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.6 seconds.)

When the following operation 1) or 2) is performed, the horn, and headlamps operate intermittently for about 50 seconds. (At the same time, the system disconnects the starting system circuit.)

- 1) Engine hood or any door is opened before unlocking door with key or keyfob.
- 2) Door is unlocked without using key or keyfob (applies to early production models).

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 15A fuse [No. 37, located in the fuse block (J/B)]
- to vehicle security lamp relay terminal 7.
- through 15A fuse [No. 38, located in the fuse block (J/B)]
- to security lamp relay terminal 5.
- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to smart entrance control unit terminal 49
- to key switch terminal 1 and
- to security indicator lamp terminal 1.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 20, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

GI

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

MA

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M14 and M68.

EM

INITIAL CONDITION TO ACTIVATE THE SYSTEM

NGEL0120S02

The operation of the vehicle security system is controlled by the doors and hood.

To activate the vehicle security system, the smart entrance control unit must receive signals indicating the doors and hood are closed and the doors are locked.

LC

EC

When a door is open, smart entrance control unit terminal 1, 2, or 3 receives a ground signal from the corresponding door switch.

When the hood is open, ground is supplied

- to smart entrance control unit terminal 6
- through hood switch terminal +
- through hood switch terminal -
- through body grounds E12 and E54.

FE

CL

When smart entrance control unit receives lock signal from key cylinder or keyfob and none of the described conditions exist, the vehicle security system will automatically shift to armed phase.

MT

VEHICLE SECURITY SYSTEM ACTIVATION (WITH KEY OR KEYFOB USED TO LOCK DOORS)

NGEL0120S03

If the key is used to lock doors, ground is supplied to smart entrance control unit terminal 11

- through front door key cylinder switch LH terminal 1
- through front door key cylinder switch LH terminal 2
- through body grounds M14 and M68 or
- through back door key cylinder switch terminal 1
- through back door key cylinder switch terminal 2
- through body grounds D402 and D404.

AT

TF

PD

If this signal or lock signal from keyfob is received by the smart entrance control unit, the vehicle security system will activate automatically.

AX

Once the vehicle security system has been activated, smart entrance control unit terminal 38 supplies ground to security indicator lamp terminal 2.

SU

The security indicator lamp will illuminate for approximately 30 seconds and then blink.

The vehicle security system is now in armed phase.

BR

VEHICLE SECURITY SYSTEM ALARM OPERATION

NGEL0120S04

The vehicle security system is triggered by

- opening a door
- opening the hood
- unlocking door without using a key or keyfob.

ST

RS

Once the vehicle security system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 1, 2, 3 (door switch) or 6 (hood switch), the horn and headlamps operate intermittently and the starting system is interrupted.

BT

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)].
- to vehicle security relay terminal 2.

HA

If the vehicle security system is triggered, ground is supplied

- to vehicle security relay terminal 1
- through smart entrance control unit terminal 40.

SC

EL

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

With power and ground supplied, starter motor circuit is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 15A fuse (No. 37, located in fuse and fusible link box)
- to vehicle security lamp relay terminal 7.
- through 15A fuse (No. 38, located in fuse and fusible link box)
- to vehicle security lamp relay terminal 5.
- through 15A fuse (No. 32, located in fuse and fusible link box)
- to horn relay terminals 1 and 5.

When the vehicle security system is triggered, ground is supplied intermittently

- to vehicle security lamp relay terminal 1
- to horn relay terminal 2
- through smart entrance control unit terminals 39 and 42.

The horn and headlamps operate intermittently.

The alarm automatically turns off after 50 seconds but will reactivate if the vehicle is tampered with again.

VEHICLE SECURITY SYSTEM DEACTIVATION

NGEL0120S05

To deactivate the vehicle security system, a door must be unlocked with the key or keyfob.

When the key is used to unlock the door, smart entrance control unit terminal 10 receives a ground signal

- through front door key cylinder switch LH terminal 3
- through front door key cylinder switch LH terminal 2
- through body grounds M14 and M68 or
- through back door key cylinder switch terminal 3
- through back door key cylinder switch terminal 2
- through body grounds D402 and D404.

When the smart entrance control unit receives this signal or an unlock signal from keyfob, the vehicle security system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

NGEL0120S06

When the remote keyless entry system is triggered, ground is supplied intermittently

- to vehicle security lamp relay terminal 1 and
- to horn relay terminal 2
- through smart entrance control unit terminals 39 and 42.

The horn and headlamps operate intermittently.


The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from keyfob.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Circuit Diagram

Circuit Diagram

NGEL0121



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WEL709A

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC —



Wiring Diagram — VEHSEC —

NGEL0122

NGEL0122S01

FIG. 1

EL-VEHSEC-01



WEL710A



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

FIG. 2

NGEL0122S02

EL-VEHSEC-02



WEL711A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

NGEL0122S03

FIG. 3

EL-VEHSEC-03



Refer to the following.
 (E43) - SUPER
 MULTIPLE JUNCTION (SMJ)

WEL712A

VEHICLE SECURITY (THEFT WARNING) SYSTEM


Trouble Diagnoses

Trouble Diagnoses PRELIMINARY CHECK

NGEL0123

NGEL0123S01

The system operation is canceled by turning ignition switch to ACC at any step between START and ARMED in the following flow chart.



WEL907A

After performing preliminary check, refer to "SYMPTOM CHART", EL-230.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

NGEL0123S02

| REFERENCE PAGE (EL-) | 229 | 231 | 232 | 236 | 237 | 238 | 239 | 241 | 209 |
|-----------------------|---|---|----------------------------|-------------------------------|--------------------------------|-----------------------------------|---------------------------------------|--------------------------------|--------------------------------------|
| SYMPTOM | PRELIMINARY CHECK | POWER SUPPLY AND GROUND CIRCUIT CHECK | DOOR AND HOOD SWITCH CHECK | SECURITY INDICATOR LAMP CHECK | DOOR KEY CYLINDER SWITCH CHECK | VEHICLE SECURITY HORN ALARM CHECK | VEHICLE SECURITY HEADLAMP ALARM CHECK | STARTER INTERRUPT SYSTEM CHECK | Check "REMOTE KEYLESS ENTRY" system. |
| 1 | Vehicle security indicator does not turn ON or is not blinking. | X | X | X | X | | | | |
| 2 | Vehicle security system cannot be set by ... | All items | X | X | X | | | | |
| | | Door outside key | X | | | X | | | |
| | | Keyfob | X | | | | | | X |
| 3 | *1 Vehicle security system does not alarm when ... | Any door is opened. | X | | X | | | | |
| | | Any door is unlocked without using key or keyfob. | X | | | | | | |
| 4 | Vehicle security alarm does not activate. | All function | X | X | X | | | | |
| | | Horn alarm | X | | | | X | | |
| | | Headlamp alarm | X | | | | | X | |
| | | Starter interrupt | X | | | | | | X |
| 5 | Vehicle security system cannot be canceled by ... | Door outside key | X | | | X | | | |
| | | Keyfob | X | | | | | | X |

X : Applicable



*1: Make sure the system is in the armed phase.

Before starting trouble diagnoses above, refer to "PRELIMINARY CHECK", EL-229.

Symptom numbers in the symptom chart correspond with those of "PRELIMINARY CHECK".

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT CHECK

NGEL0123S03

Power Supply Circuit Check

NGEL0123S0301

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (wire color) | | | | |
| M112 | 49 (G) | Ground | Battery voltage | Battery voltage | Battery voltage |
| M111 | 27 (G/W) | Ground | 0V | 0V | Battery voltage |
| M111 | 26 (G) | Ground | 0V | Battery voltage | Battery voltage |

If NG, check the following.

- 7.5A fuse [No. 28, located in fuse block (J/B)]
- 10A fuse [No. 5, located in fuse block (J/B)]
- 7.5A fuse [No. 20, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse.

Ground Circuit Check

NGEL0123S0302

| Terminals | | | Continuity |
|-----------|-----------------------|--------|------------|
| (+) | | (-) | |
| Connector | Terminal (wire color) | | |
| M111 | 43 (B) | Ground | Yes |
| M112 | 64 (B) | Ground | |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

DOOR AND HOOD SWITCH CHECK Door Switch Check

=NGEL0123S04

NGEL0123S0401

| | | |
|----------|---|--------------------|
| 1 | PRELIMINARY CHECK | |
| | 1. Turn ignition switch OFF and remove key from ignition key cylinder. 2. Close all doors and hood. “SECURITY” indicator lamp should turn off. 3. Open any door. “SECURITY” indicator lamp should blink every second. | |
| | OK or NG | |
| OK | ▶ | Door switch is OK. |
| NG | ▶ | GO TO 2. |

| | | |
|----------|---|--|
| 2 | CHECK DOOR SWITCH INPUT SIGNAL | |
| | Check voltage between smart entrance control unit connector M110 terminals 1 (G/R), 2 (G/B), or 3 (R/B) and ground. | |
| | <p style="text-align: center;">Smart entrance control unit connector</p> <p style="text-align: right;">Voltage [V]: Door is closed - Approx. 12 Door is open - Approx. 0</p> | |
| | Refer to wiring diagram on EL-226. | |
| | OK or NG | |
| OK | ▶ | Door switch is OK. Refer to “Hood Switch Check”, EL-234. |
| NG | ▶ | GO TO 3. |

LEL028A

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

| | | |
|----------|--------------------------|--|
| 3 | CHECK DOOR SWITCH | <p>1. Disconnect door switch harness connector. 2. Check continuity between door switch terminals.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Door switch connector</p> <p>Front LH : (B4)</p> </div> <div style="text-align: center;"> <p>DISCONNECT</p> </div> <div style="text-align: center;"> <p>Front RH : (B104)</p> <p>Rear LH : (B7)</p> <p>Rear RH : (B109)</p> </div> <div style="text-align: center;"> <p>DISCONNECT</p> </div> <div style="text-align: center;"> <p>Back : (D504)</p> </div> <div style="text-align: center;"> <p>DISCONNECT</p> </div> </div> <p style="text-align: right;">AEL651C</p> <p>Continuity: Front door switch LH - terminals 2 and 3 Door switch is pressed - No Door switch is released - Yes Front door switch RH, back door switch or rear door switch LH or RH - terminal + and ground Door switch is pressed - No Door switch is released - Yes</p> <p style="text-align: center;">OK or NG</p> |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Door switch ground circuit (Front LH, back door) or door switch ground condition ● Harness for open or short between smart entrance control unit and door switch |
| NG | ▶ | Replace door switch. |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM


Trouble Diagnoses (Cont'd)

Hood Switch Check

=NGEL0123S0402


| | | |
|---|--------------------------|--------------------|
| 1 | PRELIMINARY CHECK | |
| 1. Turn ignition switch OFF and remove key from ignition key cylinder. 2. Close all doors and hood. “SECURITY” indicator lamp should turn off. 3. Open hood. “SECURITY” indicator lamp should blink every second. | | |
| OK or NG | | |
| OK | ▶ | Hood switch is OK. |
| NG | ▶ | GO TO 2. |

| | | |
|-----------------|--|---|
| 2 | CHECK HOOD SWITCH FITTING CONDITION | |
| OK or NG | | |
| OK | ▶ | GO TO 3. |
| NG | ▶ | Adjust installation of hood switch or hood. |

| | | |
|--|---------------------------------------|--------------------|
| 3 | CHECK HOOD SWITCH INPUT SIGNAL | |
| Check voltage between smart entrance control unit connector M110 terminal 6 (B/P) and ground. | | |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div style="margin-left: 20px;"> <p>Voltage [V]: Hood is open - Approx. 0 Hood is closed - Approx. 12</p> </div> </div> | | |
| LEL029A | | |
| OK or NG | | |
| OK | ▶ | Hood switch is OK. |
| NG | ▶ | GO TO 4. |

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

| | | | |
|--|---|-----------|----|
| 4 | CHECK HOOD SWITCH | | GI |
| <p>1. Disconnect hood switch harness connector. 2. Check continuity between hood switch terminals + and -.</p> <div style="text-align: center;">  </div> <p>Continuity: Condition: Pressed No Condition: Released Yes</p> <p style="text-align: right;">AEL430B</p> <p style="text-align: center;">OK or NG</p> | | | MA |
| OK | ▶ Check the following. | EM | |
| | <ul style="list-style-type: none"> ● Hood switch ground circuit ● Harness for open or short between smart entrance control unit and hood switch | LC | |
| NG | ▶ Replace hood switch. | EC | |
| | | FE | |
| | | CL | |
| | | MT | |
| | | AT | |
| | | TF | |
| | | PD | |
| | | AX | |
| | | SU | |
| | | BR | |
| | | ST | |
| | | RS | |
| | | BT | |
| | | HA | |
| | | SC | |
| | | EL | |

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

SECURITY INDICATOR LAMP CHECK

=NGEL0123S05

| | | | |
|---|---|--------------------------------|--|
| 1 | CHECK INDICATOR LAMP OUTPUT SIGNAL | | |
| <p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M111 terminal 38 (G/OR) and ground.</p> | | | |
| <p>Smart entrance control unit connector</p> | | | |
| LEL030A | | | |
| Refer to "Wiring Diagram —VEHSEC—", EL-226. | | | |
| OK or NG | | | |
| OK | ▶ | Security indicator lamp is OK. | |
| NG | ▶ | GO TO 2. | |

| | | | |
|---|-----------------------------|-------------------------|--|
| 2 | CHECK INDICATOR LAMP | | |
| Refer to "Wiring Diagram —VEHSEC—", EL-226. | | | |
| OK or NG | | | |
| OK | ▶ | GO TO 3. | |
| NG | ▶ | Replace indicator lamp. | |

| | | | |
|--|--|--|--|
| 3 | CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP | | |
| <p>1. Disconnect security indicator lamp harness connector. 2. Check voltage between security indicator lamp harness connector terminal 1 and ground.</p> | | | |
| <p>Security indicator lamp connector (M30)</p> | | | |
| AEL145C | | | |
| Does battery voltage exist? | | | |
| Yes | ▶ | Check harness for open or short between security indicator lamp and smart entrance control unit. | |
| No | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 28, located in fuse block (J/B)] ● Harness for open or short between security indicator lamp and fuse | |

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

DOOR KEY CYLINDER SWITCH CHECK

=NGEL0123S07

| 1 | CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL) | | | | | | | | | | | | | | | | | | | |
|---|---|---------------------------------|-------------|--|--------------|-------------|-----|-----|----|--------|---------|------------|------|---|----|--------|---------|------------|--------|---|
| <p>Check voltage between smart entrance control unit connector M110 terminal 10 (Y/R) or 11 (Y) and ground.</p> | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin-left: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">11</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Lock</td> <td>0</td> </tr> <tr> <td rowspan="2">10</td> <td rowspan="2">Ground</td> <td>Neutral</td> <td>Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>0</td> </tr> </tbody> </table> | | | Terminals | | Key position | Voltage [V] | (+) | (-) | 11 | Ground | Neutral | Approx. 12 | Lock | 0 | 10 | Ground | Neutral | Approx. 12 | Unlock | 0 |
| Terminals | | Key position | Voltage [V] | | | | | | | | | | | | | | | | | |
| (+) | (-) | | | | | | | | | | | | | | | | | | | |
| 11 | Ground | Neutral | Approx. 12 | | | | | | | | | | | | | | | | | |
| | | Lock | 0 | | | | | | | | | | | | | | | | | |
| 10 | Ground | Neutral | Approx. 12 | | | | | | | | | | | | | | | | | |
| | | Unlock | 0 | | | | | | | | | | | | | | | | | |
| <p>Refer to "Wiring Diagram —VEHSEC—" EL-227.</p> <p style="text-align: right;">WEL328A</p> | | | | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | | | | |
| OK | ▶ | Door key cylinder switch is OK. | | | | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 2. | | | | | | | | | | | | | | | | | | |

| 2 | CHECK DOOR KEY CYLINDER SWITCH | | | | | | | | | | | | | | |
|---|---------------------------------------|--|-----------|--------------|------------|-------|---------|----|------|-----|-------|---------|----|--------|-----|
| <p>1. Disconnect door key cylinder switch harness connector. 2. Check continuity between door key cylinder switch connector D9 terminals 1 and 2, and 3 and 2.</p> | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| <table border="1" style="margin-left: auto; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1 - 2</td> <td>Neutral</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">3 - 2</td> <td>Neutral</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> | | | Terminals | Key position | Continuity | 1 - 2 | Neutral | No | Lock | Yes | 3 - 2 | Neutral | No | Unlock | Yes |
| Terminals | Key position | Continuity | | | | | | | | | | | | | |
| 1 - 2 | Neutral | No | | | | | | | | | | | | | |
| | Lock | Yes | | | | | | | | | | | | | |
| 3 - 2 | Neutral | No | | | | | | | | | | | | | |
| | Unlock | Yes | | | | | | | | | | | | | |
| <p>WEL347A</p> | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | |
| OK | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Door key cylinder switch ground circuit ● Harness for open or short between smart entrance control unit and door key cylinder switch | | | | | | | | | | | | | |
| NG | ▶ | Replace door key cylinder switch. | | | | | | | | | | | | | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

VEHICLE SECURITY HORN ALARM CHECK

=NGEL0123S09

| | | |
|--|-----------------------------|---|
| 1 | CHECK HORN OPERATION | |
| Depress the horn switch to operate horn. | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | Refer to "Wiring Diagram — HORN—", EL-129 |

| | | |
|--|-----------------------------------|---|
| 2 | CHECK HORN ALARM OPERATION | |
| <p>1. Disconnect smart entrance control unit harness connector.</p> <p>2. Apply ground to smart entrance control unit harness connector M111 terminal 42 (LG/R).</p> | | |
| <p>Smart entrance control unit connector</p>  | | |
| <p>Refer to "Wiring Diagram —VEHSEC—", EL-228.</p> <p style="text-align: right;">LEL033A</p> | | |
| OK or NG | | |
| OK | ▶ | Replace smart entrance control unit. |
| NG | ▶ | Check harness for open or short between horn relay and smart entrance control unit. |

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

VEHICLE SECURITY HEADLAMP ALARM CHECK

=NGEL0123S10

| | | |
|----------|--|-----------------------|
| 1 | CHECK VEHICLE SECURITY HEADLAMP ALARM OPERATION | |
| | <p>1. Disconnect smart entrance control unit harness connector. 2. Apply ground to smart entrance control unit harness connector M111 terminal 39 (R).</p> | |
| | | |
| | OK or NG | |
| OK | ▶ | Headlamp alarm is OK. |
| NG | ▶ | GO TO 2. |

| | | |
|----------|--|--|
| 2 | CHECK HEADLAMP OPERATION | |
| | Do headlamps come on when turning lighting switch ON? | |
| Yes | ▶ | GO TO 3. |
| No | ▶ | Check headlamp system. Refer to "HEADLAMP", EL-35. |


| | | |
|----------|--|--------------------------------------|
| 3 | CHECK VEHICLE SECURITY LAMP RELAY | |
| | Check vehicle security lamp relay. | |
| | OK or NG | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Replace vehicle security lamp relay. |

| | | |
|----------|--|--|
| 4 | CHECK POWER SUPPLY FOR VEHICLE SECURITY LAMP RELAY | |
| | <p>1. Disconnect vehicle security lamp relay harness connector. 2. Check continuity between vehicle security lamp relay harness connector E22 terminal 2 (B) and ground.</p> | |
| | | |
| | OK or NG | |
| OK | ▶ | GO TO 5. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> • Harness for open between vehicle security lamp relay and ground |

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


| | | |
|--|--|---|
| 5 | CHECK VEHICLE SECURITY LAMP RELAY CIRCUIT | |
| <ol style="list-style-type: none"> 1. Disconnect vehicle security lamp relay harness connector. 2. Check voltage between vehicle security lamp relay harness connector E22 terminals 3 (R/G) and 5 (Y/B). Battery voltage should exist. 3. Check voltage between vehicle security lamp relay harness connector E22 terminals 6 (R/W) and 7 (Y/G). Battery voltage should exist. | | |
| <p>Vehicle security lamp relay connector</p>  <p>LEL068A</p> <p>OK or NG</p> | | |
| OK | ▶ | Check harness for open or short between vehicle security lamp relay and smart entrance control unit. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between fuses and vehicle security lamp relay ● Harness for open or short between vehicle security lamp relay and headlamps |

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

STARTER INTERRUPT SYSTEM CHECK


=NGEL0123S11

| | | |
|--|---|---|
| 1 | CHECK STARTER MOTOR INTERRUPT SIGNAL | |
| <p>1. Turn ignition switch ON. 2. Check voltage between smart entrance control unit connector M111 terminal 40 (R/W) and ground.</p> | | |
|  | | |
| <p>Voltage [V]: Except starter interrupted phase - Approx. 12 Starter interrupted phase - Approx. 0</p> | | |
| <p>Refer to "Wiring Diagram —VEHSEC—", 228. LEL057A</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 2. |
| NG | ▶ | <p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 5, located in fuse block (J/B)] ● Harness for open or short between vehicle security relay and fuse ● Harness for open or short between smart entrance control unit and vehicle security relay |

GI
MA
EM
LC
EC
FE
CL
MT
AT

| | | |
|--|-------------------------------------|---------------------|
| 2 | CHECK VEHICLE SECURITY RELAY | |
| <p>Check vehicle security relay. Refer to "VEHICLE SECURITY RELAY", 241.</p> | | |
| OK or NG | | |
| OK | ▶ | Check system again. |
| NG | ▶ | Replace relay. |

TF
PD
AX



Electrical Components Inspection VEHICLE SECURITY RELAY

NGEL0214

NGEL0214S01

Check continuity between terminals 3 and 4.

| Condition | Continuity |
|---|------------|
| 12V direct current supply between terminals 1 and 2 | No |
| No current supply | Yes |

SU
BR
ST
RS
BT
HA
SC

EL

IDX

SMART ENTRANCE CONTROL UNIT

Description

Description

NGEL0124

The following systems are controlled by the smart entrance control unit.

- Warning chime
- Rear window defogger timer
- Power window
- Power door lock
- Remote keyless entry
- Vehicle security
- Room lamp

For detailed description and wiring diagrams, refer to the relevant pages for the each system. The control unit receives data from the switches and sensors to control their corresponding system relays and actuators.


| System | Input | Output |
|----------------------------|--|---|
| Warning chime | Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt buckle switch Front door switch LH | Warning chime |
| Rear window defogger timer | Ignition switch (ON or START) Rear window defogger switch | Rear window defogger relay |
| Power window | Ignition switch (ON) Door switches | Power window relay |
| Power door lock | Door lock/unlock switch Key switch (insert) Door switches Door key cylinder switches | Door lock actuator |
| Remote keyless entry | Key switch (Insert) Ignition switch (ACC) Door switches Antenna (keyfob signal) Door lock/unlock switches | Horn relay Vehicle security lamp relay Door lock actuator Room lamp |
| Vehicle security | Ignition switch (ACC, ON) Door switches Hood switch Door lock/unlock switches Door key cylinder switch (lock/unlock) | Horn relay Vehicle security lamp relay Vehicle security relay (Starter interrupt) Security indicator lamp |
| Room lamp | Door switches Ignition switch Key switch (insert) | Room lamp |

SMART ENTRANCE CONTROL UNIT

Circuit Diagram

Circuit Diagram

NGEL0125



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC


Ⓢ : For USA
Ⓡ : For Canada

WEL775A

EL

SMART ENTRANCE CONTROL UNIT

Circuit Diagram (Cont'd)



SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table

Smart Entrance Control Unit Inspection Table

NGEL0126

| Terminal No. | Wire color | Connections | Operated condition | Voltage (Approximate values) |
|--------------|------------|--|--|------------------------------|
| 1 | G/R | Front door switch LH | OFF (Closed) → ON (Open) | 12V → 0V |
| 2 | G/B | Front door switch RH | OFF (Closed) → ON (Open) | 12V → 0V |
| 3 | R/B | Rear door switch LH and RH, back door switch | OFF (Closed) → ON (Open) | 12V → 0V |
| 4 | BR | Main power window and door lock/unlock switch, door lock/unlock switch RH | Neutral → Unlock | 12V → 0V |
| 5 | LG/R | Main power window and door lock/unlock switch, door lock/unlock switch RH | Neutral → Lock | 12V → 0V |
| 6 | B/P | Hood switch | ON (Open) → OFF (Closed) | 0V → 12V |
| 10 | Y/R | Front door key cylinder unlock switch LH or back door key cylinder unlock switch | OFF (Neutral) → ON (Unlock) | 12V → 0V |
| 11 | Y | Front door key cylinder lock switch LH or back door key cylinder lock switch | OFF (Neutral) → ON (Lock) | 12V → 0V |
| 14 | G/B | Rear window defogger switch | OFF → ON | 12V → 0V |
| 25 | W/G | Ignition key switch (Insert) | Key inserted → Key removed from ignition key cylinder | 12V → 0V |
| 26 | G | Ignition switch (ACC) | ACC position | 12V |
| 27 | G/W | Ignition switch (ON) | Ignition key is in ON position | 12V |
| 28 | B/P | Seat belt buckle switch | Unfastened → Fastened (Ignition key is in ON position) | 0V → 12V |
| 31 | R/B | Room lamp | When interior lamp is operated using keyfob. (Interior lamp switch in DOOR position) | 12V → 0V |
| 32 | R/B | Door ajar indicator lamp | OFF → ON (Ignition key is in ON position) | 12V → 0V |
| 37 | G/R | Rear window defogger relay | OFF → ON (Ignition key is in ON position) | 12V → 0V |
| 38 | G/OR | Security indicator lamp | Turns off → Turns on | 12V → 0V |
| 39 | R | Vehicle security lamp relay | When panic alarm is operated using keyfob or when alarm is activated | 12V → 0V |
| 40 | R/W | Vehicle security relay (Starter cut) | OFF → ON (Ignition key is in ON position) | 12V → 0V |
| 42 | R | Horn relay | When panic alarm is operated using keyfob or when alarm is activated | 12V → 0V |
| 43 | B | Ground | — | — |
| 46 | G/W | Power window relay | Ignition key is in ON position → 45 seconds after ignition key is turned to OFF position | 12V → 0V |
| 47 | GY | Turn signal lamp LH | When doors are locked using keyfob | 12V → 0V |
| 48 | P/B | Turn signal lamp RH | When doors are locked using keyfob | 12V → 0V |
| 49 | G | Power source (Fuse) | — | 12V |
| 50 | R/G | Battery saver (Room lamp) | Turns off → Turns on | 12V → 0V |
| 51 | W/R | Power source (C/B) | — | 12V |

SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table (Cont'd)



| Terminal No. | Wire color | Connections | Operated condition | | Voltage (Approximate values) |
|--------------|------------|---|---|-----------------|------------------------------|
| 54 | L | Front door lock actuator LH and RH, rear door lock actuator LH and RH | Main power window and door lock/unlock switch, door lock/unlock switch RH | Lock | 12V |
| | | | | Neutral, unlock | 0V |
| 55 | G/W | Front door lock actuator LH | Main power window and door lock/unlock switch, door lock/unlock switch RH | Unlock | 12V |
| | | | | Neutral, lock | 0V |
| 56 | L/R | Front door lock actuator RH, rear door lock actuator LH and RH, back door lock actuator | Main power window and door lock/unlock switch, door lock/unlock switch RH | Unlock | 12V |
| | | | | Neutral, lock | 0V |
| 58 | L/R | Lighting switch | 1ST, 2ND positions: ON → OFF | | 12V → 0V |
| 64 | B | Ground | — | | — |

ELECTRICAL UNITS LOCATION

Engine Compartment

Engine Compartment

NGEL0129



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

WEL919A

EL


IDX

ELECTRICAL UNITS LOCATION

Passenger Compartment

Passenger Compartment

NGEL0130




AEL157C


ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)

A



Rear view of fuse block (J/B)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS








BT

HA

SC

EL

IDX




HARNESS LAYOUT

How to Read Harness Layout

How to Read Harness Layout

NGEL0172



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness

TO USE THE GRID REFERENCE

NGEL0172S01

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

NGEL0172S02

Main symbols of connector (in Harness Layout) are indicated below.


| Connector type | Waterproof type | | Standard type | |
|--|-----------------|--------|---------------|--------|
| | Male | Female | Male | Female |
| <ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector | | | | |
| <ul style="list-style-type: none"> • Cavity: From 5 to 8 | | | | |
| <ul style="list-style-type: none"> • Cavity: More than 9 | | | | |
| <ul style="list-style-type: none"> • Ground terminal etc. | — | | | |

HARNES LAYOUT

Outline

Outline

NGEL0173



LEL161A

NOTE:

For detailed ground distribution information, refer to "Ground Distribution", EL-18.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HARNESS LAYOUT

Main Harness

NGEL0174

Main Harness



WEL141B

HARNESS LAYOUT

Main Harness (Cont'd)

| | | | | |
|------|---|--|------|--|
| E1 | (M2) W/10 : To (R1) | (M49) B4 : Parking brake switch | E1 * | (M81) W/24 : To (M36) (with VG33E and VG33ER engine) |
| A2 | (M4) L/2 : ASCD clutch switch (with M/T) | (M50) C3 : Audio unit | D3 * | (M82) W/24 : To (E74) (with VG33E and VG33ER engine) |
| B2 | (M5) L/2 : Clutch interlock switch (with M/T) | (M61) D1 : Audio unit | E3 | (M83) W/10 : To (E102) |
| A2 | (M6) B/5 : Vehicle security relay (with power door locks) | (M62) D3 : Cigarette lighter socket | B4 | (M84) L/4 : Rear window defogger relay |
| A3 | (M7) W/18 : To (E83) | (M63) D2 : Hazard switch | A2 | (M85) W/4 : Rear window defogger timer |
| A2 | (M8) W/12 : To (D2) | (M64) E4 : Hazard switch | E5 | (M86) GY/8 : To (B1) |
| A3 | (M9) W/12 : To (D1) | (M67) C1 : Fan switch | E5 | (M87) B/8 : To (E2) |
| A2 | (M11) W/8 : Warning chime unit (without power door locks) | (M68) D1 * : To (M141) (with KA24DE engine) | E5 | (M88) GY/8 : To (E3) |
| A4 | (M12) W/2 : Circuit breaker (with power door locks) | (M68) D1 * : To (F28) (with VG33ER engine) | C3 | (M89) W/6 : Rear wiper switch |
| B4 | (M13) L/4 : Power window relay (with power windows) | (M69) D1 * : To (F28) (with VG33E engine) | E3 | (M91) W/8 : To (E103) |
| A4 | (M14) : Body ground | (M69) E1 * : To (F27) (with KA24DE engine) | C1 | (M95) B/12 : Air control |
| C4 * | (M19) W/3 : Seat belt buckle switch | (M69) E1 * : To (F27) (with VG33E and VG33ER engine) | E2 | (M96) B/6 : Intake door motor |
| D5 | (M21) GY/4 : Rear heated oxygen sensor (with KA24DE engine) | (M60) D3 : Thermo control amplifier | B2 | (M110) W/24 : Smart entrance control unit |
| B3 | (M26) W/16 : Fuse block (J/B) | (M61) D2 : Fan resistor | B2 | (M111) GY/24 : Smart entrance control unit |
| B3 * | (M27) W/10 : Fuse block (J/B) | (M62) D2 : Blower motor | B2 | (M112) GY/16 : Smart entrance control unit |
| C4 * | (M28) W/3 : Illumination control switch | (M63) E2 : To (D101) | E4 | (M113) Y/12 : Air bag unit |
| C4 | (M30) W/4 : Security indicator lamp (with power door locks) | (M64) E2 * : To (D102) | E4 | (M114) Y/20 : Air bag unit |
| B4 | (M31) W/3 : Fuse block (J/B) | (M65) E3 : To (E43) | E4 | (M115) Y/12 : Air bag unit |
| B3 | (M32) W/16 : Data link connector | (M66) E3 * : To (E44) | B3 | (M116) Y/7 : To (M201) |
| D4 | (M35) W/6 : A/T device (with A/T) | (M67) E3 * : To (E101) | D3 | (M117) Y/2 : Passenger air bag module |
| C3 | (M37) W/2 : Key switch | (M68) E3 : Body ground | C3 | (M118) W/16 : Audio unit |
| B2 | (M38) W/24 : Combination meter | (M69) F4 : G-sensor | B2 | (M119) BR/24 : ASCD control unit |
| B2 | (M39) BR/24 : Combination meter | (M76) A4 * : ATP relay (with A/T) | E4 | (M131) W/3 : Seat belt buckle switch RH |
| B1 | (M44) SB/4 : Diode - 1 | (M77) A3 * : TCM (with A/T) | D3 | (M132) W/12 : Audio amplifier |
| C1 | (M45) B/3 : Combination flasher unit | (M78) A3 * : TCM (with A/T) | D3 | (M133) W/12 : Audio amplifier |
| B1 | (M46) L/4 : Fuel pump relay | (M79) A4 * : Diode - 2 (with A/T) | E1 | (M134) BR/2 : Pillar tweeter RH |
| B1 | (M47) B/2 : Stop lamp switch | (M81) E1 * : To (M36) (with KA24DE engine) | B3 | (M137) Y/4 : To (E88) |
| B2 | (M48) L/2 : ASCD brake switch (A/T shift lock brake switch) | | A1 | (M138) BR/2 : Pillar tweeter LH |
| | | | B3 | (M138) Y/6 : To (M201) |
| | | | B3 | (M140) GY/8 : To (M203) |

WEL142B

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX


HARNESS LAYOUT

Main Harness (Cont'd)

Diode (M44)



Diode (M79)



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

WEL972A

HARNESS LAYOUT


Engine Room Harness

Engine Room Harness KA24DE Engine Compartment

NGEL0175

NGEL0175S01

NGEL0175S0101



WEL143B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL

IDX

HARNES LAYOUT

Engine Room Harness (Cont'd)

| | | | | | | | | |
|----|------------|--|----|------------|--|----|------------|---|
| A2 | (E1) B/3 | : Headlamp RH | | (E16) BR/2 | : Front wheel sensor LH | A4 | (E30) L/4 | : A/C relay |
| B2 | (E2) GY/2 | : Front wheel sensor RH | A1 | (E17) GY/8 | : Daytime light control unit (with DTRL) | C1 | (E31) - | : Fuse and fusible link box |
| B2 | (E3) B/2 | : Dual-pressure switch | B1 | (E18) GY/6 | : Daytime light control unit (with DTRL) | C2 | (E32) GY/9 | : To (E202) |
| B2 | (E4) B/1 | : Horn | A2 | (E19) GY/3 | : Front combination lamp RH | B2 | (E33) GY/6 | : To (E201) |
| C4 | (E5) BR/2 | : Washer fluid level switch (for Canada) | B1 | (E25) - | : Relay box | F2 | (E37) GY/2 | : Brake fluid level switch |
| D4 | (E6) GY/2 | : Front washer motor | A3 | (E28) L/4 | : Clutch interlock relay | F2 | (E38) B/25 | : ABS actuator and electric unit (control unit) |
| C3 | (E7) B/3 | : Headlamp LH | A4 | (E29) L/4 | : Horn relay | D1 | (E41) GY/3 | : To (F25) |
| D3 | (E8) B/2 | : Intake air temperature sensor | | | | D1 | (E42) GY/6 | : Front wiper motor |
| D3 | (E12) - | : Body ground | | | | C1 | (E54) - | : Body ground |
| C3 | (E13) GY/3 | : Front combination lamp LH | | | | B1 | (E55) - | : Battery |
| E3 | (E14) - | : Body ground | | | | D4 | (E78) BR/2 | : Rear washer motor |
| | | | | | | C2 | (E85) Y/2 | : Crash zone sensor |
| | | | | | | B2 | (E86) BR/2 | : Side marker lamp RH |
| | | | | | | D4 | (E87) BR/2 | : Side marker lamp LH |

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


HARNESS LAYOUT

Engine Room Harness (Cont'd)

Passenger Compartment

NGEL0175S0102

- * E43 SMJ : To M65
- E44 B/2 : To M66
- E45 BR/4 : Combination switch (lighting switch)
- E46 GY/8 : Front wiper switch
- E47 BR/8 : Combination switch (turn signal switch)
- * E48 W/6 : Ignition switch
- * E49 W/12 : Fuse block (J/B)
- E50 W/4 : Fuse block (J/B)
- E52 B/2 : Fuse block (J/B)
- E53 BR/12 : To M7
- E74 W/24 : To M82 (with VG33E and VG33ER engine)
- E88 Y/4 : To M137



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

WEL146B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


HARNES LAYOUT

Engine Room Harness (Cont'd)

VG33E AND VG33ER Engine Compartment

=NGEL0175S02

NGEL0175S0201



WEL147B

HARNESS LAYOUT

Engine Room Harness (Cont'd)

| | | | |
|------|-------------|--|--|
| A2 | (E1) B/3 | : Head lamp RH | |
| B2 | (E2) GY/2 | : Front wheel sensor RH | |
| B2 * | (E3) B/4 | : Triple-pressure switch | |
| B3 | (E4) B/1 | : Horn | |
| C4 | (E5) BR/2 | : Washer fluid level switch (for Canada) | |
| D4 | (E6) GY/2 | : Front washer motor | |
| C3 | (E7) B/3 | : Headlamp LH | |
| D3 * | (E8) B/2 | : Intake air temperature sensor | |
| D3 | (E9) GY/2 | : Hood switch (with vehicle security system) | |
| D1 | (E10) B/1 | : Vehicle security horn (with vehicle security system) | |
| D3 * | (E12) - | : Body ground | |
| C3 | (E13) GY/3 | : Front combination lamp LH | |
| E3 | (E14) - | : Body ground | |
| E2 | (E16) BR/2 | : Front wheel sensor LH | |
| A1 | (E17) GY/8 | : Daytime light control unit (with DTRL) | |
| B1 | (E18) GY/6 | : Daytime light control unit (with DTRL) | |
| A2 | (E19) GY/3 | : Front combination lamp RH | |
| B3 | (E22) BR/6 | : Vehicle security lamp relay (with vehicle security system) | |
| C1 | (E25) - | : Relay box | |
| A3 | (E27) BR/6 | : Park/neutral position (PNP) relay (with A/T) | |
| A4 | (E28) L/4 | : Clutch interlock relay (with M/T) | |
| A4 | (E29) W/3 | : Horn relay | |
| A4 | (E30) L/4 | : A/C relay | |
| C1 | (E31) - | : Fuse and fusible link box | |
| C2 | (E34) GY/8 | : Park/neutral position (PNP) switch (with A/T) | |
| D2 | (E35) GY/2 | : Park/neutral position (PNP) switch (with A/T) | |
| C1 | (E83) BR/4 | : Turbine revolution sensor | |
| F2 | (E84) B/2 | : Supercharger bypass valve control solenoid valve | |
| C2 | (E85) Y/2 | : Crash zone sensor | |
| B2 | (E86) BR/2 | : Side marker lamp RH | |
| D4 | (E87) BR/2 | : Side marker lamp LH | |
| B3 | (E89) B/2 | : Ambient air temperature sensor | |
| - | (E201) GY/1 | : To (E67) | |
| - | (E202) GY/1 | : Starter motor | |
| - | (E203) - | : Starter motor | |
| - | (E204) - | : Battery | |
| G2 | (E37) GY/2 | : Brake fluid level switch | |
| G2 * | (E39) B/25 | : ABS actuator and electric unit (control unit) | |
| D1 | (E42) W/6 | : Front wiper motor | |
| D1 * | (E54) - | : Body ground | |
| B2 | (E55) - | : Battery | |
| B4 * | (E56) L/4 | : Front fog lamp relay | |
| A3 | (E57) B/2 | : Front fog lamp RH | |
| C4 | (E58) B/2 | : Front fog lamp LH | |
| E2 * | (E61) L/2 | : EVAP canister purge volume control solenoid valve | |
| E3 | (E63) GY/1 | : To (A3) | |
| E3 | (E64) GY/1 | : To (A4) | |
| E2 | (E66) GY/4 | : To (A5) | |
| C2 | (E67) GY/1 | : To (E201) | |
| B3 | (E68) GY/2 | : Ambient air temperature switch | |
| B2 * | (E71) GY/2 | : Dropping resistor | |
| C1 * | (E72) BR/8 | : Terminal cord assembly | |
| C2 * | (E73) GY/3 | : Revolution sensor | |
| B1 | (E75) - | : To (E31) | |
| B1 * | (E76) - | : To (E31) | |
| D4 * | (E78) BR/2 | : Rear washer motor | |
| D1 | (E80) GY/6 | : ASCD motor actuator | |

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

WEL148B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


HARNESS LAYOUT

Engine Room Harness (Cont'd)

Passenger Compartment

NGEL0175S0202

- * E43 SMJ : To M65
- E44 B/2 : To M66
- E45 BR/4 : Combination switch (lighting switch)
- E46 GY/8 : Front wiper switch
- E47 BR/8 : Combination switch (turn signal switch)
- * E48 W/6 : Ignition switch
- * E49 W/12 : Fuse block (J/B)
- E50 W/4 : Fuse block (J/B)
- E52 B/2 : Fuse block (J/B)
- E53 W/18 : To M7
- E59 W/3 : Combination switch (front fog lamp switch)
- * E74 W/20 : To M82
- * E88 Y/4 : To M137



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

WEL149B

HARNES LAYOUT

Engine Control Harness

KA24DE

NGEL0176

NGEL0176S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Engine Control Harness



WEL932A

HARNESS LAYOUT

Engine Control Harness (Cont'd)

| | | | | | | |
|----|---------|--|----|---------|--------|---|
| D2 | * (F1) | BR/4 : Mass air flow sensor | F3 | * (F17) | GY/2 | : Distributor (ignition coil) |
| C2 | * (F2) | GY/2 : Knock sensor | E3 | * (F18) | B/2 | : Injector No. 1 |
| D2 | * (F3) | BR/3 : Throttle position sensor | F2 | * (F19) | B/2 | : Injector No. 2 |
| D2 | * (F4) | GY/3 : Throttle position switch (closed throttle position switch and wide open throttle position switch) | F2 | * (F20) | B/2 | : Injector No. 3 |
| E2 | * (F5) | GY/2 : EGR temperature sensor | F2 | * (F21) | B/2 | : Injector No. 4 |
| F2 | * (F6) | BR/2 : IACV-AAC valve | F2 | * (F22) | G/2 | : EGRC-solenoid valve |
| E2 | * (F7) | PU/2 : IACV-FICD solenoid valve | E1 | * (F25) | GY/3 | : To (E41) |
| C2 | (F8) | B/1 : Power steering oil pressure switch | E2 | * (F26) | L/2 | : EVAP canister purge volume control solenoid valve |
| D3 | * (F9) | GY/2 : Engine coolant temperature sensor | B3 | * (F27) | W/8 | : To (M69) |
| D3 | (F10) | B/1 : Thermal transmitter | B3 | * (F28) | W/6 | : To (M68) |
| D2 | * (F11) | - : Engine ground | B4 | * (F29) | GY/124 | : ECM |
| D3 | * (F12) | - : Engine ground | A4 | * (F30) | L/4 | : ECM relay |
| F4 | * (F13) | GY/6 : Distributor (camshaft position sensor) | A4 | * (F31) | GY/6 | : Joint connector-1 (early production) |
| G3 | * (F14) | GY/2 : Resistor | A5 | (F32) | GY/6 | : Joint connector-2 (early production) |
| F3 | (F15)-1 | B/1 : A/C compressor | A3 | * (F36) | W/20 | : To (M61) |
| G3 | * (F16) | GY/3 : Heated oxygen sensor 1 (front) or SB/3 | | | | |

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


WEL150B

HARNESS LAYOUT

Engine Control Harness (Cont'd)

VG33E

NGEL0176S02



LEL158A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA

SC

EL

IDX


HARNESS LAYOUT

Engine Control Harness (Cont'd)

Engine control harness

- F3 * (F1) BR/4 : Mass air flow sensor
- F2 * (F3) BR/4 : Throttle position sensor
- F2 (F4) GY/3 : Throttle position switch (closed throttle position switch and wide open throttle position switch)
- C2 (F8) B/2 : Power steering oil pressure switch
- D2 * (F9) GY/2 : Engine coolant temperature sensor
- D2 (F10) B/1 : Thermal transmitter
- E2 * (F11) - : Engine ground
- F2 * (F12) - : Engine ground
- F2 * (F13) GY/6 : Distributor (camshaft position sensor)
- E2 * (F14) GY/2 : Resistor
- E3 (F15) B/1 : A/C compressor
- E2 * (F17) GY/2 : Distributor (ignition coil)
- B3 * (F27) W/18 : To (M59)
- A3 * (F28) W/16 : To (M58)
- B4 * (F29) GY/124 : ECM
- A4 * (F30) L/4 : ECM relay
- A4 * (F31) GY/6 : Joint connector-1 (early production)
- A5 * (F32) GY/6 : Joint connector-2 (early production)
- A5 * (F33) GY/6 : Joint connector-3 (early production)
- A5 * (F34) GY/6 : Joint connector-4 (early production)
- A4 * (F35) SB/2 : Diode
- C4 * (F36) W/24 : To (M61)
- D2 * (F37) B/8 : To (F101)
- C1 * (F38) GY/8 : To (F102)
- E1 * (F39) GY/4 : Heated oxygen sensor (rear) (bank 2)
- E1 * (F40) GY/3 : Heated oxygen sensor (front) (bank 2)

Diode (F35)



Engine control harness (continued)

- D1 * (F41) GY/3 : Heated oxygen sensor (front) (bank 1)
- D1 * (F42) GY/4 : Heated oxygen sensor (rear) (bank 1)
- E1 * (F43) GY/8 : To (F201)

Engine sub harness

- D2 * (F101) B/8 : To (F37)
- D1 * (F102) GY/8 : To (F38)
- E2 * (F103) B/2 : Injector No. 1
- E2 * (F104) B/2 : Injector No. 2
- E2 * (F105) B/2 : Injector No. 3
- F2 * (F106) B/2 : Injector No. 4
- E2 * (F107) B/2 : Injector No. 5
- F1 * (F108) B/2 : Injector No. 6
- E1 * (F109) GY/2 : Knock sensor
- F1 * (F110) GY/2 : Crankshaft position sensor (OBD)
- G2 (F111) GY/2 : IACV-FICD solenoid valve
- G2 * (F112) BR/2 : IACV-AAC valve

Generator harness

- F4 (A1) - : Body ground
- D3 (A2) B/1 : Oil pressure switch
- F3 (A3) GY/1 : To (E63)
- F3 (A4) GY/1 : To (E64)
- F3 (A5) GY/4 : To (E65)
- E3 (A6) - : Generator
- D3 (A7) - : Generator
- D3 (A8) GY/2 : Generator


* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS LAYOUT

Engine Control Harness (Cont'd)

VG33ER

NGEL0176S05



LEL158A

WEL152B

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Engine Control Harness (Cont'd)

Engine control harness

- F3 * (F1) BR/4 : Mass air flow sensor
- F2 * (F3) BR/3 : Throttle position sensor
- F2 (F4) GY/3 : Throttle position switch (closed throttle position switch and wide open throttle position switch)
- C2 (F8) B/2 : Power steering oil pressure switch
- E2 * (F11) - : Engine ground
- F2 * (F12) - : Engine ground
- F2 * (F13) GY/6 : Distributor (camshaft position sensor)
- E2 * (F14) GY/2 : Resistor
- E3 (F15) B/1 : A/C compressor
- E2 * (F17) GY/2 : Distributor (ignition coil)
- B3 * (F27) W/18 : To (M59)
- A3 * (F28) W/20 : To (M58)
- B4 * (F29) GY/124 : ECM
- A4 * (F30) L/4 : ECM relay
- A4 * (F31) GY/6 : Joint connector-1 (early production)
- A5 * (F32) GY/6 : Joint connector-2 (early production)
- A5 * (F33) GY/6 : Joint connector-3 (early production)
- A5 * (F34) GY/6 : Joint connector-4 (early production)
- A4 * (F35) SB/2 : Diode
- C4 * (F36) W/24 : To (M81)
- D2 * (F37) G/10 : To (F101)
- C1 * (F38) GY/10 : To (F102)
- E1 * (F39) GY/4 : Heated oxygen sensor 2 (rear) (bank 2)
- E1 * (F40) GY/3 : Heated oxygen sensor 1 (front) (bank 2)


Engine control harness (continued)

- D1 * (F41) GY/3 : Heated oxygen sensor 1 (front) (bank 1)
- D1 * (F42) GY/4 : Heated oxygen sensor 2 (rear) (bank 1)
- E1 * (F43) GY/8 : To (F201)
- Engine sub harness**
- D2 * (F101) B/8 : To (F37)
- D1 * (F102) GY/10 : To (F38)
- E2 * (F103) B/2 : Injector No. 1
- E2 * (F104) B/2 : Injector No. 2
- E2 * (F105) B/2 : Injector No. 3
- F2 * (F106) B/2 : Injector No. 4
- E2 * (F107) B/2 : Injector No. 5
- F1 * (F108) B/2 : Injector No. 6
- E1 * (F109) GY/2 : Knock sensor
- F1 * (F110) GY/2 : Crankshaft position sensor (OBD)
- G2 (F111) GY/2 : IACV-FICD solenoid valve
- G2 * (F112) BR/2 : IACV-AAC valve
- D2 * (F113) GY/2 : Engine coolant temperature sensor
- D2 * (F114) B/1 : Thermal transmitter

Generator harness

- F4 (A1) - : Body ground
- D3 (A2) B/1 : Oil pressure switch
- F3 (A3) GY/1 : To (E63)
- F3 (A4) GY/1 : To (E64)
- F3 (A5) GY/4 : To (E65)
- E3 (A6) - : Generator
- D3 (A7) - : Generator
- D3 (A8) GY/2 : Generator

Diode (F35)



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS LAYOUT

Engine No. 2 Harness

Engine No. 2 Harness KA24DE

NGEL0177

NGEL0177S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

For detailed ground distribution information, refer to "GROUND DISTRIBUTION".



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except to the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


AEL659C

HARNES LAYOUT

Engine No. 2 Harness (Cont'd)

VG33E

NGEL0177S02



- * (F201) GY/8 : To (F43)
- * (F212)⁺ GY/2 : Vehicle speed sensor (with 4WD)
- * (F212)⁺⁺ GY/2 : Vehicle speed sensor (with 2WD M/T)
- * (F212)⁺⁺⁺ GY/2 : Vehicle speed sensor (with 2WD A/T)
- (F216) GY/2 : Back-up lamp switch (with M/T)
- * (F218) B/2 : Park/neutral position (PNP) switch (with M/T)
- (F219) GY/1 : 4WD switch (with M/T)
- (F220) GY/1 : 4WD switch (with M/T)
- (F221) GY/2 : 4WD switch (with A/T)
- (F222) B/2 : Transfer neutral position switch (with A/T)

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


LEL350A

HARNESS LAYOUT

Engine No. 2 Harness (Cont'd)

VG33ER

NGEL0177S03



- * (F201) GY/8 : To (F43) (VG33E models)
- * (F201) GY/10: To (F43) (VG33ER models)
- * (F212)+ GY/2 : Vehicle speed sensor (with 4WD)
- * (F212)++ GY/2 : Vehicle speed sensor (with 2WD M/T)
- * (F212)+++ GY/2 : Vehicle speed sensor (with 2WD A/T)
- (F216) GY/2 : Back-up lamp switch (with M/T)
- * (F218) B/2 : Park/neutral position (PNP) switch (with M/T)
- (F219) GY/1 : 4WD switch (with M/T)
- (F220) GY/1 : 4WD switch (with M/T)
- (F221) GY/2 : 4WD switch (with A/T)
- (F222) B/2 : Transfer neutral position switch (with A/T)

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

WEL474A

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


HARNESS LAYOUT

Body Harness

Body Harness


NGEL0180

For detailed ground distribution information, refer to "GROUND DISTRIBUTION".




- ⓑ1 GY/8 : To Ⓜ86
- ⓑ2 B/8 : To Ⓜ87
- ⓑ3 GY/8 : To Ⓜ88
- ⓑ4 B/3 : Front door switch LH
- ⓑ5 W/8 : To ⓓ201
- ⓑ6 — : Body ground
- ⓑ7 BR/1 : Rear door switch LH
- ⓑ8 BR/2 : Rear speaker LH
- ⓑ9 W/6 : Rear combination lamp LH
- ⓑ10 — : Body ground
- ⓑ11 W/18 : To ⓓ401
or
W/12
- ⓑ13 Y/2 : Driver seat belt pretensioner

Body ground



Body ground



WEL154B

HARNES LAYOUT

Body No. 2 and Chassis Harness

NGEL0201

Body No. 2 and Chassis Harness

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL
IDX

For detailed ground distribution information refer to "GROUND DISTRIBUTION".

Body Harness No.2


- * (B101) W/18 : To (M67)
- (B102) W/10 : To (M83)
- (B103) W/8 : To (M61)
- (B104) BR/1 : Front door switch RH
- (B105) W/8 : To (C307)

- * (B106) — : Body ground
- * (B107) GY/2 : Fuel pump
- * (B108) GY/4 : Fuel tank gauge unit



- (B109) BR/1 : Rear door switch RH
- (B110) BR/2 : Rear speaker RH
- (B111) GY/4 : To (C1)
- (B112) GY/8 : To (C2)
- * (B113) GY/8 : To (C3)

- (B114) W/8 : Trailer tow control unit (with trailer tow)
- (B115) W/6 : Rear combination lamp RH
- * (B116) — : Body ground
- (B117) Y/2 : Passenger seat belt pretensioner

Body ground



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



Chassis Harness

- (C1) GY/4 : To (B11)
 - (C2) GY/8 : To (B112)
 - * (C3) GY/8 : To (B113)
 - * (C4) GY/3 : EVAP control system pressure sensor (with KA24DE)
 - * (C4) BR/3 : EVAP control system pressure sensor (except with KA24DE)
 - (C5) † GY/2 : Rear wheel sensor (2WD)
 - (C5) †† GY/4 : Rear wheel sensor (4WD)
 - * (C6) G/2 : Vacuum cut valve bypass valve
 - * (C7) B/2 : EVAP canister vent control valve
 - (C8) GY/2 : License plate lamp assembly
 - (C9) GY/4 : To (C10) (with trailer tow)
- Trailer Tow Sub Harness
- (C10) GY/4 : To (C9) (with trailer tow)
 - (C10) B/4 : SAE J1239 trailer tow connector (with trailer tow)

WEL155B


HARNESS LAYOUT

Room Lamp Harness

Room Lamp Harness

NGEL0202

- Ⓡ1 W/10 : To Ⓜ2
- Ⓡ2 W/2 : Front room lamp
- Ⓡ3 W/2 : Rear room lamp
- Ⓡ4 W/2 : Map lamp (with map lamp)
- Ⓡ5 W/8 : Compass and thermometer




WEL156B

HARNESS LAYOUT

Front Door Harness


NGEL0182

- D1 W/12 : To M9
- D2 W/12 : To M8
- D3 BR/2 : Door speaker LH
- D4 BR/3 : Door mirror LH
- D6 B/2 : Front power window motor LH (with power windows)
- D7 W/16 : Main power window and door lock/unlock switch (with power windows)
- D8 GY/4 : Front door lock actuator LH (with power door locks)
- D9 BR/3 : Front door lock key cylinder switch LH (with power door locks)
- D10 W/10 : Door mirror switch



WEL928A

- D101 W/12 : To M63
- D102 W/6 : To M64
- D103 BR/2 : Door speaker RH
- D104 BR/3 : Door mirror RH
- D106 B/2 : Power window motor RH (with power windows)
- D107 BR/6 : Door lock/unlock switch RH (with power door locks)
- D108 GY/4 : Front door lock actuator RH (with power door locks)
- D110 W/6 : Front power window switch RH (with power windows)



WEL929A


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Rear Door Harness


Rear Door Harness

NGEL0183



- (D201) W/8 : To (B5)
- (D202) B/2 : Rear power window motor LH (with power windows)
- (D203) W/6 : Rear power window switch LH (with power windows)
- (D204) GY/4 : Rear door lock actuator LH (with power door locks)

LEL147A



- (D301) W/8 : To (E105)
- (D302) B/2 : Rear power window motor RH (with power windows)
- (D303) W/6 : Rear power window switch RH (with power windows)
- (D304) GY/4 : Rear door lock actuator RH (with power door locks)


LEL148A

HARNESS LAYOUT

Back Door Harness

Back Door Harness

NGEL0199



Back Door No. 2 Harness

- (D401) W/18 : To (B11)
or
W/12
- (D402) — : Body ground
- (D403) W/18 : To (D501)
or
W/12
- (D404) — : Body ground
- (D405) B/2 : Rear power socket

Back Door Harness

- (D501) W/18: To (D403)
or
W/12
- (D502) B/1 : Rear window defogger (+)
- (D503) W/2 : High mounted stop lamp
- (D504) B/2 : Back door switch
- (D505) W/4 : Rear wiper motor (with rear wiper)
- (D506) BR/3 : Back door key cylinder switch (with power door locks)
- (D507) B/1 : Rear window defogger (-)
- (D508) GY/4 : Back door lock actuator (with power door locks)

WEL655A

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

BULB SPECIFICATIONS

Headlamp

| Headlamp | | |
|-----------------------------|-------------|------------|
| Item | Wattage (W) | Bulb No.* |
| High/Low (Semi-sealed beam) | 65/55 | 9007 (HB5) |

NGEL0144S03

*: Always check with the Parts Department for the latest parts information.

Exterior Lamp

| Item | Wattage (W) | Bulb No.* | |
|------------------------|------------------|-----------|--------|
| Front fog lamp | 55 | H3 | |
| Front turn signal lamp | 27 | 1156A | |
| Parking lamp | 3.8 | 194 | |
| Rear combination lamp | Turn signal lamp | 27 | 3157AK |
| | Stop/Tail lamp | 27/7 | 3057K |
| | Back-up lamp | 16 | 921 |
| License plate lamp | 3.8 | 168 | |
| High-mounted stop lamp | 12.8 | 912 | |

NGEL0144S01

*: Always check with the Parts Department for the latest parts information.

Interior Lamp

| Item | Wattage (W) | Bulb No.* |
|--|-------------|-----------|
| Room lamp | 8 | 82 |
| Map lamp (with compass and thermometer) | 8 | 168 |
| Map lamp (without compass and thermometer) | 8 | 82 |

NGEL0144S02

*: Always check with the Parts Department for the latest parts information.

WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

| Code | Section | Wiring Diagram Name |
|--------|---------|---|
| 1STSIG | AT | A/T 1ST Signal |
| 2NDSIG | AT | A/T 2ND Signal |
| 3RDSIG | AT | A/T 3RD Signal |
| 4THSIG | AT | A/T 4TH Signal |
| A/C | HA | Air Conditioner |
| AAC/V | EC | IACV-AAC Valve |
| ABS | BR | Anti-lock Brake System |
| ASCD | EL | Automatic Speed Control Device |
| AT/C | EC | A/T Control |
| ATDIAG | EC | A/T Diagnosis Communication Line |
| AUDIO | EL | Audio |
| BA/FTS | AT | A/T Fluid Temperature Sensor and Transmission Control Module (TCM) Power Supply |
| BACK/L | EL | Back-up Lamp |
| BYPS/V | EC | Vacuum Cut Valve Bypass Valve |
| CHARGE | SC | Charging System |
| CHIME | EL | Warning Chime |
| CIGAR | EL | Cigarette Lighter |
| CKPS | EC | Crankshaft Position Sensor (OBD) |
| CMPS | EC | Camshaft Position Sensor |
| COMPAS | EL | Compass and Thermometer |
| D/LOCK | EL | Power Door Lock |
| DEF | EL | Rear Window Defogger |
| DTRL | EL | Headlamp - With Daytime Light System |
| ECTS | EC | Engine Coolant Temperature Sensor |
| EGRC1 | EC | EGR Function (KA24DE) |
| EGRC/V | EC | EGRC - Solenoid Valve (KA24DE) |
| EGR/TS | EC | EGR Temperature Sensor |
| ENGSS | AT | Engine Speed Signal |
| F/FOG | EL | Front Fog Lamp |
| FLS1 | EC | Fuel Level Sensor Unit |

| Code | Section | Wiring Diagram Name |
|--------|---------|---|
| FLS2 | EC | Fuel Level Sensor Unit |
| FLS3 | EC | Fuel Level Sensor Unit |
| F/PUMP | EC | Fuel Pump |
| FICD | EC | IACV-FICD Solenoid Valve |
| FTTS | EC | Fuel Tank Temperature Sensor |
| FTS | AT | A/T Fluid Temperature Sensor |
| FUEL | EC | Fuel Injection System Function (KA24DE) |
| FUELB1 | EC | Fuel Injection System Function (Bank 1) (VG33E and VG33ER) |
| FUELB2 | EC | Fuel Injection System Function (Bank 2) (VG33E and VG33ER) |
| H/LAMP | EL | Headlamp |
| HO2S1 | EC | Heated Oxygen Sensor 1 (Front) (KA24DE) |
| HO2S2 | EC | Heated Oxygen Sensor 2 (Rear) (KA24DE) |
| HO2S2H | EC | Heated Oxygen Sensor 2 Heater (Rear) (KA24DE) |
| HO2SH | EC | Heated Oxygen Sensor 1 Heater (Front) (KA24DE) |
| HORN | EL | Horn |
| IATS | EC | Intake Air Temperature Sensor |
| IGN/SG | EC | Ignition Signal |
| ILL | EL | Illumination |
| INJECT | EC | Injector |
| KEYLES | EL | Remote Keyless Entry System |
| KS | EC | Knock Sensor |
| LPSV | AT | Line Pressure Solenoid Valve |
| MAFS | EC | Mass Air Flow Sensor |
| MAIN | AT | Main Power Supply and Ground Circuit |
| MAIN | EC | Main Power Supply and Ground Circuit |
| METER | EL | Speedometer, Tachometer, Temp., Oil and Fuel Gauges |
| MIL/DL | EC | MIL and Data Link Connector |
| MIRROR | EL | Door Mirror |
| NONDTC | AT | Non-detectable Items |
| O2H1B1 | EC | Heated Oxygen Sensor 1 (Front) Heater Bank 1 (VG33E and VG33ER) |

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WIRING DIAGRAM CODES (CELL CODES)

| Code | Section | Wiring Diagram Name | Code | Section | Wiring Diagram Name |
|--------|---------|---|--------|---------|--|
| O2H1B2 | EC | Heated Oxygen Sensor 1 (Front) Heater Bank 2 (VG33E and VG33ER) | TP/SW | EC | Throttle Position Switch |
| O2H2B1 | EC | Heated Oxygen Sensor 2 (Rear) Heater Bank 1 (VG33E and VG33ER) | TPS | AT | Throttle Position Sensor |
| O2H2B2 | EC | Heated Oxygen Sensor 2 (Rear) Heater Bank 2 (VG33E and VG33ER) | TPS | EC | Throttle Position Sensor |
| O2S1B1 | EC | Heated Oxygen Sensor 1 (Front) Bank 1 (VG33E and VG33ER) | TRSA/T | AT | Turbine Revolution Sensor |
| O2S1B2 | EC | Heated Oxygen Sensor 1 (Front) Bank 2 (VG33E and VG33ER) | TURN | EL | Turn Signal and Hazard Warning Lamps |
| O2S2B1 | EC | Heated Oxygen Sensor 2 (Rear) Bank 1 (VG33E and VG33ER) | VEHSEC | EL | Vehicle Security System |
| O2S2B2 | EC | Heated Oxygen Sensor 2 (Rear) Bank 2 (VG33E and VG33ER) | VENT/V | EC | EVAP Canister Vent Control Valve |
| OVRCSV | AT | Overrun Clutch Solenoid Valve | VSS | EC | Vehicle Speed Sensor |
| PGC/V | EC | EVAP Canister Purge Volume Control Solenoid Valve | VSSAT | AT | Vehicle Speed Sensor A/T (Revolution Sensor) |
| PNP/SW | AT | Park/Neutral Position Switch | VSSMTR | AT | Vehicle Speed Sensor MTR |
| PNP/SW | EC | Park/Neutral Position Switch | WARN | EL | Warning Lamps |
| POWER | EL | Power Supply Routing | WINDOW | EL | Power Window |
| PRE/SE | EC | EVAP Control System Pressure Sensor | WIP/R | EL | Rear Wiper and Washer |
| PST/SW | EC | Power Steering Oil Pressure Switch | WIPER | EL | Front Wiper and Washer |
| ROOM/L | EL | Interior Room Lamp | | | |
| S/CHGR | EC | Supercharger bypass valve control solenoid valve (VG33ER) | | | |
| S/SIG | EC | Start Signal | | | |
| SHIFT | AT | A/T Shift Lock System | | | |
| SRS | RS | Supplemental Restraint System | | | |
| SSV/A | AT | Shift Solenoid Valve A | | | |
| SSV/B | AT | Shift Solenoid Valve B | | | |
| START | SC | Starting System | | | |
| STOP/L | EL | Stop lamp | | | |
| SW/V | EC | MAP/BARO Switch Solenoid Valve | | | |
| T/TOW | EL | Trailer Tow | | | |
| TAIL/L | EL | Parking, License and Tail Lamps | | | |
| TCCSIG | AT | A/T TCC Signal (Lock Up) | | | |
| TCV | AT | Torque Converter Clutch Solenoid Valve | | | |