

ALPHABETICAL INDEX

SECTION **IDX**

A B C D E F G H I J K L M

N O P Q R S T U V W X Y Z

GI
MA
EM
LG
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL

ALPHABETICAL INDEX

A

<p>AAC/V - Wiring diagram.....EC-428</p> <p>ABS (anti-lock brake system).....BR-34</p> <p>ABS - Wiring diagramBR-39</p> <p>Absolute pressure sensorEC-161</p> <p>A/C air flow (auto A/C)HA-21</p> <p>A/C air flow (manual A/C)HA-137</p> <p>A/C component layout (auto A/C)HA-15</p> <p>A/C component layout (manual A/C)HA-135</p> <p>A/C compressor clutch removal and installation (auto A/C).....HA-111</p> <p>A/C compressor clutch removal and installation (manual A/C).....HA-195</p> <p>A/C compressor precaution (auto A/C)HA-7</p> <p>A/C compressor precaution (manual A/C).....HA-127</p> <p>A/C compressor special service tool (auto A/C).....HA-10</p> <p>A/C compressor special service tool (manual A/C).....HA-130</p> <p>A/C control linkage adjustment (manual A/C).....HA-154, 160</p> <p>A/C control operation (auto A/C).....HA-19</p> <p>A/C control operation (manual A/C)HA-136</p> <p>A/C diagnostic work flow (auto A/C)HA-41</p> <p>A/C diagnostic work flow (manual A/C).....HA-146</p> <p>A/C HFC134a (R134a) system precaution (auto A/C).....HA-3</p> <p>A/C HFC134a (R134a) system precaution (manual A/C).....HA-123</p> <p>A/C HFC134a (R134a) system service procedure (auto A/C)HA-105</p> <p>A/C HFC134a (R134a) system service procedure (manual A/C)HA-190</p> <p>A/C HFC134a (R134a) system service tools (auto A/C).....HA-11</p> <p>A/C HFC134a (R134a) system service tools (manual A/C).....HA-131</p> <p>A/C HFC134a system service equipment precaution (auto A/C)HA-7</p> <p>A/C HFC134a system service equipment precaution (manual A/C).....HA-127</p> <p>A/C lubricant (R134a) (auto A/C)HA-107</p> <p>A/C lubricant (R134a) (manual A/C)HA-192</p> <p>A/C operational check (auto A/C)HA-42</p> <p>A/C operational check (manual A/C).....HA-147</p> <p>A/C performance chart (auto A/C)HA-83</p> <p>A/C performance chart (manual A/C).....HA-184</p> <p>A/C performance test diagnoses (auto A/C).....HA-81</p> <p>A/C performance test diagnoses (manual A/C).....HA-182</p> <p>A/C push control (manual A/C)HA-136</p> <p>A/C relay (auto A/C)HA-79</p> <p>A/C relay (manual A/C)HA-179</p> <p>A/C self-diagnoses (auto A/C).....HA-31</p> <p>A/C service data specification (auto A/C).....HA-122</p>	<p>A/C service data specification (manual A/C).....HA-207</p> <p>A/C system description (auto A/C).....HA-19</p> <p>A/C trouble diagnoses (auto A/C)HA-23</p> <p>A/C, A - Wiring diagramHA-26</p> <p>A/C, M - Wiring diagramHA-142</p> <p>Accelerator control systemFE-3</p> <p>Accelerator wire adjustmentFE-3</p> <p>Air bagRS-13</p> <p>Air bag disposal.....RS-26</p> <p>Air bag precautionsGI-3</p> <p>Air bleeding (hydraulic clutch)CL-7</p> <p>Air bleeding for brake systemBR-8</p> <p>Air cleaner filter replacement.....MA-18</p> <p>Air conditioner cut controlEC-32</p> <p>Air flow meter - See Mass air flow sensorEC-152</p> <p>Air mix door control linkage adjustment (auto A/C).....HA-56</p> <p>Air mix door control linkage adjustment (manual A/C).....HA-165</p> <p>Air mix. door motor (auto A/C).....HA-54, 104</p> <p>Air mix. door motor (manual A/C)HA-162</p> <p>Air spoiler, rear.....BT-33</p> <p>AlternatorSC-13</p> <p>Ambient sensor (auto A/C).....HA-92</p> <p>Angular tightening application.....EM-3</p> <p>Antenna - See Power antennaEL-135</p> <p>Anti-lock brake system - See ABSBR-34</p> <p>Anti-lock brake system - Wiring diagram.....BR-39</p> <p>AP/SEN - Wiring diagramEC-162</p> <p>ASCD (automatic speed control device)EL-146</p> <p>ASCD - Wiring diagramEL-150</p> <p>A/T - Wiring diagram - AT - FTSAT-112</p> <p>A/T - Wiring diagram - AT - MAIN.....AT-102</p> <p>A/T - Wiring diagram - AT - PNP/SW.....AT-106</p> <p>A/T - Wiring diagram - AT - VSS A/TAT-118</p> <p>A/T controlEC-442</p> <p>A/T diagnosis communication line.....EC-565</p> <p>A/T fluid temperature sensor.....AT-115</p> <p>A/T shift lock systemAT-269</p> <p>A/T shift lock system - Wiring diagramAT-270</p> <p>A/T trouble diagnosesAT-56</p> <p>A/T Wiring diagram - AT - ENG SSAT-122</p> <p>A/T Wiring diagram AT - 1STAT-128</p> <p>A/T Wiring diagram AT - 2NDAT-135</p> <p>A/T Wiring diagram AT - 3RDAT-141</p> <p>A/T Wiring diagram AT - 4TH.....AT-148</p> <p>A/T Wiring diagram AT - BA/FTSAT-207</p> <p>A/T Wiring diagram AT - LPSVAT-173</p> <p>A/T Wiring diagram AT - NONDTCAT-220</p> <p>A/T Wiring diagram AT - OVRCSVAT-201</p> <p>A/T Wiring diagram AT - SSV/AAT-180</p> <p>A/T Wiring diagram AT - SSV/BAT-186</p> <p>A/T Wiring diagram AT - TCCSIGAT-163</p> <p>A/T Wiring diagram AT - TCVAT-156</p> <p>A/T Wiring diagram AT - TPS.....AT-193</p> <p>A/T Wiring diagram AT - VSSMTR.....AT-214</p> <p>AT/C - Wiring diagram.....EC-443</p> <p>ATDIAG - Wiring diagram.....EC-566</p>
--	--

ALPHABETICAL INDEX

Audio	EL-130
AUDIO - Wiring diagram	EL-131
Audio and A/C control removal and installation - See Instrument panel	BT-22
Auto air conditioner - Wiring diagram	HA-26
Automatic amplifier	HA-29
Automatic amplifier (auto A/C)	HA-45
Automatic speed control system - See ASCD	EL-146
Automatic transaxle number	GI-44
Automatic transmission fluid replacement	MA-23
Auxiliary air control (AAC) valve	EC-425

B

Back door	BT-16
Back door opener - See Back door	BT-16
Back-up lamp	EL-59
Back-up lamp switch (M/T)	MT-10
BACK/L - Wiring diagram	EL-59
Ball joint (front)	SU-14
Base idle air volume initialiging	EC-65
Basic inspection	EC-106
Battery	SC-3
Baulk ring (M/T)	MT-17
Blower motor (auto A/C)	HA-65
Blower motor (manual A/C)	HA-172
Blower resistor (manual A/C)	HA-172
Blower unit (auto A/C)	HA-115
Blower unit (manual A/C)	HA-200
Board-on lift	GI-46
Body alignment	BT-56
Boring/horning cylinder block	EM-62
Brake booster	BR-17
Brake fluid change	BR-7
Brake fluid level	MA-24
Brake fluid level and line check	BR-7
Brake hydraulic line	BR-9
Brake inspection	MA-24
Brake lines and cables inspection	MA-24
Brake master cylinder	BR-14
Brake pedal	BR-12
Bulb specifications	EL-329
Bumper, front	BT-13
Bumper, rear	BT-16
BYPS/V - Wiring diagram	EC-549, 556

C

Camshaft inspection	EM-36
Camshaft position sensor (CMPS)	EC-327
Canister-See EVAP canister	EC-33
CHARGE - Wiring diagram	SC-11
Charging system	SC-10
Chassis and body maintenance	MA-22
CHIME - Wiring diagram	EL-107
CIGAR - Wiring diagram	EL-120

Cigarette lighter	EL-120
Circuit breaker	EL-17
CKPS - Wiring diagram	EC-323, 478
Closed loop control	EC-449
Closed throttle position switch	EC-434
Clutch cover	CL-19
Clutch damper	CL-11
Clutch disc	CL-19
Clutch fluid level	MA-22
Clutch master cylinder	CL-8
Clutch operating cylinder	CL-13
Clutch pedal	CL-6
Clutch release bearing	CL-16
Clutch release mechanism	CL-16
Clutch withdrawal lever	CL-16
CMPS - Wiring diagram	EC-330
Coil spring (front)	SU-9
Coil spring (rear)	SU-23
Collision diagnosis	RS-65
Combination lamp, front, removal and installation	BT-13
Combination lamp, rear, removal and installation	BT-33
Combination meter	EL-83
Combination meter removal and instal- lation - See Instrument panel	BT-22
Combination switch	EL-26
Component Location (auto A/C)	HA-23
Component Location (manual A/C)	HA-139
Compressor clutch removal and instal- lation (auto A/C)	HA-111
Compressor clutch removal and instal- lation (manual A/C)	HA-195
Compressor precaution (auto A/C)	HA-7
Compressor precaution (manual A/C)	HA-127
Compressor special service tool (auto A/C)	HA-10
Compressor special service tool (manual A/C)	HA-130
Connecting rod	EM-61
Connecting rod bearing clearance	EM-65
Connecting rod bushing clearance	EM-66
Connector inspection	GI-22
Console box - See Instrument panel	BT-22
CONSULT for ABS	BR-44
CONSULT for engine	EC-88
Control lever (M/T)	MT-15
Control valve (A/T)	AT-309
Converter housing installation	AT-281
COOL/F - Wiring diagram	EC-297, 454
Coolant mixture ratio	MA-12
Coolant replacement	MA-14
Cooling circuit (engine)	LC-9
Cooling fan control	EC-451
Cooling fan motor	EC-468
Cooling fan relay	EC-467
Cooling unit (A/C evaporator) (auto A/C)	HA-116
Cooling unit (A/C evaporator) (manual A/C)	HA-201
Coupling sleeve (M/T)	MT-17

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ALPHABETICAL INDEX

Crank angle sensor built into distributor
 - See Camshaft position sensorEC-327
 “Crankcase emission control system -
 See positive crankcase ventilation”EC-48
 Crankcase ventilation system - See
 Positive crankcase ventilationEC-48
 CrankshaftEM-63
 Crankshaft position sensor (OBD)EC-321, 476
 Crankshaft position sensor (OBD) cog
 chippingEC-476
 Cruise control - See ASCDEL-146
 Cylinder blockEM-58
 Cylinder block boringEM-62
 Cylinder headEM-30

D

Data link connector for ConsultEC-50, 88
 Daytime light systemEL-42
 Daytime running light - See Daytime
 light systemEL-42
 DEF - Wiring diagramEL-123
 Detonation sensor - See Knock sensorEC-317
 Diagnosis sensor unitRS-18
 Diagnostic trouble code (DTC) for OBD
 systemEC-8, 68
 Diagnostic trouble code (DTC) inspec-
 tion priority chartEC-122
 Differential gear (FF A/T)AT-358
 Differential gear (FF M/T)MT-17
 DimensionsGI-45
 DistributorEC-31
 Distributor ignition (DI) systemEC-31
 D/LOCK - Wiring diagramEL-178
 Dome light - See Interior lampEL-77
 Door glassBT-19
 Door lockBT-19
 Door mirrorBT-54
 Door trimBT-28
 Door, frontBT-19
 Door, rearBT-21
 Drive belt inspectionMA-13
 Drive plate runoutEM-67
 Drive shaft (front)AX-10
 Dropping resistor (A/T)AT-177
 DTC work supportEC-98
 DTRL - Wiring diagramEL-46

E

ECM input/output signalEC-133
 ECTS - Wiring diagramEC-174, 193
 EGR temperature sensorEC-482
 EGR/TS - Wiring diagramEC-485
 EGRC1 - Wiring diagramEC-339, 348, 494
 Electric sun roofEL-140
 Electrical diagnosesGI-25
 Electrical ignition systemEC-31

Electrical unitFoldout
 Electrical units locationEL-309
 Electronic ignition (EI) systemEC-31
 Engine compartmentBT-57
 Engine control circuit diagramEC-24
 Engine control component parts
 locationEC-20
 Engine control module (ECM)EC-445
 Engine control system diagram and
 chartEC-26
 Engine coolant temperature sensor
 (ECTS)EC-172, 191
 Engine fail-safe systemEC-123
 Engine oil filter replacementMA-19
 Engine oil precautionsGI-7
 Engine oil replacementMA-18
 Engine outer component partsEM-10
 Engine removalEM-55
 Engine room - See Engine
 compartmentBT-57
 Engine serial numberGI-44
 EVAP canisterEC-34
 EVAP canister purge volume control
 solenoid valveEC-370, 502
 EVAP canister vent control
 valveEC-377, 514, 534
 EVAP control system (small leak)
 diagnosisEC-36, 356, 397, 500
 EVAP control system pressure sensorEC-384
 EVAP control system purge flow moni-
 toring diagnosisEC-522
 EVAP system close modeEC-36
 EVAP vapor lines inspectionMA-21
 Evaporative emission (EVAP) systemEC-33
 Exhaust gas recirculation (EGR)
 valveEC-335, 491
 Exhaust systemFE-8
 Exhaust system inspectionMA-22
 ExteriorBT-33

F

Fan control amp. (auto A/C)HA-67
 Fan switch (manual A/C)HA-172
 F/FOG - Wiring diagramEL-62
 Final drive (FF A/T)AT-358
 Final drive (FF M/T)MT-39
 Finisher, interior - See TrimBT-26
 Fluid temperature sensor (A/T)AT-115
 FluidsMA-11
 Flywheel (clutch)CL-19
 Flywheel runoutEM-67
 Fog lamp, frontEL-60
 Fog lamp, front, removal and
 installationBT-13
 Fork rod (M/T)MT-18
 Forward clutchAT-333
 F/PUMP - Wiring diagramEC-586
 Freeze frame dataEC-68
 FRO2 - Wiring diagramEC-200, 221, 229

ALPHABETICAL INDEX

FRO2/H - Wiring diagramEC-235
 Front axle.....AX-2
 Front bumperBT-13
 Front combination lamp removal and installationBT-13
 Front disc brakeBR-20
 Front doorBT-19
 Front fog lamp.....EL-60
 Front fog lamp removal and installationBT-13
 Front heated oxygen sensor (HO2S)EC-197, 205, 211, 218, 227
 Front heated oxygen sensor (HO2S) heater.....EC-233
 Front seatBT-39
 Front seat beltRS-5
 Front suspension.....SU-2
 Front washerEL-114
 Front wiperEL-114
 FUEL - Wiring diagramEC-275, 282
 Fuel cut control (at no load & high engine speed).....EC-33
 Fuel filler lid.....BT-16
 Fuel filter.....EC-50
 Fuel filter replacementMA-17
 Fuel gaugeEL-83
 Fuel injection systemEC-273, 280
 Fuel injector.....EC-575
 Fuel line inspectionMA-16
 Fuel precautionsGI-8
 Fuel pressure check.....EC-50
 Fuel pressure regulatorEC-51
 Fuel pressure releaseEC-50
 Fuel pumpEC-584
 Fuel pump relayEC-584
 Fuel systemFE-5
 Fuel tank temperature sensorEC-287
 Fuel tank vacuum relief valveEC-34
 FuseEL-17
 Fuse blockFoldout
 Fusible linkEL-17

G

Garage jack and safety standGI-47
 Gauges.....EL-83
 Gear components (M/T)MT-17
 Generator - See Alternator.....SC-13
 Generic scan tool (GST)EC-100
 GlassBT-19
 Grease.....MA-11
 Ground distribution.....EL-18

H

Harness connector.....EL-5
 Harness connector inspectionGI-22
 Harness layoutEL-313
 Hazard warning lamp.....EL-65

Headlamp.....EL-30
 Headlining - See Roof trimBT-30
 Heated oxygen sensor (HO2S) (front).....EC-197, 205, 211, 218, 227
 Heated oxygen sensor (HO2S) heater (front)EC-233
 Heated oxygen sensor (HO2S) heater (rear)EC-268
 Heated oxygen sensor (rear).....EC-238, 246, 254, 262
 Heated seat.....BT-41, EL-145
 Heater unit (heater core) (auto A/C).....HA-114
 Heater unit (heater core) (manual A/C).....HA-199
 Height (Dimensions).....GI-45
 HFC134a (R134a) system precaution (auto A/C).....HA-3
 HFC134a (R134a) system precaution (manual A/C).....HA-123
 HFC134a (R134a) system service procedure (auto A/C)HA-105
 HFC134a (R134a) system service procedure (manual A/C).....HA-190
 HFC134a (R134a) system service tools (auto A/C).....HA-11
 HFC134a (R134a) system service tools (manual A/C).....HA-131
 HFC134a system service equipment precaution (auto A/C).....HA-7
 HFC134a system service equipment precaution (manual A/C).....HA-127
 High clutch.....AT-328
 H/LAMP - Wiring diagramEL-34
 Hood.....BT-13
 Horn.....EL-119
 HORN - Wiring diagramEL-119
 How to erase DTC for OBD system.....EC-79
 HSEAT - Wiring diagram.....EL-145
 Hydraulic lash adjuster inspectionEM-41

I

IACV-AAC valveEC-425
 IATS - Wiring diagramEC-168
 Identification plate.....GI-44
 Idle air control (IAC) systemEC-425
 Idle air control valve (IACV)EC-425
 Idle mixture ratio.....EC-53
 Idle speed.....EC-53
 IGN/SG - Wiring diagramEC-471
 Ignition coilEC-475
 Ignition control systemEC-469
 Ignition timingEC-53
 Ignition wire inspection.....EC-316
 ILL - Wiring diagramEL-73
 IlluminationEL-70
 In vehicle sensor (auto A/C).....HA-95
 INFINITI COMMUNICATOR.....EL-271
 Infiniti communicator (IVCS)EL-271
 INJECT - Wiring diagramEC-576
 Injector removal and installationEC-51

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ALPHABETICAL INDEX

Input shaft (FF M/T)MT-26
 Instrument panelBT-22
 INT/L - Wiring diagram.....EL-82
 Intake air temperature sensorEC-166
 Intake door control linkage adjustment
 (auto A/C).....HA-64
 Intake door control linkage adjustment
 (manual A/C).....HA-154
 Intake door motor (auto A/C)HA-58
 Intake door motor (manual A/C).....HA-151
 Integrated homelink transmitterEL-268
 InteriorBT-26
 Interior lamp.....EL-77, 81
 Interior lamp on-off control.....EL-78
 IVCS - Wiring diagram.....EL-282
 IVIS (Infiniti vehicle immobiliser sys-
 tem) precautionsGI-3
 IVIS (Infiniti vehicle immobilizer
 system).....EL-248

J

Jacking pointsGI-47
 Joint connector (J/C)Foldout
 Junction box (J/B).....Foldout

K

Keyless entry system - See Multi-re-
 mote control system.....EL-190
 Knock sensor (KS)EC-317, 318
 Knuckle spindleAX-5

L

Length (Dimensions)GI-45
 License lampEL-52
 Lifting pointsGI-48
 Line pressure solenoid valveAT-153
 Line pressure test (A/T)AT-66
 Liquid gasket applicationEM-3
 LOAD - Wiring diagram.....EC-603
 Location of electrical unitsEL-309
 Lock, doorBT-19
 Low and reverse brakeAT-340
 Lubricant (R134a) A/C (auto A/C)HA-107
 Lubricant (R134a) A/C (manual A/C)HA-192
 LubricantsMA-11
 Lubrication circuit (engine)LC-3
 Lubrication-locks, hinges and hood
 latchesMA-26
 Luggage room lamp.....EL-81

M

MAFS - Wiring diagram.....EC-156
 Magnet clutch (auto A/C).....HA-73, 111
 Magnet clutch (manual A/C).....HA-195
 MAIN - Wiring diagram.....EC-146
 Mainshaft (M/T)MT-31
 Maintenance (engine)MA-13
 MAJOR OVERHALL.....AT-283
 Malfunction indicator lamp (MIL).....EC-81
 Manual air conditioner - Wiring diagram.....HA-142
 Manual transaxle number.....GI-44
 Manual transmission oil replacementMA-22
 Mass air flow sensor (MAFS).....EC-152
 Master cylinder (brake)BR-14
 Master cylinder (clutch)CL-8
 MeterEL-83
 METER - Wiring diagram.....EL-86
 MIL & Data link connectors circuitEC-610
 MIL/DL - Wiring diagramEC-610
 MIRROR - Wiring diagram.....EL-143
 Mirror defoggerEL-121
 Mirror, door.....BT-54
 Mirror, out sideBT-54
 MisfireEC-310
 Mode door control linkage adjustment
 (auto A/C).....HA-53
 Mode door control linkage adjustment
 (manual A/C).....HA-160
 Mode door motor (auto A/C)HA-48
 Mode door motor (manual A/C)HA-156
 Model variationGI-42
 Molding - See ExteriorBT-33
 M/T major overhaulMT-15
 M/T removal and installationMT-12
 MULTI - Wiring diagram.....EL-194
 Multi-remote control system.....EL-190
 Multiport fuel injection (MFI) systemEC-29
 Multiport fuel injection precautions.....GI-6

N

NATS (Nissan anti-theft system)
 precautionsGI-3
 NATS - Wiring diagramEL-250
 Neutral position switchEC-568
 NVH troubleshooting (AX)AX-3
 NVH troubleshooting (BR).....BR-6
 NVH troubleshooting (CL)CL-4
 NVH troubleshooting (M/T)MT-6
 NVH troubleshooting (ST).....ST-5
 NVH troubleshooting (SU).....SU-17

O

Oil change (capacity)MA-11
 Oil pan (engine)EM-14

ALPHABETICAL INDEX

Oil pressure (engine)	LC-4
Oil pump (A/T)	AT-305
Oil pump (engine)	LC-4
Oil pump regulator valve (engine)	LC-6
Oil seal replacement (engine)	EM-28
On board diagnostic system	EC-67
Operating cylinder (clutch)	CL-13
ORVR (On-board Refueling Vapor Recovery)	EC-39
Out side mirror	BT-54
Overdrive control switch	AT-267
Overrun clutch	AT-333
Oversize piston	EM-62

P

P/ANT - Wiring diagram	EL-136
Park/Neutral position switch	EC-568
Park/neutral position switch (A/T)	AT-104
Park/neutral position switch (M/T)	MT-10
Parking brake control	BR-32
Parking lamp	EL-52
PCV (positive crankcase ventilation)	EC-48
PGC/V - Wiring diagram	EC-373, 505
Pilot bushing replacement	EM-66
Piston assembly	EM-67
Piston pin inspection	EM-59
Piston ring inspection	EM-60
Piston to bore clearance	EM-62
PNP/SW - Wiring diagram	EC-570
POWER - Wiring diagram	EL-10
Power antenna	EL-135
Power door lock	EL-176
Power door mirror	EL-143
Power seat	EL-144
Power steering fluid level	MA-25, ST-7
Power steering gear	ST-15
Power steering hydraulic pressure	ST-8
Power steering oil pressure switch	EC-593
Power steering oil pump	ST-26
Power steering system bleeding	ST-7
Power supply routing	EL-9
Power transistor	EC-475
Power transistor & ignition coil	EC-469
Power window	EL-166
PRE/SE - Wiring diagram	EC-387
Precautions (General)	GI-4
Pressure plate - See Clutch cover	CL-19
Pressure test (A/T)	AT-66
PST/SW - Wiring diagram	EC-594

R

Radiator	LC-14
Radiator fan - See Cooling fan	LC-14
Radio - See Audio	EL-130
Rear air spoiler	BT-33
Rear axle	AX-20

Rear bumper	BT-16
Rear combination lamp removal and installation	BT-33
Rear disc brake	BR-24
Rear door	BT-21
Rear heated oxygen sensor (HO2S)	EC-238, 246, 254, 262
Rear heated oxygen sensor (HO2S) heater	EC-268
Rear seat	BT-42
Rear seat belt	RS-7
Rear suspension	SU-17
Rear window defogger	EL-121
Refrigerant pressure sensor (auto A/C)	HA-79
Refrigerant pressure sensor (manual A/C)	HA-180
Refrigerant connection precaution (auto A/C)	HA-4
Refrigerant connection precaution (manual A/C)	HA-124
Refrigerant discharging evacuating charging (auto A/C)	HA-105
Refrigerant general precaution (auto A/C)	HA-4
Refrigerant general precaution (manual A/C)	HA-124
Refrigerant lines (auto A/C)	HA-117
Refrigerant lines (manual A/C)	HA-202
Refrigerant pressure sensor	EC-598
Refrigeration cycle (auto A/C)	HA-14
Refrigeration cycle (manual A/C)	HA-134
Release bearing (clutch)	CL-16
Removal and installation (A/T)	AT-280
Resistor	EC-475
Reverse clutch	AT-324
Reverse idler shaft (M/T)	MT-16
Reverse lamp switch (M/T) - See Back-up lamp switch (M/T)	MT-10
Reverse main gear (M/T)	MT-17
Road wheel size	GI-45
Roof trim	BT-30
Room lamp - See Interior lamp	EL-77
ROOM/L - Wiring diagram	EL-79
RRO2 - Wiring diagram	EC-240, 248, 256, 264
RRO2/H - Wiring diagram	EC-270

S

SAE J1930 terminology list	GI-52
Seal - See Exterior	BT-33
SEAT - Wiring diagram	EL-144
Seat belt inspection	MA-26, RS-9
Seat belt pre-tensioner	RS-3
Seat belt pre-tensioner disposal	RS-26
Seat belt, front	RS-5
Seat belt, rear	RS-7
Seat, front	BT-39
Seat, rear	BT-42
SFT, RE - Wiring diagram	AT-270
SHIFT - Wiring diagram	AT-270

ALPHABETICAL INDEX

Shift control components (M/T).....	MT-18
Shift fork (M/T)	MT-18
Shift lever	MT-15
Shift lock system	AT-269
Shift schedule.....	AT-386
Shift solenoid valve A (A/T)	AT-125, 130, 143
Shift solenoid valve B (A/T)	AT-125, 130
Shock absorber (front)	SU-10
Shock absorber (rear)	SU-23
Side air bag	RS-24
Side trim.....	BT-26
Smart entrance control unit	EL-243
SMJ (super multiple junction)	Foldout
Spare tire size	GI-45
Spark plug replacement.....	MA-19
Speedometer.....	EL-83
Spiral cable.....	RS-20
Spot lamp	EL-81
Spring (Wheelarch) height	SU-5
SROOF - Wiring diagram	EL-141
SRS - See Supplemental Restraint System.....	RS-13
SRS - Wiring diagram	RS-38
S/SIG - Wiring diagram	EC-581
Stabilizer bar (front).....	SU-13
Stall test (A/T)	AT-62
Standardized relay	EL-7
START - Wiring diagram	SC-7
Start signal	EC-580
Starter.....	SC-9
Starting system.....	SC-6
Steering gear, linkage and transfer gear inspection.....	MA-25
Steering linkage	ST-15
Steering switch.....	EL-28
Steering wheel and column	ST-10
Steering wheel play	ST-6
Steering wheel turning force.....	ST-8
Stop lamp.....	EL-58
STOP/L - Wiring diagram.....	EL-58
Striking rod (M/T)	MT-18
Strut (front)	SU-9
Strut (rear)	SU-22
Sub-gear (M/T).....	MT-17
Sun roof, electric.....	EL-140
Sunload sensor (auto A/C).....	HA-99
Sunroof.....	BT-43
Supplemental Restraint System.....	RS-13
Supplemental restraint system - Wiring diagram	RS-38
Symbols and abbreviations	GI-9
Symptom matrix chart	EC-124
Synchronizer (M/T).....	MT-17
System readiness test (SRT) code	EC-69

T

Tachometer	EL-83
Tail lamp.....	EL-52
TAIL/L - Wiring diagram	EL-54

TCM circuit diagram.....	AT-15
TCM inspection table	AT-98
TFTS - Wiring diagram.....	EC-289
THEFT - Wiring diagram.....	EL-220
Theft warning system.....	EL-215
Thermal protector (auto A/C).....	HA-114
Thermal protector (manual A/C).....	HA-199
Thermostat.....	LC-12
Three way catalyst	EC-352
Three way catalyst precautions.....	GI-6
Throttle position sensor (TPS)	EC-178
Throttle position sensor adjustment.....	EC-106
Throttle position switch	EC-434, AT-198, 267
Throwout bearing - See Clutch release bearing	CL-16
Tie-rod ball joints.....	ST-19
Tightening torque of standard bolts.....	GI-51
Timing belt.....	EM-19
Tire rotation	MA-24
Tire size	GI-45
TLID - Wiring diagram	EL-139
Torque converter installation	AT-281
Tow truck towing.....	GI-49
TP/SW - Wiring diagram	EC-436
TPS - Wiring diagram.....	EC-184
Transmission case (M/T).....	MT-16
TRANSMT - Wiring diagram.....	EL-268
Tread-FR&RR (Dimensions).....	GI-45
Trim	BT-26
Trouble diagnoses	GI-35
Trunk room trim.....	BT-32
TURN - Wiring diagram	EL-67
Turn signal lamp	EL-65
Two trip detection logic	EC-67
Two-pole lift	GI-48

U

Under body	BT-59
------------------	-------

V

Vacuum cut valve bypass valve.....	EC-547, 553
Vacuum hose (brake system).....	BR-19
Vacuum hose drawing (Engine control)	EC-27
Valve guide.....	EM-38
Valve seat.....	EM-39
Valve spring.....	EM-41
Vehicle identification number.....	GI-43
Vehicle recovery (freeing a stuck vehicle).....	GI-50
Vehicle speed sensor (VSS)	EC-421
Vent mode switch (manual A/C).....	HA-136
VENT/V - Wiring diagram	EC-379, 516, 537
Viscosity number (SAE)	MA-11
Viscous coupling (FF A/T).....	AT-358
Viscous coupling (FF M/T)	MT-11

ALPHABETICAL INDEX

VSS - Wiring diagramEC-423

W

WARN - Wiring diagramEL-99
 Warning chimeEL-105
 Warning lampsEL-98
 Washer, frontEL-114
 Water cock control rod adjustment
 (manual A/C).....HA-165
 Water pumpLC-10
 Water temperature gaugeEL-83
 Weatherstrip - See ExteriorBT-33
 Wheel alignment (front)SU-6
 Wheel alignment (rear).....SU-19
 Wheel balanceMA-24
 Wheel bearing (front).....AX-3
 Wheel bearing (rear)AX-21

Wheel hub (front).....AX-5
 Wheel hub (rear)AX-21
 Wheel sensors (ABS).....BR-75 **GI**
 Wheel sizeGI-45
 Wheelarch heightSU-5
 Wheelbase (Dimensions)GI-45 **MA**
 Wide open & closed throttle position
 switchEC-178
 Width (Dimensions)GI-45 **EM**
 WINDOW - Wiring diagramEL-169
 Window, doorBT-19 **LC**
 Windshield.....BT-52 **LC**
 WIPER - Wiring diagram.....EL-116
 Wiper, front.....EL-114 **EC**
 Wiring Diagram (Cell code) list.....EL-330
 Wiring diagramsGI-11
 Withdrawal lever (clutch)CL-16 **FE**
 Wrist pin - See Piston pin inspection.....EM-59

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES