

SECTION **EX**
EXHAUST SYSTEM

A
EX
C
D
E
F
G
H
I
J
K
L
M

CONTENTS

| | | | | |
|--------------------------------------|----------|--------------------------------------|----------|---|
| PREPARATION | 2 | Removal and Installation | 4 | F |
| Special Service Tool | 2 | Inspection After Installation | 5 | |
| Commercial Service Tools | 2 | EXHAUST SYSTEM (VQ35DE) | 6 | G |
| EXHAUST SYSTEM (QR25DE) | 3 | Checking Exhaust System | 6 | |
| Checking Exhaust System | 3 | Removal and Installation | 7 | |
| | | Inspection After Installation | 8 | H |

PREPARATION

PFP:00002


EBS00J8J

PREPARATION

Special Service Tool

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|---|
| KV10114400 (J-38365) Heated oxygen sensor wrench | Loosening or tightening heated oxygen sensors: a: 22 mm (0.87 in) |




S-NT636


Commercial Service Tools

EBS00J8K


| (Kent-Moore No.) Tool name | Description |
|---|---|
| (J-43897-18) (J-43897-12) Oxygen sensor thread cleaner | Reconditioning the exhaust system threads before installing a new oxygen sensor (Use with anti-seize lubricant shown below): a: J-43897-18 (18 mm dia.) for zirconia oxygen sensor b: J-43897-12 (12 mm dia.) for titania oxygen sensor |
| Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907) | Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads |
| Power tool | Loosening nuts and bolts |



AEM488



AEM489



PBIC0190E

EXHAUST SYSTEM (QR25DE)


EXHAUST SYSTEM (QR25DE)

PF20100

Checking Exhaust System

EBS00JBL

Check the exhaust pipes, muffler, and mounting components for incorrect attachment, leaks, cracks, damage, or deterioration.



A

EX

C

D

E

F

G

H

I

J

K


L

M

EXHAUST SYSTEM (QR25DE)

EBS00J8M

Removal and Installation




WBIA0209E

- | | | |
|-------------------------------|--|------------------------|
| 1. Rear muffler | 2. Rear muffler bracket (ground strap) | 3. Center exhaust tube |
| 4. Center exhaust tube hanger | 5. Exhaust manifold | 6. Front exhaust tube |
| 7. Front exhaust tube spring | 8. Front exhaust tube hanger | 9. Seal bearing |
| 10. Gasket | | |

EXHAUST SYSTEM (QR25DE)

CAUTION:

- Use genuine NISSAN exhaust system parts or equivalent, which are specifically designed for heat resistance, corrosion resistance, and shape.
- Perform the procedure with the exhaust system fully cooled down because the system will be hot just after the engine is turned off.
- Be careful not to cut your hand on the insulator edges.
- If the insulator is badly deformed, repair or replace it. If deposits such as mud pile up on the insulator, clean and inspect the insulator.
- When installing the insulator avoid large gaps or interference between the insulator and each exhaust pipe.
- Remove deposits from the sealing surface of each connection. Connect them securely to avoid exhaust gas leaks.
- Temporarily tighten the exhaust manifold side mounting nuts and the vehicle side mounting bolts. Check each part for any interference, and then tighten the nuts and bolts to specification.
- When installing each mounting rubber, avoid twisting or excessive extension in up/down and right/left directions.
- Tighten the mounting bolts without causing interference with the flange.
- Insert the seal bearing in the direction as shown. Tighten the mounting bolt with the big end of the spring facing the flange as shown.



Inspection After Installation

EBS00J8N

- With the engine running, check the exhaust tube joints for exhaust gas leaks and abnormal noise.
- Check that the mounting brackets and mounting insulators are installed properly and free from excessive stress. Improper installation could result in excessive noise, leaks, and vibration.

EXHAUST SYSTEM (VQ35DE)


EXHAUST SYSTEM (VQ35DE)

PF20:20100

Checking Exhaust System

EBS00J80

Check the exhaust pipes, muffler, and mounting components for incorrect attachment, leaks, cracks, damage, or deterioration.




EXHAUST SYSTEM (VQ35DE)

EBS00J8P

Removal and Installation

SEC. 200



: N-m (kg-m, ft-lb)

: Always replace after every disassembly.

- | | | |
|----------------------------|-------------------------------|--|
| 1. RH rear muffler | 2. LH rear muffler | 3. RH rear muffler bracket with ground strap |
| 4. LH rear muffler bracket | 5. Center exhaust tube hanger | 6. Center exhaust tube |
| 7. Front exhaust tube | 8. Front exhaust tube hanger | 9. LH exhaust manifold |
| 10. RH exhaust manifold | 11. Gasket | |

WBIA0588E

EXHAUST SYSTEM (VQ35DE)

CAUTION:

- Use genuine NISSAN exhaust system parts or equivalent, which are specifically designed for heat resistance, corrosion resistance, and shape.
- Perform the procedures with the exhaust system fully cooled down because the system will be hot just after the engine is turned off.
- Be careful not to cut your hand on the insulator edge.
- Always replace the exhaust gaskets with new ones for installation.
- If any insulator is badly deformed, repair or replace it. If deposits such as mud pile up on the insulator, clean and inspect them.
- When installing the insulator avoid large gaps or interference between the insulator and the exhaust pipe.
- Remove any deposits from the sealing surface of each connection. Connect them securely to avoid exhaust gas leakage.
- Temporarily tighten the mounting nuts on the exhaust manifold side and the mounting bolts on the vehicle side. Check each part for interference with other components, and then tighten the nuts and bolts to specification.
- When installing each mounting rubber, avoid twisting or any over extension in up/down and right/left directions.

Inspection After Installation

EBS00J8Q

- With the engine running, check the exhaust tube joints for exhaust gas leaks and unusual noises.
- Check that the mounting brackets and mounting insulators are installed properly and free from excessive stress. Improper installation could result in excessive noise, leaks, and vibration.